

SOLIDWORKS API (.NET VBA C#) — Reference (297/337): IStructureSystemMemberProfile- IStructureSystemSplitMember

SOLIDWORKS API Documentation (converted from CHM)

IStructureSystemMemberProfile (Type)

IStructureSystemMemberProfile Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemMemberProfile Interface

Allows access to a structure system member profile.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IStructureSystemMemberProfile

Visual Basic (Usage)

Dim instance As [IStructureSystemMemberProfile](#)

C#

public interface IStructureSystemMemberProfile

C++/CLI

public interface class IStructureSystemMemberProfile

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

See the [IStructureSystemFolder](#) Remarks.

For more information, read the **SOLIDWORKS user-interface help > Weldments and Structure System > Structure System > Profile PropertyManager** topic.

Accessors

[IStructureSystemMemberFeatureData::MemberProfile](#)

Access Diagram

[StructureSystemMemberProfile](#)

See Also

[IStructureSystemMemberProfile Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IStructureSystemMemberProfile Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemMemberProfile Interface

For a list of all members of this type, see [IStructureSystemMemberProfile members](#).

Public Methods

Name	Description
 GetSketch	Gets the sketch that contains all of the pierce points used to define this structure system member profile.

[Top](#)

See Also

[IStructureSystemMemberProfile Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructureSystemMemberProfile Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemMemberProfile Interface

The following tables list the members exposed by [IStructureSystemMemberProfile](#).

Public Properties

Name	Description
 MirrorProfile	Gets and sets whether to flip the profile of this member about an axis.
 OffsetPiercePoint	Gets and sets whether to offset the pierce point of this member profile.
 OffsetPiercePointHorizontalAxis	Gets and sets the offset value of the pierce point in the horizontal direction.
 OffsetPiercePointHorizontalAxisFlip	Gets and sets whether to reverse the offset value of the pierce point in the horizontal direction.
 OffsetPiercePointVerticalAxis	Gets and sets the offset value of the pierce point in the vertical direction.
 OffsetPiercePointVerticalAxisFlip	Gets and sets whether to reverse the offset value of the pierce point in the vertical direction.
 PiercePointSelectionObject	Gets and sets the selected pierce point object for the sketch of this member profile.
 ProfileAlignmentAngle	Gets and sets the angle of alignment between this member profile and a specified entity.
 ProfileAlignmentObject	Gets and sets the entity with which to align an axis of this member profile.
 ProfileAlignmentObjectType	Gets the type of profile alignment entity.
 ProfileAlignmentType	Gets and sets the axis of alignment for this member profile.
 ProfileMirrorType	Gets and sets the axis about which to flip this member profile.
 ProfilePiercePointType	Gets and sets the type of pierce point used to define the sketch of this structure system member profile.
 ProfileSize	Gets the profile size for this member profile.
 ProfileStandard	Gets the profile standard for this member profile.
 ProfileType	Gets the profile type for this member profile.

[Top](#)

Public Methods

Name	Description
 GetSketch	Gets the sketch that contains all of the pierce points used to define this structure system member profile.

[Top](#)

See Also

[IStructureSystemMemberProfile Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructureSystemMemberProfile Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemMemberProfile Interface

For a list of all members of this type, see [IStructureSystemMemberProfile members](#).

 Public Properties

Name	Description
 MirrorProfile	Gets and sets whether to flip the profile of this member about an axis.
 OffsetPiercePoint	Gets and sets whether to offset the pierce point of this member profile.
 OffsetPiercePointHorizontalAxis	Gets and sets the offset value of the pierce point in the horizontal direction.
 OffsetPiercePointHorizontalAxisFlip	Gets and sets whether to reverse the offset value of the pierce point in the horizontal direction.
 OffsetPiercePointVerticalAxis	Gets and sets the offset value of the pierce point in the vertical direction.
 OffsetPiercePointVerticalAxisFlip	Gets and sets whether to reverse the offset value of the pierce point in the vertical direction.
 PiercePointSelectionObject	Gets and sets the selected pierce point object for the sketch of this member profile.
 ProfileAlignmentAngle	Gets and sets the angle of alignment between this member profile and a specified entity.
 ProfileAlignmentObject	Gets and sets the entity with which to align an axis of this member profile.
 ProfileAlignmentObjectType	Gets the type of profile alignment entity.
 ProfileAlignmentType	Gets and sets the axis of alignment for this member profile.
 ProfileMirrorType	Gets and sets the axis about which to flip this member profile.
 ProfilePiercePointType	Gets and sets the type of pierce point used to define the sketch of this structure system member profile.
 ProfileSize	Gets the profile size for this member profile.
 ProfileStandard	Gets the profile standard for this member profile.
 ProfileType	Gets the profile type for this member profile.

[Top](#)

 See Also

[IStructureSystemMemberProfile Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

GetSketch Method (IStructureSystemMemberProfile)

[See Also](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : GetSketch Method (IStructureSystemMemberProfile)

Gets the sketch that contains all of the pierce points used to define this structure system member profile.

 .NET Syntax

Visual Basic (Declaration)

Function GetSketch() As System.Object

Visual Basic (Usage)

Dim instance As [IStructureSystemMemberProfile](#)
Dim value As System.Object

value = instance.GetSketch()

C#

System.object GetSketch()

C++/CLI



```
System.Object^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ISketch](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::GetSketch](#).

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorProfile Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : MirrorProfile Property (IStructureSystemMemberProfile)

Gets and sets whether to flip the profile of this member about an axis.

.NET Syntax

Visual Basic (Declaration)

```
Property MirrorProfile As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile  
Dim value As System.Boolean
```

```
instance.MirrorProfile = value
```

```
value = instance.MirrorProfile
```

C#

```
System.bool MirrorProfile {get; set;}
```

C++/CLI

```
property System.bool MirrorProfile {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the profile of the member about an axis, false to not

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::MirrorProfile](#).

Remarks

Use [IStructureSystemMemberProfile::ProfileMirrorType](#) to specify either the horizontal or vertical axis about which to flip the member profile.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetPiercePoint Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : OffsetPiercePoint Property (IStructureSystemMemberProfile)

Gets and sets whether to offset the pierce point of this member profile.

.NET Syntax

Visual Basic (Declaration)

Property OffsetPiercePoint As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile  
Dim value As System.Boolean
```

```
instance.OffsetPiercePoint = value
```

```
value = instance.OffsetPiercePoint
```

C#

```
System.bool OffsetPiercePoint {get; set;}
```

C++/CLI

```
property System.bool OffsetPiercePoint {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to offset the pierce point, false to not

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::OffsetPiercePoint](#).

Remarks

If this property is true, use [IStructureSystemMemberProfile::OffsetPiercePointHorizontalAxis](#) and [IStructureSystemMemberProfile::OffsetPiercePointVerticalAxis](#) to specify the offsets.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetPiercePointHorizontalAxis Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : OffsetPiercePointHorizontalAxis Property (IStructureSystemMemberProfile)

Gets and sets the offset value of the pierce point in the horizontal direction.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetPiercePointHorizontalAxis As System.Double
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Double

instance.OffsetPiercePointHorizontalAxis = value

value = instance.OffsetPiercePointHorizontalAxis
```

C#

```
System.double OffsetPiercePointHorizontalAxis {get; set;}
```

C++/CLI

```
property System.double OffsetPiercePointHorizontalAxis {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Horizontal offset of the pierce point

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::OffsetPiercePointHorizontalAxis](#).

Remarks

This property is valid only if [IStructureSystemMemberProfile::OffsetPiercePoint](#) is set to true.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetPiercePointHorizontalAxisFlip Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : OffsetPiercePointHorizontalAxisFlip Property (IStructureSystemMemberProfile)

Gets and sets whether to reverse the offset value of the pierce point in the horizontal direction.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetPiercePointHorizontalAxisFlip As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Boolean

instance.OffsetPiercePointHorizontalAxisFlip = value
value = instance.OffsetPiercePointHorizontalAxisFlip
```

C#

```
System.bool OffsetPiercePointHorizontalAxisFlip {get; set;}
```

C++/CLI

```
property System.bool OffsetPiercePointHorizontalAxisFlip {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the horizontal offset, false to not

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::OffsetPiercePointHorizontalAxisFlip](#).

Remarks

This property is valid only if [IStructureSystemMemberProfile::OffsetPiercePoint](#) is set to true.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetPiercePointVerticalAxis Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : OffsetPiercePointVerticalAxis Property (IStructureSystemMemberProfile)

Gets and sets the offset value of the pierce point in the vertical direction.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetPiercePointVerticalAxis As System.Double
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Double

instance.OffsetPiercePointVerticalAxis = value
value = instance.OffsetPiercePointVerticalAxis
```

C#

```
System.double OffsetPiercePointVerticalAxis {get; set;}
```

C++/CLI

```
property System.double OffsetPiercePointVerticalAxis {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Vertical offset of the pierce point

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::OffsetPiercePointVerticalAxis](#).

Remarks

This property is valid only if [IStructureSystemMemberProfile::OffsetPiercePoint](#) is set to true.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetPiercePointVerticalAxisFlip Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : OffsetPiercePointVerticalAxisFlip Property (IStructureSystemMemberProfile)

Gets and sets whether to reverse the offset value of the pierce point in the vertical direction.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetPiercePointVerticalAxisFlip As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Boolean

instance.OffsetPiercePointVerticalAxisFlip = value
value = instance.OffsetPiercePointVerticalAxisFlip
```

C#

```
System.bool OffsetPiercePointVerticalAxisFlip {get; set;}
```

C++/CLI

```
property System.bool OffsetPiercePointVerticalAxisFlip {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the vertical offset, false to not

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::OffsetPiercePointVerticalAxisFlip](#).

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

PiercePointSelectionObject Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : PiercePointSelectionObject Property (IStructureSystemMemberProfile)

Gets and sets the selected pierce point object for the sketch of this member profile.

.NET Syntax

Visual Basic (Declaration)

Property PiercePointSelectionObject As System.Object

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Object

instance.PiercePointSelectionObject = value

value = instance.PiercePointSelectionObject
```

C#

```
System.object PiercePointSelectionObject {get; set;}
```

C++/CLI

```
property System.Object^ PiercePointSelectionObject {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[ISketchPoint](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::PiercePointSelectionObject](#).

Remarks

This property is valid only if [IStructureSystemMemberProfile::ProfilePiercePointType](#) is set to [swStructureProfilePiercePointType_e](#).Selection.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileAlignmentAngle Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfileAlignmentAngle Property (IStructureSystemMemberProfile)

Gets and sets the angle of alignment between this member profile and a specified entity.

.NET Syntax

Visual Basic (Declaration)

Property ProfileAlignmentAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Double

instance.ProfileAlignmentAngle = value

value = instance.ProfileAlignmentAngle
```

C#

```
System.double ProfileAlignmentAngle {get; set;}
```

C++/CLI

```
property System.double ProfileAlignmentAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Alignment angle in radians

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfileAlignmentAngle](#).

Remarks

The angle is measured between an axis of the profile member as defined by [IStructureSystemMemberProfile::ProfileAlignmentType](#) and an entity specified by [IStructureSystemMemberProfile::ProfileAlignmentObject](#).

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileAlignmentObject Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfileAlignmentObject Property (IStructureSystemMemberProfile)

Gets and sets the entity with which to align an axis of this member profile.

.NET Syntax

Visual Basic (Declaration)

Property ProfileAlignmentObject As System.Object

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile  
Dim value As System.Object
```

```
instance.ProfileAlignmentObject = value
```

```
value = instance.ProfileAlignmentObject
```

C#

```
System.object ProfileAlignmentObject {get; set;}
```

C++/CLI

```
property System.Object^ ProfileAlignmentObject {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Direction entity with which to align an axis of the member profile, e.g.:

- [IBody2](#)
- [IEdge](#)
- [IFace2](#)
- [IRefAxis](#)
- [IRefPlane](#)
- [ISketchLine](#)
- [ISketchSegment](#)
- [ISurface](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfileAlignmentObject](#).

Remarks

Use:

- [IStructureSystemMemberProfile::ProfileAlignmentObjectType](#) to specify the type of this entity.
- [IStructureSystemMemberProfile::ProfileAlignmentType](#) to specify to which axis of the member profile to align the entity specified by this property.
- [IStructureSystemMemberProfile::ProfileAlignmentAngle](#) to specify the angle of alignment with the specified entity and member axis.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileAlignmentObjectType Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfileAlignmentObjectType Property (IStructureSystemMemberProfile)

Gets the type of profile alignment entity.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ProfileAlignmentObjectType As System.Integer
```

```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Integer

value = instance.ProfileAlignmentObjectType
```

C#

```
System.int ProfileAlignmentObjectType {get;}
```

C++/CLI

```
property System.int ProfileAlignmentObjectType {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Profile alignment object type as defined by [swSelectType_e](#):

- swSelDATUMPLANES
- swSelDATUMAXES
- swSelDATUMLINES
- swSelFACES
- swSelEDGES
- swSelSKETCHSEGS
- swSelSURFACEBODIES

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfileAlignmentObjectType](#).

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileAlignmentType Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfileAlignmentType Property (IStructureSystemMemberProfile)

Gets and sets the axis of alignment for this member profile.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileAlignmentType As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Integer

instance.ProfileAlignmentType = value

value = instance.ProfileAlignmentType
```

C#

```
System.int ProfileAlignmentType {get; set;}
```

C++/CLI

```
property System.int ProfileAlignmentType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Profile alignment type as defined by [swStructureProfileAlignmentType_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfileAlignmentType](#).

Remarks

This property is valid only if [IStructureSystemMemberProfile::ProfileAlignmentObject](#) is set.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileMirrorType Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfileMirrorType Property (IStructureSystemMemberProfile)

Gets and sets the axis about which to flip this member profile.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileMirrorType As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IStructureSystemMemberProfile
Dim value As System.Integer
```

```
instance.ProfileMirrorType = value
```

```
value = instance.ProfileMirrorType
```

C#

```
System.int ProfileMirrorType {get; set;}
```

C++/CLI

```
property System.int ProfileMirrorType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Axis about which to flip this member profile as defined by [swStructureProfileMirrorType_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfileMirrorType](#).

Remarks

This property is valid only if [IStructureSystemMemberProfile::MirrorProfile](#) is true.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfilePiercePointType Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfilePiercePointType Property (IStructureSystemMemberProfile)

Gets and sets the type of pierce point used to define the sketch of this structure system member profile.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfilePiercePointType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile  
Dim value As System.Integer  
  
instance.ProfilePiercePointType = value  
  
value = instance.ProfilePiercePointType
```

C#

```
System.int ProfilePiercePointType {get; set;}
```

C++/CLI

```
property System.int ProfilePiercePointType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of pierce point as defined by [swStructureProfilePiercePointType_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfilePiercePointType](#).

Remarks

Gets and sets the type of pierce point for the sketch of this member profile.

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileSize Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfileSize Property (IStructureSystemMemberProfile)

Gets the profile size for this member profile.

.NET Syntax

Visual Basic (Declaration)

Property ProfileSize As System.String

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile
Dim value As System.String
```

```
instance.ProfileSize = value
```

```
value = instance.ProfileSize
```

C#

```
System.string ProfileSize {get; set;}
```

C++/CLI

```
property System.String^ ProfileSize {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weldment profile size as defined in a weldment profile

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfileSize](#).

Example

See the [ICornerManagementFolder](#) examples.

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

Remarks

This property:

- is valid only if a [IStructureSystemMemberProfile::ProfileType](#) is set.
- overrides [IProfileGroupFolder::ProfileSize](#).

Specify this property using strings found in:

- SOLIDWORKS-supplied weldment profile (*.sldlfp) from *install_dir\lang\lang_name\weldment profiles* - or -
- custom weldment profile (*.sldlfp); see the SOLIDWORKS Help for details about custom weldment profiles

See Also

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileStandard Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfileStandard Property (IStructureSystemMemberProfile)

Gets the profile standard for this member profile.

.NET Syntax

Visual Basic (Declaration)

Property ProfileStandard As System.String

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile
Dim value As System.String

instance.ProfileStandard = value
value = instance.ProfileStandard
```

C#

```
System.string ProfileStandard {get; set;}
```

C++/CLI

```
property System.String^ ProfileStandard {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weldment profile standard as defined in a weldment profile

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfileStandard](#).

Example

See the [ICornerManagementFolder](#) examples.

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

Remarks

This property overrides [IProfileGroupFolder::ProfileStandard](#).

Specify this property using strings found in:

- SOLIDWORKS-supplied weldment profile (*.sldlfp) from *install_dir\lang\lang_name\weldment profiles*
 - or -
- custom weldment profile (*.sldlfp); see the SOLIDWORKS Help for details about custom weldment profiles

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

ProfileType Property (IStructureSystemMemberProfile)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberProfile Interface](#) : ProfileType Property (IStructureSystemMemberProfile)

Gets the profile type for this member profile.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileType As System.String
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberProfile  
Dim value As System.String
```

```
instance.ProfileType = value
```

```
value = instance.ProfileType
```

C#

```
System.string ProfileType {get; set;}
```

C++/CLI

```
property System.String^ ProfileType {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weldment profile type as defined in a weldment profile

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberProfile::ProfileType](#).

Example

See the [ICornerManagementFolder](#) examples.

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

Remarks

This property:

- is valid only if a [IStructureSystemMemberProfile::ProfileStandard](#) is set.
- overrides [IProfileGroupFolder::ProfileType](#).

Specify this property using strings found in:

- SOLIDWORKS-supplied weldment profile (*.sldlfp) from *install_dir\lang\lang_name\weldment profiles*
 - or -
- custom weldment profile (*.sldlfp); see the SOLIDWORKS Help for details about custom weldment profiles

See Also

[IStructureSystemMemberProfile Interface](#)
[IStructureSystemMemberProfile Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

IStructureSystemSplitMember (Type)

IStructureSystemSplitMember Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemSplitMember Interface

Allows access to a structure system split member.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IStructureSystemSplitMember
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember
```

C#

```
public interface IStructureSystemSplitMember
```

C++/CLI

```
public interface class IStructureSystemSplitMember
```

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember](#).

Example

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

Remarks

See the [IStructureSystemFolder](#) Remarks.

For more information, see the Split Member sections of the **SOLIDWORKS Design user-interface help > Weldments and Structure System : Structure System > Primary Member PropertyManager** and **Secondary Member PropertyManager** topics.

Accessors

[IStructureSystemMemberFeatureData::GetSplitMember](#)

Access Diagram

[StructureSystemSplitMember](#)

See Also

[IStructureSystemSplitMember Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IStructureSystemSplitMember Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemSplitMember Interface

The following tables list the members exposed by [IStructureSystemSplitMember](#).

Public Properties

Name	Description
 DimensionType	Gets the type of dimension split for this structure system split member.
 MemberType	Gets the type of split for this structure system split member.
 NumberOfSplitInstances	Gets the number of instances in this dimension split member.
 SplitLength	Gets the length of this dimension split member.
 SplitLengthRevDirection	Gets and sets whether to reverse the direction of the length of this dimension split member.

[Top](#)

Public Methods

Name	Description
 GetSplitReferenceObjectTypes	Gets the types of split member references.
 GetSplitReferences	Gets the entities used to split this structure system split member.
 SetSplitReferences	Sets the split member references.

[Top](#)

See Also

[IStructureSystemSplitMember Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructureSystemSplitMember Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemSplitMember Interface

For a list of all members of this type, see [IStructureSystemSplitMember members](#).

Public Methods

Name	Description
 GetSplitReferenceObjectTypes	Gets the types of split member references.
 GetSplitReferences	Gets the entities used to split this structure system split member.
 SetSplitReferences	Sets the split member references.

[Top](#)

See Also

[IStructureSystemSplitMember Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructureSystemSplitMember Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemSplitMember Interface

For a list of all members of this type, see [IStructureSystemSplitMember members](#).

Public Properties

Name	Description
 DimensionType	Gets the type of dimension split for this structure system split member.
 MemberType	Gets the type of split for this structure system split member.
 NumberOfSplitInstances	Gets the number of instances in this dimension split member.
 SplitLength	Gets the length of this dimension split member.
 SplitLengthRevDirection	Gets and sets whether to reverse the direction of the length of this dimension split member.

[Top](#)

See Also

[IStructureSystemSplitMember Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DimensionType Property (IStructureSystemSplitMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemSplitMember Interface](#) : DimensionType Property (IStructureSystemSplitMember)

Gets the type of dimension split for this structure system split member.

.NET Syntax

Visual Basic (Declaration)

```
Property DimensionType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember  
Dim value As System.Integer
```

```
instance.DimensionType = value
```

```
value = instance.DimensionType
```

C#

```
System.int DimensionType {get; set;}
```

C++/CLI

```
property System.int DimensionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of dimension split member as defined by [swSplitMemberDimensionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember::DimensionType](#).

See Also

[IStructureSystemSplitMember Interface](#)
[IStructureSystemSplitMember Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSplitReferenceObjectTypes Method (IStructureSystemSplitMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemSplitMember Interface](#) : GetSplitReferenceObjectTypes Method (IStructureSystemSplitMember)

Gets the types of split member references.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplitReferenceObjectTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember
Dim value As System.Object

value = instance.GetSplitReferenceObjectTypes()
```

C#

```
System.Object GetSplitReferenceObjectTypes()
```

C++/CLI

```
System.Object^ GetSplitReferenceObjectTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of types of split member references as defined by [swSelectType_e](#):

- swSelFACES
- swSelDATUMPLANES
- swSelADVSTRUCTMEMBER

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember::GetSplitReferenceObjectTypes](#).

Remarks

This method is valid only if [IStructureSystemSplitMember::MemberType](#) is set to [swStructureSplitMemberType_e.swStructureSplitMember_Reference](#).

The array returned by this method maps one-to-one and onto with the array returned by [IStructureSystemSplitMember::GetSplitReferences](#).

See Also

[IStructureSystemSplitMember Interface](#)
[IStructureSystemSplitMember Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplitReferences Method (IStructureSystemSplitMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemSplitMember Interface](#) : GetSplitReferences Method (IStructureSystemSplitMember)

Gets the entities used to split this structure system split member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplitReferences() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember
Dim value As System.Object

value = instance.GetSplitReferences()
```

C#

```
System.Object GetSplitReferences()
```

C++/CLI

```
System.Object^ GetSplitReferences();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of one or more references, e.g.:

- [IFace2](#)
- [IRefPlane](#)
- [IFeature](#) (i.e., another structure system member)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember::GetSplitReferences](#).

Remarks

This method is valid only if [IStructureSystemSplitMember::MemberType](#) is set to [swStructureSplitMemberType_e](#).swStructureSplitMember_Reference.

See Also

[IStructureSystemSplitMember Interface](#)
[IStructureSystemSplitMember Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

MemberType Property (IStructureSystemSplitMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemSplitMember Interface](#) : MemberType Property (IStructureSystemSplitMember)

Gets the type of split for this structure system split member.

.NET Syntax

Visual Basic (Declaration)

```
Property MemberType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember  
Dim value As System.Integer
```

```
instance.MemberType = value
```

```
value = instance.MemberType
```

C#

```
System.int MemberType {get; set;}
```

C++/CLI

```
property System.int MemberType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of split as defined by [swStructureSplitMemberType_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember::MemberType](#).

Example

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See Also

[IStructureSystemSplitMember Interface](#)
[IStructureSystemSplitMember Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

NumberOfSplitInstances Property (IStructureSystemSplitMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemSplitMember Interface](#) : NumberOfSplitInstances Property (IStructureSystemSplitMember)

Gets the number of instances in this dimension split member.

.NET Syntax

Visual Basic (Declaration)

Property NumberOfSplitInstances As System.Integer

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember  
Dim value As System.Integer
```

```
instance.NumberOfSplitInstances = value
```

```
value = instance.NumberOfSplitInstances
```

C#

```
System.int NumberOfSplitInstances {get; set;}
```

C++/CLI

```
property System.int NumberOfSplitInstances {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of instances

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember::NumberOfSplitInstances](#).

Remarks

This property is valid only for [IStructureSystemSplitMember::DimensionType](#) set to [swSplitMemberDimensionType_e](#).swSplitMemberDimensionType_Instance.

See Also

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSplitReferences Method (IStructureSystemSplitMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemSplitMember Interface](#) : SetSplitReferences Method (IStructureSystemSplitMember)

Sets the split member references.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSplitReferences( _  
    ByVal References As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember  
Dim References As System.Object  
Dim value As System.Boolean  
  
value = instance.SetSplitReferences(References)
```

C#

```
System.bool SetSplitReferences(  
    System.object References  
)
```

C++/CLI

```
System.bool SetSplitReferences(  
& System.Object^ References  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

References

Array of split member references, e.g.:

- Face2
- IRefPlane
- Member

Return Value

True if split member references successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember::SetSplitReferences](#).

Example

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

Remarks

This method is valid only if [IStructureSystemSplitMember::MemberType](#) is set to [swStructureSplitMemberType_e.swStructureSplitMember_Reference](#).

See Also

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SplitLength Property (IStructureSystemSplitMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemSplitMember Interface](#) : SplitLength Property (IStructureSystemSplitMember)

Gets the length of this dimension split member.

.NET Syntax

Visual Basic (Declaration)

Property SplitLength As System.Double

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember  
Dim value As System.Double  
  
instance.SplitLength = value  
value = instance.SplitLength
```

C#

```
System.double SplitLength {get; set;}
```

C++/CLI

```
property System.double SplitLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember::SplitLength](#).

Remarks

This property is valid only for [IStructureSystemSplitMember::DimensionType](#) set to [swSplitMemberDimensionType_e.swSplitMemberDimensionType_SplitLength](#).

See Also

[IStructureSystemSplitMember Interface](#)
[IStructureSystemSplitMember Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SplitLengthRevDirection Property (IStructureSystemSplitMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemSplitMember Interface](#) : SplitLengthRevDirection Property (IStructureSystemSplitMember)

Gets and sets whether to reverse the direction of the length of this dimension split member.

.NET Syntax

Visual Basic (Declaration)

Property SplitLengthRevDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStructureSystemSplitMember  
Dim value As System.Boolean  
  
instance.SplitLengthRevDirection = value  
value = instance.SplitLengthRevDirection
```

C#

```
System.bool SplitLengthRevDirection {get; set;}
```

C++/CLI

```
property System.bool SplitLengthRevDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of the length, false to not

Visual Basic for Applications (VBA) Syntax

See [StructureSystemSplitMember::SplitLengthRevDirection](#).

Remarks

This property is valid only for [IStructureSystemSplitMember::DimensionType](#) set to [swSplitMemberDimensionType_e.swSplitMemberDimensionType_SplitLength](#).

See Also

[IStructureSystemSplitMember Interface](#)
[IStructureSystemSplitMember Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30