

SOLIDWORKS API (.NET VBA C#) — Reference

(300/337): ISurfaceCutFeatureData- ISurfaceFlattenFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISurfaceCutFeatureData (Type)

ISurfaceCutFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceCutFeatureData Interface

Allows access to a surface-cut feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISurfaceCutFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData
```

C#

```
public interface ISurfaceCutFeatureData
```

C++/CLI

```
public interface class ISurfaceCutFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData](#).

Example

[Insert Surface-cut Feature \(C#\)](#)
[Insert Surface-cut Feature \(VB.NET\)](#)
[Insert Surface-cut Feature \(VBA\)](#)
[Modify Surface-cut Feature \(C#\)](#)
[Modify Surface-cut Feature \(VB.NET\)](#)
[Modify Surface-cut Feature \(VBA\)](#)

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData. See the examples for details.

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[SurfaceCutFeatureData](#)

See Also

[ISurfaceCutFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCutSurface](#)

ISurfaceCutFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceCutFeatureData Interface

For a list of all members of this type, see [ISurfaceCutFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this surface-cut feature.
 GetBodyIndexKept	Gets the index of the body kept while resolving ambiguity for this surface-cut feature.
 GetFeatureScopeBodiesCount	Gets the number of bodies affected by this surface-cut feature.
 IAccessSelections	Accesses the selections that define this surface-cut feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the surface-cut feature affects in a multibody part.
 ISetFeatureScopeBodies	Sets the solid bodies that this surface-cut feature affects in a multibody part.
 ReleaseSelectionAccess	Releases access to the selections that created this surface-cut feature.

[Top](#)

See Also

[ISurfaceCutFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCutSurface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISurfaceCutFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceCutFeatureData Interface

The following tables list the members exposed by [ISurfaceCutFeatureData](#).

Public Properties

Name	Description
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the surface-cut feature to affect in a multibody part.
 FeatureScope	Gets or sets whether to use scope for the surface-cut feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the surface-cut feature affects in a multibody part.
 Flip	Gets or sets the flip setting for this surface cut.
 SurfaceForCut	Gets or sets the surface to use to cut the solid bodies.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this surface-cut feature.
 GetBodyIndexKept	Gets the index of the body kept while resolving ambiguity for this surface-cut feature.
 GetFeatureScopeBodiesCount	Gets the number of bodies affected by this surface-cut feature.
 IAccessSelections	Accesses the selections that define this surface-cut feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the surface-cut feature affects in a multibody part.
 ISetFeatureScopeBodies	Sets the solid bodies that this surface-cut feature affects in a multibody part.
 ReleaseSelectionAccess	Releases access to the selections that created this surface-cut feature.

[Top](#)

See Also

[ISurfaceCutFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCutSurface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISurfaceCutFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : [ISurfaceCutFeatureData Interface](#)

For a list of all members of this type, see [ISurfaceCutFeatureData members](#).

 Public Properties

Name	Description
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the surface-cut feature to affect in a multibody part.
 FeatureScope	Gets or sets whether to use scope for the surface-cut feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the surface-cut feature affects in a multibody part.
 Flip	Gets or sets the flip setting for this surface cut.
 SurfaceForCut	Gets or sets the surface to use to cut the solid bodies.

[Top](#)

 See Also

[ISurfaceCutFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCutSurface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISurfaceCutFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : AccessSelections Method (ISurfaceCutFeatureData)

Accesses the selections that define this surface-cut feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the surface-cut feature is to be modified

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::AccessSelections](#).

Example

[Modify Surface-cut Feature \(C#\)](#)
[Modify Surface-cut Feature \(VB.NET\)](#)
[Modify Surface-cut Feature \(VBA\)](#)

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData. See the examples for details.

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfaceCutFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)
[ISurfaceCutFeatureData::iAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoSelect Property (ISurfaceCutFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : AutoSelect Property (ISurfaceCutFeatureData)

Gets or sets whether to automatically select all or only specific bodies for the surface-cut feature to affect in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property AutoSelect As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim value As System.Boolean
```

```
instance.AutoSelect = value
```

```
value = instance.AutoSelect
```

C#

```
System.bool AutoSelect {get; set;}
```

C++/CLI

```
property System.bool AutoSelect {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies, false to select specific bodies for [ISurfaceCutFeatureData::FeatureScopeBodies](#) or [ISurfaceCutFeatureData::!SetFeatureScopeBodies](#)

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::AutoSelect](#).

Example

[Insert Surface-cut Feature \(C#\)](#)
[Insert Surface-cut Feature \(VB.NET\)](#)
[Insert Surface-cut Feature \(VBA\)](#)

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

This property is only available when [ISurfaceCutFeatureData::FeatureScope](#) is true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)
[ISurfaceCutFeatureData::GetFeatureScopeBodiesCount Method](#)
[ISurfaceCutFeatureData::!GetFeatureScopeBodies Method \(\)](#)

Availability

SOLIDWORKS 2013 SP1, Revision Number 21.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScope Property (ISurfaceCutFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : FeatureScope Property (ISurfaceCutFeatureData)

Gets or sets whether to use scope for the surface-cut feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScope As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim value As System.Boolean
```

```
instance.FeatureScope = value
```

```
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get; set;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

When:

- true, only the specified bodies in a multibody part are affected by the surface-cut feature
- false, all of the bodies in a multibody part are affected by the surface-cut feature

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData.FeatureScope](#).

Example

[Insert Surface-cut Feature \(C#\)](#)
[Insert Surface-cut Feature \(VB.NET\)](#)
[Insert Surface-cut Feature \(VBA\)](#)

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)
[ISurfaceCutFeatureData::GetFeatureScopeBodiesCount Method](#)
[ISurfaceCutFeatureData::IGetFeatureScopeBodies Method](#)
[ISurfaceCutFeatureData::ISetFeatureScopeBodies Method](#)
[ISurfaceCutFeatureData::AutoSelect Property](#)
[ISurfaceCutFeatureData.FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2013 SP1, Revision Number 21.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScopeBodies Property (ISurfaceCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : FeatureScopeBodies Property (ISurfaceCutFeatureData)

Gets or sets the solid bodies that the surface-cut feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScopeBodies As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim value As System.Object
```

```
instance.FeatureScopeBodies = value
```

```
value = instance.FeatureScopeBodies
```

C#

```
System.object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of solid [bodies](#) that the surface-cut feature affects

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::FeatureScopeBodies](#).

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)
[ISurfaceCutFeatureData::GetFeatureScopeBodiesCount Method](#)
[ISurfaceCutFeatureData::IGetFeatureScopeBodies Method \(\)](#)
[ISurfaceCutFeatureData::ISetFeatureScopeBodies Method](#)
[ISurfaceCutFeatureData::AutoSelect Property](#)
[ISurfaceCutFeatureData::FeatureScope Property](#)

Availability

SOLIDWORKS 2013 SP1, Revision Number 21.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Flip Property (ISurfaceCutFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : Flip Property (ISurfaceCutFeatureData)

Gets or sets the flip setting for this surface cut.

.NET Syntax

Visual Basic (Declaration)

Property Flip As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim value As System.Boolean
```

```
instance.Flip = value
```

```
value = instance.Flip
```

C#

```
System.bool Flip {get; set;}
```

C++/CLI

```
property System.bool Flip {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the surface is flipped, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::Flip](#).

Example

[Modify Surface-cut Feature \(C#\)](#)
[Modify Surface-cut Feature \(VB.NET\)](#)
[Modify Surface-cut Feature \(VBA\)](#)

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData. See the examples for details.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBodyIndexKept Method (ISurfaceCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : GetBodyIndexKept Method (ISurfaceCutFeatureData)

Gets the index of the body kept while resolving ambiguity for this surface-cut feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodyIndexKept() As System.Short
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim value As System.Short  
  
value = instance.GetBodyIndexKept()
```

C#

```
System.short GetBodyIndexKept()
```

C++/CLI

```
System.short GetBodyIndexKept();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Body index

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::GetBodyIndexKept](#).

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

See Also

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeatureScopeBodiesCount Method (ISurfaceCutFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : GetFeatureScopeBodiesCount Method (ISurfaceCutFeatureData)

Gets the number of bodies affected by this surface-cut feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureScopeBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim value As System.Integer  
  
value = instance.GetFeatureScopeBodiesCount()
```

C#

```
System.int GetFeatureScopeBodiesCount()
```

C++/CLI

```
System.int GetFeatureScopeBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bodies affected by this surface-cut feature

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::GetFeatureScopeBodiesCount](#).

Example

[Insert Surface-cut Feature \(C#\)](#)
[Insert Surface-cut Feature \(VB.NET\)](#)
[Insert Surface-cut Feature \(VBA\)](#)

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

Call this method before calling [ISurfaceCutFeatureData::IGetFeatureScopeBodies](#) to determine the size of the array for that method.

If [ISurfaceCutFeatureData::FeatureScope](#) is false, then this method's return value is 0.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)
[ISurfaceCutFeatureData::ISetFeatureScopeBodies Method](#)
[ISurfaceCutFeatureData::FeatureScopeBodies Property](#)
[ISurfaceCutFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2013 SP1, Revision Number 21.1

IAccessSelections Method (ISurfaceCutFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : IAccessSelections Method (ISurfaceCutFeatureData)

Accesses the selections that define this surface-cut feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the surface-cut feature is to be modified

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::IAccessSelections](#).

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfaceCutFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)
[ISurfaceCutFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFeatureScopeBodies Method (ISurfaceCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : IGetFeatureScopeBodies Method (ISurfaceCutFeatureData)

Gets the solid bodies that the surface-cut feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeatureScopeBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim Count As System.Integer  
Dim value As Body2  
  
value = instance.IGetFeatureScopeBodies(Count)
```

C#

```
Body2 IGetFeatureScopeBodies(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetFeatureScopeBodies(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of solid bodies to affect

Return Value

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::IGetFeatureScopeBodies](#).

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

Before calling this method, call [ISurfaceCutFeatureData::GetFeatureScopeBodiesCount](#) to get Count.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)
[ISurfaceCutFeatureData::ISetFeatureScopeBodies Method](#)

[ISurfaceCutFeatureData::AutoSelect](#)
[ISurfaceCutFeatureData::FeatureScope Property](#)
[ISurfaceCutFeatureData::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2013 SP1, Revision Number 21.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetFeatureScopeBodies Method (ISurfaceCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : ISetFeatureScopeBodies Method (ISurfaceCutFeatureData)

Sets the solid bodies that this surface-cut feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFeatureScopeBodies( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArr As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim Count As System.Integer  
Dim BodyArr As Body2  
  
instance.ISetFeatureScopeBodies(Count, BodyArr)
```

C#

```
void ISetFeatureScopeBodies(  
    System.int Count,  
    ref Body2 BodyArr  
)
```

C++/CLI

```
void ISetFeatureScopeBodies(  
& System.int Count,  
& Body2^% BodyArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of solid bodies to affect
BodyArr
Array of solid [bodies](#) of size Count

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::ISetFeatureScopeBodies](#).

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)
[ISurfaceCutFeatureData::GetFeatureScopeBodiesCount Method](#)

[ISurfaceCutFeatureData::IGetFeatureScopeBodies Method](#)
[ISurfaceCutFeatureData::AutoSelect Property](#)
[ISurfaceCutFeatureData::FeatureScope Property](#)
[ISurfaceCutFeatureData::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2013 SP1, Revision Number 21.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISurfaceCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : ReleaseSelectionAccess Method (ISurfaceCutFeatureData)

Releases access to the selections that created this surface-cut feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::ReleaseSelectionAccess](#).

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

[ISurfaceCutFeatureData::AccessSelections](#) and [ISurfaceCutFeatureData::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SurfaceForCut Property (ISurfaceCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceCutFeatureData Interface](#) : SurfaceForCut Property (ISurfaceCutFeatureData)

Gets or sets the surface to use to cut the solid bodies.

.NET Syntax

Visual Basic (Declaration)

Property SurfaceForCut As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceCutFeatureData  
Dim value As System.Object
```

```
instance.SurfaceForCut = value
```

```
value = instance.SurfaceForCut
```

C#

```
System.object SurfaceForCut {get; set;}
```

C++/CLI

```
property System.Object^ SurfaceForCut {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Surface feature](#) to use to cut the solid bodies

Visual Basic for Applications (VBA) Syntax

See [SurfCutFeatureData::SurfaceForCut](#).

Remarks

To access this interface, you must declare it as SurfCutFeatureData or ISurfCutFeatureData.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceCutFeatureData Interface](#)
[ISurfaceCutFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

ISurfaceExtendFeatureData (Type)

ISurfaceExtendFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceExtendFeatureData Interface

Allows access to a surface-extend feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISurfaceExtendFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData
```

C#

```
public interface ISurfaceExtendFeatureData
```

C++/CLI

```
public interface class ISurfaceExtendFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData](#).

Example

[Get Data for Surface-extend Feature \(VBA\)](#)
[Get Data for Surface-extend Feature \(VB.NET\)](#)
[Get Data for Surface-extend Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[SurfaceExtendFeatureData](#)

See Also

[ISurfaceExtendFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[InsertUntrimSurface Method](#)
[IModelDoc2::InsertExtendSurface Method](#)

ISurfaceExtendFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceExtendFeatureData Interface

For a list of all members of this type, see [ISurfaceExtendFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this surface-extend feature.
GetItemsCount	Gets the number of extended faces and edges for this surface-extend feature.

		
	GetPropagatingEdgesCount	Gets the propagating edges for this surface-extend feature.
	IAccessSelections	Accesses the selections that define this surface-extend feature.
	IGetItems	Gets the extended faces and edges for this surface-extend feature.
	IGetPropagatingEdges	Gets the propagating edges for this surface-extend feature.
	ISetItems	Sets the extended faces and edges for this surface-extend feature.
	ISetPropagatingEdges	Sets the propagating edges for this surface-extend feature.
	ReleaseSelectionAccess	Releases access to the selections for this surface-extend feature.

[Top](#)

See Also

[ISurfaceExtendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[InsertUntrimSurface Method](#)
[IModelDoc2::InsertExtendSurface Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfaceExtendFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceExtendFeatureData Interface

The following tables list the members exposed by [ISurfaceExtendFeatureData](#).

Public Properties

Name	Description
 Distance	Gets or sets the extended distance for this surface-extend feature.
 EndCondition	Gets or sets the end condition for this surface-extend feature.
 Face	Gets or sets the end-condition face for this surface-extend feature.
 IFace	Gets or sets the end-condition face for this surface-extend feature.
 Items	Gets or sets the extended faces and edges for this surface-extend feature.
 IVertex	Gets and sets the vertex for the end condition of this surface-extend feature.
 PropagatingEdges	Gets or sets the propagating edges for this surface-extend feature.
 Type	Gets or sets the extension type for this surface-extend feature.
 Vertex	Gets and sets the vertex for the end condition of this surface-extend feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this surface-extend feature.
 GetItemsCount	Gets the number of extended faces and edges for this surface-extend feature.
 GetPropagatingEdgesCount	Gets the propagating edges for this surface-extend feature.
 IAccessSelections	Accesses the selections that define this surface-extend feature.
 IGetItems	Gets the extended faces and edges for this surface-extend feature.
 IGetPropagatingEdges	Gets the propagating edges for this surface-extend feature.
 ISetItems	Sets the extended faces and edges for this surface-extend feature.
 ISetPropagatingEdges	Sets the propagating edges for this surface-extend feature.
 ReleaseSelectionAccess	Releases access to the selections for this surface-extend feature.

[Top](#)

See Also

[ISurfaceExtendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[InsertUntrimSurface Method](#)
[IModelDoc2::InsertExtendSurface Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfaceExtendFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceExtendFeatureData Interface

For a list of all members of this type, see [ISurfaceExtendFeatureData members](#).

Public Properties

Name	Description
 Distance	Gets or sets the extended distance for this surface-extend feature.
 EndCondition	Gets or sets the end condition for this surface-extend feature.
 Face	Gets or sets the end-condition face for this surface-extend feature.
 IFace	Gets or sets the end-condition face for this surface-extend feature.
 Items	Gets or sets the extended faces and edges for this surface-extend feature.
 IVertex	Gets and sets the vertex for the end condition of this surface-extend feature.
 PropagatingEdges	Gets or sets the propagating edges for this surface-extend feature.
 Type	Gets or sets the extension type for this surface-extend feature.
 Vertex	Gets and sets the vertex for the end condition of this surface-extend feature.

[Top](#)

See Also

[ISurfaceExtendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[InsertUntrimSurface Method](#)
[IModelDoc2::InsertExtendSurface Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : AccessSelections Method (ISurfaceExtendFeatureData)

Accesses the selections that define this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISurfaceExtendFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#



```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you modified the feature
- [ISurfaceExtendFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::!AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Distance Property (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : Distance Property (ISurfaceExtendFeatureData)

Gets or sets the extended distance for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

Property Distance As System.Double

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData  
Dim value As System.Double
```

```
instance.Distance = value
```

```
value = instance.Distance
```

C#

```
System.double Distance {get; set;}
```

C++/CLI

```
property System.double Distance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Extended distance

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::Distance](#).

Example

See [ISurfaceExtendFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndCondition Property (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : EndCondition Property (ISurfaceExtendFeatureData)

Gets or sets the end condition for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Property EndCondition As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData  
Dim value As System.Integer
```

```
instance.EndCondition = value
```

```
value = instance.EndCondition
```

C#

```
System.int EndCondition {get; set;}
```

C++/CLI

```
property System.int EndCondition {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition as defined in [swSurfaceExtendEndCond_e](#)

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::EndCondition](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Face Property (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : Face Property (ISurfaceExtendFeatureData)

Gets or sets the end-condition face for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Face As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData
Dim value As System.Object
```

```
instance.Face = value
```

```
value = instance.Face
```

C#

```
System.object Face {get; set;}
```

C++/CLI

```
property System.Object^ Face {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End-condition [face](#)

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::Face](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::IFace Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetItemsCount Method (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : GetItemsCount Method (ISurfaceExtendFeatureData)

Gets the number of extended faces and edges for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetItemsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData  
Dim value As System.Integer  
  
value = instance.GetItemsCount()
```

C#

```
System.int GetItemsCount()
```

C++/CLI

```
System.int GetItemsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of extended items

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::GetItemsCount](#).

Remarks

Call this method before calling [ISurfaceExtendFeatureData::IGetItems](#).

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::IGetItems Method](#)
[ISurfaceExtendFeatureData::Items Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

GetPropagatingEdgesCount Method (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : GetPropagatingEdgesCount Method (ISurfaceExtendFeatureData)

Gets the propagating edges for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPropagatingEdgesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData  
Dim value As System.Integer  
  
value = instance.GetPropagatingEdgesCount()
```

C#

```
System.int GetPropagatingEdgesCount()
```

C++/CLI

```
System.int GetPropagatingEdgesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of propagating edges

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::GetPropagatingEdgesCount](#).

Remarks

Call this method before calling [ISurfaceExtendFeatureData::GetPropagatingEdges](#).

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::ISetPropagatingEdges Method](#)
[ISurfaceExtendFeatureData::PropagatingEdges Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

IAccessSelections Method (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : IAccessSelections Method (ISurfaceExtendFeatureData)

Accesses the selections that define this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _
```

```
ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData.IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfaceExtendFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFace Property (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : IFace Property (ISurfaceExtendFeatureData)

Gets or sets the end-condition face for this surface-extend feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property IFace As Face2

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData
Dim value As Face2

instance.IFace = value
value = instance.IFace
```

C#

```
Face2 IFace {get; set;}
```

C++/CLI

```
property Face2^ IFace {
    Face2^ get();
    void set ( & Face2^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End-condition [face](#)

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::IFace](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::Face Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetItems Method (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : IGetItems Method (ISurfaceExtendFeatureData)

Gets the extended faces and edges for this surface-extend feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetItems( _
    ByVal Count As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData
Dim Count As System.Integer
Dim value As System.Object

value = instance.IGetItems(Count)
```

C#

```
System.object IGetItems(
    System.int Count
)
```

C++/CLI

```
System.Object^ IGetItems(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of extended items

Return Value

- in-process, unmanaged C++: Pointer to an array extended items ([faces](#) and [edges](#)) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::IGetItems](#).

Remarks

Call [ISurfaceExtendFeatureData::GetItemsCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::ISetItems Method](#)
[ISurfaceExtendFeatureData::Items Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPropagatingEdges Method (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : IGetPropagatingEdges Method (ISurfaceExtendFeatureData)

Gets the propagating edges for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPropagatingEdges( _
    ByVal Count As System.Integer _
) As Edge
```

Visual Basic (Usage)



Copy Code

```
Dim instance As ISurfaceExtendFeatureData
Dim Count As System.Integer
Dim value As Edge

value = instance.IGetPropagatingEdges(Count)
```

C#

```
Edge IGetPropagatingEdges(
    System.int Count
)
```

C++/CLI

```
Edge^ IGetPropagatingEdges(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of propagating edges

Return Value

- in-process, unmanaged C++: Pointer to an array of propagating [edges](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISurfaceExtendFeatureData::GetPropagatingEdgesCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetItems Method (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : ISetItems Method (ISurfaceExtendFeatureData)

Sets the extended faces and edges for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetItems( _
    ByVal Count As System.Integer, _
    ByRef ItemArr As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData
Dim Count As System.Integer
Dim ItemArr As System.Object
```

```
instance.ISetItems(Count, ItemArr)
```

C#

```
void ISetItems(
    System.int Count,
```

```
ref System.object ItemArr
)
```

C++/CLI

```
void ISetItems(
& System.int Count,
& System.Object^% ItemArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of extended items

ItemArr

- in-process, unmanaged C++: Pointer to an array extended items ([faces](#) and [edges](#)) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::GetItemsCount Method](#)
[ISurfaceExtendFeatureData::GetItems Method](#)
[ISurfaceExtendFeatureData::Items Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetPropagatingEdges Method (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : ISetPropagatingEdges Method (ISurfaceExtendFeatureData)

Sets the propagating edges for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetPropagatingEdges( _
    ByVal Count As System.Integer, _
    ByRef EdgeArr As Edge _
)
```

Visual Basic (Usage)

```
Dim instance As ISurfaceExtendFeatureData
Dim Count As System.Integer
Dim EdgeArr As Edge

instance.ISetPropagatingEdges(Count, EdgeArr)
```

C#

```
void ISetPropagatingEdges(
    System.int Count,
    ref Edge EdgeArr
)
```

C++/CLI



Copy Code

```
void ISetPropagatingEdges(
& System.int Count,
& Edge^% EdgeArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of propagating edges

EdgeArr

- in-process, unmanaged C++: Pointer to an array extended items ([faces](#) and [edges](#)) of size Count

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::GetPropagatingEdgesCount Method](#)
[ISurfaceExtendFeatureData::IGetPropagatingEdges Method](#)
[ISurfaceExtendFeatureData::PropagatingEdges Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Items Property (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : Items Property (ISurfaceExtendFeatureData)

Gets or sets the extended faces and edges for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Items As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData
Dim value As System.Object
```

```
instance.Items = value
```

```
value = instance.Items
```

C#

```
System.object Items {get; set;}
```

C++/CLI

```
property System.Object^ Items {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of extended items ([faces](#) and [edges](#))

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::Items](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::ISetItems Method](#)
[ISurfaceExtendFeatureData::GetItems Method](#)
[ISurfaceExtendFeatureData::GetItemsCount Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IVertex Property (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : IVertex Property (ISurfaceExtendFeatureData)

Gets and sets the vertex for the end condition of this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

Property IVertex As Vertex

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData  
Dim value As Vertex
```

```
instance.IVertex = value
```

```
value = instance.IVertex
```

C#

```
Vertex IVertex {get; set;}
```

C++/CLI

```
property Vertex^ IVertex {  
    Vertex^ get();  
    void set ( & Vertex^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End-condition [vertex](#)

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::IVertex](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::Vertex Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagatingEdges Property (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : PropagatingEdges Property (ISurfaceExtendFeatureData)

Gets or sets the propagating edges for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

Property PropagatingEdges As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData  
Dim value As System.Object
```

```
instance.PropagatingEdges = value
```

```
value = instance.PropagatingEdges
```

C#

```
System.object PropagatingEdges {get; set;}
```

C++/CLI

```
property System.Object^ PropagatingEdges {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of propagating [edges](#)

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::PropagatingEdges](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::GetPropagatingEdgesCount Method](#)
[ISurfaceExtendFeatureData::IGetPropagatingEdges Method](#)
[ISurfaceExtendFeatureData::ISetPropagatingEdges Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

ReleaseSelectionAccess Method (ISurfaceExtendFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : ReleaseSelectionAccess Method (ISurfaceExtendFeatureData)

Releases access to the selections for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::ReleaseSelectionAccess](#).

Remarks

[ISurfaceExtendFeatureData::AccessSelections](#) and [ISurfaceExtendFeatureData::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

Type Property (ISurfaceExtendFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : Type Property (ISurfaceExtendFeatureData)

Gets or sets the extension type for this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceExtendFeatureData
Dim value As System.Integer

instance.Type = value

value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 0 = linear
- 1 = same surface

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData.Type](#).

Example

See [ISurfaceExtendFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Vertex Property (ISurfaceExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceExtendFeatureData Interface](#) : Vertex Property (ISurfaceExtendFeatureData)

Gets and sets the vertex for the end condition of this surface-extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Vertex As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISurfaceExtendFeatureData
Dim value As System.Object

instance.Vertex = value
```



```
value = instance.Vertex
```

C#

```
System.Object Vertex {get; set;}
```

C++/CLI

```
property System.Object^ Vertex {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End-condition [vertex](#)

Visual Basic for Applications (VBA) Syntax

See [SurfaceExtendFeatureData::Vertex](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceExtendFeatureData Interface](#)
[ISurfaceExtendFeatureData Members](#)
[ISurfaceExtendFeatureData::IVertex Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

ISurfaceFlattenFeatureData (Type)

ISurfaceFlattenFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceFlattenFeatureData Interface

Allows access to a surface-flatten feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISurfaceFlattenFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData
```

C#

```
public interface ISurfaceFlattenFeatureData
```

C++/CLI

```
public interface class ISurfaceFlattenFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData](#).

Example

[Get Data for Surface-flatten Feature \(VBA\)](#)
[Get Data for Surface-flatten Feature \(VB.NET\)](#)
[Get Data for Surface-flatten Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#)

Access Diagram

[SurfaceFlattenFeatureData](#)

See Also

[ISurfaceFlattenFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFlattenSurface Method \(\)](#)

ISurfaceFlattenFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceFlattenFeatureData Interface

For a list of all members of this type, see [ISurfaceFlattenFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this surface-flatten feature.
 ReleaseSelectionAccess	Releases access to the selections for this surface-flatten feature.

[Top](#)

See Also

[ISurfaceFlattenFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFlattenSurface Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfaceFlattenFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceFlattenFeatureData Interface

The following tables list the members exposed by [ISurfaceFlattenFeatureData](#).

Public Properties

Name	Description
 AccuracyFactor	Gets or sets the accuracy of the flattened triangle mesh.
 Faces	Gets or sets the faces or surfaces to flatten.
 FixPointVertex	Gets or sets the anchor point for flattening the selected faces or surfaces.
 GuideEdges	Gets or sets the edges to guide the shape and length of the flattened surface.
 KeepInternalControlCurves	Gets or sets whether to keep internal control curves for this surface-flatten feature.
 MapEdges	Gets or sets the map edges for this surface-flatten feature.
 ShouldMakeTears	Gets or sets whether to enable relief cuts for this surface-flatten feature.
 TearEdges	Gets or sets the tear edges for the relief cuts for this surface-flatten feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this surface-flatten feature.
 ReleaseSelectionAccess	Releases access to the selections for this surface-flatten feature.

[Top](#)

See Also

[ISurfaceFlattenFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFlattenSurface Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfaceFlattenFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceFlattenFeatureData Interface

For a list of all members of this type, see [ISurfaceFlattenFeatureData members](#).

Public Properties

Name	Description
 AccuracyFactor	Gets or sets the accuracy of the flattened triangle mesh.
 Faces	Gets or sets the faces or surfaces to flatten.
 FixPointVertex	Gets or sets the anchor point for flattening the selected faces or surfaces.
 GuideEdges	Gets or sets the edges to guide the shape and length of the flattened surface.
 KeepInternalControlCurves	Gets or sets whether to keep internal control curves for this surface-flatten feature.
 MapEdges	Gets or sets the map edges for this surface-flatten feature.

 ShouldMakeTears	Gets or sets whether to enable relief cuts for this surface-flatten feature.
 TearEdges	Gets or sets the tear edges for the relief cuts for this surface-flatten feature.

[Top](#)

See Also

[ISurfaceFlattenFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFlattenSurface Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (ISurfaceFlattenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : AccessSelections Method (ISurfaceFlattenFeatureData)

Accesses the selections that define this surface-flatten feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::AccessSelections](#).

Example

See the [ISurfaceFlattenFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [ISurfaceFlattenFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccuracyFactor Property (ISurfaceFlattenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : AccuracyFactor Property (ISurfaceFlattenFeatureData)

Gets or sets the accuracy of the flattened triangle mesh.

.NET Syntax

Visual Basic (Declaration)

Property AccuracyFactor As System.Integer

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
Dim value As System.Integer
```

```
instance.AccuracyFactor = value
```

```
value = instance.AccuracyFactor
```

C#

```
System.int AccuracyFactor {get; set;}
```

C++/CLI

```
property System.int AccuracyFactor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

10 >= Accuracy of flattened triangle mesh >= 1; 1 is highest accuracy

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::AccuracyFactor](#).

Example

[Get Data for Surface-flatten Feature \(C#\)](#)
[Get Data for Surface-flatten Feature \(VB.NET\)](#)
[Get Data for Surface-flatten Feature \(VBA\)](#)

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Faces Property (ISurfaceFlattenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : Faces Property (ISurfaceFlattenFeatureData)

Gets or sets the faces or surfaces to flatten.

.NET Syntax

Visual Basic (Declaration)

Property Faces As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
Dim value As System.Object
```

```
instance.Faces = value
```

```
value = instance.Faces
```

C#

```
System.Object Faces {get; set;}
```

C++/CLI

```
property System.Object^ Faces {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#) or [surfaces](#) to flatten

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::Faces](#).

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FixPointVertex Property (ISurfaceFlattenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : FixPointVertex Property (ISurfaceFlattenFeatureData)

Gets or sets the anchor point for flattening the selected faces or surfaces.

Visual Basic Syntax

Visual Basic (Declaration)

Property FixPointVertex As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
Dim value As System.Object  
  
instance.FixPointVertex = value  
value = instance.FixPointVertex
```

C#

System.object FixPointVertex {get; set;}

C++/CLI

```
property System.Object^ FixPointVertex {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Anchor point ([vertex](#) or a point on an [edge](#)) for flattening

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::FixPointVertex](#).

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GuideEdges Property (ISurfaceFlattenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : GuideEdges Property (ISurfaceFlattenFeatureData)

Gets or sets the edges to guide the shape and length of the flattened surface.

Visual Basic Syntax

Visual Basic (Declaration)

Property GuideEdges As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
Dim value As System.Object  
  
instance.GuideEdges = value  
value = instance.GuideEdges
```

C#

```
System.Object GuideEdges {get; set;}
```

C++/CLI

```
property System.Object^ GuideEdges {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of the [edges](#) to control the shape and length of the flattened surface

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::GuideEdges](#).

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepInternalControlCurves Property (ISurfaceFlattenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : KeepInternalControlCurves Property (ISurfaceFlattenFeatureData)

Gets or sets whether to keep internal control curves for this surface-flatten feature.

.NET Syntax

Visual Basic (Declaration)

```
Property KeepInternalControlCurves As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
Dim value As System.Boolean
```

```
instance.KeepInternalControlCurves = value
```

```
value = instance.KeepInternalControlCurves
```

C#

```
System.bool KeepInternalControlCurves {get; set;}
```

C++/CLI

```
property System.bool KeepInternalControlCurves {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to keep internal control curves, false to not

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::KeepInternalControlCurves](#).

Example

[Get Data for Surface-flatten Feature \(C#\)](#)
[Get Data for Surface-flatten Feature \(VB.NET\)](#)
[Get Data for Surface-flatten Feature \(VBA\)](#)

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MapEdges Property (ISurfaceFlattenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : MapEdges Property (ISurfaceFlattenFeatureData)

Gets or sets the map edges for this surface-flatten feature.

.NET Syntax

Visual Basic (Declaration)

Property MapEdges As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
Dim value As System.Object  
  
instance.MapEdges = value  
  
value = instance.MapEdges
```

C#

```
System.object MapEdges {get; set;}
```

C++/CLI

```
property System.Object^ MapEdges {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of entities that lie on the selected faces or surfaces to flatten (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::MapEdges](#).

Remarks

Map edges:

- are entities to map to the flattened surface. By default, any entity that lies on top of a face or surface to flatten is ignored unless the user selects the entity as a map edge.
- are useful when users want to see where a selected entity on the original body would lie on a flattened surface. For example, users might select edges as map lines to serve as bend lines in the flattened surface.
- can be any of these types of selected entities:
 - edges,
 - reference curves,
 - 2D/3D splines,
 - sketches, and

- sketch text.

The SOLIDWORKS API returns [edges](#) for the entities selected for the map edges in a surface-flatten feature.

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)
[ISurfaceFlattenFeatureData::TearEdges Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISurfaceFlattenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : ReleaseSelectionAccess Method (ISurfaceFlattenFeatureData)

Releases access to the selections for this surface-flatten feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::ReleaseSelectionAccess](#).

Example

[Get Data for Surface-flatten Feature \(C#\)](#)
[Get Data for Surface-flatten Feature \(VB.NET\)](#)
[Get Data for Surface-flatten Feature \(VBA\)](#)

Remarks

[ISurfaceFlattenFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature. Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) if you did modify the feature.

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

ShouldMakeTears Property (ISurfaceFlattenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : ShouldMakeTears Property (ISurfaceFlattenFeatureData)

Gets or sets whether to enable relief cuts for this surface-flatten feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ShouldMakeTears As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
Dim value As System.Boolean
```

```
instance.ShouldMakeTears = value
```

```
value = instance.ShouldMakeTears
```

C#

```
System.bool ShouldMakeTears {get; set;}
```

C++/CLI

```
property System.bool ShouldMakeTears {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable relief cuts, false to not

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::ShouldMakeTears](#).

Example

[Get Data for Surface-flatten Feature \(C#\)](#)
[Get Data for Surface-flatten Feature \(VB.NET\)](#)
[Get Data for Surface-flatten Feature \(VBA\)](#)

Remarks

[Tear edges](#) identify where to make the relief cuts before flattening the face or surface.

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

TearEdges Property (ISurfaceFlattenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceFlattenFeatureData Interface](#) : TearEdges Property (ISurfaceFlattenFeatureData)

Gets or sets the tear edges for the relief cuts for this surface-flatten feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property TearEdges As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceFlattenFeatureData  
Dim value As System.Object  
  
instance.TearEdges = value  
  
value = instance.TearEdges
```

C#

```
System.Object TearEdges {get; set;}
```

C++/CLI

```
property System.Object^ TearEdges {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of entities that lie on the selected faces or surfaces to flatten (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SurfaceFlattenFeatureData::TearEdges](#).

Example

[Get Data for Surface-flatten Feature \(C#\)](#)
[Get Data for Surface-flatten Feature \(VB.NET\)](#)
[Get Data for Surface-flatten Feature \(VBA\)](#)

Remarks

Tear edges:

- indicate where to make relief cuts before flattening the surface. During flattening, regions of the flattened surface are stretched while other regions are compressed. Adding tear edge through regions of high stress can reduce these deformations, which increases the accuracy of the flattened surface.
- allow users to flatten closed surfaces, such as spheres or entire solid bodies, that would otherwise not be flattened. See the **Example** section.
- can be any of these types of selected entities:
 - edges,
 - reference curves, and
 - 2D/3D splines.
- must each intersect the face or surface being flattened while touching one boundary edge, which is an edge adjacent to exactly one face or surface.
- are only applied when [ISurfaceFlattenFeatureData::ShouldMakeTears](#) is true.

The SOLIDWORKS API returns [edges](#) for the entities selected for the tear edges in a surface-flatten feature.

See Also

[ISurfaceFlattenFeatureData Interface](#)
[ISurfaceFlattenFeatureData Members](#)
[ISurfaceFlattenFeatureData::MapEdges Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0