

SOLIDWORKS API (.NET VBA C#) — Reference (302/337): ISurfacePlanarFeatureData- ISurfaceTrimFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISurfacePlanarFeatureData (Type)

ISurfacePlanarFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfacePlanarFeatureData Interface

Allows access to a planar surface feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISurfacePlanarFeatureData
```

Visual Basic (Usage)

```
Dim instance As ISurfacePlanarFeatureData
```

C#

```
public interface ISurfacePlanarFeatureData
```

C++/CLI

```
public interface class ISurfacePlanarFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SurfacePlanarFeatureData](#).

Example

[Create Planar Surface Feature \(VBA\)](#)
[Create Planar Surface Feature \(VB.NET\)](#)
[Create Planar Surface Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[SurfacePlanarFeatureData](#)

See Also

[ISurfacePlanarFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertPlanarRefSurface Method](#)

ISurfacePlanarFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfacePlanarFeatureData Interface

For a list of all members of this type, see [ISurfacePlanarFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Accesses the selections that define this planar surface feature.
GetBoundingEntitiesCount	Gets the number of bounding entities for this planar surface feature.

 AccessSelections	Accesses the selections that define this planar surface feature.
 GetBoundingEntities	Gets the bounding entities for this planar surface feature.
 SetBoundingEntities	Sets the bounding entities for this planar surface feature.
 ReleaseSelectionAccess	Releases access to the selections for this planar surface feature.

[Top](#)

 See Also

[ISurfacePlanarFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertPlanarRefSurface Method](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

ISurfacePlanarFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfacePlanarFeatureData Interface

The following tables list the members exposed by [ISurfacePlanarFeatureData](#).

 Public Properties

Name	Description
 BoundingEntities	Gets or sets the bounding entities for this planar surface feature.

[Top](#)

 Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this planar surface feature.
 GetBoundingEntitiesCount	Gets the number of bounding entities for this planar surface feature.
 AccessSelections	Accesses the selections that define this planar surface feature.
 GetBoundingEntities	Gets the bounding entities for this planar surface feature.
 SetBoundingEntities	Sets the bounding entities for this planar surface feature.
 ReleaseSelectionAccess	Releases access to the selections for this planar surface feature.

[Top](#)

 See Also

[ISurfacePlanarFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertPlanarRefSurface Method](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

ISurfacePlanarFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfacePlanarFeatureData Interface

For a list of all members of this type, see [ISurfacePlanarFeatureData members](#).

 Public Properties

Name	Description
 BoundingEntities	Gets or sets the bounding entities for this planar surface feature.

[Top](#)

 See Also

[ISurfacePlanarFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertPlanarRefSurface Method](#)

AccessSelections Method (ISurfacePlanarFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfacePlanarFeatureData Interface](#) : AccessSelections Method (ISurfacePlanarFeatureData)

Accesses the selections that define this planar surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfacePlanarFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfacePlanarFeatureData::AccessSelections](#).

Example

See the [ISurfacePlanarFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature

- [ISurfacePlanarFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfacePlanarFeatureData Interface](#)
[ISurfacePlanarFeatureData Members](#)
[ISurfacePlanarFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

BoundingEntities Property (ISurfacePlanarFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfacePlanarFeatureData Interface](#) : BoundingEntities Property (ISurfacePlanarFeatureData)

Gets or sets the bounding entities for this planar surface feature.

.NET Syntax

Visual Basic (Declaration)

Property BoundingEntities As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfacePlanarFeatureData  
Dim value As System.Object
```

```
instance.BoundingEntities = value
```

```
value = instance.BoundingEntities
```

C#

```
System.object BoundingEntities {get; set;}
```

C++/CLI

```
property System.Object^ BoundingEntities {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of bounding entities

Visual Basic for Applications (VBA) Syntax

See [SurfacePlanarFeatureData::BoundingEntities](#).

Example

See the [ISurfacePlanarFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfacePlanarFeatureData Interface](#)
[ISurfacePlanarFeatureData Members](#)
[ISurfacePlanarSurfaceData::GetBoundingEntitiesCount Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBoundingEntitiesCount Method (ISurfacePlanarFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfacePlanarFeatureData Interface](#) : GetBoundingEntitiesCount Method (ISurfacePlanarFeatureData)

Gets the number of bounding entities for this planar surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBoundingEntitiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfacePlanarFeatureData  
Dim value As System.Integer  
  
value = instance.GetBoundingEntitiesCount()
```

C#

```
System.int GetBoundingEntitiesCount()
```

C++/CLI

```
System.int GetBoundingEntitiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bounding entities

Visual Basic for Applications (VBA) Syntax

See [SurfacePlanarFeatureData::GetBoundingEntitiesCount](#).

Example

See the [ISurfacePlanarFeatureData](#) examples.

Remarks

Call this method before calling [ISurfacePlanarFeatureData::IGetBoundingEntities](#) to get the size of the array for that method.

See Also

[ISurfacePlanarFeatureData Interface](#)
[ISurfacePlanarFeatureData Members](#)
[ISurfacePlanarFeatureData::ISetBoundingEntities Method](#)
[ISurfacePlanarFeatureData::BoundingEntities Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ISurfacePlanarFeatureData)

[See Also](#)



Accesses the selections that define this planar surface feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfacePlanarFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfacePlanarFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfacePlanarFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfacePlanarFeatureData Interface](#)
[ISurfacePlanarFeatureData Members](#)
[ISurfacePlanarFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBoundingEntities Method (ISurfacePlanarFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfacePlanarFeatureData Interface](#) : IGetBoundingEntities Method (ISurfacePlanarFeatureData)

Gets the bounding entities for this planar surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBoundingEntities( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfacePlanarFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetBoundingEntities(Count)
```

C#

```
System.object IGetBoundingEntities(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetBoundingEntities(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of bounding entities

Return Value

- in-process, unmanaged C++: Pointer to an array of bounding entities of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISurfacePlanarFeatureData::GetBoundingEntitiesCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfacePlanarFeatureData Interface](#)
[ISurfacePlanarFeatureData Members](#)
[ISurfacePlanarFeatureData::ISetBoundingEntities Method](#)
[ISurfacePlanarFeatureData::BoundingEntities Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetBoundingEntities Method (ISurfacePlanarFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfacePlanarFeatureData Interface](#) : ISetBoundingEntities Method (ISurfacePlanarFeatureData)

Sets the bounding entities for this planar surface feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ISetBoundingEntities( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfacePlanarFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.ISetBoundingEntities(Count)
```

C#

```
System.object ISetBoundingEntities(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ ISetBoundingEntities(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of bounding entities

Return Value

- in-process, unmanaged C++: Pointer to an array of bounding entities of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfacePlanarFeatureData Interface](#)
[ISurfacePlanarFeatureData Members](#)
[ISurfacePlanarFeatureData::GetBoundingEntitiesCount Method](#)
[ISurfacePlanarFeatureData::GetBoundingEntities Method](#)
[ISurfacePlanarFeatureData::BoundingEntities Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISurfacePlanarFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfacePlanarFeatureData Interface](#) : ReleaseSelectionAccess Method (ISurfacePlanarFeatureData)

Releases access to the selections for this planar surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISurfacePlanarFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SurfacePlanarFeatureData::ReleaseSelectionAccess](#).

Example

See the [ISurfacePlanarFeatureData](#) examples.

Remarks

[ISurfacePlanarFeatureData::AccessSelections](#) and [ISurfacePlanarFeatureData::IAccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISurfacePlanarFeatureData Interface](#)
[ISurfacePlanarFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

ISurfaceRadiateFeatureData (Type)

ISurfaceRadiateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceRadiateFeatureData Interface

Allows access to a surface radiate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISurfaceRadiateFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData
```

C#

```
public interface ISurfaceRadiateFeatureData
```

C++/CLI

```
public interface class ISurfaceRadiateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData](#).

Example

[Create Radiate Surface Feature \(VBA\)](#)
[Create Radiate Surface Feature \(VB.NET\)](#)
[Create Radiate Surface Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[SurfaceRadiateFeatureData](#)

See Also

[ISurfaceRadiateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertRadiateSurface Method](#)

ISurfaceRadiateFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceRadiateFeatureData Interface

For a list of all members of this type, see [ISurfaceRadiateFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections for this surface radiate feature.
 GetRadiatedEntitiesCount	Gets the number of radiated entities for this surface radiate feature.

	IAccessSelections	Accesses the selections for this surface radiate feature.
	IGetRadiatedEntities	Gets the radiated entities for this surface radiate feature.
	ISetRadiatedEntities	Sets the radiated entities for this surface radiate feature.
	ReleaseSelectionAccess	Releases access to the selections that define this surface radiate feature.

[Top](#)

See Also

[ISurfaceRadiateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertRadiateSurface Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfaceRadiateFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceRadiateFeatureData Interface

The following tables list the members exposed by [ISurfaceRadiateFeatureData](#).

Public Properties

Name	Description
 DirectionReference	Gets or sets the radiate direction setting for this surface radiate feature.
 Distance	Gets or sets the radiate distance for this surface radiate feature.
 Flip	Gets or sets whether to flip the direction of this surface radiate feature.
 PropagateToTangentFaces	Gets or sets whether to propagate the tangent faces of this surface radiate feature.
 RadiatedEntities	Gets or sets the radiated entities for this surface radiate feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Accesses the selections for this surface radiate feature.
 GetRadiatedEntitiesCount	Gets the number of radiated entities for this surface radiate feature.
 IAccessSelections	Accesses the selections for this surface radiate feature.
 IGetRadiatedEntities	Gets the radiated entities for this surface radiate feature.
 ISetRadiatedEntities	Sets the radiated entities for this surface radiate feature.
 ReleaseSelectionAccess	Releases access to the selections that define this surface radiate feature.

[Top](#)

See Also

[ISurfaceRadiateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertRadiateSurface Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfaceRadiateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceRadiateFeatureData Interface

For a list of all members of this type, see [ISurfaceRadiateFeatureData members](#).

Public Properties

Name	Description
 DirectionReference	Gets or sets the radiate direction setting for this surface radiate feature.
 Distance	Gets or sets the radiate distance for this surface radiate feature.

[Flip](#)

Gets or sets whether to flip the direction of this surface radiate feature.

[PropagateToTangentFaces](#)

Gets or sets whether to propagate the tangent faces of this surface radiate feature.

[RadiatedEntities](#)

Gets or sets the radiated entities for this surface radiate feature.

[Top](#)

See Also

[ISurfaceRadiateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertRadiateSurface Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISurfaceRadiateFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : AccessSelections Method (ISurfaceRadiateFeatureData)

Accesses the selections for this surface radiate feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData::AccessSelections](#).

Example

See the [ISurfaceRadiateFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <code>NULL</code>
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfaceRadiateFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)
[ISurfaceRadiateFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

DirectionReference Property (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : DirectionReference Property (ISurfaceRadiateFeatureData)

Gets or sets the radiate direction setting for this surface radiate feature.

.NET Syntax

Visual Basic (Declaration)

Property DirectionReference As System.Object

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim value As System.Object
```

```
instance.DirectionReference = value
```

```
value = instance.DirectionReference
```

C#

```
System.Object DirectionReference {get; set;}
```

C++/CLI

```
property System.Object^ DirectionReference {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Face, reference plane, or reference surface indicating radiate direction

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData::DirectionReference](#).

Example

See the [ISurfaceRadiateFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)
[ISurfaceRadiateFeatureData::Flip Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

Distance Property (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : Distance Property (ISurfaceRadiateFeatureData)

Gets or sets the radiate distance for this surface radiate feature.

.NET Syntax

Visual Basic (Declaration)

Property Distance As System.Double

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim value As System.Double
```

```
instance.Distance = value
```

```
value = instance.Distance
```

C#

```
System.double Distance {get; set;}
```

C++/CLI

```
property System.double Distance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Width of the surface

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData.Distance](#).

Example

See the [ISurfaceRadiateFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Flip Property (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : Flip Property (ISurfaceRadiateFeatureData)

Gets or sets whether to flip the direction of this surface radiate feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property Flip As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim value As System.Boolean
```

```
instance.Flip = value
```

```
value = instance.Flip
```

C#

```
System.bool Flip {get; set;}
```

C++/CLI

```
property System.bool Flip {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True flips the radiate direction, false does not

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData.Flip](#).

Example

See the [ISurfaceRadiateFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)
[ISurfaceRadiateFeatureData::DirectionReference Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRadiatedEntitiesCount Method (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : GetRadiatedEntitiesCount Method (ISurfaceRadiateFeatureData)

Gets the number of radiated entities for this surface radiate feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRadiatedEntitiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim value As System.Integer  
  
value = instance.GetRadiatedEntitiesCount()
```

C#

```
System.int GetRadiatedEntitiesCount()
```

C++/CLI

```
System.int GetRadiatedEntitiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of radiated entities

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData::GetRadiatedEntitiesCount](#).

Example

See the [ISurfaceRadiateFeatureData](#) examples.

Remarks

Call this method before calling [ISurfaceRadiateFeatureData::IGetRadiatedEntities](#) to get the size of the array for that method.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)
[ISurfaceRadiateFeatureData::ISetRadiatedEntities Method](#)
[ISurfaceRadiateFeatureData::RadiatedEntities Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : IAccessSelections Method (ISurfaceRadiateFeatureData)

Accesses the selections for this surface radiate feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfaceRadiateFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)
[ISurfaceRadiateFeatureData::AccessSelections Method](#)

Availability

IGetRadiatedEntities Method (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : IGetRadiatedEntities Method (ISurfaceRadiateFeatureData)

Gets the radiated entities for this surface radiate feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRadiatedEntities( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetRadiatedEntities(Count)
```

C#

```
System.object IGetRadiatedEntities(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetRadiatedEntities(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of radiated entities

Return Value

- in-process, unmanaged C++: Pointer to an array of radiated entities of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISurfaceRadiateFeatureData::GetRadiatedEntitiesCount](#) before calling this method to get the value of Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

ISetRadiatedEntities Method (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : ISetRadiatedEntities Method (ISurfaceRadiateFeatureData)

Sets the radiated entities for this surface radiate feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetRadiatedEntities( _  
    ByVal Count As System.Integer, _  
    ByRef DispArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim Count As System.Integer  
Dim DispArr As System.Object  
  
instance.ISetRadiatedEntities(Count, DispArr)
```

C#

```
void ISetRadiatedEntities(  
    System.int Count,  
    ref System.object DispArr  
)
```

C++/CLI

```
void ISetRadiatedEntities(  
& System.int Count,  
& System.Object^% DispArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of radiated entities

DispArr

- in-process, unmanaged C++: Pointer to an array of radiated entities of size Count

VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)
[ISurfaceRadiateFeatureData::GetRadiatedEntitiesCount Method](#)
[ISurfaceRadiateFeatureData::IRadiatedEntities Method](#)
[ISurfaceRadiateFeatureData::RadiatedEntities Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateToTangentFaces Property (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : PropagateToTangentFaces Property (ISurfaceRadiateFeatureData)

Gets or sets whether to propagate the tangent faces of this surface radiate feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property PropagateToTangentFaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim value As System.Boolean
```

```
instance.PropagateToTangentFaces = value
```

```
value = instance.PropagateToTangentFaces
```

C#

```
System.bool PropagateToTangentFaces {get; set;}
```

C++/CLI

```
property System.bool PropagateToTangentFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True continues the surface to tangent faces, false does not continue the surface

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData::PropagateToTangentFaces](#).

Example

See the [ISurfaceRadiateFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

RadiatedEntities Property (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : RadiatedEntities Property (ISurfaceRadiateFeatureData)

Gets or sets the radiated entities for this surface radiate feature.

.NET Syntax

Visual Basic (Declaration)

```
Property RadiatedEntities As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
Dim value As System.Object
```

```
instance.RadiatedEntities = value  
value = instance.RadiatedEntities
```

C#

```
System.Object RadiatedEntities {get; set;}
```

C++/CLI

```
property System.Object^ RadiatedEntities {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of radiated entities

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData::RadiatedEntities](#).

Example

See the [ISurfaceRadiateFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)
[ISurfaceRadiateSurfaceData::GetRadiatedEntitiesCount Method](#)
[ISurfaceRadiateSurfaceData::IGetRadiatedEntities Method](#)
[ISurfaceRadiateSurfaceData::ISetRadiatedEntities Method](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISurfaceRadiateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceRadiateFeatureData Interface](#) : ReleaseSelectionAccess Method (ISurfaceRadiateFeatureData)

Releases access to the selections that define this surface radiate feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISurfaceRadiateFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SurfaceRadiateFeatureData::ReleaseSelectionAccess](#).

Example

See the [ISurfaceRadiateFeatureData](#) examples.

Remarks

[ISurfaceRadiateFeatureData::AccessSelections](#) and [ISurfaceRadiateFeatureData::IAccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISurfaceRadiateFeatureData Interface](#)
[ISurfaceRadiateFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

ISurfaceTrimFeatureData (Type)

ISurfaceTrimFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceTrimFeatureData Interface

Allows access to a surface trim feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISurfaceTrimFeatureData
```

Visual Basic (Usage)

```
Dim instance As ISurfaceTrimFeatureData
```

C#

```
public interface ISurfaceTrimFeatureData
```

C++/CLI

```
public interface class ISurfaceTrimFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData](#).

Example

[Create Trimmed Surface Feature \(VBA\)](#)
[Create Trimmed Surface Feature \(VB.NET\)](#)
[Create Trimmed Surface Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[SurfaceTrimFeatureData](#)

See Also

[ISurfaceTrimFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::PostTrimSurface Method](#)
[IFeatureManager::PreTrimSurface Method](#)
[IFeatureManager::SolidForTrim Property](#)

ISurfaceTrimFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceTrimFeatureData Interface

For a list of all members of this type, see [ISurfaceTrimFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Accesses the selections that define this surface trim feature.

	GetPiecesToKeepCount	Gets the number of pieces to keep for this surface trim feature.
	GetTrimToolsCount	Gets the number of trim tools for this surface trim feature.
	GetType	Gets the type of this surface trim feature.
	IAccessSelections	Accesses the selections that define this surface trim feature.
	IGetPiecesToKeep	Gets the pieces to keep for this surface trim feature.
	IGetTrimTools	Gets the trim tools for this surface trim feature.
	ISetPiecesToKeep	Sets the pieces to keep for this surface trim feature.
	ISetTrimTools	Sets the trim tools for this surface trim feature.
	ReleaseSelectionAccess	Releases access to the selections that created this surface trim feature.

[Top](#)

 See Also

[ISurfaceTrimFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::PostTrimSurface Method](#)
[IFeatureManager::PreTrimSurface Method](#)
[IFeatureManager::SolidForTrim Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISurfaceTrimFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfaceTrimFeatureData Interface

The following tables list the members exposed by [ISurfaceTrimFeatureData](#).

 Public Properties

Name	Description
 PiecesToKeep	Gets the pieces to keep for this surface trim feature. NOTE: This property is a get-only property. Set is not implemented.
 TrimTools	Gets the trim tools for surface trim feature. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 Public Methods

Name	Description
	AccessSelections Accesses the selections that define this surface trim feature.
	GetPiecesToKeepCount Gets the number of pieces to keep for this surface trim feature.
	GetTrimToolsCount Gets the number of trim tools for this surface trim feature.
	GetType Gets the type of this surface trim feature.
	IAccessSelections Accesses the selections that define this surface trim feature.
	IGetPiecesToKeep Gets the pieces to keep for this surface trim feature.
	IGetTrimTools Gets the trim tools for this surface trim feature.
	ISetPiecesToKeep Sets the pieces to keep for this surface trim feature.
	ISetTrimTools Sets the trim tools for this surface trim feature.
	ReleaseSelectionAccess Releases access to the selections that created this surface trim feature.

[Top](#)

 See Also

ISurfaceTrimFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [ISurfaceTrimFeatureData Interface](#)

For a list of all members of this type, see [ISurfaceTrimFeatureData members](#).

Public Properties

Name	Description
 PiecesToKeep	Gets the pieces to keep for this surface trim feature. NOTE: This property is a get-only property. Set is not implemented.
 TrimTools	Gets the trim tools for surface trim feature. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[ISurfaceTrimFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::PostTrimSurface Method](#)
[IFeatureManager::PreTrimSurface Method](#)
[IFeatureManager::SolidForTrim Property](#)

AccessSelections Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : [AccessSelections Method \(ISurfaceTrimFeatureData\)](#)

Accesses the selections that define this surface trim feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISurfaceTrimFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,
```



```
& System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::AccessSelections](#).

Example

See the [ISurfaceTrimFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you modified the feature
- [ISurfaceTrimFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceTrimFeatureData Interface](#)

[ISurfaceTrimFeatureData Members](#)

[ISurfaceTrimFeatureData::!AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPiecesToKeepCount Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : GetPiecesToKeepCount Method (ISurfaceTrimFeatureData)

Gets the number of pieces to keep for this surface trim feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPiecesToKeepCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData
Dim value As System.Integer
```

```
value = instance.GetPiecesToKeepCount()
```

C#

```
System.int GetPiecesToKeepCount()
```

C++/CLI

```
System.int GetPiecesToKeepCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of pieces to keep

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::GetPiecesToKeepCount](#).

Example

See the [ISurfaceTrimFeatureData](#) examples.

Remarks

Call this method before calling [ISurfaceTrimFeatureData::IGetPiecesToKeep](#) to get the size of the array for that method.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)
[ISurfaceTrimFeatureData::ISetPiecesToKeep Method](#)
[ISurfaceTrimFeatureData::PiecesToKeep Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrimToolsCount Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : GetTrimToolsCount Method (ISurfaceTrimFeatureData)

Gets the number of trim tools for this surface trim feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimToolsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData  
Dim value As System.Integer
```

```
value = instance.GetTrimToolsCount()
```

C#

```
System.int GetTrimToolsCount()
```

C++/CLI

```
System.int GetTrimToolsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of trim tools

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::GetTrimToolsCount](#).

Example

See the [ISurfaceTrimFeatureData](#) examples.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)
[ISurfaceTrimFeatureData::GetTrimTools Method](#)
[ISurfaceTrimFeatureData::ISetTrimTools Method](#)
[ISurfaceTrimFeatureData::TrimTools Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetType Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : GetType Method (ISurfaceTrimFeatureData)

Gets the type of this surface trim feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData  
Dim value As System.Integer  
  
value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Surface trim feature type as defined in [swSurfaceTrimType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::GetType](#).

Example

See the [ISurfaceTrimFeatureData](#) examples.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)

Availability

IAccessSelections Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : IAccessSelections Method (ISurfaceTrimFeatureData)

Accesses the selections that define this surface trim feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfaceTrimFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)
[ISurfaceTrimFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetPiecesToKeep Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : IGetPiecesToKeep Method (ISurfaceTrimFeatureData)

Gets the pieces to keep for this surface trim feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPiecesToKeep( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData  
Dim Count As System.Integer  
Dim value As Body2  
  
value = instance.IGetPiecesToKeep(Count)
```

C#

```
Body2 IGetPiecesToKeep(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetPiecesToKeep(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of pieces to keep

Return Value

- in-process, unmanaged C++: Pointer to an array of pieces to keep of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISurfaceTrimFeatureData::GetPiecesToKeepCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)
[ISurfaceTrimFeatureData::ISetPiecesToKeep Method](#)
[ISurfaceTrimFeatureData::PiecesToKeep Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTrimTools Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : IGetTrimTools Method (ISurfaceTrimFeatureData)

Gets the trim tools for this surface trim feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetTrimTools( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetTrimTools(Count)
```

C#

```
System.object IGetTrimTools(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetTrimTools(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of trim tools

Return Value

- in-process, unmanaged C++: Pointer to an array of trim tools of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::IGetTrimTools](#).

Remarks

Call [ISurfaceTrimFeatureData::GetTrimToolsCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)
[ISurfaceTrimFeatureData::ISetTrimTools Method](#)
[ISurfaceTrimFeatureData::TrimTools Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetPiecesToKeep Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : ISetPiecesToKeep Method (ISurfaceTrimFeatureData)

Sets the pieces to keep for this surface trim feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetPiecesToKeep( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArr As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData  
Dim Count As System.Integer  
Dim BodyArr As Body2  
  
instance.ISetPiecesToKeep(Count, BodyArr)
```

C#

```
void ISetPiecesToKeep(  
    System.int Count,  
    ref Body2 BodyArr  
)
```

C++/CLI

```
void ISetPiecesToKeep(  
& System.int Count,  
& Body2^% BodyArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of pieces to keep

BodyArr

- in-process, unmanaged C++: Pointer to an array of pieces to keep of size Count

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceTrimFeatureData Interface](#)

[ISurfaceTrimFeatureData Members](#)

[ISurfaceTrimFeatureData::GetPiecesToKeepCount Method](#)

[ISurfaceTrimFeatureData::ISetPiecesToKeep Method](#)

[ISurfaceTrimFeatureData::PiecesToKeep Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetTrimTools Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : ISetTrimTools Method (ISurfaceTrimFeatureData)

Sets the trim tools for this surface trim feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetTrimTools( _  
    ByVal Count As System.Integer, _  
    ByRef DispArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData  
Dim Count As System.Integer  
Dim DispArr As System.Object  
  
instance.ISetTrimTools(Count, DispArr)
```

C#

```
void ISetTrimTools(  
    System.int Count,  
    ref System.object DispArr  
)
```

C++/CLI

```
void ISetTrimTools(  
& System.int Count,  
& System.Object^% DispArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of trim tools

DispArr

- in-process, unmanaged C++: Pointer to an array of trim tools of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)
[ISurfaceTrimFeatureData::GetTrimToolsCount Method](#)
[ISurfaceTrimFeatureData::ISetTrimTools Method](#)
[ISurfaceTrimFeatureData::TrimTools Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PiecesToKeep Property (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : PiecesToKeep Property (ISurfaceTrimFeatureData)

Gets the pieces to keep for this surface trim feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property PiecesToKeep As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfaceTrimFeatureData  
Dim value As System.Object
```

```
instance.PiecesToKeep = value
```

```
value = instance.PiecesToKeep
```

C#

```
System.Object PiecesToKeep {get; set;}
```

C++/CLI

```
property System.Object^ PiecesToKeep {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of pieces to keep

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::PiecesToKeep](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)
[ISurfaceTrimFeatureData::GetPiecesToKeepCount Method](#)
[ISurfaceTrimFeatureData::IGetPiecesToKeep Method](#)
[ISurfaceTrimFeatureData::ISetPiecesToKeep Method](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : ReleaseSelectionAccess Method (ISurfaceTrimFeatureData)

Releases access to the selections that created this surface trim feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)

```
Dim instance As ISurfaceTrimFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::ReleaseSelectionAccess](#).

Example

See the [ISurfaceTrimFeatureData](#) examples.

Remarks

[ISurfaceTrimFeatureData::AccessSelections](#) and [ISurfaceTrimFeatureData::IAccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

TrimTools Property (ISurfaceTrimFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfaceTrimFeatureData Interface](#) : TrimTools Property (ISurfaceTrimFeatureData)

Gets the trim tools for surface trim feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property TrimTools As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISurfaceTrimFeatureData  
Dim value As System.Object  
  
instance.TrimTools = value  
  
value = instance.TrimTools
```

C#

```
System.Object TrimTools {get; set;}
```

C++/CLI

```
property System.Object^ TrimTools {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of trim tools

Visual Basic for Applications (VBA) Syntax

See [SurfaceTrimFeatureData::TrimTools](#).

Example

See the [ISurfaceTrimFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfaceTrimFeatureData Interface](#)
[ISurfaceTrimFeatureData Members](#)
[ISurfaceTrimFeatureData::GetTrimToolsCount Method](#)
[ISurfaceTrimFeatureData::IGetTrimTools Method](#)
[ISurfaceTrimFeatureData::ISetTrimTools Method](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2