

SOLIDWORKS API (.NET VBA C#) — Reference

(303/337): ISurfExtrudeFeatureData- ISurfRevolveFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISurfExtrudeFeatureData (Type)

ISurfExtrudeFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfExtrudeFeatureData Interface

Allows access to an extruded surface feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISurfExtrudeFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData
```

C#

```
public interface ISurfExtrudeFeatureData
```

C++/CLI

```
public interface class ISurfExtrudeFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData](#).

Example

[Insert Extruded Surface \(VBA\)](#)
[Insert Extruded Surface \(VB.NET\)](#)
[Insert Extruded Surface \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[SurfExtrudeFeatureData](#)

See Also

[ISurfExtrudeFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModeler::CreateExtrusionSurface Method](#)
[IModeler::ICreateExtrusionSurface Method](#)
[IFeatureManager::FeatureExtruRefSurface2 Method](#)

ISurfExtrudeFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfExtrudeFeatureData Interface

The following tables list the members exposed by [ISurfExtrudeFeatureData](#).

Public Properties

Name	Description
 BothDirections	Gets or sets whether this surface is extruded in both directions.

	D1CapEnd	Gets or sets whether to cap the end of the extruded surface in Direction 1.
	D1DraftAngle	Gets or sets the angle of the draft of this extruded surface in Direction 1.
	D1DraftOn	Gets or sets whether to draft the extruded surface in Direction 1.
	D1DraftOutward	Gets or sets whether to draft the extruded surface outward or inward in Direction 1.
	D2CapEnd	Gets or sets whether to cap the end of the extruded surface in Direction 2.
	D2DraftAngle	Gets or sets the angle of the draft of this extruded surface in Direction 2.
	D2DraftOn	Gets or sets whether to draft the extruded surface in Direction 2.
	D2DraftOutward	Gets or sets whether to draft the extruded surface outward or inward in Direction 2.
	DeleteOriginalFace	Gets or sets whether to delete the original faces of this extruded surface.
	KnitResult	Gets or sets whether to knit the bodies created by deleting original faces in an extruded surface.
	ReverseDirection	Gets or sets whether the direction of this extruded surface is reversed.

[Top](#)

Public Methods

Name	Description
	AccessSelections Accesses the selections that define this extruded surface.
	GetDepth Gets the depth of the feature in the forward or reverse direction.
	GetEndCondition Gets the end condition of this extruded surface for the forward or reverse direction.
	GetFace Gets the end condition face for this extruded surface in the forward or reverse direction.
	GetReverseOffset Gets the reverse offset direction setting for the end condition of this extruded surface.
	GetTranslateSurface Gets the translate surface setting for this extruded surface.
	GetVertex Gets the end condition vertex in the forward or reverse direction for this extruded surface.
	IAccessSelections Accesses the selections that define this extruded surface.
	IGetFace Gets the end condition face for this extruded surface in the forward or reverse direction.
	IGetVertex Gets the end condition vertex in the forward or reverse direction for this extruded surface.
	ISetFace Sets the end condition face for this extruded surface in the forward or reverse direction.
	ISetVertex Sets the end condition vertex in the forward or reverse direction for this extruded surface.
	ReleaseSelectionAccess Releases access to the selections for this extruded surface.
	SetDepth Sets the depth of this extruded surface in the forward or reverse direction.
	SetEndCondition Sets the end condition of this extruded surface in the forward or reverse direction.
	SetFace Sets the end condition face for this extruded surface in the forward or reverse direction.
	SetReverseOffset Sets the reverse offset direction setting for the end condition of this extruded surface.
	SetTranslateSurface Sets the translate surface setting for this extruded surface.
	SetVertex Sets the end condition vertex in the forward or reverse direction for this extruded surface.

[Top](#)

See Also

[ISurfExtrudeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModeler::CreateExtrusionSurface Method](#)
[IModeler::ICreateExtrusionSurface Method](#)
[IFeatureManager::FeatureExtruRefSurface2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfExtrudeFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [ISurfExtrudeFeatureData Interface](#)

For a list of all members of this type, see [ISurfExtrudeFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this extruded surface.
 GetDepth	Gets the depth of the feature in the forward or reverse direction.
 GetEndCondition	Gets the end condition of this extruded surface for the forward or reverse direction.
 GetFace	Gets the end condition face for this extruded surface in the forward or reverse direction.
 GetReverseOffset	Gets the reverse offset direction setting for the end condition of this extruded surface.
 GetTranslateSurface	Gets the translate surface setting for this extruded surface.
 GetVertex	Gets the end condition vertex in the forward or reverse direction for this extruded surface.
 IAccessSelections	Accesses the selections that define this extruded surface.
 IGetFace	Gets the end condition face for this extruded surface in the forward or reverse direction.
 IGetVertex	Gets the end condition vertex in the forward or reverse direction for this extruded surface.
 ISetFace	Sets the end condition face for this extruded surface in the forward or reverse direction.
 ISetVertex	Sets the end condition vertex in the forward or reverse direction for this extruded surface.
 ReleaseSelectionAccess	Releases access to the selections for this extruded surface.
 SetDepth	Sets the depth of this extruded surface in the forward or reverse direction.
 SetEndCondition	Sets the end condition of this extruded surface in the forward or reverse direction.
 SetFace	Sets the end condition face for this extruded surface in the forward or reverse direction.
 SetReverseOffset	Sets the reverse offset direction setting for the end condition of this extruded surface.
 SetTranslateSurface	Sets the translate surface setting for this extruded surface.
 SetVertex	Sets the end condition vertex in the forward or reverse direction for this extruded surface.

[Top](#)

See Also

[ISurfExtrudeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModeler::CreateExtrusionSurface Method](#)
[IModeler::ICreateExtrusionSurface Method](#)
[IFeatureManager::FeatureExtruRefSurface2 Method](#)

ISurfExtrudeFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfExtrudeFeatureData Interface

For a list of all members of this type, see [ISurfExtrudeFeatureData members](#).

Public Properties

Name	Description
 BothDirections	Gets or sets whether this surface is extruded in both directions.
 D1CapEnd	Gets or sets whether to cap the end of the extruded surface in Direction 1.
 D1DraftAngle	Gets or sets the angle of the draft of this extruded surface in Direction 1.
 D1DraftOn	Gets or sets whether to draft the extruded surface in Direction 1.
 D1DraftOutward	Gets or sets whether to draft the extruded surface outward or inward in Direction 1.
 D2CapEnd	Gets or sets whether to cap the end of the extruded surface in Direction 2.
 D2DraftAngle	Gets or sets the angle of the draft of this extruded surface in Direction 2.
 D2DraftOn	Gets or sets whether to draft the extruded surface in Direction 2.

	D2DraftOutward	Gets or sets whether to draft the extruded surface outward or inward in Direction 2.
	DeleteOriginalFace	Gets or sets whether to delete the original faces of this extruded surface.
	KnitResult	Gets or sets whether to knit the bodies created by deleting original faces in an extruded surface.
	ReverseDirection	Gets or sets whether the direction of this extruded surface is reversed.

[Top](#)

See Also

[ISurfExtrudeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModeler::CreateExtrusionSurface Method](#)
[IModeler::ICreateExtrusionSurface Method](#)
[IFeatureManager::FeatureExtruRefSurface2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : AccessSelections Method (ISurfExtrudeFeatureData)

Accesses the selections that define this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISurfExtrudeFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::AccessSelections](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfExtrudeFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BothDirections Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : BothDirections Property (ISurfExtrudeFeatureData)

Gets or sets whether this surface is extruded in both directions.

.NET Syntax

Visual Basic (Declaration)

Property BothDirections As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Boolean
```

```
instance.BothDirections = value
```

```
value = instance.BothDirections
```

C#

```
System.bool BothDirections {get; set;}
```

C++/CLI

```
property System.bool BothDirections {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True extrudes the surface in both directions, false does not

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::BothDirections](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D1CapEnd Property\(\)](#)
[ISurfExtrudeFeatureData::D1DraftAngle Property\(\)](#)
[ISurfExtrudeFeatureData::D1DraftOn Property\(\)](#)
[ISurfExtrudeFeatureData::D1DraftOutward Property\(\)](#)
[ISurfExtrudeFeatureData::D2CapEnd Property\(\)](#)
[ISurfExtrudeFeatureData::D2DraftAngle Property\(\)](#)
[ISurfExtrudeFeatureData::D2DraftOn Property\(\)](#)
[ISurfExtrudeFeatureData::D2DraftOutward Property\(\)](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

D1CapEnd Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : D1CapEnd Property (ISurfExtrudeFeatureData)

Gets or sets whether to cap the end of the extruded surface in Direction 1.

.NET Syntax

Visual Basic (Declaration)

Property D1CapEnd As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Boolean  
  
instance.D1CapEnd = value  
  
value = instance.D1CapEnd
```

C#

```
System.bool D1CapEnd {get; set;}
```

C++/CLI

```
property System.bool D1CapEnd {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to cap the end in Direction 1, false to not

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::D1CapEnd](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D1DraftAngle Property\(\)](#)
[ISurfExtrudeFeatureData::D1DraftOn Property\(\)](#)
[ISurfExtrudeFeatureData::D1DraftOutward Property\(\)](#)
[ISurfExtrudeFeatureData::BothDirections Property\(\)](#)
[ISurfExtrudeFeatureData::D2CapEnd Property\(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1DraftAngle Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : D1DraftAngle Property (ISurfExtrudeFeatureData)

Gets or sets the angle of the draft of this extruded surface in Direction 1.

.NET Syntax

Visual Basic (Declaration)

Property D1DraftAngle As System.Double

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Double
```

```
instance.D1DraftAngle = value
```

```
value = instance.D1DraftAngle
```

C#

```
System.double D1DraftAngle {get; set;}
```

C++/CLI

```
property System.double D1DraftAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Draft angle in Direction 1 (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::D1DraftAngle](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

This property is only available if [ISurfExtrudeFeatureData::D1DraftOn](#) = true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D1DraftOutward Property \(\)](#)
[ISurfExtrudeFeatureData::BothDirections Property \(\)](#)
[ISurfExtrudeFeatureData::D1CapEnd Property \(\)](#)
[ISurfExtrudeFeatureData::D2DraftAngle Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1DraftOn Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : D1DraftOn Property (ISurfExtrudeFeatureData)

Gets or sets whether to draft the extruded surface in Direction 1.

.NET Syntax

Visual Basic (Declaration)

Property D1DraftOn As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Boolean  
  
instance.D1DraftOn = value  
  
value = instance.D1DraftOn
```

C#

```
System.bool D1DraftOn {get; set;}
```

C++/CLI

```
property System.bool D1DraftOn {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to draft the extruded surface in Direction 1, false to not

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::D1DraftOn](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D1DraftAngle Property \(\)](#)
[ISurfExtrudeFeatureData::D1DraftOutward Property \(\)](#)
[ISurfExtrudeFeatureData::D1CapEnd Property \(\)](#)
[ISurfExtrudeFeatureData::BothDirections Property \(\)](#)
[ISurfExtrudeFeatureData::D2DraftOn Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1DraftOutward Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : D1DraftOutward Property (ISurfExtrudeFeatureData)

Gets or sets whether to draft the extruded surface outward or inward in Direction 1.

.NET Syntax

Visual Basic (Declaration)

Property D1DraftOutward As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Boolean
```

```
instance.D1DraftOutward = value
```

```
value = instance.D1DraftOutward
```

C#

```
System.bool D1DraftOutward {get; set;}
```

C++/CLI

```
property System.bool D1DraftOutward {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to draft the extruded surface outward in Direction 1, false to draft the extruded surface inward in Direction 1 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::D1DraftOutward](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

This property is only available if [ISurfExtrudeFeatureData::D1DraftOn](#) = true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D1DraftAngle Property \(\)](#)
[ISurfExtrudeFeatureData::D1CapEnd Property \(\)](#)
[ISurfExtrudeFeatureData::BothDirections Property \(\)](#)

[ISurfExtrudeFeatureData::D1CapEnd Property \(\)](#)
[ISurfExtrudeFeatureData::D2DraftOutward Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2CapEnd Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : D2CapEnd Property (ISurfExtrudeFeatureData)

Gets or sets whether to cap the end of the extruded surface in Direction 2.

.NET Syntax

Visual Basic (Declaration)

Property D2CapEnd As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Boolean
```

```
instance.D2CapEnd = value
```

```
value = instance.D2CapEnd
```

C#

```
System.bool D2CapEnd {get; set;}
```

C++/CLI

```
property System.bool D2CapEnd {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to cap the end in Direction 2, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::D2CapEnd](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

This property is only available if [ISurfExtrudeFeatureData::BothDirections](#) = true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D2DraftAngle Property \(\)](#)
[ISurfExtrudeFeatureData::D2DraftOn Property \(\)](#)
[ISurfExtrudeFeatureData::D2DraftOutward Property \(\)](#)
[ISurfExtrudeFeatureData::D1CapEnd Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2DraftAngle Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : D2DraftAngle Property (ISurfExtrudeFeatureData)

Gets or sets the angle of the draft of this extruded surface in Direction 2.

.NET Syntax

Visual Basic (Declaration)

Property D2DraftAngle As System.Double

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Double
```

```
instance.D2DraftAngle = value
```

```
value = instance.D2DraftAngle
```

C#

```
System.double D2DraftAngle {get; set;}
```

C++/CLI

```
property System.double D2DraftAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Draft angle in Direction 2 (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::D2DraftAngle](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

This property is only available if:

- [ISurfExtrudeFeatureData::BothDirections](#) = true.
- [ISurfExtrudeFeatureData::D2DraftOn](#) = true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D2DraftOutward Property\(\)](#)
[ISurfExtrudeFeatureData::D1DraftAngle Property\(\)](#)
[ISurfExtrudeFeatureData::D2CapEnd Property\(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

D2DraftOn Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : D2DraftOn Property (ISurfExtrudeFeatureData)

Gets or sets whether to draft the extruded surface in Direction 2.

.NET Syntax

Visual Basic (Declaration)

Property D2DraftOn As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Boolean  
  
instance.D2DraftOn = value  
  
value = instance.D2DraftOn
```

C#

```
System.bool D2DraftOn {get; set;}
```

C++/CLI

```
property System.bool D2DraftOn {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to draft the extruded surface in Direction 2, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::D2DraftOn](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

This property is only available if [ISurfExtrudeFeatureData::BothDirections](#) = true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D2DraftAngle Property \(\)](#)
[ISurfExtrudeFeatureData::D2DraftOutward Property \(\)](#)
[ISurfExtrudeFeatureData::D2CapEnd Property \(\)](#)
[ISurfExtrudeFeatureData::D1DraftOn Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

D2DraftOutward Property (ISurfExtrudeFeatureData)

[See Also](#)



Gets or sets whether to draft the extruded surface outward or inward in Direction 2.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property D2DraftOutward As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData
Dim value As System.Boolean
```

```
instance.D2DraftOutward = value
```

```
value = instance.D2DraftOutward
```

C#

```
System.bool D2DraftOutward {get; set;}
```

C++/CLI

```
property System.bool D2DraftOutward {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to draft the extruded surface outward in Direction 2, false to draft the extruded surface inward in Direction 2 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::D2DraftOutward](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

This property is only available if:

- [ISurfExtrudeFeatureData::BothDirections](#) = true.
- [ISurfExtrudeFeatureData::D2DraftOn](#) = true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::D2DraftAngle Property \(\)](#)
[ISurfExtrudeFeatureData::D2CapEnd Property \(\)](#)
[ISurfExtrudeFeatureData::D1DraftOutward Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

DeleteOriginalFace Property (ISurfExtrudeFeatureData)

[See Also](#)



Gets or sets whether to delete the original faces of this extruded surface.

.NET Syntax

Visual Basic (Declaration)

Property DeleteOriginalFace As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData
Dim value As System.Boolean

instance.DeleteOriginalFace = value
value = instance.DeleteOriginalFace
```

C#

```
System.bool DeleteOriginalFace {get; set;}
```

C++/CLI

```
property System.bool DeleteOriginalFace {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to delete the original faces, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::DeleteOriginalFace](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

This property is only available if [ISurfExtrudeFeatureData::BothDirections](#) = false.

Deleting original faces results in the model being hollow where the faces were deleted and creates multiple bodies. To create a single body when original faces are deleted, use [ISurfExtrudeFeatureData::KnitResult](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDepth Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : GetDepth Method (ISurfExtrudeFeatureData)

Gets the depth of the feature in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDepth( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetDepth(Forward)
```

C#

```
System.double GetDepth(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetDepth(  
&    System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True gets the depth in the forward direction, false gets it in the reverse direction

Return Value

Extrusion depth

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::GetDepth](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::SetDepth Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEndCondition Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : GetEndCondition Method (ISurfExtrudeFeatureData)

Gets the end condition of this extruded surface for the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndCondition( _  
    ByVal Forward As System.Boolean _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetEndCondition(Forward)
```

C#

```
System.int GetEndCondition(  
    System.bool Forward  
)
```

C++/CLI

```
System.int GetEndCondition(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True gets the end condition in the forward direction, false gets it in the reverse direction

Return Value

End condition as defined in [swEndConditions_e](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::GetEndCondition](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::SetEndCondition Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFace Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : GetFace Method (ISurfExtrudeFeatureData)

Gets the end condition face for this extruded surface in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFace( _  
    ByVal Forward As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Object  
  
value = instance.GetFace(Forward)
```

C#

```
System.object GetFace(  
    System.bool Forward  
)
```

C++/CLI

```
System.Object^ GetFace(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True gets the end condition face in the forward direction, false gets it in the reverse direction

Return Value

End condition [face](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::GetFace](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::SetFace Method](#)
[ISurfExtrudeFeatureData::IGetFace Method](#)
[ISurfExtrudeFeatureData::ISetFace Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetReverseOffset Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : GetReverseOffset Method (ISurfExtrudeFeatureData)

Gets the reverse offset direction setting for the end condition of this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReverseOffset( _  
    ByVal Fwd As System.Boolean _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Fwd As System.Boolean  
Dim value As System.Boolean  
  
value = instance.GetReverseOffset(Fwd)
```

C#

```
System.bool GetReverseOffset(  
    System.bool Fwd  
)
```

C++/CLI

```
System.bool GetReverseOffset(  
& System.bool Fwd  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fwd

True gets the reverse offset setting in the forward direction, false gets it in the reverse direction

Return Value

True if the reverse offset setting is enabled, false if it is disabled

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::GetReverseOffset](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::SetReverseOffset Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTranslateSurface Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : GetTranslateSurface Method (ISurfExtrudeFeatureData)

Gets the translate surface setting for this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTranslateSurface( _  
    ByVal Fwd As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Fwd As System.Boolean  
Dim value As System.Boolean  
  
value = instance.GetTranslateSurface(Fwd)
```

C#

```
System.bool GetTranslateSurface(  
    System.bool Fwd  
)
```

C++/CLI

```
System.bool GetTranslateSurface(  
& System.bool Fwd  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fwd

True gets the translate surface setting in the forward direction, false gets it in the reverse direction

Return Value

True if the translate surface setting is enabled, false if it is disabled

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::GetTranslateSurface](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfTranslateFeatureData::SetTranslateSurface Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVertex Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : GetVertex Method (ISurfExtrudeFeatureData)

Gets the end condition vertex in the forward or reverse direction for this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertex(  
    ByVal Forward As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Object  
  
value = instance.GetVertex(Forward)
```

C#

```
System.object GetVertex(  
    System.bool Forward  
)
```

C++/CLI

```
System.Object^ GetVertex(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True gets the vertex in the forward direction, false gets it in the reverse direction

Return Value

End condition [vertex](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::GetVertex](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::SetVertex Method](#)
[ISurfExtrudeFeatureData::IGetVertex Method](#)
[ISurfExtrudeFeatureData::ISetVertex Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : IAccessSelections Method (ISurfExtrudeFeatureData)

Accesses the selections that define this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections(  
    ByVal TopDoc As ModelDoc2, _
```

```
ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you modified the feature
- [ISurfExtrudeFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFace Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : IGetFace Method (ISurfExtrudeFeatureData)

Gets the end condition face for this extruded surface in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFace( _  
    ByVal Forward As System.Boolean _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As Face2  
  
value = instance.IGetFace(Forward)
```

C#

```
Face2 IGetFace(  
    System.bool Forward  
)
```

C++/CLI

```
Face2^ IGetFace(  
&    System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True gets the end condition face in the forward direction, false gets it in the reverse direction

Return Value

End condition [face](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::IGetFace](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::GetFace Method](#)
[ISurfExtrudeFeatureData::ISetFace Method](#)
[ISurfExtrudeFeatureData::SetFace Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic](#).

IGetVertex Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : IGetVertex Method (ISurfExtrudeFeatureData)

Gets the end condition vertex in the forward or reverse direction for this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVertex( _  
    ByVal Forward As System.Boolean _  
) As Vertex
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As Vertex  
  
value = instance.IGetVertex(Forward)
```

C#

```
Vertex IGetVertex(  
    System.bool Forward  
)
```

C++/CLI

```
Vertex^ IGetVertex(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True gets the vertex in the forward direction, false gets it in the reverse direction

Return Value

End condition [vertex](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::IGetVertex](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::GetVertex Method](#)
[ISurfExtrudeFeatureData::ISetVertex Method](#)
[ISurfExtrudeFeatureData::SetVertex Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFace Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : ISetFace Method (ISurfExtrudeFeatureData)

Sets the end condition face for this extruded surface in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFace( _  
    ByVal Forward As System.Boolean, _
```

```
ByVal Face As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Face As Face2
```

```
instance.ISetFace(Forward, Face)
```

C#

```
void ISetFace(  
    System.bool Forward,  
    Face2 Face  
)
```

C++/CLI

```
void ISetFace(  
& System.bool Forward,  
& Face2^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True sets the end condition face in the forward direction, false sets it in the reverse direction

Face

End condition [face](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::ISetFace](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::SetFace Method](#)
[ISurfExtrudeFeatureData::GetFace Method](#)
[ISurfExtrudeFeatureData::IGetFace Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetVertex Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : ISetVertex Method (ISurfExtrudeFeatureData)

Sets the end condition vertex in the forward or reverse direction for this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetVertex( _  
    ByVal Forward As System.Boolean, _  
    ByVal Vtx As Vertex _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Vtx As Vertex
```

```
instance.ISetVertex(Forward, Vtx)
```

C#

```
void ISetVertex(  
    System.bool Forward,  
    Vertex Vtx  
)
```

C++/CLI

```
void ISetVertex(  
& System.bool Forward,  
& Vertex^ Vtx  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True sets the vertex in the forward direction, false sets it in the reverse direction

Vtx

End condition [vertex](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData.ISetVertex](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::SetVertex Method](#)
[ISurfExtrudeFeatureData::GetVertex Method](#)
[ISurfExtrudeFeatureData::IGetVertex Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

KnitResult Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : KnitResult Property (ISurfExtrudeFeatureData)

Gets or sets whether to knit the bodies created by deleting original faces in an extruded surface.

.NET Syntax

Visual Basic (Declaration)

Property KnitResult As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Boolean  
  
instance.KnitResult = value  
  
value = instance.KnitResult
```

C#

```
System.bool KnitResult {get; set;}
```

C++/CLI

```
property System.bool KnitResult {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to knit the bodies created by deleting original faces, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::KnitResult](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

This property is only available if:

- [ISurfExtrudeFeatureData::BothDirections](#) = false.
- [ISurfExtrudeFeatureData::DeleteOriginalFace](#) = true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : ReleaseSelectionAccess Method (ISurfExtrudeFeatureData)

Releases access to the selections for this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::ReleaseSelectionAccess](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

[ISurfExtrudeFeatureData::AccessSelections](#) and [ISurfExtrudeFeatureData::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : ReverseDirection Property (ISurfExtrudeFeatureData)

Gets or sets whether the direction of this extruded surface is reversed.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the extrude direction, false does not

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::ReverseDirection](#).

Example

See the [ISurfExtrudeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDepth Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : SetDepth Method (ISurfExtrudeFeatureData)

Sets the depth of this extruded surface in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDepth( _
    ByVal Forward As System.Boolean, _
    ByVal Depth As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData
Dim Forward As System.Boolean
Dim Depth As System.Double

instance.SetDepth(Forward, Depth)
```

C#

```
void SetDepth(
    System.bool Forward,
    System.double Depth
)
```

C++/CLI

```
void SetDepth(
    & System.bool Forward,
```

```
& System.double Depth
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward
True sets the depth in the forward direction, false sets it in the reverse direction
Depth
Extrusion depth

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::SetDepth](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::GetDepth Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEndCondition Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : SetEndCondition Method (ISurfExtrudeFeatureData)

Sets the end condition of this extruded surface in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEndCondition( _
    ByVal Forward As System.Boolean, _
    ByVal EndCondition As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData
Dim Forward As System.Boolean
Dim EndCondition As System.Integer

instance.SetEndCondition(Forward, EndCondition)
```

C#

```
void SetEndCondition(
    System.bool Forward,
    System.int EndCondition
)
```

C++/CLI

```
void SetEndCondition(
& System.bool Forward,
& System.int EndCondition
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True sets the end condition in the forward direction, false sets it in the reverse direction

EndCondition

End condition as defined in [swEndConditions_e](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::SetEndCondition](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)

[ISurfExtrudeFeatureData Members](#)

[ISurfExtrudeFeatureData::GetEndCondition Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFace Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : SetFace Method (ISurfExtrudeFeatureData)

Sets the end condition face for this extruded surface in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFace( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Face As System.Object  
  
instance.SetFace(Forward, Face)
```

C#

```
void SetFace(  
    System.bool Forward,  
    System.object Face  
)
```

C++/CLI

```
void SetFace(  
& System.bool Forward,  
& System.Object^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True sets the end condition face in the forward direction, false sets it in the reverse direction

Face
End condition [face](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::SetFace](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::ISetFace Method](#)
[ISurfExtrudeFeatureData::GetFace Method](#)
[ISurfExtrudeFeatureData::ISetFace Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetReverseOffset Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : SetReverseOffset Method (ISurfExtrudeFeatureData)

Sets the reverse offset direction setting for the end condition of this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetReverseOffset( _  
    ByVal Fwd As System.Boolean, _  
    ByVal RevOffset As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Fwd As System.Boolean  
Dim RevOffset As System.Boolean  
  
instance.SetReverseOffset(Fwd, RevOffset)
```

C#

```
void SetReverseOffset(  
    System.bool Fwd,  
    System.bool RevOffset  
)
```

C++/CLI

```
void SetReverseOffset(  
& System.bool Fwd,  
& System.bool RevOffset  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fwd

True sets the reverse offset setting in the forward direction, false sets it in the reverse direction

RevOffset

True enables the reverse offset setting, false disables it

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::SetReverseOffset](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::GetReverseOffset Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTranslateSurface Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : SetTranslateSurface Method (ISurfExtrudeFeatureData)

Sets the translate surface setting for this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTranslateSurface( _  
    ByVal Fwd As System.Boolean, _  
    ByVal Trans As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Fwd As System.Boolean  
Dim Trans As System.Boolean
```

```
instance.SetTranslateSurface(Fwd, Trans)
```

C#

```
void SetTranslateSurface(  
    System.bool Fwd,  
    System.bool Trans  
)
```

C++/CLI

```
void SetTranslateSurface(  
& System.bool Fwd,  
& System.bool Trans  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fwd

True sets the translate surface setting in the forward direction, false sets it in the reverse direction

Trans

True enables the translate surface setting, false disables it

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::SetTranslateSurface](#).

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::GetTranslateSurface Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetVertex Method (ISurfExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfExtrudeFeatureData Interface](#) : SetVertex Method (ISurfExtrudeFeatureData)

Sets the end condition vertex in the forward or reverse direction for this extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVertex( _  
    ByVal Forward As System.Boolean, _  
    ByVal Vtx As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Vtx As System.Object  
  
instance.SetVertex(Forward, Vtx)
```

C#

```
void SetVertex(  
    System.bool Forward,  
    System.object Vtx  
)
```

C++/CLI

```
void SetVertex(  
& System.bool Forward,  
& System.Object^ Vtx  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True sets the vertex in the forward direction, false sets it in the reverse direction

Vtx

End condition [vertex](#)

Visual Basic for Applications (VBA) Syntax

See [SurfExtrudeFeatureData::SetVertex](#).

See Also

[ISurfExtrudeFeatureData Interface](#)
[ISurfExtrudeFeatureData Members](#)
[ISurfExtrudeFeatureData::ISetVertex Method](#)
[ISurfExtrudeFeatureData::GetVertex Method](#)
[ISurfExtrudeFeatureData::IGetVertex Method](#)

ISurfRevolveFeatureData (Type)

ISurfRevolveFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfRevolveFeatureData Interface

Allows access to a surface revolve feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISurfRevolveFeatureData
```

Visual Basic (Usage)

```
Dim instance As ISurfRevolveFeatureData
```

C#

```
public interface ISurfRevolveFeatureData
```

C++/CLI

```
public interface class ISurfRevolveFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SurfRevolveFeatureData](#).

Example

[Get Data for Surface Revolve Feature \(VBA\)](#)
[Get Data for Surface Revolve Feature \(VB.NET\)](#)
[Get Data for Surface Revolve Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[SurfRevolveFeatureData](#)

See Also

[ISurfRevolveFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRevolvedRefSurface Method](#)

ISurfRevolveFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfRevolveFeatureData Interface

The following tables list the members exposed by [ISurfRevolveFeatureData](#).

Public Properties

Name	Description
ReverseDirection	Gets or sets the reverse direction setting for this surface revolve feature.
Type	Gets or sets the type for this surface revolve feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this surface revolve feature.
 GetRevolutionAngle	Gets the angle for this surface revolve feature in Direction 1 or Direction 2.
 IAccessSelections	Accesses the selections that define this surface revolve feature.
 ReleaseSelectionAccess	Releases access to the selections for this surface revolve feature.
 SetRevolutionAngle	Sets the angle for this surface revolve feature in Direction 1 or Direction 2.

[Top](#)

See Also

[ISurfRevolveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRevolvedRefSurface Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfRevolveFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfRevolveFeatureData Interface

For a list of all members of this type, see [ISurfRevolveFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this surface revolve feature.
 GetRevolutionAngle	Gets the angle for this surface revolve feature in Direction 1 or Direction 2.
 IAccessSelections	Accesses the selections that define this surface revolve feature.
 ReleaseSelectionAccess	Releases access to the selections for this surface revolve feature.
 SetRevolutionAngle	Sets the angle for this surface revolve feature in Direction 1 or Direction 2.

[Top](#)

See Also

[ISurfRevolveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRevolvedRefSurface Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISurfRevolveFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISurfRevolveFeatureData Interface

For a list of all members of this type, see [ISurfRevolveFeatureData members](#).

Public Properties

Name	Description
 ReverseDirection	Gets or sets the reverse direction setting for this surface revolve feature.
 Type	Gets or sets the type for this surface revolve feature.

[Top](#)

See Also

[ISurfRevolveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRevolvedRefSurface Method](#)

AccessSelections Method (ISurfRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfRevolveFeatureData Interface](#) : AccessSelections Method (ISurfRevolveFeatureData)

Accesses the selections that define this surface revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfRevolveFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfRevolveFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfRevolveFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfRevolveFeatureData Interface](#)
[ISurfRevolveFeatureData Members](#)
[ISurfRevolveFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRevolutionAngle Method (ISurfRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfRevolveFeatureData Interface](#) : GetRevolutionAngle Method (ISurfRevolveFeatureData)

Gets the angle for this surface revolve feature in Direction 1 or Direction 2.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRevolutionAngle( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISurfRevolveFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Double
```

```
value = instance.GetRevolutionAngle(Forward)
```

C#

```
System.double GetRevolutionAngle(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetRevolutionAngle(  
    & System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True gets the angle in Direction 1, false gets the angle in Direction 2

Return Value

Angle of the revolution

Visual Basic for Applications (VBA) Syntax

See [SurfRevolveFeatureData::GetRevolutionAngle](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfRevolveFeatureData Interface](#)
[ISurfRevolveFeatureData Members](#)
[ISurfRevolveFeatureData::SetRevolutionAngle Method](#)

Availability

IAccessSelections Method (ISurfRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfRevolveFeatureData Interface](#) : IAccessSelections Method (ISurfRevolveFeatureData)

Accesses the selections that define this surface revolve feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISurfRevolveFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SurfRevolveFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISurfRevolveFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISurfRevolveFeatureData Interface](#)
[ISurfRevolveFeatureData Members](#)
[ISurfRevolveFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISurfRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfRevolveFeatureData Interface](#) : ReleaseSelectionAccess Method (ISurfRevolveFeatureData)

Releases access to the selections for this surface revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISurfRevolveFeatureData
```

```
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SurfRevolveFeatureData::ReleaseSelectionAccess](#).

Remarks

[ISurfRevolveFeatureData::AccessSelections](#) and [ISurfRevolveFeatureData::IAccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISurfRevolveFeatureData Interface](#)
[ISurfRevolveFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ISurfRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfRevolveFeatureData Interface](#) : ReverseDirection Property (ISurfRevolveFeatureData)

Gets or sets the reverse direction setting for this surface revolve feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISurfRevolveFeatureData  
Dim value As System.Boolean  
  
instance.ReverseDirection = value  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables the reverse direction setting, false disables it

Visual Basic for Applications (VBA) Syntax

See [SurfRevolveFeatureData.ReverseDirection](#).

Example

See [ISurfRevolveFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfRevolveFeatureData Interface](#)
[ISurfRevolveFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRevolutionAngle Method (ISurfRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfRevolveFeatureData Interface](#) : SetRevolutionAngle Method (ISurfRevolveFeatureData)

Sets the angle for this surface revolve feature in Direction 1 or Direction 2.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetRevolutionAngle( _  
    ByVal Forward As System.Boolean, _
```

```
ByVal Angle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISurfRevolveFeatureData  
Dim Forward As System.Boolean  
Dim Angle As System.Double  
  
instance.SetRevolutionAngle(Forward, Angle)
```

C#

```
void SetRevolutionAngle(  
    System.bool Forward,  
    System.double Angle  
)
```

C++/CLI

```
void SetRevolutionAngle(  
& System.bool Forward,  
& System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True sets the angle in Direction 1, false sets the angle in Direction 2

Angle

Angle of the revolution

Visual Basic for Applications (VBA) Syntax

See [SurfRevolveFeatureData::SetRevolutionAngle](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfRevolveFeatureData Interface](#)

[ISurfRevolveFeatureData Members](#)

[ISurfRevolveFeatureData::GetRevolutionAngle Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (ISurfRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISurfRevolveFeatureData Interface](#) : Type Property (ISurfRevolveFeatureData)

Gets or sets the type for this surface revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISurfRevolveFeatureData
Dim value As System.Integer

instance.Type = value

value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Revolution type as defined in [swRevolveType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SurfRevolveFeatureData::Type](#).

Example

See [ISurfRevolveFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISurfRevolveFeatureData Interface](#)
[ISurfRevolveFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1