

SOLIDWORKS API (NET VBA C#) — Reference (304/337): ISweepFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISweepFeatureData (Type)

ISweepFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISweepFeatureData Interface

Allows access to a sweep feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISweepFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData
```

C#

```
public interface ISweepFeatureData
```

C++/CLI

```
public interface class ISweepFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData](#).

Example

[Insert Swept-surface Feature \(VBA\)](#)
[Insert Swept-boss Feature \(VBA\)](#)
[Insert Swept-cut Feature Using Sketch Profile \(VBA\)](#)
[Insert Swept-cut Feature Using Circular Profile \(VBA\)](#)
[Insert Swept-cut Feature Using Tool Body \(VBA\)](#)
[Insert Swept-cut Feature with Bidirectional Twist \(VBA\)](#)
[Insert Swept-cut Thin-walled Feature \(VBA\)](#)

Remarks

To create a sweep feature, see [Sweep Features and SweepFeatureData Objects](#).

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)
[IFeatureManager::CreateDefinition](#)

Access Diagram

[SweepFeatureData](#)

See Also

[ISweepFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFeature Method \(\)](#)

ISweepFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISweepFeatureData Interface

The following tables list the members exposed by [ISweepFeatureData](#).

Public Properties

Name	Description
 AdvancedSmoothing	Gets or sets whether to apply advanced smoothing to this sweep feature.
 AlignWithEndFaces	Gets or sets whether to align this sweep with the end faces.
 AssemblyFeatureScope	Gets and sets whether this swept-cut feature affects only selected components in the assembly.
 AutoSelect	Gets or sets whether to automatically select all bodies in a multibody part to be affected by this sweep feature.
 AutoSelectComponents	Gets and sets whether to automatically select all assembly components to be affected by this swept-cutfeature.
 CircularProfile	Gets or sets whether to use a circular profile for this sweep feature.
 CircularProfileDiameter	Gets or sets the diameter of the circular profile for this sweep feature.
 D1ReverseTwistDir	Gets or sets whether to reverse the twist of this sweep feature.
 D2ReverseTwistDir	Gets or sets whether to reverse the twist in Direction 2 of this bidirectional sweep feature.
 Direction	Gets or sets the direction type of this sweep feature.
 EndDirectionVector	Obsolete. Gets or sets the direction vector in which to end this sweep feature.
 EndTangencyType	Gets or sets tangency at the end of the sweep path of this sweep feature.
 FeatureScope	Gets or sets whether to use scope in a multibody part for this sweep feature.
 FeatureScopeBodies	Gets or sets the solid bodies in a multibody part affected by this sweep feature.
 GuideCurves	Gets or sets the guide curves for this sweep feature.
 MaintainTangency	Gets or sets whether to merge tangent faces in this sweep feature.
 Merge	Gets or sets whether to merge the results of this swept-boss feature for a multibody part.
 MergeSmoothFaces	Gets or sets whether to merge the smooth faces of this sweep feature that uses guide curves.
 Path	Gets or sets the sweep path for this sweep feature.
 PathAlignmentType	Gets or sets the alignment of the sweep path in this sweep feature.
 Profile	Gets and sets the sketch profile or tool body for this sweep feature.
 PropagateFeatureToParts	Gets and sets whether to extend the swept-cut feature to all affected parts in the assembly.
 StartDirectionVector	Obsolete. Gets or sets the direction vector in which to start this sweep feature.
 StartTangencyType	Gets and sets the tangency at the start of the sweep path for this sweep feature.
 SweepType	Gets the type of this sweep feature.
 TangentPropagation	Gets or sets whether to propagate the sweep to the next tangent edge for this sweep feature.
 ThinFeature	Gets or sets whether to make this sweep feature a thin-walled feature.
 ThinWallType	Gets or sets the type of this thin-walled sweep feature.
 TwistControlType	Gets or sets the type of twist control for this sweep feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this sweep feature.
 GetCutSweepOption	Gets the type of this cut sweep feature.
 GetD2TwistAngle	Gets the twist angle in Direction 2 of this bidirectional sweep feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the sweep feature in a multibody part.
 GetGuideCurvesCount	Gets a number of guide curves for this sweep feature.
 GetGuideCurvesType	Gets the type of guide curves in this sweep feature.
 GetPathAlignmentDirectionVector	Gets the direction vector of the specified type for this sweep feature.

		
	GetPathType	Gets the path type for this sweep feature.
	GetProfileType	Gets the profile type of this sweep feature.
	GetTwistAngle	Gets the angle at which to twist this sweep feature.
	GetWallThickness	Gets the wall thickness, forward (Direction 1) or reverse (Direction 2), of this thin-walled sweep feature.
	IAccessSelections	Obsolete. Accesses the selections that define this sweep feature.
	IGetFeatureScopeBodies	Obsolete. Gets the solid bodies that the sweep feature affects in a multibody part.
	IGetGuideCurves	Obsolete. Gets the guide curves for this sweep feature.
	IGetGuideCurvesType	Obsolete. Gets the guide curve types for this sweep feature.
	IsBossFeature	Gets whether the sweep feature is a boss feature.
	ISetFeatureScopeBodies	Obsolete. Sets the solid bodies that the sweep feature affects in a multibody part.
	ISetGuideCurves	Obsolete. Sets the guide curves for this sweep feature.
	IsThinFeature	Gets whether this is a thin-walled sweep feature.
	ReleaseSelectionAccess	Releases access to the selections for this sweep feature.
	SetD2TwistAngle	Sets the twist angle in Direction 2 of this bidirectional sweep feature.
	SetPathAlignmentDirectionVector	Sets the direction vector for path alignment in this sweep feature.
	SetTwistAngle	Sets the angle at which to twist this sweep feature.
	SetWallThickness	Sets the wall thickness, forward (Direction 1) or reverse (Direction 2), of this thin-walled sweep feature.

[Top](#)

See Also

[ISweepFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFeature Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISweepFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISweepFeatureData Interface

For a list of all members of this type, see [ISweepFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this sweep feature.
 GetCutSweepOption	Gets the type of this cut sweep feature.
 GetD2TwistAngle	Gets the twist angle in Direction 2 of this bidirectional sweep feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the sweep feature in a multibody part.
 GetGuideCurvesCount	Gets a number of guide curves for this sweep feature.
 GetGuideCurvesType	Gets the type of guide curves in this sweep feature.
 GetPathAlignmentDirectionVector	Gets the direction vector of the specified type for this sweep feature.
 GetPathType	Gets the path type for this sweep feature.
 GetProfileType	Gets the profile type of this sweep feature.
 GetTwistAngle	Gets the angle at which to twist this sweep feature.
 GetWallThickness	Gets the wall thickness, forward (Direction 1) or reverse (Direction 2), of this thin-walled sweep feature.
 IAccessSelections	Obsolete. Accesses the selections that define this sweep feature.
 IGetFeatureScopeBodies	Obsolete. Gets the solid bodies that the sweep feature affects in a multibody part.

	IGetGuideCurves	Obsolete. Gets the guide curves for this sweep feature.
	IGetGuideCurvesType	Obsolete. Gets the guide curve types for this sweep feature.
	IsBossFeature	Gets whether the sweep feature is a boss feature.
	ISetFeatureScopeBodies	Obsolete. Sets the solid bodies that the sweep feature affects in a multibody part.
	ISetGuideCurves	Obsolete. Sets the guide curves for this sweep feature.
	IsThinFeature	Gets whether this is a thin-walled sweep feature.
	ReleaseSelectionAccess	Releases access to the selections for this sweep feature.
	SetD2TwistAngle	Sets the twist angle in Direction 2 of this bidirectional sweep feature.
	SetPathAlignmentDirectionVector	Sets the direction vector for path alignment in this sweep feature.
	SetTwistAngle	Sets the angle at which to twist this sweep feature.
	SetWallThickness	Sets the wall thickness, forward (Direction 1) or reverse (Direction 2), of this thin-walled sweep feature.

[Top](#)

See Also

[ISweepFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFeature Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISweepFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISweepFeatureData Interface

For a list of all members of this type, see [ISweepFeatureData members](#).

Public Properties

Name	Description
 AdvancedSmoothing	Gets or sets whether to apply advanced smoothing to this sweep feature.
 AlignWithEndFaces	Gets or sets whether to align this sweep with the end faces.
 AssemblyFeatureScope	Gets and sets whether this swept-cut feature affects only selected components in the assembly.
 AutoSelect	Gets or sets whether to automatically select all bodies in a multibody part to be affected by this sweep feature.
 AutoSelectComponents	Gets and sets whether to automatically select all assembly components to be affected by this swept-cut feature.
 CircularProfile	Gets or sets whether to use a circular profile for this sweep feature.
 CircularProfileDiameter	Gets or sets the diameter of the circular profile for this sweep feature.
 D1ReverseTwistDir	Gets or sets whether to reverse the twist of this sweep feature.
 D2ReverseTwistDir	Gets or sets whether to reverse the twist in Direction 2 of this bidirectional sweep feature.
 Direction	Gets or sets the direction type of this sweep feature.
 EndDirectionVector	Obsolete. Gets or sets the direction vector in which to end this sweep feature.
 EndTangencyType	Gets or sets tangency at the end of the sweep path of this sweep feature.
 FeatureScope	Gets or sets whether to use scope in a multibody part for this sweep feature.
 FeatureScopeBodies	Gets or sets the solid bodies in a multibody part affected by this sweep feature.
 GuideCurves	Gets or sets the guide curves for this sweep feature.
 MaintainTangency	Gets or sets whether to merge tangent faces in this sweep feature.
 Merge	Gets or sets whether to merge the results of this swept-boss feature for a multibody part.
 MergeSmoothFaces	Gets or sets whether to merge the smooth faces of this sweep feature that uses guide curves.
 Path	Gets or sets the sweep path for this sweep feature.
 PathAlignmentType	Gets or sets the alignment of the sweep path in this sweep feature.

 Profile	Gets and sets the sketch profile or tool body for this sweep feature.
 PropagateFeatureToParts	Gets and sets whether to extend the swept-cut feature to all affected parts in the assembly.
 StartDirectionVector	Obsolete. Gets or sets the direction vector in which to start this sweep feature.
 StartTangencyType	Gets and sets the tangency at the start of the sweep path for this sweep feature.
 SweepType	Gets the type of this sweep feature.
 TangentPropagation	Gets or sets whether to propagate the sweep to the next tangent edge for this sweep feature.
 ThinFeature	Gets or sets whether to make this sweep feature a thin-walled feature.
 ThinWallType	Gets or sets the type of this thin-walled sweep feature.
 TwistControlType	Gets or sets the type of twist control for this sweep feature.

[Top](#)

See Also

[ISweepFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFeature Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : AccessSelections Method (ISweepFeatureData)

Accesses the selections that define this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code.](#)

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ISweepFeatureData::AccessSelections](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	• TopDoc argument is the IModelDoc2 for the part • Component argument is NULL
Assembly	• TopDoc is the IModelDoc2 object for the assembly • Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISweepFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AdvancedSmoothing Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : AdvancedSmoothing Property (ISweepFeatureData)

Gets or sets whether to apply advanced smoothing to this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property AdvancedSmoothing As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.AdvancedSmoothing = value
```

```
value = instance.AdvancedSmoothing
```

C#

```
System.bool AdvancedSmoothing {get; set;}
```

C++/CLI

```
property System.bool AdvancedSmoothing {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables advanced smoothing, false (default) disables it

 Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::AdvancedSmoothing](#).

 Example

See the [ISweepFeatureData](#) examples.

 Remarks

See [Accessing Selections that Define Features](#) for additional details.

 See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AlignWithEndFaces Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : AlignWithEndFaces Property (ISweepFeatureData)

Gets or sets whether to align this sweep with the end faces.

 .NET Syntax

Visual Basic (Declaration)

Property AlignWithEndFaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.AlignWithEndFaces = value
```

```
value = instance.AlignWithEndFaces
```

C#

```
System.bool AlignWithEndFaces {get; set;}
```

C++/CLI

```
property System.bool AlignWithEndFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True aligns the sweep with the end faces (default for swept-cut and swept-boss), false does not (default for swept-surface) (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::AlignWithEndFaces](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

You must set this property to false if [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AssemblyFeatureScope Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : AssemblyFeatureScope Property (ISweepFeatureData)

Gets and sets whether this swept-cut feature affects only selected components in the assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property AssemblyFeatureScope As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean  
  
instance.AssemblyFeatureScope = value  
value = instance.AssemblyFeatureScope
```

C#

```
System.bool AssemblyFeatureScope {get; set;}
```

C++/CLI

```
property System.bool AssemblyFeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the swept-cutfeature affects only selected components in the assembly, false if affects all components in the assembly (**see Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::AssemblyFeatureScope](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

Use this property, [ISweepFeatureData::AutoSelectComponents](#), and [ISweepFeatureData::PropagateFeatureToParts](#) to insert sweep cuts into an assembly.

This API works with [ISweepFeatureData::AutoSelectComponents](#) to configure the scope of an assembly sweep feature. This API performs the same configuration that is done in the Feature Scope section of the PropertyManager page of the sweep feature:

AssemblyFeatureScope setting	AutoSelectComponents setting	PropertyManager page Feature Scope setting
False	Ignored	All components selected Auto-select not visible
True	If true, affected components are automatically selected If false, manually select the affected components before calling this API	Selected components selected If Auto-select is not checked, then manually select components

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoSelect Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : AutoSelect Property (ISweepFeatureData)

Gets or sets whether to automatically select all bodies in a multibody part to be affected by this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Property AutoSelect As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.AutoSelect = value
```

```
value = instance.AutoSelect
```

C#

```
System.bool AutoSelect {get; set;}
```

C++/CLI

```
property System.bool AutoSelect {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies (default for swept-boss and swept-surface), false to select specific bodies using [ISweepFeatureData::FeatureScopeBodies](#) (default for swept-cut)

Visual Basic for Applications (VBA) Syntax

See [ISweepFeatureData::AutoSelect](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is only available when the [ISweepFeatureData::FeatureScope](#) property is true. The sweep feature is expanded along the plane on which the feature is created and selects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetFeatureScopeBodiesCount Method](#)
[ISweepFeatureData::IGetFeatureScopeBodies Method](#)
[ISweepFeatureData::ISetFeatureScopeBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoSelectComponents Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : AutoSelectComponents Property (ISweepFeatureData)

Gets and sets whether to automatically select all assembly components to be affected by this swept-cutfeature.

.NET Syntax

Visual Basic (Declaration)

```
Property AutoSelectComponents As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.AutoSelectComponents = value
```

```
value = instance.AutoSelectComponents
```

C#

```
System.bool AutoSelectComponents {get; set;}
```

C++/CLI

```
property System.bool AutoSelectComponents {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all affected assembly components, false to manually select components (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::AutoSelectComponents](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

Use this property, [ISweepFeatureData::AssemblyFeatureScope](#), and [ISweepFeatureData::PropagateFeatureToParts](#) to insert sweep cuts into an assembly.

This API works with [ISweepFeatureData::AssemblyFeatureScope](#) to configure the scope of an assembly sweep feature. This API performs the same configuration that is done in the Feature Scope section of the PropertyManager page of the sweep feature:

AssemblyFeatureScope setting	AutoSelectComponents setting	PropertyManager page Feature Scope setting
False	Ignored	All components selected Auto-select not visible
True	If true, affected components are automatically selected If false, manually select the components before calling this API	Selected components selected If Auto-select is not checked, then manually select components

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CircularProfile Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : CircularProfile Property (ISweepFeatureData)

Gets or sets whether to use a circular profile for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property CircularProfile As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.CircularProfile = value
```

```
value = instance.CircularProfile
```

C#

```
System.bool CircularProfile {get; set;}
```

C++/CLI

```
property System.bool CircularProfile {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use a circular profile, false to use a [sketch profile or tool body](#).

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::CircularProfile](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

If this property is set to false, call [ISweepFeatureData::GetCutSweepOption](#) to determine the type of profile.

To get or set the diameter of a circular profile, use [ISweepFeatureData::CircularProfileDiameter](#).

See Also

[ISweepFeatureData Interface](#)

[ISweepFeatureData Members](#)

[ISweepFeatureData::GetProfileType Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CircularProfileDiameter Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : CircularProfileDiameter Property (ISweepFeatureData)

Gets or sets the diameter of the circular profile for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CircularProfileDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Double
```

```
instance.CircularProfileDiameter = value
```

```
value = instance.CircularProfileDiameter
```

C#

```
System.double CircularProfileDiameter {get; set;}
```

C++/CLI

```
property System.double CircularProfileDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Diameter of the circular profile

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::CircularProfileDiameter](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is valid only if [ISweepFeatureData::CircularProfile](#) is set to true.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1ReverseTwistDir Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : D1ReverseTwistDir Property (ISweepFeatureData)

Gets or sets whether to reverse the twist of this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property D1ReverseTwistDir As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.D1ReverseTwistDir = value
```

```
value = instance.D1ReverseTwistDir
```

C#

```
System.bool D1ReverseTwistDir {get; set;}
```

C++/CLI

```
property System.bool D1ReverseTwistDir {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the twist, false to not

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::D1ReverseTwistDir](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is valid only if [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

This property reverses the twist in Direction 1 of a bidirectional sweep.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData.D2ReverseTwistDir Property \(\)](#)
[ISweepFeatureData.GetTwistAngle Method \(\)](#)
[ISweepFeatureData.SetTwistAngle Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2ReverseTwistDir Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : D2ReverseTwistDir Property (ISweepFeatureData)

Gets or sets whether to reverse the twist in Direction 2 of this bidirectional sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D2ReverseTwistDir As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean  
  
instance.D2ReverseTwistDir = value  
  
value = instance.D2ReverseTwistDir
```

C#

```
System.bool D2ReverseTwistDir {get; set;}
```

C++/CLI

```
property System.bool D2ReverseTwistDir {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the twist in Direction 2, false to not

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData.D2ReverseTwistDir](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is valid only if:

- [ISweepFeatureData.TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).
- [ISweepFeatureData.Direction](#) is set to [swSweepDirection_e.swSweepBidirectional](#).

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::D1ReverseTwistDir Property \(\)](#)
[ISweepFeatureData::GetD2TwistAngle Method \(\)](#)
[ISweepFeatureData::SetD2TwistAngle Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Direction Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : Direction Property (ISweepFeatureData)

Gets or sets the direction type of this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Direction As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Integer
```

```
instance.Direction = value
```

```
value = instance.Direction
```

C#

```
System.int Direction {get; set;}
```

C++/CLI

```
property System.int Direction {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sweep path direction type as defined in [swSweepDirection_e](#); -1 if not valid

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::Direction](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is valid only if the profile is a [sketch profile](#), and the [sweep path](#) extends through both sides of the sketch profile.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

EndDirectionVector Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : EndDirectionVector Property (ISweepFeatureData)

Obsolete. Gets or sets the direction vector in which to end this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property EndDirectionVector As System.Object

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData
Dim value As System.Object

instance.EndDirectionVector = value
value = instance.EndDirectionVector
```

C#

```
System.Object EndDirectionVector {get; set;}
```

C++/CLI

```
property System.Object^ EndDirectionVector {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Plane](#), planar [face](#), [line](#), [edge](#), [cylinder](#), [axis](#), or a pair of [vertices](#) that defines the direction

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::EndDirectionVector](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::StartDirectionVector Property](#)
[ISweepFeatureData::GetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::SetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::PathAlignmentType Property](#)
[ISweepFeatureData::Path Property](#)
[ISweepFeatureData::GetPathType Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

EndTangencyType Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : EndTangencyType Property (ISweepFeatureData)

Gets or sets tangency at the end of the sweep path of this sweep feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property EndTangencyType As System.Short
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Short
```

```
instance.EndTangencyType = value
```

```
value = instance.EndTangencyType
```

C#

```
System.short EndTangencyType {get; set;}
```

C++/CLI

```
property System.short EndTangencyType {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tangency at end of sweep path as defined in [swTangencyType_e](#):

- swTangencyNone (default)
- swTangencyNormalToProfile

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::EndTangencyType](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is not valid if:

- [ISweepFeatureData::Direction](#) is set to [swSweepDirection_e.swSweepBiDirectional](#).
- or -
- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::StartTangencyType Property](#)
[ISweepFeatureData::MaintainTangency Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScope Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : FeatureScope Property (ISweepFeatureData)

Gets or sets whether to use scope in a multibody part for this sweep feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property FeatureScope As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.FeatureScope = value
```

```
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get; set;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

When:

- true (default), only specified bodies in the multibody part are affected by the sweep feature
- false, all of the bodies in the multibody part are affected by the sweep feature

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::FeatureScope](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

The sweep feature is expanded along the plane on which the feature is created and affects all or only the specified bodies it intersects. Use [ISweepFeatureData::FeatureScopeBodies](#) to specify the bodies.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetFeatureScopeBodiesCount Method](#)
[ISweepFeatureData::!GetFeatureScopeBodies Method](#)
[ISweepFeatureData::!SetFeatureScopeBodies Method](#)
[ISweepFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScopeBodies Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : FeatureScopeBodies Property (ISweepFeatureData)

Gets or sets the solid bodies in a multibody part affected by this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureScopeBodies As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData
Dim value As System.Object

instance.FeatureScopeBodies = value
value = instance.FeatureScopeBodies
```

C#

```
System.Object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of solid [bodies](#) that the feature affects

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::FeatureScopeBodies](#).

Remarks

This property is valid only if [ISweepFeatureData::FeatureScope](#) is set to true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetFeatureScopeBodiesCount Method](#)
[ISweepFeatureData::IGetFeatureScopeBodies Method](#)
[ISweepFeatureData::ISetFeatureScopeBodies Method](#)
[ISweepFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCutSweepOption Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetCutSweepOption Method (ISweepFeatureData)

Gets the type of this cut sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCutSweepOption() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData
Dim value As System.Integer

value = instance.GetCutSweepOption()
```

C#

```
System.int GetCutSweepOption()
```

C++/CLI

```
System.int GetCutSweepOption();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Cut sweep type as defined in [swCutSweepOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetCutSweepOption](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::CircularProfile Property\(\)](#)
[ISweepFeatureData::Profile Property\(\)](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetD2TwistAngle Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetD2TwistAngle Method (ISweepFeatureData)

Gets the twist angle in Direction 2 of this bidirectional sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetD2TwistAngle() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData
Dim value As System.Double

value = instance.GetD2TwistAngle()
```

C#

```
System.double GetD2TwistAngle()
```

C++/CLI

```
System.double GetD2TwistAngle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Angle of twist in radians in Direction 2

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetD2TwistAngle](#).

Remarks

This property is valid only if:

- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).
- [ISweepFeatureData::Direction](#) is set to [swSweepDirection_e.swSweepBidirectional](#).

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::SetD2TwistAngle Method \(\)](#)
[ISweepFeatureData::GetTwistAngle Method \(\)](#)
[ISweepFeatureData::D2ReverseTwistDir Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeatureScopeBodiesCount Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetFeatureScopeBodiesCount Method (ISweepFeatureData)

Gets the number of solid bodies affected by the sweep feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureScopeBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Integer  
  
value = instance.GetFeatureScopeBodiesCount()
```

C#

```
System.int GetFeatureScopeBodiesCount()
```

C++/CLI

```
System.int GetFeatureScopeBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of solid bodies affected, -1 if not valid

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetFeatureScopeBodiesCount](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

Call this method before calling [ISweepFeatureData::IGetFeatureScopeBodies](#) to get the size of the array for that method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::IGetFeatureScopeBodies Method](#)
[ISweepFeatureData::IGetFeatureScope Property](#)
[ISweepFeatureData::FeatureScopeBodies Property](#)
[ISweepFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetGuideCurvesCount Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetGuideCurvesCount Method (ISweepFeatureData)

Gets a number of guide curves for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGuideCurvesCount() As System.Short
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Short  
  
value = instance.GetGuideCurvesCount()
```

C#

```
System.short GetGuideCurvesCount()
```

C++/CLI

```
System.short GetGuideCurvesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of guide curves

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetGuideCurvesCount](#).

Remarks

This method is not valid if:

- [ISweepFeatureData::Direction](#) is set to [swSweepDirection_e.swSweepBiDirectional](#).
- or -
- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

Call this method before calling [ISweepFeatureData::IGetGuideCurves](#) to get the size of the array for that method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetGuideCurvesType Method](#)
[ISweepFeatureData::IGetGuideCurves Method](#)
[ISweepFeatureData::IGetGuideCurvesType Method](#)
[ISweepFeatureData::ISetGuideCurves Method](#)
[ISweepFeatureData::GuideCurves Property](#)
[ISweepFeatureData::MergeSmoothFaces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetGuideCurvesType Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetGuideCurvesType Method (ISweepFeatureData)

Gets the type of [guide curves](#) in this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGuideCurvesType() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Object  
  
value = instance.GetGuideCurvesType()
```

C#

```
System.object GetGuideCurvesType()
```

C++/CLI

```
System.Object^ GetGuideCurvesType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of longs or integers representing the types of guide curves as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetGuideCurvesType](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This method is not valid if:

- [ISweepFeatureData::Direction](#) is set to [swSweepDirection_e.swSweepBiDirectional](#).
- or -
- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetGuideCurvesCount Method](#)
[ISweepFeatureData::IGetGuideCurves Method](#)
[ISweepFeatureData::IGetGuideCurvesType Method](#)
[ISweepFeatureData::ISetGuideCurves Method](#)
[ISweepFeatureData::MergeSmoothFaces Property](#)

Availability

SOLIDWORKS 2001Plus SP3, Revision Number 10.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPathAlignmentDirectionVector Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetPathAlignmentDirectionVector Method (ISweepFeatureData)

Gets the direction vector of the specified type for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPathAlignmentDirectionVector( _  
    ByRef Type As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Type As System.Integer  
Dim value As System.Object  
  
value = instance.GetPathAlignmentDirectionVector(Type)
```

C#

```
System.object GetPathAlignmentDirectionVector(  
    out System.int Type  
)
```

C++/CLI

```
System.Object^ GetPathAlignmentDirectionVector(  
& [Out] System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of direction vector as defined in [swSelectType_e](#):

- [swSelDATAMAXES](#) (axis)
- [swSelDATUMPLANES](#) (plane)
- [swSelEDGES](#) (edge)
- [swSelFACES](#) (face)

Return Value

[Plane](#), planar [face](#), [line](#), [edge](#), [cylinder](#), [axis](#), or a pair of [vertices](#) that defines the direction

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetPathAlignmentDirectionVector](#).

Remarks

This method is valid only if:

- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlFollowPath](#).

- and -

- [ISweepFeatureData::PathAlignmentType](#) is set to [swTangencyType_e](#).swTangencyDirectionVector.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::SetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::PathAlignmentType Property](#)
[ISweepFeatureData::Path Property](#)
[ISweepFeatureData::GetPathType Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPathType Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetPathType Method (ISweepFeatureData)

Gets the path type for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPathType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Integer  
  
value = instance.GetPathType()
```

C#

```
System.int GetPathType()
```

C++/CLI

```
System.int GetPathType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Sweep path type as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetPathType](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

[ISweepFeatureData::GetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::SetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::Path Property](#)
[ISweepFeatureData::PathAlignmentType Property](#)
[ISweepFeatureData::StartTangencyType Property](#)
[ISweepFeatureData::EndTangencyType Property](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProfileType Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetProfileType Method (ISweepFeatureData)

Gets the profile type of this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProfileType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Integer  
  
value = instance.GetProfileType()
```

C#

```
System.int GetProfileType()
```

C++/CLI

```
System.int GetProfileType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Sweep profile type as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetProfileType](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::Profile Property \(\)](#)
[ISweepFeatureData::CircularProfile Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTwistAngle Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetTwistAngle Method (ISweepFeatureData)

Gets the angle at which to twist this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTwistAngle() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Double
```

```
value = instance.GetTwistAngle()
```

C#

```
System.double GetTwistAngle()
```

C++/CLI

```
System.double GetTwistAngle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Angle of twist in radians

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetTwistAngle](#).

Remarks

This method is valid only if [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

This method gets the angle of twist in radians in Direction 1 of a bidirectional sweep.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::SetTwistAngle Method](#)
[ISweepFeatureData::D1ReverseTwistDir Property \(\)](#)
[ISweepFeatureData::GetD2TwistAngle Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWallThickness Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GetWallThickness Method (ISweepFeatureData)

Gets the wall thickness, forward (Direction 1) or reverse (Direction 2), of this thin-walled sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWallThickness( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetWallThickness(Forward)
```

C#

```
System.double GetWallThickness(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetWallThickness(  
&    System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for Direction 1, false for Direction 2

Return Value

Wall thickness

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GetWallThickness](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This method is:

- valid only if [ISweepFeatureData::IsThinFeature](#) is true.
- not valid for swept-surface features.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::SetWallThickness Method](#)
[ISweepFeatureData::ThinWallType Property](#)
[ISweepFeatureData::IsThinFeature Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GuideCurves Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : GuideCurves Property (ISweepFeatureData)

Gets or sets the guide curves for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property GuideCurves As System.Object

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Object
```

```
instance.GuideCurves = value
```

```
value = instance.GuideCurves
```

C#

```
System.object GuideCurves {get; set;}
```

C++/CLI

```
property System.Object^ GuideCurves {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of guide [curves](#), [edges](#), [lines](#), or [arcs](#)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::GuideCurves](#).

Remarks

This property is not valid if:

- [ISweepFeatureData::Direction](#) is set to [swSweepDirection_e.swSweepBiDirectional](#).
- or -
- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetGuideCurvesCount Method](#)
[ISweepFeatureData::GetGuideCurvesType Method](#)
[ISweepFeatureData::IGetGuideCurves Method](#)
[ISweepFeatureData::IGetGuideCurvesType Method](#)
[ISweepFeatureData::ISetGuideCurves Method](#)
[ISweepFeatureData::MergeSmoothFaces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : IAccessSelections Method (ISweepFeatureData)

Obsolete. Accesses the selections that define this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISweepFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISweepFeatureData Interface](#)

[ISweepFeatureData Members](#)

[ISweepFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : IGetFeatureScopeBodies Method (ISweepFeatureData)

Obsolete. Gets the solid bodies that the sweep feature affects in a multibody part.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetFeatureScopeBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Count As System.Integer  
Dim value As Body2  
  
value = instance.IGetFeatureScopeBodies(Count)
```

C#

```
Body2 IGetFeatureScopeBodies(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetFeatureScopeBodies(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

Return Value

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISweepFeatureData::GetFeatureScopeBodiesCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::ISetFeatureScopeBodies Method](#)
[ISweepFeatureData::FeatureScope Property](#)
[ISweepFeatureData::FeatureScopeBodies Property](#)
[ISweepFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetGuideCurves Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : IGetGuideCurves Method (ISweepFeatureData)

Obsolete. Gets the guide curves for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetGuideCurves( _  
    ByVal Count As System.Short _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Count As System.Short  
Dim value As System.Object  
  
value = instance.IGetGuideCurves(Count)
```

C#

```
System.object IGetGuideCurves(  
    System.short Count  
)
```

C++/CLI

```
System.Object^ IGetGuideCurves(  
& System.short Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of guide curves

Return Value

- in-process, unmanaged C++: Pointer to an array of [features](#) of the guide curves of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISweepFeatureData::GetGuideCurvesCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetGuideCurvesType Method](#)
[ISweepFeatureData::IGetGuideCurvesType Method](#)
[ISweepFeatureData::ISetGuideCurves Method](#)
[ISweepFeatureData::GuideCurves Property](#)
[ISweepFeatureData::MergeSmoothFaces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetGuideCurvesType Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : IGetGuideCurvesType Method (ISweepFeatureData)

Obsolete. Gets the guide curve types for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetGuideCurvesType( _  
    ByVal Count As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Count As System.Integer  
Dim value As System.Integer  
  
value = instance.IGetGuideCurvesType(Count)
```

C#

```
System.int IGetGuideCurvesType(  
    System.int Count  
)
```

C++/CLI

```
System.int IGetGuideCurvesType(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of guide curves

Return Value

- in-process, unmanaged C++: Pointer to an array of longs or integers representing the types of guide curves as defined in [swSelectType_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISweepFeatureData::GetGuideCurvesCount](#) to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetGuideCurvesType Method](#)
[ISweepFeatureData::IGetGuideCurves Method](#)
[ISweepFeatureData::ISetGuideCurves Method](#)
[ISweepFeatureData::GuideCurves Property](#)
[ISweepFeatureData::MergeSmoothFaces Property](#)

Availability

SOLIDWORKS 2001Plus SP3, Revision Number 10.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsBossFeature Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : IsBossFeature Method (ISweepFeatureData)

Gets whether the sweep feature is a boss feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBossFeature() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean  
  
value = instance.IsBossFeature()
```

C#

```
System.bool IsBossFeature()
```

C++/CLI

```
System.bool IsBossFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a boss feature, false if not

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::IsBossFeature](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::IsThinFeature Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetFeatureScopeBodies Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : ISetFeatureScopeBodies Method (ISweepFeatureData)

Obsolete. Sets the solid bodies that the sweep feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFeatureScopeBodies( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArr As Body2 _  
)
```

Visual Basic (Usage)

```
Dim instance As ISweepFeatureData  
Dim Count As System.Integer  
Dim BodyArr As Body2
```

```
instance.ISetFeatureScopeBodies(Count, BodyArr)
```

C#

```
void ISetFeatureScopeBodies(  
    System.int Count,  
    ref Body2 BodyArr  
)
```

C++/CLI

```
void ISetFeatureScopeBodies(  
& System.int Count,  
& Body2^% BodyArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

BodyArr

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)

[ISweepFeatureData Members](#)

[ISweepFeatureData::GetFeatureScopeBodiesCount Method](#)

[ISweepFeatureData::IGetFeatureScopeBodies Method](#)

[ISweepFeatureData::FeatureScope Property](#)

[ISweepFeatureData::FeatureScopeBodies Property](#)

[ISweepFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetGuideCurves Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : ISetGuideCurves Method (ISweepFeatureData)

Obsolete. Sets the guide curves for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetGuideCurves( _  
    ByVal Count As System.Short, _  
    ByRef PDisp As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As ISweepFeatureData  
Dim Count As System.Short  
Dim PDisp As System.Object
```

```
instance.ISetGuideCurves(Count, PDisp)
```

C#

```
void ISetGuideCurves(  
    System.short Count,
```



```
ref System.object PDisp
)
```

C++/CLI

```
void ISetGuideCurves(
& System.short Count,
& System.Object^% PDisp
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of guide curves

PDisp

- in-process, unmanaged C++: Pointer to an array of the [features](#) of the guide curves of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetGuideCurvesCount Method](#)
[ISweepFeatureData::GetGuideCurvesType Method](#)
[ISweepFeatureData::IGetGuideCurves Method](#)
[ISweepFeatureData::IGetGuideCurvesType Method](#)
[ISweepFeatureData::GuideCurves Property](#)
[ISweepFeatureData::MergeSmoothFaces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsThinFeature Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : IsThinFeature Method (ISweepFeatureData)

Gets whether this is a thin-walled sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsThinFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData
Dim value As System.Boolean
```

```
value = instance.IsThinFeature()
```

C#

```
System.bool IsThinFeature()
```

C++/CLI

```
System.bool IsThinFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a thin-walled sweep feature, false if not

Visual Basic for Applications (VBA) Syntax

See [ISweepFeatureData::IsThinFeature](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

Note that you can make a sweep feature thin-walled only by setting [ISweepFeatureData::ThinFeature](#) at the time of creation.

This method is not valid for swept-surface features.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData.SetWallThickness Method](#)
[ISweepFeatureData.ThinWallType Property](#)
[ISweepFeatureData.GetWallThickness Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaintainTangency Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : MaintainTangency Property (ISweepFeatureData)

Gets or sets whether to merge tangent faces in this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property MaintainTangency As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.MaintainTangency = value
```

```
value = instance.MaintainTangency
```

C#

```
System.bool MaintainTangency {get; set;}
```

C++/CLI

```
property System.bool MaintainTangency {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge tangent faces, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::MaintainTangency](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

If the sweep profile has tangent segments, true causes the corresponding surfaces in the resulting sweep to be tangent. Faces that can be represented as a plane, cylinder, or cone are maintained. Other adjacent faces are merged, and the profiles are approximated. Sketch arcs may be converted to splines.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::EndTangencyType Property](#)
[ISweepFeatureData::StartTangencyType Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Merge Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : Merge Property (ISweepFeatureData)

Gets or sets whether to merge the results of this swept-boss feature for a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property Merge As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.Merge = value
```

```
value = instance.Merge
```

C#

```
System.bool Merge {get; set;}
```

C++/CLI

```
property System.bool Merge {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge results, false to not

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::Merge](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MergeSmoothFaces Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : MergeSmoothFaces Property (ISweepFeatureData)

Gets or sets whether to merge the smooth faces of this sweep feature that uses guide curves.

.NET Syntax

Visual Basic (Declaration)

Property MergeSmoothFaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.MergeSmoothFaces = value
```

```
value = instance.MergeSmoothFaces
```

C#

```
System.bool MergeSmoothFaces {get; set;}
```

C++/CLI

```
property System.bool MergeSmoothFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge the smooth faces, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::MergeSmoothFaces](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property corresponds to the **Merge smooth faces** check box on the **Guide Curves** group box on the **Sweep** PropertyManager.

Setting this property to false improves the performance of sweeps with guide curves and segments the sweep at all points where the guide curve or path is not curvature continuous.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetGuideCurvesCount Method](#)
[ISweepFeatureData::GetGuideCurvesType Method](#)
[ISweepFeatureData::IGetGuideCurves Method](#)
[ISweepFeatureData::IGetGuideCurvesType Method](#)
[ISweepFeatureData::ISetGuideCurves Method](#)
[ISweepFeatureData::GuideCurves Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Path Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : Path Property (ISweepFeatureData)

Gets or sets the sweep path for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property Path As System.Object

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Object
```

```
instance.Path = value
```

```
value = instance.Path
```

C#

```
System.object Path {get; set;}
```

C++/CLI

```
property System.Object^ Path {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

A set of sketched [curves](#) contained in one sketch, a curve, or a set of model [edges](#)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::Path](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::SetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::EndTangencyType Property](#)
[ISweepFeatureData::GetPathType Method](#)
[ISweepFeatureData::PathAlignmentType Property](#)
[ISweepFeatureData::Direction Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PathAlignmentType Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : PathAlignmentType Property (ISweepFeatureData)

Gets or sets the alignment of the sweep path in this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PathAlignmentType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Integer  
  
instance.PathAlignmentType = value  
  
value = instance.PathAlignmentType
```

C#

```
System.int PathAlignmentType {get; set;}
```

C++/CLI

```
property System.int PathAlignmentType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sweep path alignment as defined in [swTangencyType e](#):

- swTangencyAllFaces
- swTangencyDirectionVector
- swTangencyNone

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::PathAlignmentType](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

For user interface option...		Set...	
Profile Orientation set to...	And Profile Twist set to...	ISweepFeatureData::TwistControlType as defined in swTwistControlType_e to...	And ISweepFeatureData::PathAlignmentType as defined in swTangencyType_e to...
Follow Path	None	swTwistControlFollowPath	swTangencyNone
	Specify Twist Value	swTwistControlConstantTwistAlongPath	swTangencyNone
	Specify Direction Vector	swTwistControlFollowPath	swTangencyDirectionVector; call ISweepFeatureData::SetPathAlignmentDirectionVector to specify the direction vector
	Follow Path and First Guide Curve (option appears with at least one guide curve)	swTwistControlFollowPathFirstGuideCurve	swTangencyNone
	Follow Path and First and Second Guide Curves (option appears with at least two guide curves)	swTwistControlFollowFirstSecondGuideCurves	swTangencyNone
	Tangent to Adjacent Faces	swTwistControlFollowPath	swTangencyAllFaces
	Minimum Twist (available only with a 3D path)	swTwistControlFollowPath	swMinimumTwist
Keep Normal Constant	Natural	swTwistControlFollowPath	swTangencyNone
	None	swTwistControlKeepNormalConstant	swTangencyNone
	Specify Twist Value	swTwistControlConstantTwistAlongPath + swTwistControlKeepNormalConstant	swTangencyNone

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::GetPathType Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Profile Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : Profile Property (ISweepFeatureData)

Gets and sets the sketch profile or tool body for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property Profile As System.Object

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Object
```

```
instance.Profile = value  
value = instance.Profile
```

C#

```
System.object Profile {get; set;}
```

C++/CLI

```
property System.Object^ Profile {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sketch profile or tool body for this sweep feature (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::Profile](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

If a...	Then the type of object is a...
Sketch profile	Face , edge , or curve
Tool body (see NOTE)	Body that is convex, not merged with the main body and consists of one of the following: • A revolved feature that consist of analytical geometry only, such as lines and arcs • A cylindrical extruded feature

NOTE: Tool bodies are supported in swept-cut features in SOLIDWORKS API 2017 FCS and later.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::CircularProfile Property\(\)](#)
[ISweepFeatureData::GetProfileType Method\(\)](#)
[ISweepFeatureData::Direction Property\(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateFeatureToParts Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : PropagateFeatureToParts Property (ISweepFeatureData)

Gets and sets whether to extend the swept-cut feature to all affected parts in the assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property PropagateFeatureToParts As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.PropagateFeatureToParts = value
```

```
value = instance.PropagateFeatureToParts
```

C#

```
System.bool PropagateFeatureToParts {get; set;}
```

C++/CLI

```
property System.bool PropagateFeatureToParts {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to extend the swept-cut feature to all affected parts in the assembly, false to not

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::PropagateFeatureToParts](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

Use this property, [ISweepFeatureData::AssemblyFeatureScope](#), and [ISweepFeatureData::AutoSelectComponents](#) to insert sweep cuts into an assembly.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : ReleaseSelectionAccess Method (ISweepFeatureData)

Releases access to the selections for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::ReleaseSelectionAccess](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

[ISweepFeatureData::AccessSelections](#) and [ISweepFeatureData::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetD2TwistAngle Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : SetD2TwistAngle Method (ISweepFeatureData)

Sets the twist angle in Direction 2 of this bidirectional sweep feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub SetD2TwistAngle( _  
    ByVal Angle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Angle As System.Double
```

```
instance.SetD2TwistAngle(Angle)
```

C#

```
void SetD2TwistAngle(  
    System.double Angle  
)
```

C++/CLI

```
void SetD2TwistAngle(  
& System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

Angle of twist in radians in Direction 2

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::SetD2TwistAngle](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is valid only if:

- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).
- [ISweepFeatureData::Direction](#) is set to [swSweepDirection_e.swSweepBidirectional](#).

In the Sweep PropertyManager, you can specify revolutions, degrees, or radians. To specify Angle, you must convert revolutions and degrees to radians:

$$1 \text{ revolution} = 360 \text{ degrees} = 2\pi = 6.28319 \text{ radians}$$

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetD2TwistAngle Method \(\)](#)
[ISweepFeatureData::SetTwistAngle Method \(\)](#)
[ISweepFeatureData::D2ReverseTwistDir Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPathAlignmentDirectionVector Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : SetPathAlignmentDirectionVector Method (ISweepFeatureData)

Sets the direction vector for path alignment in this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetPathAlignmentDirectionVector( _  
    ByVal Dir As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Dir As System.Object  
  
instance.SetPathAlignmentDirectionVector(Dir)
```

C#

```
void SetPathAlignmentDirectionVector(  
    System.Object Dir  
)
```

C++/CLI

```
void SetPathAlignmentDirectionVector(  
    & System.Object^ Dir  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Dir

[Plane](#), planar [face](#), [line](#), [edge](#), [cylinder](#), [axis](#), or a pair of [vertices](#) that defines the direction

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::SetPathAlignmentDirectionVector](#).

Remarks

This method is valid only if:

- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlFollowPath](#).
- and -
- [ISweepFeatureData::PathAlignmentType](#) is set to [swTangencyType_e.swTangencyDirectionVector](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::Path Property](#)
[ISweepFeatureData::GetPathType Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTwistAngle Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : SetTwistAngle Method (ISweepFeatureData)

Sets the angle at which to twist this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTwistAngle( _  
    ByVal Angle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Angle As System.Double  
  
instance.SetTwistAngle(Angle)
```

C#

```
void SetTwistAngle(  
    System.double Angle  
)
```

C++/CLI

```
void SetTwistAngle(  
& System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle
Angle of twist in radians

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::SetTwistAngle](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This method is valid only if [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

In the Sweep PropertyManager, you can specify revolutions, degrees, or radians. To specify Angle, you must convert revolutions and degrees to radians:

$$1 \text{ revolution} = 360 \text{ degrees} = 2\pi = 6.28319 \text{ radians}$$

This method sets the angle of twist in radians in Direction 1 of a bidirectional sweep.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetTwistAngle Method](#)
[ISweepFeatureData::D1ReverseTwistDir Property\(\)](#)
[ISweepFeatureData::SetD2TwistAngle Method\(\)](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetWallThickness Method (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : SetWallThickness Method (ISweepFeatureData)

Sets the wall thickness, forward (Direction 1) or reverse (Direction 2), of this thin-walled sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetWallThickness( _  
    ByVal Forward As System.Boolean, _  
    ByVal WallThickness As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim Forward As System.Boolean  
Dim WallThickness As System.Double  
  
instance.SetWallThickness(Forward, WallThickness)
```

C#

```
void SetWallThickness(  
    System.bool Forward,  
    System.double WallThickness  
)
```

C++/CLI

```
void SetWallThickness(  
&    System.bool Forward,  
&    System.double WallThickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for Direction 1, false for Direction 2 (see **Remarks**)

WallThickness

Wall thickness

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::SetWallThickness](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This method:

- is valid only if [ISweepFeatureData::IsThinFeature](#) is true.
- sets the thickness in Direction 1 and Direction 2, depending on [ISweepFeatureData::ThinWallType](#).
- is not valid for swept-surface features.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::IsThinFeature Method](#)
[ISweepFeatureData::GetWallThickness Method](#)
[ISweepFeatureData::ThinFeature Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartDirectionVector Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : StartDirectionVector Property (ISweepFeatureData)

Obsolete. Gets or sets the direction vector in which to start this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Property StartDirectionVector As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Object  
  
instance.StartDirectionVector = value  
  
value = instance.StartDirectionVector
```

C#

```
System.Object StartDirectionVector {get; set;}
```

C++/CLI

```
property System.Object^ StartDirectionVector {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Plane](#), planar [face](#), [line](#), [edge](#), [cylinder](#), [axis](#), or a pair of [vertices](#) that defines the direction

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::StartDirectionVector](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::GetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::GetPathType Method](#)
[ISweepFeatureData::SetPathAlignmentDirectionVector Method](#)
[ISweepFeatureData::EndDirectionVector Property](#)
[ISweepFeatureData::Path Property](#)
[ISweepFeatureData::PathAlignmentType Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartTangencyType Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : StartTangencyType Property (ISweepFeatureData)

Gets and sets the tangency at the start of the sweep path for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property StartTangencyType As System.Short

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Short
```

```
instance.StartTangencyType = value
```

```
value = instance.StartTangencyType
```

C#

```
System.short StartTangencyType {get; set;}
```

C++/CLI

```
property System.short StartTangencyType {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tangency at start of sweep path as defined in [swTangencyType_e](#):

- swTangencyNone (default)
- swTangencyNormalToProfile

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::StartTangencyType](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is not valid if:

- [ISweepFeatureData::Direction](#) is set to [swSweepDirection_e.swSweepBiDirectional](#).
- OR -
- [ISweepFeatureData::TwistControlType](#) is set to [swTwistControlType_e.swTwistControlConstantTwistAlongPath](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::EndTangencyType Property](#)
[ISweepFeatureData::MaintainTangency Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SweepType Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : SweepType Property (ISweepFeatureData)

Gets the type of this sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SweepType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Integer  
  
value = instance.SweepType
```

C#

```
System.int SweepType {get;}
```

C++/CLI

```
property System.int SweepType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sweep type as defined in [swFeatureNameID_e](#):

- swFmSweep (swept boss)
- swFmSweepCut (swept cut)
- swRefSurface (swept surface)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::SweepType](#).

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TangentPropagation Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : TangentPropagation Property (ISweepFeatureData)

Gets or sets whether to propagate the sweep to the next tangent edge for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property TangentPropagation As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean  
  
instance.TangentPropagation = value  
value = instance.TangentPropagation
```

C#

```
System.bool TangentPropagation {get; set;}
```

C++/CLI

```
property System.bool TangentPropagation {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate the sweep to the next tangent edge, false to cause the sweep to occur only on the selected edge; to propagate to the next edge, the next edge must be tangent to the current edge

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::TangentPropagation](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::EndTangencyType Property](#)
[ISweepFeatureData::StartTangencyType Property](#)
[ISweepFeatureData::MaintainTangency Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThinFeature Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : ThinFeature Property (ISweepFeatureData)

Gets or sets whether to make this sweep feature a thin-walled feature.

.NET Syntax

Visual Basic (Declaration)

Property ThinFeature As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData  
Dim value As System.Boolean
```

```
instance.ThinFeature = value
```

```
value = instance.ThinFeature
```

C#

```
System.bool ThinFeature {get; set;}
```

C++/CLI

```
property System.bool ThinFeature {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to make a thin-walled sweep feature, false to not

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::ThinFeature](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

To make a thin sweep, you must set this property before calling [IFeatureManager::CreateFeature](#). You cannot make a thin-walled sweep feature after the sweep has been created, and you cannot edit a sweep feature to make it thin walled.

This property is not valid for swept-surface features.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::ThinWallType Property \(\)](#)
[ISweepFeatureData::SetWallThickness Method \(\)](#)
[ISweepFeatureData::IsThinFeature Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThinWallType Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : ThinWallType Property (ISweepFeatureData)

Gets or sets the type of this thin-walled sweep feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ThinWallType As System.Short
```

Visual Basic (Usage)

```
Dim instance As ISweepFeatureData
Dim value As System.Short

instance.ThinWallType = value

value = instance.ThinWallType
```

C#

```
System.short ThinWallType {get; set;}
```

C++/CLI

```
property System.short ThinWallType {
    System.short get();
    void set ( & System.short value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 0 = One Direction
- 1 = One Direction Reverse
- 2 = MidPlane
- 3 = Two Directions

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::ThinWallType](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

This property is:

- only valid if [ISweepFeatureData::IsThinFeature](#) is true.
- not valid for swept-surface features.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISweepFeatureData Interface](#)
[ISweepFeatureData Members](#)
[ISweepFeatureData::SetWallThickness Method](#)
[ISweepFeatureData::IsThinFeature Method](#)
[ISweepFeatureData::GetWallThickness Method](#)
[ISweepFeatureData::ThinFeature Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TwistControlType Property (ISweepFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweepFeatureData Interface](#) : TwistControlType Property (ISweepFeatureData)

Gets or sets the type of twist control for this sweep feature.

.NET Syntax

Visual Basic (Declaration)

Property TwistControlType As System.Short

Visual Basic (Usage)



```
Dim instance As ISweepFeatureData
Dim value As System.Short

instance.TwistControlType = value

value = instance.TwistControlType
```

C#

```
System.short TwistControlType {get; set;}
```

C++/CLI

```
property System.short TwistControlType {
    System.short get();
    void set ( & System.short value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Twist control as defined in [swTwistControlType_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweepFeatureData::TwistControlType](#).

Example

See the [ISweepFeatureData](#) examples.

Remarks

For user interface options...

Set...

Profile Orientation set to...	And Profile Twist set to...	ISweepFeatureData::TwistControlType as defined in swTwistControlType_e to...	And ISweepFeatureData::PathAlignmentType as defined in swTangencyType_e to...
Follow Path	None	swTwistControlFollowPath	swTangencyNone
	Specify Twist Value	swTwistControlConstantTwistAlongPath	swTangencyNone
	Specify Direction Vector	swTwistControlFollowPath	swTangencyDirectionVector
	Follow Path and First Guide Curve (option appears with at least one guide curve)	swTwistControlFollowPathFirstGuideCurve	swTangencyNone
	Follow Path and First and Second Guide Curves (option appears with at least two guide curves)	swTwistControlFollowFirstSecondGuideCurves	swTangencyNone
	Tangent to Adjacent Faces	swTwistControlFollowPath	swTangencyAllFaces
	Minimum Twist (available only with a 3D path)	swTwistControlFollowPath	swMinimumTwist
	Natural	swTwistControlFollowPath	swTangencyNone
Keep Normal Constant	None	swTwistControlKeepNormalConstant	swTangencyNone
	Specify Twist Value	swTwistControlConstantTwistAlongPath + swTwistControlKeepNormalConstant	swTangencyNone

If you specify this property with swTwistControlType_e.swTwistControlConstantTwistAlongPath to specify profile twist values, you must set [ISweepFeatureData::AlignWithEndFaces](#) to false.

See [Accessing Selections that Define Features](#) for additional details.

See Also

- [ISweepFeatureData Interface](#)
- [ISweepFeatureData Members](#)
- [ISweepFeatureData::GetTwistAngle Method](#)
- [ISweepFeatureData::SetTwistAngle Method](#)
- [ISweepFeatureData::D1ReverseTwistDir Property \(\)](#)
- [ISweepFeatureData::D2ReverseTwistDir Property \(\)](#)
- [ISweepFeatureData::GetD2TwistAngle Method \(\)](#)
- [ISweepFeatureData::SetD2TwistAngle Method \(\)](#)

Availability

