

SOLIDWORKS API (.NET VBA C#) — Reference

(305/337): ISweptFlangeFeatureData- ISWPEClassFactory

SOLIDWORKS API Documentation (converted from CHM)

ISweptFlangeFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISweptFlangeFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISweptFlangeFeatureData Interface

Allows access to a sheet metal swept flange feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISweptFlangeFeatureData
```

Visual Basic (Usage)

```
Dim instance As ISweptFlangeFeatureData
```

C#

```
public interface ISweptFlangeFeatureData
```

C++/CLI

```
public interface class ISweptFlangeFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData](#).

Example

'VBA

'Preconditions: Ensure that the specified part template exists.

'Postconditions:

- '1. **Base-Flange1** and **Swept Flange1** are created.
- '2. Inspect the graphics area and the FeatureManager design tree.

'=====

```
Dim swApp As SldWorks.SldWorks
Dim swFeat As SldWorks.Feature
Dim myFeature As SldWorks.Feature
Dim swFeatMgr As SldWorks.FeatureManager
Dim swFeatData As SldWorks.SweptFlangeFeatureData
Dim customBendAllowanceData As SldWorks.CustomBendAllowance
Dim swProfileSketch As SldWorks.Feature
Dim skSegment As SldWorks.SketchSegment
Dim Part As SldWorks.ModelDoc2
Dim swPart As PartDoc
Dim boolstatus As Boolean
Dim longstatus As Long
```

Option Explicit

Sub main()

Set swApp = Application.SldWorks

Dim swSheetWidth As Double

swSheetWidth = 0

Dim swSheetHeight As Double

swSheetHeight = 0

Set Part = swApp.NewDocument("C:\Program Files\SOLIDWORKS Corp\SOLIDWORKS\lang\english\Tutorial\part.prt", 0, swSheetWidth, swSheetHeight)

Set swPart = Part

swApp.ActivateDoc2 "Part1", False, longstatus

```

Set Part = swApp.ActiveDoc

Part.SketchManager.InsertSketch True
boolstatus = Part.Extension.SelectByID2("Front", "PLANE", -3.50345417518034E-02, 0.019677523162802, 5.11863136830445E-03, False, C
Nothing, 0)
Part.ClearSelection2 True
boolstatus = Part.Extension.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstToRectEntity,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, False)
boolstatus = Part.Extension.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstLineDiagonalType,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, True)
Dim vSkLines As Variant
vSkLines = Part.SketchManager.CreateCornerRectangle(-4.20403557341645E-02, 2.75066828701494E-02, 0, 4.75026757367474E-02,
-2.20443628675665E-02, 0)
Part.ClearSelection2 True

Part.ShowNamedView2 "**Trimetric", 8
Part.ViewZoomtofit2

Set customBendAllowanceData = Part.FeatureManager.CreateCustomBendAllowance()
customBendAllowanceData.KFactor = 0.5

Set myFeature = Part.FeatureManager.InsertSheetMetalBaseFlange2(0.0007366, False, 0.0007366, 0.02, 0.01, False, 0, 0, 1,
customBendAllowanceData, False, 0, 0.0001, 0.0001, 0.5, True, False, True, True)

Part.ClearSelection2 True
Part.SketchManager.InsertSketch True
boolstatus = Part.Extension.SelectByID2("", "FACE", 4.41584745988735E-02, 2.75066828701256E-02, -2.52375262334681E-04, True, 0,
Nothing, 0)

Set skSegment = Part.SketchManager.CreateLine(0.047503, 0#, 0#, 0.047503, -0.015713, 0#)
Part.ClearSelection2 True
Part.SketchManager.InsertSketch True

boolstatus = Part.Extension.SelectByID2("Sketch6", "SKETCH", 2.54585357375204E-02, -3.78791126417555E-03, -0.013876316631307,
True, 0, Nothing, 0)
boolstatus = Part.Extension.SelectByRay(4.72949686339916E-02, 1.33307046879168E-02, 2.07707102561017E-04, -0.499999999999997,
-0.707106781186554, -0.499999999999995, 4.23592175091009E-04, 1, True, 0, 0)
Part.ClearSelection2 True

boolstatus = Part.Extension.SelectByID2("Sketch6", "SKETCH", 2.54585357375204E-02, -3.78791126417555E-03, -0.013876316631307,
True, 0, Nothing, 0)
Set swProfileSketch = Part.SelectionManager.GetSelectedObject6(1, -1)
Part.ClearSelection2 True

Dim swPathObj As Object
Dim pathObjsArray(0) As Object
boolstatus = Part.Extension.SelectByRay(4.72949686339916E-02, 1.33307046879168E-02, 2.07707102561017E-04, -0.499999999999997,
-0.707106781186554, -0.499999999999995, 4.23592175091009E-04, 1, True, 0, 0)
Set swPathObj = Part.SelectionManager.GetSelectedObject6(1, -1)
Set pathObjsArray(0) = swPathObj
Dim pathObjsVar As Variant
pathObjsVar = pathObjsArray
Part.ClearSelection2 True

Set swFeatMgr = Part.FeatureManager

Set swFeatData = swFeatMgr.CreateDefinition(swFeatureNameID_e.swFmSweptFlange)
swFeatData.EndOffset = 0
swFeatData.FlangePosition = swSweptFlangePositionType_MaterialInside
swFeatData.FlattenAlongPath = False
swFeatData.OverrideDefaultSheetMetalParameters = False
swFeatData.Path = pathObjsVar
swFeatData.Profile = swProfileSketch
swFeatData.ReverseDirection = False
swFeatData.StartOffset = 0
swFeatData.TrimSideBends = False
swFeatData.UseDefaultBendAllowance = True
swFeatData.UseDefaultBendRelief = True
swFeatData.UseDefaultRadius = False
swFeatData.UseGaugeTable = False
swFeatData.UseMaterialSheetMetalParameters = False
Set swFeat = swFeatMgr.CreateFeature(swFeatData)
Part.ClearSelection2 True

End Sub

```

Example

[Create Swept Flange \(VB.NET\)](#)
[Create Swept Flange \(C#\)](#)

Remarks

For more information about swept flanges, read the [SOLIDWORKS Help > Sheet Metal > Using Sheet Metal Tools > Swept Flange > Swept Flange PropertyManager](#) topic.

Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[SweptFlangeFeatureData](#)

See Also

[ISweptFlangeFeatureData Members](#)

[SolidWorks.Interop.sldworks Namespace](#)

[ISheetMetalGaugeTableParameters Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISweptFlangeFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISweptFlangeFeatureData Interface

The following tables list the members exposed by [ISweptFlangeFeatureData](#).

Public Properties

Name	Description
 BendRadius	Gets or sets the bend radius of this swept flange feature.
 CylindricalOrConicalEdge	Gets or sets the linear sketch entity to propagate to the flat pattern of this cylindrical or conical swept flange feature.
 EndOffset	Gets or sets the end offset of this swept flange feature.
 FlangePosition	Gets or sets the flange position of this swept flange feature.
 FlattenAlongPath	Gets or sets whether to flatten the flange profile along the sweep path of this swept flange feature.
 MaterialInside	Gets or sets whether to flatten the flange profile with material inside of this swept flange feature.
 OverrideDefaultSheetMetalParameters	Gets or sets whether to override the default sheet metal parameters for this swept flange feature.
 Path	Gets or sets the sweep path of this swept flange feature.
 Profile	Gets or sets the sweep profile of this swept flange feature.
 ReliefDepth	Gets or sets the bend relief depth for this swept flange feature.
 ReliefRatio	Gets or sets the bend relief ratio for this swept flange feature.
 ReliefType	Gets or sets the bend relief type for this swept flange feature.
 ReliefWidth	Gets or sets the bend relief width for this swept flange feature.
 ReverseDirection	Gets or sets whether to reverse the direction of sheet metal thickness of this swept flange feature.
 StartOffset	Gets or sets the start offset of this swept flange feature.
 Thickness	Gets or sets the sheet metal thickness of this swept flange feature.
 TrimSideBends	Gets or sets whether to remove extra material in neighboring bends of this swept flange feature.
 UseDefaultBendAllowance	Gets or sets whether to use the bend allowance from the original sheet metal feature in this swept flange feature.
 UseDefaultBendRelief	Gets or sets whether to use the bend relief from the original sheet metal feature in this swept flange feature.
 UseDefaultRadius	Gets or sets whether to use the bend radius from the original sheet metal feature in this swept flange feature.
 UseGaugeTable	Gets or sets whether to use an Excel gauge table for this swept flange feature.
 UseMaterialSheetMetalParameters	Gets or sets whether to use the material sheet metal parameters in this swept flange feature.
 UseReliefRatio	Gets or sets whether to use the relief ratio in this swept flange feature.



[Top](#)

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this swept flange feature.
 GetCustomBendAllowance	Gets the custom bend allowance object.
 GetErrorCodes	Gets the error conditions that occur during swept flange feature creation or modification.
 GetGaugeTableParameters	Gets the gauge table parameters object.
 GetPathType	Gets the type of the sweep path in this swept flange feature.
 ReleaseSelectionAccess	Releases access to the selections for this swept flange feature.
 SetCustomBendAllowance	Sets the custom bend allowance for this swept flange feature.
 SetGaugeTableParameters	Sets the gauge table parameters object.

[Top](#)

See Also

[ISweptFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalGaugeTableParameters Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISweptFlangeFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISweptFlangeFeatureData Interface

For a list of all members of this type, see [ISweptFlangeFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this swept flange feature.
 GetCustomBendAllowance	Gets the custom bend allowance object.
 GetErrorCodes	Gets the error conditions that occur during swept flange feature creation or modification.
 GetGaugeTableParameters	Gets the gauge table parameters object.
 GetPathType	Gets the type of the sweep path in this swept flange feature.
 ReleaseSelectionAccess	Releases access to the selections for this swept flange feature.
 SetCustomBendAllowance	Sets the custom bend allowance for this swept flange feature.
 SetGaugeTableParameters	Sets the gauge table parameters object.

[Top](#)

See Also

[ISweptFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalGaugeTableParameters Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISweptFlangeFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISweptFlangeFeatureData Interface

For a list of all members of this type, see [ISweptFlangeFeatureData members](#).

Public Properties

Name	Description
 BendRadius	Gets or sets the bend radius of this swept flange feature.
 CylindricalOrConicalEdge	Gets or sets the linear sketch entity to propagate to the flat pattern of this cylindrical or conical swept flange feature.
 EndOffset	Gets or sets the end offset of this swept flange feature.
 FlangePosition	Gets or sets the flange position of this swept flange feature.
 FlattenAlongPath	Gets or sets whether to flatten the flange profile along the sweep path of this swept flange feature.
 MaterialInside	Gets or sets whether to flatten the flange profile with material inside of this swept flange feature.
 OverrideDefaultSheetMetalParameters	Gets or sets whether to override the default sheet metal parameters for this swept flange feature.
 Path	Gets or sets the sweep path of this swept flange feature.
 Profile	Gets or sets the sweep profile of this swept flange feature.
 ReliefDepth	Gets or sets the bend relief depth for this swept flange feature.
 ReliefRatio	Gets or sets the bend relief ratio for this swept flange feature.
 ReliefType	Gets or sets the bend relief type for this swept flange feature.
 ReliefWidth	Gets or sets the bend relief width for this swept flange feature.
 ReverseDirection	Gets or sets whether to reverse the direction of sheet metal thickness of this swept flange feature.
 StartOffset	Gets or sets the start offset of this swept flange feature.
 Thickness	Gets or sets the sheet metal thickness of this swept flange feature.
 TrimSideBends	Gets or sets whether to remove extra material in neighboring bends of this swept flange feature.
 UseDefaultBendAllowance	Gets or sets whether to use the bend allowance from the original sheet metal feature in this swept flange feature.
 UseDefaultBendRelief	Gets or sets whether to use the bend relief from the original sheet metal feature in this swept flange feature.
 UseDefaultRadius	Gets or sets whether to use the bend radius from the original sheet metal feature in this swept flange feature.
 UseGaugeTable	Gets or sets whether to use an Excel gauge table for this swept flange feature.
 UseMaterialSheetMetalParameters	Gets or sets whether to use the material sheet metal parameters in this swept flange feature.
 UseReliefRatio	Gets or sets whether to use the relief ratio in this swept flange feature.

[Top](#)

 See Also

[ISweptFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalGaugeTableParameters Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : AccessSelections Method (ISweptFlangeFeatureData)

Accesses the selections that define this swept flange feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISweptFlangeFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean
```



Copy Code

```
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::AccessSelections](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISweptFlangeFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendRadius Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : BendRadius Property (ISweptFlangeFeatureData)

Gets or sets the bend radius of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property BendRadius As System.Double

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Double  
  
instance.BendRadius = value  
  
value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend radius

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::BendRadius](#).

Remarks

The setter of this property is valid only if [ISweptFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is true.

This property gets a:

- Default bend radius if:
 - [ISweptFlangeFeatureData::UseDefaultRadius](#) is true,
- and -
 - [ISweptFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is false.
- Custom bend radius if:
 - [ISweptFlangeFeatureData::UseDefaultRadius](#) is false,
- and -
 - [ISweptFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is true.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

CylindricalOrConicalEdge Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : CylindricalOrConicalEdge Property (ISweptFlangeFeatureData)

Gets or sets the linear sketch entity to propagate to the flat pattern of this cylindrical or conical swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property CylindricalOrConicalEdge As System.Object

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Object

instance.CylindricalOrConicalEdge = value
value = instance.CylindricalOrConicalEdge
```

C#

```
System.object CylindricalOrConicalEdge {get; set;}
```

C++/CLI

```
property System.Object^ CylindricalOrConicalEdge {
    System.Object^ get();
    void set ( &    System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Linear sketch entity

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::CylindricalOrConicalEdge](#).

Remarks

This property is valid only:

- for cylindrical or conical swept flanges
- and -
- for [sweep paths](#) that are sketches,
- and -
- when not creating the swept flange on an existing sheet metal feature.

For more information, read the **SOLIDWORKS Help > Sheet Metal > Using Sheet Metal Tools > Swept Flange > Creating a Conical Body with a Swept Flange** topic.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndOffset Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : EndOffset Property (ISweptFlangeFeatureData)

Gets or sets the end offset of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property EndOffset As System.Double

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Double

instance.EndOffset = value

value = instance.EndOffset
```

C#

```
System.double EndOffset {get; set;}
```

C++/CLI

```
property System.double EndOffset {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End offset

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::EndOffset](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

This property is valid only if [ISweptFlangeFeatureData::Path](#) is an open loop.

If you want the swept flange to span the entire edge of the model, set both this property and [ISweptFlangeFeatureData::StartOffset](#) to 0.0.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlangePosition Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : FlangePosition Property (ISweptFlangeFeatureData)

Gets or sets the flange position of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FlangePosition As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Integer

instance.FlangePosition = value
```

```
value = instance.FlangePosition
```

C#

```
System.int FlangePosition {get; set;}
```

C++/CLI

```
property System.int FlangePosition {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flange position as defined by [swSweptFlangePostionTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::FlangePosition](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlattenAlongPath Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : FlattenAlongPath Property (ISweptFlangeFeatureData)

Gets or sets whether to flatten the flange profile along the sweep path of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FlattenAlongPath As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.FlattenAlongPath = value
```

```
value = instance.FlattenAlongPath
```

C#

```
System.bool FlattenAlongPath {get; set;}
```

C++/CLI

```
property System.bool FlattenAlongPath {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flatten the profile along the sweep path, false to not

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::FlattenAlongPath](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

This property is valid only when not creating the swept flange on an existing sheet metal feature.

If this property is true, then you can also specify [ISweptFlangeFeatureData::MaterialInside](#).

If this property is:

- True, then when the model is flattened the [profile](#) flattens and is rotated parallel to the plane of the path. The [path](#) is not flattened, and the result is a the shape of the path.
- False, then when the model is flattened the profile flattens and is rotated perpendicular to the plane of the path. The path is flattened, and the result is a rectangular shape.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : GetCustomBendAllowance Method (ISweptFlangeFeatureData)

Gets the custom bend allowance object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Object  
  
value = instance.GetCustomBendAllowance()
```

C#

```
System.object GetCustomBendAllowance()
```

C++/CLI

```
System.Object^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ICustomBendAllowance](#)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::GetCustomBendAllowance](#).

Remarks

This method is valid only if [ISweptFlangeFeatureData::UseDefaultBendAllowance](#) is false.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)
[ISweptFlangeFeatureData::SetCustomBendAllowance Method\(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetErrorCodes Method (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : GetErrorCodes Method (ISweptFlangeFeatureData)

Gets the error conditions that occur during swept flange feature creation or modification.

.NET Syntax

Visual Basic (Declaration)

```
Function GetErrorCodes() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Integer
```

```
value = instance.GetErrorCodes()
```

C#

```
System.int GetErrorCodes()
```

C++/CLI

```
System.int GetErrorCodes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Error codes as defined by [swSweptFlangeError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::GetErrorCodes](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGaugeTableParameters Method (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : GetGaugeTableParameters Method (ISweptFlangeFeatureData)

Gets the gauge table parameters object.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetGaugeTableParameters() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Object  
  
value = instance.GetGaugeTableParameters()
```

C#

```
System.Object GetGaugeTableParameters()
```

C++/CLI

```
System.Object^ GetGaugeTableParameters();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ISheetMetalGaugeTableParameters](#)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::GetGaugeTableParameters](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

This method is valid only if [ISweptFlangeFeatureData::UseGaugeTable](#) is true.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)
[ISweptFlangeFeatureData::SetGaugeTableParameters Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPathType Method (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : GetPathType Method (ISweptFlangeFeatureData)

Gets the type of the [sweep path](#) in this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPathType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Integer  
  
value = instance.GetPathType()
```

C#

```
System.int GetPathType()
```

C++/CLI

```
System.int GetPathType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Sweep path type as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::GetPathType](#).

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaterialInside Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : MaterialInside Property (ISweptFlangeFeatureData)

Gets or sets whether to flatten the flange profile with material inside of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property MaterialInside As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Boolean  
  
instance.MaterialInside = value  
  
value = instance.MaterialInside
```

C#

```
System.bool MaterialInside {get; set;}
```

C++/CLI

```
property System.bool MaterialInside {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flatten the flange profile with material inside, false to not

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::MaterialInside](#).

Remarks

This property is valid only:

- if [ISweptFlangeFeatureData::FlattenAlongPath](#) is true,
- and -
- when not creating the swept flange on an existing sheet metal feature.

The flat pattern of the model may fail for either setting of this property, depending on whether self-intersecting geometry occurs with material inside or outside. You should test your model to determine which setting of this property successfully flattens the flange [profile](#).

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDefaultSheetMetalParameters Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : OverrideDefaultSheetMetalParameters Property (ISweptFlangeFeatureData)

Gets or sets whether to override the default sheet metal parameters for this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OverrideDefaultSheetMetalParameters As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Boolean  
  
instance.OverrideDefaultSheetMetalParameters = value  
  
value = instance.OverrideDefaultSheetMetalParameters
```

C#

```
System.bool OverrideDefaultSheetMetalParameters {get; set;}
```

C++/CLI

```
property System.bool OverrideDefaultSheetMetalParameters {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the default values, false to not

Visual Basic for Applications (VBA) Syntax

See [ISweptFlangeFeatureData::OverrideDefaultSheetMetalParameters](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

This property is valid only when creating the swept flange in a non-sheet-metal part.

If this property is:

- True, then [ISweptFlangeFeatureData::Thickness](#) and [ISweptFlangeFeatureData::BendRadius](#) get and set user-defined values.
- False, then [ISweptFlangeFeatureData::Thickness](#) and [ISweptFlangeFeatureData::BendRadius](#) are invalid as setters and get only default values.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

Path Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : Path Property (ISweptFlangeFeatureData)

Gets or sets the sweep path of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property Path As System.Object

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Object
```

```
instance.Path = value
```

```
value = instance.Path
```

C#

```
System.object Path {get; set;}
```

C++/CLI

```
property System.Object^ Path {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [edges](#) or a [sketch](#) of lines and arcs

Visual Basic for Applications (VBA) Syntax

See [ISweptFlangeFeatureData::Path](#).

Example

See the [ISweptFlangeFeatureData](#) and [ISheetMetalGaugeTableParameters](#) examples.

Remarks

If the sweep path is a closed loop, then [ISweptFlangeFeatureData::StartOffset](#) and [ISweptFlangeFeatureData::EndOffset](#) are not valid.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)
[ISweptFlangeFeatureData::GetPathType Method \(\)](#)
[ISweptFlangeFeatureData::CylindricalOrConicalEdge Property \(\)](#)
[ISweptFlangeFeatureData::FlattenAlongPath Property \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

Profile Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : Profile Property (ISweptFlangeFeatureData)

Gets or sets the sweep profile of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property Profile As System.Object

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Object

instance.Profile = value

value = instance.Profile
```

C#

```
System.Object Profile {get; set;}
```

C++/CLI

```
property System.Object^ Profile {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Sketch](#) consisting of lines and arcs (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::Profile](#).

Example

See the [ISweptFlangeFeatureData](#) and [ISheetMetalGaugeTableParameters](#) examples.

Remarks

Splines are not supported in sweep profile sketches.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)
[ISweptFlangeFeatureData::FlattenAlongPath Property\(\)](#)
[ISweptFlangeFeatureData::MaterialInside Property\(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : ReleaseSelectionAccess Method (ISweptFlangeFeatureData)

Releases access to the selections for this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::ReleaseSelectionAccess](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

[ISweptFlangeFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.
Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) if you did modify the feature.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefDepth Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : ReliefDepth Property (ISweptFlangeFeatureData)

Gets or sets the bend relief depth for this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property ReliefDepth As System.Double

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Double
```

```
instance.ReliefDepth = value
```

```
value = instance.ReliefDepth
```

C#

```
System.double ReliefDepth {get; set;}
```

C++/CLI

```
property System.double ReliefDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend relief depth

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::ReliefDepth](#).

Remarks

This property is valid:

- If [ISweptFlangeFeatureData::UseReliefRatio](#) is false,
- and -
- For regular swept flanges, but for cylindrical or conical swept flanges only during creation,
- and -
- When [ISweptFlangeFeatureData::ReliefType](#) is [swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular](#) or [swSheetMetalReliefTypes_e.swSheetMetalReliefObround](#).

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefRatio Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : ReliefRatio Property (ISweptFlangeFeatureData)

Gets or sets the bend relief ratio for this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefRatio As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Double

instance.ReliefRatio = value

value = instance.ReliefRatio
```

C#

```
System.double ReliefRatio {get; set;}
```

C++/CLI

```
property System.double ReliefRatio {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Ratio of bend relief width to bend relief depth

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::ReliefRatio](#).

Remarks

This property is valid:

- For regular swept flanges, but for cylindrical or conical swept flanges only during creation,
- When [SweptFlangeFeatureData::UseReliefRatio](#) is true,
- and -
- When [SweptFlangeFeatureData::ReliefType](#) is [swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular](#) or [swSheetMetalReliefTypes_e.swSheetMetalReliefObround](#).

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefType Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : ReliefType Property (ISweptFlangeFeatureData)

Gets or sets the bend relief type for this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property ReliefType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Integer

instance.ReliefType = value

value = instance.ReliefType
```

C#

```
System.int ReliefType {get; set;}
```

C++/CLI

```
property System.int ReliefType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend relief type as defined by [swSheetMetalReliefTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::ReliefType](#).

Remarks

This property is valid:

- for regular swept flanges,
- and -
- for cylindrical or conical swept flanges only during creation.

The setter of this property is valid only if [ISweptFlangeFeatureData::UseDefaultBendRelief](#) is false.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefWidth Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : ReliefWidth Property (ISweptFlangeFeatureData)

Gets or sets the bend relief width for this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefWidth As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Double
```

```
instance.ReliefWidth = value  
value = instance.ReliefWidth
```

C#

```
System.double ReliefWidth {get; set;}
```

C++/CLI

```
property System.double ReliefWidth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend relief width

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::ReliefWidth](#).

Remarks

This property is valid:

- If [ISweptFlangeFeatureData::UseReliefRatio](#) is false,
- and -
- For regular swept flanges, but for cylindrical or conical swept flanges only during creation,
- and -
- When [ISweptFlangeFeatureData::ReliefType](#) is [swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular](#) or [swSheetMetalReliefTypes_e.swSheetMetalReliefObround](#).

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : ReverseDirection Property (ISweptFlangeFeatureData)

Gets or sets whether to reverse the direction of sheet metal thickness of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse direction of thickness, false to not

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::ReverseDirection](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

This property is valid only when creating the swept flange in a non-sheet-metal part.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCustomBendAllowance Method (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : SetCustomBendAllowance Method (ISweptFlangeFeatureData)

Sets the custom bend allowance for this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance(  
    ByVal PBendData As System.Object  
)
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim PBendData As System.Object  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    System.object PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(  
& System.Object^ PBendData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[PBendData](#)
[ICustomBendAllowance](#)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::SetCustomBendAllowance](#).

Remarks

This method is valid only when creating the swept flange and only if [ISweptFlangeFeatureData::UseDefaultBendAllowance](#) is false.

Use [ISweptFlangeFeatureData::GetCustomBendAllowance](#) to specify PBendData.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetGaugeTableParameters Method (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : SetGaugeTableParameters Method (ISweptFlangeFeatureData)

Sets the gauge table parameters object.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetGaugeTableParameters( _  
    ByVal DispIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim DispIn As System.Object  
  
instance.SetGaugeTableParameters(DispIn)
```

C#

```
void SetGaugeTableParameters(  
    System.object DispIn  
)
```

C++/CLI

```
void SetGaugeTableParameters(  
& System.Object^ DispIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::SetGaugeTableParameters](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

This method is valid only if [ISweptFlangeFeatureData::UseGaugeTable](#) is true.

Use [ISweptFlangeFeatureData::GetGaugeTableParameters](#) to specify Displn.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

StartOffset Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : StartOffset Property (ISweptFlangeFeatureData)

Gets or sets the start offset of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property StartOffset As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Double
```

```
instance.StartOffset = value
```

```
value = instance.StartOffset
```

C#

```
System.double StartOffset {get; set;}
```

C++/CLI

```
property System.double StartOffset {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Start offset

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::StartOffset](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

This property is valid only if [ISweptFlangeFeatureData::Path](#) is an open loop.

If you want the swept flange to span the entire edge of the model, set both this property and [ISweptFlangeFeatureData::EndOffset](#) to 0.0.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

Thickness Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : Thickness Property (ISweptFlangeFeatureData)

Gets or sets the sheet metal thickness of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property Thickness As System.Double

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Double
```

```
instance.Thickness = value
```

```
value = instance.Thickness
```

C#

```
System.double Thickness {get; set;}
```

C++/CLI

```
property System.double Thickness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sheet metal thickness

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::Thickness](#).

Remarks

This property is valid only when not creating the swept flange on an existing sheet metal feature.

The setter of this property is valid only if [ISweptFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is true.

This property gets:

- Default thickness if [ISweptFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is false.
- Custom thickness if [ISweptFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is true.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

TrimSideBends Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : TrimSideBends Property (ISweptFlangeFeatureData)

Gets or sets whether to remove extra material in neighboring bends of this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property TrimSideBends As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.TrimSideBends = value
```

```
value = instance.TrimSideBends
```

C#

```
System.bool TrimSideBends {get; set;}
```

C++/CLI

```
property System.bool TrimSideBends {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to trim extra material in neighboring bends, false to not

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::TrimSideBends](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

UseDefaultBendAllowance Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : UseDefaultBendAllowance Property (ISweptFlangeFeatureData)

Gets or sets whether to use the bend allowance from the original sheet metal feature in this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendAllowance As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Boolean
```

```
instance.UseDefaultBendAllowance = value
```

```
value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend allowance, false to use a custom bend allowance (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::UseDefaultBendAllowance](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

For cylindrical/conical swept flanges, this property is valid only during creation.

If this property is false, then use [ISweptFlangeFeatureData::GetCustomBendAllowance](#) and [ISweptFlangeFeatureData::SetCustomBendAllowance](#) to get and set a custom bend allowance.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

UseDefaultBendRelief Property (ISweptFlangeFeatureData)

[See Also](#)



Gets or sets whether to use the bend relief from the original sheet metal feature in this swept flange feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property UseDefaultBendRelief As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.UseDefaultBendRelief = value
```

```
value = instance.UseDefaultBendRelief
```

C#

```
System.bool UseDefaultBendRelief {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRelief {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend relief, false to specify custom bend relief values (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::UseDefaultBendRelief](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

For cylindrical/conical swept flanges, this property is valid only during creation.

If this property is false, then you can set:

- [ISweptFlangeFeatureData::ReliefType](#)
- [ISweptFlangeFeatureData::UseReliefRatio](#)

If [ISweptFlangeFeatureData::UseReliefRatio](#) is:

- True, then you can set [ISweptFlangeFeatureData::ReliefRatio](#).
- False, then you can set [ISweptFlangeFeatureData::ReliefDepth](#) and [ISweptFlangeFeatureData::ReliefWidth](#).

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29



Gets or sets whether to use the bend radius from the original sheet metal feature in this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.UseDefaultRadius = value
```

```
value = instance.UseDefaultRadius
```

C#

```
System.bool UseDefaultRadius {get; set;}
```

C++/CLI

```
property System.bool UseDefaultRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the original sheet metal bend radius, false to use a custom bend radius (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::UseDefaultRadius](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

If this property is false, then use [ISweptFlangeFeatureData::BendRadius](#) to get or set a custom bend radius.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseGaugeTable Property (ISweptFlangeFeatureData)

[See Also](#)



Gets or sets whether to use an Excel gauge table for this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

Property UseGaugeTable As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISweptFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.UseGaugeTable = value
```

```
value = instance.UseGaugeTable
```

C#

```
System.bool UseGaugeTable {get; set;}
```

C++/CLI

```
property System.bool UseGaugeTable {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use an Excel gauge table, false to not

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::UseGaugeTable](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

This property is valid only:

- if [ISweptFlangeFeatureData::UseMaterialSheetMetalParameters](#) is false,
- and -
- when not creating the swept flange on an existing sheet metal feature.

If this property is true, then use [ISweptFlangeFeatureData::GetGaugeTableParameters](#) and [ISweptFlangeFeatureData::SetGaugeTableParameters](#) to get and set the gauge table.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseMaterialSheetMetalParameters Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : UseMaterialSheetMetalParameters Property (ISweptFlangeFeatureData)

Gets or sets whether to use the material sheet metal parameters in this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseMaterialSheetMetalParameters As System.Boolean
```

```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Boolean

instance.UseMaterialSheetMetalParameters = value

value = instance.UseMaterialSheetMetalParameters
```

C#

```
System.bool UseMaterialSheetMetalParameters {get; set;}
```

C++/CLI

```
property System.bool UseMaterialSheetMetalParameters {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the material sheet metal parameters, false to not

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::UseMaterialSheetMetalParameters](#).

Example

See the [ISweptFlangeFeatureData](#) examples.

Remarks

This property is valid only:

- when not creating the swept flange on an existing sheet metal feature,
- and -
- when [ISweptFlangeFeatureData::UseGaugeTable](#) is false.

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseReliefRatio Property (ISweptFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISweptFlangeFeatureData Interface](#) : UseReliefRatio Property (ISweptFlangeFeatureData)

Gets or sets whether to use the relief ratio in this swept flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseReliefRatio As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISweptFlangeFeatureData
Dim value As System.Boolean
```

```
instance.UseReliefRatio = value
```

```
value = instance.UseReliefRatio
```

C#

```
System.bool UseReliefRatio {get; set;}
```

C++/CLI

```
property System.bool UseReliefRatio {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the relief ratio, false to not

Visual Basic for Applications (VBA) Syntax

See [SweptFlangeFeatureData::UseReliefRatio](#).

Remarks

This property is valid:

- If [ISweptFlangeFeatureData::UseDefaultBendRelief](#) is false,
 - and -
 - For regular swept flanges, but for cylindrical/conical swept flanges only during creation,
 - and -
 - When [ISweptFlangeFeatureData::ReliefType](#) is [swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular](#) or [swSheetMetalReliefTypes_e.swSheetMetalReliefObround](#).

If this property is:

- True, then use [ISweptFlangeFeatureData::ReliefRatio](#) to set a ratio of bend relief width to bend relief depth.
- False, then specify [ISweptFlangeFeatureData::ReliefWidth](#) and [ISweptFlangeFeatureData::ReliefDepth](#).

See Also

[ISweptFlangeFeatureData Interface](#)
[ISweptFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

ISwOLEObject (Type)

ISwOLEObject Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISwOLEObject Interface

Allows access to an OLE object.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwOLEObject
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject
```

C#

```
public interface ISwOLEObject
```

C++/CLI

```
public interface class ISwOLEObject
```

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject](#).

Example

[Get OLE Object Data \(VBA\)](#)
[Get OLE Object Data \(VB.NET\)](#)
[Get OLE Object Data \(C#\)](#)

Accessors

[IModelDocExtension::CreateOLEObject](#) and [IModelDocExtension::ICreateOLEObject](#)
[IModelDocExtension::GetOLEObjects](#) and [IModelDocExtension::IGetOLEObjects](#)
[IModelDocExtension::InsertObjectFromFile](#)

Access Diagram

[SwOLEObject](#)

See Also

[ISwOLEObject Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISwOLEObject Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISwOLEObject Interface

For a list of all members of this type, see [ISwOLEObject members](#).

Public Methods

Name	Description
IGetBoundaries	Gets the boundaries for this OLE object.

		
	IGetBuffer	Gets the data for this OLE object.
	ISetBoundaries	Sets the boundaries of this OLE object.
	Refresh	Refreshes the data (i.e., reloads the data from the external file in case it was changed by another application).
	Select	Selects an OLE object.
	SetActive	Activates or deactivates the OLE object.

[Top](#)

See Also

[ISwOLEObject Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISwOLEObject Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISwOLEObject Interface

The following tables list the members exposed by [ISwOLEObject](#).

Public Properties

Name	Description
 Aspect	Gets the viewing aspect for this OLE object.
 Boundaries	Gets or sets the boundaries for this OLE object.
 Buffer	Gets the data for this OLE object.
 BufferSize	Gets the size of the OLE object data.
 Clsid	Gets the class ID of this OLE object.
 FileName	Gets the path and name of the external file to which this OLE object is linked.
 IsLinked	Gets whether the OLE objects are linked to external files or not.

[Top](#)

Public Methods

Name	Description
 IGetBoundaries	Gets the boundaries for this OLE object.
 IGetBuffer	Gets the data for this OLE object.
 ISetBoundaries	Sets the boundaries of this OLE object.
 Refresh	Refreshes the data (i.e., reloads the data from the external file in case it was changed by another application).
 Select	Selects an OLE object.
 SetActive	Activates or deactivates the OLE object.

[Top](#)

See Also

[ISwOLEObject Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISwOLEObject Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISwOLEObject Interface

For a list of all members of this type, see [ISwOLEObject members](#).

Public Properties

Name	Description
 Aspect	Gets the viewing aspect for this OLE object.
 Boundaries	Gets or sets the boundaries for this OLE object.
 Buffer	Gets the data for this OLE object.
 BufferSize	Gets the size of the OLE object data.
 Clsid	Gets the class ID of this OLE object.
 FileName	Gets the path and name of the external file to which this OLE object is linked.
 IsLinked	Gets whether the OLE objects are linked to external files or not.

[Top](#)

See Also

[ISwOLEObject Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Aspect Property (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : Aspect Property (ISwOLEObject)

Gets the viewing aspect for this OLE object.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Aspect As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim value As System.Integer  
  
value = instance.Aspect
```

C#

```
System.int Aspect {get;}
```

C++/CLI

```
property System.int Aspect {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Viewing aspect as defined in the DVASPECT enumeration (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::Aspect](#).

Example

See the [ISwOLEObject](#) examples.

Remarks

The ViewingAspect argument uses the DVASPECT enumeration, which has the following values:

- DVASPECT_CONTENT = 1
- DVASPECT_THUMBNAIL = 2
- DVASPECT_ICON = 4
- DVASPECT_DOCPRINT = 8

See the MSDN documentation for additional details about the DVASPECT enumeration.

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Boundaries Property (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : Boundaries Property (ISwOLEObject)

Gets or sets the boundaries for this OLE object.

.NET Syntax

Visual Basic (Declaration)

Property Boundaries As System.Object

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim value As System.Object
```

```
instance.Boundaries = value
```

```
value = instance.Boundaries
```

C#

```
System.Object Boundaries {get; set;}
```

C++/CLI

```
property System.Object^ Boundaries {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of these coordinates:

- Drawings: sheet coordinates
- Parts or assemblies: screen pixel coordinates

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::Boundaries](#).

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)
[ISwOLEObject::IGetBoundaries Method](#)
[ISwOLEObject::ISetBoundaries Method](#)

Availability

Buffer Property (ISwOLEObject)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : Buffer Property (ISwOLEObject)

Gets the data for this OLE object.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Buffer As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim value As System.Object  
  
value = instance.Buffer
```

C#

```
System.object Buffer {get;}
```

C++/CLI

```
property System.Object^ Buffer {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of buffer data

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::Buffer](#).

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)
[ISwOLEObject::GetBuffer Method](#)
[ISwOLEObject::BufferSize Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

BufferSize Property (ISwOLEObject)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : BufferSize Property (ISwOLEObject)

Gets the size of the OLE object data.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property BufferSize As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject
Dim value As System.Integer

value = instance.BufferSize
```

C#

```
System.int BufferSize {get;}
```

C++/CLI

```
property System.int BufferSize {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Size of the OLE object data

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::BufferSize](#).

Example

See the [ISwOLEObject](#) examples.

Remarks

Call this method before calling [ISwOLEObject::IGetBuffer](#) to get the size of the array for that method.

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)
[ISwOLEObject::Buffer Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Clsid Property (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : Clsid Property (ISwOLEObject)

Gets the class ID of this OLE object.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Clsid As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject
Dim value As System.String
```

```
value = instance.Clsid
```

C#

```
System.string Clsid {get;}
```

C++/CLI

```
property System.String^ Clsid {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Either an alpha-numeric string or the class ID of the host application

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::Clsid](#).

Example

See the [ISwOLEObject](#) examples.

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FileName Property (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : FileName Property (ISwOLEObject)

Gets the path and name of the external file to which this OLE object is linked.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FileName As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject
Dim value As System.String
```

```
value = instance.FileName
```

C#

```
System.string FileName {get;}
```

C++/CLI

```
property System.String^ FileName {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and name of external file to which this OLE object is linked

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::FileName](#).

Example

See the [ISwOLEObject](#) examples.

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)
[ISwOLEObject::IsLinked Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBoundaries Method (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : IGetBoundaries Method (ISwOLEObject)

Gets the boundaries for this OLE object.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetBoundaries( _  
    ByRef Boundary As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim Boundary As System.Double  
  
instance.IGetBoundaries(Boundary)
```

C#

```
void IGetBoundaries(  
    out System.double Boundary  
)
```

C++/CLI

```
void IGetBoundaries(  
    & [Out] System.double Boundary  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Boundary

- in-process, unmanaged C++: Pointer to an array of doubles of these coordinates:
 - Drawings: sheet coordinates
 - Parts or assemblies: screen pixel coordinates
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)
[ISwOLEObject::ISetBoundaries Method](#)
[ISwOLEObject::Boundaries Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBuffer Method (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : IGetBuffer Method (ISwOLEObject)

Gets the data for this OLE object.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetBuffer( _  
    ByVal OleBufferSize As System.Integer, _  
    ByRef BOleData As System.Byte _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim OleBufferSize As System.Integer  
Dim BOleData As System.Byte  
  
instance.IGetBuffer(OleBufferSize, BOleData)
```

C#

```
void IGetBuffer(  
    System.int OleBufferSize,  
    out System.byte BOleData  
)
```

C++/CLI

```
void IGetBuffer(  
& System.int OleBufferSize,  
& [Out] System.byte BOleData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OleBufferSize
Size of the OLE buffer
BOleData
Byte array for the buffer data

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::IGetBuffer](#).

Remarks

Before calling this method, call [ISwOLEObject::BufferSize](#) to get the value for OleBufferSize.

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)
[ISwOLEObject::Buffer Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetBoundaries Method (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : ISetBoundaries Method (ISwOLEObject)

Sets the boundaries of this OLE object.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetBoundaries( _  
    ByRef Boundary As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim Boundary As System.Double  
  
instance.ISetBoundaries(Boundary)
```

C#

```
void ISetBoundaries(  
    ref System.double Boundary  
)
```

C++/CLI

```
void ISetBoundaries(  
    & System.double% Boundary  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Boundary

- in-process, unmanaged C++: Pointer to an array of doubles of these coordinates:
 - Drawings: sheet coordinates
 - Parts or assemblies: screen pixel coordinates
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)
[ISwOLEObject::IGetBoundaries Method](#)
[ISwOLEObject::Boundaries Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsLinked Property (ISwOLEObject)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : IsLinked Property (ISwOLEObject)

Gets whether the OLE objects are linked to external files or not.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property IsLinked As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim value As System.Boolean
```

```
value = instance.IsLinked
```

C#

```
System.bool IsLinked {get;}
```

C++/CLI

```
property System.bool IsLinked {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the OLE objects are linked to external files, false if they are embedded

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::IsLinked](#).

Example

See the [ISwOLEObject](#) examples.

Example

[Determine If OLE Objects are Linked or Embedded \(VBA\)](#)

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)
[ISwOLEObject::FileName Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Refresh Method (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : Refresh Method (ISwOLEObject)

Refreshes the data (i.e., reloads the data from the external file in case it was changed by another application).

.NET Syntax

Visual Basic (Declaration)

```
Sub Refresh()
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
  
instance.Refresh()
```

C#

```
void Refresh()
```

C++/CLI

```
void Refresh();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::Refresh](#).

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select Method (ISwOLEObject)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : Select Method (ISwOLEObject)

Selects an OLE object.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Append As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim Append As System.Boolean  
Dim value As System.Boolean  
  
value = instance.Select(Append)
```

C#

```
System.bool Select(  
    System.bool Append  
)
```

C++/CLI

```
System.bool Select(  
& System.bool Append  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True appends the OLE object to the selection list, false replaces the selection list with this OLE object

Return Value

True if the OLE object is selected, false if it is not

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::Select](#).

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetActive Method (ISwOLEObject)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwOLEObject Interface](#) : SetActive Method (ISwOLEObject)

Activates or deactivates the OLE object.

.NET Syntax

Visual Basic (Declaration)

```
Function SetActive( _  
    ByVal Active As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwOLEObject  
Dim Active As System.Boolean  
Dim value As System.Object  
  
value = instance.SetActive(Active)
```

C#

```
System.object SetActive(  
    System.bool Active  
)
```

C++/CLI

```
System.Object^ SetActive(  
& System.bool Active  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Active

True activates the OLE object, false deactivates the OLE object

Return Value

True gets the activated OLE object, false returns null

Visual Basic for Applications (VBA) Syntax

See [SwOLEObject::SetActive](#).

Example

[Activate OLE Object \(VBA\)](#)

See Also

[ISwOLEObject Interface](#)
[ISwOLEObject Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

ISwPEClassFactory (Type)

ISwPEClassFactory Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISwPEClassFactory Interface

Allows access to the callback object used by [ISwPEManager](#) to send a license key back to SOLIDWORKS for SOLIDWORKS Partner entitlement verification.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwPEClassFactory

Visual Basic (Usage)

Dim instance As [ISwPEClassFactory](#)

C#

public interface ISwPEClassFactory

C++/CLI

public interface class ISwPEClassFactory

Visual Basic for Applications (VBA) Syntax

See [SwPEClassFactory](#).

Remarks

This interface provides a callback mechanism in which:

1. SOLIDWORKS requests the partner's key through the add-in by calling [ISwPEManager::IdentifyToSW](#).
2. The partner add-in sends a license key back to SOLIDWORKS in [ISwPEClassFactory::SetPartnerKey](#), and
3. SOLIDWORKS uses the license key to verify the entitlement of the SOLIDWORKS Partner and returns [ISwPEToken](#).

See [SOLIDWORKS Partner Program](#).

Accessors

ISwPEManager::IdentifyToSW

See Also

[ISwPEClassFactory Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISwPEClassFactory Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISwPEClassFactory Interface

For a list of all members of this type, see [ISwPEClassFactory members](#).

Public Methods

Name	Description
SetPartnerKey	Sets the license key which SOLIDWORKS uses to verify SOLIDWORKS Partner entitlement.

[Top](#)

See Also

ISwPEClassFactory Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISwPEClassFactory Interface

The following tables list the members exposed by [ISwPEClassFactory](#).

 Public Methods

Name	Description
 SetPartnerKey	Sets the license key which SOLIDWORKS uses to verify SOLIDWORKS Partner entitlement.

[Top](#)

 See Also

[ISwPEClassFactory Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SetPartnerKey Method (ISwPEClassFactory)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISwPEClassFactory Interface](#) : SetPartnerKey Method (ISwPEClassFactory)

Sets the license key which SOLIDWORKS uses to verify SOLIDWORKS Partner entitlement.

 .NET Syntax

Visual Basic (Declaration)

```
Function SetPartnerKey( _  
    ByVal StrPartnerEntitlement As System.String, _  
    ByRef TokenObject As System.Object _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISwPEClassFactory  
Dim StrPartnerEntitlement As System.String  
Dim TokenObject As System.Object  
Dim value As System.Integer  
  
value = instance.SetPartnerKey(StrPartnerEntitlement, TokenObject)
```

C#

```
System.int SetPartnerKey(  
    System.string StrPartnerEntitlement,  
    out System.object TokenObject  
)
```

C++/CLI

```
System.int SetPartnerKey(  
& System.String^ StrPartnerEntitlement,  
& [Out] System.Object^ TokenObject  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StrPartnerEntitlement
License key string (see [Remarks](#))
TokenObject
[ISwPEToken](#) (for future use only - see [Remarks](#))

Return Value

Return code as defined by [swPartnerEntitlementStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwPEClassFactory::SetPartnerKey](#).

Remarks

When this method is called, SOLIDWORKS compares the registry against these values in the license key specified in StrPartnerEntitlement:

- SOLIDWORKS Partner entitlement
- SOLIDWORKS version
- Add-in name
- Add-in GUID
- Expiration date

See [SOLIDWORKS Partner Program](#).

TokenObject is for future use only.

See Also

[ISwPEClassFactory Interface](#)
[ISwPEClassFactory Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29