

SOLIDWORKS API (.NET VBA C#) — Reference (307/337): ITabAndSlotFeatureData-ITableAnchor

SOLIDWORKS API Documentation (converted from CHM)

ITabAndSlotFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ITabAndSlotFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITabAndSlotFeatureData Interface

Allows access to a tab and slot feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ITabAndSlotFeatureData
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotFeatureData
```

C#

```
public interface ITabAndSlotFeatureData
```

C++/CLI

```
public interface class ITabAndSlotFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotFeatureData](#).

Example

'VBA

' *****

' 1. Open *public_documents\samples\whatsnew\sheet metal\tab_and_slot.sldprt*.

' 2. Run this macro until the Stop.

' 3. Select **Tab and Slot-Tab1** in the FeatureManager design tree;

' 5 tabs/slots created

' 4. Press F5 to continue.

' 5. Select **Tab and Slot-Tab1** in the FeatureManager design tree;

' 1 tab/slot remains

' *****

Dim swApp As SldWorks.SldWorks

Dim featdata As TabAndSlotFeatureData

Dim grp As SldWorks.TabAndSlotGroupData

Dim Part As SldWorks.ModelDoc2

Dim swedge As SldWorks.Edge

Dim swface As SldWorks.Face2

Dim feat As SldWorks.Feature

Dim newFeatData As SldWorks.TabAndSlotFeatureData

Dim boolstatus As Boolean

Option Explicit

Sub main()

Set swApp = Application.SldWorks

Set Part = swApp.ActiveDoc

boolstatus = Part.Extension.SelectByRay(-5.81596588411344E-02, 2.47654446213232E-02, 2.34517259855238E-04, -0.577381545199981, -0.577287712085548, -0.577381545199979, 1.57359077741066E-03, 1, False, 0, 0)

Set swedge = Part.SelectionManager.GetSelectedObject6(1, -1)

Part.ClearSelection2 True

boolstatus = Part.Extension.SelectByRay(-1.33680887414585E-02, -9.08584763345743E-03, -1.99999999999534E-03, -0.821234743714012, -0.560561193384781, 0.106511239726198, 1.57359077741066E-03, 2, False, 0, 0)

Set swface = Part.SelectionManager.GetSelectedObject6(1, -1)

Part.ClearSelection2 True

```
Set featdata = Part.FeatureManager.CreateDefinition(swFmTabAndSlot)

Set grp = featdata.SelectionAddNewGroup
grp.Offset = True
grp.SelectionTabEdge = swedge
grp.SelectionSlotFace = swface
Part.FeatureManager.CreateFeature featdata

Stop
' Select Tab and Slot-Tab1 in the FeatureManager design tree; 5 tabs/slots created on the part
' Press F5 to continue

Set feat = Part.SelectionManager.GetSelectedObject6(1, -1)
Set newFeatData = feat.GetDefinition
Dim var As Variant
newFeatData.AccessSelections Part, Nothing
var = newFeatData.SelectionGetGroups
var(0).Offset = False
var(0).SpacingType = 0
var(0).SpacingNumberOfInstances = 1
feat.ModifyDefinition newFeatData, Part, Nothing

' Select Tab and Slot-Tab1 in the FeatureManager design tree; only one tab and slot remain

End Sub
```

Example

[Create Tab and Slot \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)
[IFeatureManager::CreateDefinition](#)

Access Diagram

[TabAndSlotFeatureData](#)

See Also

[ITabAndSlotFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ITabAndSlotGroupData Interface](#)

ITabAndSlotFeatureData Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITabAndSlotFeatureData Interface

The following tables list the members exposed by [ITabAndSlotFeatureData](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this Tab and Slot feature.
 ReleaseSelectionAccess	Releases access to the selections for this Tab and Slot feature.
 SelectionAddNewGroup	Adds a Tab and Slot group.
 SelectionGetGroups	Gets the Tab and Slot groups defined for this part.

[Top](#)

See Also

[ITabAndSlotFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ITabAndSlotGroupData Interface](#)

ITabAndSlotFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITabAndSlotFeatureData Interface

For a list of all members of this type, see [ITabAndSlotFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this Tab and Slot feature.
 ReleaseSelectionAccess	Releases access to the selections for this Tab and Slot feature.
 SelectionAddNewGroup	Adds a Tab and Slot group.
 SelectionGetGroups	Gets the Tab and Slot groups defined for this part.

[Top](#)

See Also

[ITabAndSlotFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ITabAndSlotGroupData Interface](#)

AccessSelections Method (ITabAndSlotFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotFeatureData Interface](#) : AccessSelections Method (ITabAndSlotFeatureData)

Accesses the selections that define this Tab and Slot feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ITabAndSlotFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotFeatureData::AccessSelections](#).

Example

See the [ITabAndSlotFeatureData](#) example.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ITabAndSlotFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ITabAndSlotFeatureData Interface](#)
[ITabAndSlotFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

[Send comments on this topic.](#)

SOLIDWORKS API Help

ReleaseSelectionAccess Method (ITabAndSlotFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotFeatureData Interface](#) : ReleaseSelectionAccess Method (ITabAndSlotFeatureData)

Releases access to the selections for this Tab and Slot feature.

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)

```
Dim instance As ITabAndSlotFeatureData  
instance.ReleaseSelectionAccess()
```

C#

void ReleaseSelectionAccess()

C++/CLI

void ReleaseSelectionAccess();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotFeatureData::ReleaseSelectionAccess](#).

Remarks

[ITabAndSlotFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ITabAndSlotFeatureData Interface](#)
[ITabAndSlotFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectionAddNewGroup Method (ITabAndSlotFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotFeatureData Interface](#) : SelectionAddNewGroup Method (ITabAndSlotFeatureData)

Adds a Tab and Slot group.

.NET Syntax

Visual Basic (Declaration)

```
Function SelectionAddNewGroup() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotFeatureData  
Dim value As System.Object  
  
value = instance.SelectionAddNewGroup()
```

C#

```
System.object SelectionAddNewGroup()
```

C++/CLI

```
System.Object^ SelectionAddNewGroup();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ITabAndSlotGroupData](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotFeatureData::SelectionAddNewGroup](#).

Example

See the [ITabAndSlotFeatureData](#) example.

See Also

[ITabAndSlotFeatureData Interface](#)
[ITabAndSlotFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SelectionGetGroups Method (ITabAndSlotFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotFeatureData Interface](#) : SelectionGetGroups Method (ITabAndSlotFeatureData)

Gets the Tab and Slot groups defined for this part.

.NET Syntax

Visual Basic (Declaration)

```
Function SelectionGetGroups() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotFeatureData  
Dim value As System.Object  
  
value = instance.SelectionGetGroups()
```

C#

```
System.object SelectionGetGroups()
```

C++/CLI

```
System.Object^ SelectionGetGroups();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [ITabAndSlotGroupData](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotFeatureData::SelectionGetGroups](#).

Example

See the [ITabAndSlotFeatureData](#) example.

See Also

[ITabAndSlotFeatureData Interface](#)
[ITabAndSlotFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

ITabAndSlotGroupData (Type)

ITabAndSlotGroupData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITabAndSlotGroupData Interface

Allows access to a tab and slot feature group.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ITabAndSlotGroupData
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData
```

C#

```
public interface ITabAndSlotGroupData
```

C++/CLI

```
public interface class ITabAndSlotGroupData
```

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData](#).

Example

See the [ITabAndSlotFeatureData](#) example.

Accessors

[ITabAndSlotFeatureData::SelectionAddNewGroup](#)

[ITabAndSlotFeatureData::SelectionGetGroups](#)

Access Diagram

[TabAndSlotGroupData](#)

See Also

[ITabAndSlotGroupData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ITabAndSlotGroupData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITabAndSlotGroupData Interface

The following tables list the members exposed by [ITabAndSlotGroupData](#).

Public Properties

Name	Description
 D1OffsetFromStart	Gets or sets the starting offset of the tabs/slots in this group.
 D2OffsetFromEnd	Gets or sets the ending offset of the tabs/slots in this group.

 Offset	Gets or sets whether to offset the tabs/slots from the edge of the model.
 SelectionEndReferencePoint	Gets or sets the end location of this Tab and Slot group.
 SelectionSlotFace	Gets or sets the slot face of this Tab and Slot group.
 SelectionStartReferencePoint	Gets or sets the start location of this Tab and Slot group.
 SelectionTabEdge	Gets or sets the tab edge of this Tab and Slot group.
 SlotClearance	Gets or sets the offset of the slots relative to the tabs.
 Spacing	Gets or sets the spacing between tabs/slots.
 SpacingNumberOfInstances	Gets or sets the number of instances of equally spaced tabs/slots in this group.
 SpacingType	Gets or sets the type of spacing of tabs/slots in this group.
 TabChamferEdgeTreatmentValue	Gets or sets the chamfer distance for tab edges.
 TabEdgesType	Gets or sets the tab edge treatment.
 TabFace	Gets or sets the tab face that defines the tab thickness.
 TabFilletEdgeTreatmentValue	Gets or sets the fillet radius for tab edges.
 TabHeightType	Gets or sets the type of tab height.
 TabHeightValue	Gets or sets the tab height.
 TabLength	Gets or sets the tab length.
 TabOffsetValue	Gets or sets the tab offset value.
 TabReverseDirection	Gets or sets whether to reverse the tab offset from surface value.
 TabThickness	Gets or sets the tab thickness.

[Top](#)

See Also

[ITabAndSlotGroupData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ITabAndSlotGroupData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITabAndSlotGroupData Interface

For a list of all members of this type, see [ITabAndSlotGroupData members](#).

Public Properties

Name	Description
 D1OffsetFromStart	Gets or sets the starting offset of the tabs/slots in this group.
 D2OffsetFromEnd	Gets or sets the ending offset of the tabs/slots in this group.
 Offset	Gets or sets whether to offset the tabs/slots from the edge of the model.
 SelectionEndReferencePoint	Gets or sets the end location of this Tab and Slot group.
 SelectionSlotFace	Gets or sets the slot face of this Tab and Slot group.
 SelectionStartReferencePoint	Gets or sets the start location of this Tab and Slot group.
 SelectionTabEdge	Gets or sets the tab edge of this Tab and Slot group.
 SlotClearance	Gets or sets the offset of the slots relative to the tabs.
 Spacing	Gets or sets the spacing between tabs/slots.
 SpacingNumberOfInstances	Gets or sets the number of instances of equally spaced tabs/slots in this group.
 SpacingType	Gets or sets the type of spacing of tabs/slots in this group.
 TabChamferEdgeTreatmentValue	Gets or sets the chamfer distance for tab edges.
TabEdgesType	Gets or sets the tab edge treatment.

		
	TabFace	Gets or sets the tab face that defines the tab thickness.
	TabFilletEdgeTreatmentValue	Gets or sets the fillet radius for tab edges.
	TabHeightType	Gets or sets the type of tab height.
	TabHeightValue	Gets or sets the tab height.
	TabLength	Gets or sets the tab length.
	TabOffsetValue	Gets or sets the tab offset value.
	TabReverseDirection	Gets or sets whether to reverse the tab offset from surface value.
	TabThickness	Gets or sets the tab thickness.

[Top](#)

See Also

[ITabAndSlotGroupData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1OffsetFromStart Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : D1OffsetFromStart Property (ITabAndSlotGroupData)

Gets or sets the starting offset of the tabs/slots in this group.

.NET Syntax

Visual Basic (Declaration)

Property D1OffsetFromStart As System.Double

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData
Dim value As System.Double

instance.D1OffsetFromStart = value

value = instance.D1OffsetFromStart
```

C#

```
System.double D1OffsetFromStart {get; set;}
```

C++/CLI

```
property System.double D1OffsetFromStart {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance from the edge where to start the tabs and slots

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::D1OffsetFromStart](#).

Remarks

This method is valid only if [ITabAndSlotGroupData::Offset](#) is set to true.

If you want the tabs/slots to span the entire edge of the model, set both this property and [ITabAndSlotGroupData::D2OffsetFromEnd](#) to zero.

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2OffsetFromEnd Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : D2OffsetFromEnd Property (ITabAndSlotGroupData)

Gets or sets the ending offset of the tabs/slots in this group.

.NET Syntax

Visual Basic (Declaration)

Property D2offsetFromEnd As System.Double

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Double
```

```
instance.D2offsetFromEnd = value
```

```
value = instance.D2offsetFromEnd
```

C#

```
System.double D2offsetFromEnd {get; set;}
```

C++/CLI

```
property System.double D2offsetFromEnd {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance from the edge where to end the tabs and slots

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::D2OffsetFromEnd](#).

Remarks

This method is valid only if [ITabAndSlotGroupData::Offset](#) is set to true.

If you want the tabs/slots to span the entire edge of the model, set both this property and [ITabAndSlotGroupData::D2OffsetFromStart](#) to zero.

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Offset Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : Offset Property (ITabAndSlotGroupData)

Gets or sets whether to offset the tabs/slots from the edge of the model.

.NET Syntax

Visual Basic (Declaration)

Property Offset As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Boolean
```

```
instance.Offset = value
```

```
value = instance.Offset
```

C#

```
System.bool Offset {get; set;}
```

C++/CLI

```
property System.bool Offset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to offset the tabs/slots, false to not

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::Offset](#).

Example

See the [ITabAndSlotFeatureData](#) example.

Remarks

If you set this property to true, also set:

- [ITabAndSlotGroupData::D1OffsetFromStart](#)
- [ITabAndSlotGroupData::D2OffsetFromEnd](#)

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectionEndReferencePoint Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : SelectionEndReferencePoint Property (ITabAndSlotGroupData)

Gets or sets the end location of this Tab and Slot group.

.NET Syntax

Visual Basic (Declaration)

```
Property SelectionEndReferencePoint As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Object  
  
instance.SelectionEndReferencePoint = value  
value = instance.SelectionEndReferencePoint
```

C#

```
System.object SelectionEndReferencePoint {get; set;}
```

C++/CLI

```
property System.Object^ SelectionEndReferencePoint {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IVertex](#) or [ISketchPoint](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::SelectionEndReferencePoint](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)
[ITabAndSlotGroupData::SelectionStartReferencePoint Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectionSlotFace Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : SelectionSlotFace Property (ITabAndSlotGroupData)

Gets or sets the slot face of this Tab and Slot group.

.NET Syntax

Visual Basic (Declaration)

```
Property SelectionSlotFace As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Object  
  
instance.SelectionSlotFace = value  
value = instance.SelectionSlotFace
```

C#

```
System.Object SelectionSlotFace {get; set;}
```

C++/CLI

```
property System.Object^ SelectionSlotFace {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::SelectionSlotFace](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectionStartReferencePoint Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : SelectionStartReferencePoint Property (ITabAndSlotGroupData)

Gets or sets the start location of this Tab and Slot group.

.NET Syntax

Visual Basic (Declaration)

```
Property SelectionStartReferencePoint As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Object  
  
instance.SelectionStartReferencePoint = value  
  
value = instance.SelectionStartReferencePoint
```

C#

```
System.Object SelectionStartReferencePoint {get; set;}
```

C++/CLI

```
property System.Object^ SelectionStartReferencePoint {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IVertex](#) or [ISketchPoint](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::SelectionStartReferencePoint](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)
[ITabAndSlotGroupData::SelectionEndReferencePoint Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectionTabEdge Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : SelectionTabEdge Property (ITabAndSlotGroupData)

Gets or sets the tab edge of this Tab and Slot group.

.NET Syntax

Visual Basic (Declaration)

Property SelectionTabEdge As System.Object

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Object
```

```
instance.SelectionTabEdge = value
```

```
value = instance.SelectionTabEdge
```

C#

```
System.object SelectionTabEdge {get; set;}
```

C++/CLI

```
property System.Object^ SelectionTabEdge {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IEdge](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::SelectionTabEdge](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)
[ITabAndSlotGroupData::TabFace Property \(\)](#)
[ITabAndSlotGroupData::TabThickness Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SlotClearance Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : SlotClearance Property (ITabAndSlotGroupData)

Gets or sets the offset of the slots relative to the tabs.

.NET Syntax

Visual Basic (Declaration)

```
Property SlotClearance As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData
Dim value As System.Double
```

```
instance.SlotClearance = value
```

```
value = instance.SlotClearance
```

C#

```
System.double SlotClearance {get; set;}
```

C++/CLI

```
property System.double SlotClearance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Slot clearance

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::SlotClearance](#).

Remarks

This property allows you to make the slots larger than the tabs.

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Spacing Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : Spacing Property (ITabAndSlotGroupData)

Gets or sets the spacing between tabs/slots.

.NET Syntax

Visual Basic (Declaration)

```
Property Spacing As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Double
```

```
instance.Spacing = value
```

```
value = instance.Spacing
```

C#

```
System.double Spacing {get; set;}
```

C++/CLI

```
property System.double Spacing {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Spacing between tabs

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData.Spacing](#).

Remarks

This property is valid only if [ITabAndSlotGroupData.SpacingType](#) is set to [swTabSlotFeatureSpacingType_e.SpacingLength](#).

The value of this property drives the number of instances.

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SpacingNumberOfInstances Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : SpacingNumberOfInstances Property (ITabAndSlotGroupData)

Gets or sets the number of instances of equally spaced tabs/slots in this group.

.NET Syntax

Visual Basic (Declaration)

```
Property SpacingNumberOfInstances As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Integer
```

```
instance.SpacingNumberOfInstances = value
```

```
value = instance.SpacingNumberOfInstances
```

C#

```
System.int SpacingNumberOfInstances {get; set;}
```

C++/CLI

```
property System.int SpacingNumberOfInstances {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of instances

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::SpacingNumberOfInstances](#).

Example

See the [ITabAndSlotFeatureData](#) example.

Remarks

This property is valid only if [ITabAndSlotGroupData::SpacingType](#) is set to [swTabSlotFeatureSpacingType_e.EqualSpacing](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SpacingType Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : SpacingType Property (ITabAndSlotGroupData)

Gets or sets the type of spacing of tabs/slots in this group.

.NET Syntax

Visual Basic (Declaration)

```
Property SpacingType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Integer
```

```
instance.SpacingType = value
```

```
value = instance.SpacingType
```

C#

```
System.int SpacingType {get; set;}
```

C++/CLI

```
property System.int SpacingType {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Spacing type as defined in [swTabSlotFeatureSpacingType_e](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::SpacingType](#).

Example

See the [ITabAndSlotFeatureData](#) example.

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TabChamferEdgeTreatmentValue Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabChamferEdgeTreatmentValue Property (ITabAndSlotGroupData)

Gets or sets the chamfer distance for tab edges.

.NET Syntax

Visual Basic (Declaration)

```
Property TabChamferEdgeTreatmentValue As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Double  
  
instance.TabChamferEdgeTreatmentValue = value  
  
value = instance.TabChamferEdgeTreatmentValue
```

C#

```
System.double TabChamferEdgeTreatmentValue {get; set;}
```

C++/CLI

```
property System.double TabChamferEdgeTreatmentValue {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Chamfer distance

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::TabChamferEdgeTreatmentValue](#).

Remarks

This property is valid only if [ITabAndSlotGroupData::TabEdgesType](#) is set to [swTabEdgesType_e](#).ChamferEdge.

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabEdgesType Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabEdgesType Property (ITabAndSlotGroupData)

Gets or sets the tab edge treatment.

.NET Syntax

Visual Basic (Declaration)

Property TabEdgesType As System.Integer

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Integer
```

```
instance.TabEdgesType = value
```

```
value = instance.TabEdgesType
```

C#

```
System.int TabEdgesType {get; set;}
```

C++/CLI

```
property System.int TabEdgesType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tab edge treatment as defined in [swTabEdgesType_e](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::TabEdgesType](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabFace Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabFace Property (ITabAndSlotGroupData)

Gets or sets the tab face that defines the tab thickness.

.NET Syntax

Visual Basic (Declaration)

```
Property TabFace As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Object
```

```
instance.TabFace = value
```

```
value = instance.TabFace
```

C#

```
System.object TabFace {get; set;}
```

C++/CLI

```
property System.Object^ TabFace {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::TabFace](#).

Remarks

The value of this property is a planar face that is shared with [ITabAndSlotGroupData::SelectionTabEdge](#) of thickness, [ITabAndSlotGroupData::TabThickness](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabFilletEdgeTreatmentValue Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabFilletEdgeTreatmentValue Property (ITabAndSlotGroupData)

Gets or sets the fillet radius for tab edges.

.NET Syntax

Visual Basic (Declaration)

```
Property TabFilletEdgeTreatmentValue As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData
Dim value As System.Double

instance.TabFilletEdgeTreatmentValue = value

value = instance.TabFilletEdgeTreatmentValue
```

C#

```
System.double TabFilletEdgeTreatmentValue {get; set;}
```

C++/CLI

```
property System.double TabFilletEdgeTreatmentValue {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fillet radius

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData.TabFilletEdgeTreatmentValue](#).

Remarks

This property is valid only if [ITabAndSlotGroupData.TabEdgesType](#) is set to [swTabEdgesType_e.FilletEdge](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabHeightType Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabHeightType Property (ITabAndSlotGroupData)

Gets or sets the type of tab height.

.NET Syntax

Visual Basic (Declaration)

```
Property TabHeightType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData
Dim value As System.Integer
```

```
instance.TabHeightType = value
```

```
value = instance.TabHeightType
```

C#

```
System.int TabHeightType {get; set;}
```

C++/CLI

```
property System.int TabHeightType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tab height type as defined in [swTabSlotFeatureHeightType_e](#)

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData.TabHeightType](#).

Remarks

If you set this property to `swTabSlotFeatureHeightType_e`:

- Blind, then use [ITabAndSlotGroupData.TabHeightValue](#) to set the tab height.
- OffsetFromSurface, then use [ITabAndSlotGroupData.TabOffsetValue](#) to set the tab offset value as measured from the slot face. Also set [ITabAndSlotGroupData.TabReverseDirection](#).
- UpToSurface, then the tab height is automatically set to the distance up to the slot face.

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabHeightValue Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabHeightValue Property (ITabAndSlotGroupData)

Gets or sets the tab height.

.NET Syntax

Visual Basic (Declaration)

```
Property TabHeightValue As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData
Dim value As System.Double
```

```
instance.TabHeightValue = value
```

```
value = instance.TabHeightValue
```

C#

```
System.double TabHeightValue {get; set;}
```

C++/CLI

```
property System.double TabHeightValue {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tab height

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::TabHeightValue](#).

Remarks

This property is valid only if [ITabAndSlotGroupData::TabHeightType](#) is set to [swTabSlotFeatureHeightType_e.Blind](#).
See the Remarks for [ITabAndSlotGroupData::TabHeightType](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabLength Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabLength Property (ITabAndSlotGroupData)

Gets or sets the tab length.

.NET Syntax

Visual Basic (Declaration)

Property TabLength As System.Double

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Double
```

```
instance.TabLength = value
```

```
value = instance.TabLength
```

C#

```
System.double TabLength {get; set;}
```

C++/CLI

```
property System.double TabLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tab length

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData::TabLength](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabOffsetValue Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabOffsetValue Property (ITabAndSlotGroupData)

Gets or sets the tab offset value.

.NET Syntax

Visual Basic (Declaration)

```
Property TabOffsetValue As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Double
```

```
instance.TabOffsetValue = value
```

```
value = instance.TabOffsetValue
```

C#

```
System.double TabOffsetValue {get; set;}
```

C++/CLI

```
property System.double TabOffsetValue {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tab offset value

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData.TabOffsetValue](#).

Remarks

This property is:

- measured from [ITabAndSlotGroupData.SelectionSlotFace](#)
- and-
- valid only if [ITabAndSlotGroupData.TabHeightType](#) is set to [swTabSlotFeatureHeightType_e.OffsetFromSurface](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabReverseDirection Property (ITabAndSlotGroupData)

[See Also](#)



Gets or sets whether to reverse the tab offset from surface value.

.NET Syntax

Visual Basic (Declaration)

Property TabReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Boolean
```

```
instance.TabReverseDirection = value
```

```
value = instance.TabReverseDirection
```

C#

```
System.bool TabReverseDirection {get; set;}
```

C++/CLI

```
property System.bool TabReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the tab offset from surface value, false to not

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData.TabReverseDirection](#).

Remarks

This property is valid only if valid only if [ITabAndSlotGroupData.TabHeightType](#) is set to [swTabSlotFeatureHeightType_e.OffsetFromSurface](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabThickness Property (ITabAndSlotGroupData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITabAndSlotGroupData Interface](#) : TabThickness Property (ITabAndSlotGroupData)

Gets or sets the tab thickness.

.NET Syntax

Visual Basic (Declaration)

Property TabThickness As System.Double

Visual Basic (Usage)



```
Dim instance As ITabAndSlotGroupData  
Dim value As System.Double
```

```
instance.TabThickness = value
```

```
value = instance.TabThickness
```

C#

```
System.double TabThickness {get; set;}
```

C++/CLI

```
property System.double TabThickness {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tab thickness

Visual Basic for Applications (VBA) Syntax

See [TabAndSlotGroupData.TabThickness](#).

Remarks

This property defines the thickness of [ITabAndSlotGroupData.TabFace](#), which is a planar face shared with [ITabAndSlotGroupData.SelectionTabEdge](#).

See Also

[ITabAndSlotGroupData Interface](#)
[ITabAndSlotGroupData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

ITableAnchor (Type)

ITableAnchor Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITableAnchor Interface

Allows access to the data that defines a table anchor feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ITableAnchor
```

Visual Basic (Usage)

```
Dim instance As ITableAnchor
```

C#

```
public interface ITableAnchor
```

C++/CLI

```
public interface class ITableAnchor
```

Visual Basic for Applications (VBA) Syntax

See [TableAnchor](#).

Example

- [Get Table Anchor \(VBA\)](#)
- [Get and Set Table Anchor of Hole Table \(VBA\)](#)
- [Get and Set Table Anchor of Hole Table \(VB.NET\)](#)
- [Get and Set Table Anchor of Hole Table \(C#\)](#)

Remarks

If a table anchor is selected, then it can be retrieved with [ISelectionMgr::GetSelectedObject6](#). If the selected object type is swSelBOMTEMPS, then getting the selected object is a [IFeature](#) object. Use [IFeature::GetSpecifiedFeature2](#) to return a TableAnchor object.

If you traverse the features and subfeatures of a drawing, then the table anchors display as subfeatures of the sheet format. When [IFeature::GetTypeNames](#) returns GeneralTableAnchor, HoleTableAnchor, WeldmentCutListAnchor, RevisionTableAnchor, or BomTemplate, use [IFeature::GetSpecifiedFeature2](#) to return a ITableAnchor object.

NOTE: Weld table anchors are not currently supported.

You can also retrieve a ITableAnchor object from the [ISheet](#) object using [ISheet::TableAnchor](#). There is only one anchor of each type on a sheet format.

Accessors

- [IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)
- [ISheet::SetAsTableAnchor](#)
- [ISheet::TableAnchor](#)

Access Diagram

[TableAnchor](#)

See Also

ITableAnchor Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITableAnchor Interface

For a list of all members of this type, see [ITableAnchor members](#).

Public Methods

Name	Description
 GetFeature	Gets the feature for this table anchor.

[Top](#)

See Also

[ITableAnchor Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ITableAnchor Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITableAnchor Interface

The following tables list the members exposed by [ITableAnchor](#).

Public Properties

Name	Description
 Position	Gets or sets the location of the table anchor.
 Type	Gets the type of table anchor.

[Top](#)

Public Methods

Name	Description
 GetFeature	Gets the feature for this table anchor.

[Top](#)

See Also

[ITableAnchor Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ITableAnchor Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITableAnchor Interface

For a list of all members of this type, see [ITableAnchor members](#).

Public Properties

Name	Description
 Position	Gets or sets the location of the table anchor.
 Type	Gets the type of table anchor.

[Top](#)

See Also

GetFeature Method (ITableAnchor)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnchor Interface](#) : GetFeature Method (ITableAnchor)

Gets the feature for this table anchor.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As ITableAnchor  
Dim value As Feature
```

```
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#) object for this table anchor

Visual Basic for Applications (VBA) Syntax

See [TableAnchor::GetFeature](#).

See Also

[ITableAnchor Interface](#)
[ITableAnchor Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

Position Property (ITableAnchor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnchor Interface](#) : Position Property (ITableAnchor)

Gets or sets the location of the table anchor.

.NET Syntax

Visual Basic (Declaration)

```
Property Position As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITableAnchor  
Dim value As System.Object
```

```
instance.Position = value  
value = instance.Position
```

C#

```
System.Object Position {get; set;}
```

C++/CLI

```
property System.Object^ Position {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of doubles of x and y coordinates of the table anchor

Visual Basic for Applications (VBA) Syntax

See [TableAnchor::Position](#).

Example

[Get and Set Table Anchor of Hole Table \(C#\)](#)
[Get and Set Table Anchor of Hole Table \(VB.NET\)](#)
[Get and Set Table Anchor of Hole Table \(VBA\)](#)

See Also

[ITableAnchor Interface](#)
[ITableAnchor Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (ITableAnchor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnchor Interface](#) : Type Property (ITableAnchor)

Gets the type of table anchor.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnchor  
Dim value As System.Integer  
  
value = instance.Type
```

C#

```
System.int Type {get;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of table anchor as defined in [swTableAnnotationType_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnchor::Type](#).

Example

[Get Table Anchor \(VBA\)](#)
[Get Table Anchor \(VB.NET\)](#)
[Get Table Anchor \(C#\)](#)

See Also

[ITableAnchor Interface](#)
[ITableAnchor Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0