

SOLIDWORKS API (.NET VBA C#) — Reference (308/337): ITableAnnotation (part 1 of 2)

SOLIDWORKS API Documentation (converted from CHM)

ITableAnnotation (part 1 of 2) (Type)

ITableAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITableAnnotation Interface

Provides access to table annotations.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ITableAnnotation
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
```

C#

```
public interface ITableAnnotation
```

C++/CLI

```
public interface class ITableAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation](#).

Example

[Hide or Show First Column in Hole Table \(VB.NET\)](#)
[Hide or Show First Column in Hole Table \(VBA\)](#)
[Hide or Show First Column in Hole Table \(C#\)](#)
[Select Table Cells \(C#\)](#)
[Select Table Cells \(VB.NET\)](#)
[Select Table Cells \(VBA\)](#)
[Get General Table Feature \(C#\)](#)
[Get General Table Feature \(VB.NET\)](#)
[Get General Table Feature \(VBA\)](#)
[Get Components in Each BOM Table Row \(C#\)](#)
[Get Components in Each BOM Table Row \(VB.NET\)](#)
[Get Components in Each BOM Table Row \(VBA\)](#)

Remarks

See [swTableAnnotationType](#) e for the types of tables derived from ITableAnnotation.

Accessors

[IDrawingDoc::InsertTableAnnotation2](#)
[IGeneralTableFeature::GetTableAnnotations](#) and [IGeneralTableFeature::!GetTableAnnotations](#)
[IModelDocExtension::GetGeneralTableAnnotation](#)
[IModelDocExtension::InsertGeneralTableAnnotation](#)
[IModelDocExtension::InsertTitleBlockTable](#)
[ITableAnnotation::GetNext](#)
[ITableAnnotation::HorizontalAutoSplit](#)
[ITableAnnotation::Split](#)
[IView::GetFirstTableAnnotation](#)
[IView::GetTableAnnotations](#) and [IView::!GetTableAnnotations](#)

Access Diagram

[TableAnnotation](#)

See Also

[ITableAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ITableAnnotation Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ITableAnnotation Interface

For a list of all members of this type, see [ITableAnnotation members](#).

Public Methods

Name	Description
 DeleteColumn	Obsolete. Superseded by ITableAnnotation.DeleteColumn2 .
 DeleteColumn2	Deletes the specified column in this table.
 DeleteRow	Obsolete. Superseded by ITableAnnotation.DeleteRow2 .
 DeleteRow2	Deletes the specified row from this table.
 EvaluateCellEquation	Solves the specified equation in the specified cell of this BOM table.
 GetAnnotation	Gets the annotation for this table annotation.
 GetCellEquation	Gets the equation and its solved value for the specified row and column of this BOM table.
 GetCellRange	Gets the selected table cells' row and column index ranges.
 GetCellTextFormat	Gets the text format for the specified cell in this table.
 GetCellTextOrientation	Gets the text orientation in the specified cell of this table.
 GetCellUseDocTextFormat	Gets whether this cell uses the document setting for its text format.
 GetColumnName	Obsolete. Superseded by ITableAnnotation.GetColumnName2 .
 GetColumnName2	Gets the title of the specified column.
 GetColumnType	Obsolete. Superseded by ITableAnnotation.GetColumnType2 .
 GetColumnType2	Obsolete. Superseded by ITableAnnotation.GetColumnType3 .
 GetColumnType3	Gets the type and property data for the specified BOM table column.
 GetColumnWidth	Gets the width of the specified column of this table annotation.
 GetHeaderCount	Gets the number of rows or columns in the header of this table.
 GetHeaderStyle	Gets the header style of this table.
 GetLockColumnWidth	Gets whether the width of the specified column is locked in this table annotation.
 GetLockRowHeight	Gets whether the height of the specified row is locked in this table annotation.
 GetNext	Gets the next table annotation in this drawing view.
 GetRowHeight	Gets the height of the specified row of this table.
 GetRowVerticalGap	Gets the gap between the text and the top or bottom of the specified row of this table.
 GetSplitInformation	Gets information about any splits in this table.
 GetTextFormat	Gets the text format for this table.
 GetUseDocTextFormat	Gets whether this table uses the document setting for text formatting.
 HorizontalAutoSplit	Starts the automatic horizontal splitting of this table using the specified options.
 InsertColumn	Obsolete. Superseded by ITableAnnotation.InsertColumn2 .
 InsertColumn2	Inserts a column into this table.

 InsertRow	Inserts a row into this table.
 IsCellMerged	Gets whether the specified cell is merged with other cells.
 IsCellTextEditable	Gets whether the text in this cell can be edited.
 Merge	Merges the display of this table.
 MergeCells	Merges the cells in the specified range.
 MoveColumn	Moves a column in this table annotation.
 MoveRow	Moves a row in this table either up one row or down one row.
 SaveAsPDF	Saves this table to a PDF file.
 SaveAsTemplate	Saves the format of this table as a template file, which you can then use to create other tables of the same type and that look the same.
 SaveAsText	Obsolete. Superseded by ITableAnnotation::SaveAsText2 .
 SaveAsText2	Saves this table to a text data file.
 SetCellEquation	Sets the specified equation for the specified row and column of this BOM table.
 SetCellRange	Sets the current range of cells.
 SetCellTextFormat	Sets the text format for the text in the specified cell.
 SetCellTextOrientation	Sets the text orientation in the specified table cell.
 SetColumnTitle	Obsolete. Superseded by ITableAnnotation::SetColumnTitle2 .
 SetColumnTitle2	Sets the title of the specified column.
 SetColumnType	Obsolete. Superseded by ITableAnnotation::SetColumnType2 .
 SetColumnType2	Obsolete. Superseded by ITableAnnotation::SetColumnType3 .
 SetColumnType3	Sets the type and property data for the specified BOM table column.
 SetColumnWidth	Sets the width of the specified column in this table.
 SetHeader	Sets the header for this table.
 SetLockColumnWidth	Sets whether to lock the width of the specified column in this table annotation.
 SetLockRowHeight	Sets whether to lock the height of the specified row in this table annotation.
 SetRowHeight	Sets the height of the specified row in this table.
 SetRowVerticalGap	Sets the gap between the text and the top or bottom of the specified row of this table.
 SetTextFormat	Sets the text format for this table.
 Split	Splits the table at the specified location.
 UnmergeCells	Splits the specified previously merged cell in this table.

[Top](#)

See Also

[ITableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ITableAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ITableAnnotation Interface

The following tables list the members exposed by [ITableAnnotation](#).

Public Properties

Name	Description
 Anchored	Gets or sets whether this table is attached to its anchor.
 AnchorType	Gets or sets the anchor point for this table annotation.
BorderLineWeight	Gets or sets the line weight of the border lines to the specified SOLIDWORKS-supplied weight for this table.

		
	BorderLineWeightCustom	Gets or sets the line weight of the border lines to the specified custom weight for this table.
	CellTextHorizontalJustification	Gets or sets the horizontal justification for the text in the specified cell.
	CellTextVerticalJustification	Gets or sets the vertical justification for the text in the specified cell.
	ColumnCount	Gets the number of columns in this table.
	ColumnHidden	Hides or shows the specified column in this table annotation.
	DisplayedText	Obsolete. Superseded by ITableAnnotation::DisplayedText2 .
	DisplayedText2	Gets the actual text displayed in the specified cell in this table.
	GeneralTableFeature	Gets the general table feature for this general table annotation.
	GridLineWeight	Gets or sets the line weight of the inner lines to the SOLIDWORKS-supplied weight for this table.
	GridLineWeightCustom	Gets or sets the line weight of the inner lines to the specified custom weight for this table.
	RowCount	Gets the number of rows in this table.
	RowHidden	Gets or sets whether the specified row is hidden in this table.
	StopAutoSplitting	Stops the automatic horizontal splitting of this table.
	Text	Obsolete. Superseded by ITableAnnotation::Text2 .
	Text2	Gets or sets the parametrized string of text for the specified cell of this table.
	TextHorizontalJustification	Gets or sets the horizontal justification setting for the text in this table.
	TextVerticalJustification	Gets or sets the vertical justification for the text in this table.
	Title	Gets or sets the title for this table.
	TitleVisible	Gets or sets whether the title of the table is visible.
	TotalColumnCount	Gets the total number of visible and hidden columns in this table.
	TotalRowCount	Gets the total number of visible and hidden rows in this table.
	Type	Gets the type of table.
	UpperCase	Gets or sets whether text in the table is all upper case.

[Top](#)

Public Methods

Name	Description
 DeleteColumn	Obsolete. Superseded by ITableAnnotation::DeleteColumn2 .
 DeleteColumn2	Deletes the specified column in this table.
 DeleteRow	Obsolete. Superseded by ITableAnnotation::DeleteRow2 .
 DeleteRow2	Deletes the specified row from this table.
 EvaluateCellEquation	Solves the specified equation in the specified cell of this BOM table.
 GetAnnotation	Gets the annotation for this table annotation.
 GetCellEquation	Gets the equation and its solved value for the specified row and column of this BOM table.
 GetCellRange	Gets the selected table cells' row and column index ranges.
 GetCellTextFormat	Gets the text format for the specified cell in this table.
 GetCellTextOrientation	Gets the text orientation in the specified cell of this table.
 GetCellUseDocTextFormat	Gets whether this cell uses the document setting for its text format.
 GetColumnTitle	Obsolete. Superseded by ITableAnnotation::GetColumnTitle2 .
 GetColumnTitle2	Gets the title of the specified column.
 GetColumnType	Obsolete. Superseded by ITableAnnotation::GetColumnType2 .
 GetColumnType2	Obsolete. Superseded by ITableAnnotation::GetColumnType3 .

	GetColumnType3	Gets the type and property data for the specified BOM table column.
	GetColumnWidth	Gets the width of the specified column of this table annotation.
	GetHeaderCount	Gets the number of rows or columns in the header of this table.
	GetHeaderStyle	Gets the header style of this table.
	GetLockColumnWidth	Gets whether the width of the specified column is locked in this table annotation.
	GetLockRowHeight	Gets whether the height of the specified row is locked in this table annotation.
	GetNext	Gets the next table annotation in this drawing view.
	GetRowHeight	Gets the height of the specified row of this table.
	GetRowVerticalGap	Gets the gap between the text and the top or bottom of the specified row of this table.
	GetSplitInformation	Gets information about any splits in this table.
	GetTextFormat	Gets the text format for this table.
	GetUseDocTextFormat	Gets whether this table uses the document setting for text formatting.
	HorizontalAutoSplit	Starts the automatic horizontal splitting of this table using the specified options.
	InsertColumn	Obsolete. Superseded by ITableAnnotation.InsertColumn2 .
	InsertColumn2	Inserts a column into this table.
	InsertRow	Inserts a row into this table.
	IsCellMerged	Gets whether the specified cell is merged with other cells.
	IsCellTextEditable	Gets whether the text in this cell can be edited.
	Merge	Merges the display of this table.
	MergeCells	Merges the cells in the specified range.
	MoveColumn	Moves a column in this table annotation.
	MoveRow	Moves a row in this table either up one row or down one row.
	SaveAsPDF	Saves this table to a PDF file.
	SaveAsTemplate	Saves the format of this table as a template file, which you can then use to create other tables of the same type and that look the same.
	SaveAsText	Obsolete. Superseded by ITableAnnotation.SaveAsText2 .
	SaveAsText2	Saves this table to a text data file.
	SetCellEquation	Sets the specified equation for the specified row and column of this BOM table.
	SetCellRange	Sets the current range of cells.
	SetCellTextFormat	Sets the text format for the text in the specified cell.
	SetCellTextOrientation	Sets the text orientation in the specified table cell.
	SetColumnTitle	Obsolete. Superseded by ITableAnnotation.SetColumnTitle2 .
	SetColumnTitle2	Sets the title of the specified column.
	SetColumnType	Obsolete. Superseded by ITableAnnotation.SetColumnType2 .
	SetColumnType2	Obsolete. Superseded by ITableAnnotation.SetColumnType3 .
	SetColumnType3	Sets the type and property data for the specified BOM table column.
	SetColumnWidth	Sets the width of the specified column in this table.
	SetHeader	Sets the header for this table.
	SetLockColumnWidth	Sets whether to lock the width of the specified column in this table annotation.
	SetLockRowHeight	Sets whether to lock the height of the specified row in this table annotation.
	SetRowHeight	Sets the height of the specified row in this table.
	SetRowVerticalGap	Sets the gap between the text and the top or bottom of the specified row of this table.
	SetTextFormat	Sets the text format for this table.
	Split	Splits the table at the specified location.



[UnmergeCells](#)

Splits the specified previously merged cell in this table.

[Top](#)

See Also

[ITableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ITableAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITableAnnotation Interface

For a list of all members of this type, see [ITableAnnotation members](#).

Public Properties

Name	Description
 Anchored	Gets or sets whether this table is attached to its anchor.
 AnchorType	Gets or sets the anchor point for this table annotation.
 BorderLineWeight	Gets or sets the line weight of the border lines to the specified SOLIDWORKS-supplied weight for this table.
 BorderLineWeightCustom	Gets or sets the line weight of the border lines to the specified custom weight for this table.
 CellTextHorizontalJustification	Gets or sets the horizontal justification for the text in the specified cell.
 CellTextVerticalJustification	Gets or sets the vertical justification for the text in the specified cell.
 ColumnCount	Gets the number of columns in this table.
 ColumnHidden	Hides or shows the specified column in this table annotation.
 DisplayedText	Obsolete. Superseded by ITableAnnotation::DisplayedText2.
 DisplayedText2	Gets the actual text displayed in the specified cell in this table.
 GeneralTableFeature	Gets the general table feature for this general table annotation.
 GridLineWeight	Gets or sets the line weight of the inner lines to the SOLIDWORKS-supplied weight for this table.
 GridLineWeightCustom	Gets or sets the line weight of the inner lines to the specified custom weight for this table.
 RowCount	Gets the number of rows in this table.
 RowHidden	Gets or sets whether the specified row is hidden in this table.
 StopAutoSplitting	Stops the automatic horizontal splitting of this table.
 Text	Obsolete. Superseded by ITableAnnotation::Text2.
 Text2	Gets or sets the parametrized string of text for the specified cell of this table.
 TextHorizontalJustification	Gets or sets the horizontal justification setting for the text in this table.
 TextVerticalJustification	Gets or sets the vertical justification for the text in this table.
 Title	Gets or sets the title for this table.
 TitleVisible	Gets or sets whether the title of the table is visible.
 TotalColumnCount	Gets the total number of visible and hidden columns in this table.
 TotalRowCount	Gets the total number of visible and hidden rows in this table.
 Type	Gets the type of table.
 UpperCase	Gets or sets whether text in the table is all upper case.

[Top](#)

See Also

[ITableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

Anchored Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : Anchored Property (ITableAnnotation)

Gets or sets whether this table is attached to its anchor.

.NET Syntax

Visual Basic (Declaration)

Property Anchored As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Boolean
```

```
instance.Anchored = value
```

```
value = instance.Anchored
```

C#

```
System.bool Anchored {get; set;}
```

C++/CLI

```
property System.bool Anchored {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the table is attached to the anchor, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::Anchored](#).

Example

[Get and Set Table Anchor of Hole Table \(C#\)](#)

[Get and Set Table Anchor of Hole Table \(VB.NET\)](#)

[Get and Set Table Anchor of Hole Table \(VBA\)](#)

Remarks

If setting this property to TRUE, then the table origin is snapped to the anchor point, according to the anchor type of this table. Use:

- [ITableAnnotation::AnchorType](#) to determine where the origin is on the table.
- [IAnnotation::GetPosition](#) to determine the position of the table.

If the drawing sheet format does not contain an anchor point for this type of table, then attempting to attach the table to the anchor point has no effect.

See Also

[ITableAnnotation Interface](#)

[ITableAnnotation Members](#)

[IAnnotation::SetPosition Method](#)

[ITableAnnotation::AnchorType Property](#)

Availability

SOLIDWORKS 2004 SP2, Revision Number 12.2

AnchorType Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : AnchorType Property (ITableAnnotation)

Gets or sets the anchor point for this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property AnchorType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer
```

```
instance.AnchorType = value
```

```
value = instance.AnchorType
```

C#

```
System.int AnchorType {get; set;}
```

C++/CLI

```
property System.int AnchorType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of anchor as defined by [swBOMConfigurationAnchorType_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::AnchorType](#).

Example

[Get and Set Table Anchor of Hole Table \(C#\)](#)
[Get and Set Table Anchor of Hole Table \(VB.NET\)](#)
[Get and Set Table Anchor of Hole Table \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::Anchored Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BorderLineWeight Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : BorderLineWeight Property (ITableAnnotation)

Gets or sets the line weight of the border lines to the specified SOLIDWORKS-supplied weight for this table.

.NET Syntax

Visual Basic (Declaration)

Property BorderLineWeight As System.Integer

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim value As System.Integer

instance.BorderLineWeight = value
value = instance.BorderLineWeight
```

C#

```
System.int BorderLineWeight {get; set;}
```

C++/CLI

```
property System.int BorderLineWeight {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weight of border lines for this table as defined by [swLineWeights_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::BorderLineWeight](#).

Example

[Get General Table Feature \(C#\)](#)
[Get General Table Feature \(VB.NET\)](#)
[Get General Table Feature \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::ITableAnnotation::GridLineWeight Property](#)
[ITableAnnotation::BorderLineWeightCustom Property](#)
[ITableAnnotation::GridLineWeightCustom Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BorderLineWeightCustom Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : BorderLineWeightCustom Property (ITableAnnotation)

Gets or sets the line weight of the border lines to the specified custom weight for this table.

.NET Syntax

Visual Basic (Declaration)

```
Property BorderLineWeightCustom As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim value As System.Double

instance.BorderLineWeightCustom = value
```

```
value = instance.BorderLineWeightCustom
```

C#

```
System.double BorderLineWeightCustom {get; set;}
```

C++/CLI

```
property System.double BorderLineWeightCustom {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Custom weight, in millimeters, of border lines for this table

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::BorderLineWeightCustom](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CellTextHorizontalJustification Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : CellTextHorizontalJustification Property (ITableAnnotation)

Gets or sets the horizontal justification for the text in the specified cell.

.NET Syntax

Visual Basic (Declaration)

```
Property CellTextHorizontalJustification( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim value As System.Integer
```

```
instance.CellTextHorizontalJustification(Row, Column) = value
```

```
value = instance.CellTextHorizontalJustification(Row, Column)
```

C#

```
System.int CellTextHorizontalJustification(  
    System.int Row,  
    System.int Column  
) {get; set;}
```

C++/CLI

```
property System.int CellTextHorizontalJustification {  
    System.int get(System.int Row, System.int Column);  
    void set (System.int Row, System.int Column, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Index of the row in which the cell resides

Column

Index of the column in which the cell resides

Property Value

Justification as defined by [swTextJustification_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::CellTextHorizontalJustification](#).

Remarks

The index for both the rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellRange Method](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::IsCellTextEditable Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::SetCellRange Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)
[ITableAnnotation::TextHorizontalJustification Property](#)
[ITableAnnotation::TextVerticalJustification Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CellTextVerticalJustification Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : CellTextVerticalJustification Property (ITableAnnotation)

Gets or sets the vertical justification for the text in the specified cell.

.NET Syntax

Visual Basic (Declaration)

```
Property CellTextVerticalJustification( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```

Dim instance As ITableAnnotation
Dim Row As System.Integer
Dim Column As System.Integer
Dim value As System.Integer

instance.CellTextVerticalJustification(Row, Column) = value

value = instance.CellTextVerticalJustification(Row, Column)

```

C#

```

System.int CellTextVerticalJustification(
    System.int Row,
    System.int Column
) {get; set;}

```

C++/CLI

```

property System.int CellTextVerticalJustification {
    System.int get(System.int Row, System.int Column);
    void set (System.int Row, System.int Column, System.int value);
}

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
Index of the row in which this cell resides

Column
Index of the column in which this cell resides

Property Value

Justification as defined by [swTextAlignmentVertical_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::CellTextVerticalJustification](#).

Remarks

The index for both the rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellRange Method](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::IsCellTextEditable Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::SetCellRange Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::TextHorizontalJustification Property](#)
[ITableAnnotation::TextVerticalJustification Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ColumnCount Property (ITableAnnotation)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : ColumnCount Property (ITableAnnotation)

Gets the number of columns in this table.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ColumnCount As System.Integer

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer
```

```
value = instance.ColumnCount
```

C#

```
System.int ColumnCount {get;}
```

C++/CLI

```
property System.int ColumnCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of columns in this table

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::ColumnCount](#).

Example

[Get Custom Properties for Bom Table Columns \(VBA\)](#)
[Get Revision Table \(VBA\)](#)
[Get Table Annotation and Contents \(VBA\)](#)
[Insert Hole Table \(VBA\)](#)
[Insert Table \(VBA\)](#)
[Insert Column in BOM Table \(C#\)](#)
[Insert Column in BOM Table \(VB.NET\)](#)
[Insert Column in BOM Table \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnTitle Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnTitle Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::SetColumnWidth Method](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ColumnHidden Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : ColumnHidden Property (ITableAnnotation)

Hides or shows the specified column in this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property ColumnHidden( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
instance.ColumnHidden(Index) = value  
  
value = instance.ColumnHidden(Index)
```

C#

```
System.bool ColumnHidden(  
    System.int Index  
) {get; set;}
```

C++/CLI

```
property System.bool ColumnHidden {  
    System.bool get(System.int Index);  
    void set (System.int Index, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of column to show or hide

Property Value

True to hide the specified column, false to show it

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::ColumnHidden](#).

Example

[Hide or Show First Column in Hole Table \(VB.NET\)](#)
[Hide or Show First Column in Hole Table \(VBA\)](#)
[Hide or Show First Column in Hole Table \(C#\)](#)

Remarks

The index for both the rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnTitle Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnTitle Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::SetColumnWidth Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

DeleteColumn Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : DeleteColumn Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::DeleteColumn2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteColumn( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.DeleteColumn(Index)
```

C#

```
System.bool DeleteColumn(  
    System.int Index  
)
```

C++/CLI

```
System.bool DeleteColumn(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the column you want to delete

Return Value

True if column is deleted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::DeleteColumn](#).

Remarks

The index for both the rows and columns is 0-based.

This method deletes the entire table if you try to delete the only column in the table.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetColumnName Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnName Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteColumn2 Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : DeleteColumn2 Method (ITableAnnotation)

Deletes the specified column in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteColumn2( _  
    ByVal Index As System.Integer, _  
    ByVal IncludeHidden As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim value As System.Boolean  
  
value = instance.DeleteColumn2(Index, IncludeHidden)
```

C#

```
System.bool DeleteColumn2(  
    System.int Index,  
    System.bool IncludeHidden  
)
```

C++/CLI

```
System.bool DeleteColumn2(  
& System.int Index,  
& System.bool IncludeHidden  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the column you want to delete

IncludeHidden

True to delete the hidden column, false to not

Return Value

True if column is deleted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::DeleteColumn2](#).

Remarks

The index for both the rows and columns is 0-based.

This method deletes the entire table if you try to delete the only column in the table.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::InsertColumn2 Method \(\)](#)
[ITableAnnotation::ColumnCount Property \(\)](#)
[ITableAnnotation::ColumnHidden Property \(\)](#)
[ITableAnnotation::TotalColumnCount Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteRow Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : DeleteRow Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::DeleteRow2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteRow( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.DeleteRow(Index)
```

C#

```
System.bool DeleteRow(  
    System.int Index  
)
```

C++/CLI

```
System.bool DeleteRow(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the row you want to delete

Return Value

True if the row is deleted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::DeleteRow](#).

Remarks

The index for both the rows and columns is 0-based.

This method deletes the entire table if you try to delete the only row in the table.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

[ITableAnnotation::GetRowHeight Method](#)
[ITableAnnotation::GetRowVerticalGap Method](#)
[ITableAnnotation::InsertRow Method](#)
[ITableAnnotation::MoveRow Method](#)
[ITableAnnotation::SetRowHeight Method](#)
[ITableAnnotation::SetRowVerticalGap Method](#)
[ITableAnnotation::RowCount Property](#)
[ITableAnnotation::TotalRowCount Property](#)
[ITableAnnotation::RowHidden Property](#)
[ITableAnnotation::GetLockRowHeight Method](#)
[ITableAnnotation::SetLockRowHeight Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteRow2 Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : DeleteRow2 Method (ITableAnnotation)

Deletes the specified row from this table.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteRow2( _  
    ByVal Index As System.Integer, _  
    ByVal IncludeHidden As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim value As System.Boolean  
  
value = instance.DeleteRow2(Index, IncludeHidden)
```

C#

```
System.bool DeleteRow2(  
    System.int Index,  
    System.bool IncludeHidden  
)
```

C++/CLI

```
System.bool DeleteRow2(  
    & System.int Index,  
    & System.bool IncludeHidden  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the row you want to delete

IncludeHidden

True to delete the hidden row, false to not

Return Value

True if the row is deleted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::DeleteRow2](#).

Remarks

The index for both the rows and columns is 0-based.

This method deletes the entire table if you try to delete the only row in the table.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::InsertRow Method \(\)](#)
[ITableAnnotation::RowCount Property \(\)](#)
[ITableAnnotation::RowHidden Property \(\)](#)
[ITableAnnotation::TotalRowCount Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DisplayedText Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : DisplayedText Property (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::DisplayedText2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DisplayedText( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer _  
    ) As System.String
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim value As System.String  
  
value = instance.DisplayedText(Row, Column)
```

C#

```
System.string DisplayedText(  
    System.int Row,  
    System.int Column  
    ) {get;}
```

C++/CLI

```
property System.String^ DisplayedText {  
    System.String^ get(System.int Row, System.int Column);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
Index of the row
Column
Index of the column

Property Value

Text displayed in the specified cell

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::DisplayedText](#).

Remarks

Index for both rows and columns is 0-based.

To get the string that drives the text displayed in the specified cell, use [ITableAnnotation::Text](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::IsCellTextEditable Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::SetCellRange Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::SetTextFormat Method](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayedText2 Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : DisplayedText2 Property (ITableAnnotation)

Gets the actual text displayed in the specified cell in this table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DisplayedText2( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer, _  
    ByVal IncludeHidden As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim value As System.String  
  
value = instance.DisplayedText2(Row, Column, IncludeHidden)
```

C#

```
System.string DisplayedText2(  
    System.int Row,  
    System.int Column,  
    System.bool IncludeHidden  
) {get;}
```

C++/CLI

```
property System.String^ DisplayedText2 {  
    System.String^ get(System.int Row, System.int Column, System.bool IncludeHidden);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
Index of the row
Column
Index of the column

IncludeHidden
True to get the text displayed in the hidden cell, false to not

Property Value

Actual text displayed in the specified cell

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::DisplayedText2](#).

Example

[Get Table Annotation and Contents \(VBA\)](#)

Remarks

Index for both rows and columns is 0-based.

To get the parameterized string that drives this displayed text, use [ITableAnnotation::Text2](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EvaluateCellEquation Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : EvaluateCellEquation Method (ITableAnnotation)

Solves the specified equation in the specified cell of this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function EvaluateCellEquation( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer, _  
    ByVal IncludeHidden As System.Boolean, _  
    ByVal Equation As System.String, _  
    ByRef SolvedValue As System.String _  
    ) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim Equation As System.String  
Dim SolvedValue As System.String  
Dim value As System.Integer  
  
value = instance.EvaluateCellEquation(Row, Column, IncludeHidden, Equation, SolvedValue)
```

C#

```
System.int EvaluateCellEquation(  
    System.int Row,  
    System.int Column,  
    System.bool IncludeHidden,  
    System.string Equation,
```



```
    out System.string SolvedValue
)
```

C++/CLI

```
System.int EvaluateCellEquation(
& System.int Row,
& System.int Column,
& System.bool IncludeHidden,
& System.String^ Equation,
& [Out] System.String^ SolvedValue
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
0-based index of the row
Column
0-based index of the column
IncludeHidden
True to include hidden rows and columns in the Row and Column indexes, false to not
Equation
Equation to solve; empty string to remove an equation
SolvedValue
Value of solved Equation

Return Value

Return code as defined in [swCellEquationStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::EvaluateCellEquation](#).

Example

[Get and Set BOM Column Types and Cell Equations \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellEquation Method \(\)](#)
[ITableAnnotation::SetCellEquation Method \(\)](#)
[ITableAnnotation::GetColumnType3 Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GeneralTableFeature Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GeneralTableFeature Property (ITableAnnotation)

Gets the general table feature for this general table annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property GeneralTableFeature As GeneralTableFeature
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim value As GeneralTableFeature

value = instance.GeneralTableFeature
```

C#

```
GeneralTableFeature GeneralTableFeature {get;}
```

C++/CLI

```
property GeneralTableFeature^ GeneralTableFeature {  
    GeneralTableFeature^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IGeneralTableFeature](#) object

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GeneralTableFeature](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAnnotation Method (ITableAnnotation)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetAnnotation Method (ITableAnnotation)

Gets the annotation for this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As Annotation  
  
value = instance.GetAnnotation()
```

C#

```
Annotation GetAnnotation()
```

C++/CLI

```
Annotation^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetAnnotation](#).

Example

[Get Table Annotation and Contents \(VBA\)](#)
[Insert Hole Table \(VBA\)](#)

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCellEquation Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetCellEquation Method (ITableAnnotation)

Gets the equation and its solved value for the specified row and column of this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCellEquation( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer, _  
    ByVal IncludeHidden As System.Boolean, _  
    ByRef SolvedValue As System.String, _  
    ByRef Status As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim SolvedValue As System.String  
Dim Status As System.Integer  
Dim value As System.String  
  
value = instance.GetCellEquation(Row, Column, IncludeHidden, SolvedValue, Status)
```

C#

```
System.string GetCellEquation(  
    System.int Row,  
    System.int Column,  
    System.bool IncludeHidden,  
    out System.string SolvedValue,  
    out System.int Status  
)
```

C++/CLI

```
System.String^ GetCellEquation(  
& System.int Row,  
& System.int Column,  
& System.bool IncludeHidden,  
& [Out] System.String^ SolvedValue,  
& [Out] System.int Status  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
0-based index of the row, -1 to get the column equation
Column

0-based index of the column
IncludeHidden
True to include hidden rows and columns in the Row and Column indexes, false to not
SolvedValue
Evaluated equation
Status
Return code as defined in [swCellEquationStatus_e](#)

Return Value

Equation

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetCellEquation](#).

Example

[Get and Set BOM Column Types and Cell Equations \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SetCellEquation Method \(\)](#)
[ITableAnnotation::EvaluateCellEquation Method \(\)](#)
[ITableAnnotation::GetColumnType3 Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCellRange Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetCellRange Method (ITableAnnotation)

Gets the selected table cells' row and column index ranges.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetCellRange( _  
    ByRef FirstRow As System.Integer, _  
    ByRef LastRow As System.Integer, _  
    ByRef FirstColumn As System.Integer, _  
    ByRef LastColumn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim FirstRow As System.Integer  
Dim LastRow As System.Integer  
Dim FirstColumn As System.Integer  
Dim LastColumn As System.Integer  
  
instance.GetCellRange(FirstRow, LastRow, FirstColumn, LastColumn)
```

C#

```
void GetCellRange(  
    out System.int FirstRow,  
    out System.int LastRow,  
    out System.int FirstColumn,  
    out System.int LastColumn  
)
```

C++/CLI

```
void GetCellRange(
& [Out] System.int FirstRow,
& [Out] System.int LastRow,
& [Out] System.int FirstColumn,
& [Out] System.int LastColumn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FirstRow
Index of row of first selected cell
LastRow
Index of row of last selected cell
FirstColumn
Index of column of first selected cell
LastColumn
Index of column of last selected cell

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetCellRange](#).

Example

[Select Table Cells \(C#\)](#)
[Select Table Cells \(VB.NET\)](#)
[Select Table Cells \(VBA\)](#)

Remarks

The returned indexes are all 0-based.

If you don't multi-select table cells before you call this method, then the cell row/column index range for the entire table is returned.

Before calling this method, you can select the table cells in the graphics area whose row/column index range you want to get. How you make these selections determines what this method returns.

Selection	Steps	Cell range returned
Table cell	1. Place the cursor on the desired table cell. 2. Click the left-mouse button.	Selected cell
	1. Hold down the Ctrl key and place the cursor on the desired table cell. 2. Click the left-mouse button.	Selected cell
Multiple table cells	1. Place the cursor on a desired table cell. 2. Click and hold down the left-mouse button. 3. Drag the cursor over the other desired table cells. 4. Release the left-mouse button when the cursor is on the last table cell that you want selected.	All selected cells
	1. Hold down the Ctrl key and place the cursor on a desired table cell. 2. Click the left-mouse button. 3. Repeat steps 1 and 2 until all desired table cells are selected.	Each selected cell
Table column	Place the cursor just above the desired column and click the left-mouse button when the cursor changes to a solid arrow	All selected cells
Table row	Place the cursor to just left of the desired row and click the left-mouse button when the cursor changes to a solid arrow	All selected cells

Run any of the examples in the **Example** section to better understand the values returned by this method.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::IsCellTextEditable Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::SetCellRange Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)
[ITableAnnotation::DisplayedText Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

GetCellTextFormat Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetCellTextFormat Method (ITableAnnotation)

Gets the text format for the specified cell in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCellTextFormat( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer _  
) As TextFormat
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim value As TextFormat
```

```
value = instance.GetCellTextFormat(Row, Column)
```

C#

```
TextFormat GetCellTextFormat(  
    System.int Row,  
    System.int Column  
)
```

C++/CLI

```
TextFormat^ GetCellTextFormat(  
& System.int Row,  
& System.int Column  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Index of the row in which the cell is located

Column

Index of the column in which the cell is located

Return Value

[ITextFormat](#) object

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetCellTextFormat](#).

Remarks

The index for both the rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::GetTextFormat Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::SetTextFormat Method](#)
[ITableAnnotation::Text Property](#)

Availability

GetCellTextOrientation Method (ITableAnnotation)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetCellTextOrientation Method (ITableAnnotation)

Gets the text orientation in the specified cell of this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCellTextOrientation( _
    ByVal Row As System.Integer, _
    ByVal Column As System.Integer, _
    ByVal IncludeHidden As System.Boolean, _
    ByVal AllCells As System.Boolean _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim Row As System.Integer
Dim Column As System.Integer
Dim IncludeHidden As System.Boolean
Dim AllCells As System.Boolean
Dim value As System.Integer

value = instance.GetCellTextOrientation(Row, Column, IncludeHidden, AllCells)
```

C#

```
System.int GetCellTextOrientation(
    System.int Row,
    System.int Column,
    System.bool IncludeHidden,
    System.bool AllCells
)
```

C++/CLI

```
System.int GetCellTextOrientation(
    & System.int Row,
    & System.int Column,
    & System.bool IncludeHidden,
    & System.bool AllCells
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

0-based index of the cell row; valid only if AllCells is set to false

Column

0-based index of the cell column; valid only if AllCells is set to false

IncludeHidden

True to include hidden rows and columns in Row and Column indexes, false to not

*AllCells*True to get the orientation in all cells, false to not; if false, set Row and Column (see **Remarks**)

Return Value

Text orientation as defined in [swTableCellOrientation_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetCellTextOrientation](#).

Remarks

If AllCells is set to false, this method returns one of swTableCellOrientation_e.:

- swTableCellOrientation_Right
- swTableCellOrientation_Left
- swTableCellOrientation_Up
- swTableCellOrientation_Down

If AllCells is set to true, this method returns one of the above or:

- swTableCellOrientation_Varies, if all the cells do not share the same text orientation.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SetCellTextOrientation Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCellUseDocTextFormat Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetCellUseDocTextFormat Method (ITableAnnotation)

Gets whether this cell uses the document setting for its text format.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCellUseDocTextFormat( _
    ByVal Row As System.Integer, _
    ByVal Column As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim Row As System.Integer
Dim Column As System.Integer
Dim value As System.Boolean

value = instance.GetCellUseDocTextFormat(Row, Column)
```

C#

```
System.bool GetCellUseDocTextFormat(
    System.int Row,
    System.int Column
)
```

C++/CLI

```
System.bool GetCellUseDocTextFormat(
    & System.int Row,
    & System.int Column
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Index of the row in which the cell resides

Column

Index of the column in which the cell resides

Return Value

True to use the document setting for its text format, false to not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetCellUseDocTextFormat](#).

Remarks

The index for both the rows and columns in this table are 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetTextFormat Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::SetTextFormat Method](#)
[ITableAnnotation::Text Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetColumnTitle Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetColumnTitle Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::GetColumnTitle2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnTitle(  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetColumnTitle(Index)
```

C#

```
System.string GetColumnTitle(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetColumnTitle(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0-based index indicating the column

Return Value

Column title

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetColumnTitle](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetColumnTitle2 Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetColumnTitle2 Method (ITableAnnotation)

Gets the title of the specified column.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnTitle2( _  
    ByVal Index As System.Integer, _  
    ByVal IncludeHidden As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim value As System.String  
  
value = instance.GetColumnTitle2(Index, IncludeHidden)
```

C#

```
System.string GetColumnTitle2(  
    System.int Index,  
    System.bool IncludeHidden  
)
```

C++/CLI

```
System.String^ GetColumnTitle2(  
& System.int Index,  
& System.bool IncludeHidden  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index indicating the column

IncludeHidden

True to get the title of the hidden column, false to not

Return Value

Column title

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetColumnTitle2](#).

Example

[Export BOMs to XML \(VBA\)](#)
[Export BOMs to XML \(VB.NET\)](#)
[Export BOMs to XML \(C#\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SetColumnTitle2 Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetColumnType Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetColumnType Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::GetColumnType2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnType( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetColumnType(Index)
```

C#

```
System.int GetColumnType(  
    System.int Index  
)
```

C++/CLI

```
System.int GetColumnType(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0-based index indicating the column whose type to get

Return Value

Type of column as defined by [swTableColumnTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetColumnType](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetColumnTitle Method](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnWidth Method](#)

[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnTitle Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::SetColumnWidth Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::GetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetColumnType2 Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetColumnType2 Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::GetColumnType3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnType2( _  
    ByVal Index As System.Integer, _  
    ByVal IncludeHidden As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetColumnType2(Index, IncludeHidden)
```

C#

```
System.int GetColumnType2(  
    System.int Index,  
    System.bool IncludeHidden  
)
```

C++/CLI

```
System.int GetColumnType2(  
& System.int Index,  
& System.bool IncludeHidden  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index indicating the column whose type to get

IncludeHidden

True to get the type of the hidden column, false to not

Return Value

Type of column as defined by [swTableColumnTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetColumnType2](#).

Example

[Insert Column in BOM Table \(VBA\)](#)
[Insert Column in BOM Table \(VB.NET\)](#)
[Insert Column in BOM Table \(C#\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SetColumnType2 Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetColumnType3 Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetColumnType3 Method (ITableAnnotation)

Gets the type and property data for the specified BOM table column.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnType3(  
    ByVal Index As System.Integer, _  
    ByVal IncludeHidden As System.Boolean, _  
    ByRef PropertyData As System.Object, _  
    ByRef Status As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim PropertyData As System.Object  
Dim Status As System.Integer  
Dim value As System.Integer  
  
value = instance.GetColumnType3(Index, IncludeHidden, PropertyData, Status)
```

C#

```
System.int GetColumnType3(  
    System.int Index,  
    System.bool IncludeHidden,  
    out System.object PropertyData,  
    out System.int Status  
)
```

C++/CLI

```
System.int GetColumnType3(  
& System.int Index,  
& System.bool IncludeHidden,  
& [Out] System.Object^ PropertyData,  
& [Out] System.int Status  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of the column whose type to get

IncludeHidden

True to include hidden columns in Index, false to not

PropertyData

Property data specific to the type of column (see **Remarks**)

Status

Return code as defined in [swColumnTypeStatus_e](#)

Return Value

Type of column as defined in [swTableColumnTypes](#) e

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetColumnType3](#).

Example

[Get and Set BOM Column Types and Cell Equations \(VBA\)](#)

Remarks

PropertyData varies by the type of column. See the Remarks in [ITableAnnotation::SetColumnType3](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellEquation Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetColumnWidth Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetColumnWidth Method (ITableAnnotation)

Gets the width of the specified column of this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnWidth(  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetColumnWidth(Index)
```

C#

```
System.double GetColumnWidth(  
    System.int Index  
)
```

C++/CLI

```
System.double GetColumnWidth(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of column for which to get the width

Return Value

Width of the specified column, in system units

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetColumnWidth](#).

Remarks

The index for both rows and columns is 0-based.

To set the column width, use [ITableAnnotation::SetColumnWidth](#).

To get or set the row height, use [ITableAnnotation::GetRowHeight](#) and [ITableAnnotation::SetRowHeight](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnTitle Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnTitle Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHeaderCount Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetHeaderCount Method (ITableAnnotation)

Gets the number of rows or columns in the header of this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHeaderCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer  
  
value = instance.GetHeaderCount()
```

C#

```
System.int GetHeaderCount()
```

C++/CLI

```
System.int GetHeaderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of rows or columns in the header of this table

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetHeaderCount](#).

Example

[Export BOMs to XML \(C#\)](#)
[Export BOMs to XML \(VB.NET\)](#)
[Export BOMs to XML \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetHeaderStyle Method](#)
[ITableAnnotation::SetHeader Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHeaderStyle Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetHeaderStyle Method (ITableAnnotation)

Gets the header style of this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHeaderStyle() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer  
  
value = instance.GetHeaderStyle()
```

C#

```
System.int GetHeaderStyle()
```

C++/CLI

```
System.int GetHeaderStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Style of table header as defined in [swTableHeaderPosition](#) e

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetHeaderStyle](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetHeaderCount Method](#)
[ITableAnnotation::SetHeader Method](#)

Availability

GetLockColumnWidth Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetLockColumnWidth Method (ITableAnnotation)

Gets whether the width of the specified column is locked in this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLockColumnWidth( _
    ByVal Index As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation
Dim Index As System.Integer
Dim value As System.Boolean

value = instance.GetLockColumnWidth(Index)
```

C#

```
System.bool GetLockColumnWidth(
    System.int Index
)
```

C++/CLI

```
System.bool GetLockColumnWidth(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of the column (see **Remarks**)

Return Value

True if the specified column's width is locked, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetLockColumnWidth](#).

Remarks

Call [ITableAnnotation::ColumnCount](#) to get the number of visible columns or [ITableAnnotation::TotalColumnCount](#) to get the number of visible and hidden columns in this table annotation.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SetLockColumnWidth Method \(\)](#)
[ITableAnnotation::DeleteColumn Method \(\)](#)
[ITableAnnotation::GetColumnType Method \(\)](#)
[ITableAnnotation::GetColumnWidth Method \(\)](#)
[ITableAnnotation::InsertColumn2 Method \(\)](#)
[ITableAnnotation::MoveColumn Method \(\)](#)
[ITableAnnotation::SetColumnTitle Method \(\)](#)
[ITableAnnotation::SetColumnType Method \(\)](#)
[ITableAnnotation::SetColumnWidth Method \(\)](#)
[ITableAnnotation::ColumnHidden Property \(\)](#)

Availability

GetLockRowHeight Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetLockRowHeight Method (ITableAnnotation)

Gets whether the height of the specified row is locked in this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLockRowHeight( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetLockRowHeight(Index)
```

C#

```
System.bool GetLockRowHeight(  
    System.int Index  
)
```

C++/CLI

```
System.bool GetLockRowHeight(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of the row (see **Remarks**)

Return Value

True if the specified row's height is locked, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetLockRowHeight](#).

Example

[Get Components in Each BOM Table Row \(C#\)](#)
[Get Components in Each BOM Table Row \(VB.NET\)](#)
[Get Components in Each BOM Table Row \(VBA\)](#)

Remarks

Call [ITableAnnotation::RowCount](#) to get the number of visible rows or [ITableAnnotation::TotalRowCount](#) to get the number of visible and hidden rows in this table annotation.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SetLockRowHeight Method \(\)](#)
[ITableAnnotation::DeleteRow Method \(\)](#)
[ITableAnnotation::GetRowHeight Method \(\)](#)
[ITableAnnotation::GetRowVerticalGap Method \(\)](#)
[ITableAnnotation::InsertRow Method \(\)](#)
[ITableAnnotation::MoveRow Method \(\)](#)
[ITableAnnotation::SetRowHeight Method \(\)](#)

[ITableAnnotation::SetRowVerticalGap Method \(\)](#)
[ITableAnnotation::RowHidden Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetNext Method (ITableAnnotation)

Gets the next table annotation in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As TableAnnotation
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As TableAnnotation  
  
value = instance.GetNext()
```

C#

```
TableAnnotation GetNext()
```

C++/CLI

```
TableAnnotation^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [ITableAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetNext](#).

Example

[Get Table Annotation and Contents \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[IView::GetFirstTableAnnotation Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRowHeight Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetRowHeight Method (ITableAnnotation)

Gets the height of the specified row of this table.

.NET Syntax

```
Function GetRowHeight( _
    ByVal Index As System.Integer _
) As System.Double
```



```
Dim instance As ITableAnnotation
Dim Index As System.Integer
Dim value As System.Double

value = instance.GetRowHeight(Index)
```

```
System.double GetRowHeight(
    System.int Index
)
```

```
System.double GetRowHeight(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of row for which to get the height

Return Value

Height of the specified row, in system units

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetRowHeight](#).

Example

[Get Components in Each BOM Table Row \(C#\)](#)
[Get Components in Each BOM Table Row \(VB.NET\)](#)
[Get Components in Each BOM Table Row \(VBA\)](#)

Remarks

The index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteRow Method](#)
[ITableAnnotation::GetRowVerticalGap Method](#)
[ITableAnnotation::InsertRow Method](#)
[ITableAnnotation::MoveRow Method](#)
[ITableAnnotation::SetRowHeight Method](#)
[ITableAnnotation::SetRowVerticalGap Method](#)
[ITableAnnotation::TotalRowCount Property](#)
[ITableAnnotation::RowCount Property](#)
[ITableAnnotation::RowHidden Property](#)
[ITableAnnotation::GetLockRowHeight Method](#)
[ITableAnnotation::SetLockRowHeight Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0



Gets the gap between the text and the top or bottom of the specified row of this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRowVerticalGap( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetRowVerticalGap(Index)
```

C#

```
System.double GetRowVerticalGap(  
    System.int Index  
)
```

C++/CLI

```
System.double GetRowVerticalGap(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of row for which to get the height

Return Value

Gap in system units

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetRowVerticalGap](#).

Remarks

Use [ITableAnnotation::SetRowVerticalGap](#) to set the size of the gap.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteRow Method](#)
[ITableAnnotation::GetRowHeight Method](#)
[ITableAnnotation::MoveRow Method](#)
[ITableAnnotation::SetRowHeight Method](#)
[ITableAnnotation::TotalRowCount Property](#)
[ITableAnnotation::GetLockRowHeight Method](#)
[ITableAnnotation::GetRowVerticalGap Method](#)
[ITableAnnotation::InsertRow Method](#)
[ITableAnnotation::SetLockRowHeight Method](#)
[ITableAnnotation::RowCount Property](#)
[ITableAnnotation::RowHidden Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetSplitInformation Method (ITableAnnotation)

Gets information about any splits in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplitInformation( _  
    ByRef Index As System.Integer, _  
    ByRef Count As System.Integer, _  
    ByRef RangeStart As System.Integer, _  
    ByRef RangeEnd As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim Count As System.Integer  
Dim RangeStart As System.Integer  
Dim RangeEnd As System.Integer  
Dim value As System.Integer  
  
value = instance.GetSplitInformation(Index, Count, RangeStart, RangeEnd)
```

C#

```
System.int GetSplitInformation(  
    out System.int Index,  
    out System.int Count,  
    out System.int RangeStart,  
    out System.int RangeEnd  
)
```

C++/CLI

```
System.int GetSplitInformation(  
& [Out] System.int Index,  
& [Out] System.int Count,  
& [Out] System.int RangeStart,  
& [Out] System.int RangeEnd  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Piece of the table that this is
Count
Piece of the table that this is
RangeStart
Beginning row for this piece of the table
RangeEnd
Ending row for this piece of the table

Return Value

Direction in which the table was split as defined by [swTableSplitDirection_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetSplitInformation](#).

Example

[Export BOMs to XML \(C#\)](#)
[Export BOMs to XML \(VB.NET\)](#)
[Export BOMs to XML \(VBA\)](#)

Remarks

A table split is a table divided into multiple tables, also called pieces.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::Split Method](#)
[ITableAnnotation::HorizontalAutoSplit Method \(\)](#)
[ITableAnnotation::StopAutoSplitting Property \(\)](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextFormat Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetTextFormat Method (ITableAnnotation)

Gets the text format for this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormat() As TextFormat
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As TextFormat  
  
value = instance.GetTextFormat()
```

C#

```
TextFormat GetTextFormat()
```

C++/CLI

```
TextFormat^ GetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ITextFormat](#) object

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetTextFormat](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::GetUseDocTextFormat Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::SetTextFormat Method](#)
[ITableAnnotation::Text Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetUseDocTextFormat Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GetUseDocTextFormat Method (ITableAnnotation)

Gets whether this table uses the document setting for text formatting.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocTextFormat() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Boolean  
  
value = instance.GetUseDocTextFormat()
```

C#

```
System.bool GetUseDocTextFormat()
```

C++/CLI

```
System.bool GetUseDocTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this table uses the document setting for the text format, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GetUseDocTextFormat](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::GetTextFormat Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::SetTextFormat Method](#)
[ITableAnnotation::Text Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GridLineWidth Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GridLineWidth Property (ITableAnnotation)

Gets or sets the line weight of the inner lines to the SOLIDWORKS-supplied weight for this table.

.NET Syntax

Visual Basic (Declaration)

```
Property GridLineWidth As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer  
  
instance.GridLineWidth = value
```

```
value = instance.GridLineWeight
```

C#

```
System.int GridLineWeight {get; set;}
```

C++/CLI

```
property System.int GridLineWeight {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weight for inner lines of this table as defined by [swLineWeights_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GridLineWeight](#).

Example

[Get General Table Feature \(C#\)](#)
[Get General Table Feature \(VB.NET\)](#)
[Get General Table Feature \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::BorderLineWeight Property](#)
[ITableAnnotation::GridLineWeightCustom Property](#)
[ITableAnnotation::BorderLineWeightCustom Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GridLineWeightCustom Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : GridLineWeightCustom Property (ITableAnnotation)

Gets or sets the line weight of the inner lines to the specified custom weight for this table.

.NET Syntax

Visual Basic (Declaration)

```
Property GridLineWeightCustom As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Double  
  
instance.GridLineWeightCustom = value  
value = instance.GridLineWeightCustom
```

C#

```
System.double GridLineWeightCustom {get; set;}
```

C++/CLI

```
property System.double GridLineWeightCustom {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Custom weight for inner lines in millimeters

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::GridLineWeightCustom](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GridLineWeight Property](#)
[ITableAnnotation::BorderLineWeightCustom Property](#)
[ITableAnnotation::BorderLineWeightCustom Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

HorizontalAutoSplit Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : HorizontalAutoSplit Method (ITableAnnotation)

Starts the automatic horizontal splitting of this table using the specified options.

.NET Syntax

Visual Basic (Declaration)

```
Function HorizontalAutoSplit( _
    ByVal MaxNumberOfRows As System.Integer, _
    ByVal Apply As System.Integer, _
    ByVal PlacementOfNewSplitTables As System.Integer _
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation
Dim MaxNumberOfRows As System.Integer
Dim Apply As System.Integer
Dim PlacementOfNewSplitTables As System.Integer
Dim value As System.Object

value = instance.HorizontalAutoSplit(MaxNumberOfRows, Apply, PlacementOfNewSplitTables)
```

C#

```
System.object HorizontalAutoSplit(
    System.int MaxNumberOfRows,
    System.int Apply,
    System.int PlacementOfNewSplitTables
)
```

C++/CLI

```
System.Object^ HorizontalAutoSplit(
    & System.int MaxNumberOfRows,
    & System.int Apply,
    & System.int PlacementOfNewSplitTables
)
```



Copy Code

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MaxNumberOfRows

Maximum number of rows in the split portions

Apply

How often to horizontally split the table as defined in [swHorizontalAutoSplitApply_e](#)

PlacementOfNewSplitTables

Where to place the horizontally split table as defined in [swHorizontalAutoSplitPlacementOfSplitTable_e](#)

Return Value

Array of split [ITableAnnotations](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::HorizontalAutoSplit](#).

Remarks

This method horizontally splits:

- [Hole tables](#)
- [Bill of Materials tables](#)
- [General tables](#)

If Apply is set to [swHorizontalAutoSplitApply_e](#).Continuously, in order to stop the automatic splitting of tables, you must set [ITableAnnotation::StopAutoSplitting](#) to true.

See Also

[ITableAnnotation Interface](#)

[ITableAnnotation Members](#)

[ITableAnnotation::Split Method \(\)](#)

[ITableAnnotation::GetSplitInformation Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertColumn Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : InsertColumn Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::InsertColumn2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertColumn( _  
    ByVal Where As System.Integer, _  
    ByVal Index As System.Integer, _  
    ByVal Name As System.String _  
    ) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation  
Dim Where As System.Integer  
Dim Index As System.Integer  
Dim Name As System.String  
Dim value As System.Boolean
```

```
value = instance.InsertColumn(Where, Index, Name)
```

C#

```
System.bool InsertColumn(  
    System.int Where,  
    System.int Index,
```



```
        System.string Name
    )
```

C++/CLI

```
System.bool InsertColumn(
& System.int Where,
& System.int Index,
& System.String^ Name
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Where

Where to insert the column as specified in [swTableItemInsertPosition_e](#)

Index

Index of the column where to insert the new column

Name

Column name

Return Value

True if column is inserted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::InsertColumn](#).

Example

[Insert Part Number Column in BOM Table \(C#\)](#)
[Insert Part Number Column in BOM Table \(VB.NET\)](#)
[Insert Part Number Column in BOM Table \(VBA\)](#)

Remarks

The index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertColumn2 Method (ITableAnnotation)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : InsertColumn2 Method (ITableAnnotation)

Inserts a column into this table.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertColumn2( _
    ByVal Where As System.Integer, _
    ByVal Index As System.Integer, _
    ByVal Name As System.String, _
    ByVal WidthStyle As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Where As System.Integer  
Dim Index As System.Integer  
Dim Name As System.String  
Dim WidthStyle As System.Integer  
Dim value As System.Boolean  
  
value = instance.InsertColumn2(Where, Index, Name, WidthStyle)
```

C#

```
System.bool InsertColumn2(  
    System.int Where,  
    System.int Index,  
    System.string Name,  
    System.int WidthStyle  
)
```

C++/CLI

```
System.bool InsertColumn2(  
& System.int Where,  
& System.int Index,  
& System.String^ Name,  
& System.int WidthStyle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Where

Where to insert the column as specified in [swTableItemInsertPosition_e](#)

Index

Index of the column where to insert the new column

Name

Column name

WidthStyle

Style of the width of the column as defined in [swInsertTableColumnWidthStyle_e](#)

Return Value

True if column is inserted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::InsertColumn2](#).

Example

[Insert Column in BOM Table \(C#\)](#)
[Insert Column in BOM Table \(VB.NET\)](#)
[Insert Column in BOM Table \(VBA\)](#)

Remarks

Index:

- is 0-based.
- is valid only if Where is set to swTableItemInsertPosition_e.swTableItemInsertPosition_After or swTableItemInsertPosition_e.swTableItemInsertPosition_Before.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnTitle Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnTitle Method](#)

[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::SetColumnWidth Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0