

SOLIDWORKS API (.NET VBA C#) — Reference (309/337): ITableAnnotation (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

ITableAnnotation (part 2 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertRow Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : InsertRow Method (ITableAnnotation)

Inserts a row into this table.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertRow( _  
    ByVal Where As System.Integer, _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Where As System.Integer  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.InsertRow(Where, Index)
```

C#

```
System.bool InsertRow(  
    System.int Where,  
    System.int Index  
)
```

C++/CLI

```
System.bool InsertRow(  
& System.int Where,  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Where

Where to insert the new row as defined in [swTableItemInsertPosition_e](#)

Index

Index of row where to insert new row (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::InsertRow](#).

Example

[Sort Table \(VBA\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(C#\)](#)

Remarks

Index:

- is 0-based.
- is valid only if Where is set to [swTableItemInsertPosition_e.swTableItemInsertPosition_After](#) or [swTableItemInsertPosition_e.swTableItemInsertPosition_Before](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteRow Method](#)
[ITableAnnotation::GetRowHeight Method](#)
[ITableAnnotation::GetRowVerticalGap Method](#)
[ITableAnnotation::MoveRow Method](#)
[ITableAnnotation::SetRowHeight Method](#)
[ITableAnnotation::SetRowVerticalGap Method](#)
[ITableAnnotation::RowCount Property](#)
[ITableAnnotation::TotalRowCount Property](#)
[ITableAnnotation::GetLockRowHeight Method](#)
[ITableAnnotation::SetLockRowHeight Method](#)
[ITableAnnotation::RowHidden Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsCellMerged Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : IsCellMerged Method (ITableAnnotation)

Gets whether the specified cell is merged with other cells.

.NET Syntax

Visual Basic (Declaration)

```
Function IsCellMerged( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer, _  
    ByRef WithRow As System.Integer, _  
    ByRef WithColumn As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim WithRow As System.Integer  
Dim WithColumn As System.Integer  
Dim value As System.Boolean  
  
value = instance.IsCellMerged(Row, Column, WithRow, WithColumn)
```

C#

```
System.bool IsCellMerged(  
    System.int Row,  
    System.int Column,  
    out System.int WithRow,  
    out System.int WithColumn  
)
```

C++/CLI

```
System.bool IsCellMerged(  
& System.int Row,  
& System.int Column,  
& [Out] System.int WithRow,  
& [Out] System.int WithColumn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Index of the row of the first cell to see if it's merged

Column

Index of the column of the first cell to see if it's merged

WithRow

Index of the row of the second cell with which the first cell is merged

WithColumn

Index of the column of the second cell with which the first cell is merged

Return Value

True if this cell is merged with other cells, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::IsCellMerged](#).

Remarks

The index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellRange Method](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::IsCellTextEditable Method](#)
[ITableAnnotation::Merge Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::SetCellRange Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::UnmergeCells Method](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)
[ITableAnnotation::DisplayedText Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsCellTextEditable Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : IsCellTextEditable Method (ITableAnnotation)

Gets whether the text in this cell can be edited.

.NET Syntax

Visual Basic (Declaration)

```
Function IsCellTextEditable( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim value As System.Boolean
```

```
value = instance.IsCellTextEditable(Row, Column)
```

C#

```
System.bool IsCellTextEditable(  
    System.int Row,  
    System.int Column  
)
```

```
System.bool IsCellTextEditable(
& System.int Row,
& System.int Column
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
Index of row in which cell resides
Column
Index of column in which cell resides

Return Value

True if text in this cell can be edited, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::IsCellTextEditable](#).

Remarks

The index for both rows and columns is 0-based.

Tables and cells:

- [BOM table annotation](#): All cells can be edited.
- [General table annotation](#): All cells can be edited.
- [Hole table annotation](#): Only some columns can be edited because some information is automatically generated, thus, that information cannot be edited. The header row and custom columns can be edited.
- [Revision table annotation](#): All cells can be edited.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellRange Method](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::SetCellRange Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::UnmergeCells Method](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)
[ITableAnnotation::DisplayedText Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Merge Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : Merge Method (ITableAnnotation)

Merges the display of this table.

.NET Syntax

Visual Basic (Declaration)

```
Function Merge( _
    ByVal Where As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation
Dim Where As System.Integer
Dim value As System.Boolean
```



```
value = instance.Merge(Where)
```

C#

```
System.bool Merge(  
    System.int Where  
)
```

C++/CLI

```
System.bool Merge(  
& System.int Where  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Where

Merge the display of this table as defined in [swTableMergeLocations_e](#)

Return Value

True if the merge is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::Merge](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::GetSplitInformation Method](#)
[ITableAnnotation::Split Method](#)
[ITableAnnotation::UnmergeCells Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MergeCells Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : MergeCells Method (ITableAnnotation)

Merges the cells in the specified range.

.NET Syntax

Visual Basic (Declaration)

```
Function MergeCells( _  
    ByVal RowStart As System.Integer, _  
    ByVal ColumnStart As System.Integer, _  
    ByVal RowEnd As System.Integer, _  
    ByVal ColumnEnd As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim RowStart As System.Integer  
Dim ColumnStart As System.Integer  
Dim RowEnd As System.Integer  
Dim ColumnEnd As System.Integer  
Dim value As System.Boolean
```

```
value = instance.MergeCells(RowStart, ColumnStart, RowEnd, ColumnEnd)
```

C#

```
System.bool MergeCells(  
    System.int RowStart,  
    System.int ColumnStart,  
    System.int RowEnd,  
    System.int ColumnEnd  
)
```

C++/CLI

```
System.bool MergeCells(  
    & System.int RowStart,  
    & System.int ColumnStart,  
    & System.int RowEnd,  
    & System.int ColumnEnd  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowStart

Index of row at which start the merge

ColumnStart

Index of column at which to start the merge

RowEnd

Index of row at which to end the merge

ColumnEnd

Index of column at which to end the merge

Return Value

True if the cells in the specified range merge successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::MergeCells](#).

Remarks

The index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)

[ITableAnnotation Members](#)

[ITableAnnotation::GetCellRange Method](#)

[ITableAnnotation::IsCellMerged Method](#)

[ITableAnnotation::Merge Method](#)

[ITableAnnotation::UnmergeCells Method](#)

[ITableAnnotation::GetSplitInformation Method](#)

[ITableAnnotation::Split Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MoveColumn Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : MoveColumn Method (ITableAnnotation)

Moves a column in this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function MoveColumn( _  
    ByVal Source As System.Integer, _
```

```

        ByVal Where As System.Integer, _
        ByVal Destination As System.Integer _
    ) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As ITableAnnotation
Dim Source As System.Integer
Dim Where As System.Integer
Dim Destination As System.Integer
Dim value As System.Boolean

value = instance.MoveColumn(Source, Where, Destination)

```

C#

```

System.bool MoveColumn(
    System.int Source,
    System.int Where,
    System.int Destination
)

```

C++/CLI

```

System.bool MoveColumn(
    & System.int Source,
    & System.int Where,
    & System.int Destination
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Source
Index of column to move

Where
Position where to move Source relative to Destination as defined by [swTableItemInsertPosition_e](#)

Destination
Index of column where to move Source

Return Value

True if a column is moved, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::MoveColumn](#).

Remarks

The index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnTitle Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::SetColumnTitle Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::SetColumnWidth Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

MoveRow Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : MoveRow Method (ITableAnnotation)

Moves a row in this table either up one row or down one row.

.NET Syntax

Visual Basic (Declaration)

```
Function MoveRow( _  
    ByVal Source As System.Integer, _  
    ByVal Where As System.Integer, _  
    ByVal Destination As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Source As System.Integer  
Dim Where As System.Integer  
Dim Destination As System.Integer  
Dim value As System.Boolean  
  
value = instance.MoveRow(Source, Where, Destination)
```

C#

```
System.bool MoveRow(  
    System.int Source,  
    System.int Where,  
    System.int Destination  
)
```

C++/CLI

```
System.bool MoveRow(  
& System.int Source,  
& System.int Where,  
& System.int Destination  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Source
Index of row to move
Where
Position where to move Source relative to Destination as defined by [swTableItemInsertPosition_e](#)
Destination
Index of row where to move Source, which is either 1 greater than the Source or 1 less than Source

Return Value

True if a row is moved, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::MoveRow](#).

Remarks

The index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteRow Method](#)
[ITableAnnotation::GetRowHeight Method](#)
[ITableAnnotation::GetRowVerticalGap Method](#)

[ITableAnnotation::InsertRow Method](#)
[ITableAnnotation::SetRowHeight Method](#)
[ITableAnnotation::SetRowVerticalGap Method](#)
[ITableAnnotation::RowCount Property](#)
[ITableAnnotation::TotalRowCount Property](#)
[ITableAnnotation::RowHidden Property](#)
[ITableAnnotation::GetLockRowHeight Method](#)
[ITableAnnotation::SetLockRowHeight Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RowCount Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : RowCount Property (ITableAnnotation)

Gets the number of rows in this table.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property RowCount As System.Integer

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer
```

```
value = instance.RowCount
```

C#

```
System.int RowCount {get;}
```

C++/CLI

```
property System.int RowCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of rows in this table

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::RowCount](#).

Example

[Get Revision Table \(VBA\)](#)
[Get Table Annotation and Contents \(VBA\)](#)
[Insert Hole Table \(VBA\)](#)
[Insert Table \(VBA\)](#)
[Get General Table Feature \(C#\)](#)
[Get General Table Feature \(VB.NET\)](#)
[Get General Table Feature \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteRow Method](#)
[ITableAnnotation::GetRowHeight Method](#)
[ITableAnnotation::GetRowVerticalGap Method](#)
[ITableAnnotation::InsertRow Method](#)
[ITableAnnotation::MoveRow Method](#)
[ITableAnnotation::SetRowHeight Method](#)
[ITableAnnotation::SetRowVerticalGap Method](#)
[ITableAnnotation::TotalRowCount Property](#)
[ITableAnnotation::RowHidden Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RowHidden Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : RowHidden Property (ITableAnnotation)

Gets or sets whether the specified row is hidden in this table.

.NET Syntax

Visual Basic (Declaration)

```
Property RowHidden( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
instance.RowHidden(Index) = value  
  
value = instance.RowHidden(Index)
```

C#

```
System.bool RowHidden(  
    System.int Index  
) {get; set;}
```

C++/CLI

```
property System.bool RowHidden {  
    System.bool get(System.int Index);  
    void set (System.int Index, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of row

Property Value

True if hidden, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::RowHidden](#).

Example

[Hide and Show Row \(VBA\)](#)
[Insert General Table \(VBA\)](#)

Remarks

The index for both the rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::TotalRowCount Property \(\)](#)
[ITableAnnotation::DeleteColumn Method \(\)](#)
[ITableAnnotation::GetLockRowHeight Method \(\)](#)
[ITableAnnotation::GetRowHeight Method \(\)](#)
[ITableAnnotation::GetRowVerticalGap Method \(\)](#)
[ITableAnnotation::InsertRow Method \(\)](#)
[ITableAnnotation::MoveRow Method \(\)](#)
[ITableAnnotation::SetLockRowHeight Method \(\)](#)
[ITableAnnotation::SetRowHeight Method \(\)](#)
[ITableAnnotation::SetRowVerticalGap Method \(\)](#)
[ITableAnnotation::RowCount Property \(\)](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SaveAsPDF Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SaveAsPDF Method (ITableAnnotation)

Saves this table to a PDF file.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveAsPDF( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.SaveAsPDF(FileName)
```

C#

```
System.bool SaveAsPDF(  
    System.string FileName  
)
```

C++/CLI

```
System.bool SaveAsPDF(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Full path and filename of the PDF File (see **Remarks**)

Return Value

True if the table is saved to a PDF file, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SaveAsPDF](#).

Example

[Save Table to PDF \(C#\)](#)
[Save Table to PDF \(VB.NET\)](#)
[Save Table to PDF \(VBA\)](#)

Remarks

You must specify a filename. It should include the path, filename, and the PDF filename extension to which to save the table.

If a file of the specified name in the specified path...	Then it is...
Exists	Overwritten
Does not exist	Created

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SaveAsTemplate Method](#)
[ITableAnnotation::SaveAsText Method](#)

Availability

SOLIDWORKS 2012 SP04, Revision Number 20.4

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

SaveAsTemplate Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SaveAsTemplate Method (ITableAnnotation)

Saves the format of this table as a template file, which you can then use to create other tables of the same type and that look the same.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveAsTemplate( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.SaveAsTemplate(FileName)
```

C#

```
System.bool SaveAsTemplate(  
    System.string FileName  
)
```

C++/CLI

```
System.bool SaveAsTemplate(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Full path and filename to which to save the table template file (see **Remarks**)

Return Value

True if the table is saved as a template file, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SaveAsTemplate](#).

Remarks

You must specify a filename. It should include the path, filename, and filename extension to which to save the table as a template file.

If a file of the specified name in the specified path...	Then it is...
Exists	Overwritten
Does not exist	Created

The filename extension of the file does not matter, but to be consistent with the SOLIDWORKS naming conventions, the following extensions should be used:

- **.sldbomtbt** for BOM tables
- **.sldrevtbt** for revision tables
- **.sldholtbt** for hole tables
- **.sldtbt** for general tables

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SaveAsPDF Method](#)
[ITableAnnotation::SaveAsText Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SaveAsText Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SaveAsText Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::SaveAsText2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SaveAsText( _  
    ByVal FileName As System.String, _  
    ByVal Separator As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim FileName As System.String  
Dim Separator As System.String  
Dim value As System.Boolean
```

```
value = instance.SaveAsText(FileName, Separator)
```

C#

```
System.bool SaveAsText(  
    System.string FileName,  
    System.string Separator  
)
```

C++/CLI

```
System.bool SaveAsText(  
& System.String^ FileName,  
& System.String^ Separator  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Full path and filename of text data file (see **Remarks**)

Separator

Character or string to use to separate each of the text within each of the cells in the table in the text file

Return Value

True if table is saved as a text file, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SaveAsText](#).

Remarks

You must specify a filename. It should include the path, filename, and filename extension to which to save the table as a text file.

If a file of the specified name in the specified path...	Then it is...
Exists	Overwritten
Does not exist	Created

The Separator argument is typically a single character, but it can be a string. If Separator is empty, then the tab character is used.

NOTE: Although you can save a table as a text file for use with other applications like Microsoft Excel, you cannot currently import a text file to a table in SOLIDWORKS.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::SaveAsPDF Method](#)
[ITableAnnotation::SaveAsTemplate Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SaveAsText2 Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SaveAsText2 Method (ITableAnnotation)

Saves this table to a text data file.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveAsText2( _  
    ByVal FileName As System.String, _  
    ByVal Separator As System.String, _  
    ByVal IncludeHidden As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim FileName As System.String  
Dim Separator As System.String  
Dim IncludeHidden As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SaveAsText2(FileName, Separator, IncludeHidden)
```

C#

```
System.bool SaveAsText2(  
    System.string FileName,  
    System.string Separator,  
    System.bool IncludeHidden  
)
```

C++/CLI

```
System.bool SaveAsText2(  
& System.String^ FileName,  
& System.String^ Separator,  
& System.bool IncludeHidden  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Full path and filename of text data file (see **Remarks**)

Separator

Character or string to use to separate each of the text within each of the cells in the table in the text file (see **Remarks**)

IncludeHidden

True to include text in hidden cells, false to not

Return Value

True if table is saved as a text file, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SaveAsText2](#).

Remarks

FileName should include the path, filename, and filename extension to which to save the table as a text file.

If a file of the specified name in the specified path...	Then it is...
Exists	Overwritten
Does not exist	Created

Separator is typically a single character, but it can be a string. If Separator is empty, then the tab character is used.

NOTE: Although you can save a table as a text file for use with other applications, like Microsoft Excel, you cannot currently import a text file to a table in SOLIDWORKS.

See Also

[ITableAnnotation Interface](#)

[ITableAnnotation Members](#)

[ITableAnnotation::SaveAsPDF Method \(\)](#)

[ITableAnnotation::SaveAsTemplate Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCellEquation Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetCellEquation Method (ITableAnnotation)

Sets the specified equation for the specified row and column of this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetCellEquation( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer, _  
    ByVal IncludeHidden As System.Boolean, _  
    ByVal Equation As System.String _  
) As System.Integer
```

Visual Basic (Usage)

 Copy Code


```

Dim instance As ITableAnnotation
Dim Row As System.Integer
Dim Column As System.Integer
Dim IncludeHidden As System.Boolean
Dim Equation As System.String
Dim value As System.Integer

value = instance.SetCellEquation(Row, Column, IncludeHidden, Equation)

```

C#

```

System.int SetCellEquation(
    System.int Row,
    System.int Column,
    System.bool IncludeHidden,
    System.string Equation
)

```

C++/CLI

```

System.int SetCellEquation(
    & System.int Row,
    & System.int Column,
    & System.bool IncludeHidden,
    & System.String^ Equation
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
0-based index of the row, -1 to set a column equation

Column
0-based index of the column

IncludeHidden
True to include hidden rows and columns in the Row and Column indexes, false to not

Equation
Equation

Return Value

Return code as defined in [swCellEquationStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetCellEquation](#).

Example

[Get and Set BOM Column Types and Cell Equations \(VBA\)](#)

Remarks

After calling this method, call [IModelDoc2::EditRebuild3](#) to refresh the table in the user interface.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellEquation Method \(\)](#)
[ITableAnnotation::EvaluateCellEquation Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

Sets the current range of cells.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCellRange( _  
    ByVal FirstRow As System.Integer, _  
    ByVal LastRow As System.Integer, _  
    ByVal FirstColumn As System.Integer, _  
    ByVal LastColumn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim FirstRow As System.Integer  
Dim LastRow As System.Integer  
Dim FirstColumn As System.Integer  
Dim LastColumn As System.Integer  
  
instance.SetCellRange(FirstRow, LastRow, FirstColumn, LastColumn)
```

C#

```
void SetCellRange(  
    System.int FirstRow,  
    System.int LastRow,  
    System.int FirstColumn,  
    System.int LastColumn  
)
```

C++/CLI

```
void SetCellRange(  
& System.int FirstRow,  
& System.int LastRow,  
& System.int FirstColumn,  
& System.int LastColumn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FirstRow
First row in the range

LastRow
Last row in the range

FirstColumn
First column in the range

LastColumn
Last column in the range

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetCellRange](#).

Remarks

The index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellRange Method](#)
[ITableAnnotation::SetCellRange Method](#)
[ITableAnnotation::GetCellTextFormat Method](#)

[ITableAnnotation::GetCellUseDocTextFormat Method](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::IsCellTextEditable Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::SetCellTextFormat Method](#)
[ITableAnnotation::UnmergeCells Method](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)
[ITableAnnotation::DisplayedText Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCellTextFormat Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetCellTextFormat Method (ITableAnnotation)

Sets the text format for the text in the specified cell.

.NET Syntax

Visual Basic (Declaration)

```
Function SetCellTextFormat( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer, _  
    ByVal UseDoc As System.Boolean, _  
    ByVal TextFormat As TextFormat _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim UseDoc As System.Boolean  
Dim TextFormat As TextFormat  
Dim value As System.Boolean  
  
value = instance.SetCellTextFormat(Row, Column, UseDoc, TextFormat)
```

C#

```
System.bool SetCellTextFormat(  
    System.int Row,  
    System.int Column,  
    System.bool UseDoc,  
    TextFormat TextFormat  
)
```

C++/CLI

```
System.bool SetCellTextFormat(  
& System.int Row,  
& System.int Column,  
& System.bool UseDoc,  
& TextFormat^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Index of row in which cell resides

Column

Index of column in which cell resides

UseDoc

True to use the document setting for the text format, false to not

TextFormat

[ITextFormat](#) object

Return Value

True if the text format is set, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetCellTextFormat](#).

Remarks

The index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellRange Method](#)
[ITableAnnotation::GetCellTextFormat Method](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::IsCellTextEditable Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::SetCellRange Method](#)
[ITableAnnotation::UnmergeCells Method](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)
[ITableAnnotation::TextHorizontalJustification Property](#)
[ITableAnnotation::TextVerticalJustification Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCellTextOrientation Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetCellTextOrientation Method (ITableAnnotation)

Sets the text orientation in the specified table cell.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCellTextOrientation( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer, _  
    ByVal IncludeHidden As System.Boolean, _  
    ByVal AllCells As System.Boolean, _  
    ByVal Orientation As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim AllCells As System.Boolean  
Dim Orientation As System.Integer  
  
instance.SetCellTextOrientation(Row, Column, IncludeHidden, AllCells, Orientation)
```

C#

```
void SetCellTextOrientation(  
    System.int Row,  
    System.int Column,  
    System.bool IncludeHidden,  
    System.bool AllCells,  
    System.int Orientation  
)
```

C++/CLI

```

void SetCellTextOrientation(
& System.int Row,
& System.int Column,
& System.bool IncludeHidden,
& System.bool AllCells,
& System.int Orientation
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
0-based index of row; valid only if AllCells is set to false
Column
0-based index of column; valid only if AllCells is set to false
IncludeHidden
True to include hidden rows and columns in the Row and Column indexes, false to not
AllCells
True for all cells, false if not; if false, set Row and Column
Orientation
Text orientation as defined in [swTableCellOrientation_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetCellTextOrientation](#).

Remarks

You can set Orientation to any member of swTableCellOrientation_e except swTableCellOrientation_Varies.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetCellTextOrientation Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetColumnTitle Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetColumnTitle Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::SetColumnTitle2](#).

.NET Syntax

Visual Basic (Declaration)

```

Function SetColumnTitle( _
    ByVal Index As System.Integer, _
    ByVal Title As System.String _
) As System.Boolean

```

Visual Basic (Usage)

```

Dim instance As ITableAnnotation
Dim Index As System.Integer
Dim Title As System.String
Dim value As System.Boolean

value = instance.SetColumnTitle(Index, Title)

```

C#



```
System.bool SetColumnTitle(  
    System.int Index,  
    System.string Title  
)
```

C++/CLI

```
System.bool SetColumnTitle(  
& System.int Index,  
& System.String^ Title  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the column whose title to set
Title
Column title

Return Value

True if title is set, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetColumnTitle](#).

Remarks

The index for both rows and columns is 0-based.
False is returned if the table does not have a header enabled. The title cannot be set to empty text.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnTitle Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::SetColumnWidth Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method \(\)](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetColumnTitle2 Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetColumnTitle2 Method (ITableAnnotation)

Sets the title of the specified column.

.NET Syntax

Visual Basic (Declaration)

```
Function SetColumnTitle2( _  
    ByVal Index As System.Integer, _  
    ByVal Title As System.String, _  
    ByVal IncludeHidden As System.Boolean _  
) As System.Boolean
```

```

Dim instance As ITableAnnotation
Dim Index As System.Integer
Dim Title As System.String
Dim IncludeHidden As System.Boolean
Dim value As System.Boolean

value = instance.SetColumnTitle2(Index, Title, IncludeHidden)

```

C#

```

System.bool SetColumnTitle2(
    System.int Index,
    System.string Title,
    System.bool IncludeHidden
)

```

C++/CLI

```

System.bool SetColumnTitle2(
    & System.int Index,
    & System.String^ Title,
    & System.bool IncludeHidden
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the column whose title to set

Title

Column title

IncludeHidden

True to set the hidden column title, false to not

Return Value

True if title is set, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetColumnTitle2](#).

Remarks

The index for both rows and columns is 0-based.

False is returned if the table does not have a header enabled. The title cannot be set to empty text.

See Also

[ITableAnnotation Interface](#)

[ITableAnnotation Members](#)

[ITableAnnotation::GetColumnTitle2 Method \(\)](#)

[ITableAnnotation::SetColumnType2 Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SetColumnType Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetColumnType Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::SetColumnType2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetColumnType( _  
    ByVal Index As System.Integer, _  
    ByVal Type As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim Type As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetColumnType(Index, Type)
```

C#

```
System.bool SetColumnType(  
    System.int Index,  
    System.int Type  
)
```

C++/CLI

```
System.bool SetColumnType(  
& System.int Index,  
& System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the column whose type to set

Type

Column type as defined by [swTableColumnTypes_e](#)

Return Value

True if column type is set, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetColumnType](#).

Remarks

The index for both rows and columns is 0-based.

When you set a column type, the title is automatically changed to match that column type. If you change the column type to be a custom proper column, then the column title is empty and you must set the column title using [ITableAnnotation::SetColumnTitle](#).

A BOM table column cannot be changed to a Quantity type column in the SOLIDWORKS Design user interface. This method is consistent with the user interface and should return a failure; that is, a value < 0.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnTitle Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnTitle Method](#)
[ITableAnnotation::SetColumnWidth Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method \(\)](#)

Availability

SetColumnType2 Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetColumnType2 Method (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::SetColumnType3](#).

.NET Syntax

Visual Basic (Declaration)

```

Function SetColumnType2( _
    ByVal Index As System.Integer, _
    ByVal Type As System.Integer, _
    ByVal IncludeHidden As System.Boolean _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As ITableAnnotation
Dim Index As System.Integer
Dim Type As System.Integer
Dim IncludeHidden As System.Boolean
Dim value As System.Boolean

value = instance.SetColumnType2(Index, Type, IncludeHidden)

```

C#

```

System.bool SetColumnType2(
    System.int Index,
    System.int Type,
    System.bool IncludeHidden
)

```

C++/CLI

```

System.bool SetColumnType2(
    & System.int Index,
    & System.int Type,
    & System.bool IncludeHidden
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the column whose type to set

Type

Column type as defined by [swTableColumnTypes_e](#)

IncludeHidden

True to set the hidden column type, false to not

Return Value

True if column type is set, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetColumnType2](#).

Example

[Insert Column in BOM Table \(VBA\)](#)
[Insert Column in BOM Table \(VB.NET\)](#)
[Insert Column in BOM Table \(C#\)](#)

Remarks

The index for both rows and columns is 0-based.

When you set a column type, the title is automatically changed to match that column type. If you change the column type to be a custom property column, then the column title is empty and you must set the column title using [ITableAnnotation::SetColumnTitle2](#).

A BOM table column cannot be changed to a Quantity type column in the SOLIDWORKS Design user interface. This method is consistent with the user interface.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetColumnType2 Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetColumnType3 Method (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetColumnType3 Method (ITableAnnotation)

Sets the type and property data for the specified BOM table column.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetColumnType3(  
    ByVal Index As System.Integer, _  
    ByVal ColumnType As System.Integer, _  
    ByVal IncludeHidden As System.Boolean, _  
    ByVal PropertyData As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim ColumnType As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim PropertyData As System.Object  
Dim value As System.Integer  
  
value = instance.SetColumnType3(Index, ColumnType, IncludeHidden, PropertyData)
```

C#

```
System.int SetColumnType3(  
    System.int Index,  
    System.int ColumnType,  
    System.bool IncludeHidden,  
    System.object PropertyData  
)
```

C++/CLI

```
System.int SetColumnType3(  
& System.int Index,  
& System.int ColumnType,  
& System.bool IncludeHidden,  
& System.Object^ PropertyData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of the column whose type to set

ColumnType
Type of column as defined in [swTableColumnTypes](#) [e](#) (see **Remarks**)
IncludeHidden
True to include hidden columns in Index, false to not
PropertyData
Property data specific to ColumnType (see **Remarks**)

Return Value

Return code as defined in [swColumnTypeStatus](#) [e](#)

 Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetColumnType3](#).

 Example

[Get and Set BOM Column Types and Cell Equations \(VBA\)](#)

 Remarks

PropertyData specifies the column title and contents.

If ColumnType is set to swTableColumnTypes_e....	Then Set PropertyData with...
swBomTableColumnType_CustomProperty	Valid property name*
swBomTableColumnType_UnitOfMeasure	Valid property name*
swBomTableColumnType_Equation	Equation string
swBomTableColumnType_ComponentReference	Null or Nothing
swBomTableColumnType_ToolboxProperty	Property as defined in swToolBoxPropertyName e
swBomTableColumnType_CutListProperties (valid only for sheetmetal parts)	Valid cutlist property name*
swBomTableColumnType_ItemNumber	Array of four values {Start_Item_Int, Increment_Int, Order_balloons_and_BOM_to_follow_assembly_order_Boolean, Do_not_change_BOM_item_number_Boolean}
swBomTableColumnType_PartNumber	True to use title summary, false to not

* Note: To get the valid property names for a given column type, open a part in SOLIDWORKS and add a BOM table to it. Right-click a column and select **Insert > Column Right**. In the popup, select the column type of interest in the first dropdown. Inspect the contents of the second dropdown to see the valid property names for the column type.

When you set a column type, the title is automatically changed to match that column type. If you change the column type to custom property, you must set the column title using [ITableAnnotation::SetColumnTitle2](#).

This method is consistent with the SOLIDWORKS Design user interface where you cannot add, delete, or replace the Quantity type column in a BOM table.

 See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetColumnType3 Method \(\)](#)
[ITableAnnotation::SetCellEquation Method \(\)](#)

 Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetColumnWidth Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetColumnWidth Method (ITableAnnotation)

Sets the width of the specified column in this table.

 .NET Syntax

Visual Basic (Declaration)

```
Function SetColumnWidth(  
    ByVal Index As System.Integer, _  
    ByVal Width As System.Double, _  
    ByVal Options As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```

Dim instance As ITableAnnotation
Dim Index As System.Integer
Dim Width As System.Double
Dim Options As System.Integer
Dim value As System.Double

value = instance.SetColumnWidth(Index, Width, Options)

```

C#

```

System.double SetColumnWidth(
    System.int Index,
    System.double Width,
    System.int Options
)

```

C++/CLI

```

System.double SetColumnWidth(
    & System.int Index,
    & System.double Width,
    & System.int Options
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of column for which to set the width

Width

Width at which to set specified column, in system units

Options

Table's behavior after changing column width as defined by [swTableRowColSizeChangeBehavior_e](#) (see **Remarks**)

Return Value

Width at which specified column is set (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetColumnWidth](#).

Remarks

Index is the column number for which to set the width. Thus, the first column is column 0. It can also be a value from the [swTableCellRangeIdentifier_e](#) enumerator.

If Index equals...	Then the width of all of the columns...
swTableCellRange_All	Is set, if possible.
swTableCellRange_Current	In the current range (see ITableAnnotation::GetCellRange and ITableAnnotation::SetCellRange) is set, if possible.

When the width of a column changes, the rest of the table is affected. The Options argument indicates how the rest of the table should behave.

If...	Then...
Options = swTableRowColChange_TableSizeCanChange	The rest of the columns remain the same width and are shifted away from the table anchor to make room for the changed column.
Width of the entire table must remain the same, so that the table continues to fit properly on the drawing	Other columns must absorb the change in width. There are two possibilities supported by this method. If Options = swTableRowColChange_AbsorbedByNext, then the first column to the right of the columns whose width has changed, is adjusted if possible. If that is not possible, then the first column to the left of the columns whose width has changed, is adjusted if possible. If that is not possible either, then no action is taken.

- The other similar case is if Options = swTableRowColChange_AbsorbedByPrevious. First the column to the left is tried, then the column to the right.

Options =
swTableRowColChange_AbsorbedByNext or
swTableRowColChange_AbsorbedByPrevious

It may not be possible to get the desired results. If this is the case, you must determine the full width of the table yourself and set row widths individually using the swTableRowColChange_TableSizeCanChange option, making sure to end up with the original table width.

The return value is the width that the column is set to. If you specified a range of columns, it is the width of the first column of that range.

It is possible that the return value is different than the width value that you passed in. One possibility is that if you specify a column width that is less than the minimum column width, the minimum column width is used, instead of what you specified. Another possibility is that if you are trying to maintain a fixed table width, but the width of the adjacent columns is not big enough to absorb the width changes to the columns that you specified, then the return value is the same as the column's original width instead of what you specified.

To get the column width, use [ITableAnnotation::GetColumnWidth](#).

To get or set the row height, use [ITableAnnotation::GetRowHeight](#) and [ITableAnnotation::SetRowHeight](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnName Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnName Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::TotalColumnCount Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetHeader Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetHeader Method (ITableAnnotation)

Sets the header for this table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetHeader( _
    ByVal Style As System.Integer, _
    ByVal Count As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim Style As System.Integer
Dim Count As System.Integer
Dim value As System.Boolean
```

```
value = instance.SetHeader(Style, Count)
```

C#

```
System.bool SetHeader(
    System.int Style,
    System.int Count
)
```

C++/CLI

```
System.bool SetHeader(  
& System.int Style,  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Header style as defined in [swTableHeaderPosition_e](#)

Count

Number of lines in the header

Return Value

True if header is set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetHeader](#).

Remarks

Tables created internally by the SOLIDWORKS Design software, such as Hole Charts, Revision Blocks, and BOM tables, are created with a specific number of headers lines.

This method cannot:

- Change the number of lines in the header for these tables; thus, the Count argument is ignored.
- Turn off the header in these types of tables; thus, this method has no effect, and FALSE is returned.

Essentially, the only thing this method can do with these types of tables is to change the header between the top and the bottom.

If you are changing the header style and number of header lines in a single use of this method, the number of lines is considered before changing the header style. For example, if you are changing a table that had 1 header line at the top, by calling SetHeader (swTableHeader_Bottom, 3), the first 3 lines in the table are moved to the bottom of the table.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetHeaderCount Method](#)
[ITableAnnotation::GetHeaderStyle Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLockColumnWidth Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetLockColumnWidth Method (ITableAnnotation)

Sets whether to lock the width of the specified column in this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLockColumnWidth( _  
    ByVal Index As System.Integer, _  
    ByVal LockColumnWidth As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim LockColumnWidth As System.Boolean  
Dim value As System.Boolean
```



```
value = instance.SetLockColumnWidth(Index, LockColumnWidth)
```

C#

```
System.bool SetLockColumnWidth(  
    System.int Index,  
    System.bool LockColumnWidth  
)
```

C++/CLI

```
System.bool SetLockColumnWidth(  
& System.int Index,  
& System.bool LockColumnWidth  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of the column (see **Remarks**)

LockColumnWidth

True to lock this column's width, false to not

Return Value

True if setting whether to lock the width of the specified column is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetLockColumnWidth](#).

Remarks

Call [ITableAnnotation::ColumnCount](#) to get the number of visible columns or [ITableAnnotation::TotalColumnCount](#) to get the number of visible and hidden columns in this table annotation.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetLockColumnWidth Method \(\)](#)
[ITableAnnotation::DeleteColumn Method \(\)](#)
[ITableAnnotation::GetColumnTitle Method \(\)](#)
[ITableAnnotation::GetColumnType Method \(\)](#)
[ITableAnnotation::GetColumnWidth Method \(\)](#)
[ITableAnnotation::InsertColumn2 Method \(\)](#)
[ITableAnnotation::MoveColumn Method \(\)](#)
[ITableAnnotation::SetColumnTitle Method \(\)](#)
[ITableAnnotation::SetColumnType Method \(\)](#)
[ITableAnnotation::SetColumnWidth Method \(\)](#)
[ITableAnnotation::ColumnHidden Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLockRowHeight Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetLockRowHeight Method (ITableAnnotation)

Sets whether to lock the height of the specified row in this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLockRowHeight( _  
    ByVal Index As System.Integer, _  
    ByVal LockRowHeight As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation
Dim Index As System.Integer
Dim LockRowHeight As System.Boolean
Dim value As System.Boolean

value = instance.SetLockRowHeight(Index, LockRowHeight)
```

C#

```
System.bool SetLockRowHeight(
    System.int Index,
    System.bool LockRowHeight
)
```

C++/CLI

```
System.bool SetLockRowHeight(
    & System.int Index,
    & System.bool LockRowHeight
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0-based index of the row (see **Remarks**)
LockRowHeight
True to lock this row's height, false to not

Return Value

True if setting whether to lock the height of the specified row is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetLockRowHeight](#).

Remarks

Call [ITableAnnotation::RowCount](#) to get the number of visible rows or [ITableAnnotation::TotalRowCount](#) to get the number of visible and hidden rows in this table annotation.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetLockRowHeight Method \(\)](#)
[ITableAnnotation::DeleteRow Method \(\)](#)
[ITableAnnotation::GetRowHeight Method \(\)](#)
[ITableAnnotation::GetRowVerticalGap Method \(\)](#)
[ITableAnnotation::InsertRow Method \(\)](#)
[ITableAnnotation::MoveRow Method \(\)](#)
[ITableAnnotation::SetRowHeight Method \(\)](#)
[ITableAnnotation::SetRowVerticalGap Method \(\)](#)
[ITableAnnotation::RowHidden Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRowHeight Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetRowHeight Method (ITableAnnotation)

Sets the height of the specified row in this table.

.NET Syntax

Visual Basic (Declaration)


```
Function SetRowHeight( _
    ByVal Index As System.Integer, _
    ByVal Height As System.Double, _
    ByVal Options As System.Integer _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim Index As System.Integer
Dim Height As System.Double
Dim Options As System.Integer
Dim value As System.Double

value = instance.SetRowHeight(Index, Height, Options)
```

C#

```
System.double SetRowHeight(
    System.int Index,
    System.double Height,
    System.int Options
)
```

C++/CLI

```
System.double SetRowHeight(
    & System.int Index,
    & System.double Height,
    & System.int Options
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of row for which to set height

Height
Height at which to set specified row, in system units

Options
Table's behavior after changing row as defined by [swTableRowColSizeChangeBehavior_e](#) (see **Remarks**)

Return Value

Height to which specified row is set (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetRowHeight](#).

Remarks

The index for both rows and columns is 0-based.

Index is the number of the row whose height to set. The first row is row 0. It can also be a value from the [swTableCellRangeIdentifier_e](#) enumerator.

If Index equals...	Then the height of all of the rows...
swTableCellRange_All	Is set, if possible.
swTableCellRange_Current	In the current range (see ITableAnnotation::GetCellRange and ITableAnnotation::SetCellRange) is set, if possible

When the height of a row changes, then the rest of the table is affected. The Options argument indicates the rest of the table's behavior.

If...	Then...
Options = swTableRowColChange_TableSizeCanChange	The rest of the rows remain the same height and are shifted away from the table anchor to make room for the changed row.

Height of the entire table must remain the same, so that the table continues to fit properly on the drawing

Other rows must absorb the change in height. There are two possibilities supported by this method.

- If Options = `swTableRowColChange_AbsorbedByNext`, then first row below the rows whose height has changed, are adjusted if possible. If that is not possible, then the first row above the rows whose height has changed, is adjusted if possible. If that is not possible either, then no action is taken.
- The other similar case is if Options = `swTableRowColChange_AbsorbedByPrevious`. First the row above is tried, then the row below.

Options = `swTableRowColChange_AbsorbedByNext` or `swTableRowColChange_AbsorbedByPrevious`

It might not be possible to get the desired results. If this is the case, then you must determine the full height of the table yourself and set row heights individually using the `swTableRowColChange_TableSizeCanChange` option, making sure to end up with the original table height.

The return value is the height at which the row is set. If you specified a range of rows, it is the height of the first row of that range.

It is possible that the return value is different than the value that you passed in. One possibility is that if you specify a row height that is less than the minimum row height, then the minimum row height is used instead of what you specified. Another possibility is that if you are trying to maintain a fixed table height, but the height of the adjacent rows is not big enough to absorb the height changes to the rows that you specified, then the return value is the same as the row's original width instead of what you specified.

To get the row height, use [ITableAnnotation::GetRowHeight](#).

To get or set the column width, use [ITableAnnotation::GetColumnWidth](#) and [ITableAnnotation::SetColumnWidth](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteRow Method](#)
[ITableAnnotation::GetRowVerticalGap Method](#)
[ITableAnnotation::InsertRow Method](#)
[ITableAnnotation::MoveRow Method](#)
[ITableAnnotation::SetRowVerticalGap Method](#)
[ITableAnnotation::RowCount Property](#)
[ITableAnnotation::TotalRowCount Property](#)
[ITableAnnotation::RowHidden Property](#)
[ITableAnnotation::GetLockRowHeight Method](#)
[ITableAnnotation::SetLockRowHeight Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRowVerticalGap Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetRowVerticalGap Method (ITableAnnotation)

Sets the gap between the text and the top or bottom of the specified row of this table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetRowVerticalGap( _  
    ByVal Index As System.Integer, _  
    ByVal Gap As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Index As System.Integer  
Dim Gap As System.Double  
Dim value As System.Boolean  
  
value = instance.SetRowVerticalGap(Index, Gap)
```

C#

```
System.bool SetRowVerticalGap(  
    System.int Index,  
    System.double Gap  
)
```

C++/CLI

```
System.bool SetRowVerticalGap(  
& System.int Index,  
& System.double Gap  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of row for which to get the height
Gap
Gap in system units

Return Value

True if the gap is set, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetRowVerticalGap](#).

Remarks

Use [ITableAnnotation::GetRowVerticalGap](#) to get the size of the gap.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteRow Method](#)
[ITableAnnotation::GetRowHeight Method](#)
[ITableAnnotation::InsertRow Method](#)
[ITableAnnotation::MoveRow Method](#)
[ITableAnnotation::SetRowHeight Method](#)
[ITableAnnotation::RowCount Property](#)
[ITableAnnotation::TotalRowCount Property](#)
[ITableAnnotation::RowHidden Property](#)
[ITableAnnotation::GetLockRowHeight Method](#)
[ITableAnnotation::SetLockRowHeight Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextFormat Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : SetTextFormat Method (ITableAnnotation)

Sets the text format for this table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextFormat( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal TextFormat As TextFormat _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation  
Dim UseDoc As System.Boolean
```



```
Dim TextFormat As TextFormat
Dim value As System.Boolean

value = instance.SetTextFormat(UseDoc, TextFormat)
```

C#

```
System.bool SetTextFormat(
    System.bool UseDoc,
    TextFormat TextFormat
)
```

C++/CLI

```
System.bool SetTextFormat(
    & System.bool UseDoc,
    & TextFormat^ TextFormat
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True to use the document setting, false to not

TextFormat

[ITextFormat](#) object

Return Value

True if the text format is set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::SetTextFormat](#).

See Also

[ITableAnnotation Interface](#)

[ITableAnnotation Members](#)

[ITableAnnotation::GetTextFormat Method](#)

[ITableAnnotation::GetUseDocTextFormat Method](#)

[ITableAnnotation::Text Property](#)

[ITableAnnotation::TextHorizontalJustification Property](#)

[ITableAnnotation::TextVerticalJustification Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Split Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : Split Method (ITableAnnotation)

Splits the table at the specified location.

.NET Syntax

Visual Basic (Declaration)

```
Function Split( _
    ByVal Where As System.Integer, _
    ByVal Index As System.Integer _
) As TableAnnotation
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation
Dim Where As System.Integer
Dim Index As System.Integer
Dim value As TableAnnotation
```



```
value = instance.Split(Where, Index)
```

C#

```
TableAnnotation Split(  
    System.int Where,  
    System.int Index  
)
```

C++/CLI

```
TableAnnotation^ Split(  
& System.int Where,  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Where

Where to split the table as defined in [swTableSplitLocations_e](#)

Index

Index of the row or column as specified in Where to split the table (see **Remarks**)

Return Value

Newly created [ITableAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::Split](#).

Remarks

The index for both rows and columns is 0-based.

The indexes for the rows and columns always correspond to the rows and columns of the table from which the split table originates.

See Also

[ITableAnnotation Interface](#)

[ITableAnnotation Members](#)

[ITableAnnotation::IsCellMerged Method](#)

[ITableAnnotation::Merge Method](#)

[ITableAnnotation::MergeCells Method](#)

[ITableAnnotation::UnmergeCells Method](#)

[ITableAnnotation::GetSplitInformation Method](#)

[ITableAnnotation::HorizontalAutoSplit Method \(\)](#)

[ITableAnnotation::StopAutoSplitting Property \(\)](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StopAutoSplitting Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : StopAutoSplitting Property (ITableAnnotation)

Stops the automatic horizontal splitting of this table.

.NET Syntax

Visual Basic (Declaration)

Property StopAutoSplitting As System.Boolean

Visual Basic (Usage)



Copy Code

```
Dim instance As ITableAnnotation
Dim value As System.Boolean

instance.StopAutoSplitting = value

value = instance.StopAutoSplitting
```

C#

```
System.bool StopAutoSplitting {get; set;}
```

C++/CLI

```
property System.bool StopAutoSplitting {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to stop the automatic horizontal splitting of this table, false to not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::StopAutoSplitting](#).

Remarks

This property works with [ITableAnnotation::HorizontalAutoSplit](#) to control the automatic horizontal splitting of:

- [Hole tables](#)
- [Bill of Materials tables](#)
- [General tables](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::Split Method \(\)](#)
[ITableAnnotation::GetSplitInformation Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Text Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : Text Property (ITableAnnotation)

Obsolete. Superseded by [ITableAnnotation::Text2](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Text( _
    ByVal Row As System.Integer, _
    ByVal Column As System.Integer _
) As System.String
```

Visual Basic (Usage)

```
Dim instance As ITableAnnotation
Dim Row As System.Integer
Dim Column As System.Integer
Dim value As System.String
```



```
instance.Text(Row, Column) = value
```

```
value = instance.Text(Row, Column)
```

C#

```
System.string Text(  
    System.int Row,  
    System.int Column  
) {get; set;}
```

C++/CLI

```
property System.String^ Text {  
    System.String^ get(System.int Row, System.int Column);  
    void set (System.int Row, System.int Column, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Index of the row

Column

Index of the column

Property Value

Cell text

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::Text](#).

Example

[Get Table Annotation and Contents \(VBA\)](#)

[Insert Hole Table \(VBA\)](#)

Remarks

Index for both rows and columns is 0-based.

This property returns the string that drives the text displayed in the specified cell. For example, the string returned by this property would be the parameter string if the cell is linked to a dimension value or custom property. To get the text actually displayed in the cell, use [ITableAnnotation::DisplayedText](#).

Table annotation:

- [BOM](#): All cells are editable.
- [General](#): All cells are editable.
- [Hole](#): Only some columns are editable because some information is automatically generated, thus, that information cannot be edited. The header row and custom columns are editable.
- [Revision](#): All cells are editable

You might experience decreased performance when updating the text in multiple cells in large tables because the table is rebuilt after changing the text in a cell. To increase performance while updating the text in large tables:

1. Set [IAnnotation::Visible](#) to false. (The table is not rebuilt while the table is hidden.)
2. Update the text in the table cells.
3. Set [IAnnotation::Visible](#) to true.

See Also

[ITableAnnotation Interface](#)

[ITableAnnotation Members](#)

[ITableAnnotation::GetCellTextFormat Method](#)

[ITableAnnotation::GetCellUseDocTextFormat Method](#)

[ITableAnnotation::GetTextFormat Method](#)

[ITableAnnotation::GetUseDocTextFormat Method](#)

[ITableAnnotation::IsCellTextEditable Method](#)

[ITableAnnotation::SetCellTextFormat Method](#)

[ITableAnnotation::SetTextFormat Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Text2 Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : Text2 Property (ITableAnnotation)

Gets or sets the parametrized string of text for the specified cell of this table.

.NET Syntax

Visual Basic (Declaration)

```
Property Text2( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer, _  
    ByVal IncludeHidden As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim IncludeHidden As System.Boolean  
Dim value As System.String  
  
instance.Text2(Row, Column, IncludeHidden) = value  
value = instance.Text2(Row, Column, IncludeHidden)
```

C#

```
System.string Text2(  
    System.int Row,  
    System.int Column,  
    System.bool IncludeHidden  
) {get; set;}
```

C++/CLI

```
property System.String^ Text2 {  
    System.String^ get(System.int Row, System.int Column, System.bool IncludeHidden);  
    void set (System.int Row, System.int Column, System.bool IncludeHidden, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
Index of the row
Column
Index of the column
IncludeHidden
True to get or set text in the hidden cell, false to not

Property Value

Cell text

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::Text2](#).

Example

[Insert BOM Table and Extract Data \(VBA\)](#)
[Insert BOM Table and Extract Data \(VB.NET\)](#)
[Insert BOM Table and Extract Data \(C#\)](#)

Remarks

Index for both rows and columns is 0-based.

This property returns the string that drives the text displayed in the specified cell. For example, the string returned by this property would be the parameter string if the cell is linked to a dimension value or custom property. To get the text actually displayed in the cell, use [ITableAnnotation::DisplayedText2](#).

Table annotation:

- [BOM](#): All cells are editable.
- [General](#): All cells are editable.
- [Hole](#): Only columns that are not automatically generated are editable. The header row and custom columns are editable.
- [Revision](#): All cells are editable

You might experience decreased performance when updating the text in multiple cells in large tables, because the table automatically rebuilds each time you change the text in a cell. To increase performance while updating the text in large tables:

1. Set [IAnnotation::Visible](#) to false. (The table is not rebuilt while the table is hidden.)
2. Update the text in the table cells.
3. Set [IAnnotation::Visible](#) to true.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextHorizontalJustification Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : TextHorizontalJustification Property (ITableAnnotation)

Gets or sets the horizontal justification setting for the text in this table.

.NET Syntax

Visual Basic (Declaration)

Property TextHorizontalJustification As System.Integer

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim value As System.Integer

instance.TextHorizontalJustification = value

value = instance.TextHorizontalJustification
```

C#

```
System.int TextHorizontalJustification {get; set;}
```

C++/CLI

```
property System.int TextHorizontalJustification {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Horizontal justification as defined in [swTextJustification_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::TextHorizontalJustification](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::TextVerticalJustification Property](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TextVerticalJustification Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : TextVerticalJustification Property (ITableAnnotation)

Gets or sets the vertical justification for the text in this table.

.NET Syntax

Visual Basic (Declaration)

Property TextVerticalJustification As System.Integer

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim value As System.Integer

instance.TextVerticalJustification = value
value = instance.TextVerticalJustification
```

C#

```
System.int TextVerticalJustification {get; set;}
```

C++/CLI

```
property System.int TextVerticalJustification {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Vertical justification as defined by [swTextAlignmentVertical_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::TextVerticalJustification](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::TextHorizontalJustification Property](#)
[ITableAnnotation::CellTextHorizontalJustification Property](#)
[ITableAnnotation::CellTextVerticalJustification Property](#)

Availability

Title Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : Title Property (ITableAnnotation)

Gets or sets the title for this table.

.NET Syntax

Visual Basic (Declaration)

Property Title As System.String

Visual Basic (Usage)



```
Dim instance As ITableAnnotation
Dim value As System.String
```

```
instance.Title = value
```

```
value = instance.Title
```

C#

```
System.string Title {get; set;}
```

C++/CLI

```
property System.String^ Title {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for title of table

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::Title](#).

Example

[Get Components for Each BOM Table Row \(VBA\)](#)
[Export BOMs to XML \(C#\)](#)
[Export BOMs to XML \(VB.NET\)](#)
[Export BOMs to XML \(VBA\)](#)

Remarks

You can set the title of the table even if the title is not currently visible. See [ITableAnnotation::TitleVisible](#) for details.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

TitleVisible Property (ITableAnnotation)

[See Also](#)



Gets or sets whether the title of the table is visible.

.NET Syntax

Visual Basic (Declaration)

```
Property TitleVisible As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Boolean
```

```
instance.TitleVisible = value
```

```
value = instance.TitleVisible
```

C#

```
System.bool TitleVisible {get; set;}
```

C++/CLI

```
property System.bool TitleVisible {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if title of the table is visible, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::TitleVisible](#).

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::Title Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TotalColumnCount Property (ITableAnnotation)

See Also [Example](#)



Gets the total number of visible and hidden columns in this table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TotalColumnCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer
```

```
value = instance.TotalColumnCount
```

C#

```
System.int TotalColumnCount {get;}
```

C++/CLI

```
property System.int TotalColumnCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Total number of visible and hidden columns in this table

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::TotalColumnCount](#).

Example

[Get the Total Number of Columns and Rows in a Table \(VBA\)](#)
[Get the Total Number of Columns and Rows in a Table \(VB.NET\)](#)
[Get the Total Number of Columns and Rows in a Table \(C#\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteColumn Method](#)
[ITableAnnotation::GetColumnName Method](#)
[ITableAnnotation::GetColumnType Method](#)
[ITableAnnotation::GetColumnWidth Method](#)
[ITableAnnotation::InsertColumn2 Method](#)
[ITableAnnotation::MoveColumn Method](#)
[ITableAnnotation::SetColumnName Method](#)
[ITableAnnotation::SetColumnType Method](#)
[ITableAnnotation::SetColumnWidth Method](#)
[ITableAnnotation::ColumnCount Property](#)
[ITableAnnotation::ColumnHidden Property](#)
[ITableAnnotation::GetLockColumnWidth Method](#)
[ITableAnnotation::SetLockColumnWidth Method](#)

Availability

SOLIDWORKS 2011 SP05, Revision Number 19.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

TotalRowCount Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : TotalRowCount Property (ITableAnnotation)

Gets the total number of visible and hidden rows in this table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TotalRowCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer  
  
value = instance.TotalRowCount
```

C#

```
System.int TotalRowCount {get;}
```

C++/CLI

```
property System.int TotalRowCount {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Total number of visible and hidden rows in this table

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::TotalRowCount](#).

Example

[Get the Total Number of Columns and Rows in a Table \(C#\)](#)
[Get the Total Number of Columns and Rows in a Table \(VB.NET\)](#)
[Get the Total Number of Columns and Rows in a Table \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::DeleteRow Method](#)
[ITableAnnotation::GetRowHeight Method](#)
[ITableAnnotation::GetRowVerticalGap Method](#)
[ITableAnnotation::InsertRow Method](#)
[ITableAnnotation::MoveRow Method](#)
[ITableAnnotation::SetRowHeight Method](#)
[ITableAnnotation::SetRowVerticalGap Method](#)
[ITableAnnotation::RowCount Property](#)
[ITableAnnotation::RowHidden Property](#)
[ITableAnnotation::GetLockRowHeight Method](#)
[ITableAnnotation::SetLockRowHeight Method](#)

Availability

SOLIDWORKS 2011 SP05, Revision Number 19.5

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (ITableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : Type Property (ITableAnnotation)

Gets the type of table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer
```

```
value = instance.Type
```

C#

```
System.int Type {get;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of table as defined in [swTableAnnotationType_e](#)

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::Type](#).

Example

[Get Table Annotation and Contents \(VBA\)](#)
[Insert Column in BOM Table \(C#\)](#)
[Insert Column in BOM Table \(VB.NET\)](#)
[Insert Column in BOM Table \(VBA\)](#)

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revisoin Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UnmergeCells Method (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : UnmergeCells Method (ITableAnnotation)

Splits the specified previously merged cell in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function UnmergeCells( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim Row As System.Integer  
Dim Column As System.Integer  
Dim value As System.Boolean  
  
value = instance.UnmergeCells(Row, Column)
```

C#

```
System.bool UnmergeCells(  
    System.int Row,  
    System.int Column  
)
```

C++/CLI

```
System.bool UnmergeCells(  
& System.int Row,  
& System.int Column  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
Index of the row of the cell
Column
Index of the column of the cell

Return Value

True if the cell splits successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::UnmergeCells](#).

Remarks

Index for both rows and columns is 0-based.

See Also

[ITableAnnotation Interface](#)
[ITableAnnotation Members](#)
[ITableAnnotation::GetSplitInformation Method](#)
[ITableAnnotation::IsCellMerged Method](#)
[ITableAnnotation::Merge Method](#)
[ITableAnnotation::MergeCells Method](#)
[ITableAnnotation::Split Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UpperCase Property (ITableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITableAnnotation Interface](#) : UpperCase Property (ITableAnnotation)

Gets or sets whether text in the table is all upper case.

.NET Syntax

Visual Basic (Declaration)

Property UpperCase As System.Integer

Visual Basic (Usage)



```
Dim instance As ITableAnnotation  
Dim value As System.Integer
```

```
instance.UpperCase = value
```

```
value = instance.UpperCase
```

C#

```
System.int UpperCase {get; set;}
```

C++/CLI

```
property System.int UpperCase {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

1 if text is all upper case, 0 if not

Visual Basic for Applications (VBA) Syntax

See [TableAnnotation::UpperCase](#).

See Also

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0