

# SOLIDWORKS API (.NET, VBA, C#) — Reference

## (310/337): ITablePatternFeatureData- ITaperedTapElementData

SOLIDWORKS API Documentation (converted from CHM)

# ITablePatternFeatureData (Type)

## ITablePatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITablePatternFeatureData Interface

Allows access to a table-driven pattern feature.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

#### Visual Basic (Declaration)

Public Interface ITablePatternFeatureData

#### Visual Basic (Usage)

Dim instance As [ITablePatternFeatureData](#)

#### C#

public interface ITablePatternFeatureData

#### C++/CLI

public interface class ITablePatternFeatureData

### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData](#).

### Example

```
'VBA
' *****
' 1. Open public_documents\samples\tutorial\api\tablepattern.sldprt.
' 2. Delete TPattern1.
' 3. Run the macro.
' 4. Creates a new TPattern1.
' 5. Inspect the FeatureManager design tree and the graphics area.
' *****

Dim swApp As SldWorks.SldWorks
Dim swFeatData As TablePatternFeatureData
Dim Part As SldWorks.ModelDoc2
Dim swFeat As Feature
Dim swFeatMgr As FeatureManager
Dim boolstatus As Boolean

Option Explicit
Sub main()

    Set swApp = Application.SldWorks
    Set Part = swApp.ActiveDoc

    boolstatus = Part.Extension.SelectByID2("Coordinate System1", "COORDSYS", 0, 0, 0, True, 16, Nothing, 0)
    boolstatus = Part.Extension.SelectByID2("Cut-Extrude1", "BODYFEATURE", 0, 0, 0, True, 4, Nothing, 0)
    Part.ActivateSelectedFeature
    Dim swPointArray() As Double
    ReDim swPointArray(0 To 5) As Double
    swPointArray(0) = 0.04
    swPointArray(1) = 0
    swPointArray(2) = 0
    swPointArray(3) = -0.025
    swPointArray(4) = 0
    swPointArray(5) = 0

    Set swFeatMgr = Part.FeatureManager

    Set swFeatData = swFeatMgr.CreateDefinition(swFmTablePattern)
    swFeatData.GeometryPattern = False
```

```

swFeatData.PointArray = swPointArray
swFeatData.PropagateVisualProperty = True
swFeatData.UseCentroid = True
Set swFeat = swFeatMgr.CreateFeature(swFeatData)
End Sub

```

## Example

[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VBA\)](#)  
[Create Table Pattern \(C#\)](#)

## Remarks

Read [Pattern Features and their Feature Data Objects](#).

Before calling IFeatureManager::CreateDefinition, you must pre-select the entities needed to create the table-driven pattern feature.

| To select...      | Use mark... |
|-------------------|-------------|
| Seed feature      | 4           |
| Coordinate system | 16          |
| Reference point   | 32          |
| Seed face         | 128         |
| Seed body         | 256         |

You must call [IFeatureManager::CreateFeature](#) after initializing this feature data object in order to successfully create the table-driven pattern.

See the **Table Driven Patterns** topic in the SOLIDWORKS Design user-interface help for more information about table-driven patterns.

## Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

## Access Diagram

[TablePatternFeatureData](#)

## See Also

[ITablePatternFeatureData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ITablePatternFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITablePatternFeatureData Interface

For a list of all members of this type, see [ITablePatternFeatureData members](#).

## Public Methods

| Name                                   | Description                                                                                             |
|----------------------------------------|---------------------------------------------------------------------------------------------------------|
| <a href="#">AccessSelections</a>       | Gains access to selections used to define the table-driven pattern feature.                             |
| <a href="#">GetBasePoint</a>           | Gets the base point for this table-driven pattern feature.                                              |
| <a href="#">GetPatternBodyCount</a>    | Gets the number of seed bodies for this table-driven pattern feature.                                   |
| <a href="#">GetPatternFaceCount</a>    | Gets the number of patterned faces in this table-driven feature.                                        |
| <a href="#">GetPatternFeatureCount</a> | Gets the number of distinct seed features used to create this table-driven pattern feature.             |
| <a href="#">GetPointCount</a>          | Gets the number of x, y, and z locations of the repeating elements in this table-driven pattern.        |
| <a href="#">GetReferencePointType</a>  | Gets whether the table-driven pattern's reference point is a closed curve, a sketch point, or a vertex. |
| <a href="#">GetSkippedItemCount</a>    | Gets the number of skipped items in this table-driven pattern feature.                                  |
| <a href="#">GetTransform</a>           | Gets the transform for the specified repeating element in this table-driven pattern feature.            |

|                                                                                   |                                         |                                                                                                                                  |
|-----------------------------------------------------------------------------------|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|  | <a href="#">IAccessSelections</a>       | Obsolete. Superseded by <a href="#">ITablePatternFeatureData.IAccessSelections2</a> .                                            |
|  | <a href="#">IAccessSelections2</a>      | Gains access to selections used to define the table-driven pattern feature.                                                      |
|  | <a href="#">IGetBasePoint</a>           | Gets the base point for this table-driven pattern feature.                                                                       |
|  | <a href="#">IGetPatternBodyArray</a>    | Gets the seed bodies for this table-driven pattern feature.                                                                      |
|  | <a href="#">IGetPatternFaceArray</a>    | Gets the patterned faces in this table-driven pattern feature.                                                                   |
|  | <a href="#">IGetPatternFeatureArray</a> | Gets the seed features used to create the table-driven pattern.                                                                  |
|  | <a href="#">IGetPointArray</a>          | Gets an array of doubles that describe the x, y, and z locations of the repeating elements in this table-driven pattern feature. |
|  | <a href="#">IGetSkippedItemArray</a>    | Gets the skipped items in this table-driven pattern feature.                                                                     |
|  | <a href="#">ISetPatternBodyArray</a>    | Sets the seed bodies for this table-driven pattern feature.                                                                      |
|  | <a href="#">ISetPatternFaceArray</a>    | Sets the patterned faces for this table-driven pattern feature.                                                                  |
|  | <a href="#">ISetPatternFeatureArray</a> | Sets the seed features used to create the table-driven pattern feature.                                                          |
|  | <a href="#">ISetPointArray</a>          | Sets the points that describe the x, y, and z locations of the repeating elements in the table-driven pattern feature.           |
|  | <a href="#">ISetSkippedItemArray</a>    | Sets the skipped items in this table-driven pattern feature.                                                                     |
|  | <a href="#">LoadPointsFromFile</a>      | Loads the location points of the table-driven pattern from a *.sldptab file.                                                     |
|  | <a href="#">ReleaseSelectionAccess</a>  | Releases access to the selections that created this table-driven pattern feature.                                                |
|  | <a href="#">SavePointsToFile</a>        | Saves the location of the table-driven pattern feature's points to a *.sldptab file.                                             |

[Top](#)

## See Also

[ITablePatternFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ITablePatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITablePatternFeatureData Interface

The following tables list the members exposed by [ITablePatternFeatureData](#).

## Public Properties

| Name                                                                                                                        | Description                                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">CoordinateSystem</a>        | Gets or sets the coordinate system of the table-driven pattern feature.                                                                    |
|  <a href="#">GeometryPattern</a>         | Gets or sets whether to create the pattern using only the geometry (faces and edges) of the features for the table-driven pattern feature. |
|  <a href="#">PatternBodyArray</a>        | Gets or sets the seed bodies to pattern for this table-driven pattern feature.                                                             |
|  <a href="#">PatternFaceArray</a>        | Gets or sets the patterned faces for this table-driven pattern feature.                                                                    |
|  <a href="#">PatternFeatureArray</a>     | Gets or sets the seed features used to create the table-driven pattern feature.                                                            |
|  <a href="#">PointArray</a>              | Gets or sets the array of points that describe the x,y, and z locations of the repeating elements in the table-driven pattern feature.     |
|  <a href="#">PropagateVisualProperty</a> | Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) in the table-driven pattern feature.                    |
|  <a href="#">ReferencePoint</a>          | Gets or sets the reference point for pattern instances of this table-driven pattern feature.                                               |
|  <a href="#">SkippedItemArray</a>        | Gets or sets the skipped items for this table-driven pattern feature.                                                                      |
|  <a href="#">UseCentroid</a>             | Gets or sets whether to set the reference point to the centroid of the seed feature for this table-driven pattern feature.                 |

[Top](#)

## Public Methods

| Name                                                                                                                 | Description                                                                 |
|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
|  <a href="#">AccessSelections</a> | Gains access to selections used to define the table-driven pattern feature. |
|  <a href="#">GetBasePoint</a>     | Gets the base point for this table-driven pattern feature.                  |

|                                                                                     |                                         |                                                                                                                                  |
|-------------------------------------------------------------------------------------|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|    | <a href="#">GetPatternBodyCount</a>     | Gets the number of seed bodies for this table-driven pattern feature.                                                            |
|    | <a href="#">GetPatternFaceCount</a>     | Gets the number of patterned faces in this table-driven feature.                                                                 |
|    | <a href="#">GetPatternFeatureCount</a>  | Gets the number of distinct seed features used to create this table-driven pattern feature.                                      |
|    | <a href="#">GetPointCount</a>           | Gets the number of x, y, and z locations of the repeating elements in this table-driven pattern.                                 |
|    | <a href="#">GetReferencePointType</a>   | Gets whether the table-driven pattern's reference point is a closed curve, a sketch point, or a vertex.                          |
|    | <a href="#">GetSkippedItemCount</a>     | Gets the number of skipped items in this table-driven pattern feature.                                                           |
|    | <a href="#">GetTransform</a>            | Gets the transform for the specified repeating element in this table-driven pattern feature.                                     |
|    | <a href="#">IAccessSelections</a>       | <b>Obsolete. Superseded by <a href="#">ITablePatternFeatureData.IAccessSelections2</a>.</b>                                      |
|    | <a href="#">IAccessSelections2</a>      | Gains access to selections used to define the table-driven pattern feature.                                                      |
|    | <a href="#">IGetBasePoint</a>           | Gets the base point for this table-driven pattern feature.                                                                       |
|    | <a href="#">IGetPatternBodyArray</a>    | Gets the seed bodies for this table-driven pattern feature.                                                                      |
|    | <a href="#">IGetPatternFaceArray</a>    | Gets the patterned faces in this table-driven pattern feature.                                                                   |
|    | <a href="#">IGetPatternFeatureArray</a> | Gets the seed features used to create the table-driven pattern.                                                                  |
|    | <a href="#">IGetPointArray</a>          | Gets an array of doubles that describe the x, y, and z locations of the repeating elements in this table-driven pattern feature. |
|    | <a href="#">IGetSkippedItemArray</a>    | Gets the skipped items in this table-driven pattern feature.                                                                     |
|    | <a href="#">ISetPatternBodyArray</a>    | Sets the seed bodies for this table-driven pattern feature.                                                                      |
|    | <a href="#">ISetPatternFaceArray</a>    | Sets the patterned faces for this table-driven pattern feature.                                                                  |
|    | <a href="#">ISetPatternFeatureArray</a> | Sets the seed features used to create the table-driven pattern feature.                                                          |
|    | <a href="#">ISetPointArray</a>          | Sets the points that describe the x, y, and z locations of the repeating elements in the table-driven pattern feature.           |
|    | <a href="#">ISetSkippedItemArray</a>    | Sets the skipped items in this table-driven pattern feature.                                                                     |
|    | <a href="#">LoadPointsFromFile</a>      | Loads the location points of the table-driven pattern from a *.sldptab file.                                                     |
|   | <a href="#">ReleaseSelectionAccess</a>  | Releases access to the selections that created this table-driven pattern feature.                                                |
|  | <a href="#">SavePointsToFile</a>        | Saves the location of the table-driven pattern feature's points to a *.sldptab file.                                             |

[Top](#)

## See Also

[ITablePatternFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ITablePatternFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITablePatternFeatureData Interface

For a list of all members of this type, see [ITablePatternFeatureData members](#).

## Public Properties

| Name                                                                                                                        | Description                                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">CoordinateSystem</a>        | Gets or sets the coordinate system of the table-driven pattern feature.                                                                    |
|  <a href="#">GeometryPattern</a>         | Gets or sets whether to create the pattern using only the geometry (faces and edges) of the features for the table-driven pattern feature. |
|  <a href="#">PatternBodyArray</a>        | Gets or sets the seed bodies to pattern for this table-driven pattern feature.                                                             |
|  <a href="#">PatternFaceArray</a>        | Gets or sets the patterned faces for this table-driven pattern feature.                                                                    |
|  <a href="#">PatternFeatureArray</a>     | Gets or sets the seed features used to create the table-driven pattern feature.                                                            |
|  <a href="#">PointArray</a>              | Gets or sets the array of points that describe the x,y, and z locations of the repeating elements in the table-driven pattern feature.     |
|  <a href="#">PropagateVisualProperty</a> | Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) in the table-driven pattern feature.                    |
|  <a href="#">ReferencePoint</a>          | Gets or sets the reference point for pattern instances of this table-driven pattern feature.                                               |
|  <a href="#">SkippedItemArray</a>        | Gets or sets the skipped items for this table-driven pattern feature.                                                                      |



[UseCentroid](#)

Gets or sets whether to set the reference point to the centroid of the seed feature for this table-driven pattern feature.

[Top](#)

## See Also

[ITablePatternFeatureData Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## AccessSelections Method (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : AccessSelections Method (ITablePatternFeatureData)

Gains access to selections used to define the table-driven pattern feature.

## .NET Syntax

### Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

### C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

### C++/CLI

```
System.bool AccessSelections(  
    & System.Object^ TopDoc,  
    & System.Object^ Component  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*TopDoc*

Top-level document

*Component*

Component for the feature

### Return Value

Component for the feature

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::AccessSelections](#).

## Example

[Get Table-driven Pattern Properties \(VBA\)](#)

[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)

## Remarks

| To modify a feature in a... | Then...                                                                                                                                                                                                      |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Part                        | <ul style="list-style-type: none"><li>TopDoc argument is the <a href="#">IModelDoc2</a> for the part</li><li>Component argument is NULL</li></ul>                                                            |
| Assembly                    | <ul style="list-style-type: none"><li>TopDoc is the IModelDoc2 object for the assembly</li><li>Component argument is the <a href="#">IComponent2</a> object in which the feature is to be modified</li></ul> |

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ITablePatternFeatureData::ReleaseSelectionAccess](#) if you did not

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITableDrivenPatternFeatureData::IAccessSelections2 Method](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## CoordinateSystem Property (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : CoordinateSystem Property (ITablePatternFeatureData)

Gets or sets the coordinate system of the table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

Property CoordinateSystem As System.Object

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Object
```

```
instance.CoordinateSystem = value
```

```
value = instance.CoordinateSystem
```

C#

```
System.object CoordinateSystem {get; set;}
```

C++/CLI

```
property System.Object^ CoordinateSystem {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Pointer to the coordinate system [feature](#)

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::CoordinateSystem](#).

## Example

[Get Table-driven Pattern Properties \(VBA\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VBA\)](#)

## Remarks

See [Accessing Selections that Define Features](#) for additional details.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GeometryPattern Property (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GeometryPattern Property (ITablePatternFeatureData)

Gets or sets whether to create the pattern using only the geometry (faces and edges) of the features for the table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

Property GeometryPattern As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Boolean
```

```
instance.GeometryPattern = value
```

```
value = instance.GeometryPattern
```

C#

```
System.bool GeometryPattern {get; set;}
```

C++/CLI

```
property System.bool GeometryPattern {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to pattern using only geometry of the features; false to pattern and solve entire features

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GeometryPattern](#).

## Example

See the [ITablePatternFeatureData](#) example.

## Remarks

This property is valid with [ITablePatternFeatureData::PatternFaceArray](#) or [ITablePatternFeatureData::PatternFeatureArray](#) and is invalid with [ITablePatternFeatureData::PatternBodyArray](#).

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetBasePoint Method (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GetBasePoint Method (ITablePatternFeatureData)

Gets the base point for this table-driven pattern feature.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetBasePoint() As System.Object
```

### Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Object  
  
value = instance.GetBasePoint()
```

### C#

```
System.object GetBasePoint()
```

### C++/CLI

```
System.Object^ GetBasePoint();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Base point

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GetBasePoint](#).

## Example

[Get Table-driven Pattern Properties \(VBA\)](#)

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::IGetBasePoint Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetPatternBodyCount Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GetPatternBodyCount Method (ITablePatternFeatureData)

Gets the number of seed bodies for this table-driven pattern feature.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetPatternBodyCount() As System.Integer
```

### Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetPatternBodyCount()
```

### C#

```
System.int GetPatternBodyCount()
```

### C++/CLI

```
System.int GetPatternBodyCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of seed bodies

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GetPatternBodyCount](#).

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::IGetPatternBodyArray Method](#)  
[ITablePatternFeatureData::ISetPatternBodyArray Method](#)  
[ITablePatternFeatureData::PatternBodyArray Property](#)

## Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

### GetPatternFaceCount Method (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GetPatternFaceCount Method (ITablePatternFeatureData)

Gets the number of patterned faces in this table-driven feature.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetPatternFaceCount() As System.Integer
```

### Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetPatternFaceCount()
```

### C#

```
System.int GetPatternFaceCount()
```

### C++/CLI

```
System.int GetPatternFaceCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of patterned faces in this table-driven feature

#### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GetPatternFaceCount](#).

#### Example

[Get Table-driven Pattern Properties \(VBA\)](#)

#### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::IGetPatternFaceArray Method](#)  
[ITablePatternFeatureData::ISetPatternFaceArray Method](#)  
[ITablePatternFeatureData::PatternFaceArray Property](#)

#### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetPatternFeatureCount Method (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GetPatternFeatureCount Method (ITablePatternFeatureData)

Gets the number of distinct seed features used to create this table-driven pattern feature.

#### .NET Syntax

Visual Basic (Declaration)

```
Function GetPatternFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetPatternFeatureCount()
```

C#

```
System.int GetPatternFeatureCount()
```

C++/CLI

```
System.int GetPatternFeatureCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of distinct seed features used to create this table-driven pattern

#### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GetPatternFeatureCount](#).

#### Example

[Get Table-driven Pattern Properties \(VBA\)](#)

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::IGetPatternFeatureArray Method](#)  
[ITablePatternFeatureData::ISetPatternFeatureArray Method](#)  
[ITablePatternFeatureData::PatternFeatureArray Property](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetPointCount Method (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GetPointCount Method (ITablePatternFeatureData)

Gets the number of x, y, and z locations of the repeating elements in this table-driven pattern.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetPointCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetPointCount()
```

C#

```
System.int GetPointCount()
```

C++/CLI

```
System.int GetPointCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Number of x, y, and z locations of the repeating elements in this table-driven pattern

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GetPointCount](#).

## Example

[Get Table-driven Pattern Properties \(VBA\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VBA\)](#)

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::IGetPointArray Method](#)  
[ITablePatternFeatureData::ISetPointArray Method](#)  
[ITablePatternFeatureData::PointArray Property](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

## GetReferencePointType Method (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GetReferencePointType Method (ITablePatternFeatureData)

Gets whether the table-driven pattern's reference point is a closed curve, a sketch point, or a vertex.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetReferencePointType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetReferencePointType()
```

C#

```
System.int GetReferencePointType()
```

C++/CLI

```
System.int GetReferencePointType();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Type of reference point:

- 0 = closed curve
- 1 = sketch point
- 2 = vertex

### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GetReferencePointType](#).

### Example

[Get Table-driven Pattern Properties \(VBA\)](#)

### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::ReferencePoint Property](#)

### Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

## GetSkippedItemCount Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GetSkippedItemCount Method (ITablePatternFeatureData)

Gets the number of skipped items in this table-driven pattern feature.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetSkippedItemCount() As System.Integer
```

```
Dim instance As ITablePatternFeatureData
Dim value As System.Integer

value = instance.GetSkippedItemCount()
```

C#

```
System.int GetSkippedItemCount()
```

C++/CLI

```
System.int GetSkippedItemCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of skipped items

### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GetSkippedItemCount](#).

### Remarks

Call this method before calling [ITablePatternFeatureData::!GetSkippedItemArray](#) to get the size of the array.

### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::!GetSkippedItemArray Method](#)  
[ITablePatternFeatureData::!SetSkippedItemArray Method](#)  
[ITablePatternFeatureData::SkippedItemArray Property](#)

### Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetTransform Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : GetTransform Method (ITablePatternFeatureData)

Gets the transform for the specified repeating element in this table-driven pattern feature.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetTransform( _
    ByVal Instance As System.Integer _
) As MathTransform
```

Visual Basic (Usage)

```
Dim instance As ITablePatternFeatureData
Dim Instance As System.Integer
Dim value As MathTransform

value = instance.GetTransform(Instance)
```

C#

```
MathTransform GetTransform(
    System.int Instance
```

)

C++/CLI

```
MathTransform^ GetTransform(  
& System.int Instance  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Instance*

Index of one repeating element in the pattern (see **Remarks**)

#### Return Value

[Transform](#)

### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::GetTransform](#).

### Remarks

1 <= *Instance* <= [ITablePatternFeatureData::GetPointCount](#)

### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)

### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## IAccessSelections Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : IAccessSelections Method (ITablePatternFeatureData)

**Obsolete.** Superseded by [ITablePatternFeatureData::IAccessSelections2](#).

### .NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*TopDoc*

*Component*

### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::IAccessSelections](#).

### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## IAccessSelections2 Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : IAccessSelections2 Method (ITablePatternFeatureData)

Gains access to selections used to define the table-driven pattern feature.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

#### Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections2(TopDoc, Component)
```

#### C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

#### C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*TopDoc*

Top-level document

*Component*

Component for the feature

## Return Value

True if the selections are successfully accessed, false if not

## Remarks

| To modify a feature in a... | Then...                                                                                                                                                                                                                      |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Part                        | <ul style="list-style-type: none"><li>TopDoc argument is the <a href="#">IModelDoc2</a> for the part</li><li>Component argument is <code>NULL</code></li></ul>                                                               |
| Assembly                    | <ul style="list-style-type: none"><li>TopDoc is the <a href="#">IModelDoc2</a> object for the assembly</li><li>Component argument is the <a href="#">IComponent2</a> object in which the feature is to be modified</li></ul> |

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ITablePatternFeatureData::ReleaseSelectionAccess](#) if you did not

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::AccessSelections Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetBasePoint Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : IGetBasePoint Method (ITablePatternFeatureData)

Gets the base point for this table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

```
Function IGetBasePoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Double  
  
value = instance.IGetBasePoint()
```

C#

```
System.double IGetBasePoint()
```

C++/CLI

```
System.double IGetBasePoint();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Return Value

Number of doubles that describe the table-driven pattern ( 3x number of points)

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::GetBasePoint Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

## IGetPatternBodyArray Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : IGetPatternBodyArray Method (ITablePatternFeatureData)

Gets the seed bodies for this table-driven pattern feature.

### .NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternBodyArray() As Body2
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As Body2
```

```
value = instance.IGetPatternBodyArray()
```

C#

```
Body2 IGetPatternBodyArray()
```

C++/CLI

```
Body2^ IGetPatternBodyArray();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

- in-process, unmanaged C++: Pointer to an array of seed [bodies](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

### Remarks

See [Accessing Selections that Define Features](#) for additional details.

### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::PatternBodyArray Property](#)  
[ITablePatternFeatureData::GetPatternBodyCount Method](#)  
[ITablePatternFeatureData::ISetPatternBodyArray Method](#)

### Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

## IGetPatternFaceArray Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : IGetPatternFaceArray Method (ITablePatternFeatureData)

Gets the patterned faces in this table-driven pattern feature.

### .NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternFaceArray() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData
Dim value As System.Object

value = instance.IGetPatternFaceArray()
```

C#

```
System.object IGetPatternFaceArray()
```

C++/CLI

```
System.Object^ IGetPatternFaceArray();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

in-process, unmanaged C++: Pointer to an array of patterned [faces](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported
  - See [In-process Methods](#) for details about this type of method.

#### Remarks

See [Accessing Selections that Define Features](#) for additional details.

#### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::PatternFaceArray Property](#)

#### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetPatternFeatureArray Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : IGetPatternFeatureArray Method (ITablePatternFeatureData)

Gets the seed features used to create the table-driven pattern.

#### .NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternFeatureArray() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData
Dim value As System.Object

value = instance.IGetPatternFeatureArray()
```

C#

```
System.object IGetPatternFeatureArray()
```

C++/CLI

```
System.Object^ IGetPatternFeatureArray();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

- in-process, unmanaged C++: Pointer to an array of [features](#) used to create this table-driven pattern feature
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

#### Remarks

See [Accessing Selections that Define Features](#) for additional details.

#### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::GetPatternFeatureCount Method](#)  
[ITablePatternFeatureData::ISetPatternFeatureArray Method](#)  
[ITablePatternFeatureData::PatternFeatureArray Property](#)

#### Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetPointArray Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : IGetPointArray Method (ITablePatternFeatureData)

Gets an array of doubles that describe the x, y, and z locations of the repeating elements in this table-driven pattern feature.

#### .NET Syntax

Visual Basic (Declaration)

```
Function IGetPointArray() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Double  
  
value = instance.IGetPointArray()
```

C#

```
System.double IGetPointArray()
```

C++/CLI

```
System.double IGetPointArray();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

- in-process, unmanaged C++: Pointer to an array of doubles that describe the x, y, and z locations of the repeating elements in this table-driven pattern feature
  - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

#### Remarks

The points returned are based on the table-driven pattern's coordinate system.

The array of doubles, which describe the x, y, and z locations, is the number of repeating elements \* 3:

*[ point1x, point1y, point1z, point2x, point2y, point2z, ... ]*

To get the number of points, call [ITablePatternFeatureData::GetPointCount](#).

#### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::ISetPointArray Method](#)  
[ITablePatternFeatureData::PointArray Property](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetSkippedItemArray Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : IGetSkippedItemArray Method (ITablePatternFeatureData)

Gets the skipped items in this table-driven pattern feature.

## Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetSkippedItemArray( _  
    ByVal Count As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim Count As System.Integer  
Dim value As System.Integer  
  
value = instance.IGetSkippedItemArray(Count)
```

C#

```
System.int IGetSkippedItemArray(  
    System.int Count  
)
```

C++/CLI

```
System.int IGetSkippedItemArray(  
& System.int Count  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*Count*

Number of skipped items

### Return Value

- in-process, unmanaged C++: Pointer to an array of skipped items
  - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

## Remarks

See [Accessing Selections that Define Features](#) for additional details.

Call [ITablePatternFeatureData::GetSkippedItemCount](#) before calling this method to get the size of the array.

Because this is a 0-based array, if you skipped the third feature and fifth feature in the pattern, then:

- 0 = 3
- 1 = 5

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::ISetSkippedItemArray Method](#)  
[ITablePatternFeatureData::SkippedItemArray Property](#)

## Availability

## ISetPatternBodyArray Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : ISetPatternBodyArray Method (ITablePatternFeatureData)

Sets the seed bodies for this table-driven pattern feature.

### Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetPatternBodyArray( _
    ByVal BodyCount As System.Integer, _
    ByRef ArrayDataIn As Body2 _
)
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData
Dim BodyCount As System.Integer
Dim ArrayDataIn As Body2

instance.ISetPatternBodyArray(BodyCount, ArrayDataIn)
```

C#

```
void ISetPatternBodyArray(
    System.int BodyCount,
    ref Body2 ArrayDataIn
)
```

C++/CLI

```
void ISetPatternBodyArray(
    & System.int BodyCount,
    & Body2^% ArrayDataIn
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*BodyCount*

Number of seed bodies

*ArrayDataIn*

• In-process, unmanaged C++: Pointer to an array of seed [bodies](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

### Remarks

See [Accessing Selections that Define Features](#) for additional details.

### See Also

[ITablePatternFeatureData Interface](#)

[ITablePatternFeatureData Members](#)

[ITablePatternFeatureData::GetPatternBodyCount Method](#)

[ITablePatternFeatureData::IGetPatternBodyArray Method](#)

[ITablePatternFeatureData::PatternBodyArray Property](#)

### Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

## ISetPatternFaceArray Method (ITablePatternFeatureData)

[See Also](#)



Sets the patterned faces for this table-driven pattern feature.

## Visual Basic Syntax

### Visual Basic (Declaration)

```
Sub ISetPatternFaceArray( _  
    ByVal FaceCount As System.Integer, _  
    ByRef ArrayDataIn As System.Object _  
)
```

### Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim FaceCount As System.Integer  
Dim ArrayDataIn As System.Object  
  
instance.ISetPatternFaceArray(FaceCount, ArrayDataIn)
```

### C#

```
void ISetPatternFaceArray(  
    System.int FaceCount,  
    ref System.object ArrayDataIn  
)
```

### C++/CLI

```
void ISetPatternFaceArray(  
& System.int FaceCount,  
& System.Object^% ArrayDataIn  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*FaceCount*

Number of patterned faces

*ArrayDataIn*

- In-process, unmanaged C++: Pointer to an array of patterned [faces](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

## Remarks

See [Accessing Selections that Define Features](#) for additional details.

## See Also

[ITablePatternFeatureData Interface](#)

[ITablePatternFeatureData Members](#)

[ITablePatternFeatureData::GetPatternFaceCount Method](#)

[ITablePatternFeatureData::IGetPatternFaceArray Method](#)

[ITablePatternFeatureData::PatternFaceArray Property](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Sets the seed features used to create the table-driven pattern feature.

## Visual Basic Syntax

### Visual Basic (Declaration)

```
Sub ISetPatternFeatureArray( _  
    ByVal FeatCount As System.Integer, _  
    ByRef ArrayDataIn As System.Object _  
)
```

### Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim FeatCount As System.Integer  
Dim ArrayDataIn As System.Object  
  
instance.ISetPatternFeatureArray(FeatCount, ArrayDataIn)
```

### C#

```
void ISetPatternFeatureArray(  
    System.int FeatCount,  
    ref System.object ArrayDataIn  
)
```

### C++/CLI

```
void ISetPatternFeatureArray(  
& System.int FeatCount,  
& System.Object^% ArrayDataIn  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

#### *FeatCount*

Number of seed features that to use to create this table-driven pattern feature

#### *ArrayDataIn*

- in-process, unmanaged C++: Pointer to an array of seed [features](#) to use to create the table-driven pattern feature

VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

## Remarks

See [Accessing Selections that Define Features](#) for additional details.

## See Also

[ITablePatternFeatureData Interface](#)

[ITablePatternFeatureData Members](#)

[ITablePatternFeatureData::ISetPatternFeatureArray Method](#)

[ITablePatternFeatureData::PatternFeatureArray Property](#)

[ITablePatternFeatureData::GetPatternFeatureCount Method](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ISetPointArray Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : ISetPointArray Method (ITablePatternFeatureData)

Sets the points that describe the x, y, and z locations of the repeating elements in the table-driven pattern feature.

## Visual Basic Syntax

### Visual Basic (Declaration)

```
Sub ISetPointArray( _
    ByVal FeatCount As System.Integer, _
    ByRef ArrayDataIn As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData
Dim FeatCount As System.Integer
Dim ArrayDataIn As System.Double

instance.ISetPointArray(FeatCount, ArrayDataIn)
```

C#

```
void ISetPointArray(
    System.int FeatCount,
    ref System.double ArrayDataIn
)
```

C++/CLI

```
void ISetPointArray(
    & System.int FeatCount,
    & System.double% ArrayDataIn
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*FeatCount*

Number of seed features for the table-driven pattern feature

*ArrayDataIn*

- in-process, unmanaged C++: Pointer to an array of points that describe the x, y, and z locations of the repeating elements in the table-driven pattern

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

#### Remarks

The array of doubles, which describe the x, y, and z locations, is the number of repeating elements \* 3:

[ *point1x*, *point1y*, *point1z*, *point2x*, *point2y*, *point2z*, ... ]

See [Accessing Selections that Define Features](#) for additional details.

#### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::IGetPointArray Method](#)  
[ITablePatternFeatureData::PointArray Property](#)  
[ITablePatternFeatureData::GetPointCount Method](#)

#### Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ISetSkippedItemArray Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : ISetSkippedItemArray Method (ITablePatternFeatureData)

Sets the skipped items in this table-driven pattern feature.

#### .NET Syntax

Visual Basic (Declaration)

```
Sub ISetSkippedItemArray( _
    ByVal Count As System.Integer, _
    ByRef ArrayDataIn As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData
Dim Count As System.Integer
Dim ArrayDataIn As System.Integer

instance.ISetSkippedItemArray(Count, ArrayDataIn)
```

C#

```
void ISetSkippedItemArray(
    System.int Count,
    ref System.int ArrayDataIn
)
```

C++/CLI

```
void ISetSkippedItemArray(
    & System.int Count,
    & System.int% ArrayDataIn
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Count*

Number of skipped items

*ArrayDataIn*

- in-process, unmanaged C++: Pointer to an array of skipped items

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

#### Remarks

See [Accessing Selections that Define Features](#) for additional details.

#### See Also

[ITablePatternFeatureData Interface](#)

[ITablePatternFeatureData Members](#)

[ITablePatternFeatureData::GetSkippedItemCount Method](#)

[ITablePatternFeatureData::ISetSkippedItemArray Method](#)

[ITablePatternFeatureData::SkippedItemArray Property](#)

#### Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## LoadPointsFromFile Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : LoadPointsFromFile Method (ITablePatternFeatureData)

Loads the location points of the table-driven pattern from a \*.**sldptab** file.

#### .NET Syntax

Visual Basic (Declaration)

```
Function LoadPointsFromFile( _
    ByVal FileName As System.String _
) As System.Boolean
```

```
Dim instance As ITablePatternFeatureData
Dim FileName As System.String
Dim value As System.Boolean

value = instance.LoadPointsFromFile(FileName)
```

C#

```
System.bool LoadPointsFromFile(
    System.string FileName
)
```

C++/CLI

```
System.bool LoadPointsFromFile(
    & System.String^ FileName
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*FileName*

Name of the file with the table-driven pattern feature's point locations

#### Return Value

True if the file loads successfully, false if not

### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::LoadPointsFromFile](#).

### See Also

[ITablePatternFeatureData Interface](#)

[ITablePatternFeatureData Members](#)

[ITablePatternFeatureData::SavePointsToFile Method](#)

### Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## PatternBodyArray Property (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : PatternBodyArray Property (ITablePatternFeatureData)

Gets or sets the seed bodies to pattern for this table-driven pattern feature.

### .NET Syntax

Visual Basic (Declaration)

```
Property PatternBodyArray As System.Object
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ITablePatternFeatureData
Dim value As System.Object
```

```
instance.PatternBodyArray = value
```

```
value = instance.PatternBodyArray
```

C#

```
System.Object PatternBodyArray {get; set;}
```

C++/CLI

```
property System.Object^ PatternBodyArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Array of [bodies](#) to pattern

### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::PatternBodyArray](#).

### Remarks

See [Accessing Selections that Define Features](#) for additional details.

### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::GetPatternBodyCount Method](#)  
[ITablePatternFeatureData::GetPatternBodyArray Method](#)  
[ITablePatternFeatureData::SetPatternBodyArray Method](#)

### Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PatternFaceArray Property (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : PatternFaceArray Property (ITablePatternFeatureData)

Gets or sets the patterned faces for this table-driven pattern feature.

### .NET Syntax

Visual Basic (Declaration)

```
Property PatternFaceArray As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Object
```

```
instance.PatternFaceArray = value
```

```
value = instance.PatternFaceArray
```

C#

```
System.Object PatternFaceArray {get; set;}
```

C++/CLI

```
property System.Object^ PatternFaceArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

Array of patterned [faces](#)

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::PatternFaceArray](#).

## Remarks

See [Accessing Selections that Define Features](#) for additional details.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::GetPatternFaceCount Method](#)  
[ITablePatternFeatureData::IGetPatternFaceArray Method](#)  
[ITablePatternFeatureData::ISetPatternFaceArray Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PatternFeatureArray Property (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : PatternFeatureArray Property (ITablePatternFeatureData)

Gets or sets the seed features used to create the table-driven pattern feature.

## .NET Syntax

### Visual Basic (Declaration)

```
Property PatternFeatureArray As System.Object
```

### Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Object
```

```
instance.PatternFeatureArray = value
```

```
value = instance.PatternFeatureArray
```

### C#

```
System.object PatternFeatureArray {get; set;}
```

### C++/CLI

```
property System.Object^ PatternFeatureArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

Array of the [features](#) used to create this table-driven pattern feature

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::PatternFeatureArray](#).

## Example

## Remarks

See [Accessing Selections that Define Features](#) for additional details.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::GetPatternFeatureCount Method](#)  
[ITablePatternFeatureData::IGetPatternFeatureArray Method](#)  
[ITablePatternFeatureData::ISetPatternFeatureArray Method](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PointArray Property (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : PointArray Property (ITablePatternFeatureData)

Gets or sets the array of points that describe the x,y, and z locations of the repeating elements in the table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

```
Property PointArray As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Object  
  
instance.PointArray = value  
  
value = instance.PointArray
```

C#

```
System.Object PointArray {get; set;}
```

C++/CLI

```
property System.Object^ PointArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Array of doubles that describe the x, y, and z locations of the repeating elements in the table-driven pattern

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::PointArray](#).

## Example

See the [ITablePatternFeatureData](#) example.

## Example

[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)

## Remarks

The points returned are based on the table-driven pattern's coordinate system.

The array of doubles describe the x, y, and z locations of the repeating elements in the table-driven pattern. The size of the array is the number of repeating elements \* 3:

*[ point1x, point1y, point1z, point2x, point2y, point2z, ... ]*

Use [ITablePatternFeatureData::GetPointCount](#) to get the number of points in the array.

See [Accessing Selections that Define Features](#) for additional details.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::GetPointArray Method](#)  
[ITablePatternFeatureData::SetPointArray Method](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PropagateVisualProperty Property (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : PropagateVisualProperty Property (ITablePatternFeatureData)

Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) in the table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

```
Property PropagateVisualProperty As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Boolean
```

```
instance.PropagateVisualProperty = value
```

```
value = instance.PropagateVisualProperty
```

C#

```
System.bool PropagateVisualProperty {get; set;}
```

C++/CLI

```
property System.bool PropagateVisualProperty {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to propagate visual properties, false to not

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::PropagateVisualProperty](#).

## Example

See the [ITablePatternFeatureData](#) example.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ReferencePoint Property (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : ReferencePoint Property (ITablePatternFeatureData)

Gets or sets the reference point for pattern instances of this table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

Property ReferencePoint As System.Object

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData
Dim value As System.Object

instance.ReferencePoint = value

value = instance.ReferencePoint
```

C#

```
System.object ReferencePoint {get; set;}
```

C++/CLI

```
property System.Object^ ReferencePoint {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Reference point of this table-driven pattern feature

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::ReferencePoint](#).

## Example

[Get Table-driven Pattern Properties \(VBA\)](#)

## Remarks

See [Accessing Selections that Define Features](#) for additional details.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::GetReferencePointType Method](#)  
[ITablePatternFeatureData::UseCentroid Property\(\)](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ReleaseSelectionAccess Method (ITablePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : ReleaseSelectionAccess Method (ITablePatternFeatureData)

Releases access to the selections that created this table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::ReleaseSelectionAccess](#).

## Example

[Get Table-driven Pattern Properties \(VBA\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)  
[Get Points of Repeating Elements in Table-driven Pattern \(VBA\)](#)

## Remarks

[ITablePatternFeatureData::AccessSelections](#) and [ITablePatternFeatureData::!AccessSelections2](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SavePointsToFile Method (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : SavePointsToFile Method (ITablePatternFeatureData)

Saves the location of the table-driven pattern feature's points to a \*.**sldptab** file.

## .NET Syntax

Visual Basic (Declaration)

```
Function SavePointsToFile( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.SavePointsToFile(FileName)
```

C#

```
System.bool SavePointsToFile(  
    System.string FileName  
)
```

C++/CLI

```
System.bool SavePointsToFile(  
& System.String^ FileName  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*FileName*

Name of the file to which to save the points

### Return Value

True if successful, false if not

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::SavePointsToFile](#).

## Remarks

Exported units, e.g. meters, of the document that owns the feature, and not necessarily those of the active document, are used when data is saved to a file.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::LoadPointsFromFile Method](#)

## Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SkippedItemArray Property (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : SkippedItemArray Property (ITablePatternFeatureData)

Gets or sets the skipped items for this table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

## Property SkippedItemArray As System.Object

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Object
```

```
instance.SkippedItemArray = value
```

```
value = instance.SkippedItemArray
```

C#

```
System.object SkippedItemArray {get; set;}
```

C++/CLI

```
property System.Object^ SkippedItemArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

0-based array of skipped items

## Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::SkippedItemArray](#).

## Remarks

See [Accessing Selections that Define Features](#) for additional details.

## See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)  
[ITablePatternFeatureData::GetSkippedItemCount Method](#)  
[ITablePatternFeatureData::ISetSkippedItemArray Method](#)  
[ITablePatternFeatureData::ISetSkippedItemArray Method](#)

## Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## UseCentroid Property (ITablePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITablePatternFeatureData Interface](#) : UseCentroid Property (ITablePatternFeatureData)

Gets or sets whether to set the reference point to the centroid of the seed feature for this table-driven pattern feature.

## .NET Syntax

Visual Basic (Declaration)

```
Property UseCentroid As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITablePatternFeatureData  
Dim value As System.Boolean
```

```
instance.UseCentroid = value
```

```
value = instance.UseCentroid
```

C#

```
System.bool UseCentroid {get; set;}
```

C++/CLI

```
property System.bool UseCentroid {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to use the seed feature's centroid as the reference point, false to not

### Visual Basic for Applications (VBA) Syntax

See [TablePatternFeatureData::UseCentroid](#).

### Example

See the [ITablePatternFeatureData](#) example.

### Remarks

If this property is set to false, then you must specify [ITablePatternFeatureData::ReferencePoint](#).

### See Also

[ITablePatternFeatureData Interface](#)  
[ITablePatternFeatureData Members](#)

### Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

# ITangentMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ITangentMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITangentMateFeatureData Interface

Allows access to a tangent mate feature.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface ITangentMateFeatureData
```

Visual Basic (Usage)



```
Dim instance As ITangentMateFeatureData
```

C#

```
public interface ITangentMateFeatureData
```

C++/CLI

```
public interface class ITangentMateFeatureData
```

### Visual Basic for Applications (VBA) Syntax

See [TangentMateFeatureData](#).

### Example

[Create Standard Mates \(VBA\)](#)  
[Create Standard Mates \(C#\)](#)

### Remarks

A tangent mate:

- Places selected items tangent to one another.
- Must have at least one cylindrical, conical, or spherical item.

[IMateFeatureData](#) is the parent of this mate interface.

To create a tangent mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [ITangentMateFeatureData::EntitiesToMate](#) or use [IModelDocExtension::SelectByIID2](#) to pre-select the entities to mate using Mark = 1.
3. Specify other properties of the TangentMateFeatureData object.

To edit a tangent mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a TangentMateFeatureData object.
3. Modify the TangentMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete this tangent mate, use [IModelDocExtension::DeleteSelection2](#).

### Access Diagram

[TangentMateFeatureData](#)

### See Also

[ITangentMateFeatureData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ITangentMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITangentMateFeatureData Interface

The following tables list the members exposed by [ITangentMateFeatureData](#).

## Public Properties

| Name                                                                                                             | Description                                                                 |
|------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
|  <a href="#">EntitiesToMate</a> | Gets or sets the entities to mate in this tangent mate.                     |
|  <a href="#">MateAlignment</a>  | Gets or sets the mate alignment of this tangent mate.                       |
|  <a href="#">PickPoints</a>     | Gets or sets the pick points for the entities to mate in this tangent mate. |

[Top](#)

## See Also

[ITangentMateFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ITangentMateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITangentMateFeatureData Interface

For a list of all members of this type, see [ITangentMateFeatureData members](#).

## Public Properties

| Name                                                                                                             | Description                                                                 |
|------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
|  <a href="#">EntitiesToMate</a> | Gets or sets the entities to mate in this tangent mate.                     |
|  <a href="#">MateAlignment</a> | Gets or sets the mate alignment of this tangent mate.                       |
|  <a href="#">PickPoints</a>   | Gets or sets the pick points for the entities to mate in this tangent mate. |

[Top](#)

## See Also

[ITangentMateFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## EntitiesToMate Property (ITangentMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITangentMateFeatureData Interface](#) : EntitiesToMate Property (ITangentMateFeatureData)

Gets or sets the entities to mate in this tangent mate.

## .NET Syntax

Visual Basic (Declaration)

Property EntitiesToMate As System.Object

Visual Basic (Usage)



```
Dim instance As ITangentMateFeatureData  
Dim value As System.Object
```

```
instance.EntitiesToMate = value
```

```
value = instance.EntitiesToMate
```

C#

```
System.object EntitiesToMate {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

**Property Value**

Entities to mate (see **Remarks**)

 **Visual Basic for Applications (VBA) Syntax**

See [ITangentMateFeatureData::EntitiesToMate](#).

 **Example**

See the [ITangentMateFeatureData](#) example.

 **Remarks**

You can create tangent mates with the following mate entity combinations:

| Mate entity/Mate entity                          | <a href="#">ISurface</a> ,<br><a href="#">IFace2</a><br>(cone, cylinder) | <a href="#">IFace2</a><br>(extrusion face, draft is not allowed) | <a href="#">IEdge</a> ,<br><a href="#">IRefAxis</a> ,<br><a href="#">ICenterLine</a> ,<br><a href="#">ISketchLine</a><br>(line) | <a href="#">IRefPlane</a> | <a href="#">ISurface</a> ,<br><a href="#">IFace2</a><br>(sphere) | <a href="#">ISurface</a> |
|--------------------------------------------------|--------------------------------------------------------------------------|------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|---------------------------|------------------------------------------------------------------|--------------------------|
| ISurface, IFace2 (cone, cylinder)                | •                                                                        | •                                                                | •                                                                                                                               | •                         | •                                                                | •                        |
| IFace2 (extrusion face; draft is not allowed)    | •                                                                        |                                                                  |                                                                                                                                 |                           | •                                                                |                          |
| IEdge, IRefAxis, ICenterLine, ISketchLine (line) | •                                                                        |                                                                  |                                                                                                                                 |                           | •                                                                |                          |
| IRefPlane                                        | •                                                                        |                                                                  |                                                                                                                                 |                           | •                                                                |                          |
| ISurface, IFace2 (sphere)                        | •                                                                        | •                                                                | •                                                                                                                               | •                         | •                                                                | •                        |
| ISurface                                         | •                                                                        |                                                                  |                                                                                                                                 |                           | •                                                                |                          |

Instead of specifying this property, you can use [IModelDocExtension::SelectByID2](#) to pre-select the entities to mate using Mark = 1. You can pre-select mate entities during mate creation, but not during mate editing.

 **See Also**

[ITangentMateFeatureData Interface](#)  
[ITangentMateFeatureData Members](#)

 **Availability**

SOLIDWORKS 2019 FCS, Revision Number 27.0

**MateAlignment Property (ITangentMateFeatureData)**

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITangentMateFeatureData Interface](#) : MateAlignment Property (ITangentMateFeatureData)

Gets or sets the mate alignment of this tangent mate.

 **.NET Syntax**

Visual Basic (Declaration)

```
Property MateAlignment As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ITangentMateFeatureData
Dim value As System.Integer

instance.MateAlignment = value
```



```
value = instance.MateAlignment
```

C#

```
System.int MateAlignment {get; set;}
```

C++/CLI

```
property System.int MateAlignment {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Mate alignment as defined in [swMateAlign\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [TangentMateFeatureData::MateAlignment](#).

### Example

See the [ITangentMateFeatureData](#) example.

### See Also

[ITangentMateFeatureData Interface](#)  
[ITangentMateFeatureData Members](#)

### Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PickPoints Property (ITangentMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITangentMateFeatureData Interface](#) : PickPoints Property (ITangentMateFeatureData)

Gets or sets the pick points for the entities to mate in this tangent mate.

### .NET Syntax

Visual Basic (Declaration)

```
Property PickPoints As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITangentMateFeatureData  
Dim value As System.Object
```

```
instance.PickPoints = value
```

```
value = instance.PickPoints
```

C#

```
System.object PickPoints {get; set;}
```

C++/CLI

```
property System.Object^ PickPoints {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Array of x, y, z-coordinates, one set for each mate entity

#### Visual Basic for Applications (VBA) Syntax

See [TangentMateFeatureData::PickPoints](#).

#### Remarks

After you set the pick points for a given selection of [ITangentMateFeatureData::EntitiesToMate](#), you cannot modify the pick points. If you want to use new pick points, then you must create an entirely new tangent mate.

#### See Also

[ITangentMateFeatureData Interface](#)  
[ITangentMateFeatureData Members](#)

#### Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

# ITaperedTapElementData (Type)

## ITaperedTapElementData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITaperedTapElementData Interface

Allows access to the data of a tapered tap hole element in an Advanced Hole.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface ITaperedTapElementData
```

Visual Basic (Usage)

```
Dim instance As ITaperedTapElementData
```

C#

```
public interface ITaperedTapElementData
```

C++/CLI

```
public interface class ITaperedTapElementData
```

### Visual Basic for Applications (VBA) Syntax

See [TaperedTapElementData](#).

### Example

[Create Advanced Hole Feature \(VBA\)](#)  
[Create Advanced Hole Feature \(VB.NET\)](#)  
[Create Advanced Hole Feature \(C#\)](#)

### Remarks

To create an Advanced Hole feature, see the [IFeatureManager::AdvancedHole](#) Remarks.

### Accessors

[IAdvancedHoleFeatureData::GetFarSideElements](#)  
[IAdvancedHoleFeatureData::GetNearSideElements](#)

### Access Diagram

[TaperedTapElementData](#)

### See Also

[ITaperedTapElementData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[ICounterboreElementData Interface](#)  
[ICountersinkElementData Interface](#)  
[IStraightElementData Interface](#)  
[IStraightTapElementData Interface](#)  
[IFeatureManager::AdvancedHole Method \(\)](#)  
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)  
[IAdvancedHoleElementData Interface](#)

## ITaperedTapElementData Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [ITaperedTapElementData](#).

 **Public Properties**

| Name                                                                                                                   | Description                                                                                                      |
|------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
|  <a href="#">CustomSizing</a>         | Gets or sets the custom sizing for this tapered tap hole element.                                                |
|  <a href="#">EndConditionOverride</a> | Gets or sets whether to override the end condition of this tapered tap hole element.                             |
|  <a href="#">ThreadClass</a>          | Gets or sets the thread class for this tapered tap hole element.                                                 |
|  <a href="#">ThreadClassOverride</a>  | Gets or sets whether to override the thread class of this tapered tap hole element.                              |
|  <a href="#">UseStandardDepth</a>     | Gets or sets whether to use the standard offset distance for the end condition of this tapered tap hole element. |

[Top](#)

 **See Also**

[ITaperedTapElementData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[ICounterboreElementData Interface](#)  
[ICountersinkElementData Interface](#)  
[IStraightElementData Interface](#)  
[IStraightTapElementData Interface](#)  
[IFeatureManager::AdvancedHole Method \(\)](#)  
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)  
[IAdvancedHoleElementData Interface](#)

**ITaperedTapElementData Interface Properties**

[See Also](#)



For a list of all members of this type, see [ITaperedTapElementData members](#).

 **Public Properties**

| Name                                                                                                                     | Description                                                                                                      |
|--------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
|  <a href="#">CustomSizing</a>         | Gets or sets the custom sizing for this tapered tap hole element.                                                |
|  <a href="#">EndConditionOverride</a> | Gets or sets whether to override the end condition of this tapered tap hole element.                             |
|  <a href="#">ThreadClass</a>          | Gets or sets the thread class for this tapered tap hole element.                                                 |
|  <a href="#">ThreadClassOverride</a>  | Gets or sets whether to override the thread class of this tapered tap hole element.                              |
|  <a href="#">UseStandardDepth</a>     | Gets or sets whether to use the standard offset distance for the end condition of this tapered tap hole element. |

[Top](#)

 **See Also**

[ITaperedTapElementData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[ICounterboreElementData Interface](#)  
[ICountersinkElementData Interface](#)  
[IStraightElementData Interface](#)  
[IStraightTapElementData Interface](#)  
[IFeatureManager::AdvancedHole Method \(\)](#)  
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)  
[IAdvancedHoleElementData Interface](#)

**CustomSizing Property (ITaperedTapElementData)**

[See Also](#)



Gets or sets the custom sizing for this tapered tap hole element.

 **.NET Syntax**

Visual Basic (Declaration)

## Property CustomSizing As System.Integer

Visual Basic (Usage)



```
Dim instance As ITaperedTapElementData  
Dim value As System.Integer  
  
instance.CustomSizing = value  
value = instance.CustomSizing
```

C#

```
System.int CustomSizing {get; set;}
```

C++/CLI

```
property System.int CustomSizing {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Custom sizing as defined in [swTaperedTapCustomSizing\\_e](#)

## Visual Basic for Applications (VBA) Syntax

See [TaperedTapElementData::CustomSizing](#).

## Example

See the [ITaperedTapElementData](#) examples.

## See Also

[ITaperedTapElementData Interface](#)  
[ITaperedTapElementData Members](#)

## Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## EndConditionOverride Property (ITaperedTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITaperedTapElementData Interface](#) : EndConditionOverride Property (ITaperedTapElementData)

Gets or sets whether to override the end condition of this tapered tap hole element.

## .NET Syntax

Visual Basic (Declaration)

Property EndConditionOverride As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITaperedTapElementData  
Dim value As System.Boolean  
  
instance.EndConditionOverride = value  
value = instance.EndConditionOverride
```

C#

```
System.bool EndConditionOverride {get; set;}
```

C++/CLI

```
property System.bool EndConditionOverride {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to override the end condition, false to not (see **Remarks**)

### Visual Basic for Applications (VBA) Syntax

See [ITaperedTapElementData::EndConditionOverride](#).

### Example

See the [ITaperedTapElementData](#) examples.

### Remarks

This property can be set only if [IAdvancedHoleFeatureData::UseBaselineDimensions](#) is set to false.

Set this property to true and specify [IAdvancedHoleElementData::EndCondition](#) to override the end condition.

### See Also

[ITaperedTapElementData Interface](#)  
[ITaperedTapElementData Members](#)

### Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ThreadClass Property (ITaperedTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITaperedTapElementData Interface](#) : ThreadClass Property (ITaperedTapElementData)

Gets or sets the thread class for this tapered tap hole element.

### .NET Syntax

Visual Basic (Declaration)

```
Property ThreadClass As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITaperedTapElementData  
Dim value As System.Integer
```

```
instance.ThreadClass = value
```

```
value = instance.ThreadClass
```

C#

```
System.int ThreadClass {get; set;}
```

C++/CLI

```
property System.int ThreadClass {
    System.int get();
    void set ( & System.int value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Thread class as defined in [swTaperedTapThreadClass](#) e

### Visual Basic for Applications (VBA) Syntax

See [TaperedTapElementData::ThreadClass](#).

### Example

See the [ITaperedTapElementData](#) examples.

### Remarks

This property is valid only if [ITaperedTapElementData::ThreadClassOverride](#) is set to true.

### See Also

[ITaperedTapElementData Interface](#)  
[ITaperedTapElementData Members](#)

### Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ThreadClassOverride Property (ITaperedTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITaperedTapElementData Interface](#) : ThreadClassOverride Property (ITaperedTapElementData)

Gets or sets whether to override the thread class of this tapered tap hole element.

### .NET Syntax

#### Visual Basic (Declaration)

```
Property ThreadClassOverride As System.Boolean
```

#### Visual Basic (Usage)



```
Dim instance As ITaperedTapElementData
Dim value As System.Boolean
```

```
instance.ThreadClassOverride = value
```

```
value = instance.ThreadClassOverride
```

#### C#

```
System.bool ThreadClassOverride {get; set;}
```

#### C++/CLI

```
property System.bool ThreadClassOverride {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to override the thread class, false to not

## Visual Basic for Applications (VBA) Syntax

See [ITaperedTapElementData::ThreadClassOverride](#).

## Example

See the [ITaperedTapElementData](#) examples.

## See Also

[ITaperedTapElementData Interface](#)  
[ITaperedTapElementData Members](#)  
[ITaperedTapElementData::ThreadClass Property\(\)](#)

## Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## UseStandardDepth Property (ITaperedTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITaperedTapElementData Interface](#) : UseStandardDepth Property (ITaperedTapElementData)

Gets or sets whether to use the standard offset distance for the end condition of this tapered tap hole element.

## .NET Syntax

Visual Basic (Declaration)

Property UseStandardDepth As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITaperedTapElementData  
Dim value As System.Boolean
```

```
instance.UseStandardDepth = value
```

```
value = instance.UseStandardDepth
```

C#

```
System.bool UseStandardDepth {get; set;}
```

C++/CLI

```
property System.bool UseStandardDepth {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to use the standard offset distance, false to not (see **Remarks**)

## Remarks

This property is valid only if [AdvancedHoleFeatureData::UseBaselineDimensions](#) is set to true.

If this property is set to false, then use [AdvancedHoleElementData::OffsetDistance](#) to set the custom offset distance.

## See Also

[ITaperedTapElementData Interface](#)  
[ITaperedTapElementData Members](#)

## Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0