

SOLIDWORKS API (.NET VBA C#) — Reference (312/337): Tessellation

SOLIDWORKS API Documentation (converted from CHM)

ITessellation (Type)

ITessellation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITessellation Interface

Used to gather tessellation information from a SOLIDWORKS body.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ITessellation
```

Visual Basic (Usage)



```
Dim instance As ITessellation
```

C#

```
public interface ITessellation
```

C++/CLI

```
public interface class ITessellation
```

Visual Basic for Applications (VBA) Syntax

See [Tessellation](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

Remarks

Allows you to specify certain tolerances to adjust the information that is returned that describes the tessellation of this body.

Accessors

[IBody2::GetTessellation](#) and [IBody2::!GetTessellation](#)

Access Diagram

[Tessellation](#)

See Also

[ITessellation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ITessellation Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITessellation Interface

For a list of all members of this type, see [ITessellation members](#).

Public Methods

Name	Description
 GetEdgeFins	Gets all of the fin IDs corresponding to a edge.
 GetErrorList	Gets the tessellation error list.
 GetFaceFacets	Gets the facets IDs that correspond to a SOLIDWORKS face.
 GetFacetCount	Gets the number of facets used to create this tessellation.
 GetFacetFace	Gets a face that corresponds to a facet.
 GetFacetFins	Gets all of the fin IDs of the fins that border this facet.
 GetFinCoFin	Gets the ID of the CoFin that is shared by a fin.
 GetFinCount	Gets the number of fins for this tessellation.
 GetFinEdge	Gets the edge corresponding to a fin.
 GetFinVertices	Gets the IDs of the two vertices that correspond to a fin.
 GetVertexCount	Gets the number of vertices for this tessellation.
 GetVertexNormal	Gets the information that describes the normal direction corresponding to vertex.
 GetVertexParams	Gets the parameters corresponding to a tessellation vertex.
 GetVertexPoint	Gets the X, Y and Z values that describe a tessellation vertex.
 IGetEdgeFins	Gets all of the fin IDs corresponding to a edge.
 IGetEdgeFinsCount	Gets the number of fins corresponding to an edge.
 IGetErrorList	Obsolete. Superseded by ITessellation.IGetErrorList2
 IGetErrorList2	Gets the tessellation error list.
 IGetErrorListCount	Gets number of tessellation errors by error type.
 IGetFaceFacets	Obsolete. Superseded by ITessellation.IGetFaceFacets2
 IGetFaceFacets2	Gets the facets IDs that correspond to a face.
 IGetFaceFacetsCount	Obsolete. Superseded by ITessellation.IGetFaceFacetsCount2
 IGetFaceFacetsCount2	Gets the number of facets corresponding to a face.
 IGetFacetFace	Obsolete. Superseded by ITessellation.IGetFacetFace2
 IGetFacetFace2	Gets a face that corresponds to a facet.
 IGetFacetFins	Gets all of the fin IDs of the fins that border this facet.
 IGetFacetFinsCount	Gets the number of fins corresponding to a facet.
 IGetFinEdge	Gets the edge corresponding to a fin.
 IGetFinVertices	Gets the IDs of the two vertices that correspond to a fin.
 IGetVertexNormal	Gets the information that describes the normal direction corresponding to vertex.
 IGetVertexParams	Gets the parameters corresponding to a tessellation vertex.
 IGetVertexPoint	Gets the X, Y and Z values that describe a tessellation vertex.
 Tessellate	Performs the tessellation.

[Top](#)

See Also

[ITessellation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ITessellation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITessellation Interface

The following tables list the members exposed by [ITessellation](#).

Public Properties

Name	Description
 CurveChordAngleTolerance	Gets or sets the maximum angle, in radians, that is allowed between a chord and its originating curve.
 CurveChordTolerance	Gets or sets the maximum permitted distance from a chord (facet fin) to the curve (edge entity).
 ImprovedQuality	Gets or sets whether to return higher-quality data.
 MatchType	Gets or sets the type of Parasolid facet match for the tessellation.
 MaxFacetWidth	Gets or sets the maximum width of any side of a facet.
 MinFacetWidth	Gets or sets the minimum facet width for this tessellation.
 NeedEdgeFinMap	Gets or sets the need edge fin map option.
 NeedErrorList	Gets or sets the need error list option.
 NeedFaceFacetMap	Gets or sets the need face facet map option.
 NeedVertexNormal	Gets or sets the need vertex normal option.
 NeedVertexParams	Gets or sets the need vertex params option.
 SurfacePlaneAngleTolerance	Gets or sets the surface plane angle tolerance.
 SurfacePlaneTolerance	Gets or sets the surface plane tolerance.

[Top](#)

Public Methods

Name	Description
 GetEdgeFins	Gets all of the fin IDs corresponding to a edge.
 GetErrorList	Gets the tessellation error list.
 GetFaceFacets	Gets the facets IDs that correspond to a SOLIDWORKS face.
 GetFacetCount	Gets the number of facets used to create this tessellation.
 GetFacetFace	Gets a face that corresponds to a facet.
 GetFacetFins	Gets all of the fin IDs of the fins that border this facet.
 GetFinCoFin	Gets the ID of the CoFin that is shared by a fin.
 GetFinCount	Gets the number of fins for this tessellation.
 GetFinEdge	Gets the edge corresponding to a fin.
 GetFinVertices	Gets the IDs of the two vertices that correspond to a fin.
 GetVertexCount	Gets the number of vertices for this tessellation.
 GetVertexNormal	Gets the information that describes the normal direction corresponding to vertex.
 GetVertexParams	Gets the parameters corresponding to a tessellation vertex.
 GetVertexPoint	Gets the X, Y and Z values that describe a tessellation vertex.
 IGetEdgeFins	Gets all of the fin IDs corresponding to a edge.
 IGetEdgeFinsCount	Gets the number of fins corresponding to an edge.
 IGetErrorList	Obsolete. Superseded by ITessellation.IGetErrorList2 .
 IGetErrorList2	Gets the tessellation error list.
 IGetErrorListCount	Gets number of tessellation errors by error type.
 IGetFaceFacets	Obsolete. Superseded by ITessellation.IGetFaceFacets2 .
 IGetFaceFacets2	Gets the facets IDs that correspond to a face.
 IGetFaceFacetsCount	Obsolete. Superseded by ITessellation.IGetFaceFacetsCount2 .
 IGetFaceFacetsCount2	Gets the number of facets corresponding to a face.
 IGetFacetFace	Obsolete. Superseded by ITessellation.IGetFacetFace2 .

		
	IGetFaceFace2	Gets a face that corresponds to a facet.
	IGetFaceFins	Gets all of the fin IDs of the fins that border this facet.
	IGetFaceFinsCount	Gets the number of fins corresponding to a facet.
	IGetFinEdge	Gets the edge corresponding to a fin.
	IGetFinVertices	Gets the IDs of the two vertices that correspond to a fin.
	IGetVertexNormal	Gets the information that describes the normal direction corresponding to vertex.
	IGetVertexParams	Gets the parameters corresponding to a tessellation vertex.
	IGetVertexPoint	Gets the X, Y and Z values that describe a tessellation vertex.
	Tessellate	Performs the tessellation.

[Top](#)

 See Also

[ITessellation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ITessellation Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ITessellation Interface

For a list of all members of this type, see [ITessellation members](#).

 Public Properties

Name	Description
 CurveChordAngleTolerance	Gets or sets the maximum angle, in radians, that is allowed between a chord and its originating curve.
 CurveChordTolerance	Gets or sets the maximum permitted distance from a chord (facet fin) to the curve (edge entity).
 ImprovedQuality	Gets or sets whether to return higher-quality data.
 MatchType	Gets or sets the type of Parasolid facet match for the tessellation.
 MaxFacetWidth	Gets or sets the maximum width of any side of a facet.
 MinFacetWidth	Gets or sets the minimum facet width for this tessellation.
 NeedEdgeFinMap	Gets or sets the need edge fin map option.
 NeedErrorList	Gets or sets the need error list option.
 NeedFaceFacetMap	Gets or sets the need face facet map option.
 NeedVertexNormal	Gets or sets the need vertex normal option.
 NeedVertexParams	Gets or sets the need vertex params option.
 SurfacePlaneAngleTolerance	Gets or sets the surface plane angle tolerance.
 SurfacePlaneTolerance	Gets or sets the surface plane tolerance.

[Top](#)

 See Also

[ITessellation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CurveChordAngleTolerance Property (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : CurveChordAngleTolerance Property (ITessellation)

Gets or sets the maximum angle, in radians, that is allowed between a chord and its originating curve.

Visual Basic Syntax

Visual Basic (Declaration)

Property CurveChordAngleTolerance As System.Double

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Double

instance.CurveChordAngleTolerance = value
value = instance.CurveChordAngleTolerance
```

C#

```
System.double CurveChordAngleTolerance {get; set;}
```

C++/CLI

```
property System.double CurveChordAngleTolerance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value for the curve chord angle tolerance

Visual Basic for Applications (VBA) Syntax

See [Tessellation::CurveChordAngleTolerance](#).

Remarks

This angle is calculated as the sum of the two angles between a chord and the curve tangents, measured at the chord ends.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CurveChordTolerance Property (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : CurveChordTolerance Property (ITessellation)

Gets or sets the maximum permitted distance from a chord (facet fin) to the curve (edge entity).

Visual Basic Syntax

Visual Basic (Declaration)

Property CurveChordTolerance As System.Double

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Double
```

```
instance.CurveChordTolerance = value  
value = instance.CurveChordTolerance
```

C#

```
System.double CurveChordTolerance {get; set;}
```

C++/CLI

```
property System.double CurveChordTolerance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value for the curve chord tolerance

Visual Basic for Applications (VBA) Syntax

See [Tessellation::CurveChordTolerance](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEdgeFins Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetEdgeFins Method (ITessellation)

Gets all of the fin IDs corresponding to a edge.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeFins( _  
    ByVal EdgeDisp As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim EdgeDisp As System.Object  
Dim value As System.Object  
  
value = instance.GetEdgeFins(EdgeDisp)
```

C#

```
System.object GetEdgeFins(  
    System.object EdgeDisp  
)
```

C++/CLI

```
System.Object^ GetEdgeFins(  
& System.Object^ EdgeDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeDisp
[IEdge](#) object

Return Value

Array of long or integer values describing the unique fin ID of every fin shared by this edge

Visual Basic for Applications (VBA) Syntax

See [Tessellation::GetEdgeFins](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::IGetEdgeFins Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetErrorList Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetErrorList Method (ITessellation)

Gets the tessellation error list.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetErrorList( _  
    ByRef FaceErrArray As System.Object, _  
    ByRef FacetErrArray As System.Object, _  
    ByRef VertexPointErrArray As System.Object, _  
    ByRef VertexNormalErrArray As System.Object, _  
    ByRef VertexParamsErrArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FaceErrArray As System.Object  
Dim FacetErrArray As System.Object  
Dim VertexPointErrArray As System.Object  
Dim VertexNormalErrArray As System.Object  
Dim VertexParamsErrArray As System.Object
```

```
instance.GetErrorList(FaceErrArray, FacetErrArray, VertexPointErrArray, VertexNormalErrArray,  
VertexParamsErrArray)
```

C#

```
void GetErrorList(  
    out System.object FaceErrArray,  
    out System.object FacetErrArray,  
    out System.object VertexPointErrArray,  
    out System.object VertexNormalErrArray,  
    out System.object VertexParamsErrArray  
)
```

C++/CLI

```
void GetErrorList(  
& [Out] System.Object^ FaceErrArray,  
& [Out] System.Object^ FacetErrArray,
```



```
& [Out] System.Object^ VertexPointErrArray,  
& [Out] System.Object^ VertexNormalErrArray,  
& [Out] System.Object^ VertexParamsErrArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceErrArray
Array of tessellation faces that have errors
FacetErrArray
Array of tessellation facets that have errors
VertexPointErrArray
Array of tessellation vertex points that have errors
VertexNormalErrArray
Array of tessellation vertex normals that have errors
VertexParamsErrArray
Array of tessellation vertex parameters that have errors

Visual Basic for Applications (VBA) Syntax

See [ITessellation::GetErrorList](#).

Remarks

Before using this method, make sure that you can retrieve the list for the tessellation data that you want to query error information from:

- [ITessellation::NeedVertexNormal](#)
- [ITessellation::NeedVertexParams](#)
- [ITessellation::NeedFaceFacetMap](#)
- [ITessellation::NeedEdgeFinMap](#)
- [ITessellation::NeedErrorList](#)

After using an ITessellation function, you can return error information about any of the tessellation data.

The arrays returned by ITessellation::GetErrorList contains the tessellation entity IDs that have errors:

- Face error: The specified face could not be faceted.
- Facet error: The specified facet is disconnected from its neighboring facets.
- Vertex error: The specified vertex does not match any vertices on adjacent faces. There may be gaps between facets.
- Vertex normal error: The tessellate function could not calculate an accurate vertex normal.
- Vertex parameter error: The tessellate function could not calculate accurate vertex parameters.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::GetErrorList2 Method](#)
[ITessellation::GetErrorListCount Method](#)
[ITessellate::NeedErrorList Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceFacets Method (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetFaceFacets Method (ITessellation)

Gets the facets IDs that correspond to a SOLIDWORKS face.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceFacets( _  
    ByVal Facedisp As System.Object _  
) As System.Object
```

```
Dim instance As ITessellation
Dim Facedisp As System.Object
Dim value As System.Object

value = instance.GetFaceFacets(Facedisp)
```

C#

```
System.object GetFaceFacets(
    System.object Facedisp
)
```

C++/CLI

```
System.Object^ GetFaceFacets(
    & System.Object^ Facedisp
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Facedisp
[Face](#) from which to return the corresponding facet IDs

Return Value

Array of longs or integers (see [Long vs. Integer](#)) that describe the facet IDs that correspond to the face

Visual Basic for Applications (VBA) Syntax

See [Tessellation::GetFaceFacets](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

Remarks

[ITessellation::NeedFaceFacetMap](#) must be set to true to return results.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::IGetFaceFacets2 Method](#)
[ITessellation::IGetFaceFacetsCount2 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacetCount Method (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetFacetCount Method (ITessellation)

Gets the number of facets used to create this tessellation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacetCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ITessellation
Dim value As System.Integer

value = instance.GetFacetCount()
```

C#

```
System.int GetFacetCount()
```

C++/CLI

```
System.int GetFacetCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of facets

Visual Basic for Applications (VBA) Syntax

See [Tessellation::GetFacetCount](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFacetFace Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetFacetFace Method (ITessellation)

Gets a face that corresponds to a facet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacetFace( _
    ByVal FacetId As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim FacetId As System.Integer
Dim value As System.Object

value = instance.GetFacetFace(FacetId)
```

C#

```
System.object GetFacetFace(
    System.int FacetId
)
```

C++/CLI

```
System.Object^ GetFacetFace(  
& System.int FacetId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FacetId

Facet ID of the facet from which to return the face

Return Value

[Face](#) to which that this facet belongs

Visual Basic for Applications (VBA) Syntax

See [Tessellation::GetFacetFace](#).

See Also

[ITessellation Interface](#)

[ITessellation Members](#)

[ITessellation::IGetFacetFace2 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFacetFins Method (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetFacetFins Method (ITessellation)

Gets all of the fin IDs of the fins that border this facet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacetFins( _  
    ByVal FacetId As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FacetId As System.Integer  
Dim value As System.Object  
  
value = instance.GetFacetFins(FacetId)
```

C#

```
System.object GetFacetFins(  
    System.int FacetId  
)
```

C++/CLI

```
System.Object^ GetFacetFins(  
& System.int FacetId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FacetId

ID of the facet to use to return the fin IDs

Return Value

Array of long or integer values that describe the fin IDs

Visual Basic for Applications (VBA) Syntax

See [Tessellation::GetFacetFins](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[Tessellation::GetFacetFins Method](#)
[Tessellation::GetFacetFinsCount Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFinCoFin Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetFinCoFin Method (ITessellation)

Gets the ID of the CoFin that is shared by a fin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFinCoFin( _  
    ByVal FinId As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FinId As System.Integer  
Dim value As System.Integer  
  
value = instance.GetFinCoFin(FinId)
```

C#

```
System.int GetFinCoFin(  
    System.int FinId  
)
```

C++/CLI

```
System.int GetFinCoFin(  
& System.int FinId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FinId

Fin ID that to use to return the cofin ID

Return Value

Long or integer value that describes the ID number of the cofin

Visual Basic for Applications (VBA) Syntax

See [ITessellation::GetFinCoFin](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFinCount Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetFinCount Method (ITessellation)

Gets the number of fins for this tessellation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFinCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim value As System.Integer  
  
value = instance.GetFinCount()
```

C#

```
System.int GetFinCount()
```

C++/CLI

```
System.int GetFinCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of fins for this tessellation

Visual Basic for Applications (VBA) Syntax

See [ITessellation::GetFinCount](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFinEdge Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetFinEdge Method (ITessellation)

Gets the edge corresponding to a fin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFinEdge( _  
    ByVal FinId As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FinId As System.Integer  
Dim value As System.Object  
  
value = instance.GetFinEdge(FinId)
```

C#

```
System.object GetFinEdge(  
    System.int FinId  
)
```

C++/CLI

```
System.Object^ GetFinEdge(  
& System.int FinId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FinId

ID of the fin from which you want to return the edge

Return Value

[Edge](#) with which this fin is shared

Visual Basic for Applications (VBA) Syntax

See [Tessellation::GetFinEdge](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[Tessellation::IGetFinEdge Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFinVertices Method (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetFinVertices Method (ITessellation)

Gets the IDs of the two vertices that correspond to a fin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFinVertices(  
    ByVal FinId As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim FinId As System.Integer
Dim value As System.Object

value = instance.GetFinVertices(FinId)
```

C#

```
System.Object GetFinVertices(
    System.int FinId
)
```

C++/CLI

```
System.Object^ GetFinVertices(
    & System.int FinId
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FinId

Fin ID of the fin from which you want to return the vertices IDs

Return Value

Array of two longs or two integers (see [Long vs. Integer](#)) describing the vertices IDs of a fin

Visual Basic for Applications (VBA) Syntax

See [Tessellation::GetFinVertices](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::IGetFinVertices Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetVertexCount Method (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetVertexCount Method (ITessellation)

Gets the number of vertices for this tessellation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertexCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Integer

value = instance.GetVertexCount()
```


C#

```
System.int GetVertexCount()
```

C++/CLI

```
System.int GetVertexCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of vertices for this tessellation

Visual Basic for Applications (VBA) Syntax

See [Tessellation::GetVertexCount](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVertexNormal Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetVertexNormal Method (ITessellation)

Gets the information that describes the normal direction corresponding to vertex.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertexNormal( _  
    ByVal VertexId As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim VertexId As System.Integer  
Dim value As System.Object  
  
value = instance.GetVertexNormal(VertexId)
```

C#

```
System.object GetVertexNormal(  
    System.int VertexId  
)
```

C++/CLI

```
System.Object^ GetVertexNormal(  
& System.int VertexId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertexId

ID of the vertex from which you want to return the normal information

Return Value

Array of 3 doubles describing the normal vector direction of this vertex corresponding to the face to which it belongs

Visual Basic for Applications (VBA) Syntax

See [ITessellation::GetVertexNormal](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::IGetVertexNormal Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVertexParams Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetVertexParams Method (ITessellation)

Gets the parameters corresponding to a tessellation vertex.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertexParams( _  
    ByVal VertexId As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim VertexId As System.Integer  
Dim value As System.Object  
  
value = instance.GetVertexParams(VertexId)
```

C#

```
System.Object GetVertexParams(  
    System.int VertexId  
)
```

C++/CLI

```
System.Object^ GetVertexParams(  
& System.int VertexId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertexId

ID of the tessellation vertex for which you want to the parameters

Return Value

Array of 17 doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ITessellation::GetVertexParams](#).

Remarks

The following parameters returned from this method are formatted as an array of 17 doubles:

- u, v - location of the vertex on the face (return value position [0-1])
- du - tangent vector at u (return value [2-4])
- dv - tangent vector at v (return value [5-7])
- d2u, dudv, d2v - curvature vectors for u and v (return value [8-16])

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::IGetVertexParams Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVertexPoint Method (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : GetVertexPoint Method (ITessellation)

Gets the X, Y and Z values that describe a tessellation vertex.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertexPoint( _  
    ByVal VertexId As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim VertexId As System.Integer  
Dim value As System.Object  
  
value = instance.GetVertexPoint(VertexId)
```

C#

```
System.object GetVertexPoint(  
    System.int VertexId  
)
```

C++/CLI

```
System.Object^ GetVertexPoint(  
& System.int VertexId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertexId

Tessellation vertex ID of the vertex for which you want to get the X Y Z position values

Return Value

Array of 3 doubles that describe the tessellation vertex's X, Y, and Z position

Visual Basic for Applications (VBA) Syntax

See [ITessellation::GetVertexPoint](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdgeFins Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetEdgeFins Method (ITessellation)

Gets all of the fin IDs corresponding to a edge.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdgeFins( _  
    ByVal EdgeObj As Edge _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim EdgeObj As Edge  
Dim value As System.Integer  
  
value = instance.IGetEdgeFins(EdgeObj)
```

C#

```
System.int IGetEdgeFins(  
    Edge EdgeObj  
)
```

C++/CLI

```
System.int IGetEdgeFins(  
& Edge^ EdgeObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeObj
[IEdge](#) object

Return Value

- in-process, unmanaged C++: Pointer to an array of long or integer values describing the unique fin ID of every fin shared by this edge
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::GetEdgeFins Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdgeFinsCount Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetEdgeFinsCount Method (ITessellation)

Gets the number of fins corresponding to an edge.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdgeFinsCount( _  
    ByVal EdgeObj As Edge _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim EdgeObj As Edge  
Dim value As System.Integer  
  
value = instance.IGetEdgeFinsCount(EdgeObj)
```

C#

```
System.int IGetEdgeFinsCount(  
    Edge EdgeObj  
)
```

C++/CLI

```
System.int IGetEdgeFinsCount(  
& Edge^ EdgeObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeObj

[IEdge](#) object of which to get the number

Return Value

Number of fins corresponding to the specified edge

Visual Basic for Applications (VBA) Syntax

See [Tessellation::IGetEdgeFinsCount](#).

See Also

[ITessellation Interface](#)

[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetErrorList Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetErrorList Method (ITessellation)

Obsolete. Superseded by [ITessellation::IGetErrorList2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub IGetErrorList( _  
    ByRef FaceErrArray As Face, _  
    ByRef FacetErrArray As System.Integer, _  
    ByRef VertexPointErrArray As System.Integer, _  
    ByRef VertexNormalErrArray As System.Integer, _  
    ByRef VertexParamsErrArray As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FaceErrArray As Face  
Dim FacetErrArray As System.Integer  
Dim VertexPointErrArray As System.Integer  
Dim VertexNormalErrArray As System.Integer  
Dim VertexParamsErrArray As System.Integer  
  
instance.IGetErrorList(FaceErrArray, FacetErrArray, VertexPointErrArray, VertexNormalErrArray, VertexParamsErrArray)
```

C#

```
void IGetErrorList(  
    out Face FaceErrArray,  
    out System.int FacetErrArray,  
    out System.int VertexPointErrArray,  
    out System.int VertexNormalErrArray,  
    out System.int VertexParamsErrArray  
)
```

C++/CLI

```
void IGetErrorList(  
& [Out] Face^ FaceErrArray,  
& [Out] System.int FacetErrArray,  
& [Out] System.int VertexPointErrArray,  
& [Out] System.int VertexNormalErrArray,  
& [Out] System.int VertexParamsErrArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceErrArray

FacetErrArray

VertexPointErrArray

VertexNormalErrArray

VertexParamsErrArray

Visual Basic for Applications (VBA) Syntax

See [Tessellation::IGetErrorList](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Gets the tessellation error list.

 .NET Syntax

Visual Basic (Declaration)

```
Sub IGetErrorList2( _
    ByRef FaceErrArray As Face2, _
    ByRef FacetErrArray As System.Integer, _
    ByRef VertexPointErrArray As System.Integer, _
    ByRef VertexNormalErrArray As System.Integer, _
    ByRef VertexParamsErrArray As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim FaceErrArray As Face2
Dim FacetErrArray As System.Integer
Dim VertexPointErrArray As System.Integer
Dim VertexNormalErrArray As System.Integer
Dim VertexParamsErrArray As System.Integer

instance.IGetErrorList2(FaceErrArray, FacetErrArray, VertexPointErrArray, VertexNormalErrArray, VertexParamsErrArray)
```

C#

```
void IGetErrorList2(
    out Face2 FaceErrArray,
    out System.int FacetErrArray,
    out System.int VertexPointErrArray,
    out System.int VertexNormalErrArray,
    out System.int VertexParamsErrArray
)
```

C++/CLI

```
void IGetErrorList2(
    & [Out] Face2^ FaceErrArray,
    & [Out] System.int FacetErrArray,
    & [Out] System.int VertexPointErrArray,
    & [Out] System.int VertexNormalErrArray,
    & [Out] System.int VertexParamsErrArray
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Parameters***FaceErrArray*

- in-process, unmanaged C++: Pointer to an array of [faces](#) that have errors

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.*FacetErrArray*

- in-process, unmanaged C++: Pointer to an array of longs or integers describing the facets with errors
- VBA, VB.NET, C#, and C++/CLI: Not supported

VertexPointErrArray

- in-process, unmanaged C++: Pointer to an array of longs or integers of vertex point IDs from FacetErrArray
- VBA, VB.NET, C#, and C++/CLI: Not supported

VertexNormalErrArray

- in-process, unmanaged C++: Pointer to an array of longs or integers of vertex normal IDs from FacetErrArray
- VBA, VB.NET, C#, and C++/CLI: Not supported

VertexParamsErrArray

- in-process, unmanaged C++: Pointer to an array of longs or integers of vertex parameters IDs from facetErrArray
- VBA, VB.NET, C#, and C++/CLI: Not supported

 Remarks

Before using this method, make sure that you can retrieve the list for the tessellation data that you want to query error information from:

- [ITessellation::NeedVertexNormal](#)
- [ITessellation::NeedVertexParams](#)

- [ITessellation::NeedFaceFacetMap](#)
- [ITessellation::NeedEdgeFinMap](#)
- [ITessellation::NeedErrorList](#)

After using an ITessellation function, you can return error information about any of the tessellation data.

The arrays returned by ITessellation::GetErrorList contains the tessellation entity IDs that have errors:

- Face error: The specified face could not be faceted.
- Facet error: The specified facet is disconnected from its neighboring facets.
- Vertex error: The specified vertex does not match any vertices on adjacent faces. There may be gaps between facets.
- Vertex normal error: The tessellate function could not calculate an accurate vertex normal.
- Vertex parameter error: The tessellate function could not calculate accurate vertex parameters.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::GetErrorList Method](#)
[ITessellation::IGetErrorListCount Method](#)
[ITessellate::NeedErrorList Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetErrorListCount Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetErrorListCount Method (ITessellation)

Gets number of tessellation errors by error type.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetErrorListCount( _
    ByRef FaceErrArrayCount As System.Integer, _
    ByRef FacetErrArrayCount As System.Integer, _
    ByRef VertexPointErrArrayCount As System.Integer, _
    ByRef VertexNormalErrArrayCount As System.Integer, _
    ByRef VertexParamsErrArrayCount As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim FaceErrArrayCount As System.Integer
Dim FacetErrArrayCount As System.Integer
Dim VertexPointErrArrayCount As System.Integer
Dim VertexNormalErrArrayCount As System.Integer
Dim VertexParamsErrArrayCount As System.Integer

instance.IGetErrorListCount(FaceErrArrayCount, FacetErrArrayCount, VertexPointErrArrayCount,
VertexNormalErrArrayCount, VertexParamsErrArrayCount)
```

C#

```
void IGetErrorListCount(
    out System.int FaceErrArrayCount,
    out System.int FacetErrArrayCount,
    out System.int VertexPointErrArrayCount,
    out System.int VertexNormalErrArrayCount,
    out System.int VertexParamsErrArrayCount
)
```

C++/CLI


```

void IGetErrorListCount(
& [Out] System.int FaceErrArrayCount,
& [Out] System.int FacetErrArrayCount,
& [Out] System.int VertexPointErrArrayCount,
& [Out] System.int VertexNormalErrArrayCount,
& [Out] System.int VertexParamsErrArrayCount
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceErrArrayCount

Number of face errors

FacetErrArrayCount

Number of facet errors

VertexPointErrArrayCount

Number of vertex point errors

VertexNormalErrArrayCount

Number of vertex point errors

VertexParamsErrArrayCount

Number of vertex parameter errors

Visual Basic for Applications (VBA) Syntax

See [Tessellation::IGetErrorListCount](#).

See Also

[ITessellation Interface](#)

[ITessellation Members](#)

[ITessellation::IGetErrorList2 Method](#)

[ITessellation::GetErrorList Method](#)

[ITessellate::NeedErrorList Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaceFacets Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetFaceFacets Method (ITessellation)

Obsolete. Superseded by [ITessellation::IGetFaceFacets2](#).

.NET Syntax

Visual Basic (Declaration)

```

Function IGetFaceFacets( _
    ByVal FaceObj As Face _
) As System.Integer

```

Visual Basic (Usage)



```

Dim instance As ITessellation
Dim FaceObj As Face
Dim value As System.Integer

```

```
value = instance.IGetFaceFacets(FaceObj)
```

C#

```

System.int IGetFaceFacets(
    Face FaceObj
)

```

C++/CLI

```
System.int IGetFaceFacets(  
& Face^ FaceObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceObj

Visual Basic for Applications (VBA) Syntax

See [ITessellation::IGetFaceFacets](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFaceFacets2 Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetFaceFacets2 Method (ITessellation)

Gets the facets IDs that correspond to a face.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaceFacets2(  
    ByVal FaceObj As Face2  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FaceObj As Face2  
Dim value As System.Integer  
  
value = instance.IGetFaceFacets2(FaceObj)
```

C#

```
System.int IGetFaceFacets2(  
    Face2 FaceObj  
)
```

C++/CLI

```
System.int IGetFaceFacets2(  
& Face2^ FaceObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceObj

[Face](#) from which you want to return the corresponding facet IDs

Return Value

- in-process, unmanaged C++: Pointer to an array of longs or integers that describe the facet IDs that correspond to the face
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

[ITessellation::NeedFaceFacetMap](#) must be set to true to return results.

Before calling this method, call [ITessellation::IGetFaceFacetsCount2](#) to fetch the raw facet data. ITessellation::IGetFaceFacets2 clears the cache of raw facet data.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::GetFaceFacets Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaceFacetsCount Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetFaceFacetsCount Method (ITessellation)

Obsolete. Superseded by [ITessellation::IGetFaceFacetsCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaceFacetsCount( _  
    ByVal FaceObj As Face _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FaceObj As Face  
Dim value As System.Integer  
  
value = instance.IGetFaceFacetsCount(FaceObj)
```

C#

```
System.int IGetFaceFacetsCount(  
    Face FaceObj  
)
```

C++/CLI

```
System.int IGetFaceFacetsCount(  
& Face^ FaceObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceObj

Visual Basic for Applications (VBA) Syntax

See [Tessellation::IGetFaceFacetsCount](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaceFacetsCount2 Method (ITessellation)

[See Also](#)



Gets the number of facets corresponding to a face.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaceFacetsCount2( _  
    ByVal FaceObj As Face2 _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FaceObj As Face2  
Dim value As System.Integer  
  
value = instance.IGetFaceFacetsCount2(FaceObj)
```

C#

```
System.int IGetFaceFacetsCount2(  
    Face2 FaceObj  
)
```

C++/CLI

```
System.int IGetFaceFacetsCount2(  
& Face2^ FaceObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceObj
Face on which to count the facets

Return Value

Number of facets

Visual Basic for Applications (VBA) Syntax

See [Tessellation::IGetFaceFacetsCount2](#).

Remarks

This method caches the raw facet data after determining the number of facets. A subsequent call to [ITessellation::IGetFaceFacets2](#) does not have to fetch the facet data again.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::GetFaceFacets Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IGetFacetFace Method (ITessellation)

[See Also](#)



Obsolete. Superseded by [ITessellation::IGetFacetFace2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFacetFace( _  
    ByVal FacetId As System.Integer _  
) As Face
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FacetId As System.Integer  
Dim value As Face  
  
value = instance.IGetFacetFace(FacetId)
```

C#

```
Face IGetFacetFace(  
    System.int FacetId  
)
```

C++/CLI

```
Face^ IGetFacetFace(  
& System.int FacetId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FacetId

Visual Basic for Applications (VBA) Syntax

See [Tessellation::IGetFacetFace](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFacetFace2 Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetFacetFace2 Method (ITessellation)

Gets a face that corresponds to a facet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFacetFace2( _  
    ByVal FacetId As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FacetId As System.Integer  
Dim value As Face2  
  
value = instance.IGetFacetFace2(FacetId)
```

C#

```
Face2 IGetFacetFace2(  
    System.int FacetId  
)
```

```
)
```

C++/CLI

```
Face2^ IGetFacetFace2(  
& System.int FacetId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FacetId

Facet ID of the facet from which you want to return the face pointer

Return Value

[Face](#) to which this facet belongs

Visual Basic for Applications (VBA) Syntax

See [ITessellation::IGetFacetFace2](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::IGetFacetFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFacetFins Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetFacetFins Method (ITessellation)

Gets all of the fin IDs of the fins that border this facet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFacetFins( _  
    ByVal FacetId As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FacetId As System.Integer  
Dim value As System.Integer
```

```
value = instance.IGetFacetFins(FacetId)
```

C#

```
System.int IGetFacetFins(  
    System.int FacetId  
)
```

C++/CLI

```
System.int IGetFacetFins(  
& System.int FacetId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FacetId

ID of the facet to use to return the fin IDs

Return Value

- in-process, unmanaged C++: Pointer to an array of long or integer values that describe the fin IDs
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

A cache is created when you use [ITessellation::IGetFacetFinsCount](#). This cache is released when you use [ITessellation::IGetFacetFins](#). If you use [ITessellation::IGetFacetFinsCount](#) again, then the cache is refilled. Alternatively, you can use [ITessellation::IGetFacetFins](#) repeatedly.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::GetFacetFins Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFacetFinsCount Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetFacetFinsCount Method (ITessellation)

Gets the number of fins corresponding to a facet.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetFacetFinsCount( _  
    ByVal FacetId As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FacetId As System.Integer  
Dim value As System.Integer  
  
value = instance.IGetFacetFinsCount(FacetId)
```

C#

```
System.int IGetFacetFinsCount(  
    System.int FacetId  
)
```

C++/CLI

```
System.int IGetFacetFinsCount(  
& System.int FacetId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FacetId

Facet for which to count fins

Return Value

Number of fins corresponding to FacetId

Visual Basic for Applications (VBA) Syntax

See [ITessellation::IGetFacetFinsCount](#).

Remarks

A cache is created when you use this method. This cache is released when you use [ITessellation::IGetFacetFins](#). If you use [ITessellation::IGetFacetFinsCount](#) again, then the cache is refilled. Alternatively, you can use [ITessellation::IGetFacetFins](#) repeatedly.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::GetFacetFins Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFinEdge Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetFinEdge Method (ITessellation)

Gets the edge corresponding to a fin.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFinEdge( _  
    ByVal FinId As System.Integer _  
) As Edge
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FinId As System.Integer  
Dim value As Edge  
  
value = instance.IGetFinEdge(FinId)
```

C#

```
Edge IGetFinEdge(  
    System.int FinId  
)
```

C++/CLI

```
Edge^ IGetFinEdge(  
& System.int FinId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FinId

ID of the fin from which you want to return the edge

Return Value

[Edge](#) with which this fin is shared

Visual Basic for Applications (VBA) Syntax

See [ITessellation::IGetFinEdge](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0 [ITessellate::GetFinEdge Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFinVertices Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetFinVertices Method (ITessellation)

Gets the IDs of the two vertices that correspond to a fin.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFinVertices( _  
    ByVal FinId As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim FinId As System.Integer  
Dim value As System.Integer  
  
value = instance.IGetFinVertices(FinId)
```

C#

```
System.int IGetFinVertices(  
    System.int FinId  
)
```

C++/CLI

```
System.int IGetFinVertices(  
& System.int FinId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FinId

Fin ID of the fin from which you want to return the vertices

Return Value

- in-process, unmanaged C++: Pointer to an array of two longs or integers describing the vertices IDs of a fin
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::GetFinVertices Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetVertexNormal Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetVertexNormal Method (ITessellation)

Gets the information that describes the normal direction corresponding to vertex.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVertexNormal( _  
    ByVal VertexId As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim VertexId As System.Integer  
Dim value As System.Double  
  
value = instance.IGetVertexNormal(VertexId)
```

C#

```
System.double IGetVertexNormal(  
    System.int VertexId  
)
```

C++/CLI

```
System.double IGetVertexNormal(  
    & System.int VertexId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertexId

ID of the vertex from which you want to return the normal information

Return Value

Array of 3 doubles describing the normal vector direction of this vertex corresponding to the face to which it belongs

Visual Basic for Applications (VBA) Syntax

See [Tessellation::IGetVertexNormal](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::GetVertexNormal Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetVertexParams Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetVertexParams Method (ITessellation)

Gets the parameters corresponding to a tessellation vertex.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVertexParams( _  
    ByVal VertexId As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim VertexId As System.Integer  
Dim value As System.Double  
  
value = instance.IGetVertexParams(VertexId)
```

C#

```
System.double IGetVertexParams(  
    System.int VertexId  
)
```

C++/CLI

```
System.double IGetVertexParams(  
& System.int VertexId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertexId

ID of the tessellation vertex for which you want to the parameters

Return Value

- in-process, unmanaged C++: Pointer to an array of contains 17 doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The following parameters returned from this method are formatted as an array of 17 doubles:

- u, v - location of the vertex on the face (return value position [0-1])
- du - tangent vector at u (return value [2-4])
- dv - tangent vector at v (return value [5-7])
- d2u, dudv, d2v - curvature vectors for u and v (return value [8-16])

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::GetVertexParams Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetVertexPoint Method (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : IGetVertexPoint Method (ITessellation)

Gets the X, Y and Z values that describe a tessellation vertex.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVertexPoint( _  
    ByVal VertexId As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim VertexId As System.Integer  
Dim value As System.Double  
  
value = instance.IGetVertexPoint(VertexId)
```

C#

```
System.double IGetVertexPoint(  
    System.int VertexId  
)
```

C++/CLI

```
System.double IGetVertexPoint(  
&    System.int VertexId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertexId

Tessellation vertex ID of the vertex for which you want to get the X Y Z position values

Return Value

Array of 3 doubles that describe the tessellation vertex's X, Y, and Z position

Visual Basic for Applications (VBA) Syntax

See [Tessellation::IGetVertexPoint](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::GetVertexParams Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImprovedQuality Property (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : ImprovedQuality Property (ITessellation)

Gets or sets whether to return higher-quality data.

.NET Syntax

Visual Basic (Declaration)

```
Property ImprovedQuality As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim value As System.Boolean  
  
instance.ImprovedQuality = value
```

```
value = instance.ImprovedQuality
```

C#

```
System.bool ImprovedQuality {get; set;}
```

C++/CLI

```
property System.bool ImprovedQuality {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to return higher-quality tessellation analysis data; false to return tessellation rendering data

Visual Basic for Applications (VBA) Syntax

See [Tessellation::ImprovedQuality](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

Remarks

If this property is not set, tessellation rendering data is returned by default.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MatchType Property (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : MatchType Property (ITessellation)

Gets or sets the type of Parasolid facet match for the tessellation.

.NET Syntax

Visual Basic (Declaration)

```
Property MatchType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim value As System.Integer
```

```
instance.MatchType = value
```

```
value = instance.MatchType
```

C#

```
System.int MatchType {get; set;}
```

C++/CLI

```
property System.int MatchType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of match as defined by [swTessellationMatchType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Tessellation::MatchType](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaxFacetWidth Property (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : MaxFacetWidth Property (ITessellation)

Gets or sets the maximum width of any side of a facet.

.NET Syntax

Visual Basic (Declaration)

```
Property MaxFacetWidth As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Double

instance.MaxFacetWidth = value
value = instance.MaxFacetWidth
```

C#

```
System.double MaxFacetWidth {get; set;}
```

C++/CLI

```
property System.double MaxFacetWidth {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum facet width

Visual Basic for Applications (VBA) Syntax

See [ITessellation::MaxFacetWidth](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::MinFacetWidth Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MinFacetWidth Property (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : MinFacetWidth Property (ITessellation)

Gets or sets the minimum facet width for this tessellation.

.NET Syntax

Visual Basic (Declaration)

Property MinFacetWidth As System.Double

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim value As System.Double  
  
instance.MinFacetWidth = value  
  
value = instance.MinFacetWidth
```

C#

```
System.double MinFacetWidth {get; set;}
```

C++/CLI

```
property System.double MinFacetWidth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Minimum tessellation width

Visual Basic for Applications (VBA) Syntax

See [ITessellation::MinFacetWidth](#).

Remarks

The default value for the underlying modeler is used when tessellating.

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::MaxFacetWidth Property](#)

Availability

SolidWork s2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NeedEdgeFinMap Property (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : NeedEdgeFinMap Property (ITessellation)

Gets or sets the need edge fin map option.

.NET Syntax

Visual Basic (Declaration)

Property NeedEdgeFinMap As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim value As System.Boolean
```

```
instance.NeedEdgeFinMap = value
```

```
value = instance.NeedEdgeFinMap
```

C#

```
System.bool NeedEdgeFinMap {get; set;}
```

C++/CLI

```
property System.bool NeedEdgeFinMap {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True generates this information, false does not

Visual Basic for Applications (VBA) Syntax

See [Tessellation::NeedEdgeFinMap](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NeedErrorList Property (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : NeedErrorList Property (ITessellation)

Gets or sets the need error list option.

.NET Syntax

Visual Basic (Declaration)

Property NeedErrorList As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Boolean

instance.NeedErrorList = value

value = instance.NeedErrorList
```

C#

```
System.bool NeedErrorList {get; set;}
```

C++/CLI

```
property System.bool NeedErrorList {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True generates need error list option, false to not

Visual Basic for Applications (VBA) Syntax

See [Tessellation::NeedErrorList](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::GetErrorList Method](#)
[ITessellate::IGetErrorList2 Method](#)
[ITessellate::IGetErrorListCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

NeedFaceFacetMap Property (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : NeedFaceFacetMap Property (ITessellation)

Gets or sets the need face facet map option.

.NET Syntax

Visual Basic (Declaration)

Property NeedFaceFacetMap As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Boolean

instance.NeedFaceFacetMap = value

value = instance.NeedFaceFacetMap
```

C#

```
System.bool NeedFaceFacetMap {get; set;}
```

C++/CLI

```
property System.bool NeedFaceFacetMap {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True generates this information, false does not

Visual Basic for Applications (VBA) Syntax

See [ITessellation::NeedFaceFacetMap](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

NeedVertexNormal Property (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : NeedVertexNormal Property (ITessellation)

Gets or sets the need vertex normal option.

.NET Syntax

Visual Basic (Declaration)

```
Property NeedVertexNormal As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Boolean

instance.NeedVertexNormal = value

value = instance.NeedVertexNormal
```

C#

```
System.bool NeedVertexNormal {get; set;}
```

C++/CLI

```
property System.bool NeedVertexNormal {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True generates this information, false does not

Visual Basic for Applications (VBA) Syntax

See [ITessellation::NeedVertexNormal](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

NeedVertexParams Property (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : NeedVertexParams Property (ITessellation)

Gets or sets the need vertex params option.

.NET Syntax

Visual Basic (Declaration)

Property NeedVertexParams As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Boolean

instance.NeedVertexParams = value

value = instance.NeedVertexParams
```

C#

```
System.bool NeedVertexParams {get; set;}
```

C++/CLI

```
property System.bool NeedVertexParams {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True generates this information, false does not

Visual Basic for Applications (VBA) Syntax

See [ITessellation::NeedVertexParams](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SurfacePlaneAngleTolerance Property (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : SurfacePlaneAngleTolerance Property (ITessellation)

Gets or sets the surface plane angle tolerance.

.NET Syntax

Visual Basic (Declaration)

Property SurfacePlaneAngleTolerance As System.Double

Visual Basic (Usage)



```
Dim instance As ITessellation
Dim value As System.Double

instance.SurfacePlaneAngleTolerance = value
value = instance.SurfacePlaneAngleTolerance
```

C#

```
System.double SurfacePlaneAngleTolerance {get; set;}
```

C++/CLI

```
property System.double SurfacePlaneAngleTolerance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Surface plane angle tolerance

Visual Basic for Applications (VBA) Syntax

See [Tessellation::SurfacePlaneAngleTolerance](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellation::SurfacePlaneTolerance Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SurfacePlaneTolerance Property (ITessellation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : SurfacePlaneTolerance Property (ITessellation)

Gets or sets the surface plane tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Property SurfacePlaneTolerance As System.Double
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim value As System.Double  
  
instance.SurfacePlaneTolerance = value  
value = instance.SurfacePlaneTolerance
```

C#

```
System.double SurfacePlaneTolerance {get; set;}
```

C++/CLI

```
property System.double SurfacePlaneTolerance {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Surface plane tolerance

Visual Basic for Applications (VBA) Syntax

See [Tessellate::SurfacePlaneTolerance](#).

See Also

[ITessellation Interface](#)
[ITessellation Members](#)
[ITessellate::SurfacePlaneAngleTolerance Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Tessellate Method (ITessellation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITessellation Interface](#) : Tessellate Method (ITessellation)

Performs the tessellation.

.NET Syntax

Visual Basic (Declaration)

```
Function Tessellate() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITessellation  
Dim value As System.Boolean  
  
value = instance.Tessellate()
```

C#

```
System.bool Tessellate()
```

C++/CLI

```
System.bool Tessellate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Tessellation::Tessellate](#).

Example

[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)

See Also

[ITessellation Interface](#)
[ITessellation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0