

# SOLIDWORKS API (.NET VBA C#) — Reference

## (313/337): ITextAndCustomProperty-ITexture

SOLIDWORKS API Documentation (converted from CHM)

# ITextAndCustomProperty (Type)

## ITextAndCustomProperty Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITextAndCustomProperty Interface

Gains access to the text and custom properties in a [theme](#) of a [SOLIDWORKS MBD 3D PDF](#).

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface ITextAndCustomProperty
```

Visual Basic (Usage)

```
Dim instance As ITextAndCustomProperty
```

C#

```
public interface ITextAndCustomProperty
```

C++/CLI

```
public interface class ITextAndCustomProperty
```

### Visual Basic for Applications (VBA) Syntax

See [TextAndCustomProperty](#).

### Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

### Remarks

SOLIDWORKS Model Based Definition (MBD) is an integrated drawingless manufacturing solution for SOLIDWORKS.

Typical steps for generating a SOLIDWORKS MBD 3D PDF using the SOLIDWORKS API are:

1. Get the [IMBD3DPdfData](#) object using [IModelDocExtension::GetMBD3DPdfData](#).
2. Set the path and file name of the SOLIDWORKS MBD 3D PDF theme using [IMBD3DPdfData::ThemeName](#).
3. Get standard and custom views using [IMBD3DPdfData::GetStandardViews](#) and [IMBD3DPdfData::GetMoreViews](#).
4. Set standard and custom views using [IMBD3DPdfData::SetStandardViews](#) and [IMBD3DPdfData::SetMoreViews](#).
5. Get and set text and custom properties in the theme using the array of objects returned by this interface's accessor. See the **Accessors** section.
6. Set the path for the SOLIDWORKS MBD 3D PDF using [IMBD3DPdfData::FilePath](#).
7. Generate the SOLIDWORKS MBD 3D PDF using [IModelDocExtension::PublishTo3DPDF](#).

See the SOLIDWORKS Help for details about MBD.

### Accessors

[IMBD3DPdfData::GetTextAndCustomProperties](#)

### Access Diagram

[TextAndCustomProperty](#)

### See Also

[ITextAndCustomProperty Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)

[See Also](#) [Properties](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITextAndCustomProperty Interface

The following tables list the members exposed by [ITextAndCustomProperty](#).

 **Public Properties**

| Name                                                                                                                 | Description                                                                                                                    |
|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">CustomPropertyName</a> | Gets or sets the name of the custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> .          |
|  <a href="#">Description</a>        | Gets the description of the text or custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> .   |
|  <a href="#">IsCustomProperty</a>   | Gets whether this is text or a custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> .        |
|  <a href="#">Name</a>               | Gets the name of the text or custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> .          |
|  <a href="#">Value</a>              | Gets or sets the value of the text or custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> . |

[Top](#)

 **See Also**

[ITextAndCustomProperty Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

**ITextAndCustomProperty Interface Properties**

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITextAndCustomProperty Interface

For a list of all members of this type, see [ITextAndCustomProperty members](#).

 **Public Properties**

| Name                                                                                                                   | Description                                                                                                                    |
|------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">CustomPropertyName</a> | Gets or sets the name of the custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> .          |
|  <a href="#">Description</a>        | Gets the description of the text or custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> .   |
|  <a href="#">IsCustomProperty</a>   | Gets whether this is text or a custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> .        |
|  <a href="#">Name</a>               | Gets the name of the text or custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> .          |
|  <a href="#">Value</a>              | Gets or sets the value of the text or custom property in a <a href="#">theme</a> for a <a href="#">SOLIDWORKS MBD 3D PDF</a> . |

[Top](#)

 **See Also**

[ITextAndCustomProperty Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

**CustomPropertyName Property (ITextAndCustomProperty)**

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextAndCustomProperty Interface](#) : CustomPropertyName Property (ITextAndCustomProperty)

Gets or sets the name of the custom property in a [theme](#) for a [SOLIDWORKS MBD 3D PDF](#).

 **.NET Syntax**

Visual Basic (Declaration)

Property CustomPropertyName As System.String

Visual Basic (Usage)



```
Dim instance As ITextAndCustomProperty  
Dim value As System.String
```

```
instance.CustomPropertyName = value  
value = instance.CustomPropertyName
```

C#

```
System.string CustomPropertyName {get; set;}
```

C++/CLI

```
property System.String^ CustomPropertyName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Name of custom property

### Visual Basic for Applications (VBA) Syntax

See [TextAndCustomProperty::CustomPropertyName](#).

### Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

### Remarks

This property corresponds to the **Custom property** text box in a **Custom Property Field** group box in a theme.

### See Also

[ITextAndCustomProperty Interface](#)  
[ITextAndCustomProperty Members](#)

### Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Description Property (ITextAndCustomProperty)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextAndCustomProperty Interface](#) : Description Property (ITextAndCustomProperty)

Gets the description of the text or custom property in a [theme](#) for a [SOLIDWORKS MBD 3D PDF](#).

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Description As System.String
```

Visual Basic (Usage)



```
Dim instance As ITextAndCustomProperty  
Dim value As System.String
```

```
value = instance.Description
```

C#

```
System.string Description {get;}
```

C++/CLI

```
property System.String^ Description {
    System.String^ get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Description

### Visual Basic for Applications (VBA) Syntax

See [TextAndCustomProperty::Description](#).

### Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

### Remarks

This property corresponds to the **Instructions** text box in a **Text Field** or **Custom Property Field** group box in a theme.

### See Also

[ITextAndCustomProperty Interface](#)  
[ITextAndCustomProperty Members](#)

### Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IsCustomProperty Property (ITextAndCustomProperty)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextAndCustomProperty Interface](#) : IsCustomProperty Property (ITextAndCustomProperty)

Gets whether this is text or a custom property in a [theme](#) for a [SOLIDWORKS MBD 3D PDF](#).

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property IsCustomProperty As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITextAndCustomProperty  
Dim value As System.Boolean
```

```
value = instance.IsCustomProperty
```

C#

```
System.bool IsCustomProperty {get;}
```

C++/CLI

```
property System.bool IsCustomProperty {  
    System.bool get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True if a custom property, false if text

## Visual Basic for Applications (VBA) Syntax

See [TextAndCustomProperty::IsCustomProperty](#).

## Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

## Remarks

This property corresponds to a **Text Field** or **Custom Property Field** group box in a theme.

## See Also

[ITextAndCustomProperty Interface](#)  
[ITextAndCustomProperty Members](#)

## Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Name Property (ITextAndCustomProperty)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextAndCustomProperty Interface](#) : Name Property (ITextAndCustomProperty)

Gets the name of the text or custom property in a [theme](#) for a [SOLIDWORKS MBD 3D PDF](#).

## .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As ITextAndCustomProperty  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Name of the text or custom property

## Visual Basic for Applications (VBA) Syntax

See [TextAndCustomProperty::Name](#).

## Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

## Remarks

This property corresponds to the **Field name** text box in a **Text Field** or **Custom Property Field** group box in a theme.

## See Also

[ITextAndCustomProperty Interface](#)  
[ITextAndCustomProperty Members](#)

## Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Value Property (ITextAndCustomProperty)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextAndCustomProperty Interface](#) : Value Property (ITextAndCustomProperty)

Gets or sets the value of the text or custom property in a [theme](#) for a [SOLIDWORKS MBD 3D PDF](#).

## .NET Syntax

Visual Basic (Declaration)

Property Value As System.String

Visual Basic (Usage)



```
Dim instance As ITextAndCustomProperty  
Dim value As System.String
```

```
instance.Value = value
```

```
value = instance.Value
```

C#

```
System.string Value {get; set;}
```

C++/CLI

```
property System.String^ Value {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Value

## Visual Basic for Applications (VBA) Syntax

See [TextAndCustomProperty.Value](#).

## Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)  
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

## See Also

[ITextAndCustomProperty Interface](#)  
[ITextAndCustomProperty Members](#)



# ITextFormat (Type)

## ITextFormat Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITextFormat Interface

Allows access to and control of the formatting of text used in annotations.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface ITextFormat
```

Visual Basic (Usage)

```
Dim instance As ITextFormat
```

C#

```
public interface ITextFormat
```

C++/CLI

```
public interface class ITextFormat
```

### Visual Basic for Applications (VBA) Syntax

See [TextFormat](#).

### Example

[Get All Elements of Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

### Accessors

[IAnnotation::GetTextFormat](#) and [IAnnotation::IGetTextFormat](#)  
[ICallout::TextFormat](#)  
[IDetailCircle::GetTextFormat](#)  
[IDrSection::GetTextFormat](#) and [IDrSection::IGetTextFormat](#)  
[IModelDocExtension::GetUserPreferenceTextFormat](#)  
[IPageSetup::FooterTextFormat](#)  
[IPageSetup::HeaderTextFormat](#)  
[IParagraphs::GetTextSegmentFormat](#)  
[IProjectionArrow::GetTextFormat](#) and [IProjectionArrow::IGetTextFormat](#)  
[ISketchText::GetTextFormat](#) and [ISketchText::IGetTextFormat](#)  
[ITableAnnotation::GetCellTextFormat](#)  
[ITableAnnotation::GetTextFormat](#)

### Access Diagram

[TextFormat](#)

### See Also

ITextFormat Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITextFormat Interface

The following tables list the members exposed by [ITextFormat](#).

 **Public Properties**

| Name                                                                                                                | Description                                                           |
|---------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
|  <a href="#">BackWards</a>         | Gets or sets whether the text is displayed backwards.                 |
|  <a href="#">Bold</a>              | Gets or sets the whether the text format is bold.                     |
|  <a href="#">CharHeight</a>        | Gets or sets the height of the font in meters.                        |
|  <a href="#">CharHeightInPts</a>   | Gets or sets the height of the font in points.                        |
|  <a href="#">CharSpacingFactor</a> | Gets or sets the factor that controls the spacing between characters. |
|  <a href="#">Escapement</a>        | Gets or sets the text angle in radians.                               |
|  <a href="#">Italic</a>            | Gets or sets the whether the text format is italic.                   |
|  <a href="#">LineLength</a>        | Gets or sets the text line length in meters.                          |
|  <a href="#">LineSpacing</a>       | Gets or sets the text line spacing.                                   |
|  <a href="#">ObliqueAngle</a>      | Gets or sets the text slant.                                          |
|  <a href="#">Strikeout</a>         | Gets or sets the whether the text format is strikeout.                |
|  <a href="#">TypeFaceName</a>      | Gets or sets the name of the font.                                    |
|  <a href="#">Underline</a>         | Gets or sets the whether the text format is underlined.               |
|  <a href="#">UpsideDown</a>       | Gets or sets whether the whole text string is upside down.            |
|  <a href="#">Vertical</a>        | Gets or sets the individual characters as vertical.                   |
|  <a href="#">WidthFactor</a>     | Stretches the text by the specified factor.                           |

[Top](#)

 **Public Methods**

| Name                                                                                                                       | Description                                                     |
|----------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|
|  <a href="#">IsHeightSpecifiedInPts</a> | Gets whether the character height is in points or system units. |

[Top](#)

 **See Also**

[ITextFormat Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

ITextFormat Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ITextFormat Interface

For a list of all members of this type, see [ITextFormat members](#).

 **Public Methods**

| Name                                                                                                                       | Description                                                     |
|----------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|
|  <a href="#">IsHeightSpecifiedInPts</a> | Gets whether the character height is in points or system units. |

[Top](#)

 See Also

[ITextFormat Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ITextFormat Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITextFormat Interface

For a list of all members of this type, see [ITextFormat members](#).

 Public Properties

| Name                                                                                                                | Description                                                           |
|---------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
|  <a href="#">BackWards</a>         | Gets or sets whether the text is displayed backwards.                 |
|  <a href="#">Bold</a>              | Gets or sets the whether the text format is bold.                     |
|  <a href="#">CharHeight</a>        | Gets or sets the height of the font in meters.                        |
|  <a href="#">CharHeightInPts</a>   | Gets or sets the height of the font in points.                        |
|  <a href="#">CharSpacingFactor</a> | Gets or sets the factor that controls the spacing between characters. |
|  <a href="#">Escapement</a>        | Gets or sets the text angle in radians.                               |
|  <a href="#">Italic</a>            | Gets or sets the whether the text format is italic.                   |
|  <a href="#">LineLength</a>        | Gets or sets the text line length in meters.                          |
|  <a href="#">LineSpacing</a>       | Gets or sets the text line spacing.                                   |
|  <a href="#">ObliqueAngle</a>      | Gets or sets the text slant.                                          |
|  <a href="#">Strikeout</a>        | Gets or sets the whether the text format is strikeout.                |
|  <a href="#">TypeFaceName</a>    | Gets or sets the name of the font.                                    |
|  <a href="#">Underline</a>       | Gets or sets the whether the text format is underlined.               |
|  <a href="#">UpsideDown</a>      | Gets or sets whether the whole text string is upside down.            |
|  <a href="#">Vertical</a>        | Gets or sets the individual characters as vertical.                   |
|  <a href="#">WidthFactor</a>     | Stretches the text by the specified factor.                           |

[Top](#)

 See Also

[ITextFormat Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## BackWards Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : BackWards Property (ITextFormat)

Gets or sets whether the text is displayed backwards.

 .NET Syntax

Visual Basic (Declaration)

Property BackWards As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITextFormat  
Dim value As System.Boolean  
  
instance.BackWards = value
```

```
value = instance.BackWards
```

C#

```
System.bool BackWards {get; set;}
```

C++/CLI

```
property System.bool BackWards {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True if the text is displayed backwards, false if not

### Visual Basic for Applications (VBA) Syntax

See [TextFormat::BackWards](#).

### Example

[Get All Elements of Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

### See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Bold Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : Bold Property (ITextFormat)

Gets or sets the whether the text format is bold.

### .NET Syntax

Visual Basic (Declaration)

```
Property Bold As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITextFormat  
Dim value As System.Boolean
```

```
instance.Bold = value
```

```
value = instance.Bold
```

C#

```
System.bool Bold {get; set;}
```

C++/CLI

```
property System.bool Bold {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

True if the text is bold, false otherwise

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.Bold](#).

## Example

[Change Text Format \(VBA\)](#)  
[Get All Elements of Sketch \(VBA\)](#)  
[Get Note Text Formatting Properties \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## CharHeight Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : CharHeight Property (ITextFormat)

Gets or sets the height of the font in meters.

## .NET Syntax

### Visual Basic (Declaration)

Property CharHeight As System.Double

### Visual Basic (Usage)



```
Dim instance As ITextFormat  
Dim value As System.Double
```

```
instance.CharHeight = value
```

```
value = instance.CharHeight
```

### C#

```
System.double CharHeight {get; set;}
```

### C++/CLI

```
property System.double CharHeight {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

Font height in meters

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.CharHeight](#).

## Example

[Change Text Format \(VBA\)](#)  
[Get All Elements of Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)  
[ITextFormat.CharHeightInPts Property](#)  
[ITextFormat.IsHeightSpecifiedInPts Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## CharHeightInPts Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : CharHeightInPts Property (ITextFormat)

Gets or sets the height of the font in points.

## .NET Syntax

### Visual Basic (Declaration)

Property CharHeightInPts As System.Integer

### Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Integer

instance.CharHeightInPts = value

value = instance.CharHeightInPts
```

### C#

```
System.int CharHeightInPts {get; set;}
```

### C++/CLI

```
property System.int CharHeightInPts {
    System.int get();
    void set ( & System.int value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Font height in points

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.CharHeightInPts](#).

## Example

[Get All Elements of Sketch \(VBA\)](#)  
[Get Note Text Formatting Properties \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)  
[ITextFormat.CharHeight Property](#)  
[ITextFormat.IsHeightSpecifiedInPts Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## CharSpacingFactor Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : CharSpacingFactor Property (ITextFormat)

Gets or sets the factor that controls the spacing between characters.

## .NET Syntax

Visual Basic (Declaration)

Property CharSpacingFactor As System.Double

Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Double

instance.CharSpacingFactor = value
value = instance.CharSpacingFactor
```

C#

```
System.double CharSpacingFactor {get; set;}
```

C++/CLI

```
property System.double CharSpacingFactor {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Factor that controls the spacing between characters

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.CharSpacingFactor](#).

## Example

[Get All Elements of Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## Remarks

The character spacing factor for a piece of text is normally 1. To make the spacing between characters larger, increase this value; to make the spacing between characters smaller, decrease this value.

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Escapement Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : Escapement Property (ITextFormat)

Gets or sets the text angle in radians.

## .NET Syntax

Visual Basic (Declaration)

## Property Escapement As System.Double

Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Double

instance.Escapement = value

value = instance.Escapement
```

C#

```
System.double Escapement {get; set;}
```

C++/CLI

```
property System.double Escapement {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Text angle in radians

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.Escapement](#).

## Example

[Gets All Elements of Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## IsHeightSpecifiedInPts Method (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : IsHeightSpecifiedInPts Method (ITextFormat)

Gets whether the character height is in points or system units.

## .NET Syntax

Visual Basic (Declaration)

```
Function IsHeightSpecifiedInPts() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Boolean

value = instance.IsHeightSpecifiedInPts()
```

C#

```
System.bool IsHeightSpecifiedInPts()
```

C++/CLI

```
System.bool IsHeightSpecifiedInPts();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the character height is in points, false if it is in system units

### Visual Basic for Applications (VBA) Syntax

See [TextFormat::IsHeightSpecifiedInPts](#).

### Example

[Get All Elements in Sketch \(VBA\)](#)  
[Get Note Text Formatting Properties \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

### Remarks

| If the font height was set using...          | Then this method returns... |
|----------------------------------------------|-----------------------------|
| <a href="#">ITextFormat::CharHeight</a>      | False                       |
| <a href="#">ITextFormat::CharHeightInPts</a> | True                        |

### See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Italic Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : Italic Property (ITextFormat)

Gets or sets the whether the text format is italic.

### .NET Syntax

Visual Basic (Declaration)

Property Italic As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Boolean
```

```
instance.Italic = value
```

```
value = instance.Italic
```

C#

```
System.bool Italic {get; set;}
```

C++/CLI

```
property System.bool Italic {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

True if the text is italic, false otherwise

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.Italic](#).

## Example

[Change Text Format \(VBA\)](#)  
[Get All Elements of Sketch \(VBA\)](#)  
[Get Format of Note Text \(VBA\)](#)  
[Get Note Text Formatting Properties \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## LineLength Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : LineLength Property (ITextFormat)

Gets or sets the text line length in meters.

## .NET Syntax

Visual Basic (Declaration)

Property LineLength As System.Double

Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Double
```

```
instance.LineLength = value
```

```
value = instance.LineLength
```

C#

```
System.double LineLength {get; set;}
```

C++/CLI

```
property System.double LineLength {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

Line length

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.LineLength](#).

## Example

[Get All Elements of Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## LineSpacing Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : LineSpacing Property (ITextFormat)

Gets or sets the text line spacing.

## .NET Syntax

### Visual Basic (Declaration)

```
Property LineSpacing As System.Double
```

### Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Double

instance.LineSpacing = value
value = instance.LineSpacing
```

### C#

```
System.double LineSpacing {get; set;}
```

### C++/CLI

```
property System.double LineSpacing {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Line spacing

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.LineSpacing](#).

## Example

[Get All Elements in Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ObliqueAngle Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : ObliqueAngle Property (ITextFormat)

Gets or sets the text slant.

## .NET Syntax

#### Visual Basic (Declaration)

Property ObliqueAngle As System.Double

#### Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Double

instance.ObliqueAngle = value

value = instance.ObliqueAngle
```

#### C#

```
System.double ObliqueAngle {get; set;}
```

#### C++/CLI

```
property System.double ObliqueAngle {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Text slant

### Visual Basic for Applications (VBA) Syntax

See [TextFormat::ObliqueAngle](#).

### Example

[Get All Elements in Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

### See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Strikeout Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : Strikeout Property (ITextFormat)

Gets or sets the whether the text format is strikeout.

### .NET Syntax

#### Visual Basic (Declaration)

Property Strikeout As System.Boolean

#### Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Boolean

instance.Strikeout = value

value = instance.Strikeout
```

#### C#

```
System.bool Strikeout {get; set;}
```

C++/CLI

```
property System.bool Strikeout {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True if the text is strikeout, false otherwise

### Visual Basic for Applications (VBA) Syntax

See [TextFormat::Strikeout](#).

### Example

[Get All Elements of Sketch \(VBA\)](#)  
[Get Note Text Formatting Properties \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

### See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TypeFaceName Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : TypeFaceName Property (ITextFormat)

Gets or sets the name of the font.

### .NET Syntax

Visual Basic (Declaration)

```
Property TypeFaceName As System.String
```

Visual Basic (Usage)

```
Dim instance As ITextFormat  
Dim value As System.String  
  
instance.TypeFaceName = value  
value = instance.TypeFaceName
```

C#

```
System.string TypeFaceName {get; set;}
```

C++/CLI

```
property System.String^ TypeFaceName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Name of the font

## Visual Basic for Applications (VBA) Syntax

See [TextFormat::TypeFaceName](#).

## Example

[Change Text Format \(VBA\)](#)  
[Get All Elements of Sketch \(VBA\)](#)  
[Get Note Text Formatting Properties \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Underline Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : Underline Property (ITextFormat)

Gets or sets the whether the text format is underlined.

## .NET Syntax

Visual Basic (Declaration)

Property Underline As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITextFormat  
Dim value As System.Boolean
```

```
instance.Underline = value
```

```
value = instance.Underline
```

C#

```
System.bool Underline {get; set;}
```

C++/CLI

```
property System.bool Underline {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True if the text is underlined, false otherwise

## Visual Basic for Applications (VBA) Syntax

See [TextFormat::Underline](#).

## Example

[Get All Elements of Sketch \(VBA\)](#)  
[Get Note Text Formatting Properties \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

## UpsideDown Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : UpsideDown Property (ITextFormat)

Gets or sets whether the whole text string is upside down.

### .NET Syntax

#### Visual Basic (Declaration)

```
Property UpsideDown As System.Boolean
```

#### Visual Basic (Usage)



```
Dim instance As ITextFormat  
Dim value As System.Boolean
```

```
instance.UpsideDown = value
```

```
value = instance.UpsideDown
```

#### C#

```
System.bool UpsideDown {get; set;}
```

#### C++/CLI

```
property System.bool UpsideDown {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True if the string is upside down, false if not

### Visual Basic for Applications (VBA) Syntax

See [TextFormat::UpsideDown](#).

### Example

[Get All Elements of Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

### See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

## Vertical Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : Vertical Property (ITextFormat)

Gets or sets the individual characters as vertical.

### .NET Syntax

#### Visual Basic (Declaration)

## Property Vertical As System.Boolean

Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Boolean
```

```
instance.Vertical = value
```

```
value = instance.Vertical
```

C#

```
System.bool Vertical {get; set;}
```

C++/CLI

```
property System.bool Vertical {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True if the characters are vertical, false if not

## Visual Basic for Applications (VBA) Syntax

See [TextFormat.Vertical](#).

## Example

[Get All Elements in Sketch \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

## See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## WidthFactor Property (ITextFormat)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITextFormat Interface](#) : WidthFactor Property (ITextFormat)

Stretches the text by the specified factor.

## .NET Syntax

Visual Basic (Declaration)

## Property WidthFactor As System.Double

Visual Basic (Usage)



```
Dim instance As ITextFormat
Dim value As System.Double
```

```
instance.WidthFactor = value
```

```
value = instance.WidthFactor
```

C#

```
System.double WidthFactor {get; set;}
```

C++/CLI

```
property System.double WidthFactor {  
    System.double get();  
    void set ( &    System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Stretch factor

### Visual Basic for Applications (VBA) Syntax

See [TextFormat.WidthFactor](#).

### Example

[Get All Elements of Sketch \(VBA\)](#)  
[Increase Width of Text \(VBA\)](#)  
[Get Arrow in Projected View \(C#\)](#)  
[Get Arrow in Projected View \(VB.NET\)](#)  
[Get Arrow in Projected View \(VBA\)](#)

### See Also

[ITextFormat Interface](#)  
[ITextFormat Members](#)

# ITexture (Type)

## ITexture Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITexture Interface

Use to apply 2D textures to part and assembly documents for a more realistic finish.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface ITexture
```

Visual Basic (Usage)



```
Dim instance As ITexture
```

C#

```
public interface ITexture
```

C++/CLI

```
public interface class ITexture
```

### Visual Basic for Applications (VBA) Syntax

See [Texture](#).

### Example

[Change Texture on Face in Specified Configuration \(VBA\)](#)  
[Change Texture on Face in Specified Configuration \(VB.NET\)](#)  
[Change Texture on Face in Specified Configuration \(C#\)](#)

### Remarks

To get or set the location of a texture file, use [ISldWorks::GetUserPreferenceStringValue](#) or [ISldWorks::SetUserPreferenceStringValue](#) and swFileLocationsTextures.

### Accessors

[IBody2::GetTexture](#)  
[IComponent2::GetModelTexture](#)  
[IComponent2::GetTexture](#)  
[IFace2::GetTexture](#)  
[IFeature::GetTexture](#)  
[IModelDocExtension::CreateTexture](#)  
[IModelDocExtension::GetTexture](#)

### Access Diagram

[Texture](#)

### See Also

[ITexture Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)

# ITexture Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITexture Interface

The following tables list the members exposed by [ITexture](#).

## Public Properties

| Name                                                                                                                  | Description                                                                      |
|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
|  <a href="#">Angle</a>               | Gets or sets the rotation angle of the texture.                                  |
|  <a href="#">BlendColor</a>          | Gets or sets whether to blend the part color with the texture color.             |
|  <a href="#">DecalType</a>           | Gets whether the texture is a decal.                                             |
|  <a href="#">IgnoreColorMaterial</a> | Gets whether to ignore the color texture-based appearance.                       |
|  <a href="#">MaterialName</a>        | Gets or sets the path and file name of the texture material.                     |
|  <a href="#">ScaleFactor</a>         | Gets or sets the granularity of the texture.                                     |
|  <a href="#">TransX</a>              | Gets the x coordinate for the translation point of the texture-based appearance. |
|  <a href="#">TransY</a>              | Gets the y coordinate for the translation point of the texture-based appearance. |
|  <a href="#">UDir</a>                | Gets the U value of the texture-based appearance.                                |
|  <a href="#">VDir</a>                | Gets the V value of the texture-based appearance.                                |
|  <a href="#">VScale</a>              | Gets the scale for this texture-based appearance or decal.                       |

[Top](#)

## Public Methods

| Name                                                                                                                     | Description                                                               |
|--------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
|  <a href="#">GetSystemTextureName</a> | Gets the name of the texture that appears in the Texture PropertyManager. |

[Top](#)

## See Also

[ITexture Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

# ITexture Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITexture Interface

For a list of all members of this type, see [ITexture members](#).

## Public Methods

| Name                                                                                                                     | Description                                                               |
|--------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
|  <a href="#">GetSystemTextureName</a> | Gets the name of the texture that appears in the Texture PropertyManager. |

[Top](#)

## See Also

[ITexture Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

# ITexture Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITexture Interface

For a list of all members of this type, see [ITexture members](#).

## Public Properties

| Name                                                                                                                  | Description                                                                      |
|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
|  <a href="#">Angle</a>               | Gets or sets the rotation angle of the texture.                                  |
|  <a href="#">BlendColor</a>          | Gets or sets whether to blend the part color with the texture color.             |
|  <a href="#">DecalType</a>           | Gets whether the texture is a decal.                                             |
|  <a href="#">IgnoreColorMaterial</a> | Gets whether to ignore the color texture-based appearance.                       |
|  <a href="#">MaterialName</a>        | Gets or sets the path and file name of the texture material.                     |
|  <a href="#">ScaleFactor</a>         | Gets or sets the granularity of the texture.                                     |
|  <a href="#">TransX</a>              | Gets the x coordinate for the translation point of the texture-based appearance. |
|  <a href="#">TransY</a>              | Gets the y coordinate for the translation point of the texture-based appearance. |
|  <a href="#">UDir</a>                | Gets the U value of the texture-based appearance.                                |
|  <a href="#">VDir</a>                | Gets the V value of the texture-based appearance.                                |
|  <a href="#">VScale</a>              | Gets the scale for this texture-based appearance or decal.                       |

[Top](#)

## See Also

[ITexture Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Angle Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : Angle Property (ITexture)

Gets or sets the rotation angle of the texture.

## .NET Syntax

### Visual Basic (Declaration)

Property Angle As System.Double

### Visual Basic (Usage)



```
Dim instance As ITexture  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

### C#

```
System.double Angle {get; set;}
```

### C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

0.0 < Angle in degrees of texture rotation < 360.0

## Visual Basic for Applications (VBA) Syntax

See [Texture::Angle](#).

## Example

See the [ITexture](#) examples.

## See Also

[ITexture Interface](#)  
[ITexture Members](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## BlendColor Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : BlendColor Property (ITexture)

Gets or sets whether to blend the part color with the texture color.

## .NET Syntax

### Visual Basic (Declaration)

```
Property BlendColor As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As ITexture
Dim value As System.Boolean

instance.BlendColor = value

value = instance.BlendColor
```

### C#

```
System.bool BlendColor {get; set;}
```

### C++/CLI

```
property System.bool BlendColor {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to blend the colors of the part and texture, false to not

## Visual Basic for Applications (VBA) Syntax

See [Texture::BlendColor](#).

## See Also

[ITexture Interface](#)  
[ITexture Members](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## DecalType Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : DecalType Property (ITexture)

Gets whether the texture is a decal.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DecalType As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ITexture  
Dim value As System.Boolean  
  
value = instance.DecalType
```

C#

```
System.bool DecalType {get;}
```

C++/CLI

```
property System.bool DecalType {  
    System.bool get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True if the texture is a decal, false if not

### Visual Basic for Applications (VBA) Syntax

See [Texture::DecalType](#).

### See Also

[ITexture Interface](#)  
[ITexture Members](#)

### Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetSystemTextureName Method (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : GetSystemTextureName Method (ITexture)

Gets the name of the texture that appears in the Texture PropertyManager.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetSystemTextureName( _  
    ByVal FileNameIn As System.String, _  
    ByRef Res As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ITexture  
Dim FileNameIn As System.String
```

```
Dim Res As System.Boolean
Dim value As System.String

value = instance.GetSystemTextureName(FileNameIn, Res)
```

C#

```
System.string GetSystemTextureName(
    System.string FileNameIn,
    out System.bool Res
)
```

C++/CLI

```
System.String^ GetSystemTextureName(
    & System.String^ FileNameIn,
    & [Out] System.bool Res
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*FileNameIn*

Path and filename of texture (see **Remarks**)

*Res*

True if the name of the texture that appears in the Texture PropertyManager is returned, false if not

#### Return Value

Name of texture as it appears in the Texture PropertyManager (see **Remarks**)

### Visual Basic for Applications (VBA) Syntax

See [Texture::GetSystemTextureName](#).

### Example

See the [ITexture](#) examples.

### Remarks

This method only supports SOLIDWORKS-supplied textures.

Call [ITexture::MaterialName](#) to get the value for *FileNameIn* before calling this method. *ITexture::MaterialName* returns an abbreviated path and the name of the texture as it appears in the Texture PropertyManager. For example, if *ITexture::MaterialName* returns *install\_dir\data\images\textures\plastic\brushed\bred.jpg*, then this method returns **Plastic\Brushed\Red**.

### See Also

[ITexture Interface](#)  
[ITexture Members](#)

### Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IgnoreColorMaterial Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : IgnoreColorMaterial Property (ITexture)

Gets whether to ignore the color texture-based appearance.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property IgnoreColorMaterial As System.Boolean
```

```
Dim instance As ITexture
Dim value As System.Boolean

value = instance.IgnoreColorMaterial
```

C#

```
System.bool IgnoreColorMaterial {get;}
```

C++/CLI

```
property System.bool IgnoreColorMaterial {
    System.bool get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to ignore the color of this texture-based appearance, false to not

### Visual Basic for Applications (VBA) Syntax

See [Texture.IgnoreColorMaterial](#).

### See Also

[ITexture Interface](#)  
[ITexture Members](#)

### Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## MaterialName Property (ITexture)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : MaterialName Property (ITexture)

Gets or sets the path and file name of the texture material.

### .NET Syntax

Visual Basic (Declaration)

```
Property MaterialName As System.String
```

Visual Basic (Usage)

```
Dim instance As ITexture
Dim value As System.String

instance.MaterialName = value

value = instance.MaterialName
```

C#

```
System.string MaterialName {get; set;}
```

C++/CLI

```
property System.String^ MaterialName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Path and file name of the texture (see **Remarks**)

### Visual Basic for Applications (VBA) Syntax

See [Texture::MaterialName](#).

### Example

See the [ITexture](#) examples.

### Example

[Remove Textures From Assembly Components \(VBA\)](#)

### Remarks

If the texture is a SOLIDWORKS-supplied texture, then the path returned is:

*install\_dir\data\images\textures\texture\_library\texture\_type\texture\_image\_file*

For example, *install\_dir\data\images\textures\plastic\brushed\bred.jpg*.

If the texture is user-defined texture, then the path returned is:

*drive:\path\_name\texture\_image\_file*

For example, **D:\MyTextures\gear.jpg**.

Call this property before calling [ITexture::GetSystemTextureName](#) to obtain a value for FileNameIn.

### See Also

[ITexture Interface](#)  
[ITexture Members](#)

### Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ScaleFactor Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : ScaleFactor Property (ITexture)

Gets or sets the granularity of the texture.

### .NET Syntax

Visual Basic (Declaration)

Property ScaleFactor As System.Double

Visual Basic (Usage)



```
Dim instance As ITexture
Dim value As System.Double

instance.ScaleFactor = value
value = instance.ScaleFactor
```

C#

```
System.double ScaleFactor {get; set;}
```

C++/CLI

```
property System.double ScaleFactor {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

0.001 < Granularity of the texture < 1000000.00

### Visual Basic for Applications (VBA) Syntax

See [Texture::ScaleFactor](#).

### Example

See the [ITexture](#) examples.

### See Also

[ITexture Interface](#)  
[ITexture Members](#)

### Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TransX Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : TransX Property (ITexture)

Gets the x coordinate for the translation point of the texture-based appearance.

### .NET Syntax

Visual Basic (Declaration)

ReadOnly Property TransX As System.Double

Visual Basic (Usage)



```
Dim instance As ITexture  
Dim value As System.Double
```

```
value = instance.TransX
```

C#

```
System.double TransX {get;}
```

C++/CLI

```
property System.double TransX {  
    System.double get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

x coordinate for the translation point of the texture-based appearance

### Visual Basic for Applications (VBA) Syntax

See [Texture::TransX](#).

## See Also

[ITexture Interface](#)  
[ITexture Members](#)  
[ITexture::TransY Property\(\)](#)

## Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TransY Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : TransY Property (ITexture)

Gets the y coordinate for the translation point of the texture-based appearance.

## .NET Syntax

### Visual Basic (Declaration)

ReadOnly Property TransY As System.Double

### Visual Basic (Usage)



```
Dim instance As ITexture
Dim value As System.Double

value = instance.TransY
```

### C#

```
System.double TransY {get;}
```

### C++/CLI

```
property System.double TransY {
    System.double get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

y coordinate for the translation point of the texture-based appearance

## Visual Basic for Applications (VBA) Syntax

See [Texture::TransY](#).

## See Also

[ITexture Interface](#)  
[ITexture Members](#)  
[ITexture::TransX Property\(\)](#)

## Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## UDir Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : UDir Property (ITexture)

Gets the U value of the texture-based appearance.

## .NET Syntax

#### Visual Basic (Declaration)

ReadOnly Property UDir As System.Double

#### Visual Basic (Usage)



```
Dim instance As ITexture
Dim value As System.Double

value = instance.UDir
```

#### C#

```
System.double UDir {get;}
```

#### C++/CLI

```
property System.double UDir {
    System.double get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

U value of the texture-based appearance

### Visual Basic for Applications (VBA) Syntax

See [Texture::UDir](#).

### See Also

[ITexture Interface](#)  
[ITexture Members](#)  
[ITexture::VDir Property \(\)](#)

### Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## VDir Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : VDir Property (ITexture)

Gets the V value of the texture-based appearance.

### .NET Syntax

#### Visual Basic (Declaration)

ReadOnly Property VDir As System.Double

#### Visual Basic (Usage)



```
Dim instance As ITexture
Dim value As System.Double

value = instance.VDir
```

#### C#

```
System.double VDir {get;}
```

#### C++/CLI

```
property System.double VDir {  
    System.double get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

V value of the texture-based appearance

### Visual Basic for Applications (VBA) Syntax

See [Texture::VDir](#).

### See Also

[ITexture Interface](#)  
[ITexture Members](#)  
[ITexture::UDir Property\(\)](#)

### Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## VScale Property (ITexture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITexture Interface](#) : VScale Property (ITexture)

Gets the scale for this texture-based appearance or decal.

### .NET Syntax

Visual Basic (Declaration)

ReadOnly Property VScale As System.Double

Visual Basic (Usage)



```
Dim instance As ITexture  
Dim value As System.Double  
  
value = instance.VScale
```

C#

```
System.double VScale {get;}
```

C++/CLI

```
property System.double VScale {  
    System.double get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Scale

### Visual Basic for Applications (VBA) Syntax

See [Texture::VScale](#).

### See Also

[ITexture Interface](#)  
[ITexture Members](#)

