

SOLIDWORKS API (.NET VBA C#) — Reference

(315/337): IThreadFeatureData- ITitleBlockTableAnnotation

SOLIDWORKS API Documentation (converted from CHM)

IThreadFeatureData (Type)

IThreadFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IThreadFeatureData Interface

Allows access to a thread feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IThreadFeatureData

Visual Basic (Usage)

Dim instance As [IThreadFeatureData](#)

C#

public interface IThreadFeatureData

C++/CLI

public interface class IThreadFeatureData

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData](#).

Example

[Create a Thread Feature \(VBA\)](#)
[Create a Thread Feature \(VB.NET\)](#)
[Create a Thread Feature \(C#\)](#)

Remarks

This interface:

- Accesses the feature data for a thread created either inside a cylindrical hole or around a cylindrical rod.
- Is functionally similar to the Thread PropertyManager in the SOLIDWORKS Design user interface.

To create a Thread feature, see [Thread Features and ThreadFeatureData Objects](#).

For more information, see the **Thread PropertyManager** topic in the SOLIDWORKS Design user-interface help.

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[ThreadFeatureData](#)

See Also

[IThreadFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFeature Method \(\)](#)

IThreadFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IThreadFeatureData Interface

For a list of all members of this type, see [IThreadFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this thread feature.
 GetEndConditionReference	Gets the Up To Selection end condition reference of this thread feature.
 InitializeThreadData	Initializes this thread feature's data with default values.
 ReleaseSelectionAccess	Releases the selections that created this thread feature.
 SetEndConditionReference	Sets the Up To Selection end condition reference of this thread feature.

[Top](#)

See Also

[IThreadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFeature Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IThreadFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IThreadFeatureData Interface

The following tables list the members exposed by [IThreadFeatureData](#).

Public Properties

Name	Description
 BlindDepth	Gets or sets the distance from the blind end condition reference of this thread feature, taking into account any offset.
 Diameter	Gets or sets the diameter of the cylindrical face or helix of this thread feature.
 DiameterOverride	Gets or sets whether to override the diameter of the cylindrical face or helix of this thread feature.
 Edge	Gets or sets the entity where to start the helix of this thread feature.
 EndCondition	Gets or sets the end condition for this thread feature.
 EndConditionOffset	Gets or sets whether to offset the end condition of this thread feature.
 EndConditionOffsetDistance	Gets or sets the end condition offset distance of this thread feature.
 EndConditionOffsetReverse	Gets or sets whether to flip the offset of the end condition to the opposite side of the end condition reference in this thread feature.
 MaintainThreadLength	Gets or sets whether to keep the thread a constant length from the starting surface in this thread feature.
 MirrorProfile	Gets or sets whether to flip the profile of the thread helix about its horizontal or vertical axis in this thread feature.
 MirrorType	Gets or sets how to flip the profile of the thread helix of this thread feature.
 MultipleStart	Gets or sets whether the thread has multiple starts in this thread feature.
 NumberOfStarts	Gets or sets the number of times the thread is created in an evenly-spaced pattern around the hole or shaft of this thread feature.
 Offset	Gets or sets whether to offset the starting location of the helix of this thread feature.
 OffsetDistance	Gets or sets the offset of the starting location of the helix of this thread feature.
 Pitch	Gets or sets the pitch of the thread helix of this thread feature.
 PitchOverride	Gets or sets whether to override the pitch of the thread helix of this thread feature.
 ProfileLocation	Gets or sets the point or vertex where to start the helix on the thread profile sketch of this thread feature.
 ReverseDirection	Gets or sets whether to reverse the direction of the Blind or Revolutions end condition of this thread feature.
 ReverseOffset	Gets or sets whether to flip the offset of the helix to the opposite side of the starting entity in this thread feature.
 Revolutions	Gets or sets the number of revolutions in the helix of this thread feature, taking into account any offset.
 RightHanded	Gets or sets how the thread is wound in this thread feature.

		
 RotationAngle		Gets or sets the angle of rotation of the thread helix of this thread feature.
 Size		Gets or sets the size of the thread of this thread feature.
 StartEntity		Gets or sets the starting entity for the helix of this thread feature.
 ThreadMethod		Gets or sets the thread method for this thread feature.
 ThreadStartAngle		Gets or sets the start angle of the thread of this thread feature
 TrimEndFace		Gets or sets whether to align the thread to the end face of this thread feature.
 TrimStartFace		Gets or sets whether to align the thread to the start face of this thread feature.
 Type		Gets or sets the thread profile of this thread feature.

[Top](#)

Public Methods

	Name	Description
	AccessSelections	Gains access to the selections that define this thread feature.
	GetEndConditionReference	Gets the Up To Selection end condition reference of this thread feature.
	InitializeThreadData	Initializes this thread feature's data with default values.
	ReleaseSelectionAccess	Releases the selections that created this thread feature.
	SetEndConditionReference	Sets the Up To Selection end condition reference of this thread feature.

[Top](#)

See Also

[IThreadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFeature Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IThreadFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IThreadFeatureData Interface

For a list of all members of this type, see [IThreadFeatureData members](#).

Public Properties

	Name	Description
	BlindDepth	Gets or sets the distance from the blind end condition reference of this thread feature, taking into account any offset.
	Diameter	Gets or sets the diameter of the cylindrical face or helix of this thread feature.
	DiameterOverride	Gets or sets whether to override the diameter of the cylindrical face or helix of this thread feature.
	Edge	Gets or sets the entity where to start the helix of this thread feature.
	EndCondition	Gets or sets the end condition for this thread feature.
	EndConditionOffset	Gets or sets whether to offset the end condition of this thread feature.
	EndConditionOffsetDistance	Gets or sets the end condition offset distance of this thread feature.
	EndConditionOffsetReverse	Gets or sets whether to flip the offset of the end condition to the opposite side of the end condition reference in this thread feature.
	MaintainThreadLength	Gets or sets whether to keep the thread a constant length from the starting surface in this thread feature.
	MirrorProfile	Gets or sets whether to flip the profile of the thread helix about its horizontal or vertical axis in this thread feature.
	MirrorType	Gets or sets how to flip the profile of the thread helix of this thread feature.
	MultipleStart	Gets or sets whether the thread has multiple starts in this thread feature.
	NumberOfStarts	Gets or sets the number of times the thread is created in an evenly-spaced pattern around the hole or shaft of this thread feature.

 Offset	Gets or sets whether to offset the starting location of the helix of this thread feature.
 OffsetDistance	Gets or sets the offset of the starting location of the helix of this thread feature.
 Pitch	Gets or sets the pitch of the thread helix of this thread feature.
 PitchOverride	Gets or sets whether to override the pitch of the thread helix of this thread feature.
 ProfileLocation	Gets or sets the point or vertex where to start the helix on the thread profile sketch of this thread feature.
 ReverseDirection	Gets or sets whether to reverse the direction of the Blind or Revolutions end condition of this thread feature.
 ReverseOffset	Gets or sets whether to flip the offset of the helix to the opposite side of the starting entity in this thread feature.
 Revolutions	Gets or sets the number of revolutions in the helix of this thread feature, taking into account any offset.
 RightHanded	Gets or sets how the thread is wound in this thread feature.
 RotationAngle	Gets or sets the angle of rotation of the thread helix of this thread feature.
 Size	Gets or sets the size of the thread of this thread feature.
 StartEntity	Gets or sets the starting entity for the helix of this thread feature.
 ThreadMethod	Gets or sets the thread method for this thread feature.
 ThreadStartAngle	Gets or sets the start angle of the thread of this thread feature
 TrimEndFace	Gets or sets whether to align the thread to the end face of this thread feature.
 TrimStartFace	Gets or sets whether to align the thread to the start face of this thread feature.
 Type	Gets or sets the thread profile of this thread feature.

[Top](#)

See Also

[IThreadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFeature Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : AccessSelections Method (IThreadFeatureData)

Gains access to the selections that define this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As ModelDoc, _
    ByVal Component As Component _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData
Dim TopDoc As ModelDoc
Dim Component As Component
Dim value As System.Boolean
```

```
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    ModelDoc TopDoc,
    Component Component
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component to which this feature is to be applied

Return Value

True if access is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::AccessSelections](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IThreadFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IThreadFeatureData Interface](#)

[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BlindDepth Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : BlindDepth Property (IThreadFeatureData)

Gets or sets the distance from the blind end condition reference of this thread feature, taking into account any offset.

.NET Syntax

Visual Basic (Declaration)

Property BlindDepth As System.Double

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Double
```

```
instance.BlindDepth = value
```

```
value = instance.BlindDepth
```

C#

```
System.double BlindDepth {get; set;}
```

C++/CLI

```
property System.double BlindDepth {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 < Distance from the blind end condition reference; default is 0.01 m

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::BlindDepth](#).

Remarks

This property is valid only if [IThreadFeatureData::EndCondition](#) is set to [swThreadEndCondition_e.swThreadEndCondition_Blind](#).
Specify either a value or an equation that starts with an equal sign (=).

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Diameter Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : Diameter Property (IThreadFeatureData)

Gets or sets the diameter of the cylindrical face or helix of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Diameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Double
```

```
instance.Diameter = value
```

```
value = instance.Diameter
```

C#

```
System.double Diameter {get; set;}
```

C++/CLI

```
property System.double Diameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 < Diameter of the helix; default is the diameter of the circular edge specified by [IThreadFeatureData::Edge](#)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::Diameter](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

Specify either a value or an equation that starts with an equal sign (=).

This property is valid only if [IThreadFeatureData::DiameterOverride](#) is set to true.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DiameterOverride Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : DiameterOverride Property (IThreadFeatureData)

Gets or sets whether to override the diameter of the cylindrical face or helix of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Property DiameterOverride As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.DiameterOverride = value
```

```
value = instance.DiameterOverride
```

C#

```
System.bool DiameterOverride {get; set;}
```

C++/CLI

```
property System.bool DiameterOverride {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the diameter, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::DiameterOverride](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

If this property is set to true, use [IThreadFeatureData::Diameter](#) to specify the override diameter.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edge Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : Edge Property (IThreadFeatureData)

Gets or sets the entity where to start the helix of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property Edge As Edge

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData
Dim value As Edge
```

```
instance.Edge = value
```

```
value = instance.Edge
```

C#

```
Edge Edge {get; set;}
```

C++/CLI

```
property Edge^ Edge {
    Edge^ get();
    void set ( & Edge^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Planar circular [edge](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::Edge](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

Use [IModelDocExtension::SelectByRay](#) with Mark = 1 to select the edge.

If this property does not set a planar circular edge, then you must use [IThreadFeatureData::StartEntity](#) to specify the start location of this thread's helix.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndCondition Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : EndCondition Property (IThreadFeatureData)

Gets or sets the end condition for this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property EndCondition As System.Integer

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Integer
```

```
instance.EndCondition = value
```

```
value = instance.EndCondition
```

C#

```
System.int EndCondition {get; set;}
```

C++/CLI

```
property System.int EndCondition {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread end condition as defined in [swThreadEndCondition_e](#); default is swThreadEndCondition_e.swThreadEndCondition_Blind

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::EndCondition](#).

Example

See the [IThreadFeatureData](#) examples.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::GetEndConditionReference Method \(\)](#)
[IThreadFeatureData::SetEndConditionReference Method \(\)](#)
[IThreadFeatureData::BlindDepth Property \(\)](#)
[IThreadFeatureData::EndConditionOffset Property \(\)](#)
[IThreadFeatureData::EndConditionOffsetDistance Property \(\)](#)
[IThreadFeatureData::EndConditionOffsetReverse Property \(\)](#)
[IThreadFeatureData::MaintainThreadLength Property \(\)](#)
[IThreadFeatureData::ReverseDirection Property \(\)](#)
[IThreadFeatureData::Revolutions Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndConditionOffset Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : EndConditionOffset Property (IThreadFeatureData)

Gets or sets whether to offset the end condition of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property EndConditionOffset As System.Boolean

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData
Dim value As System.Boolean
```

```
instance.EndConditionOffset = value
```

```
value = instance.EndConditionOffset
```

C#

```
System.bool EndConditionOffset {get; set;}
```

C++/CLI

```
property System.bool EndConditionOffset {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to offset the end condition, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::EndConditionOffset](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if [IThreadFeatureData::EndCondition](#) is set to [swThreadEndCondition_e.swThreadEndCondition_UpToSelection](#).

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::EndConditionOffsetDistance Property \(\)](#)
[IThreadFeatureData::EndConditionOffsetReverse Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndConditionOffsetDistance Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : EndConditionOffsetDistance Property (IThreadFeatureData)

Gets or sets the end condition offset distance of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property EndConditionOffsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Double  
  
instance.EndConditionOffsetDistance = value  
  
value = instance.EndConditionOffsetDistance
```

C#

```
System.double EndConditionOffsetDistance {get; set;}
```

C++/CLI

```
property System.double EndConditionOffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) < End condition offset distance

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::EndConditionOffsetDistance](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if:

- [IThreadFeatureData::EndCondition](#) is set to [swThreadEndCondition_e.swThreadEndCondition_UpToSelection](#).
- and -
- [IThreadFeatureData::EndConditionOffset](#) is set to true.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndConditionOffsetReverse Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : EndConditionOffsetReverse Property (IThreadFeatureData)

Gets or sets whether to flip the offset of the end condition to the opposite side of the end condition reference in this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property EndConditionOffsetReverse As System.Boolean

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.EndConditionOffsetReverse = value
```

```
value = instance.EndConditionOffsetReverse
```

C#

```
System.bool EndConditionOffsetReverse {get; set;}
```

C++/CLI

```
property System.bool EndConditionOffsetReverse {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the offset, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::EndConditionOffsetReverse](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if:

- [IThreadFeatureData::EndCondition](#) is set to [swThreadEndCondition_e.swThreadEndCondition_UpToSelection](#).
- and -
- [IThreadFeatureData::EndConditionOffset](#) is set to true.

See Also

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEndConditionReference Method (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : GetEndConditionReference Method (IThreadFeatureData)

Gets the Up To Selection end condition reference of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndConditionReference() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Object
```

```
value = instance.GetEndConditionReference()
```

C#

```
System.object GetEndConditionReference()
```

C++/CLI

```
System.Object^ GetEndConditionReference();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Vertex](#), [edge](#), [plane](#), or planar [surface](#)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::GetEndConditionReference](#).

Remarks

This method is valid only if [IThreadFeatureData::EndCondition](#) is set to [swEndConditions_e.swEndCondUpToSelection](#). See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::SetEndConditionReference Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InitializeThreadData Method (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : InitializeThreadData Method (IThreadFeatureData)

Initializes this thread feature's data with default values.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub InitializeThreadData()
```

Visual Basic (Usage)

```
Dim instance As IThreadFeatureData  
instance.InitializeThreadData()
```

C#

```
void InitializeThreadData()
```

C++/CLI

```
void InitializeThreadData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::InitializeThreadData](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This method initializes all of the properties of this interface to the default values documented for each property.

To create a thread feature, see [Thread features and ThreadFeatureData Objects](#).

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaintainThreadLength Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : MaintainThreadLength Property (IThreadFeatureData)

Gets or sets whether to keep the thread a constant length from the starting surface in this thread feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property MaintainThreadLength As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean  
  
instance.MaintainThreadLength = value
```

```
value = instance.MaintainThreadLength
```

C#

```
System.bool MaintainThreadLength {get; set;}
```

C++/CLI

```
property System.bool MaintainThreadLength {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to maintain a constant thread length, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::MaintainThreadLength](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if:

- [IThreadFeatureData::Offset](#) is set to true.
 - [IThreadFeatureData::EndCondition](#) is set to [swThreadEndCondition_e](#):
 - swThreadEndCondition_Blind
- or -
- swThreadEndCondition_Revolutions

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorProfile Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : MirrorProfile Property (IThreadFeatureData)

Gets or sets whether to flip the profile of the thread helix about its horizontal or vertical axis in this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Property MirrorProfile As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.MirrorProfile = value
```

```
value = instance.MirrorProfile
```

C#

```
System.bool MirrorProfile {get; set;}
```

C++/CLI

```
property System.bool MirrorProfile {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the profile of the thread helix about its horizontal or vertical axis, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::MirrorProfile](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

If this property is set to true, use [IThreadFeatureData::MirrorType](#) to specify the axis about which to flip the thread helix profile.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MirrorType Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : MirrorType Property (IThreadFeatureData)

Gets or sets how to flip the profile of the thread helix of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Property MirrorType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Integer
```

```
instance.MirrorType = value
```

```
value = instance.MirrorType
```

C#

```
System.int MirrorType {get; set;}
```

C++/CLI

```
property System.int MirrorType {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mirror profile type as defined in [swThreadMirrorType_e](#); default is swThreadMirrorType_e.swThreadMirrorType_Horizontally

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::MirrorType](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if [IThreadFeatureData::MirrorProfile](#) is set to true.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MultipleStart Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : MultipleStart Property (IThreadFeatureData)

Gets or sets whether the thread has multiple starts in this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property MultipleStart As System.Boolean

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.MultipleStart = value
```

```
value = instance.MultipleStart
```

C#

```
System.bool MultipleStart {get; set;}
```

C++/CLI

```
property System.bool MultipleStart {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the thread has multiple starts, false if not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::MultipleStart](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

If this property is set to true, use [IThreadFeatureData::NumberOfStarts](#) to set the number of times the thread is created in an evenly-spaced circular pattern around the hole or shaft.

[IThreadFeatureData::Pitch](#) must permit multiple starts without causing crossing or self-intersecting threads. For example, the pitch of one thread must be wide enough to allow the nesting of other threads of different pitch.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::TrimEndFace Property \(\)](#)
[IThreadFeatureData::TrimStartFace Property \(\)](#)
[IThreadFeatureData::RightHanded Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NumberOfStarts Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : NumberOfStarts Property (IThreadFeatureData)

Gets or sets the number of times the thread is created in an evenly-spaced pattern around the hole or shaft of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Property NumberOfStarts As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Integer
```

```
instance.NumberOfStarts = value
```

```
value = instance.NumberOfStarts
```

C#

```
System.int NumberOfStarts {get; set;}
```

C++/CLI

```
property System.int NumberOfStarts {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

2 (default) <= Number of times the thread is started <= 1000

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::NumberOfStarts](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if [IThreadFeatureData::MultipleStart](#) is set to true.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Offset Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : Offset Property (IThreadFeatureData)

Gets or sets whether to offset the starting location of the helix of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property Offset As System.Boolean

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.Offset = value
```

```
value = instance.Offset
```

C#

```
System.bool Offset {get; set;}
```

C++/CLI

```
property System.bool Offset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True of offset the starting location of the thread helix, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::Offset](#).

Example

See the [IThreadFeatureData](#) examples.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::MaintainThreadLength Property \(\)](#)
[IThreadFeatureData::OffsetDistance Property \(\)](#)
[IThreadFeatureData::ReverseOffset Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetDistance Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : OffsetDistance Property (IThreadFeatureData)

Gets or sets the offset of the starting location of the helix of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Double
```

```
instance.OffsetDistance = value
```

```
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) < Offset of the starting location of the thread helix

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::OffsetDistance](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if [IThreadFeatureData::Offset](#) is set to true.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

Pitch Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : Pitch Property (IThreadFeatureData)

Gets or sets the pitch of the thread helix of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property Pitch As System.Double

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Double
```

```
instance.Pitch = value
```

```
value = instance.Pitch
```

C#

```
System.double Pitch {get; set;}
```

C++/CLI

```
property System.double Pitch {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 < Pitch of the helix; default is determined by interrogating the selected configuration's profile sketch

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::Pitch](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

Specify either a value or an equation that starts with an equal sign (=).

This property is valid only if [IThreadFeatureData::PitchOverride](#) is set to true.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::MultipleStart Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

PitchOverride Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : PitchOverride Property (IThreadFeatureData)

Gets or sets whether to override the pitch of the thread helix of this thread feature.

 .NET Syntax

Visual Basic (Declaration)

Property PitchOverride As System.Boolean

Visual Basic (Usage)

Dim instance As [IThreadFeatureData](#)
Dim value As System.Boolean

instance.PitchOverride = value

value = instance.PitchOverride

C#

System.bool PitchOverride {get; set;}

C++/CLI

property System.bool PitchOverride {
 System.bool get();
 void set (& System.bool value);
}

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the pitch, false to not (default)

 Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::PitchOverride](#).

 Example

See the [IThreadFeatureData](#) examples.

 Remarks

If this property is set to true, use [IThreadFeatureData::Pitch](#) to set the pitch of the thread helix.

 See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

 Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : ProfileLocation Property (IThreadFeatureData)

Gets or sets the point or vertex where to start the helix on the thread profile sketch of this thread feature.

 .NET Syntax

Visual Basic (Declaration)

Property ProfileLocation As System.Object

```
Dim instance As IThreadFeatureData
Dim value As System.Object

instance.ProfileLocation = value

value = instance.ProfileLocation
```

C#

```
System.Object ProfileLocation {get; set;}
```

C++/CLI

```
property System.Object^ ProfileLocation {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Point](#) or [vertex](#) in the thread profile sketch where to start the thread helix

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::ProfileLocation](#).

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : ReleaseSelectionAccess Method (IThreadFeatureData)

Releases the selections that created this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)

```
Dim instance As IThreadFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::ReleaseSelectionAccess](#).

Remarks

[IThreadFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) if you did modify the feature.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : ReverseDirection Property (IThreadFeatureData)

Gets or sets whether to reverse the direction of the Blind or Revolutions end condition of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of the Blind or Revolutions end condition, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::ReverseDirection](#).

Remarks

This property is valid only if [IThreadFeatureData::EndCondition](#) is set to [swThreadEndCondition_e](#):

- swThreadEndCondition_Blind
- OR -
- swThreadEndCondition_Revolutions.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReverseOffset Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : ReverseOffset Property (IThreadFeatureData)

Gets or sets whether to flip the offset of the helix to the opposite side of the starting entity in this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseOffset As System.Boolean

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseOffset = value
```

```
value = instance.ReverseOffset
```

C#

```
System.bool ReverseOffset {get; set;}
```

C++/CLI

```
property System.bool ReverseOffset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the offset of the helix, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::ReverseOffset](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if [IThreadFeatureData::Offset](#) is set to true.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

Revolutions Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : Revolutions Property (IThreadFeatureData)

Gets or sets the number of revolutions in the helix of this thread feature, taking into account any offset.

.NET Syntax

Visual Basic (Declaration)

Property Revolutions As System.Double

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData
Dim value As System.Double
```

```
instance.Revolutions = value
```

```
value = instance.Revolutions
```

C#

```
System.double Revolutions {get; set;}
```

C++/CLI

```
property System.double Revolutions {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 < Number of revolutions in the thread helix; default is 10.0 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::Revolutions](#).

Remarks

This property is valid only if [IThreadFeatureData::EndCondition](#) is set to [swThreadEndCondition_e.swThreadEndCondition_Revolutions](#). Specify either a value or an equation that starts with an equal sign (=).

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

RightHanded Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : RightHanded Property (IThreadFeatureData)

Gets or sets how the thread is wound in this thread feature.

.NET Syntax

```
Property RightHanded As System.Boolean
```



```
Dim instance As IThreadFeatureData
Dim value As System.Boolean
```

```
instance.RightHanded = value
```

```
value = instance.RightHanded
```

```
System.bool RightHanded {get; set;}
```

```
property System.bool RightHanded {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the thread is wound clockwise (default), false if counter clockwise

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::RightHanded](#).

Example

See the [IThreadFeatureData](#) examples.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::MultipleStart Property \(\)](#)
[IThreadFeatureData::TrimEndFace Property \(\)](#)
[IThreadFeatureData::TrimStartFace Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

RotationAngle Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : RotationAngle Property (IThreadFeatureData)

Gets or sets the angle of rotation of the thread helix of this thread feature.

.NET Syntax

```
Property RotationAngle As System.Double
```



```
Dim instance As IThreadFeatureData
Dim value As System.Double
```

```
instance.RotationAngle = value
```

```
value = instance.RotationAngle
```

C#

```
System.double RotationAngle {get; set;}
```

C++/CLI

```
property System.double RotationAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Angle of rotation <= 2*pi radians

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::RotationAngle](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

Specify either a value or an equation that starts with an equal sign (=).

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetEndConditionReference Method (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : SetEndConditionReference Method (IThreadFeatureData)

Sets the Up To Selection end condition reference of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEndConditionReference( _  
    ByVal Value As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim Value As System.Object  
  
instance.SetEndConditionReference(Value)
```

C#

```
void SetEndConditionReference(  
    System.object Value  
)
```

C++/CLI

```
void SetEndConditionReference(  
& System.Object^ Value  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Value
[Vertex](#), [edge](#), [plane](#), or planar [surface](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::SetEndConditionReference](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This method is valid only if [IThreadFeatureData::EndCondition](#) is set to [swEndConditions_e.swEndCondUpToSelection](#).

Use [IModelDocExtension::SelectByRay](#) with Mark = 1 to select the end condition reference.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::GetEndConditionReference Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Size Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : Size Property (IThreadFeatureData)

Gets or sets the size of the thread of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property Size As System.String

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.String
```

```
instance.Size = value
```

```
value = instance.Size
```

C#

```
System.string Size {get; set;}
```

C++/CLI

```
property System.String^ Size {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread size (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::Size](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property corresponds to a Size selected in the Thread PropertyManager for a selected [IThreadFeatureData::Type](#).

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

StartEntity Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : StartEntity Property (IThreadFeatureData)

Gets or sets the starting entity for the helix of this thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Property StartEntity As System.Object
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Object
```

```
instance.StartEntity = value
```

```
value = instance.StartEntity
```

C#

```
System.object StartEntity {get; set;}
```

C++/CLI

```
property System.Object^ StartEntity {  
    System.Object^ get();
```

```
void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Vertex](#), [edge](#), [plane](#), or planar [surface](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::StartEntity](#).

Remarks

Use [IModelDocExtension::SelectByRay](#) with Mark = 2 to select the start entity.

This property is optional, but required if [IThreadFeatureData::Edge](#) is not a planar circular [edge](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadMethod Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : ThreadMethod Property (IThreadFeatureData)

Gets or sets the thread method for this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property ThreadMethod As System.Integer

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Integer
```

```
instance.ThreadMethod = value
```

```
value = instance.ThreadMethod
```

C#

```
System.int ThreadMethod {get; set;}
```

C++/CLI

```
property System.int ThreadMethod {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread method as defined in [swThreadMethod_e](#); default is swThreadMethod_e.swThreadMethod_CutThread

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::ThreadMethod](#).

Example

See the [IThreadFeatureData](#) examples.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadStartAngle Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : ThreadStartAngle Property (IThreadFeatureData)

Gets or sets the start angle of the thread of this thread feature

.NET Syntax

Visual Basic (Declaration)

```
Property ThreadStartAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Double
```

```
instance.ThreadStartAngle = value
```

```
value = instance.ThreadStartAngle
```

C#

```
System.double ThreadStartAngle {get; set;}
```

C++/CLI

```
property System.double ThreadStartAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) < Thread start angle < 2*pi radians

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::ThreadStartAngle](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

Specify either a value or an equation that starts with an equal sign (=).

See Also

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TrimEndFace Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : TrimEndFace Property (IThreadFeatureData)

Gets or sets whether to align the thread to the end face of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property TrimEndFace As System.Boolean

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.TrimEndFace = value
```

```
value = instance.TrimEndFace
```

C#

```
System.bool TrimEndFace {get; set;}
```

C++/CLI

```
property System.bool TrimEndFace {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to align the thread to the end face, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::TrimEndFace](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if the thread profile extends beyond the trimming face.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::TrimStartFace Property \(\)](#)
[IThreadFeatureData::MultipleStart Property \(\)](#)
[IThreadFeatureData::RightHanded Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

TrimStartFace Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : TrimStartFace Property (IThreadFeatureData)

Gets or sets whether to align the thread to the start face of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property TrimStartFace As System.Boolean

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.Boolean
```

```
instance.TrimStartFace = value
```

```
value = instance.TrimStartFace
```

C#

```
System.bool TrimStartFace {get; set;}
```

C++/CLI

```
property System.bool TrimStartFace {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to align the thread to the start face, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::TrimStartFace](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property is valid only if the thread profile extends beyond the trimming face.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::TrimEndFace Property \(\)](#)
[IThreadFeatureData::MultipleStart Property \(\)](#)
[IThreadFeatureData::RightHanded Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

Type Property (IThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThreadFeatureData Interface](#) : Type Property (IThreadFeatureData)

Gets or sets the thread profile of this thread feature.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.String

Visual Basic (Usage)



```
Dim instance As IThreadFeatureData  
Dim value As System.String
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.string Type {get; set;}
```

C++/CLI

```
property System.String^ Type {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread profile (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ThreadFeatureData::Type](#).

Example

See the [IThreadFeatureData](#) examples.

Remarks

This property corresponds to a Type in the Thread PropertyManager.

Types are defined in ***.sldlfp** files. You can specify this property with or without the sldlfp extension and path. If you specify this property without:

- a path, SOLIDWORKS searches for the file in the folder specified by **Tools > Options > System Options > File Locations > Show folders for Thread Profiles**.
- an extension, SOLIDWORKS assumes the extension is sldlfp.

See Also

[IThreadFeatureData Interface](#)
[IThreadFeatureData Members](#)
[IThreadFeatureData::Size Property\(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

ITitleBlock (Type)

ITitleBlock Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITitleBlock Interface

Allows access to the title block in this sheet.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ITitleBlock
```

Visual Basic (Usage)

```
Dim instance As ITitleBlock
```

C#

```
public interface ITitleBlock
```

C++/CLI

```
public interface class ITitleBlock
```

Visual Basic for Applications (VBA) Syntax

See [TitleBlock](#).

Example

[Get Notes from New or Existing Title Block \(C#\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)

Remarks

Only one title block feature can exist in a sheet.

Accessors

[ISheet::InsertTitleBlock](#)
[ISheet::TitleBlock](#)

Access Diagram

[TitleBlock](#)

See Also

[ITitleBlock Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ITitleBlock Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITitleBlock Interface

The following tables list the members exposed by [ITitleBlock](#).

Public Methods

Name	Description
 GetExtents	Gets the coordinates on the drawing sheet format that define the extents of the title block.
 GetFeature	Gets the feature for this title block.
 GetNoteCount	Gets the number of notes in this title block.
 GetNotes	Gets the notes in this title block.
 IGetNotes	Gets the notes in this title block.
 SetExtents	Sets the coordinates on the drawing sheet format that define the extents of the title block.

[Top](#)

See Also

[ITitleBlock Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ITitleBlock Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITitleBlock Interface

For a list of all members of this type, see [ITitleBlock members](#).

Public Methods

Name	Description
 GetExtents	Gets the coordinates on the drawing sheet format that define the extents of the title block.
 GetFeature	Gets the feature for this title block.
 GetNoteCount	Gets the number of notes in this title block.
 GetNotes	Gets the notes in this title block.
 IGetNotes	Gets the notes in this title block.
 SetExtents	Sets the coordinates on the drawing sheet format that define the extents of the title block.

[Top](#)

See Also

[ITitleBlock Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExtents Method (ITitleBlock)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITitleBlock Interface](#) : GetExtents Method (ITitleBlock)

Gets the coordinates on the drawing sheet format that define the extents of the title block.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetExtents( _  
    ByRef XUpperLeft As System.Double, _  
    ByRef YUpperLeft As System.Double, _  
    ByRef XLowerRight As System.Double, _  
    ByRef YLowerRight As System.Double _  
)
```

Visual Basic (Usage)



Copy Code

```

Dim instance As ITitleBlock
Dim XUpperLeft As System.Double
Dim YUpperLeft As System.Double
Dim XLowerRight As System.Double
Dim YLowerRight As System.Double

instance.GetExtents(XUpperLeft, YUpperLeft, XLowerRight, YLowerRight)

```

C#

```

void GetExtents(
    out System.double XUpperLeft,
    out System.double YUpperLeft,
    out System.double XLowerRight,
    out System.double YLowerRight
)

```

C++/CLI

```

void GetExtents(
    & [Out] System.double XUpperLeft,
    & [Out] System.double YUpperLeft,
    & [Out] System.double XLowerRight,
    & [Out] System.double YLowerRight
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XUpperLeft
X upper-left coordinate
YUpperLeft
Y upper-left coordinate
XLowerRight
X lower-right coordinate
YLowerRight
Y lower-right coordinate

Visual Basic for Applications (VBA) Syntax

See [TitleBlock::GetExtents](#).

See Also

[ITitleBlock Interface](#)
[ITitleBlock Members](#)
[ITitleBlock::SetExtents Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (ITitleBlock)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITitleBlock Interface](#) : GetFeature Method (ITitleBlock)

Gets the feature for this title block.

.NET Syntax

Visual Basic (Declaration)

Function GetFeature() As Feature

Visual Basic (Usage)

```

Dim instance As ITitleBlock
Dim value As Feature

```



Copy Code

```
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [TitleBlock::GetFeature](#).

See Also

[ITitleBlock Interface](#)
[ITitleBlock Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNoteCount Method (ITitleBlock)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITitleBlock Interface](#) : GetNoteCount Method (ITitleBlock)

Gets the number of notes in this title block.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNoteCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ITitleBlock  
Dim value As System.Integer  
  
value = instance.GetNoteCount()
```

C#

```
System.int GetNoteCount()
```

C++/CLI

```
System.int GetNoteCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of notes in this title block

Visual Basic for Applications (VBA) Syntax

See [TitleBlock::GetNoteCount](#).

Remarks

Call this method before calling [ITitleBlock::!GetNotes](#) to get the size of the array for that method.

See Also

[ITitleBlock Interface](#)
[ITitleBlock Members](#)
[ITitleBlock::GetNotes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNotes Method (ITitleBlock)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITitleBlock Interface](#) : GetNotes Method (ITitleBlock)

Gets the notes in this title block.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNotes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ITitleBlock
Dim value As System.Object

value = instance.GetNotes()
```

C#

```
System.object GetNotes()
```

C++/CLI

```
System.Object^ GetNotes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [notes](#) in this title block

Visual Basic for Applications (VBA) Syntax

See [TitleBlock::GetNotes](#).

Example

[Get Notes from New or Existing Title Block \(VBA\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(C#\)](#)

See Also

[ITitleBlock Interface](#)
[ITitleBlock Members](#)
[ITitleBlock::GetNoteCount Method](#)
[ITitleBlock::!GetNotes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNotes Method (ITitleBlock)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITitleBlock Interface](#) : IGetNotes Method (ITitleBlock)

Gets the notes in this title block.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNotes( _  
    ByVal Count As System.Integer _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As ITitleBlock  
Dim Count As System.Integer  
Dim value As Note
```

```
value = instance.IGetNotes(Count)
```

C#

```
Note IGetNotes(  
    System.int Count  
)
```

C++/CLI

```
Note^ IGetNotes(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of notes in this title block

Return Value

- in-process, unmanaged C++: Pointer to an array of [notes](#) in this title block
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ITitleBlock::GetNoteCount](#) before calling this method to get Count.

See Also

[ITitleBlock Interface](#)
[ITitleBlock Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0 [ITitleBlock::GetNotes Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetExtents Method (ITitleBlock)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITitleBlock Interface](#) : SetExtents Method (ITitleBlock)

Sets the coordinates on the drawing sheet format that define the extents of the title block.

.NET Syntax

```

Sub SetExtents( _
    ByVal XUpperLeft As System.Double, _
    ByVal YUpperLeft As System.Double, _
    ByVal XLowerRight As System.Double, _
    ByVal YLowerRight As System.Double _
)

```



```

Dim instance As ITitleBlock
Dim XUpperLeft As System.Double
Dim YUpperLeft As System.Double
Dim XLowerRight As System.Double
Dim YLowerRight As System.Double

instance.SetExtents(XUpperLeft, YUpperLeft, XLowerRight, YLowerRight)

```

```

void SetExtents(
    System.double XUpperLeft,
    System.double YUpperLeft,
    System.double XLowerRight,
    System.double YLowerRight
)

```

```

void SetExtents(
    & System.double XUpperLeft,
    & System.double YUpperLeft,
    & System.double XLowerRight,
    & System.double YLowerRight
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XUpperLeft
X upper-left coordinate

YUpperLeft
Y upper-left coordinate

XLowerRight
X lower-right coordinate

YLowerRight
Y lower-right coordinate

Visual Basic for Applications (VBA) Syntax

See [TitleBlock::SetExtents](#).

See Also

[ITitleBlock Interface](#)
[ITitleBlock Members](#)
[ITitleBlock::GetExtents Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

ITitleBlockTableAnnotation (Type)

ITitleBlockTableAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITitleBlockTableAnnotation Interface

Provides access to title block table annotations.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ITitleBlockTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As ITitleBlockTableAnnotation
```

C#

```
public interface ITitleBlockTableAnnotation
```

C++/CLI

```
public interface class ITitleBlockTableAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [TitleBlockTableAnnotation](#).

Example

[Get Title Block Tables \(VBA\)](#)
[Get Title Block Tables \(VB.NET\)](#)
[Get Title Block Tables \(C#\)](#)

Accessors

[IModelDocExtension::InsertTitleBlockTable](#)
[ITitleBlockTableFeature::GetTableAnnotations](#) and [ITitleBlockTableFeature::!GetTableAnnotations](#)

Access Diagram

[TitleBlockTableAnnotation](#)

See Also

[ITitleBlockTableAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ITitleBlockTableAnnotation Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITitleBlockTableAnnotation Interface

The following tables list the members exposed by [ITitleBlockTableAnnotation](#).

Public Properties

Name	Description
 TitleBlockTableFeature	Gets the title block table feature associated with this annotation.

[Top](#)

See Also

[ITitleBlockTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ITitleBlockTableAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ITitleBlockTableAnnotation Interface

For a list of all members of this type, see [ITitleBlockTableAnnotation members](#).

Public Properties

Name	Description
 TitleBlockTableFeature	Gets the title block table feature associated with this annotation.

[Top](#)

See Also

[ITitleBlockTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

TitleBlockTableFeature Property (ITitleBlockTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ITitleBlockTableAnnotation Interface](#) : TitleBlockTableFeature Property (ITitleBlockTableAnnotation)

Gets the title block table feature associated with this annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TitleBlockTableFeature As TitleBlockTableFeature
```

Visual Basic (Usage)



```
Dim instance As ITitleBlockTableAnnotation  
Dim value As TitleBlockTableFeature  
  
value = instance.TitleBlockTableFeature
```

C#

```
TitleBlockTableFeature TitleBlockTableFeature {get;}
```

C++/CLI

```
property TitleBlockTableFeature^ TitleBlockTableFeature {  
    TitleBlockTableFeature^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[TitleBlockTableFeature](#)

Visual Basic for Applications (VBA) Syntax

See [TitleBlockTableAnnotation::TitleBlockTableFeature](#).

Example

[Get Title Block Tables \(VBA\)](#)
[Get Title Block Tables \(VB.NET\)](#)
[Get Title Block Tables \(C#\)](#)

See Also

[ITitleBlockTableAnnotation Interface](#)
[ITitleBlockTableAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0