

SOLIDWORKS API (.NET VBA C#) — Reference

(319/337): IVariableFilletFeatureData2

SOLIDWORKS API Documentation (converted from CHM)

IVariableFilletFeatureData2 (Type)

IVariableFilletFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IVariableFilletFeatureData2 Interface

Allows access to a variable radius fillet feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IVariableFilletFeatureData2
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
```

C#

```
public interface IVariableFilletFeatureData2
```

C++/CLI

```
public interface class IVariableFilletFeatureData2
```

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2](#).

Example

[Create Variable Radius Asymmetric Elliptical Fillet \(VBA\)](#)
[Create Variable Radius Asymmetric Elliptical Fillet \(VB.NET\)](#)
[Create Variable Radius Asymmetric Elliptical Fillet \(C#\)](#)
[Create Curvature Continuous Variable Fillet Feature \(C#\)](#)
[Create Curvature Continuous Variable Fillet Feature \(VB.NET\)](#)
[Create Curvature Continuous Variable Fillet Feature \(VBA\)](#)

Remarks

To create a variable fillet feature, follow the instructions in the Remarks section of [IFeatureManager::FeatureFillet3](#).

To edit a variable fillet feature:

1. Call [IFeature::GetDefinition](#).
2. Call [IVariableFilletFeatureData2::AccessSelections](#).
3. Modify properties on this interface as needed and call [IFeature::ModifyDefinition](#).
4. If nothing is modified, call [IVariableFilletFeatureData2::ReleaseSelectionAccess](#).

For more information, read the **Variable Size Fillets** topic in the SOLIDWORKS Design user-interface help.

Accessors

[IFeature::GetDefinition](#)

Access Diagram

[VariableFilletFeatureData2](#)

See Also

[IVariableFilletFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISimpleFilletFeatureData2 Interface](#)
[IChamferFeatureData2 Interface](#)

IVariableFilletFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IVariableFilletFeatureData2 Interface

For a list of all members of this type, see [IVariableFilletFeatureData2 members](#).

Public Methods

Name	Description
AccessSelections	Gains access to the selections used to define the variable fillet feature.
GetConicRhoOrRadius	Gets the conic rho, conic radius, or circular radius of this fillet.
GetConicRhoOrRadius2	Gets the conic rho or radius at the specified vertex.
GetControlPointConicRhoOrRadiusAtIndex	Gets the conic rho or radius at the specified control point.
GetControlPointDistanceAtIndex	Gets the Distance 2 radius at the specified control point for the asymmetric fillet.
GetControlPointRadiusAtIndex	Gets the radius at the specified control point.
GetControlPointsCount	Gets the number of intermediate control points on this variable fillet feature.
GetDistance	Gets the Distance 2 radius for this asymmetric fillet.
GetFilletEdgeAtIndex	Gets the fillet edge at the specified index.
GetRadius	Obsolete. Superseded by IVariableFilletFeatureData2.GetRadius2 .
GetRadius2	Gets the value of the Distance 1 radius at the specified vertex.
GetSetbackDistanceCount	Gets the number of setback distances for the specified vertex on this variable fillet feature.
GetSetbackVertexDistance	Gets the setback distance for the specified vertex on this variable fillet feature.
GetSetbackVertices	Gets the setback vertices for this variable fillet feature.
GetSetbackVerticesCount	Gets the number of setback vertices for this variable fillet feature.
IAccessSelections	Gains access to the selections used to define the variable fillet feature.
IGetConicRhoOrRadius	Gets the conic rho, conic radius, or circular radius of this fillet.
IGetFilletEdgeAtIndex	Gets the fillet edge at the specified index.
IGetRadius	Obsolete. Superseded by IVariableFilletFeatureData2.Radius2 .
IGetSetbackVertexDistance	Gets the setback distance for the specified vertex on this variable fillet feature.
IGetSetbackVertices	Gets the setback vertices for this variable fillet feature.
ISetConicRhoOrRadius	Sets the conic rho, conic radius, or circular radius of this fillet.
ISetRadius	Sets the radius value for specified fillet item.
ISetSetbackVertexDistance	Sets the setback distance for the specified vertex and its edges on this variable fillet feature.
ISetSetbackVertices	Sets the setback vertices for this variable fillet feature.
ReleaseSelectionAccess	Releases access to the selections used to define the variable fillet feature.
SetConicRhoOrRadius	Sets the conic rho or radius for the specified fillet item.
SetControlPointConicRhoOrRadiusAtIndex	Sets the conic rho or radius at the specified control point.
SetControlPointDistanceAtIndex	Sets the Distance 2 radius at the specified control point for the asymmetric fillet.
SetControlPointRadiusAtIndex	Sets the radius at the specified control point.
SetDistance	Sets the Distance 2 radius for this asymmetric fillet.
SetRadius	Sets the value of the Distance 1 radius at the specified vertex.
SetSetbackVertexDistance	Sets the setback distances on fillet edges from the specified fillet corner vertex on this variable fillet feature.
SetSetbackVertices	Sets the setback vertices for this variable fillet feature.

[Top](#)

See Also

IVariableFilletFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IVariableFilletFeatureData2 Interface

The following tables list the members exposed by [IVariableFilletFeatureData2](#).

Public Properties

Name	Description
 AsymmetricFillet	Gets or sets whether this variable radius fillet is asymmetric.
 ConicTypeForCrossSectionProfile	Gets or sets the type of profile for this fillet.
 CurvatureContinuous	Gets or sets whether to create a smoother curvature between adjacent surfaces for this variable radius fillet feature.
 DefaultConicRhoOrRadius	Gets or sets the default conic rho or conic radius of this fillet.
 DefaultDistance	Gets or sets the default Distance 2 radius of this asymmetric fillet.
 DefaultRadius	Gets or sets the default radius for this symmetric fillet or the default Distance 1 radius for this asymmetric fillet.
 FilletEdgeCount	Gets the number of edges to fillet.
 OverflowType	Gets or sets the overflow type for this variable fillet feature.
 PropagateFeatureToParts	Gets or sets whether to extend the fillet feature to all affected parts in the assembly.
 PropagateToTangentFaces	Gets or sets whether to extend the fillet to all faces tangent to the selected face or edge.
 TransitionType	Gets or sets the type of transition between this variable fillet and an adjacent fillet.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the variable fillet feature.
 GetConicRhoOrRadius	Gets the conic rho, conic radius, or circular radius of this fillet.
 GetConicRhoOrRadius2	Gets the conic rho or radius at the specified vertex.
 GetControlPointConicRhoOrRadiusAtIndex	Gets the conic rho or radius at the specified control point.
 GetControlPointDistanceAtIndex	Gets the Distance 2 radius at the specified control point for the asymmetric fillet.
 GetControlPointRadiusAtIndex	Gets the radius at the specified control point.
 GetControlPointsCount	Gets the number of intermediate control points on this variable fillet feature.
 GetDistance	Gets the Distance 2 radius for this asymmetric fillet.
 GetFilletEdgeAtIndex	Gets the fillet edge at the specified index.
 GetRadius	Obsolete. Superseded by IVariableFilletFeatureData2.GetRadius2
 GetRadius2	Gets the value of the Distance 1 radius at the specified vertex.
 GetSetbackDistanceCount	Gets the number of setback distances for the specified vertex on this variable fillet feature.
 GetSetbackVertexDistance	Gets the setback distance for the specified vertex on this variable fillet feature.
 GetSetbackVertices	Gets the setback vertices for this variable fillet feature.
 GetSetbackVerticesCount	Gets the number of setback vertices for this variable fillet feature.
 IAccessSelections	Gains access to the selections used to define the variable fillet feature.
 IGetConicRhoOrRadius	Gets the conic rho, conic radius, or circular radius of this fillet.
 IGetFilletEdgeAtIndex	Gets the fillet edge at the specified index.
 IGetRadius	Obsolete. Superseded by IVariableFilletFeatureData2.Radius2

	IGetSetbackVertexDistance	Gets the setback distance for the specified vertex on this variable fillet feature.
	IGetSetbackVertices	Gets the setback vertices for this variable fillet feature.
	ISetConicRhoOrRadius	Sets the conic rho, conic radius, or circular radius of this fillet.
	ISetRadius	Sets the radius value for specified fillet item.
	ISetSetbackVertexDistance	Sets the setback distance for the specified vertex and its edges on this variable fillet feature.
	ISetSetbackVertices	Sets the setback vertices for this variable fillet feature.
	ReleaseSelectionAccess	Releases access to the selections used to define the variable fillet feature.
	SetConicRhoOrRadius	Sets the conic rho or radius for the specified fillet item.
	SetControlPointConicRhoOrRadiusAtIndex	Sets the conic rho or radius at the specified control point.
	SetControlPointDistanceAtIndex	Sets the Distance 2 radius at the specified control point for the asymmetric fillet.
	SetControlPointRadiusAtIndex	Sets the radius at the specified control point.
	SetDistance	Sets the Distance 2 radius for this asymmetric fillet.
	SetRadius	Sets the value of the Distance 1 radius at the specified vertex.
	SetSetbackVertexDistance	Sets the setback distances on fillet edges from the specified fillet corner vertex on this variable fillet feature.
	SetSetbackVertices	Sets the setback vertices for this variable fillet feature.

[Top](#)

See Also

[IVariableFilletFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISimpleFilletFeatureData2 Interface](#)
[IChamferFeatureData2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IVariableFilletFeatureData2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IVariableFilletFeatureData2 Interface

For a list of all members of this type, see [IVariableFilletFeatureData2 members](#).

Public Properties

Name	Description
 AsymmetricFillet	Gets or sets whether this variable radius fillet is asymmetric.
 ConicTypeForCrossSectionProfile	Gets or sets the type of profile for this fillet.
 CurvatureContinuous	Gets or sets whether to create a smoother curvature between adjacent surfaces for this variable radius fillet feature.
 DefaultConicRhoOrRadius	Gets or sets the default conic rho or conic radius of this fillet.
 DefaultDistance	Gets or sets the default Distance 2 radius of this asymmetric fillet.
 DefaultRadius	Gets or sets the default radius for this symmetric fillet or the default Distance 1 radius for this asymmetric fillet.
 FilletEdgeCount	Gets the number of edges to fillet.
 OverflowType	Gets or sets the overflow type for this variable fillet feature.
 PropagateFeatureToParts	Gets or sets whether to extend the fillet feature to all affected parts in the assembly.
 PropagateToTangentFaces	Gets or sets whether to extend the fillet to all faces tangent to the selected face or edge.
 TransitionType	Gets or sets the type of transition between this variable fillet and an adjacent fillet.

[Top](#)

See Also

[IVariableFilletFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISimpleFilletFeatureData2 Interface](#)
[IChamferFeatureData2 Interface](#)

AccessSelections Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : AccessSelections Method (IVariableFilletFeatureData2)

Gains access to the selections used to define the variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::AccessSelections](#).

Example

See the [IVariableFilletFeatureData2](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature

- [IVariableFilletFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AsymmetricFillet Property (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : AsymmetricFillet Property (IVariableFilletFeatureData2)

Gets or sets whether this variable radius fillet is asymmetric.

.NET Syntax

Visual Basic (Declaration)

```
Property AsymmetricFillet As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim value As System.Boolean
```

```
instance.AsymmetricFillet = value
```

```
value = instance.AsymmetricFillet
```

C#

```
System.bool AsymmetricFillet {get; set;}
```

C++/CLI

```
property System.bool AsymmetricFillet {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if an asymmetric fillet, false if a symmetric fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::AsymmetricFillet](#).

Example

See the [IVariableFilletFeatureData2](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConicTypeForCrossSectionProfile Property (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : ConicTypeForCrossSectionProfile Property (IVariableFilletFeatureData2)

Gets or sets the type of profile for this fillet.

.NET Syntax

Visual Basic (Declaration)

Property ConicTypeForCrossSectionProfile As System.Integer

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Integer

instance.ConicTypeForCrossSectionProfile = value
value = instance.ConicTypeForCrossSectionProfile
```

C#

```
System.int ConicTypeForCrossSectionProfile {get; set;}
```

C++/CLI

```
property System.int ConicTypeForCrossSectionProfile {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of fillet profile as defined in [swFeatureFilletProfileType_e](#)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#).

Example

See the [IVariableFilletFeatureData2](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CurvatureContinuous Property (IVariableFilletFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : CurvatureContinuous Property (IVariableFilletFeatureData2)

Gets or sets whether to create a smoother curvature between adjacent surfaces for this variable radius fillet feature.

.NET Syntax

Visual Basic (Declaration)

Property CurvatureContinuous As System.Boolean

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Boolean

instance.CurvatureContinuous = value

value = instance.CurvatureContinuous
```

C#

```
System.bool CurvatureContinuous {get; set;}
```

C++/CLI

```
property System.bool CurvatureContinuous {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to make curvatures continuous, false to not

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::CurvatureContinuous](#).

Example

[Create Curvature Continuous Variable Fillet Feature \(C#\)](#)
[Create Curvature Continuous Variable Fillet Feature \(VB.NET\)](#)
[Create Curvature Continuous Variable Fillet Feature \(VBA\)](#)

Remarks

This property supersedes any [IVariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting. Curvature continuous fillets are smoother than standard fillets because there is no jump in curvature at the boundary.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DefaultConicRhoOrRadius Property (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : DefaultConicRhoOrRadius Property (IVariableFilletFeatureData2)

Gets or sets the default conic rho or conic radius of this fillet.

Visual Basic Syntax

Visual Basic (Declaration)

Property DefaultConicRhoOrRadius As System.Double

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Double

instance.DefaultConicRhoOrRadius = value
value = instance.DefaultConicRhoOrRadius
```

C#

```
System.double DefaultConicRhoOrRadius {get; set;}
```

C++/CLI

```
property System.double DefaultConicRhoOrRadius {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Default conic rho or conic radius (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::DefaultConicRhoOrRadius](#).

Remarks

If [IVariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) is set to [swFeatureFilletProfileType_e](#):

- [swFeatureFilletConicRadius](#) (symmetric fillet only), then this property gets or sets a radius.
- [swFeatureFilletConicRho](#) (symmetric or asymmetric fillet), then this property gets or sets a conic rho value in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::DefaultRadius Property\(\)](#)
[IVariableFilletFeatureData2::DefaultDistance Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DefaultDistance Property (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : DefaultDistance Property (IVariableFilletFeatureData2)

Gets or sets the default Distance 2 radius of this asymmetric fillet.

Visual Basic Syntax

Visual Basic (Declaration)

Property DefaultDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Double

instance.DefaultDistance = value

value = instance.DefaultDistance
```

C#

```
System.double DefaultDistance {get; set;}
```

C++/CLI

```
property System.double DefaultDistance {
    System.double get();
    void set ( &    System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Default distance 2 radius of this asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::DefaultDistance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::DefaultRadius Property \(\)](#)
[IVariableFilletFeatureData2::DefaultConicRhoOrRadius Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DefaultRadius Property (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : DefaultRadius Property (IVariableFilletFeatureData2)

Gets or sets the default radius for this symmetric fillet or the default Distance 1 radius for this asymmetric fillet.

.NET Syntax

Visual Basic (Declaration)

```
Property DefaultRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Double

instance.DefaultRadius = value

value = instance.DefaultRadius
```

C#

```
System.double DefaultRadius {get; set;}
```

C++/CLI

```
property System.double DefaultRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Default radius if a symmetric fillet; default Distance 1 radius if an asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::DefaultRadius](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetRadius2 Method](#)
[IVariableFilletFeatureData2::ISetRadius Method](#)
[IVariableFilletFeatureData2::SetRadius Method](#)
[IVariableFilletFeatureData2::DefaultConicRhoOrRadius Property_\(\)](#)
[IVariableFilletFeatureData2::DefaultDistance Property_\(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FilletEdgeCount Property (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : FilletEdgeCount Property (IVariableFilletFeatureData2)

Gets the number of edges to fillet.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FilletEdgeCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim value As System.Integer  
  
value = instance.FilletEdgeCount
```

C#

```
System.int FilletEdgeCount {get;}
```

C++/CLI

```
property System.int FilletEdgeCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of edges to fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::FilletEdgeCount](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetFilletEdgeAtIndex Method](#)
[IVariableFilletFeatureData2::!GetFilletEdgeAtIndex Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConicRhoOrRadius Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetConicRhoOrRadius Method (IVariableFilletFeatureData2)

Gets the conic rho, conic radius, or circular radius of this fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConicRhoOrRadius( _  
    ByVal PFilletItem As System.Object _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim value As System.Double  
  
value = instance.GetConicRhoOrRadius(PFilletItem)
```

C#

```
System.double GetConicRhoOrRadius(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double GetConicRhoOrRadius(  
    & System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem
Fillet edge for which to get a value (see **Remarks**)

Return Value

Conic rho or radius of this fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetConicRhoOrRadius](#).

Remarks

Before calling this method, call [IVariableFilletFeatureData2::GetFilletEdgeAtIndex](#) to specify PFilletItem.

The type of value returned by this method corresponds to the [IVariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::SetConicRhoOrRadius Method \(\)](#)
[IVariableFilletFeatureData2::GetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConicRhoOrRadius2 Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetConicRhoOrRadius2 Method (IVariableFilletFeatureData2)

Gets the conic rho or radius at the specified vertex.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConicRhoOrRadius2( _  
    ByVal PFilletItem As Vertex, _  
    ByRef IsAssigned As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As Vertex  
Dim IsAssigned As System.Boolean  
Dim value As System.Double  
  
value = instance.GetConicRhoOrRadius2(PFilletItem, IsAssigned)
```

C#

```
System.double GetConicRhoOrRadius2(  
    Vertex PFilletItem,  
    out System.bool IsAssigned  
)
```

C++/CLI

```
System.double GetConicRhoOrRadius2(  
& Vertex^ PFilletItem,  
& [Out] System.bool IsAssigned  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Vertex for which to get a value (see **Remarks**)

IsAssigned

True if the conic value is assigned to each control point, false if not

Return Value

Conic rho or radius

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetConicRhoOrRadius2](#).

Remarks

Before calling this method, call [VariableFilletFeatureData2::GetFilletEdgeAtIndex](#) to specify PFilletItem.

If [VariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) is set to [swFeatureFilletProfileType_e](#):

- [swFeatureFilletConicRadius](#) (symmetric fillet only), then this method returns a radius.
- [swFeatureFilletConicRho](#) (symmetric or asymmetric fillet), then this method returns a conic rho value in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::IGetConicRhoOrRadius Method \(\)](#)
[IVariableFilletFeatureData2::SetConicRhoOrRadius Method \(\)](#)
[IVariableFilletFeatureData2::GetRadius2 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControlPointConicRhoOrRadiusAtIndex Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetControlPointConicRhoOrRadiusAtIndex Method (IVariableFilletFeatureData2)

Gets the conic rho or radius at the specified control point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControlPointConicRhoOrRadiusAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetControlPointConicRhoOrRadiusAtIndex(Index)
```

C#

```
System.double GetControlPointConicRhoOrRadiusAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetControlPointConicRhoOrRadiusAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Zero-based index of the control point (see **Remarks**)

Return Value

Conic rho or radius

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetControlPointConicRhoOrRadiusAtIndex](#).

Remarks

Call [IVariableFilletFeatureData2::GetControlPointsCount](#) before calling this method to determine a value for Index.

If [IVariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) is set to [swFeatureFilletProfileType_e](#):

- [swFeatureFilletConicRadius](#) (symmetric fillet only), then this method returns a radius.
- [swFeatureFilletConicRho](#) (symmetric or asymmetric fillet), then this method returns a conic rho value in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::SetControlPointConicRhoOrRadiusAtIndex Method \(\)](#)
[IVariableFilletFeatureData2::GetControlPointRadiusAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControlPointDistanceAtIndex Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetControlPointDistanceAtIndex Method (IVariableFilletFeatureData2)

Gets the Distance 2 radius at the specified control point for the asymmetric fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControlPointDistanceAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetControlPointDistanceAtIndex(Index)
```

C#

```
System.double GetControlPointDistanceAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetControlPointDistanceAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Zero-based index of control point for which to get the radius

Return Value

Value of the Distance 2 radius at the specified control point for the asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetControlPointDistanceAtIndex](#).

Remarks

Call [IVariableFilletFeatureData2::GetControlPointRadiusAtIndex](#) to get the Distance 1 radius of the control point for this asymmetric fillet.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::SetControlPointDistanceAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControlPointRadiusAtIndex Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetControlPointRadiusAtIndex Method (IVariableFilletFeatureData2)

Gets the radius at the specified control point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControlPointRadiusAtIndex( _  
    ByVal Index As System.Integer, _  
    ByRef Location As System.Double, _  
    ByRef PEdge As Edge _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Index As System.Integer  
Dim Location As System.Double  
Dim PEdge As Edge  
Dim value As System.Double  
  
value = instance.GetControlPointRadiusAtIndex(Index, Location, PEdge)
```

C#

```
System.double GetControlPointRadiusAtIndex(  
    System.int Index,  
    out System.double Location,  
    out Edge PEdge  
)
```

C++/CLI

```
System.double GetControlPointRadiusAtIndex(  
& System.int Index,  
& [Out] System.double Location,  
& [Out] Edge^ PEdge  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Zero-based index of the control point
Location
Location of the control point
PEdge

[Edge](#)

Return Value

Value of the radius at the specified control point for the symmetric fillet; value of the Distance 1 radius at the specified control point for the asymmetric fillet (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetControlPointRadiusAtIndex](#).

Remarks

Call [IVariableFilletFeatureData2::GetControlPointsCount](#) before calling this method.

Call [IVariableFilletFeatureData2::GetControlPointDistanceAtIndex](#) to get the Distance 2 radius for the control point of the asymmetric fillet.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)

[IVariableFilletFeatureData2 Members](#)

[IVariableFilletFeatureData2::SetControlPointRadiusAtIndex Method](#)

[IVariableFilletFeatureData2::GetControlPointConicRhoOrRadiusAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControlPointsCount Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetControlPointsCount Method (IVariableFilletFeatureData2)

Gets the number of intermediate control points on this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControlPointsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
```

```
Dim value As System.Integer
```

```
value = instance.GetControlPointsCount()
```

C#

```
System.int GetControlPointsCount()
```

C++/CLI

```
System.int GetControlPointsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of intermediate control points

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetControlPointsCount](#).

Remarks

Call this method before calling [IVariableFilletFeatureData2::GetControlPointRadiusAtIndex](#).

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDistance Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetDistance Method (IVariableFilletFeatureData2)

Gets the Distance 2 radius for this asymmetric fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDistance( _  
    ByVal PFilletItem As System.Object _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim value As System.Double
```

```
value = instance.GetDistance(PFilletItem)
```

C#

```
System.double GetDistance(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double GetDistance(  
    & System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem
[Vertex](#) at which to get the radius

Return Value

Distance 2 radius at the vertex for the asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetDistance](#).

Example

See the [IVariableFilletFeatureData2](#) examples.

Remarks

Call [IVariableFilletFeatureData2::GetRadius2](#) to get the Distance 1 radius at the vertex for this asymmetric fillet.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::SetDistance Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFilletEdgeAtIndex Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetFilletEdgeAtIndex Method (IVariableFilletFeatureData2)

Gets the fillet edge at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFilletEdgeAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetFilletEdgeAtIndex(Index)
```

C#

```
System.object GetFilletEdgeAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetFilletEdgeAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Zero-based index of the fillet edge

Return Value

Fillet [edge](#)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetFilletEdgeAtIndex](#).

Example

See the [IVariableFilletFeatureData2](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::IGetFilletEdgeAtIndex Method](#)
[IVariableFilletFeatureData2::FilletEdgeCount Property](#)
[IVariableFilletFeatureData2::GetConicRhoOrRadius Method \(\)](#)
[IVariableFilletFeatureData2::GetConicRhoOrRadius2 Method \(\)](#)
[IVariableFilletFeatureData2::SetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRadius Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetRadius Method (IVariableFilletFeatureData2)

Obsolete. Superseded by [IVariableFilletFeatureData2::GetRadius2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetRadius( _  
    ByVal PFilletItem As System.Object _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim value As System.Double  
  
value = instance.GetRadius(PFilletItem)
```

C#

```
System.double GetRadius(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double GetRadius(  
& System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetRadius](#).

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRadius2 Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetRadius2 Method (IVariableFilletFeatureData2)

Gets the value of the Distance 1 radius at the specified vertex.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRadius2( _  
    ByVal PFilletItem As Vertex, _  
    ByRef IsAssigned As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As Vertex  
Dim IsAssigned As System.Boolean  
Dim value As System.Double  
  
value = instance.GetRadius2(PFilletItem, IsAssigned)
```

C#

```
System.double GetRadius2(  
    Vertex PFilletItem,  
    out System.bool IsAssigned  
)
```

C++/CLI

```
System.double GetRadius2(  
& Vertex^ PFilletItem,  
& [Out] System.bool IsAssigned  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

[Vertex](#) at which to get the radius

IsAssigned

True if the radius is assigned to a control point, false if not

Return Value

Fillet radius at the vertex specified by PFilletItem for the symmetric fillet; Distance 1 radius at the vertex for the asymmetric fillet (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetRadius2](#).

Example

See the [IVariableFilletFeatureData2](#) examples.

Remarks

Call [IVariableFilletFeatureData2::GetDistance](#) to get the Distance 2 radius at the vertex for the asymmetric fillet.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::ISetRadius Method](#)
[IVariableFilletFeatureData2::SetRadius Method](#)
[IVariableFilletFeatureData2::DefaultRadius Property](#)
[IVariableFilletFeatureData2::GetConicRhoOrRadius2 Method \(\)](#)

Availability

GetSetbackDistanceCount Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetSetbackDistanceCount Method (IVariableFilletFeatureData2)

Gets the number of setback distances for the specified vertex on this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSetbackDistanceCount( _  
    ByVal Vtx As Vertex _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Vtx As Vertex  
Dim value As System.Integer  
  
value = instance.GetSetbackDistanceCount(Vtx)
```

C#

```
System.int GetSetbackDistanceCount(  
    Vertex Vtx  
)
```

C++/CLI

```
System.int GetSetbackDistanceCount(  
& Vertex^ Vtx  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Vtx
[Vertex](#)

Return Value

Number of setback distances and number of edges

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetSetbackDistanceCount](#).

Remarks

Because there is a one-to-one correspondence between the edges and distances, the count argument also represents the number of edges at the specified vertex.

Call this method before calling [IVariableFilletFeatureData2::IGetSetbackVertexDistance](#).

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::GetSetbackVertices Method](#)
[IVariableFilletFeatureData2::GetSetbackVerticesCount Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)
[IVariableFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::SetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::SetSetbackVertices Method](#)

Availability

GetSetbackVertexDistance Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetSetbackVertexDistance Method (IVariableFilletFeatureData2)

Gets the setback distance for the specified vertex on this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSetbackVertexDistance( _
    ByVal Vtx As System.Object, _
    ByRef EdgeVar As System.Object _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim Vtx As System.Object
Dim EdgeVar As System.Object
Dim value As System.Object

value = instance.GetSetbackVertexDistance(Vtx, EdgeVar)
```

C#

```
System.object GetSetbackVertexDistance(
    System.object Vtx,
    out System.object EdgeVar
)
```

C++/CLI

```
System.Object^ GetSetbackVertexDistance(
    & System.Object^ Vtx,
    & [Out] System.Object^ EdgeVar
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[Vtx](#)
[Vertex](#) for which to get setback distance
[EdgeVar](#)
 Array of [edges](#) at the specified vertex (see **Remarks**)

Return Value

Array of setback distances at the specified

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetSetbackVertexDistance](#).

Remarks

There is a one-to-one correspondence between the edge array and the setback distance array.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::GetSetbackDistanceCount Method](#)
[IVariableFilletFeatureData2::GetSetbackVertices Method](#)
[IVariableFilletFeatureData2::GetSetbackVerticesCount Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSetbackVertices Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetSetbackVertices Method (IVariableFilletFeatureData2)

Gets the setback vertices for this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSetbackVertices() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim value As System.Object
```

```
value = instance.GetSetbackVertices()
```

C#

```
System.Object GetSetbackVertices()
```

C++/CLI

```
System.Object^ GetSetbackVertices();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of setback [vertices](#)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetSetbackVertices](#).

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)
[IVariableFilletFeatureData2::GetSetbackVerticesCount Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::SetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::SetSetbackVertices Method](#)
[IVariableFilletFeatureData2::GetSetbackDistanceCount Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::SetSetbackVertexDistance Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSetbackVerticesCount Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : GetSetbackVerticesCount Method (IVariableFilletFeatureData2)

Gets the number of setback vertices for this variable fillet feature.

.NET Syntax

```
Function GetSetbackVerticesCount() As System.Integer
```



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Integer

value = instance.GetSetbackVerticesCount()
```

```
System.int GetSetbackVerticesCount()
```

```
System.int GetSetbackVerticesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of setback vertices

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::GetSetbackVerticesCount](#).

Remarks

Call this method before calling [IVariableFilletFeatureData2::IGetSetbackVertices](#).

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetSetbackDistanceCount Method](#)
[IVariableFilletFeatureData2::GetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::GetSetbackVertices Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)
[IVariableFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::ISetSetbackVertices Method](#)
[IVariableFilletFeatureData2::SetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : IAccessSelections Method (IVariableFilletFeatureData2)

Gains access to the selections used to define the variable fillet feature.

.NET Syntax

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```



```

Dim instance As IVariableFilletFeatureData2
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)

```

C#

```

System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)

```

C++/CLI

```

System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

TRUE if the selections are successfully accessed, FALSE if not

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IVariableFilletFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetConicRhoOrRadius Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : IGetConicRhoOrRadius Method (IVariableFilletFeatureData2)

Gets the conic rho, conic radius, or circular radius of this fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetConicRhoOrRadius( _  
    ByVal PFilletItem As Vertex _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As Vertex  
Dim value As System.Double  
  
value = instance.IGetConicRhoOrRadius(PFilletItem)
```

C#

```
System.double IGetConicRhoOrRadius(  
    Vertex PFilletItem  
)
```

C++/CLI

```
System.double IGetConicRhoOrRadius(  
& Vertex^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Fillet edge for which to get a value (see **Remarks**)

Return Value

Conic rho, conic radius, or circular radius

Remarks

Before calling this method, call [IVariableFilletFeatureData2::IGetFilletEdgeAtIndex](#) to specify PFilletItem.

The type of value returned by this method corresponds to the [IVariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetConicRhoOrRadius2 Method \(\)](#)
[IVariableFilletFeatureData2::IGetConicRhoOrRadius Method \(\)](#)
[IVariableFilletFeatureData2::IGetRadius Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFilletEdgeAtIndex Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : IGetFilletEdgeAtIndex Method (IVariableFilletFeatureData2)

Gets the fillet edge at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFilletEdgeAtIndex( _  
    ByVal Index As System.Integer _  
) As Edge
```

```
Dim instance As IVariableFilletFeatureData2
Dim Index As System.Integer
Dim value As Edge

value = instance.IGetFilletEdgeAtIndex(Index)
```

C#

```
Edge IGetFilletEdgeAtIndex(
    System.int Index
)
```

C++/CLI

```
Edge^ IGetFilletEdgeAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index at which fillet edge is required

Return Value

Fillet [edge](#)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::IGetFilletEdgeAtIndex](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetFilletEdgeAtIndex Method](#)
[IVariableFilletFeatureData2::FilletEdgeCount Property](#)
[IVariableFilletFeatureData2::IGetConicRhoOrRadius Method \(\)](#)
[IVariableFilletFeatureData2::ISetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetRadius Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : IGetRadius Method (IVariableFilletFeatureData2)

Obsolete. Superseded by [IVariableFilletFeatureData2::Radius2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRadius( _
    ByVal PFilletItem As Vertex _
) As System.Double
```

Visual Basic (Usage)

```
Dim instance As IVariableFilletFeatureData2
Dim PFilletItem As Vertex
Dim value As System.Double

value = instance.IGetRadius(PFilletItem)
```

C#

```
System.double IGetRadius(
    Vertex PFilletItem
)
```

C++/CLI

```
System.double IGetRadius(
    & Vertex^ PFilletItem
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::IGetRadius](#).

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSetbackVertexDistance Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : IGetSetbackVertexDistance Method (IVariableFilletFeatureData2)

Gets the setback distance for the specified vertex on this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSetbackVertexDistance( _
    ByVal Count As System.Integer, _
    ByVal Vtx As Vertex, _
    ByRef EdgeArr As Edge _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim Count As System.Integer
Dim Vtx As Vertex
Dim EdgeArr As Edge
Dim value As System.Double

value = instance.IGetSetbackVertexDistance(Count, Vtx, EdgeArr)
```

C#

```
System.double IGetSetbackVertexDistance(
    System.int Count,
    Vertex Vtx,
    out Edge EdgeArr
)
```

```
System.double IGetSetbackVertexDistance(
    & System.int Count,
    & Vertex^ Vtx,
    & [Out] Edge^ EdgeArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of edges and setback distances for this vertex

Vtx

[Vertex](#) for which to get setback distance

EdgeArr

- in-process, unmanaged C++: Pointer to an array of [edges](#) at the specified vertex (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Return Value

- in-process, unmanaged C++: Pointer to an array of setback distances at the specified
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

There is a one-to-one correspondence between the edge array and the setback distance array.

Before calling this method, call [VariableFilletFeatureData2::GetSetbackDistanceCount](#) to get the number of edges and setback distances at the specified vertex.

See Also

[IVariableFilletFeatureData2 Interface](#)
[VariableFilletFeatureData2 Members](#)
[VariableFilletFeatureData2::GetSetbackVertexDistance Method](#)
[VariableFilletFeatureData2::GetSetbackVertices Method](#)
[VariableFilletFeatureData2::IGetSetbackVertices Method](#)
[VariableFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[VariableFilletFeatureData2::ISetSetbackVertices Method](#)
[VariableFilletFeatureData2::SetSetbackVertexDistance Method](#)
[VariableFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSetbackVertices Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : IGetSetbackVertices Method (IVariableFilletFeatureData2)

Gets the setback vertices for this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSetbackVertices( _
    ByVal Count As System.Integer _
) As Vertex
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim Count As System.Integer
Dim value As Vertex

value = instance.IGetSetbackVertices(Count)
```

C#

```
Vertex IGetSetbackVertices(  
    System.int Count  
)
```

C++/CLI

```
Vertex^ IGetSetbackVertices(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of setback vertices

Return Value

- in-process, unmanaged C++: Pointer to an array of setback [vertices](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [VariableFilletFeatureData2::GetSetbackVerticesCount](#).

See Also

[VariableFilletFeatureData2 Interface](#)
[VariableFilletFeatureData2 Members](#)
[VariableFilletFeatureData2::GetSetbackVertices Method](#)
[VariableFilletFeatureData2::GetSetbackDistanceCount Method](#)
[VariableFilletFeatureData2::GetSetbackVertexDistance Method](#)
[VariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[VariableFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[VariableFilletFeatureData2::ISetSetbackVertices Method](#)
[VariableFilletFeatureData2::SetSetbackVertexDistance Method](#)
[VariableFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetConicRhoOrRadius Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : ISetConicRhoOrRadius Method (IVariableFilletFeatureData2)

Sets the conic rho, conic radius, or circular radius of this fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetConicRhoOrRadius( _  
    ByVal PFilletItem As Vertex, _  
    ByVal ConicRhoVal As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As Vertex  
Dim ConicRhoVal As System.Double  
  
instance.ISetConicRhoOrRadius(PFilletItem, ConicRhoVal)
```

C#

```
void ISetConicRhoOrRadius(  
    Vertex PFilletItem,  
    System.double ConicRhoVal  
)
```

C++/CLI

```
void ISetConicRhoOrRadius(  
& Vertex^ PFilletItem,  
& System.double ConicRhoVal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Fillet edge for which to set ConicRhoVal (see **Remarks**)

ConicRhoVal

Conic rho, conic radius, or circular radius (see **Remarks**)

Remarks

Before calling this method, call [IVariableFilletFeatureData2::IGetFilletEdgeAtIndex](#) to specify PFilletItem.

The type of ConicRhoVal must match the [IVariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting.

If setting the conic rho value, it must be in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)

[IVariableFilletFeatureData2 Members](#)

[IVariableFilletFeatureData2::IGetConicRhoOrRadius Method \(\)](#)

[IVariableFilletFeatureData2::SetConicRhoOrRadius Method \(\)](#)

[IVariableFilletFeatureData2::ISetRadius Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetRadius Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : ISetRadius Method (IVariableFilletFeatureData2)

Sets the radius value for specified fillet item.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetRadius(  
    ByVal PFilletItem As Vertex, _  
    ByVal Radius As System.Double _  
)
```

Visual Basic (Usage)

```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As Vertex  
Dim Radius As System.Double  
  
instance.ISetRadius(PFilletItem, Radius)
```

C#



```
void ISetRadius(
    Vertex PFilletItem,
    System.double Radius
)
```

C++/CLI

```
void ISetRadius(
    & Vertex^ PFilletItem,
    & System.double Radius
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

[Vertex](#) whose radius to set

Radius

Radius

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::ISetRadius](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::SetRadius Method](#)
[IVariableFilletFeatureData2::DefaultRadius Property](#)
[IVariableFilletFeatureData2::GetRadius2 Method](#)
[IVariableFilletFeatureData2::ISetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSetbackVertexDistance Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : ISetSetbackVertexDistance Method (IVariableFilletFeatureData2)

Sets the setback distance for the specified vertex and its edges on this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetSetbackVertexDistance( _
    ByVal Count As System.Integer, _
    ByVal Vtx As Vertex, _
    ByRef EdgeArr As Edge, _
    ByRef DistArr As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim Count As System.Integer
Dim Vtx As Vertex
Dim EdgeArr As Edge
Dim DistArr As System.Double
```

```
Dim value As System.Boolean
```

```
value = instance.ISetSetbackVertexDistance(Count, Vtx, EdgeArr, DistArr)
```

C#

```
System.bool ISetSetbackVertexDistance(  
    System.int Count,  
    Vertex Vtx,  
    ref Edge EdgeArr,  
    ref System.double DistArr  
)
```

C++/CLI

```
System.bool ISetSetbackVertexDistance(  
    & System.int Count,  
    & Vertex^ Vtx,  
    & Edge^% EdgeArr,  
    & System.double% DistArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of setback distances

Vtx

[Vertex](#) for which to set the setback distance

EdgeArr

- in-process, unmanaged C++: Pointer to an array of [edges](#) at the specified vertex (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

DistArr

- in-process, unmanaged C++: Pointer to an array of setback distances at the specified
- VBA, VB.NET, C#, and C++/CLI: Not supported

Return Value

TRUE if setback distance is set, FALSE if not

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::ISetSetbackVertexDistance](#).

Remarks

There is a one-to-one correspondence between the edge array and the distance array.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)

[IVariableFilletFeatureData2 Members](#)

[IVariableFilletFeatureData2::SetSetbackVertexDistance Method](#)

[IVariableFilletFeatureData2::SetSetbackVertices Method](#)

[IVariableFilletFeatureData2::ISetSetbackVertices Method](#)

[IVariableFilletFeatureData2::GetSetbackDistanceCount Method](#)

[IVariableFilletFeatureData2::GetSetbackVertexDistance Method](#)

[IVariableFilletFeatureData2::GetSetbackVertices Method](#)

[IVariableFilletFeatureData2::GetSetbackVerticesCount Method](#)

[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)

[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSetbackVertices Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : ISetSetbackVertices Method (IVariableFilletFeatureData2)

Sets the setback vertices for this variable fillet feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ISetSetbackVertices( _  
    ByVal Count As System.Integer, _  
    ByRef VertArr As Vertex _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Count As System.Integer  
Dim VertArr As Vertex  
Dim value As System.Boolean  
  
value = instance.ISetSetbackVertices(Count, VertArr)
```

C#

```
System.bool ISetSetbackVertices(  
    System.int Count,  
    ref Vertex VertArr  
)
```

C++/CLI

```
System.bool ISetSetbackVertices(  
& System.int Count,  
& Vertex^% VertArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of vertices

VertArr

- in-process, unmanaged C++: Pointer to an array of setback [vertices](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if all edges of vertex are filleted, false if not

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)

[IVariableFilletFeatureData2 Members](#)

[IVariableFilletFeatureData2::SetSetbackVertices Method](#)

[IVariableFilletFeatureData2::SetSetbackVertexDistance Method](#)

[IVariableFilletFeatureData2::ISetSetbackVertexDistance Method](#)

[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)

[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)

[IVariableFilletFeatureData2::GetSetbackVerticesCount Method](#)

[IVariableFilletFeatureData2::GetSetbackVertices Method](#)

[IVariableFilletFeatureData2::GetSetbackVertexDistance Method](#)

[IVariableFilletFeatureData2::GetSetbackDistanceCount Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverflowType Property (IVariableFilletFeatureData2)

[See Also](#)



Gets or sets the overflow type for this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

Property OverflowType As System.Integer

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Integer

instance.OverflowType = value

value = instance.OverflowType
```

C#

```
System.int OverflowType {get; set;}
```

C++/CLI

```
property System.int OverflowType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Overflow type as defined in [swFilletOverFlowType_e](#)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::OverflowType](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateFeatureToParts Property (IVariableFilletFeatureData2)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IVariableFilletFeatureData2 Interface : PropagateFeatureToParts Property (IVariableFilletFeatureData2)

Gets or sets whether to extend the fillet feature to all affected parts in the assembly.

.NET Syntax

Visual Basic (Declaration)

Property PropagateFeatureToParts As System.Boolean

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Boolean

instance.PropagateFeatureToParts = value

value = instance.PropagateFeatureToParts
```

C#

```
System.bool PropagateFeatureToParts {get; set;}
```

C++/CLI

```
property System.bool PropagateFeatureToParts {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to extend fillet feature to all affected parts in the assembly, false to not

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::PropagateFeatureToParts](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateToTangentFaces Property (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : PropagateToTangentFaces Property (IVariableFilletFeatureData2)

Gets or sets whether to extend the fillet to all faces tangent to the selected face or edge.

.NET Syntax

Visual Basic (Declaration)

```
Property PropagateToTangentFaces As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
Dim value As System.Boolean

instance.PropagateToTangentFaces = value

value = instance.PropagateToTangentFaces
```

C#

```
System.bool PropagateToTangentFaces {get; set;}
```

C++/CLI

```
property System.bool PropagateToTangentFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to extend fillet to all faces tangent to the selected face or edge, false to not

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::PropagateToTangentFaces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : ReleaseSelectionAccess Method (IVariableFilletFeatureData2)

Releases access to the selections used to define the variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2
```

```
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::ReleaseSelectionAccess](#).

Example

See the [IVariableFilletFeatureData2](#) examples.

Remarks

[IVariableFilletFeatureData2::AccessSelections](#) and [IVariableFilletFeatureData2::IAccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetConicRhoOrRadius Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : SetConicRhoOrRadius Method (IVariableFilletFeatureData2)

Sets the conic rho or radius for the specified fillet item.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetConicRhoOrRadius( _  
    ByVal PFilletItem As System.Object, _  
    ByVal ConicRhoVal As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim ConicRhoVal As System.Double  
  
instance.SetConicRhoOrRadius(PFilletItem, ConicRhoVal)
```

C#

```
void SetConicRhoOrRadius(  
    System.object PFilletItem,  
    System.double ConicRhoVal  
)
```

C++/CLI

```
void SetConicRhoOrRadius(  
& System.Object^ PFilletItem,  
& System.double ConicRhoVal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem
Fillet item for which to set ConicRhoVal (see **Remarks**)
ConicRhoVal
Conic rho or radius (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::SetConicRhoOrRadius](#).

Remarks

Before calling this method, call [IVariableFilletFeatureData2::GetFilletEdgeAtIndex](#) to specify PFilletItem.

If [IVariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) is set to [swFeatureFilletProfileType_e](#):

- [swFeatureFilletConicRadius](#) (symmetric fillet only), then specify [ConicRhoVal](#) with a radius.
- [swFeatureFilletConicRho](#) (symmetric or asymmetric fillet), then specify [ConicRhoVal](#) with the conic rho value in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetConicRhoOrRadius2 Method \(\)](#)
[IVariableFilletFeatureData2::ISetConicRhoOrRadius Method \(\)](#)
[IVariableFilletFeatureData2::SetRadius Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetControlPointConicRhoOrRadiusAtIndex Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : SetControlPointConicRhoOrRadiusAtIndex Method (IVariableFilletFeatureData2)

Sets the conic rho or radius at the specified control point.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetControlPointConicRhoOrRadiusAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal ConicRhoVal As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Index As System.Integer  
Dim ConicRhoVal As System.Double  
  
instance.SetControlPointConicRhoOrRadiusAtIndex(Index, ConicRhoVal)
```

C#

```
void SetControlPointConicRhoOrRadiusAtIndex(  
    System.int Index,  
    System.double ConicRhoVal  
)
```

C++/CLI

```
void SetControlPointConicRhoOrRadiusAtIndex(  
& System.int Index,  
& System.double ConicRhoVal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Zero-based index of the control point for which to set [ConicRhoVal](#) (see **Remarks**)

ConicRhoVal

Conic rho or radius (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::SetControlPointConicRhoOrRadiusAtIndex](#).

Remarks

Call [IVariableFilletFeatureData2::GetControlPointsCount](#) before calling this method to determine a value for Index.

If [IVariableFilletFeatureData2::ConicTypeForCrossSectionProfile](#) is set to [swFeatureFilletProfileType_e](#):

- [swFeatureFilletConicRadius](#) (symmetric fillet only), then specify [ConicRhoVal](#) with a radius.
- [swFeatureFilletConicRho](#) (symmetric or asymmetric fillet), then specify [ConicRhoVal](#) with the conic rho value in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetControlPointConicRhoOrRadiusAtIndex Method \(\)](#)
[IVariableFilletFeatureData2::SetControlPointRadiusAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetControlPointDistanceAtIndex Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : [SetControlPointDistanceAtIndex Method \(IVariableFilletFeatureData2\)](#)

Sets the Distance 2 radius at the specified control point for the asymmetric fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetControlPointDistanceAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal Dist2 As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Index As System.Integer  
Dim Dist2 As System.Double  
  
instance.SetControlPointDistanceAtIndex(Index, Dist2)
```

C#

```
void SetControlPointDistanceAtIndex(  
    System.int Index,  
    System.double Dist2  
)
```

C++/CLI

```
void SetControlPointDistanceAtIndex(  
& System.int Index,  
& System.double Dist2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Zero-based index of control point whose radius to set

Dist2

Distance 2 radius for the control point of this asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::SetControlPointDistanceAtIndex](#).

Remarks

Call [IVariableFilletFeatureData2::SetControlPointRadiusAtIndex](#) to set the Distance 1 radius for the control point of this asymmetric fillet.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetControlPointDistanceAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetControlPointRadiusAtIndex Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : SetControlPointRadiusAtIndex Method (IVariableFilletFeatureData2)

Sets the radius at the specified control point.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetControlPointRadiusAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal Location As System.Double, _  
    ByVal Radius As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Index As System.Integer  
Dim Location As System.Double  
Dim Radius As System.Double  
  
instance.SetControlPointRadiusAtIndex(Index, Location, Radius)
```

C#

```
void SetControlPointRadiusAtIndex(  
    System.int Index,  
    System.double Location,  
    System.double Radius  
)
```

C++/CLI

```
void SetControlPointRadiusAtIndex(  
& System.int Index,  
& System.double Location,  
& System.double Radius  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Zero-based index of control point whose radius to set

Location

Percent distance between the edge start vertex and the edge end vertex

Radius

Value of the radius for the control point of this symmetric fillet; Distance 1 radius for the control point of this asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::SetControlPointRadiusAtIndex](#).

Remarks

Call [IVariableFilletFeatureData2::SetControlPointDistanceAtIndex](#) to set the Distance 2 radius for the control point of this asymmetric fillet.
See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetControlPointRadiusAtIndex Method](#)
[IVariableFilletFeatureData2::GetControlPointsCount Method](#)
[IVariableFilletFeatureData2::SetControlPointConicRhoOrRadiusAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDistance Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : SetDistance Method (IVariableFilletFeatureData2)

Sets the Distance 2 radius for this asymmetric fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDistance( _  
    ByVal PFilletItem As System.Object, _  
    ByVal Dist2 As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim Dist2 As System.Double  
  
instance.SetDistance(PFilletItem, Dist2)
```

C#

```
void SetDistance(  
    System.object PFilletItem,  
    System.double Dist2  
)
```

C++/CLI

```
void SetDistance(  
& System.Object^ PFilletItem,  
& System.double Dist2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[PFilletItem](#)
[Vertex](#) at which to set the Distance 2 radius
[Dist2](#)
Distance 2 radius at the vertex specified by PFilletItem

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::SetDistance](#).

Remarks

Call [IVariableFilletFeatureData2::SetRadius](#) to set the Distance 1 radius at the vertex.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::GetDistance Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRadius Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : SetRadius Method (IVariableFilletFeatureData2)

Sets the value of the Distance 1 radius at the specified vertex.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetRadius( _  
    ByVal PFilletItem As System.Object, _  
    ByVal Radius As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim Radius As System.Double  
  
instance.SetRadius(PFilletItem, Radius)
```

C#

```
void SetRadius(  
    System.object PFilletItem,  
    System.double Radius  
)
```

C++/CLI

```
void SetRadius(  
& System.Object^ PFilletItem,  
& System.double Radius  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

[Vertex](#) at which to set the radius

Radius

Radius of the symmetric fillet at the vertex specified by *PFilletItem*; Distance 1 radius of the asymmetric fillet at the vertex

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::SetRadius](#).

Remarks

Call [IVariableFilletFeatureData2::SetDistance](#) to set the Distance 2 radius at the vertex for the asymmetric fillet.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::DefaultRadius Property](#)
[IVariableFilletFeatureData2::GetRadius2 Method](#)
[IVariableFilletFeatureData2::SetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSetbackVertexDistance Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : SetSetbackVertexDistance Method (IVariableFilletFeatureData2)

Sets the setback distances on fillet edges from the specified fillet corner vertex on this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSetbackVertexDistance( _  
    ByVal Vtx As System.Object, _  
    ByVal EdgeVar As System.Object, _  
    ByVal DistVar As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim Vtx As System.Object  
Dim EdgeVar As System.Object  
Dim DistVar As System.Object  
Dim value As System.Boolean  
  
value = instance.SetSetbackVertexDistance(Vtx, EdgeVar, DistVar)
```

C#

```
System.bool SetSetbackVertexDistance(  
    System.object Vtx,  
    System.object EdgeVar,  
    System.object DistVar  
)
```

C++/CLI

```
System.bool SetSetbackVertexDistance(  
& System.Object^ Vtx,  
& System.Object^ EdgeVar,  
& System.Object^ DistVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[Vtx](#)
[Vertex](#) for which to set the setback distance
[EdgeVar](#)
Array of [edges](#) for this vertex
[DistVar](#)
Array of distances

Return Value

True if setback distances are set, false if not

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::SetSetbackVertexDistance](#).

Remarks

There is a one-to-one correspondence between the arrays specified by EdgeVar and DistVar.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::SetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::SetSetbackVertices Method](#)
[IVariableFilletFeatureData2::ISetSetbackVertices Method](#)
[IVariableFilletFeatureData2::GetSetbackDistanceCount Method](#)
[IVariableFilletFeatureData2::GetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::GetSetbackVertices Method](#)
[IVariableFilletFeatureData2::GetSetbackVerticesCount Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSetbackVertices Method (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : SetSetbackVertices Method (IVariableFilletFeatureData2)

Sets the setback vertices for this variable fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSetbackVertices( _  
    ByVal VertVar As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim VertVar As System.Object  
Dim value As System.Boolean  
  
value = instance.SetSetbackVertices(VertVar)
```

C#

```
System.bool SetSetbackVertices(  
    System.object VertVar  
)
```

C++/CLI

```
System.bool SetSetbackVertices(  
& System.Object^ VertVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertVar
Array of [vertices](#)

Return Value

True if setback vertices are set, false if not

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::SetSetbackVertices](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)
[IVariableFilletFeatureData2::ISetSetbackVertices Method](#)
[IVariableFilletFeatureData2::SetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::GetSetbackDistanceCount Method](#)
[IVariableFilletFeatureData2::GetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::GetSetbackVertices Method](#)
[IVariableFilletFeatureData2::GetSetbackVerticesCount Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[IVariableFilletFeatureData2::IGetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TransitionType Property (IVariableFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IVariableFilletFeatureData2 Interface](#) : TransitionType Property (IVariableFilletFeatureData2)

Gets or sets the type of transition between this variable fillet and an adjacent fillet.

.NET Syntax

Visual Basic (Declaration)

```
Property TransitionType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IVariableFilletFeatureData2  
Dim value As System.Integer  
  
instance.TransitionType = value  
  
value = instance.TransitionType
```

C#

```
System.int TransitionType {get; set;}
```

C++/CLI

```
property System.int TransitionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of transition as defined in [swVariableRadiusFilletOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [VariableFilletFeatureData2::TransitionType](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IVariableFilletFeatureData2 Interface](#)
[IVariableFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0