

SOLIDWORKS API (.NET VBA C#) — Reference (322/337): View (part 2 of 10)

SOLIDWORKS API Documentation (converted from CHM)

IView (part 2 of 10) (Type)

FlipView Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : FlipView Property (IView)

Gets or sets whether to flip a flat-pattern view of a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Property FlipView As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

instance.FlipView = value

value = instance.FlipView
```

C#

```
System.bool FlipView {get; set;}
```

C++/CLI

```
property System.bool FlipView {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the flat-pattern view, false to not

Visual Basic for Applications (VBA) Syntax

See [View::FlipView](#).

Example

[Create and Flip Flat-Pattern View of Sheet Metal Part \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView3 Method](#)

Availability

SOLIDWORKS 2007 SP5, Revision Number 15.5

FocusLocked Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : FocusLocked Property (IView)

Gets or sets whether or not focus is locked on this view.

.NET Syntax

Visual Basic (Declaration)

Property FocusLocked As System.Boolean

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

instance.FocusLocked = value

value = instance.FocusLocked
```

C#

```
System.bool FocusLocked {get; set;}
```

C++/CLI

```
property System.bool FocusLocked {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if focus is locked on the view, false if not

Visual Basic for Applications (VBA) Syntax

See [View::FocusLocked](#).

Example

[Insert Spline in Drawing \(C++\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[ISheet::FocusLocked Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAlignment Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetAlignment Method (IView)

Gets the alignment information of this view.

.NET Syntax

Visual Basic (Declaration)

Function GetAlignment() As System.Integer

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetAlignment()
```

C#

```
System.int GetAlignment()
```

C++/CLI

```
System.int GetAlignment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Alignment information as defined in [swViewAlignment_e](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetAlignment](#).

Remarks

The alignment information returned indicates if:

- This view is aligned with a parent view.
- There are child views that are aligned with this view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::AlignWithView Method](#)
[IView::RemoveAlignment Method](#)
[IView::UseDefaultAlignment Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotationCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetAnnotationCount Method (IView)

Gets the number of annotations in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetAnnotationCount()
```

C#

```
System.int GetAnnotationCount()
```

C++/CLI

```
System.int GetAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of annotations

Visual Basic for Applications (VBA) Syntax

See [View::GetAnnotationCount](#).

Remarks

Call this method before [IView::GetAnnotations](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetAnnotations Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotations Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetAnnotations Method (IView)

Gets the annotations in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetAnnotations()
```

C#

```
System.object GetAnnotations()
```

C++/CLI

```
System.Object^ GetAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [annotations](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetAnnotations](#).

Example

[Get Names of Annotations \(VBA\)](#)
[Get Names of Annotations \(C#\)](#)
[Get Names of Annotations \(VB.NET\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetAnnotationCount Method](#)
[IView::IGetAnnotations Method](#)
[IView::GetFirstAnnotation3 Method](#)
[IView::GetAnnotationsByType Method \(\)](#)

Availability

GetAnnotationsByType Method (IView)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetAnnotationsByType Method (IView)

Gets the annotations of the specified type in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotationsByType( _
    ByVal Type As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim Type As System.Integer
Dim value As System.Object

value = instance.GetAnnotationsByType(Type)
```

C#

```
System.object GetAnnotationsByType(
    System.int Type
)
```

C++/CLI

```
System.Object^ GetAnnotationsByType(
    & System.int Type
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Annotation type as defined by [swAnnotationType_e](#)

Return Value

Array of [annotations](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetAnnotationsByType](#).

See Also

[IView Interface](#)[IView Members](#)[IView::GetAnnotations Method \(\)](#)[IView::GetFirstAnnotation3 Method \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

GetArcCount Method (IView)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetArcCount Method (IView)

Gets the number of arcs in this view.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetArcCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetArcCount()
```

C#

```
System.int GetArcCount()
```

C++/CLI

```
System.int GetArcCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arcs

Visual Basic for Applications (VBA) Syntax

See [View::GetArcCount](#).

Example

[Get Polylines Information \(VBA\)](#)

Remarks

Call this method before [IView::GetArcs4](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetArcs4 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcs Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetArcs Method (IView)

Obsolete. Superseded by [IView::GetArcs4](#) and [IView::IGetArcs4](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetArcs() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetArcs()
```

C#

```
System.object GetArcs()
```

C++/CLI

```
System.Object^ GetArcs();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetArcs](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArcs2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetArcs2 Method (IView)

Obsolete. Superseded by [IView::GetArcs4](#) and [IView::IGetArcs4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcs2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetArcs2()
```

C#

```
System.object GetArcs2()
```

C++/CLI

```
System.Object^ GetArcs2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetArcs2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArcs3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetArcs3 Method (IView)

Obsolete. Superseded by [IView::GetArcs4](#) and [IView::IGetArcs4](#).

.NET Syntax

Visual Basic (Declaration)

Function GetArcs3() As System.Object

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetArcs3()
```

C#

```
System.object GetArcs3()
```

C++/CLI

```
System.Object^ GetArcs3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetArcs3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArcs4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetArcs4 Method (IView)

Gets all of the information for all of the arcs added by a user in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcs4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetArcs4()
```

C#

```
System.object GetArcs4()
```

C++/CLI

```
System.Object^ GetArcs4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [View::GetArcs4](#).

Remarks

This method only returns arcs that were sketched by a user in a drawing view. Use [IView::GetPolylines6](#) or [IView::IGetPolylines6](#) to access the solid model's projected display data in the drawing view.

Return value is an array of doubles with the format:

[*Color*, *LineType*, *LineStyleIndex*, *LineWidth*, *LayerID*, *LayerOverride*, *StartPt*[3], *EndPt*[3], *CenterPt*[3], *RotDir*, ...]

where:

- *Color* - COLORREF returned as an integer. Return value could be 0 or -1 for default color.
- *LineType* - Line type. Valid returns as defined in [swLineTypes_e](#). A *LineType* is a combination of a line style and line weight.
- *LineStyleIndex* - Line style. Valid line styles as defined in [swLineStyles_e](#) enumeration.
- *LineWidth* - Integer value defining the line width. Valid width values as defined in [swLineWeights_e](#).
- *LayerID* - Integer value indicating which layer holds this entity. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::IGetLayerById](#).
- *LayerOverride* - Integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, the color and style have been specifically set for this item and may not match the default values associated with this item's layer.
- *StartPt*[3] - An array of 3 doubles (X,Y,Z) describing the start point.
- *EndPt*[3] - An array of 3 doubles (X,Y,Z) describing the end point. If the arc is closed, then *EndPt*[3] is the same point as the StartPt.
- *CenterPt*[3] - An array of 3 doubles (X,Y,Z) describing the center point.
- *RotDir* - Rotational direction (CW = -1, CCW = 1)

...

This set of data repeats for each arc in the view. The size of the array is (NumArcs * 16). To determine the number of arcs, use [IView::GetArcCount](#).

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (for example, the 0,0 origin being the lower-left corner of the sheet), then you should combine this data with the three return values from [IView::GetXForm](#) or [IView::IGetXForm](#).

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetArcs4 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBaseView Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBaseView Method (IView)

Gets the base (parent) view used to create this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBaseView() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.Object

value = instance.GetBaseView()
```

C#

```
System.Object GetBaseView()
```

C++/CLI

```
System.Object^ GetBaseView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Base [view](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetBaseView](#).

Example

[Get Base Views \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetBaseView Method](#)
[IView::IGetNextView Method](#)
[IView::IGetNextView Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::IGetFirstView Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBendLineCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBendLineCount Method (IView)

Gets the number of bendlines in a [flat-pattern drawing view](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetBendLineCount()
```

C#

```
System.int GetBendLineCount()
```

C++/CLI

```
System.int GetBendLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bendlines in a flat-pattern drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetBendLineCount](#).

Example

[Get Tangent Edges of Bendlines \(VB.NET\)](#)
[Get Tangent Edges of Bendlines \(VBA\)](#)
[Get Tangent Edges of Bendlines \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBendLines Method](#)
[IView::IGetBendLines Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBendLines Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBendLines Method (IView)

Gets the bendlines in a [flat-pattern drawing view](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendLines() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetBendLines()
```

C#

```
System.object GetBendLines()
```

C++/CLI

```
System.Object^ GetBendLines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [bendlines](#) in the flat-pattern drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetBendLines](#).

Example

[Get Tangent Edges of Bendlines \(VB.NET\)](#)
[Get Tangent Edges of Bendlines \(VBA\)](#)
[Get Tangent Edges of Bendlines \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBendLineCount Method](#)
[IView::IGetBendLines Method](#)
[ISketchSegment::IsBendLine Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetBendNoteAttributeString Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBendNoteAttributeString Method (IView)

Gets the internal string that is used to format the text of the specified bend note attribute in this drawing view of a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendNoteAttributeString( _  
    ByVal Attribute As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Attribute As System.Integer  
Dim value As System.String  
  
value = instance.GetBendNoteAttributeString(Attribute)
```

C#

```
System.string GetBendNoteAttributeString(  
    System.int Attribute  
)
```

C++/CLI

```
System.String^ GetBendNoteAttributeString(  
& System.int Attribute  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Attribute

Bend note attribute as defined in [swBendNoteAttribute](#) e

Return Value

String that is used to format the bend note attribute

Visual Basic for Applications (VBA) Syntax

See [View::GetBendNoteAttributeString](#).

Remarks

Call this method to specify the Format parameter of [IView::SetBendNoteTextFormat](#).

See Also

[IView Interface](#)

[IView Members](#)

[IView::GetBendNoteTextFormat Method](#)

[IView::ShowSheetMetalBendNotes Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

GetBendNoteTextFormat Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBendNoteTextFormat Method (IView)

Gets the text format of all bend notes in this drawing view of a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendNoteTextFormat() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.GetBendNoteTextFormat()
```

C#

```
System.string GetBendNoteTextFormat()
```

C++/CLI

```
System.String^ GetBendNoteTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Format of all bend notes in this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetBendNoteTextFormat](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::SetBendNoteTextFormat Method](#)
[IView::GetBendNoteAttributeString Method](#)
[IView::ShowSheetMetalBendNotes Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBodiesCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBodiesCount Method (IView)

Gets the number of bodies of a multibody part in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetBodiesCount()
```

C#

```
System.int GetBodiesCount()
```

C++/CLI

```
System.int GetBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bodies of a multibody part in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetBodiesCount](#).

Example

[Set Body for View \(C#\)](#)
[Set Body for View \(VB.NET\)](#)
[Set Body for View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IBody2 Interface](#)
[IView::IGetBodies Method](#)
[IView::ISetBodies Method](#)
[IView::Bodies Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBomTable Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBomTable Method (IView)

Gets the BOM table found in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBomTable() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetBomTable()
```

C#

```
System.object GetBomTable()
```

C++/CLI

```
System.Object^ GetBomTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[BOM table](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetBomTable](#).

Remarks

This method only returns a BOM table if there is a Microsoft Excel-based BOM for the drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::InsertBomTable Method](#)
[IView::InsertBomTable2 Method](#)
[IView::IGetBomTable Method](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOMName Method](#)
[IView::InsertBomTable Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBreakLineCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBreakLineCount Method (IView)

Obsolete. Superseded by [IView::GetBreakLineCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBreakLineCount( _  
    ByRef Size As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Size As System.Integer  
Dim value As System.Integer  
  
value = instance.GetBreakLineCount(Size)
```

C#

```
System.int GetBreakLineCount(  
    out System.int Size  
)
```

C++/CLI

```
System.int GetBreakLineCount(  
& [Out] System.int Size  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size

Size of an array of doubles to allocate in call to [IView::GetBreakLineInfo](#) and [IView::IGetBreakLineInfo](#)

Return Value

Number of breaks

Visual Basic for Applications (VBA) Syntax

See [IView::GetBreakLineCount](#).

Remarks

This method indicates the number of break lines in the view; it does not indicate if the view is broken.

A drawing view can have break lines without the break being applied. To determine whether a view is broken, use [IView::IsBroken](#).

A break in a drawing view consists of a pair of lines. This method returns the number of breaks in the view, not the number of break lines. For example, this method returns 3 for a view that has three breaks in it, even though there are three pairs (or six lines) on the display.

Call this method before calling [IView::IGetBreakLines](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLines Method](#)
[IView::BreakLineGap Property](#)
[IView::InsertBreak Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBreakLineCount2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBreakLineCount2 Method (IView)

Gets the number of breaks lines and breaks in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBreakLineCount2( _  
    ByRef Size As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Size As System.Integer  
Dim value As System.Integer  
  
value = instance.GetBreakLineCount2(Size)
```

C#

```
System.int GetBreakLineCount2(  
    out System.int Size  
)
```

C++/CLI

```
System.int GetBreakLineCount2(  
& [Out] System.int Size  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size
Size of an array of doubles to allocate in [IView::GetBreakLineInfo2](#) and [IView::!GetBreakLineInfo2](#)

Return Value

Number of breaks

Visual Basic for Applications (VBA) Syntax

See [IView::GetBreakLineCount2](#).

Example

[Get Break Line Data \(VBA\)](#)
[Get Break Line Data \(VB.NET\)](#)
[Get Break Line Data \(C#\)](#)

Remarks

A drawing view can have break lines without the break being applied. To determine whether a view is broken, use [IView::IsBroken](#).

A break in a drawing view consists of a pair of lines. This method returns the number of breaks in the view. For example, this method returns 3 for a view that has three breaks in it, even though there are six lines on the display.

Call this method before calling [IView::IGetBreakLines](#) to determine the size of the array for that method.

 See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLines Method](#)
[IView::BreakLineGap Property](#)
[IView::InsertBreak Method](#)

 Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBreakLineInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBreakLineInfo Method (IView)

Obsolete. Superseded by [IView::GetBreakLineInfo2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function GetBreakLineInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetBreakLineInfo()
```

C#

```
System.object GetBreakLineInfo()
```

C++/CLI

```
System.Object^ GetBreakLineInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of break line information (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [View::GetBreakLineInfo](#).

 Remarks

The return value is the following array of doubles:

[*breaklineStyle*, [*color*, *lineType*, *lineStyleIndex*, *lineWeight*, *layerId*, *layerOverride*, *number of lines*, *number of arcs*], *line data or arc data*]

<i>breaklineStyle</i>	Valid returns are found in swBreakLineStyle_e
<i>color</i>	COLORREF returned as an integer. Return value could be 0 or -1 for default color
<i>lineType</i>	Valid returns are found in swLineTypes_e . A lineType is a combination of a lineStyle and lineWeight.
<i>LineStyleIndex</i>	Valid line styles can be found in swLineStyles_e .

<i>lineWeight</i>	An integer value defining the line width. Valid width values can be found in swLineWeights e.
<i>layerId</i>	An integer value indicating which layer holds this entity. The ILayer object can be obtained by passing this integer value to ILayerMgr::GetLayerById and ILayerMgr::GetLayerId .
<i>layerOverride</i>	An integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: • color = 0x1 • style = 0x2 • width = 0x4 Therefore, if LayerOverride is returned as 3, then the color and style were specifically set for this item and may not match the default values associated with this item's layer.
Number of lines	Number of pairs of lines in the break line.
Number of arcs	Number of pairs of arcs in the break line.

Each break line is a pair of line segments:

For...	Then...
swBreakLineStraight	Each has 1 line for a total of 4 points: • LineStartPt[3] • Line1EngPt[3] • Line2StartPt[3] • Line2EndPt[3]
swBreakLineZigZag	Each has 5 lines
swBreakLine_SmallZigZag	Each has 5 lines
swBreakLine_Curve	Each has 2 arcs; data is packed as follows: • arcDirection • startPoint • EndPoint • CenterPoint

 See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLineCount Method](#)
[IView::GetBreakLines Method](#)
[IView::IGetBreakLineInfo Method](#)
[IView::IGetBreakLines Method](#)
[IView::IsBroken Method](#)
[IView::BreakLineGap Property](#)
[IView::InsertBreak Method](#)

 Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

GetBreakLineInfo2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBreakLineInfo2 Method (IView)

Gets information for all of the break lines in this view.

 .NET Syntax

Visual Basic (Declaration)

Function GetBreakLineInfo2() As System.Object

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetBreakLineInfo2()
```

C#

```
System.object GetBreakLineInfo2()
```

C++/CLI

```
System.Object^ GetBreakLineInfo2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of data for all break lines in the view (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetBreakLineInfo2](#).

Example

[Get Break Line Data \(VBA\)](#)
[Get Break Line Data \(VB.NET\)](#)
[Get Break Line Data \(C#\)](#)

Remarks

The return value is a one-dimensional array consisting of the following data:

[breakLineStyle, color, lineType, lineStyleIndex, lineWeight, layerId, layerOverride, numLines, numArcs, numSplines, [break line data]]

where:

<i>breakLineStyle</i>	Break line style as defined in swBreakLineStyle_e
<i>color</i>	COLORREF returned as an integer; 0 or -1 for default color
<i>lineType</i>	Line type as defined in swLineTypes_e ; lineType is a combination of a lineStyle and lineWeight
<i>lineStyleIndex</i>	Line style as defined in swLineStyles_e
<i>lineWeight</i>	Line width as defined in swLineWeights_e
<i>layerId</i>	An integer value indicating which layer holds this entity; ILayer can be obtained by passing this integer value to ILayerMgr::GetLayerById and ILayerMgr::GetLayerId
<i>layerOverride</i>	An integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. Valid bit values as defined in swLayerOverride_e: • color = 0x1 • style = 0x2 • width = 0x4 Therefore, if LayerOverride is returned as 3, then the color and style are specifically set for this item; it may not match the default values associated with this item's layer.
<i>numLines</i>	Number of line segments if a straight or zig zag break
<i>numArcs</i>	Number of arc lines if a curve break
<i>numSplines</i>	Number of spline lines if a jagged break

If the break line style is `swBreakLineStyle_e...`

`swBreakLine_Straight`

`swBreakLine_ZigZag`

`swBreakLine_SmallZigZag`

`swBreakLine_Curve`

`swBreakLine_Jagged`

Then [*break line data*] is packed with...

12 doubles (2 lines * 1 segment * 2 points * 3 coordinates)

60 doubles (2 lines * 5 segments * 2 points * 3 coordinates)

60 doubles (2 lines * 5 segments * 2 points * 3 coordinates)

for each arc line in the break:

- . arc direction (1 double)
- . start point (3 doubles)
- . end point (3 doubles)
- . center point (3 doubles)

for each spline line in the break:

- . n (1 integer)
- . $3*n$ doubles (n points * 3 coordinates)

where:

n is the number of spline points generated based on the jagged cut shape intensity selected by the user in the Break View Property Manager

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetBreakLineInfo2 Method](#)
[IView::GetBreakLineCount2 Method](#)
[IView::GetBreakLines Method](#)
[IView::IGetBreakLines Method](#)
[IView::IsBroken Method](#)
[IView::BreakLineGap Property](#)
[IView::InsertBreak Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBreakLines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBreakLines Method (IView)

Gets the all of the breaks in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBreakLines() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetBreakLines()
```

C#

```
System.object GetBreakLines()
```

C++/CLI

```
System.Object^ GetBreakLines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Breaks](#) in this view

Visual Basic for Applications (VBA) Syntax

See [View::GetBreakLines](#).

Remarks

This method gets all of the breaks in the view, regardless if the view is broken. A drawing view can have break lines that are not applied. To determine whether a view is broken, use [View::IsBroken](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetBreakLines Method](#)
[IView::IGetBreakLineInfo Method](#)
[IView::GetBreakLineCount Method](#)
[IView::GetBreakLineInfo Method](#)
[IView::BreakLineGap Property](#)
[IView::InsertBreak Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBreakOutSectionCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBreakOutSectionCount Method (IView)

Gets the number of broken-out sections in this view.

NET Syntax

Visual Basic (Declaration)

```
Function GetBreakOutSectionCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetBreakOutSectionCount()
```

C#

```
System.int GetBreakOutSectionCount()
```

C++/CLI

```
System.int GetBreakOutSectionCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of broken-out sections

Visual Basic for Applications (VBA) Syntax

See [View::GetBreakOutSectionCount](#).

Example

[Get Broken-Out Section Feature Data \(VBA\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(C#\)](#)

Remarks

Call this method before calling [IView::GetBreakOutSections](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakOutSections Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBreakOutSections Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetBreakOutSections Method (IView)

Gets all of the broken-out sections in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBreakOutSections() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetBreakOutSections()
```

C#

```
System.object GetBreakOutSections()
```

C++/CLI

```
System.Object^ GetBreakOutSections();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of broken-out section [features](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetBreakOutSections](#).

Example

[Get Broken-Out Section Feature Data \(C#\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakOutSections Method](#)
[IView::GetBreakOutSectionCount Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

GetCenterLineCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCenterLineCount Method (IView)

Gets the number of centerlines on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetCenterLineCount()
```

C#

```
System.int GetCenterLineCount()
```

C++/CLI

```
System.int GetCenterLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of centerlines

Visual Basic for Applications (VBA) Syntax

See [View::GetCenterLineCount](#).

Remarks

Call this method before calling [IView::IGetCenterLines](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterLines Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

GetCenterLines Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCenterLines Method (IView)

Gets all of the centerline annotations on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterLines() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetCenterLines()
```

C#

```
System.object GetCenterLines()
```

C++/CLI

```
System.Object^ GetCenterLines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [centerlines](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetCenterLines](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

Use this method to obtain the array of centerlines all at once instead of calling [IView::GetFirstCenterLine](#) and then repeatedly calling [ICenterLine::GetNext](#) to obtain the remaining centerlines in the drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterLineCount Method](#)
[IView::IGetCenterLines Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCenterLineSketch Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCenterLineSketch Method (IView)

Gets the sketch that contains all of the centerline information for this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterLineSketch() As Sketch
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As Sketch  
  
value = instance.GetCenterLineSketch()
```

C#

```
Sketch GetCenterLineSketch()
```

C++/CLI

```
Sketch^ GetCenterLineSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetCenterLineSketch](#).

Remarks

All of the centerlines for a drawing view are stored on a sketch. This method returns that sketch. You can get information about the sketch entities, including the centerlines, in the sketch.

This method allows you to access properties of individual centerlines. DXF translation may use this method to get the centerline information in a SOLIDWORKS drawing.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetFirstCenterLine Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCenterMarkCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCenterMarkCount Method (IView)

Obsolete. Superseded by [IView::GetCenterMarkCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterMarkCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetCenterMarkCount()
```

C#

```
System.int GetCenterMarkCount()
```

C++/CLI

```
System.int GetCenterMarkCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetCenterMarkCount](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCenterMarkCount2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCenterMarkCount2 Method (IView)

Gets the number of center marks that are features in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterMarkCount2( _  
    ByRef Size As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Size As System.Integer  
Dim value As System.Integer  
  
value = instance.GetCenterMarkCount2(Size)
```

C#

```
System.int GetCenterMarkCount2(  
    out System.int Size  
)
```

C++/CLI

```
System.int GetCenterMarkCount2(  
& [Out] System.int Size  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size
Not used

Return Value

Number of center marks in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetCenterMarkCount2](#).

Remarks

Center marks are now annotations. Previously, center marks were features. This method is only valid for center marks that are features.

One difference between this method and the now obsolete [IView::GetCenterMarkCount](#) is that this method also works if this view represents the drawing sheet. The original method always returns 0 if this view is the drawing sheet.

Call this method before calling [IView::IGetCenterMarks](#) to get the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterMarkInfo Method](#)
[IView::GetCenterMarks Method](#)
[IView::IGetCenterMarkInfo Method](#)
[IView::IGetCenterMarks Method](#)
[IView::GetFirstCenterMark Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCenterMarkInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCenterMarkInfo Method (IView)

Gets information about each center mark that is a feature in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterMarkInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetCenterMarkInfo()
```

C#

```
System.Object GetCenterMarkInfo()
```

C++/CLI

```
System.Object^ GetCenterMarkInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [IView::GetCenterMarkInfo](#).

Remarks

Center marks are now annotations. Previously, center marks were features. This method is only valid for center marks that are features.

The return value is the following array of doubles:

$$\left[\text{numCenterMarks}, \left[\text{numCenterMarkLines}, \text{lineType1}, \text{plus1StartPt}\{3\}, \text{plus1EndPt}\{3\}, \text{lineType2}, \text{plus2StartPt}\{3\}, \text{plus2EndPt}\{3\}, \left[\text{lineType}, \text{lineStartPt}\{3\}, \text{lineEndPt}\{3\} \right] \right] \right]$$

where:

numCenterMarks = is the number of center marks in this view. See also [IView::GetCenterMarkCount2](#).

The following set of data repeats itself for each center mark in the view. The number of times the information is given is *numCenterMarks*:

numCenterMarkLines = number of centermark lines in the current center mark. Every center mark has at least two lines. These two lines represent the plus at the center of the circle.

lineType1 = line type associated with the first plus-sign line. See the [swLineTypes_e](#) enumeration.

plus1StartPt{3} = X,Y,Z start point of the first line in the plus sign.

plus1EndPt{3} = X,Y,Z end point of the first line in the plus sign.

lineType2 = line type associated with the second plus-sign line. See the [swLineTypes_e](#) enumeration.

plus2StartPt{3} = X,Y,Z start point of the second line in the plus sign.

plus2EndPt{3} = X,Y,Z end point of the second line in the plus sign.

This set of data also repeats itself for the remaining centermark lines in this particular center mark. The number of times this information is given is (*numCenterMarkLines* - 2):

LineType = line type associated with the second plus-sign line. See the [swLineTypes_e](#) enumeration.

lineStartPt[3] = X,Y,Z start point for this centermark line.

lineEndPt[3] = X,Y,Z end point for this centermark line.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterMarks Method](#)
[IView::GetFirstCenterMark Method](#)
[IView::IGetCenterMarkInfo Method](#)
[IView::IGetCenterMarks Method](#)
[ICenterMark Interface](#)
[IView::AutoInsertCenterMarks Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCenterMarks Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCenterMarks Method (IView)

Gets all of the center marks that are features in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterMarks() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object
```

```
value = instance.GetCenterMarks()
```

C#

```
System.Object GetCenterMarks()
```

C++/CLI

```
System.Object^ GetCenterMarks();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Centermarks](#) that are features in this view

Visual Basic for Applications (VBA) Syntax

See [View::GetCenterMarks](#).

Example

[List Center Marks in Drawing \(VBA\)](#)

Remarks

Center marks are now annotations. Previously, center marks were features. This method returns an empty array for center marks that are annotations; thus, this method is only valid for center marks that are features. See [ICenterMark](#) for details.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterMarkCount2 Method](#)
[IView::GetCenterMarkInfo Method](#)

[IView::GetFirstCenterMark Method](#)
[IView::IGetCenterMarkInfo Method](#)
[IView::IGetCenterMarks Method](#)
[ICenterMark Interface](#)
[IView::AutoinsertCenterMarks Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCorresponding Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCorresponding Method (IView)

Gets the object in this drawing view that corresponds to the specified part or assembly object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCorresponding( _  
    ByVal InputObject As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim InputObject As System.Object  
Dim value As System.Object  
  
value = instance.GetCorresponding(InputObject)
```

C#

```
System.object GetCorresponding(  
    System.object InputObject  
)
```

C++/CLI

```
System.Object^ GetCorresponding(  
& System.Object^ InputObject  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InputObject

Pointer to the Dispatch object in a part or assembly (see **Remarks**)

Return Value

Pointer to the corresponding object in this drawing view; null or Nothing if none found

Visual Basic for Applications (VBA) Syntax

See [View::GetCorresponding](#).

Example

[Get Corresponding Entities Between Parts and Drawing Views \(VBA\)](#)
[Get Corresponding Entities Between Parts and Drawing Views \(VB.NET\)](#)
[Get Corresponding Entities Between Parts and Drawing Views \(C#\)](#)

Remarks

InputObject can be any object assigned a persistent reference or object ID; for example, [IAnnotation](#), [IFeature](#), [ISketch](#), [ISketchSegment](#), etc.

Annotation objects will be found only if they were previously imported into this drawing view.

Use [IModelDocExtension::GetCorresponding2](#) to get the part or assembly object that corresponds to an object in a drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCorrespondingEntity Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCorrespondingEntity Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCorrespondingEntity Method (IView)

Gets the entity in this drawing view that corresponds to the specified part or assembly entity.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCorrespondingEntity( _  
    ByVal Entity As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Entity As System.Object  
Dim value As System.Object  
  
value = instance.GetCorrespondingEntity(Entity)
```

C#

```
System.object GetCorrespondingEntity(  
    System.object Entity  
)
```

C++/CLI

```
System.Object^ GetCorrespondingEntity(  
& System.Object^ Entity  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entity
Dispatch pointer to a [vertex](#), [face](#), or [edge](#) entity in the part or assembly

Return Value

Corresponding [entity](#) in this drawing view; null or Nothing if none found

Visual Basic for Applications (VBA) Syntax

See [View::GetCorrespondingEntity](#).

Example

[Get Corresponding Entities Between Parts and Drawing Views \(VBA\)](#)
[Get Corresponding Entities Between Parts and Drawing Views \(VB.NET\)](#)
[Get Corresponding Entities Between Parts and Drawing Views \(C#\)](#)

Remarks

Use [IModelDocExtension::GetCorrespondingEntity2](#) to get the part entity that corresponds to a drawing view entity.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCorresponding Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCThreadCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCThreadCount Method (IView)

Gets the number of cosmetic threads in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCThreadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetCThreadCount()
```

C#

```
System.int GetCThreadCount()
```

C++/CLI

```
System.int GetCThreadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of cosmetic threads

Visual Basic for Applications (VBA) Syntax

See [IView::GetCThreadCount](#).

Remarks

Call this method before calling [IView::IGetCThreads](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCThreads Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCThreadQuality Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCThreadQuality Method (IView)

Gets the cosmetic thread display quality in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCThreadQuality() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
value = instance.GetCThreadQuality()
```

C#

```
System.bool GetCThreadQuality()
```

C++/CLI

```
System.bool GetCThreadQuality();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if precision quality, false if draft quality

Visual Basic for Applications (VBA) Syntax

See [View::GetCThreadQuality](#).

Example

See the [IView::SetDisplayMode4](#) examples.

See Also

[IView Interface](#)
[IView Members](#)
[IView::SetDisplayMode4 Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCThreads Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetCThreads Method (IView)

Gets all of the cosmetic threads on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCThreads() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetCThreads()
```

C#

```
System.object GetCThreads()
```

C++/CLI

```
System.Object^ GetCThreads();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [cosmetic threads](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetCThreads](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

Use this method to obtain the array of cosmetic threads all at once instead of calling [IView::GetFirstCThread](#) and then repeatedly calling [ICThread::GetNext](#) to obtain the remaining cosmetic threads on the drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCThreadCount Method](#)
[IView::ICThread::GetNext Method](#)
[IModelDocExtension::HasLegacyCThreads Method\(\)](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumOriginCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumOriginCount Method (IView)

Gets the number of datum origins on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumOriginCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDatumOriginCount()
```

C#

```
System.int GetDatumOriginCount()
```

C++/CLI

```
System.int GetDatumOriginCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of datum origins

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumOriginCount](#).

Remarks

Call this method before calling [IView::IGetDatumOrigins](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumOrigins Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumOrigins Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumOrigins Method (IView)

Gets all of the datum origins on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumOrigins() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDatumOrigins()
```

C#

```
System.Object GetDatumOrigins()
```

C++/CLI

```
System.Object^ GetDatumOrigins();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [datum origins](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumOrigins](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

Use this method to obtain the array of datum origins all at once instead of calling [IView::GetFirstDatumOrigin](#) and then repeatedly calling [IDatumOrigin::GetNext](#) to obtain the remaining datum origins on this drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumOriginCount Method](#)
[IView::IGetDatumOrigins Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumPoints Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumPoints Method (IView)

Obsolete. Superseded by [IView::GetDatumPoints2](#) and [IView::IGetDatumPoints2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object
```

```
value = instance.GetDatumPoints()
```

C#

```
System.object GetDatumPoints()
```

C++/CLI

```
System.Object^ GetDatumPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumPoints](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumPoints2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumPoints2 Method (IView)

Gets all of the information about all the datum points in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumPoints2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object
```

```
value = instance.GetDatumPoints2()
```

C#

```
System.Object GetDatumPoints2()
```

C++/CLI

```
System.Object^ GetDatumPoints2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumPoints2](#).

Remarks

Return value is an array of doubles with the format:

[*Color*, *LineStyleIndex*, *LineWidth*, *LayerID*, *LayerOverride*, *ptLoc*[3] ...]

Color = COLORREF returned as an integer. Return value can be 0 or -1 for default color.

LineStyleIndex = line style. Valid line styles as defined in [swLineStyles e](#).

LineWidth = integer value defining the line width. Valid width values as defined in [swLineWeights e](#).

LayerID = integer value indicating which layer holds this entity. This integer value is the array index value into the layerList array. The layerList array can be obtained using [ILayerMgr::GetLayerList](#) or [ILayerMgr::IGetLayerList](#). A value of 1 indicates that this item is not on a layer.

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the [ILayer](#) default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style : 0x2, and width = 0x4. Therefore, if *LayerOverride* is returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

ptLoc[3] = array of 3 doubles (X,Y,Z) describing the point location

...

This entire set of data repeats for each datum point in the view. The size of the array is (NumPts * 8). To determine the number of points, use [IView::GetDatumPointsCount](#).

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (for example, the 0,0 origin being the lower-left corner of the sheet), then combine this data with the three return values from [IView::GetXForm](#) or [IView::IGetXForm](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetDatumPoints2 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumPointsCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumPointsCount Method (IView)

Gets the number of datum points in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumPointsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDatumPointsCount()
```

C#

```
System.int GetDatumPointsCount()
```

C++/CLI

```
System.int GetDatumPointsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of datum points

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumPointsCount](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumTagCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumTagCount Method (IView)

Gets the number of datum tags on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumTagCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDatumTagCount()
```

C#

```
System.int GetDatumTagCount()
```

C++/CLI

```
System.int GetDatumTagCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of datum tags

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumTagCount](#).

Example

[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Call this method before calling [IView::IGetDatumTags](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetDatumTags Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumTags Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumTags Method (IView)

Gets all of the datum tags on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumTags() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDatumTags()
```

C#

```
System.object GetDatumTags()
```

C++/CLI

```
System.Object^ GetDatumTags();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [datum tags](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumTags](#).

Example

[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Use this method to obtain the array of datum tags all at once instead of calling [IView::GetFirstDatumTag](#) and then repeatedly calling [IDatumTag::GetNext](#) to obtain the remaining datum tags on this drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumTagCount Method](#)
[IView::IGetDatumTags Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumTargetSymCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumTargetSymCount Method (IView)

Gets the number of datum target symbols on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumTargetSymCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDatumTargetSymCount()
```

C#

```
System.int GetDatumTargetSymCount()
```

C++/CLI

```
System.int GetDatumTargetSymCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of datum target symbols

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumTargetSymCount](#).

Example

[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Call this method before calling [IView::IGetDatumTargetSyms](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumTargetSyms Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

GetDatumTargetSyms Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDatumTargetSyms Method (IView)

Gets all of the datum target symbols on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumTargetSyms() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDatumTargetSyms()
```

C#

```
System.Object GetDatumTargetSyms()
```

C++/CLI

```
System.Object^ GetDatumTargetSyms();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [datum target symbols](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDatumTargetSyms](#).

Example

[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Use this method to obtain the array of datum target symbols all at once instead of calling [IView::GetFirstDatumTargetSym](#) and then repeatedly calling [IDatumTargetSym::GetNext](#) to obtain the remaining datum target symbols on this drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumTargetSymCount Method](#)
[IView::IGetDatumTargetSyms Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

GetDependentViewCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDependentViewCount Method (IView)

Gets the number of all, or only the specified, dependent views (i.e., alternate position, detail, section, etc.) in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDependentViewCount( _  
    ByVal AllViews As System.Boolean, _  
    ByVal SpecificViewType As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim AllViews As System.Boolean  
Dim SpecificViewType As System.Integer  
Dim value As System.Integer  
  
value = instance.GetDependentViewCount(AllViews, SpecificViewType)
```

C#

```
System.int GetDependentViewCount(  
    System.bool AllViews,  
    System.int SpecificViewType  
)
```

C++/CLI

```
System.int GetDependentViewCount(  
& System.bool AllViews,  
& System.int SpecificViewType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AllViews

True to get the number of all of the dependent views in this view, false to get the number of *SpecificViewType* views in this view

SpecificViewType

Type of dependent view as defined in [swDrawingViewTypes_e](#)

Return Value

Number of dependent views

Visual Basic for Applications (VBA) Syntax

See [View::GetDependentViewCount](#).

Remarks

Call this method before calling [IView::IGetDependentViews](#) to get the size of the array for that method.

See Also

[IView Interface](#)

[IView Members](#)

[IView::GetDependentViews Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDependentViews Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDependentViews Method (IView)

Gets either all, or only the specified, dependent views in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDependentViews( _  
    ByVal AllViews As System.Boolean, _  
    ByVal SpecificViewType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim AllViews As System.Boolean  
Dim SpecificViewType As System.Integer  
Dim value As System.Object  
  
value = instance.GetDependentViews(AllViews, SpecificViewType)
```

C#

```
System.Object GetDependentViews(  
    System.bool AllViews,  
    System.int SpecificViewType  
)
```

C++/CLI

```
System.Object^ GetDependentViews(  
& System.bool AllViews,  
& System.int SpecificViewType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AllViews

True to get all of the dependent views in this view, false to get only the SpecificViewType views in this view

SpecificViewType

Type of dependent view as defined in [swDrawingViewTypes_e](#)

Return Value

Array of dependent [views](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDependentViews](#).

See Also

[IView Interface](#)

[IView Members](#)

[IView::GetDependentViewCount Method](#)

[IView::IGetDependentViews Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDesignTableExtent Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDesignTableExtent Method (IView)

Gets the size and location of the design table associated with this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDesignTableExtent() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDesignTableExtent()
```

C#

```
System.object GetDesignTableExtent()
```

C++/CLI

```
System.Object^ GetDesignTableExtent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 6 doubles; the lower left (x,y,z) and upper right (x,y,z) values indicating the design table extents; values are in meters and refer to drawing view space

Visual Basic for Applications (VBA) Syntax

See [View::GetDesignTableExtent](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::HasDesignTable Method](#)
[IView::IGetDesignTableExtent Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDetail Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDetail Method (IView)

Gets the detail circle for this detail view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDetail() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDetail()
```

C#

```
System.object GetDetail()
```

C++/CLI

```
System.Object^ GetDetail();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Detail circle](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDetail](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDetailCircleCount2 Method](#)
[IView::GetDetailCircleInfo2 Method](#)
[IView::GetDetailCircles Method](#)
[IView::GetDetailCircleStrings Method](#)
[IView::IGetDetail Method](#)
[IView::IGetDetailCircleInfo2 Method](#)
[IView::IGetDetailCircles Method](#)
[IView::IGetDetailCircleStrings Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDetailCircleCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDetailCircleCount Method (IView)

Obsolete. Superseded by [IView::GetDetailCircleCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDetailCircleCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDetailCircleCount()
```

C#

```
System.int GetDetailCircleCount()
```

C++/CLI

```
System.int GetDetailCircleCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDetailCircleCount](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDetailCircleCount2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDetailCircleCount2 Method (IView)

Gets the number of detail circles in the drawing view.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetDetailCircleCount2( _  
    ByRef Size As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Size As System.Integer  
Dim value As System.Integer  
  
value = instance.GetDetailCircleCount2(Size)
```

C#

```
System.int GetDetailCircleCount2(  
    out System.int Size  
)
```

C++/CLI

```
System.int GetDetailCircleCount2(  
& [Out] System.int Size  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size
Size, which includes a double for each detail circle; this new double contains the layer ID for the detail circle

Return Value

Number of detail circles in the drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetDetailCircleCount2](#).

Example

[Get Detail Circle Information \(VBA\)](#)

Remarks

Call this method before calling [View::GetDetailCircles](#) to get the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetDetail Method](#)
[IView::IGetDetailCircleInfo2 Method](#)
[IView::IGetDetailCircleStrings Method](#)
[IView::GetDetail Method](#)
[IView::GetDetailCircleInfo2 Method](#)
[IView::GetDetailCircleStrings Method](#)
[IView::GetDetailCircles Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDetailCircleInfo Method (IView)

[See Also](#)



Obsolete. Superseded by [IView::GetDetailCircleInfo2](#) and [IView::IGetDetailCircleInfo2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDetailCircleInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDetailCircleInfo()
```

C#

```
System.object GetDetailCircleInfo()
```

C++/CLI

```
System.Object^ GetDetailCircleInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDetailCircleInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

GetDetailCircleInfo2 Method (IView)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > [IView Interface](#) : GetDetailCircleInfo2 Method (IView)

Gets all of the information about each detail circle in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDetailCircleInfo2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDetailCircleInfo2()
```

C#

```
System.object GetDetailCircleInfo2()
```

C++/CLI

```
System.Object^ GetDetailCircleInfo2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetDetailCircleInfo2](#).

Example

[Get Detail Circle Information \(VBA\)](#)

Remarks

The return value is the following array of doubles:

```
[ numDetailCircles, [ layer, centerPt[3], startPt[3], endPt[3], lineType, textPt[3], textHeight, numArrows, [ arrowTip[3], arrowComponent[3], arrowWidth, arrowHeight, arrowStyle ] ] ]
```

where:

numDetailCircles = the number of detail circles in this view. See also [View::GetDetailCircleCount2](#).

The following set of data repeats itself for each detail circle in the view. The number of times the following information is given is *numDetailCircles*:

layer = integer value indicating which layer holds this entity. Obtain the [ILayer](#) object by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::GetLayerById](#).

centerPt[3] = X,Y,Z center point for this detail circle

startPt[3] = X,Y,Z start point for this detail circle

endPt[3] = X,Y,Z end point for this detail circle

lineType = line type for this detail circle as defined in [swLineTypes_e](#)

textPt[3] = X,Y,Z point for the text location.

textHeight = text height in meters

numArrows = number of arrows for this detail circle.

The following set of data repeats itself for each arrow in the current detail circle. The number of times the following information is given is *numArrows*:

arrowTip[3] = X,Y,Z start point for this arrow head

arrowComponent[3] = X,Y,Z component for this arrow head

arrowWidth = width of this arrow head

arrowHeight = height of this arrow head

arrowStyle = style of this arrow head as defined in [swArrowStyle_e](#)

To get the actual text value, see [View::GetDetailCircleStrings](#) or [IView::GetDetailCircleStrings](#).

The number of line segments, line segment geometry, and line type returned depend on the drawing's display standard.

See Also

[IView Interface](#)
[IView Members](#)
[View::GetDetail Method](#)
[View::GetDetailCircles Method](#)
[View::GetDetail Method](#)
[View::GetDetailCircleInfo2 Method](#)
[View::GetDetailCircles Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDetailCircles Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDetailCircles Method (IView)

Gets the detail circles in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDetailCircles() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDetailCircles()
```

C#

```
System.object GetDetailCircles()
```

C++/CLI

```
System.Object^ GetDetailCircles();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Detail circles](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDetailCircles](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDetail Method](#)
[IView::GetDetailCircleCount2 Method](#)
[IView::GetDetailCircleInfo2 Method](#)
[IView::GetDetailCircleStrings Method](#)
[IView::IGetDetail Method](#)
[IView::IGetDetailCircleInfo2 Method](#)
[IView::IGetDetailCircles Method](#)
[IView::IGetDetailCircleStrings Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0