

SOLIDWORKS API (.NET VBA C#) — Reference (323/337): View (part 3 of 10)

SOLIDWORKS API Documentation (converted from CHM)

IView (part 3 of 10) (Type)

GetDetailCircleStrings Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDetailCircleStrings Method (IView)

Gets an array of strings; each string represents the text label for a detail circle in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDetailCircleStrings() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDetailCircleStrings()
```

C#

```
System.object GetDetailCircleStrings()
```

C++/CLI

```
System.Object^ GetDetailCircleStrings();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings with one string for each detail circle in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetDetailCircleStrings](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDetail Method](#)
[IView::GetDetailCircleCount2 Method](#)
[IView::GetDetailCircleInfo2 Method](#)
[IView::GetDetailCircles Method](#)
[IView::IGetDetail Method](#)
[IView::IGetDetailCircleInfo2 Method](#)
[IView::IGetDetailCircles Method](#)
[IView::IGetDetailCircleStrings Method](#)

GetDimensionCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionCount Method (IView)

Obsolete. Superseded by [IView::GetDimensionCount4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDimensionCount()
```

C#

```
System.int GetDimensionCount()
```

C++/CLI

```
System.int GetDimensionCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionCount](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionCount2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionCount2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionCount4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionCount2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDimensionCount2()
```

C#

```
System.int GetDimensionCount2()
```

C++/CLI

```
System.int GetDimensionCount2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionCount2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionCount3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionCount3 Method (IView)

Obsolete. Superseded by [IView::GetDimensionCount4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionCount3() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetDimensionCount3()
```

C#

```
System.int GetDimensionCount3()
```

C++/CLI

```
System.int GetDimensionCount3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionCount3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionCount4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionCount4 Method (IView)

Gets the number of display dimensions in the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionCount4() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetDimensionCount4()
```

C#

```
System.int GetDimensionCount4()
```

C++/CLI

```
System.int GetDimensionCount4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of dimensions

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionCount4](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionDisplayInfo5 Method](#)
[IView::GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::GetFirstDisplayDimension5 Method](#)
[IView::IGetDimensionDisplayInfo5 Method](#)
[IView::IGetDimensionDisplayString4 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::IGetDimensionString4 Method](#)
[IView::ProjectedDimensions Property](#)
[IView::GetFirstDisplayDimension5 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionDisplayInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayInfo Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayInfo5](#) and [IView::IGetDimensionDisplayInfo5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionDisplayInfo()
```

C#

```
System.object GetDimensionDisplayInfo()
```

C++/CLI

```
System.Object^ GetDimensionDisplayInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionDisplayInfo2 Method (IView)

[See Also](#)



Obsolete. Superseded by [IView::GetDimensionDisplayInfo5](#) and [IView::IGetDimensionDisplayInfo5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayInfo2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionDisplayInfo2()
```

C#

```
System.object GetDimensionDisplayInfo2()
```

C++/CLI

```
System.Object^ GetDimensionDisplayInfo2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayInfo2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionDisplayInfo3 Method (IView)

[See Also](#)



Obsolete. Superseded by [IView::GetDimensionDisplayInfo5](#) and [IView::IGetDimensionDisplayInfo5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayInfo3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionDisplayInfo3()
```

C#

```
System.object GetDimensionDisplayInfo3()
```

C++/CLI

```
System.Object^ GetDimensionDisplayInfo3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayInfo3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionDisplayInfo4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayInfo4 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayInfo5](#) and [IView::IGetDimensionDisplayInfo5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayInfo4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionDisplayInfo4()
```

C#

```
System.object GetDimensionDisplayInfo4()
```

C++/CLI

```
System.Object^ GetDimensionDisplayInfo4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayInfo4](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionDisplayInfo5 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayInfo5 Method (IView)

Gets the display dimension information for the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayInfo5() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionDisplayInfo5()
```

C#

System.Object GetDimensionDisplayInfo5()

C++/CLI

System.Object^ GetDimensionDisplayInfo5();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayInfo5](#).

Remarks

The data returned is an array of doubles as follows:

dimensionCount, [*lineCount*, [*lineSegmentCount* [*StartPt*[3], *endPt*[3]]], *arcCount*, [*arcSegmentCount*, [*arcCenter*[3], [*StartPt*[3], *EndPt*[3]]], *arrowCount*, [*arrowTipPt*[3], *arrowVector*[3], *arrowWidth*, *arrowHeight*], *tolType*, *isDual*, *showParens*, *textAngle*, *value1Pos*[3], *tolmax1Pos*[3], *tolmin1Pos*[3], *value2Pos*[3], *tolmax2Pos*[3], *tolmin2Pos*[3], *prefixPos*[3], *suffixPos*[3], *tolbox1Corner1*[3], *tolbox1Corner2*[3], *tolbox2Corner1*[3], *tolbox2Corner2*[3], *parenArc1Start*[3], *parenArc1End*[3], *parenArc1Center*[3], *parenArc1Vector*[3], *parenArc2Start*[3], *parenArc2End*[3], *parenArc2Center*[3], *parenArc2Vector*[3], *callout1TextPos*[3], *callout2TextPos*[3]]

where:

dimensionCount = number of dimensions found in the drawing sheet or drawing view

For each dimension:

lineCount = number of extension and leader lines for this dimension

For each line:

StartPt[3] = array of three doubles representing the line start point

EndPt[3] = array of three doubles representing the line end point

Repeating the *StartPt*[3] and *EndPt*[3] pair up to *lineSegmentCount*

arcCount = number of leader lines which are arcs for this dimension

For each arc:

arcCenter[3] = array of three doubles representing the arc center point

StartPt[3] = array of three doubles representing the arc start point

EndPt[3] = array of three doubles representing the arc end point

Repeating the *arcCenter*[3], *StartPt*[3], and *EndPt*[3] group up to *arcSegmentCount*

arrowCount = number of arrowheads for this dimension

arrowTipPt[3] = array of three doubles representing the arrowhead tip location

arrowVector[3] = array of three doubles representing the arrow direction

arrowWidth = arrowhead width

arrowHeight = arrowhead height

Repeating the *arrowTipPt*[3], *arrowVector*[3], *arrowWidth* and *arrowHeight* group up to *arrowCount* arrowheads

tolType = tolerance type as defined in [swTolType_e](#)

isDual = True if this dimension is a dual dimension, false otherwise

showParens = True if parenthesis are shown, false otherwise

The next 25 values represent text angle and positioning. All text positions are the upper-left corner of the string.

textAngle = text angle in radians (counter clockwise from +ve x-axis)

value1Pos[3] = XYZ position of text 1; the position is the upper-left corner of the actual string
tolmax1Pos[3] = XYZ position of maximum tolerance text 1
tolmin1Pos[3] = XYZ position of minimum tolerance text 1
value2Pos[3] = XYZ position of text 2; data returned is only valid if *isDual* is true
tolmax2Pos[3] = XYZ position of maximum tolerance text 2; data returned is valid when *isDual* is true
tolmin2Pos[3] = XYZ position of minimum tolerance text 2; data returned is valid when *isDual* is true
prefixPos[3] = XYZ position of prefix text
suffixPos[3] = XYZ position of suffix text

The next 12 values represent the box corners for dimensions with swToIBASIC tolerance types:

tolbox1Corner1[3] = XYZ corner 1 of tolerance box 1
tolbox1Corner2[3] = XYZ corner 2 of tolerance box 1
tolbox2Corner1[3] = XYZ corner 1 of tolerance box 2; data returned is valid when *isDual* is true
tolbox2Corner2[3] = XYZ corner 2 of tolerance box 2; data returned is valid when *isDual* is true

The next 24 values are valid when *showParens* is True; for example, when this is a reference dimension.

parenArc1Start[3] = XYZ start point of the arc representing parenthesis 1
parenArc1End[3] = XYZ end point of the arc representing parenthesis 1
parenArc1Center[3] = XYZ center point of the arc representing parenthesis 1
parenArc1Vector[3] = XYZ reference direction for the arc representing parenthesis 1
parenArc2Start[3] = XYZ start point of the arc representing parenthesis 2
parenArc2End[3] = XYZ end point of the arc representing parenthesis 2
parenArc2Center[3] = XYZ center point of the arc representing parenthesis 2
parenArc2Vector[3] = XYZ reference direction for the arc representing parenthesis 2

callout1TextPos[3] = XYZ position of first callout text (text above)
callout2TextPos[3] = XYZ position of second callout text (text below)

Repeating the entire *lineCount* *callout2TextPos* group up to *dimensionCount* dimensions

For example, if a particular sheet or view had two dimensions, and the first dimension had three lines, zero arcs, and two arrows, and the second dimension had two lines, one arc, and two arrows, then array returned would be as follows:

[2, **3**, line1StartPtx, y, z, line1EndPtx, y, z, line2StartPtx, y, z, line2EndPtx, y, z, line3StartPtx, y, z, line3EndPtx, y, z, **0**, **2**,
 arrow1TipPtx, y, z, arrow1Vectorx, y, z, arrow1Width, arrow1Height, arrow2TipPtx, y, z, arrow2Vectorx, y, z, arrow2Width,
 arrow2Height, tolType, isDual, showParens, textAngle, value1Posx, y, z, tolmax1Posx, y, z, tolmin1Posx, y, z, value2Posx, y, z,
 tolmax2Posx, y, z, tolmin2Posx, y, z, prefixPosx, y, z, suffixPosx, y, z, tolbox1Corner1x, y, z, tolbox1Corner2x, y, z, tolbox2Corner1x
 y, z, tolbox2Corner2x, y, z, parenArc1Startx, y, z, parenArc1Endx, y, z, parenArc1Centerx, y, z, parenArc1Vectorx, y, z,
 parenArc2Startx, y, z, parenArc2Endx, y, z, parenArc2Centerx, y, z, parenArc2Vectorx, y, z, callout1TextPosx, y, z, callout2TextPosx
 y, z, 2, line1StartPtx, y, z, line1EndPtx, y, z, line2StartPtx, y, z, line2EndPtx, y, z, 1, arc1Vertexx, y, z, arc1StartPtx, y, z,
 arc1EndPtx, y, z, 2, arrow1TipPtx, y, z, arrow1Vectorx, y, z, arrow1Width, arrow1Height, arrow2TipPtx, y, z, arrow2Vectorx, y, z,
arrow2Width, arrow2Height, tolType, isDual, showParens, textAngle, value1Posx, y, z, tolmax1Posx, y, z, tolmin1Posx, y, z,
value2Posx, y, z, tolmax2Posx, y, z, tolmin2Posx, y, z, prefixPosx, y, z, suffixPosx, y, z, tolbox1Corner1x, y, z, tolbox1Corner2x, y, z,
tolbox2Corner1x, y, z, tolbox2Corner2x, y, z, parenArc1Startx, y, z, parenArc1Endx, y, z, parenArc1Centerx, y, z, parenArc1Vectorx
y, z, parenArc2Startx, y, z, parenArc2Endx, y, z, parenArc2Centerx, y, z, parenArc2Vectorx, y, z, callout1TextPosx, y, z,
callout2TextPosx, y, z]

where the **3**, **0**, **2** and **2**, **1**, **2** represent the number of lines, arcs and arrows for each of the two dimensions. The information for the second dimension is underlined to distinguish it from information returned for the first dimension.

This method does not support [hole callouts](#).

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionCount4 Method](#)
[IView::GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::GetFirstDisplayDimension5 Method](#)
[IView::IGetDimensionDisplayInfo5 Method](#)
[IView::IGetDimensionDisplayString4 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::IGetDimensionString4 Method](#)
[IView::ProjectedDimensions Property](#)
[IView::GetFirstDisplayDimension5 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionDisplayInfoSize Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayInfoSize Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayInfoSize2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayInfoSize() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDimensionDisplayInfoSize()
```

C#

```
System.int GetDimensionDisplayInfoSize()
```

C++/CLI

```
System.int GetDimensionDisplayInfoSize();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayInfoSize](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionDisplayInfoSize2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayInfoSize2 Method (IView)

Gets the number of the dimension lines in the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayInfoSize2() As System.Integer
```

```
Dim instance As IView
Dim value As System.Integer

value = instance.GetDimensionDisplayInfoSize2()
```

C#

```
System.int GetDimensionDisplayInfoSize2()
```

C++/CLI

```
System.int GetDimensionDisplayInfoSize2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of dimension lines

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayInfoSize2](#).

Remarks

Call this method before calling [IView::IGetDimensionDisplayInfo5](#) to get the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionCount4 Method](#)
[IView::GetDimensionDisplayInfo5 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::GetFirstDisplayDimension5 Method](#)
[IView::IGetDimensionDisplayInfo5 Method](#)
[IView::IGetDimensionDisplayString4 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::IGetDimensionString4 Method](#)
[IView::GetFirstDisplayDimension5 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionDisplayString Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayString Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayString4](#) and [IView::IGetDimensionDisplayString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayString() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionDisplayString()
```

C#

```
System.Object GetDimensionDisplayString()
```

C++/CLI

```
System.Object^ GetDimensionDisplayString();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayString](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionDisplayString2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayString2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayString4](#) and [IView::IGetDimensionDisplayString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayString2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object
```

```
value = instance.GetDimensionDisplayString2()
```

C#

```
System.Object GetDimensionDisplayString2()
```

C++/CLI

```
System.Object^ GetDimensionDisplayString2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayString2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionDisplayString3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayString3 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayString4](#) and [IView::IGetDimensionDisplayString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayString3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionDisplayString3()
```

C#

```
System.object GetDimensionDisplayString3()
```

C++/CLI

```
System.Object^ GetDimensionDisplayString3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayString3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionDisplayString4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayString4 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayString5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayString4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionDisplayString4()
```

C#

```
System.object GetDimensionDisplayString4()
```

C++/CLI

```
System.Object^ GetDimensionDisplayString4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings containing the dimension text (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayString4](#).

Remarks

For each dimension in the drawing sheet or drawing view, this method returns 10 strings. If any of the dimension strings are not used, then those strings are returned as empty strings.

[*value1, tolMax1 tolMin1, value2, tolMax2, tolMin2, prefix, suffix, callout1, callout2*]

This set of data is returned for each dimension in the view. See [IView::GetDimensionCount4](#) to determine the number of dimensions in the drawing sheet or drawing view.

NOTES:

- A previous version of this method, [IView::GetDimensionDisplayString2](#) or [IView::!GetDimensionDisplayString2](#), detects and overlooks dangling dimensions. These method, [IView::GetDimensionDisplayString4](#) and [IView::!GetDimensionDisplayString4](#), do not overlook nor do they indicate that any dimensions are dangling. Use [IView::GetDimensionDisplayString2](#) if you need dangling dimensions detected and overlooked.
- This method does not support [hole callouts](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionDisplayInfo5 Method](#)
[IView::GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::!GetDimensionDisplayInfo5 Method](#)
[IView::!GetDimensionIds4 Method](#)
[IView::!GetDimensionInfo6 Method](#)
[IView::!GetDimensionString4 Method](#)
[IView::ProjectedDimensions Property](#)
[IView::GetFirstDisplayDimension5 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionDisplayString5 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionDisplayString5 Method (IView)

Gets all of the dimension text in the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionDisplayString5( _  
    ByRef DimensionSize As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim DimensionSize As System.Integer  
Dim value As System.Object  
  
value = instance.GetDimensionDisplayString5(DimensionSize)
```

C#

```
System.Object GetDimensionDisplayString5(  
    out System.int DimensionSize  
)
```

C++/CLI

```
System.Object^ GetDimensionDisplayString5(  
    [Out] System.int DimensionSize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimensionSize
Number of strings for each dimension (see **Remarks**)

Return Value

Array of strings (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionDisplayString5](#).

Example

```
'VBA
' Open a drawing that has one or more display dimensions
'=====
Dim swApp As SldWorks.SldWorks
Dim swModel As ModelDoc2
Dim swDraw As DrawingDoc
Dim swView As View
Option Explicit
Sub main()
    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc

    Set swDraw = swModel

    Dim views As Variant
    views = swDraw.GetViews()

    Set swView = views(0)(0)
    Dim var As Variant
    Dim size As Long
    var = swView.GetDimensionDisplayString5(size)

    Debug.Print "Number of strings in returned array: " & UBound(var) + 1
    Debug.Print "Number of strings for each display dimension: " & size
End Sub
```

Remarks

This method returns a string array of size (*DimensionSize*) x (*number_of_dimensions_in_view*).

This set of values returned for each dimension in the view:

[*value1*, *tolMax1* *tolMin1*, *value2*, *tolMax2*, *tolMin2*, *prefix*, *suffix*, *callout1*, *callout2*, *bottom*]

where:

value1 = Primary Dimension Value

tolMax1 = Maximum Variation for *value1*

tolMin1 = Minimum Variation for *value1*

value2 = Dual Dimension Value

tolMax2 = Maximum Variation for *value2*

tolMin2 = Minimum Variation for *value2*
prefix = Text before *value1*
suffix = Text after *value1*
callout1 = Text above *prefix*<*value1*>*suffix*
callout2 = Text below *prefix*<*value1*>*suffix*
bottom = Text below *callout2*

The Dimension PropertyManager page (PMP) contains two Dimension Text boxes. Add dimension text by entering prefix, suffix, callout1, and callout2 texts in the first Dimension Text box. Enter bottom text in the second Dimension Text box.

If any of the above values are not used in the dimension, then those values are returned as empty strings in the returned array of this method.

For more information, see **SOLIDWORKS Design user-interface help > Detailing and Drawings > Drawings > Dimensions in Drawings > Dimension Value PropertyManager**.

NOTES:

- A previous version of this method, [IView::GetDimensionDisplayString2](#), detects and overlooks dangling dimensions. This method neither overlooks nor indicates that any dimensions are dangling. Use [IView::GetDimensionDisplayString2](#) if you need dangling dimensions detected and overlooked.
- This method does not support [hole callouts](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionDisplayInfo5 Method \(\)](#)
[IView::GetDimensionDisplayInfoSize2 Method \(\)](#)
[IView::GetDimensionIds4 Method \(\)](#)
[IView::GetDimensionInfo7 Method \(\)](#)
[IView::GetDimensionString4 Method \(\)](#)
[IView::GetFirstDisplayDimension5 Method \(\)](#)
[IView::ProjectedDimensions Property \(\)](#)

Availability

SOLIDWORKS 2024 SP02, Revision Number 32.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionIds Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionIds Method (IView)

Obsolete. Superseded by [IView::GetDimensionIds4](#) and [IView::IGetDimensionIds4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionIds() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionIds()
```

C#

```
System.object GetDimensionIds()
```

C++/CLI

```
System.Object^ GetDimensionIds();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionIds](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionIds2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionIds2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionIds4](#) and [IView::IGetDimensionIds4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionIds2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionIds2()
```

C#

```
System.object GetDimensionIds2()
```

C++/CLI

```
System.Object^ GetDimensionIds2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionIds2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionIds3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionIds3 Method (IView)

Obsolete. Superseded by [IView::GetDimensionIds4](#) and [IView::IGetDimensionIds4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionIds3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionIds3()
```

C#

```
System.object GetDimensionIds3()
```

C++/CLI

```
System.Object^ GetDimensionIds3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionIds3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionIds4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionIds4 Method (IView)

Gets the dimension names from the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionIds4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionIds4()
```

C#

```
System.object GetDimensionIds4()
```

C++/CLI

```
System.Object^ GetDimensionIds4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings; each string represents one dimension name from the current drawing sheet or current drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionIds4](#).

Remarks

The order of the dimension names returned align with the order of information returned from [IView::GetDimensionInfo6](#) or [IView::IGetDimensionInfo6](#). This alignment of information is valid as long as the calls to this method and [IView::GetDimensionInfo6](#) or [IView::IGetDimensionInfo6](#) are made consecutively.

One string is returned for each dimension in the view. See [IView::GetDimensionCount4](#) to determine the number of dimensions in the view.

See Also

[IView Interface](#)
[IView Members](#)

[IView::GetFirstDisplayDimension5 Method](#)
[IView::GetDimensionDisplayInfo5 Method](#)
[IView::GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::IGetDimensionDisplayInfo5 Method](#)
[IView::IGetDimensionDisplayString4 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionString4 Method](#)
[IView::ProjectedDimensions Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionInfo Method (IView)

Obsolete. Superseded by [IView::GetDimensionInfo6](#) and [IView::IGetDimensionInfo6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionInfo()
```

C#

```
System.object GetDimensionInfo()
```

C++/CLI

```
System.Object^ GetDimensionInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionInfo2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionInfo2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionInfo6](#) and [IView::IGetDimensionInfo6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionInfo2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionInfo2()
```

C#

```
System.object GetDimensionInfo2()
```

C++/CLI

```
System.Object^ GetDimensionInfo2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionInfo2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionInfo3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionInfo3 Method (IView)

Obsolete. Superseded by [IView::GetDimensionInfo6](#) and [IView::IGetDimensionInfo6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionInfo3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object
```

```
value = instance.GetDimensionInfo3()
```

C#

```
System.object GetDimensionInfo3()
```

C++/CLI

```
System.Object^ GetDimensionInfo3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionInfo3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionInfo4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionInfo4 Method (IView)

Obsolete. Superseded by [IView::GetDimensionInfo6](#) and [IView::IGetDimensionInfo6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionInfo4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionInfo4()
```

C#

```
System.object GetDimensionInfo4()
```

C++/CLI

```
System.Object^ GetDimensionInfo4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionInfo4](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionInfo5 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionInfo5 Method (IView)

Obsolete. Superseded by [IView::GetDimensionInfo6](#) and [IView::IGetDimensionInfo6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionInfo5() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionInfo5()
```

C#

```
System.object GetDimensionInfo5()
```

C++/CLI

```
System.Object^ GetDimensionInfo5();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionInfo5](#).

See Also

GetDimensionInfo6 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionInfo6 Method (IView)

Obsolete. Superseded by [IView::GetDimensionInfo7](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionInfo6() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object
```

```
value = instance.GetDimensionInfo6()
```

C#

```
System.Object GetDimensionInfo6()
```

C++/CLI

```
System.Object^ GetDimensionInfo6();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionInfo6](#).

Remarks

The data returned is an array of doubles as follows:

```
[ dimensionCount, [ dimensionType, LineStyleIndex, LineWidth, Color, LayerID, LayerOverride, refPoint1a[3], refPoint1b[3],  
  refPoint2a[3], refPoint2b[3], refPoint3[3], textPoint[3], textDirection[3], dimNormal[3], angularDimInfo[9], precision, arrowLength,  
  arrowHeadWidth, arrowHeadHeight, arrowHeadStyle, witnessGap, witnessExt, dimValue, textHeight, arrowsOut, isDiameter,  
  RadialDimensionflags ] ]
```

where:

dimensionCount = number of dimensions found in the drawing view

For each dimension, you have a repeating set of the following data:

dimensionType = returns 0 = Linear, 1 = Angular, 2 = Radial, 3 = Ordinate

LineStyleIndex = line style; valid line styles as defined in [swLineStyles_e](#)

LineWidth = integer value defining the line width; valid width values as defined in [swLineWeights_e](#)

Color = COLORREF returned as an integer; return value could be 0 or -1 for default color

LayerID = integer value indicating which layer holds this entity; this integer value is the array index value into the layerList array; obtain the layerList array using [ILayerMgr::GetLayerList](#) or [ILayerMgr::!GetLayerList](#); a value of 1 indicates that this item is not on a layer

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the [ILayer](#) default properties; if the bit value is set, then the specific property or properties have been overridden; the bit indicators are: color = 0x1, style = 0x2, and width = 0x4; therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer

refPoint1a[3] = array of three doubles

refPoint1b[3] = array of three doubles

refPoint2a[3] = array of three doubles

refPoint2b[3] = array of three doubles

refPoint3[3] = array of three doubles

textPoint[3] = array of three doubles; this is the upper-left corner of the dimension bounding box

textDirection[3] = array of three doubles

dimNormal[3] = array of three doubles

angularDimInfo[9] This data is only returned for angular dimensions; the array of 9 values is as follows:

quadrant = as defined in [swQuadrant_e](#)

directionLine1[3] = array of three doubles

directionLine2[3] = array of three doubles

isInteriorAngle = BOOLEAN returned as a double; true if it is an interior angle

isFlipped = BOOLEAN returned as a double; true if it is flipped

precision = number of decimal places

arrowLength = arrow length

arrowHeadWidth = arrowhead width

arrowHeadHeight = arrowhead height

arrowHeadStyle = arrowhead style as defined in [swArrowStyle_e](#)

witnessGap = extension gap

witnessExt = extension's extension

dimValue = dimension value

textHeight = dimension text height

arrowsOut = BOOLEAN returned as a double and is true if the arrows are outside

isDiameter = BOOLEAN returned as a double and is used by radial dimensions; if this value is true, then the *dimValue* returned is the diameter value, if false, then the *dimValue* returned is the radial value

RadialDimensionflags = bit code defining properties for radial dimensions or 0 if the dimension is not radial. This element contains a bitwise OR of the following values:

RADIAL_INSIDE - Specifies that the arrows of the radial dimension are displayed inside the arc/circle.

RADIAL_2ND_ARROW - Specifies that there should be two outside arrows displayed with the radial dimension.

RADIAL_SOLID_LEADER - Specifies that the leader line should be drawn in solid.

RADIAL_CALLOUT - Specifies that there should be text displayed with the dimension.

RADIAL_IS_RADIAL - Specifies that the leader line should remain radial.

RADIAL_IS_BENT - Specifies that the leader line should be bent at the end.

RADIAL_IS_LINEAR - Specifies that the leader line should be straight at the end.

RADIAL_DOC_2ND_ARROW - Specifies that there should be two outside document arrows displayed with the radial dimension.

RADIAL_HAS_SNAPPED_DIR - Specifies that the arrow should snap to the grid.

The maximum number of doubles contained in the array will be (1 + *dimensionCount* * 51).

This method does not support [hole callouts](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionCount4 Method](#)
[IView::GetDimensionDisplayInfo5 Method](#)
[IView::GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::GetFirstDisplayDimension5 Method](#)
[IView::IGetDimensionDisplayInfo5 Method](#)
[IView::IGetDimensionDisplayString4 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::IGetDimensionString4 Method](#)
[IView::ProjectedDimensions Property](#)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionInfo7 Method (IView)

Gets all of the dimension information in the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionInfo7() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionInfo7()
```

C#

```
System.object GetDimensionInfo7()
```

C++/CLI

```
System.Object^ GetDimensionInfo7();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionInfo7](#).

Remarks

The data returned is an array of doubles as follows:

```
[ dimensionCount, [ dimensionType, LineStyleIndex, LineWidth, Color, LayerID, LayerOverride, refPoint1a[3], refPoint1b[3],
refPoint2a[3], refPoint2b[3], refPoint3[3], textPoint[3], textDirection[3], dimNormal[3], angularDimInfo[9], angularOrdinateDimInfo[10]
precision, arrowLength, arrowHeadWidth, arrowHeadHeight, arrowHeadStyle, witnessGap, witnessExt, dimValue, textHeight,
arrowsOut, isDiameter, RadialDimensionflags ] ]
```

where:

dimensionCount = number of dimensions found in the drawing view

Each dimension has the following data:

dimensionType = returns 0 = Linear, 1 = Angular, 2 = Radial, 3 = Ordinate, 4 = Chamfer, 5 = Angular Ordinate

LineStyleIndex = line style; valid line styles as defined in [swLineStyles_e](#)

LineWidth = integer value defining the line width; valid width values as defined in [swLineWeights_e](#)

Color = COLORREF returned as an integer; return value could be 0 or -1 for default color

LayerID = integer value indicating which layer holds this entity; this integer value is the array index value into the layerList array; obtain the layerList array using [ILayerMgr::GetLayerList](#) or [ILayerMgr::IGetLayerList](#); a value of 1 indicates that this item is not on a layer

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the [ILay](#) default properties; if the bit value is set, then the specific property or properties have been overridden; the bit indicators are: color = 0x1, style = 0x2, and width = 0x4; therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer

refPoint1a[3] = array of three doubles

refPoint1b[3] = array of three doubles

refPoint2a[3] = array of three doubles

refPoint2b[3] = array of three doubles

refPoint[3] = array of three doubles

textPoint[3] = array of three doubles; this is the upper-left corner of the dimension bounding box

textDirection[3] = array of three doubles

dimNormal[3] = array of three doubles

angularDimInfo[9] This data is only returned for angular dimensions; the array of 9 values is as follows:

quadrant = as defined in [swQuadrant_e](#)

directionLine1[3] = array of three doubles

directionLine2[3] = array of three doubles

isInteriorAngle = BOOLEAN returned as a double; true if it is an interior angle

isFlipped = BOOLEAN returned as a double; true if it is flipped

angularOrdinateDimInfo[10] This data is only returned for angular ordinate dimensions; the array of 10 values is as follows:

point[3] = array of three doubles

isPermanent = BOOLEAN returned as a double; true if it is permanent

leaderType = where 1 = Above Text, 2 = Inline Text, 3 = Horizontal Text

isExtThruCenter = BOOLEAN returned as a double; true if the extension line passes through the center

isBidirectiona = BOOLEAN returned as a double; true if it is bidirectional

direction[3] = array of three doubles

precision = number of decimal places

arrowLength = arrow length

arrowHeadWidth = arrowhead width

arrowHeadHeight = arrowhead height

arrowHeadStyle = arrowhead style as defined in [swArrowStyle_e](#)

witnessGap = extension gap

witnessExt = extension's extension

dimValue = dimension value

textHeight = dimension text height

arrowsOut = BOOLEAN returned as a double and is true if the arrows are outside

isDiameter = BOOLEAN returned as a double and is used by radial dimensions; if this value is true, then the *dimValue* returned is the diameter value, if false, then the *dimValue* returned is the radial value

RadialDimensionFlags = bit code defining properties for radial dimensions or 0 if the dimension is not radial. This element contains a bitwise OR of the following values:

RADIAL_INSIDE - Specifies that the arrows of the radial dimension are displayed inside the arc/circle.

RADIAL_2ND_ARROW - Specifies that there should be two outside arrows displayed with the radial dimension.

RADIAL_SOLID_LEADER - Specifies that the leader line should be drawn in solid.

RADIAL_CALLOUT - Specifies that there should be text displayed with the dimension.

RADIAL_IS_RADIAL - Specifies that the leader line should remain radial.

RADIAL_IS_BENT - Specifies that the leader line should be bent at the end.

RADIAL_IS_LINEAR - Specifies that the leader line should be straight at the end.

RADIAL_DOC_2ND_ARROW - Specifies that there should be two outside document arrows displayed with the radial dimension.

RADIAL_HAS_SNAPPED_DIR - Specifies that the arrow should snap to the grid.

The maximum number of doubles contained in the array will be (1 + *dimensionCount* * 52).

This method does not support [hole callouts](#).

See Also

[View Interface](#)
[View Members](#)

Availability

GetDimensionString Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionString Method (IView)

Obsolete. Superseded by [IView::GetDimensionString4](#) and [IView::IGetDimensionString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionString() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionString()
```

C#

```
System.object GetDimensionString()
```

C++/CLI

```
System.Object^ GetDimensionString();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionString](#).

See Also

[IView Interface](#)
[IView Members](#)

GetDimensionString2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionString2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionString4](#) and [IView::IGetDimensionString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionString2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDimensionString2()
```

C#

```
System.object GetDimensionString2()
```

C++/CLI

```
System.Object^ GetDimensionString2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionString2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionString3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionString3 Method (IView)

Obsolete. Superseded by [IView::GetDimensionString4](#) and [IView::IGetDimensionString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionString3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionString3()
```

C#

```
System.object GetDimensionString3()
```

C++/CLI

```
System.Object^ GetDimensionString3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionString3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionString4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDimensionString4 Method (IView)

Gets the strings containing the text associated with each dimension in the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionString4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDimensionString4()
```

C#

```
System.Object GetDimensionString4()
```

C++/CLI

```
System.Object^ GetDimensionString4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings containing the text associated with each dimension

Visual Basic for Applications (VBA) Syntax

See [View::GetDimensionString4](#).

Remarks

Use [IView::GetDimensionCount4](#) to determine the number of strings to be returned.

This method does not support [hole callouts](#).

See Also

[IView Interface](#)
[View Members](#)
[View::GetDimensionCount4 Method](#)
[View::GetDimensionDisplayInfo5 Method](#)
[View::GetDimensionDisplayInfoSize2 Method](#)
[View::GetDimensionIds4 Method](#)
[View::GetDimensionInfo6 Method](#)
[View::GetDimensionDisplayString4 Method](#)
[View::GetFirstDisplayDimension5 Method](#)
[View::IGetDimensionDisplayInfo5 Method](#)
[View::IGetDimensionDisplayString4 Method](#)
[View::IGetDimensionIds4 Method](#)
[View::IGetDimensionInfo6 Method](#)
[View::IGetDimensionString4 Method](#)
[View::ProjectedDimensions Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayData Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayData Method (IView)

Obsolete. Superseded by [IView::GetDisplayData3](#) and [IView::IGetDisplayData3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDisplayData()
```

C#

```
System.Object GetDisplayData()
```

C++/CLI

```
System.Object^ GetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayData](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayData2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayData2 Method (IView)

Obsolete. Superseded by [IView::GetDisplayData3](#) and [IView::IGetDisplayData3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDisplayData2()
```

C#

```
System.Object GetDisplayData2()
```

C++/CLI

```
System.Object^ GetDisplayData2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayData2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayData3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayData3 Method (IView)

Obsolete. Superseded by [IView::GetDisplayData4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDisplayData3()
```

C#

```
System.object GetDisplayData3()
```

C++/CLI

```
System.Object^ GetDisplayData3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IDisplayData](#) object

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayData3](#).

Remarks

The data kept with the [IDisplayData](#) object is strictly for display purposes and allows you to recreate unintelligent geometry. It does not provide associations or detailed information about the geometry.

This method supersedes the now obsolete [View::GetDisplayData2](#) and should be used in its place. The previous version of this method returned model items that were not imported to the drawing view and, therefore, not visible in the drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetDisplayData3 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayData4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayData4 Method (IView)

Gets the the [IDisplayData](#) object for this drawing view containing only those model items that are visible in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDisplayData4()
```

C#

```
System.object GetDisplayData4()
```

C++/CLI

```
System.Object^ GetDisplayData4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IDisplayData](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayData4](#).

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayDimensionCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayDimensionCount Method (IView)

Gets the number of display dimensions in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayDimensionCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetDisplayDimensionCount()
```

C#

```
System.int GetDisplayDimensionCount()
```

C++/CLI

```
System.int GetDisplayDimensionCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of display dimensions

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayDimensionCount](#).

Example

[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Call this method before calling [IView::IGetDisplayDimensions](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayDimensions Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayDimensions Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayDimensions Method (IView)

Gets all of the display dimension on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayDimensions() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetDisplayDimensions()
```

C#

```
System.object GetDisplayDimensions()
```

C++/CLI

```
System.Object^ GetDisplayDimensions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [display dimensions](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayDimensions](#).

Example

[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Use this method to obtain the array of display dimensions all at once instead of calling [IView::GetFirstDisplayDimension5](#) and then repeatedly calling [IDisplayDimension::GetNext5](#) to obtain the remaining display dimensions on this drawing view.

NOTE: Display dimensions are not the same as [actual model dimensions](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayDimensionCount Method](#)
[IView::IGetDisplayDimensions Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayEdgesInShadedMode Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayEdgesInShadedMode Method (IView)

Gets whether to display the edges in this when the drawing view is in shaded mode.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayEdgesInShadedMode() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
value = instance.GetDisplayEdgesInShadedMode()
```

C#

```
System.bool GetDisplayEdgesInShadedMode()
```

C++/CLI

```
System.bool GetDisplayEdgesInShadedMode();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the edges are displayed when the view is in shaded mode, false if not

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayEdgesInShadedMode](#).

Remarks

To...	Then use...
Determine whether this view is displayed with faceted or precise geometry	IView::GetFacettedHlrDisplay
Determine the display mode of a drawing view	IView::GetDisplayMode2
Set the display mode of a drawing view	IView::SetDisplayMode3

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayTangentEdges2 Method](#)
[IView::GetUseParentDisplayMode Method](#)
[IView::SetDisplayTangentEdges2 Method](#)
[IView::UpdateViewDisplayGeometry Method](#)

GetDisplayMode Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayMode Method (IView)

Obsolete. Superseded by [IView::GetDisplayMode2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayMode() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDisplayMode()
```

C#

```
System.int GetDisplayMode()
```

C++/CLI

```
System.int GetDisplayMode();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayMode](#).

See Also

[IView Interface](#)
[IView Members](#)

GetDisplayMode2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayMode2 Method (IView)

Gets the current display mode of the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayMode2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetDisplayMode2()
```

C#

```
System.int GetDisplayMode2()
```

C++/CLI

```
System.int GetDisplayMode2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Current display mode of the drawing view as defined in [swDisplayMode_e](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayMode2](#).

Example

[Set View Display Mode \(C++\)](#)
[Change Display Mode to Draft Quality \(VBA\)](#)
[Get Number of Polylines in Shaded Mode Drawing View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayEdgesInShadedMode Method](#)
[IView::GetFacettedHlrDisplay Method](#)
[IView::SetDisplayMode3 Method](#)
[IView::UpdateViewDisplayGeometry Method](#)
[IView::SetDisplayTangentEdges2 Method](#)
[IView::GetDisplayTangentEdges2 Method](#)
[IView::GetUseParentDisplayMode Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayTangentEdges Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayTangentEdges Method (IView)

Obsolete. Superseded by [IView::GetDisplayTangentEdges2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayTangentEdges() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
value = instance.GetDisplayTangentEdges()
```

C#

```
System.bool GetDisplayTangentEdges()
```

C++/CLI

```
System.bool GetDisplayTangentEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayTangentEdges](#).

See Also

[IView Interface](#)
[IView Members](#)

GetDisplayTangentEdges2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDisplayTangentEdges2 Method (IView)

Gets the current tangent edge display mode of the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayTangentEdges2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetDisplayTangentEdges2()
```

C#

```
System.int GetDisplayTangentEdges2()
```

C++/CLI

```
System.int GetDisplayTangentEdges2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Tangent edge display mode as defined in [swDisplayTangentEdges_e](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDisplayTangentEdges2](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayEdgesInShadedMode Method](#)
[IView::GetDisplayMode2 Method](#)
[IView::GetFacettedHlrDisplay Method](#)
[IView::GetUseParentDisplayMode Method](#)
[IView::SetDisplayMode3 Method](#)
[IView::UpdateViewDisplayGeometry Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

GetDowelSymbolCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDowelSymbolCount Method (IView)

Gets the number of dowel symbols in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDowelSymbolCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetDowelSymbolCount()
```

C#

```
System.int GetDowelSymbolCount()
```

C++/CLI

```
System.int GetDowelSymbolCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of dowel symbols

Visual Basic for Applications (VBA) Syntax

See [View::GetDowelSymbolCount](#)

Remarks

Call this method before calling [IView::IGetDowelSymbols](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDowelSymbols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDowelSymbols Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetDowelSymbols Method (IView)

Gets all of the dowel symbols on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDowelSymbols() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetDowelSymbols()
```

C#

```
System.object GetDowelSymbols()
```

C++/CLI

```
System.Object^ GetDowelSymbols();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [dowel symbols](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetDowelSymbols](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

Use this method to obtain the array of dowel symbols all at once instead of calling [IView::GetFirstDowelSymbol](#) and then repeatedly calling [IDowelSymbol::GetNext](#) to obtain the remaining dowel symbols on this drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDowelSymbolCount Method](#)
[IView::IGetDowelSymbols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEllipseCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetEllipseCount Method (IView)

Gets the number of ellipses in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEllipseCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetEllipseCount()
```

C#

```
System.int GetEllipseCount()
```

C++/CLI

```
System.int GetEllipseCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of ellipses in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetEllipseCount](#).

Example

[Get Polylines Information \(VBA\)](#).

Remarks

Call this method before calling [IView::IGetEllipses5](#) to get the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEllipses Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetEllipses Method (IView)

Obsolete. Superseded by [IView::GetEllipses5](#) and [IView::IGetEllipses5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEllipses() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetEllipses()
```

C#

```
System.object GetEllipses()
```

C++/CLI

```
System.Object^ GetEllipses();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetEllipses](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEllipses2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetEllipses2 Method (IView)

Obsolete. Superseded by [IView::GetEllipses5](#) and [IView::IGetEllipses5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEllipses2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetEllipses2()
```

C#

```
System.Object GetEllipses2()
```

C++/CLI

```
System.Object^ GetEllipses2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetEllipses2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEllipses3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetEllipses3 Method (IView)

Obsolete. Superseded by [IView::GetEllipses5](#) and [IView::IGetEllipses5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEllipses3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetEllipses3()
```

C#

```
System.Object GetEllipses3()
```

C++/CLI

```
System.Object^ GetEllipses3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetEllipses3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEllipses4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetEllipses4 Method (IView)

Obsolete. Superseded by [IView::GetEllipses5](#) and [IView::IGetEllipses5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEllipses4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetEllipses4()
```

C#

```
System.object GetEllipses4()
```

C++/CLI

```
System.Object^ GetEllipses4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetEllipses4](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEllipses5 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetEllipses5 Method (IView)

Gets all of the ellipses added by a user in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEllipses5() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetEllipses5()
```

C#

```
System.object GetEllipses5()
```

C++/CLI

```
System.Object^ GetEllipses5();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (**Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetEllipses5](#).

Remarks

This method only returns ellipses that were sketched by a user in this drawing view. Use [View::GetPolylines6](#) or [IView::GetPolylines6](#) to access the solid model's projected display data in the drawing view.

All part and assembly geometry shown in a drawing view is represented by polylines. To access the polylines, use [View::GetPolylines3](#). The return values are in an array of doubles:

```
[ Color, LineType, LineStyleIndex, LineWidth, LayerID, LayerOverride, StartPt[3], EndPt[3], CenterPt[3], MajorPt[3], MinorPt[3], Direction .. ]
```

where:

Color = COLORREF returned as an integer. Return value can be 0 or -1 for default color.

LineType = line type. Valid returns as defined in [swLineTypes_e](#). A *lineType* is a combination of a *LineStyle* and *lineWeight*.

LineStyleIndex = line style. Valid line styles as defined in [swLineStyles_e](#).

LineWidth = integer value defining the line width. Valid width values as defined in [swLineWeights_e](#).

LayerID = integer value indicating that layer holds this entity. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::!GetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* is returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

StartPt[3] = array of 3 doubles (X,Y,Z) describing the ellipse start point.

EndPt[3] = array of 3 doubles (X,Y,Z) describing the ellipse end point. If the ellipse is closed, then this will be the same point as the *StartPt*.

CenterPt[3] = array of 3 doubles (X,Y,Z) describing the ellipse center point.

MajorPt[3] = array of 3 doubles (X,Y,Z) describing a point on the ellipse and on the major axis.

MinorPt[3] = array of 3 doubles (X,Y,Z) describing a point on the ellipse and on the minor axis.

Direction = -1 for clockwise, +1 for counterclockwise.

This set of data repeats for each ellipse in the view. The size of the array is (NumEllipses * 22). To determine the number of ellipses, use [IView::GetEllipseCount](#).

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (for example, the 0,0 origin being the lower-left corner of the sheet), then combine this data with the three return values from [IView::GetXForm](#) or [IView::!GetXForm](#).

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::!GetEllipses5 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceHatchCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFaceHatchCount Method (IView)

Gets the number of face hatches in the view.

.NET Syntax

Visual Basic (Declaration)

Function GetFaceHatchCount() As System.Integer

Visual Basic (Usage)

```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetFaceHatchCount()
```

C#

```
System.int GetFaceHatchCount()
```

C++/CLI

```
System.int GetFaceHatchCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces hatches in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetFaceHatchCount](#).

Example

[Get Crosshatches on the View \(VBA\)](#)

Remarks

Call this method before calling [IView::IGetFaceHatches](#) to get the size of the array for that method.

To get the number of solid hatches in a detail, broken, or crop view, use [IView::GetSolidHatchCount](#). To get solid hatches in detail, broken, or crop views, use [IView::GetSolidHatchInfo](#) or [IView::IGetSolidHatchInfo](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetFaceHatches Method](#)
[IView::IGetFaceHatches Method](#)
[IView::ScaleHatchPattern Property](#)
[IModelDoc2::InsertHatchedFace Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceHatches Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFaceHatches Method (IView)

Gets the face hatches in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceHatches() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.Object

value = instance.GetFaceHatches()
```

C#

```
System.Object GetFaceHatches()
```

C++/CLI

```
System.Object^ GetFaceHatches();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Face hatches](#) in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetFaceHatches](#).

Example

[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

Remarks

To get the number of solid hatches in a detail, broken, or crop view, use [IView::GetSolidHatchCount](#). To get solid hatches in detail, broken, or crop views, use [IView::GetSolidHatchInfo](#) or [IView::IGetSolidHatchInfo](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetFaceHatchCount Method](#)
[IView::IGetFaceHatches Method](#)
[IView::ScaleHatchPattern Property](#)
[IModelDoc2::InsertHatchedFace Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacettedHlrDisplay Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFacettedHlrDisplay Method (IView)

Gets whether HLR/HLV (Hidden Lines Removed/Hidden Lines Visible) edges should be displayed faceted in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacettedHlrDisplay() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.Boolean

value = instance.GetFacettedHlrDisplay()
```

C#



```
System.bool GetFacettedHlrDisplay()
```

C++/CLI

```
System.bool GetFacettedHlrDisplay();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the edges should be displayed faceted, false if not

Visual Basic for Applications (VBA) Syntax

See [View::GetFacettedHlrDisplay](#).

Example

[Get Whether HLR/HLV Edges are Displayed Faceted \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayEdgesInShadedMode Method](#)
[IView::GetDisplayMode2 Method](#)
[IView::GetDisplayTangentEdges2 Method](#)
[IView::SetDisplayMode3 Method](#)
[IView::SetDisplayTangentEdges2 Method](#)
[IView::UpdateViewDisplayGeometry Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstAnnotation Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstAnnotation Method (IView)

Obsolete. Superseded by [IView::GetFirstAnnotation3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstAnnotation()
```

C#

```
System.object GetFirstAnnotation()
```

C++/CLI

```
System.Object^ GetFirstAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstAnnotation](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstAnnotation2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstAnnotation2 Method (IView)

Obsolete. Superseded by [IView::GetFirstAnnotation3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstAnnotation2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstAnnotation2()
```

C#

```
System.object GetFirstAnnotation2()
```

C++/CLI

```
System.Object^ GetFirstAnnotation2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstAnnotation2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstAnnotation3 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstAnnotation3 Method (IView)

Gets the first annotation in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstAnnotation3() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As Annotation  
  
value = instance.GetFirstAnnotation3()
```

C#

Annotation GetFirstAnnotation3()

C++/CLI

```
Annotation^ GetFirstAnnotation3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [annotation](#) in the drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstAnnotation3](#).

Example

[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)
[Get Entities Attached to Cosmetic Thread \(VBA\)](#)
[Show Dimensions in Drawing Sheet \(VBA\)](#)

Remarks

This method gets any display dimension, including suppressed, hidden, or dangling dimensions on the sheet and on the sheet format if it is visible. The sheet must be visible. See [ISheet::SheetFormatVisible](#).

A dimension becomes suppressed or hidden when you specifically select a dimension and hide it or when you select a feature and say hide all dimensions. If you need to filter out these dimensions, you must use [IAnnotation::Visible](#) to check that status.

If the annotation is on a layer that is not shown, the annotation is still returned.

To get the next annotation, call [IAnnotation::GetNext3](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetAnnotations Method](#)
[IView::IGetAnnotations Method](#)
[IView::GetAnnotationCount Method](#)
[IAnnotation::GetNext3 Method](#)
[IView::GetAnnotationsByType Method \(\)](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0