

SOLIDWORKS API (.NET VBA C#) — Reference

(324/337): View (part 4 of 10)

SOLIDWORKS API Documentation (converted from CHM)

IView (part 4 of 10) (Type)

GetFirstBlockInstance Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstBlockInstance Method (IView)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstBlockInstance() As BlockInstance
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As BlockInstance

value = instance.GetFirstBlockInstance()
```

C#

```
BlockInstance GetFirstBlockInstance()
```

C++/CLI

```
BlockInstance^ GetFirstBlockInstance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstBlockInstance](#).

See Also

[IView Interface](#)
[IView Members](#)

GetFirstCenterLine Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstCenterLine Method (IView)

Gets the first centerline in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstCenterLine() As Centerline
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As Centerline

value = instance.GetFirstCenterLine()
```

C#

```
Centerline GetFirstCenterLine()
```

C++/CLI

```
Centerline^ GetFirstCenterLine();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [centerline](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstCenterLine](#).

Example

[Get Centerlines in Drawing \(C#\)](#)
[Get Centerlines in Drawing \(VB.NET\)](#)
[Get Centerlines in Drawing \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterLineSketch Method](#)
[ICenterline::GetNext Method](#)
[IView::GetCenterLines Method](#)
[IView::IGetCenterLines Method](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstCenterMark Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstCenterMark Method (IView)

Obsolete. Superseded by [IView::GetFirstCenterMark2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstCenterMark() As CenterMark
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As CenterMark  
  
value = instance.GetFirstCenterMark()
```

C#

```
CenterMark GetFirstCenterMark()
```

C++/CLI

```
CenterMark^ GetFirstCenterMark();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [center mark](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstCenterMark](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterMarkCount2 Method](#)
[IView::GetCenterMarkInfo Method](#)
[IView::GetCenterMarks Method](#)
[IView::IGetCenterMarkInfo Method](#)
[IView::IGetCenterMarks Method](#)
[ICenterMark::GetNext Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstCenterMark2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstCenterMark2 Method (IView)

Gets the first center mark in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstCenterMark2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstCenterMark2()
```

C#

```
System.object GetFirstCenterMark2()
```

C++/CLI

```
System.Object^ GetFirstCenterMark2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [center mark](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstCenterMark2](#).

Example

[List Center Marks in Drawing \(VBA\)](#)
[Select All Center Marks \(C#\)](#)
[Select All Center Marks \(VB.NET\)](#)
[Select All Center Marks \(VBA\)](#)

Remarks

This method obsoletes IView::GetFirstCenterMark by supporting inactive sheets.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterMarkCount2 Method \(\)](#)
[IView::GetCenterMarkInfo Method \(\)](#)
[IView::GetCenterMarks Method \(\)](#)
[ICenterMark::GetNext Method \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstCenterOfMass Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstCenterOfMass Method (IView)

Gets the first center of mass in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstCenterOfMass() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetFirstCenterOfMass()
```

C#

```
System.Object GetFirstCenterOfMass()
```

C++/CLI

```
System.Object^ GetFirstCenterOfMass();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ICenterOfMass](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstCenterOfMass](#).

Example

[Get Centers of Mass in Drawing Views \(VBA\)](#)
[Get Centers of Mass in Drawing Views \(VB.NET\)](#)
[Get Centers of Mass in Drawing Views \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetFirstCenterOfMass Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstCThread Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstCThread Method (IView)

Gets the first cosmetic thread in the view.

.NET Syntax

Visual Basic (Declaration)

Function GetFirstCThread() As System.Object

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstCThread()
```

C#

System.object GetFirstCThread()

C++/CLI

System.Object^ GetFirstCThread();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [cosmetic thread](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstCThread](#).

Example

[Get Patterned Cosmetic Thread Annotations Data \(C#\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VB.NET\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetFirstCThread Method](#)
[ICThread::GetNext Method](#)
[ICThread::IGetNext Method](#)
[IView::IGetCThreads Method](#)
[IView::GetCThreads Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstCustomSymbol Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstCustomSymbol Method (IView)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

Function GetFirstCustomSymbol() As System.Object

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstCustomSymbol()
```

C#

System.object GetFirstCustomSymbol()

C++/CLI

```
System.Object^ GetFirstCustomSymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstCustomSymbol](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstDatumOrigin Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstDatumOrigin Method (IView)

Gets the first datum origin in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDatumOrigin() As DatumOrigin
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As DatumOrigin  
  
value = instance.GetFirstDatumOrigin()
```

C#

```
DatumOrigin GetFirstDatumOrigin()
```

C++/CLI

```
DatumOrigin^ GetFirstDatumOrigin();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [datum origin](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDatumOrigin](#).

See Also

[IView Interface](#)
[IView Members](#)
[IDatumOrigin::GetNext Method](#)
[IView::GetDatumOrigins Method](#)
[IView::IGetDatumOrigins Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstDatumTag Method (IView)

[See Also](#)



Gets the first datum tag in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDatumTag() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstDatumTag()
```

C#

```
System.object GetFirstDatumTag()
```

C++/CLI

```
System.Object^ GetFirstDatumTag();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [datum tag](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDatumTag](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetFirstDatumTag Method](#)
[IDatumTag::GetNext Method](#)
[IDatumTag::IGetNext Method](#)
[IView::IGetDatumTags Method](#)
[IView::GetDatumTags Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstDatumTargetSym Method (IView)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [IView Interface](#) : GetFirstDatumTargetSym Method (IView)

Gets the first datum target symbol in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDatumTargetSym() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstDatumTargetSym()
```

C#

```
System.object GetFirstDatumTargetSym()
```

C++/CLI

```
System.Object^ GetFirstDatumTargetSym();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [datum target symbol](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDatumTargetSym](#).

See Also

[IView Interface](#)
[IView Members](#)
[IDatumTargetSym::GetNext Method](#)
[IDatumTargetSym::IGetNext Method](#)
[IView::IGetFirstDatumTargetSym Method](#)
[IView::GetDatumTargetSyms Method](#)
[IView::IGetDatumTargetSyms Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstDisplayDimension Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstDisplayDimension Method (IView)

Obsolete. Superseded by [IView::GetFirstDisplayDimension5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDisplayDimension() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstDisplayDimension()
```

C#

```
System.object GetFirstDisplayDimension()
```

C++/CLI

```
System.Object^ GetFirstDisplayDimension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDisplayDimension](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstDisplayDimension2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstDisplayDimension2 Method (IView)

Obsolete. Superseded by [IView::GetFirstDisplayDimension5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDisplayDimension2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstDisplayDimension2()
```

C#

```
System.object GetFirstDisplayDimension2()
```

C++/CLI

```
System.Object^ GetFirstDisplayDimension2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDisplayDimension2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstDisplayDimension3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstDisplayDimension3 Method (IView)

Obsolete. Superseded by [IView::GetFirstDisplayDimension5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDisplayDimension3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstDisplayDimension3()
```

C#

```
System.object GetFirstDisplayDimension3()
```

C++/CLI

```
System.Object^ GetFirstDisplayDimension3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDisplayDimension3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstDisplayDimension4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstDisplayDimension4 Method (IView)

Obsolete. Superseded by [IView::GetFirstDisplayDimension5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDisplayDimension4() As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As DisplayDimension

value = instance.GetFirstDisplayDimension4()
```

C#

```
DisplayDimension GetFirstDisplayDimension4()
```

C++/CLI

```
DisplayDimension^ GetFirstDisplayDimension4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDisplayDimension4](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstDisplayDimension5 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstDisplayDimension5 Method (IView)

Obsolete. Superseded by [IView::GetFirstDisplayDimension6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDisplayDimension5() As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As DisplayDimension

value = instance.GetFirstDisplayDimension5()
```

C#

```
DisplayDimension GetFirstDisplayDimension5()
```

C++/CLI

```
DisplayDimension^ GetFirstDisplayDimension5();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [display dimension](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDisplayDimension5](#).

Remarks

A SOLIDWORKS dimension can be displayed more than once. For example, the base-extrude dimension could be brought into three different views on a drawing. These three dimensions are referred to as display dimensions and are represented by the [IDisplayDimension](#) object in the SOLIDWORKS API. The original base-extrude dimension is represented by the [IDimension](#) object in the SOLIDWORKS API.

This method displays:

- dimensions on both the sheet and sheet format.
- suppressed dimensions.

Call [IDisplayDimension::GetNext5](#) to get the next display dimension on this drawing sheet.

Do not use [IAnnotation::Visible](#) property to modify this method's return value.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionCount4 Method](#)
[IView::GetDimensionDisplayInfo5 Method](#)
[IView::GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::IGetDimensionDisplayInfo5 Method](#)
[IView::IGetDimensionDisplayString4 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::ProjectedDimensions Property](#)
[IView::IGetDisplayDimensions Method](#)
[IView::GetDisplayDimensions Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstDisplayDimension6 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstDisplayDimension6 Method (IView)

Gets the first display dimension in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDisplayDimension6() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstDisplayDimension6()
```

C#

```
System.Object GetFirstDisplayDimension6()
```

C++/CLI

```
System.Object^ GetFirstDisplayDimension6();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDisplayDimension6](#).

Example

[Get Dimension Values in Drawing \(VBA\)](#)

Remarks

This method obsoletes `IView::GetFirstDisplayDimension5` by supporting inactive sheets.

A SOLIDWORKS dimension can be displayed more than once. For example, the base-extrude dimension could be brought into three different views on a drawing. These three dimensions are referred to as display dimensions and are represented by the [IDisplayDimension](#) object in the SOLIDWORKS API. The original base-extrude dimension is represented by the [IDimension](#) object in the SOLIDWORKS API.

This method displays:

- dimensions on both the sheet and sheet format.
- suppressed dimensions.

Call [IDisplayDimension::GetNext5](#) to get the next display dimension on this drawing sheet.

Do not use [IAnnotation::Visible](#) property to modify this method's return value.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionCount4 Method \(\)](#)
[IView::GetDimensionDisplayInfo5 Method \(\)](#)
[IView::GetDimensionDisplayInfoSize2 Method \(\)](#)
[IView::GetDimensionDisplayString5 Method \(\)](#)
[IView::GetDimensionIds4 Method \(\)](#)
[IView::GetDimensionInfo7 Method \(\)](#)
[IView::GetDimensionString4 Method \(\)](#)
[IView::GetDisplayDimensions Method \(\)](#)
[IView::ProjectedDimensions Property \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstDowelSymbol Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstDowelSymbol Method (IView)

Gets the first dowel symbol in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDowelSymbol() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstDowelSymbol()
```

C#

```
System.object GetFirstDowelSymbol()
```

C++/CLI

```
System.Object^ GetFirstDowelSymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [dowel symbol](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstDowelSymbol](#).

See Also

[IView Interface](#)
[IView Members](#)
[IDowelSymbol::GetNext Method](#)
[IDowelSymbol::IGetNext Method](#)
[IView::IGetFirstDowelSymbol Method](#)
[IView::GetDowelSymbols Method](#)
[IView::IGetDowelSymbols Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstGTOL Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstGTOL Method (IView)

Gets the first geometric tolerance in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstGTOL() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstGTOL()
```

C#

```
System.object GetFirstGTOL()
```

C++/CLI

```
System.Object^ GetFirstGTOL();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [GTol](#)

 Visual Basic for Applications (VBA) Syntax

See [View::GetFirstGTOL](#).

 See Also

[IView Interface](#)
[IView Members](#)
[IGtol::GetNextGTOL Method](#)
[IGtol::IGetNextGTOL Method](#)
[IView::IGetFirstGTOL Method](#)
[IView::IGetGTols Method](#)
[IView::GetGTols Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstMultiJogLeader Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstMultiJogLeader Method (IView)

Obsolete. Superseded by [IView::GetFirstMultiJogLeader2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function GetFirstMultiJogLeader() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstMultiJogLeader()
```

C#

```
System.object GetFirstMultiJogLeader()
```

C++/CLI

```
System.Object^ GetFirstMultiJogLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [multi-jog leader](#)

 Visual Basic for Applications (VBA) Syntax

See [View::GetFirstMultiJogLeader](#).

 See Also

[IView Interface](#)
[IView Members](#)
[IMultiJogLeader::GetNext Method](#)
[IMultiJogLeader::IGetNext Method](#)
[IView::IGetFirstMultiJogLeader Method](#)
[IView::GetMultiJogLeaders Method](#)
[IView::IGetMultiJogLeaders Method](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

GetFirstMultiJogLeader2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstMultiJogLeader2 Method (IView)

Gets the first multi-jog leader in the view.

.NET Syntax

Visual Basic (Declaration)

Function GetFirstMultiJogLeader2() As System.Object

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetFirstMultiJogLeader2()
```

C#

System.object GetFirstMultiJogLeader2()

C++/CLI

System.Object^ GetFirstMultiJogLeader2();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstMultiJogLeader2](#).

Example

[Get Multi-jog Leader Data \(VBA\)](#)
[Get Multi-jog Leader Data \(VB.NET\)](#)
[Get Multi-jog Leader Data \(C#\)](#)

Remarks

This method obsoletes IView::GetFirstMultiJogLeader by supporting inactive sheets.

See Also

[IView Interface](#)
[IView Members](#)
[IMultiJogLeader::GetNext Method \(\)](#)
[IView::GetMultiJogLeaders Method \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

GetFirstNote Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstNote Method (IView)

Obsolete. Superseded by [IView::GetFirstNote2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstNote() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstNote()
```

C#

```
System.object GetFirstNote()
```

C++/CLI

```
System.Object^ GetFirstNote();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [note](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstNote](#).

Remarks

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetFirstNote Method](#)
[INote::GetNext Method](#)
[INote::IGetNext Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstNote2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstNote2 Method (IView)

Gets the first note in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstNote2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstNote2()
```

C#

```
System.object GetFirstNote2()
```

C++/CLI

```
System.Object^ GetFirstNote2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [note](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstNote2](#).

Example

[Change Note Text \(VBA\)](#)
[Get All Notes in Drawing Template \(VBA\)](#)
[Select Silhouette Edge Attached to Note \(VBA\)](#)
[Select Silhouette Edge Attached to Note \(VB.NET\)](#)
[Select Silhouette Edge Attached to Note \(C#\)](#)

Remarks

This method obsoletes [IView::GetFirstNote](#) by supporting inactive sheets.

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[INote::GetNext Method \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstRevisionCloud Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstRevisionCloud Method (IView)

Obsolete. Superseded by [IView::GetFirstRevisionCloud2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstRevisionCloud() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstRevisionCloud()
```

C#

```
System.object GetFirstRevisionCloud()
```

C++/CLI

```
System.Object^ GetFirstRevisionCloud();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IRevisionCloud](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstRevisionCloud](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetFirstRevisionCloud Method \(\)](#)
[IView::GetRevisionCloudCount Method \(\)](#)
[IView::GetRevisionClouds Method \(\)](#)
[IView::IGetRevisionClouds Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstRevisionCloud2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstRevisionCloud2 Method (IView)

Gets the first revision cloud annotation in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstRevisionCloud2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstRevisionCloud2()
```

C#

```
System.Object GetFirstRevisionCloud2()
```

C++/CLI

```
System.Object^ GetFirstRevisionCloud2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IRevisionCloud](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstRevisionCloud2](#).

Remarks

This method obsoletes IView::GetFirstRevisionCloud by supporting inactive sheets.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetRevisionCloudCount Method \(\)](#)
[IView::GetRevisionClouds Method \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstSFSymbol Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstSFSymbol Method (IView)

Gets the first surface-finish symbols in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstSFSymbol() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetFirstSFSymbol()
```

C#

```
System.object GetFirstSFSymbol()
```

C++/CLI

```
System.Object^ GetFirstSFSymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [surface-finish symbol](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstSFSymbol](#).

See Also

[IView Interface](#)
[IView Members](#)
[ISFSymbol::GetNext Method](#)
[ISFSymbol::IGetNext Method](#)
[IView::IGetFirstSFSymbol Method](#)
[IView::IGetSFSymbols Method](#)
[IView::GetSFSymbols Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstTableAnnotation Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstTableAnnotation Method (IView)

Obsolete. Superseded by [IView::GetFirstTableAnnotation2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstTableAnnotation() As TableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As TableAnnotation

value = instance.GetFirstTableAnnotation()
```

C#

```
TableAnnotation GetFirstTableAnnotation()
```

C++/CLI

```
TableAnnotation^ GetFirstTableAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstTableAnnotation](#).

See Also

[IView Interface](#)
[IView Members](#)
[ITableAnnotation::GetNext Method](#)
[IView::GetTableAnnotations Method](#)
[IView::IGetTableAnnotations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstTableAnnotation2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstTableAnnotation2 Method (IView)

Gets the first table annotation in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstTableAnnotation2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetFirstTableAnnotation2()
```

C#

```
System.object GetFirstTableAnnotation2()
```

C++/CLI

```
System.Object^ GetFirstTableAnnotation2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstTableAnnotation2](#).

Example

[Get Table Annotation and Contents \(VBA\)](#)

Remarks

This method obsoletes `IView::GetFirstTableAnnotation` by supporting inactive sheets.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetTableAnnotations Method \(\)](#)
[TableAnnotation::GetNext Method \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

[SOLIDWORKS API Help](#)

[Send comments](#) on this topic.

GetFirstWeldBead Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstWeldBead Method (IView)

Gets the first weld bead annotation in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstWeldBead() As WeldBead
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As WeldBead
```

```
value = instance.GetFirstWeldBead()
```

C#

```
WeldBead GetFirstWeldBead()
```

C++/CLI

```
WeldBead^ GetFirstWeldBead();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [weld bead](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstWeldBead](#).

Example

[Get Weld Bead Symbol Data \(VBA\)](#)
[Get Weld Bead Symbol Data \(VB.NET\)](#)
[Get Weld Bead Symbol Data \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[WeldBead::GetNext Method](#)
[IView::IGetWeldBeads Method](#)
[IView::GetWeldBeads Method](#)

Availability

GetFirstWeldSymbol Method (IView)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetFirstWeldSymbol Method (IView)

Gets the first weld symbol in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstWeldSymbol() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetFirstWeldSymbol()
```

C#

```
System.object GetFirstWeldSymbol()
```

C++/CLI

```
System.Object^ GetFirstWeldSymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [weld symbol](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetFirstWeldSymbol](#).

See Also

[IView Interface](#)
[IView Members](#)
[IWeldSymbol::GetNext Method](#)
[IWeldSymbol::IGetNext Method](#)
[IView::GetWeldSymbols Method](#)
[IView::IGetWeldSymbols Method](#)

GetGTolCount Method (IView)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetGTolCount Method (IView)

Gets the number of geometric tolerances in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGTolCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetGTolCount()
```

C#

```
System.int GetGTolCount()
```

C++/CLI

```
System.int GetGTolCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of geometric tolerances

Visual Basic for Applications (VBA) Syntax

See [View::GetGTolCount](#)

Example

[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Call this method before calling [View::IGetGTols](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetGTols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetGTols Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetGTols Method (IView)

Gets all of the geometric tolerances on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGTols() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetGTols()
```

C#

```
System.object GetGTols()
```

C++/CLI

```
System.Object^ GetGTols();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [geometric tolerances](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetGTols](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

Use this method to obtain the array of geometric tolerances all at once instead of calling [IView::GetFirstGTOL](#) and then repeatedly calling [IGtol::GetNextGTOL](#) to obtain the remaining geometric tolerances in the drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetGTolCount Method](#)
[IView::IGetGTols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHiddenComponents Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetHiddenComponents Method (IView)

Gets the hidden components in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHiddenComponents() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetHiddenComponents()
```

C#

```
System.object GetHiddenComponents()
```

C++/CLI

```
System.Object^ GetHiddenComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of hidden components

Visual Basic for Applications (VBA) Syntax

See [View::GetHiddenComponents](#).

Example

See Also

[IView Interface](#)
[IView Members](#)
[IView::EnumHiddenComponents2 Method](#)
[IView::GetVisibleComponentCount Method](#)
[IView::GetVisibleComponents Method](#)
[IView::IGetVisibleComponents Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetKeepLinkedToBOM Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetKeepLinkedToBOM Method (IView)

Gets whether this drawing view is linked to a BOM or weldment cut-list table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetKeepLinkedToBOM() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

value = instance.GetKeepLinkedToBOM()
```

C#

```
System.bool GetKeepLinkedToBOM()
```

C++/CLI

```
System.bool GetKeepLinkedToBOM();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this drawing view is linked to a BOM or weldment cut-list table, false if not

Visual Basic for Applications (VBA) Syntax

See [View::GetKeepLinkedToBOM](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBomTable Method](#)
[IView::GetKeepLinkedToBOMName Method](#)
[IView::IGetBomTable Method](#)
[IView::IInsertBomTable Method](#)
[IView::InsertBomTable Method](#)
[IView::InsertBomTable2 Method](#)
[IView::InsertWeldmentTable Method](#)
[IView::SetKeepLinkedToBOM Method](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetKeepLinkedToBOMName Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetKeepLinkedToBOMName Method (IView)

Gets the name of the BOM or weldment cut-list table feature to which this drawing view is linked.

.NET Syntax

Visual Basic (Declaration)

```
Function GetKeepLinkedToBOMName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.GetKeepLinkedToBOMName()
```

C#

```
System.string GetKeepLinkedToBOMName()
```

C++/CLI

```
System.String^ GetKeepLinkedToBOMName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of BOM or weldment cut-list table feature

Visual Basic for Applications (VBA) Syntax

See [View::GetKeepLinkedToBOMName](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBomTable Method](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::IGetBomTable Method](#)
[IView::InsertBomTable Method](#)
[IView::InsertBomTable Method](#)
[IView::InsertBomTable2 Method](#)
[IView::InsertWeldmentTable Method](#)
[IView::SetKeepLinkedToBOM Method](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetLineCount Method (IView)

Obsolete. Superseded by [IView::GetLineCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer
```

```
value = instance.GetLineCount()
```

C#

```
System.int GetLineCount()
```

C++/CLI

```
System.int GetLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetLineCount](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineCount2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetLineCount2 Method (IView)

Gets the number of lines in this view with an option to include or exclude crosshatch lines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineCount2( _  
    ByVal CrossHatchOption As System.Short _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim CrossHatchOption As System.Short  
Dim value As System.Integer  
  
value = instance.GetLineCount2(CrossHatchOption)
```

C#

```
System.int GetLineCount2(  
    System.short CrossHatchOption  
)
```

C++/CLI

```
System.int GetLineCount2(  
& System.short CrossHatchOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CrossHatchOption

Crosshatch option as defined in [swCrossHatchFilter_e](#)

Return Value

Number of lines

Visual Basic for Applications (VBA) Syntax

See [View::GetLineCount2](#).

 Example

[Get Polyline Information \(VBA\)](#)

 Remarks

Call this method before calling [View::IGetLines4](#) to get the size of the array for that method.

 See Also

[IView Interface](#)
[IView Members](#)
[IView::GetLines4 Method](#)
[IView::IGetLines4 Method](#)

 Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetLines Method (IView)

Obsolete. Superseded by [IView::GetLines4](#) and [IView::IGetLines4](#).

 .NET Syntax

Visual Basic (Declaration)

Function GetLines() As System.Object

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetLines()
```

C#

System.object GetLines()

C++/CLI

System.Object^ GetLines();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [View::GetLines](#).

 See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLines2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetLines2 Method (IView)

Obsolete. Superseded by [IView::GetLines4](#) and [IView::IGetLines4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLines2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetLines2()
```

C#

```
System.object GetLines2()
```

C++/CLI

```
System.Object^ GetLines2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetLines2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLines3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetLines3 Method (IView)

Obsolete. Superseded by [IView::GetLines4](#) and [IView::IGetLines4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLines3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetLines3()
```

C#

```
System.object GetLines3()
```

C++/CLI

```
System.Object^ GetLines3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetLines3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLines4 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetLines4 Method (IView)

Gets all of the lines in the view with an option to include or exclude crosshatch lines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLines4( _  
    ByVal CrossHatchOption As System.Short _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim CrossHatchOption As System.Short  
Dim value As System.Object  
  
value = instance.GetLines4(CrossHatchOption)
```

C#

```
System.Object GetLines4(  
    System.short CrossHatchOption  
)
```

C++/CLI

```
System.Object^ GetLines4(  
& System.short CrossHatchOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CrossHatchOption
Crosshatch option as defined in [swCrossHatchFilter_e](#)

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetLines4](#).

Example

[Get Polylines Information \(VBA\)](#)

Remarks

This method only returns lines that were sketched in this drawing view. Use [IView::GetPolylines6](#) or [IView::IGetPolylines6](#) to access the solid model's projected display data in this view.

The return value is the following array of doubles:

[*Color*, *LineType*, *LineStyleIndex*, *LineWidth*, *LayerID*, *LayerOverride*, *StartPt*[3], *EndPt*[3], ...]

where all data values are returned as doubles:

- *Color* = COLORREF returned as an integer. Return value could be 0 or -1 for default color.

- *LineType* = line type. Valid returns as defined in [swLineTypes_e](#). A *lineType* is a combination of a *lineStyle* and *lineWeight*.
- *LineStyleIndex* = line style. Valid line styles as defined in [swLineStyles_e](#).
- *LineWidth* = integer value defining the line width. Valid width values as defined in [swLineWeights_e](#).
- *LayerID* = integer value indicating which layer holds this entity. Obtain the [ILayer](#) object by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::IGetLayerById](#).
- *LayerOverride* = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* is returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.
- *StartPt[3]* = array of 3 doubles (X,Y,Z) describing the line start point.
- *EndPt[3]* = array of 3 doubles (X,Y,Z) describing the line end point.

This set of data repeats for each line in the view. The number of doubles returned is (lineCount * 12). To determine the number of lines in the view, use [IView::GetLineCount2](#).

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (that is, the 0,0 origin being the lower-left corner of the sheet), then combine this data with the three return values from [IView::GetXForm](#) or [IView::IGetXForm](#).

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetLines4 Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMirrorViewOrientation Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetMirrorViewOrientation Method (IView)

Gets whether this view is mirrored.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMirrorViewOrientation( _
    ByRef BIsMirrorView As System.Boolean, _
    ByRef LMirrorViewOrientation As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IView
Dim BIsMirrorView As System.Boolean
Dim LMirrorViewOrientation As System.Integer
Dim value As System.Boolean

value = instance.GetMirrorViewOrientation(BIsMirrorView, LMirrorViewOrientation)
```

C#

```
System.bool GetMirrorViewOrientation(
    out System.bool BIsMirrorView,
    out System.int LMirrorViewOrientation
)
```

C++/CLI

```
System.bool GetMirrorViewOrientation(
    & [Out] System.bool BIsMirrorView,
    & [Out] System.int LMirrorViewOrientation
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BIsMirrorView
True if the view is mirrored, false if not
LMirrorViewOrientation
Orientation of the mirror view as defined in [swMirrorViewPositions_e](#)

Return Value

True if the method executed successfully, false if not

 Visual Basic for Applications (VBA) Syntax

See [View::GetMirrorViewOrientation](#).

 Example

[Mirror View \(C#\)](#)
[Mirror View \(VB.NET\)](#)
[Mirror View \(VBA\)](#)

 See Also

[IView Interface](#)
[IView Members](#)
[IView::SetMirrorViewOrientation Method \(\)](#)

 Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMultiJogLeaderCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetMultiJogLeaderCount Method (IView)

Gets the number of multi-jog leaders on this drawing view.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetMultiJogLeaderCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetMultiJogLeaderCount()
```

C#

```
System.int GetMultiJogLeaderCount()
```

C++/CLI

```
System.int GetMultiJogLeaderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Total number of multi-jog leaders on this drawing view

 Visual Basic for Applications (VBA) Syntax

See [View::GetMultiJogLeaderCount](#).

Remarks

Call this method before calling [IView::IGetMultiJogLeaders](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetMultiJogLeaders Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMultiJogLeaders Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetMultiJogLeaders Method (IView)

Gets all of the multi-jog leaders in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMultiJogLeaders() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetMultiJogLeaders()
```

C#

```
System.object GetMultiJogLeaders()
```

C++/CLI

```
System.Object^ GetMultiJogLeaders();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [multi-jog leaders](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetMultiJogLeaders](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

Use this method to obtain the array of multi-jog leaders all at once instead of calling [IView::GetFirstMultiJogLeader](#) and then repeatedly calling [IMultiJogLeader::GetNext](#) to obtain the remaining multi-jog leaders in the drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetMultiJogLeaderCount Method](#)
[IView::IGetMultiJogLeaders Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetName2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetName2 Method (IView)

Gets the name of this drawing view displayed in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName2() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.GetName2()
```

C#

```
System.string GetName2()
```

C++/CLI

```
System.String^ GetName2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetName2](#).

Example

[Activate Each View On Current Sheet \(VBA\)](#)
[Get Drawing View Names and Types \(VBA\)](#)
[Get Polylines Information \(VBA\)](#)
[Get Visible Components and Entities in Drawing View \(VBA\)](#)
[List Center Marks in Drawing \(VBA\)](#)
[Get the Number of Lines of Flat-pattern Drawing View's Boundary-box Sketch \(C#\)](#)
[Get the Number of Lines of Flat-pattern Drawing View's Boundary-box Sketch \(VB.NET\)](#)
[Get the Number of Lines of Flat-pattern Drawing View's Boundary-box Sketch \(VBA\)](#)
[Get Centerlines in Drawing \(C#\)](#)
[Get Centerlines in Drawing \(VB.NET\)](#)
[Get Centerlines In Drawing \(VBA\)](#)

Remarks

This method does not return unique names for section views. Call [IView::GetUniqueName](#) to get the unique name of a section view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::SetName2 Method](#)

Availability

GetNextView Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetNextView Method (IView)

Gets the next drawing view in the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextView() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetNextView()
```

C#

```
System.object GetNextView()
```

C++/CLI

```
System.Object^ GetNextView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [view](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetNextView](#).

Example

[Insert Spline in Drawing \(C++\)](#)
[Change Note Text \(VBA\)](#)
[Create Section View at Specified Location \(VBA\)](#)
[Dimension Edge in Drawing \(VBA\)](#)
[Get Crosshatches on View \(VBA\)](#)
[Select Entity in Drawing View \(VBA\)](#)
[Get Drawing View Names and Types \(VB.NET\)](#)
[Get Drawing View Names and Types \(C#\)](#)
[Get Drawing View Names and Types \(VBA\)](#)
[Get View Bounding Box and Position \(C#\)](#)
[Get View Bounding Box and Position \(VB.NET\)](#)
[Get View Bounding Box and Position \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetNextView Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::IGetFirstView Method](#)
[IView::GetBaseView Method](#)
[IView::IGetBaseView Method](#)

GetNoteCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetNoteCount Method (IView)

Gets the number notes in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNoteCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetNoteCount()
```

C#

```
System.int GetNoteCount()
```

C++/CLI

```
System.int GetNoteCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of notes in this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetNoteCount](#).

Example

[Get Views and Notes \(VBA\)](#)

Remarks

Call this method before calling [IView::IGetNotes](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetNotes Method](#)
[INote Interface](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNotes Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetNotes Method (IView)

Gets the notes in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNotes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetNotes()
```

C#

```
System.Object GetNotes()
```

C++/CLI

```
System.Object^ GetNotes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [notes](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetNotes](#).

Example

[Get Views and Notes \(VBA\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(C#\)](#)

Remarks

Use this method to obtain the array of notes all at once instead of calling [IView::GetFirstNote](#) and then repeatedly calling [INote::GetNext](#) to obtain the remaining notes on this drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetNoteCount Method](#)
[IView::IGetNotes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOrientationName Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetOrientationName Method (IView)

Gets the predefined name of this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOrientationName() As System.String
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim value As System.String  
  
value = instance.GetOrientationName()
```

C#

```
System.string GetOrientationName()
```

C++/CLI

```
System.String^ GetOrientationName();
```



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Predefined name of view or an empty string for unnamed views

Visual Basic for Applications (VBA) Syntax

See [View::GetOrientationName](#).

Remarks

This method returns the orientation (predefined) name of the view; e.g., *Front, *Top, *Isometric, or a user-defined view name defined in the model. This method returns an empty string ("") for section views, detail views, projected views, and unfolded views.

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic](#).

GetOutline Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetOutline Method (IView)

Gets the bounding box for a view (sheet or drawing) in meters on the drawing page.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOutline() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetOutline()
```

C#

```
System.object GetOutline()
```

C++/CLI

```
System.Object^ GetOutline();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetOutline](#).

Example

[Reposition Drawing Views to Avoid Overlap \(VBA\)](#)
[Select Entity in Drawing View \(VBA\)](#)
[Get View Bounding Box and Position \(C#\)](#)
[Get View Bounding Box and Position \(C#\)](#)
[Get View Bounding Box and Position \(VBA\)](#)

Remarks

The return value is an array of 4 doubles with the following format:

- 0, X min
- 1, Y min
- 2, X max
- 3, Y max

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetOutline Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetParabolaCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetParabolaCount Method (IView)

Gets the number of parabolas in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParabolaCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetParabolaCount()
```

C#

```
System.int GetParabolaCount()
```

C++/CLI

```
System.int GetParabolaCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of parabolas in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetParabolaCount](#).

Example

[Get Polyline Information \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetParabolas2 Method](#)
[IView::IGetParabolas2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetParabolas Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetParabolas Method (IView)

Obsolete. Superseded by [IView::GetParabolas2](#) and [IView::IGetParabolas2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetParabolas() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetParabolas()
```

C#

```
System.object GetParabolas()
```

C++/CLI

```
System.Object^ GetParabolas();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetParabolas](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetParabolas2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetParabolas2 Method (IView)

Gets all of the information about all of the parabolas in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParabolas2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetParabolas2()
```

C#

```
System.object GetParabolas2()
```

C++/CLI

```
System.Object^ GetParabolas2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetParabolas2](#).

Remarks

The return values are in an array of doubles:

[*Color*, *LineType*, *LineFont*, *LineWidth*, *LayerID*, *LayerOverride*, *StartPt*[3], *EndPt*[3], *FocusPt*[3], *ApexPt*[3]]

where:

Color = COLORREF returned as an integer. Return value could be 0 or -1 for default color.

LineType = line type. Valid returns as defined in [swLineTypes e](#). A *LineType* is a combination of a *LineStyle* and *LineWeight*.

LineFont = Value is used for polyline font information.

LineWidth = integer value defining the line width. Valid width values as defined in [swLineWeights e](#).

LayerID = integer value indicating which layer holds this entity. Obtain the [ILayer](#) object by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::!GetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

StartPt[3] = array of 3 doubles (X,Y,Z) describing the parabola start point.

EndPt[3] = array of 3 doubles (X,Y,Z) describing the parabola end point.

FocusPt[3] = array of 3 doubles (X,Y,Z) describing the parabola focus point.

ApexPt[3] = array of 3 doubles (X,Y,Z) describing the parabola apex point.

This set of data repeats for each parabola in the view. The size of the array is (NumParabolas * 18). To determine the number of parabolas, use [IView::GetParabolaCount](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::!GetParabolas2 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPolyLineCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolyLineCount Method (IView)

Obsolete. Superseded by [IView::GetPolyLineCount5](#)

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolyLineCount( _  
    ByRef PointCount As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim PointCount As System.Integer  
Dim value As System.Integer  
  
value = instance.GetPolyLineCount(PointCount)
```

C#

```
System.int GetPolyLineCount(  
    out System.int PointCount  
)
```

C++/CLI

```
System.int GetPolyLineCount(  
& [Out] System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointCount

Visual Basic for Applications (VBA) Syntax

See [View::GetPolyLineCount](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPolyLineCount2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolyLineCount2 Method (IView)

Obsolete. Superseded by [IView::GetPolyLineCount5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolyLineCount2( _  
    ByRef PointCount As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim PointCount As System.Integer  
Dim value As System.Integer  
  
value = instance.GetPolyLineCount2(PointCount)
```

C#

```
System.int GetPolyLineCount2(  
    out System.int PointCount  
)
```

C++/CLI

```
System.int GetPolyLineCount2(  
& [Out] System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointCount

Visual Basic for Applications (VBA) Syntax

See [View::GetPolyLineCount2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPolyLineCount3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolyLineCount3 Method (IView)

Obsolete. Superseded by [IView::GetPolyLineCount5](#)

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolyLineCount3( _  
    ByRef PointCount As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim PointCount As System.Integer  
Dim value As System.Integer  
  
value = instance.GetPolyLineCount3(PointCount)
```

C#

```
System.int GetPolyLineCount3(  
    out System.int PointCount  
)
```

C++/CLI

```
System.int GetPolyLineCount3(  
& [Out] System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointCount

Visual Basic for Applications (VBA) Syntax

See [View::GetPolyLineCount3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPolyLineCount4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolyLineCount4 Method (IView)

Obsolete. Superseded by [IView::GetPolyLineCount5](#)

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetPolyLineCount4( _  
    ByRef PointCount As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim PointCount As System.Integer  
Dim value As System.Integer  
  
value = instance.GetPolyLineCount4(PointCount)
```

C#

```
System.int GetPolyLineCount4(  
    out System.int PointCount  
)
```

C++/CLI

```
System.int GetPolyLineCount4(  
& [Out] System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointCount

Visual Basic for Applications (VBA) Syntax

See [View::GetPolyLineCount4](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPolyLineCount5 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolyLineCount5 Method (IView)

Gets the number of polylines in this view with an option to include or exclude crosshatch lines.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetPolyLineCount5( _  
    ByVal CrossHatchOption As System.Short, _  
    ByRef PointCount As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim CrossHatchOption As System.Short  
Dim PointCount As System.Integer  
Dim value As System.Integer  
  
value = instance.GetPolyLineCount5(CrossHatchOption, PointCount)
```

C#

```
System.int GetPolyLineCount5(  
    System.short CrossHatchOption,  
    out System.int PointCount  
)
```

C++/CLI

```
System.int GetPolyLineCount5(  
& System.short CrossHatchOption,  
& [Out] System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CrossHatchOption

Crosshatch option as defined in [swCrossHatchFilter_e](#)

PointCount

Size of array needed to allocate in doubles for [IView::IGetPolylines6](#)

Return Value

Number of polylines

Visual Basic for Applications (VBA) Syntax

See [View::GetPolyLineCount5](#).

Example

[Get Number of Polylines in Shaded Mode Drawing View \(VBA\)](#)

Remarks

Call this method before calling [IView::IGetPolylines6](#).

If...

Drawing view is in any of these modes:

- Shaded mode
- Shaded with edges mode
- Draft quality

Changes are made to the parts or assemblies shown in this drawing

Drawing is already open

Then...

This method returns 0.

Use [IView::SetDisplayMode3](#) to change Shaded or Shaded with edges mode to Wireframe, Hidden Lines Removed (HLR), or Hidden Lines Visible (HLV), and then get the number of polylines.

Polylines are only generated that are in the visible viewing bounds when the drawing is opened.

All polylines in the drawing are generated. If you open a drawing that is zoomed in to a particular region, then the polylines that are outside the zoomed region do not exist if the parts or assemblies shown in this drawing have been changed. To force the generation of all possible polyline data, call [IModelDoc2::ViewZoomtofit2](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayMode2 Method](#)
[IView::GetPolylines6 Method](#)
[IView::GetPolyLinesAndCurves Method](#)
[IView::GetPolyLinesAndCurvesCount Method](#)
[IView::IGetPolyLinesAndCurves Method](#)

Availability

GetPolylines Method (IView)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolylines Method (IView)

Obsolete. Superseded by [IView::GetPolyLines6](#) and [IView::IGetPolyLines6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolylines() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.Object

value = instance.GetPolylines()
```

C#

```
System.object GetPolylines()
```

C++/CLI

```
System.Object^ GetPolylines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetPolylines](#).

See Also

[IView Interface](#)
[IView Members](#)

GetPolylines2 Method (IView)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolylines2 Method (IView)

Obsolete. Superseded by [IView::GetPolyLines6](#) and [IView::IGetPolyLines6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolylines2() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.Object

value = instance.GetPolylines2()
```

C#

```
System.object GetPolylines2()
```

C++/CLI

```
System.Object^ GetPolylines2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetPolylines2](#).

See Also

[IView Interface](#)
[IView Members](#)