

SOLIDWORKS API (.NET VBA C#) — Reference (325/337): View (part 5 of 10)

SOLIDWORKS API Documentation (converted from CHM)

IView (part 5 of 10) (Type)

GetPolylines3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolylines3 Method (IView)

Obsolete. Superseded by [IView::GetPolyLines6](#) and [IView::IGetPolyLines6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolylines3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetPolylines3()
```

C#

```
System.object GetPolylines3()
```

C++/CLI

```
System.Object^ GetPolylines3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetPolylines3](#).

See Also

[IView Interface](#)
[IView Members](#)

GetPolylines4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolylines4 Method (IView)

Obsolete. Superseded by [IView::GetPolyLines6](#) and [IView::IGetPolyLines6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolylines4() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetPolylines4()
```

C#

```
System.object GetPolylines4()
```

C++/CLI

```
System.Object^ GetPolylines4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetPolylines4](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPolylines5 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolylines5 Method (IView)

Obsolete. Superseded by [IView::GetPolyLines6](#) and [IView::IGetPolyLines6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolylines5( _  
    ByVal CrossHatchOption As System.Short _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim CrossHatchOption As System.Short  
Dim value As System.Object  
  
value = instance.GetPolylines5(CrossHatchOption)
```

C#

```
System.object GetPolylines5(  
    System.short CrossHatchOption  
)
```

C++/CLI

```
System.Object^ GetPolylines5(  
& System.short CrossHatchOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CrossHatchOption

Visual Basic for Applications (VBA) Syntax

See [View::GetPolylines5](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPolylines6 Method (IView)

[See Also](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetPolylines6( _  
    ByVal CrossHatchOption As System.Short, _  
    ByRef Polylines As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim CrossHatchOption As System.Short  
Dim Polylines As System.Object  
Dim value As System.Object  
  
value = instance.GetPolylines6(CrossHatchOption, Polylines)
```

C#

```
System.object GetPolylines6(  
    System.short CrossHatchOption,  
    out System.object Polylines  
)
```

C++/CLI

```
System.Object^ GetPolylines6(  
& System.short CrossHatchOption,  
& [Out] System.Object^ Polylines  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CrossHatchOption

- 0 = include crosshatch lines
- 1 = exclude crosshatch lines
- 2 = include only crosshatch lines

Polylines

Array of doubles representing the lines in the view (see **Remarks**)

Return Value

Array of modeling [edges](#) corresponding to the polylines in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetPolylines6](#).

Remarks

The difference between this method and [IView::GetPolyLinesAndCurves](#) and [IView::IGetPolyLinesAndCurves](#) is that splines and ellipses returned by these methods are returned as equation parameters, which are more precise definitions.

This method returns data for all visible solid model edges in the drawing view. This includes these types of edges:

- arcs: Returned using a center point, radius, and start and stop location.
- circles: Returned using a center point, radius, and start and stop location.
- ellipses: Returned as tessellated polylines.
- splines: Returned as tessellated polylines.
- straight lines: Returned as tessellated polylines, but because the edges are straight, there is no loss of data in the approximation.

NOTE: If the view contains silhouette edges, then the polylines that render them cannot correspond to an edge because an edge does not actually exist. For example, if the third and fourth polyline in the set of polylines returned describe a silhouette edge, then array positions 4 and 5 in the edge array will be null.

This method also lets you include or exclude crosshatch lines. This method does not return data for sketch segments added by a user in the drawing view.

To get...	Call...
Size of array needed to hold this data	IView::GetPolylineCount5
Items that were sketched in this drawing view	IView::GetArcs4 and IView::IGetArcs4 IView::GetLines4 and IView::IGetLines4 IView::GetSplines3 and IView::IGetSplines3 IView::GetEllipses5 and IView::IGetEllipses5

Format of the return value is the following array of doubles:

[*Type*, *GeomDataSize*, *GeomData[]*, *LineColor*, *LineStyle*, *LineFont*, *LineWeight*, *LayerID*, *LayerOverride*, *NumPolyPoints*, [x,y,z]]

where:

Type = underlying geometry type, possible values are:

- 0 Polyline type
- 1 Arc or Circle type

GeomDataSize = number of elements in the *GeomData* array, for *Type* = 0 this will be 0.

GeomData[] = geometric data that can be used to represent the underlying geometry type. The data returned in this array is based on the underlying geometry type:

- *Type* = 0. This array is empty
- *Type* = 1. [*centerPtX*, *centerPtY*, *centerPtZ*, *startPtX*, *startPtY*, *startPtZ*, *endPtX*, *endPtY*, *endPtZ*, *normalX*, *normalY*, *normalZ*]

LineColor = polyline color. This value is determined either by the explicitly set value or by the layer that the polyline is on.

LineStyle = value combines polyline font and weight information. This value can be used as an input to [GetLineFontInfo](#) and [GetLineFontName](#). If this value is -1, then the user has probably modified the line display manually in the drawing and you should use the *LineFont* and *LineWeight* return values to recreate the exact polyline style.

LineFont = value is used for polyline font information. This value can be used as an input to the [GetLineFontInfo2](#) and [GetLineFontName2](#) functions. This value will only be valid if *LineStyle* is -1.

LineWeight = polyline weight where Thin = 0.0, Normal = 1.0, Thick = 2.0. This value will only be valid if *LineStyle* is -1.

LayerID = integer value indicating which layer holds this polyline. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) and [ILayerMgr::IGetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

NumPolyPoints = number of XYZ points found in the [x,y,z] return value

[x,y,z] = array of points used to describe the polyline. This array has *NumPolyPoints* points. This data will be returned for every polyline regardless of *Type*.

If...	Then...
Display mode of the view is: • Shaded • Shaded with Edges • Draft Quality • Fast HLR/HLV	A value is not returned. Use IView::SetDisplayMode3 to change Shaded or Shaded with Edges mode to Wireframe, Hidden Lines Removed (HLR), or Hidden Lines Visible (HLV), and then get the polylines.
Changes are made to the parts or assemblies shown in this drawing	Polylines are only generated that are in the visible viewing bounds when the drawing is opened.
Drawing is already open	All polylines in the drawing are generated. If you open a drawing that is zoomed in to a particular region, then the polylines that are outside the zoomed region do not exist if the parts or assemblies shown in this drawing have been changed. To force the generation of all possible polyline data, call IModelDoc2::ViewZoomtofit2 .

See Also

[IView Interface](#)
[IView Members](#)

[IView::GetDisplayMode2 Method](#)
[IView::IGetPolylines6 Method](#)
[IView::IGetPolyLinesAndCurves Method](#)
[IView::GetPolyLinesAndCurves Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPolylines7 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolylines7 Method (IView)

Gets all of the polylines in the view with an option to include or exclude crosshatch lines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolylines7( _  
    ByVal CrossHatchOption As System.Short, _  
    ByRef Polylines As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim CrossHatchOption As System.Short  
Dim Polylines As System.Object  
Dim value As System.Object  
  
value = instance.GetPolylines7(CrossHatchOption, Polylines)
```

C#

```
System.object GetPolylines7(  
    System.short CrossHatchOption,  
    out System.object Polylines  
)
```

C++/CLI

```
System.Object^ GetPolylines7(  
& System.short CrossHatchOption,  
& [Out] System.Object^ Polylines  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CrossHatchOption

- 0 = include crosshatch lines
- 1 = exclude crosshatch lines
- 2 = include only crosshatch lines

Polylines

Array of doubles of the lines in the view

Return Value

Array of modeling [edges](#) and [silhouette edges](#) corresponding to polylines in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetPolylines7](#).

Example

[Get Polyline Data from Drawing View \(VBA\)](#)

Remarks

The difference between this method and [IView::GetPolyLinesAndCurves](#) and [IView::IGetPolyLinesAndCurves](#) is that splines and ellipses returned by these methods are returned as equation parameters, which are more precise definitions.

This method returns data for all visible solid model edges in the drawing view. This includes these types of edges:

- arcs: Returned using a center point, radius, and start and stop location.
- circles: Returned using a center point, radius, and start and stop location.
- ellipses: Returned as tessellated polylines.
- splines: Returned as tessellated polylines.
- straight lines: Returned as tessellated polylines, but because the edges are straight, there is no loss of data in the approximation.

NOTE: If the view contains silhouette edges, then the polylines that render them cannot correspond to an edge because an edge does not actually exist. For example, if the third and fourth polyline in the set of polylines returned describe a silhouette edge, then array positions 4 and 5 in the edge array will be null.

This method also lets you include or exclude crosshatch lines. This method does not return data for sketch segments added by a user in the drawing view.

To get...	Call...
Size of array needed to hold this data	IView::GetPolylineCount5
Items that were sketched in this drawing view	IView::GetArcs4 and IView::IGetArcs4 IView::GetLines4 and IView::IGetLines4 IView::GetSplines3 and IView::IGetSplines3 IView::GetEllipses5 and IView::IGetEllipses5

Format of the return value is the following array of doubles:

[*Type*, *GeomDataSize*, *GeomData*[], *LineColor*, *LineStyle*, *LineFont*, *LineWeight*, *LayerID*, *LayerOverride*, *NumPolyPoints*, [x,y,z]]

where:

Type = underlying geometry type, possible values are:

- 0 Polyline type
- 1 Arc or Circle type

GeomDataSize = number of elements in the *GeomData* array, for *Type* = 0 this will be 0.

GeomData[] = geometric data that can be used to represent the underlying geometry type. The data returned in this array is based on the underlying geometry type:

- *Type* = 0. This array is empty
- *Type* = 1. [*centerPtX*, *centerPtY*, *centerPtZ*, *startPtX*, *startPtY*, *startPtZ*, *endPtX*, *endPtY*, *endPtZ*, *normalX*, *normalY*, *normalZ*]

LineColor = polyline color. This value is determined either by the explicitly set value or by the layer that the polyline is on.

LineStyle = value combines polyline font and weight information. This value can be used as an input to [GetLineFontInfo](#) and [GetLineFontName](#). If this value is -1, then the user has probably modified the line display manually in the drawing and you should use the *LineFont* and *LineWeight* return values to recreate the exact polyline style.

LineFont = value is used for polyline font information. This value can be used as an input to the [GetLineFontInfo2](#) and [GetLineFontName2](#) functions. This value will only be valid if *LineStyle* is -1.

LineWeight = polyline weight where Thin = 0.0, Normal = 1.0, Thick = 2.0. This value will only be valid if *LineStyle* is -1.

LayerID = integer value indicating which layer holds this polyline. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) and [ILayerMgr::IGetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

NumPolyPoints = number of XYZ points found in the [x,y,z] return value

[x,y,z] = array of points used to describe the polyline. This array has *NumPolyPoints* points. This data will be returned for every polyline regardless of *Type*.

If...	Then...
-------	---------

Display mode of the view is:	A value is not returned.
. Shaded . Shaded with Edges . Draft Quality . Fast HLR/HLV	Use IView::SetDisplayMode3 to change Shaded or Shaded with Edges mode to Wireframe, Hidden Lines Removed (HLR), or Hidden Lines Visible (HLV), and then get the polylines.
Changes are made to the parts or assemblies shown in this drawing	Polylines are only generated that are in the visible viewing bounds when the drawing is opened.
Drawing is already open	All polylines in the drawing are generated. If you open a drawing that is zoomed in to a particular region, then the polylines that are outside the zoomed region do not exist if the parts or assemblies shown in this drawing have been changed. To force the generation of all possible polyline data, call IModelDoc2::ViewZoomtofit2 .

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayMode2 Method](#)
[IView::GetPolyLinesAndCurvesCount Method](#)
[IView::IGetPolylines7 Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPolyLinesAndCurves Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolyLinesAndCurves Method (IView)

Gets the arcs, ellipses, splines, and polylines in the view with an option to include or exclude crosshatch lines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolyLinesAndCurves( _
    ByVal CrossHatchOption As System.Short _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim CrossHatchOption As System.Short
Dim value As System.Object

value = instance.GetPolyLinesAndCurves(CrossHatchOption)
```

C#

```
System.object GetPolyLinesAndCurves(
    System.short CrossHatchOption
)
```

C++/CLI

```
System.Object^ GetPolyLinesAndCurves(
    & System.short CrossHatchOption
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- CrossHatchOption*
- 0 = include crosshatch lines
 - 1 = exclude crosshatch lines

- 2 = include only crosshatch lines

Return Value

Array of lines and parameters in the view (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetPolyLinesAndCurves](#).

Remarks

The difference between this method and [IView::GetPolylines7](#) is that splines and ellipses returned by this method are returned as equation parameters, which are more precise definitions.

This method returns data for all visible solid model edges in the drawing view. This includes these types of edges:

- 1= arcs: Returned using a center point, radius, and start and stop location.
- 1 = circles: Returned using a center point, radius, and start and stop location.
- 2 = ellipses: Returned as equation parameters.
- 3 = splines: Returned as equation parameters.
- 0 = straight lines: Returned as tessellated polylines, but because the edges are straight, there is no loss of data in the approximation.

This method returns data for all visible solid model edges in the drawing view. This includes these types of edges:

- 1= arcs: Returned using a center point, radius, and start and stop location.
- 1 = circles: Returned using a center point, radius, and start and stop location.
- 2 = ellipses: Returned as tessellated polylines.
- 3 = splines: Returned as tessellated polylines.
- 0 = straight lines: Returned as tessellated polylines, but because the edges are straight, there is no loss of data in the approximation.

For each arc:

- first double gives the type
- next double gives the number of doubles required to hold arc geometry (center, startPt, endPt, normal) == 12
- next three doubles give the coordinates of center
- next three doubles give the coordinates of startPt
- next three doubles give the coordinates of endPt
- next three doubles give the coordinates of the normal
- next six doubles are line attributes:
 - *LineColor* = polyline color. This value is determined either by the explicitly set value or by the layer that the polyline is on.
 - *LineStyle* = value combines polyline font and weight information. This value can be used as an input to *GetLineFontInfo* and *GetLineFontName*. If this value is -1, then the user has probably modified the line display manually in the drawing and you should use the *LineFont* and *LineWeight* return values to recreate the exact polyline style.
 - *LineFont* = value is used for polyline font information. This value can be used as an input to the *GetLineFontInfo2* and *GetLineFontName2* functions. This value will only be valid if *LineStyle* is -1.
 - *LineWeight* = polyline weight where Thin = 0.0, Normal = 1.0, Thick = 2.0. This value will only be valid if *LineStyle* is -1.
 - *LayerID* = integer value indicating which layer holds this polyline. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#).
 - *LayerOverride* = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.
- next double is the number of points lying on the arc
- next (numPoints * 3) doubles are the coordinates of points lying on the arc

For each ellipse:

- first double gives the type
- next double gives the number of doubles required to hold ellipse geometry (center, unit vector along majorAxis, unit vector along minor axis, major radius, minor radius, startPt, endPt, normal) == 17

- next three doubles give the coordinates of center
- next three doubles give the coordinates of unit vector along major axis
- next three doubles give the coordinates of unit vector along minor axis
- next doubles gives the major radius
- next double gives the minor radius
- next three doubles give the coordinates of startPt
- next three doubles give the coordinates of endPt
- next six doubles are line attributes (see description of line attributes in previous bulleted item)
- next double is the number of points lying on the ellipse
- next (numPoints * 3) doubles are the coordinates of points lying on the ellipse

For each spline

- first double gives the type
- next double gives the number of doubles required to hold the information about the spline geometry (5 + numCtrlPts* numDims + numKnot); if the spline is rational, numDims ==4 otherwise numDims ==3
- next double gives degree = order -1
- next double gives whether the spline is rational (1) or non-rational (0)
- next double gives numDims (i.e., number of coordinates associated with each control point; if the spline is rational , these are four, else three)
- next double gives the number of control points of the spline
- next double gives the number of knots on the spline
- next (numCtlPoints*numDims) number of doubles are the coordinates of control points; each control point has numDims number of coordinates
- next "numKnots" number of doubles; the knots on the spline
- next six doubles are line attributes (see description of line attributes in previous bulleted item)
- next double is the number of points lying on the spline
- next (numPoints * 3) doubles are the coordinates of points lying on the spline
- For each polyline
 - first double gives the type
 - next double holds value 0.0 as there is no geometry information for a polyline
 - next six doubles are line attributes (see description of line attributes in previous bulleted item)
 - next double is the number of points lying on the polyline
 - next (numPoints * 3) doubles are the coordinates of points lying on the polyline

This method also lets you include or exclude crosshatch lines. This method does not return data for sketch segments added by a user in the drawing view.

To get...	Call...
Size of array needed to hold this data	IView::GetPolyLinesAndCurvesCount
Items that were sketched in this drawing view	IView::GetArcs4 IView::GetLines4 IView::GetSplines3 IView::GetEllipses5

If...	Then...
Display mode of the view is: • Shaded • Shaded with Edges • Draft Quality • Fast HLR/HLV	A value is not returned. Use IView::SetDisplayMode3 to change Shaded or Shaded with Edges mode to Wireframe, Hidden Lines Removed (HLR), or Hidden Lines Visible (HLV), and then get the polylines.

Changes are made to the parts or assemblies shown in this drawing

Polylines are only generated that are in the visible viewing bounds when the drawing is opened.

Drawing is already open

All polylines in the drawing are generated. If you open a drawing that is zoomed in to a particular region, then the polylines that are outside the zoomed region do not exist if the parts or assemblies shown in this drawing have been changed. To force the generation of all possible polyline data, call [IModelDoc2::ViewZoomtofit2](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayMode2 Method](#)
[IView::GetPolyLineCount5 Method](#)
[IView::IGetPolyLinesAndCurves Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPolyLinesAndCurvesCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetPolyLinesAndCurvesCount Method (IView)

Gets the number of lines, including arcs, ellipses, splines, and polylines, in the view with the option to include or exclude cross hatch lines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPolyLinesAndCurvesCount( _  
    ByVal CrossHatchOption As System.Short, _  
    ByRef PointCount As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim CrossHatchOption As System.Short  
Dim PointCount As System.Integer  
Dim value As System.Integer  
  
value = instance.GetPolyLinesAndCurvesCount(CrossHatchOption, PointCount)
```

C#

```
System.int GetPolyLinesAndCurvesCount(  
    System.short CrossHatchOption,  
    out System.int PointCount  
)
```

C++/CLI

```
System.int GetPolyLinesAndCurvesCount(  
& System.short CrossHatchOption,  
& [Out] System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CrossHatchOption

Crosshatch option as defined in [swCrossHatchFilter_e](#)

PointCount

Size of array to allocate in doubles for [IView::IGetPolyLinesAndCurves](#)

Return Value

Number of lines

Visual Basic for Applications (VBA) Syntax

See [View::GetPolyLinesAndCurvesCount](#).

Remarks

Call this method before calling [View::IGetPolyLinesAndCurves](#).

If...	Then...
Drawing view is in any of these modes: - Shaded mode - Shaded with edges mode - Draft quality	This method returns 0. Use View::SetDisplayMode3 to change Shaded or Shaded with edges mode to Wireframe, Hidden Lines Removed (HLR), or Hidden Lines Visible (HLV), and then get the number of polylines.
Changes are made to the parts or assemblies shown in this drawing	Polylines are only generated that are in the visible viewing bounds when the drawing is opened.
Drawing is already open	All polylines in the drawing are generated. If you open a drawing that is zoomed in to a particular region, then the polylines that are outside the zoomed region do not exist if the parts or assemblies shown in this drawing have been changed. To force the generation of all possible polyline data, call IModelDoc2::ViewZoomtofit2 .

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayMode2 Method](#)
[IView::GetPolyLineCount5 Method](#)
[IView::GetPolyLines6 Method](#)
[IView::GetPolyLinesAndCurves Method](#)
[IView::IGetPolyLines6 Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProjectionArrow Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetProjectionArrow Method (IView)

Gets the projection arrow for this projected view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProjectionArrow() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object
```

```
value = instance.GetProjectionArrow()
```

C#

```
System.object GetProjectionArrow()
```

C++/CLI

```
System.Object^ GetProjectionArrow();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Projection arrow](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetProjectionArrow](#).

Example

[Get Arrow in Projected View \(C#\)](#)
[Get Arrow in Projected View \(VB.NET\)](#)
[Get Arrow in Projected View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetProjectionArrow Method](#)
[IView::GetProjectionLineCount Method](#)
[IView::GetProjectionLines Method](#)
[IProjectionArrow::GetProjectedView Method](#)
[IProjectionArrow::IGetProjectedView Method](#)
[IView::IGetProjectionLines Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProjectionLineCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetProjectionLineCount Method (IView)

Gets the number of projection lines (arrows) in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProjectionLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetProjectionLineCount()
```

C#

```
System.int GetProjectionLineCount()
```

C++/CLI

```
System.int GetProjectionLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of projection lines in this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetProjectionLineCount](#).

Remarks

This method only works for base drawing views; it does not work for projected or auxiliary views.

Call this method before [IView::IGetProjectionLines](#) to get the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetProjectionLines Method](#)
[IView::GetProjectionArrow Method](#)
[IView::IGetProjectionArrow Method](#)
[IProjectionArrow Interface](#)

Availability

SOLIDWORKS 2007 SP2, Revision Number 15.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetProjectionLines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetProjectionLines Method (IView)

Gets the projection lines (arrows) in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProjectionLines() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetProjectionLines()
```

C#

```
System.object GetProjectionLines()
```

C++/CLI

```
System.Object^ GetProjectionLines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [projection lines](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetProjectionLines](#).

Remarks

This method only works for base drawing views; it does not work for projected or auxiliary views.

Multiple projection lines can exist in a view. This method returns the interface for each projection line so that an application such as DXF/DWG translation can create the projection lines with the base drawing view rather than creating those lines when cycling through the views and finding a projected or auxiliary view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetProjectionLineCount Method](#)
[IView::IGetProjectionLines Method](#)
[IView::IGetProjectionArrow Method](#)
[IView::GetProjectionArrow Method](#)

[IView::GetBaseView Method](#)
[IView::IGetBaseView Method](#)

Availability

SOLIDWORKS 2007 SP2, Revision Number 15.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetReferencedModelName Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetReferencedModelName Method (IView)

Gets the name of the model that is referenced in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferencedModelName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.String

value = instance.GetReferencedModelName()
```

C#

```
System.string GetReferencedModelName()
```

C++/CLI

```
System.String^ GetReferencedModelName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the model in the drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetReferencedModelName](#).

Example

[Create Layer for Selected View \(VBA\)](#)
[Get Document Referenced by Drawing View \(VBA\)](#)
[Get Excel Design Table Worksheet \(VBA\)](#)
[Traverse Drawing FeatureManager Design Tree \(VBA\)](#)
[Get Configurations Referenced in View \(C#\)](#)
[Get Configurations Referenced in View \(VB.NET\)](#)
[Get Configurations Referenced in View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::ReferencedConfiguration Property](#)
[IView::ReferencedDocument Property](#)
[IView::ReferencedConfigurationID Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRelatedTangentEdgeCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetRelatedTangentEdgeCount Method (IView)

Gets the number of visible tangent edges for the specified bendline in a [flat-pattern drawing view](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetRelatedTangentEdgeCount( _  
    ByVal BendLine As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim BendLine As System.Object  
Dim value As System.Integer  
  
value = instance.GetRelatedTangentEdgeCount(BendLine)
```

C#

```
System.int GetRelatedTangentEdgeCount(  
    System.object BendLine  
)
```

C++/CLI

```
System.int GetRelatedTangentEdgeCount(  
& System.Object^ BendLine  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BendLine

Bendline whose visible tangent edges you want (see **Remarks**)

Return Value

Array of visible tangent edges for the specified bendline

Visual Basic for Applications (VBA) Syntax

See [View::GetRelatedTangentEdgeCount](#).

Example

[Get Tangent Edges of Bendlines \(VB.NET\)](#)
[Get Tangent Edges of Bendline \(VBA\)](#)
[Get Tangent Edges of Bendlines \(C#\)](#)

Remarks

Hidden tangent edges are not returned by this method. Call [IDrawingDoc::ViewTangentEdges](#) to change the visibility of tangent edges in a drawing.

Call [IView::GetBendLineCount](#) to get the number of bendlines in a flat-pattern drawing view. Call [IView::GetBendLines](#) or [IView::IGetBendLines](#) to get an array of bendlines for a flat-pattern drawing view. Use the value returned by [IView::GetBendLineCount](#) to determine the index of the bendline in the array of bendlines you want.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetRelatedTangentEdges Method](#)
[IView::IGetRelatedTangentEdges Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetRelatedTangentEdges Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetRelatedTangentEdges Method (IView)

Gets the visible tangent edges for the specified bendline in a [flat-pattern drawing view](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetRelatedTangentEdges( _  
    ByVal BendLine As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim BendLine As System.Object  
Dim value As System.Object  
  
value = instance.GetRelatedTangentEdges(BendLine)
```

C#

```
System.object GetRelatedTangentEdges(  
    System.object BendLine  
)
```

C++/CLI

```
System.Object^ GetRelatedTangentEdges(  
& System.Object^ BendLine  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BendLine

Bendline whose visible tangent edges you want (see **Remarks**)

Return Value

Array of visible tangent edges for the specified bendline

Visual Basic for Applications (VBA) Syntax

See [View::GetRelatedTangentEdges](#).

Example

[Get Tangent Edges of Bendlines \(VB.NET\)](#)
[Get Tangent Edges of Bendlines \(VBA\)](#)
[Get Tangent Edges of Bendlines \(C#\)](#)

Remarks

Hidden tangent edges are not returned by this method. Use [IDrawingDoc::ViewTangentEdges](#) to change the visibility of tangent edges in a drawing.

Call [IView::GetBendLineCount](#) to get the number of bendlines in a flat-pattern drawing view. Call [IView::GetBendLines](#) or [IView::!GetBendLines](#) to get an array of bendlines for a flat-pattern drawing view. Use the value returned by [IView::GetBendLineCount](#) to determine the index of the bendline in the array of bendlines you want.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetRelatedTangentEdgeCount Method](#)
[IView::!GetRelatedTangentEdges Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRevisionCloudCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetRevisionCloudCount Method (IView)

Gets the number of revision cloud annotations in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRevisionCloudCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetRevisionCloudCount()
```

C#

```
System.int GetRevisionCloudCount()
```

C++/CLI

```
System.int GetRevisionCloudCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of revision cloud annotations in this view

Visual Basic for Applications (VBA) Syntax

See [View::GetRevisionCloudCount](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetFirstRevisionCloud Method \(\)](#)
[IView::IGetFirstRevisionCloud Method \(\)](#)
[IView::GetRevisionClouds Method \(\)](#)
[IView::IGetRevisionClouds Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRevisionClouds Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetRevisionClouds Method (IView)

Gets all of the revision cloud annotations in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRevisionClouds() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetRevisionClouds()
```

C#

```
System.object GetRevisionClouds()
```

C++/CLI

```
System.Object^ GetRevisionClouds();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IRevisionClouds](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetRevisionClouds](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetFirstRevisionCloud Method \(\)](#)
[IView::GetRevisionCloudCount Method \(\)](#)
[IView::IGetFirstRevisionCloud Method \(\)](#)
[IView::IGetRevisionClouds Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSection Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSection Method (IView)

Gets the section for this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSection() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSection()
```

C#

```
System.object GetSection()
```

C++/CLI

```
System.Object^ GetSection();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Section](#) for this section view

Visual Basic for Applications (VBA) Syntax

See [View::GetSection](#).

Example

[Get Section View \(VBA\)](#)
[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VBA\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetSection Method](#)
[IView::GetSectionLineCount2 Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::GetSectionLineStrings Method](#)
[IView::IGetSectionLineInfo2 Method](#)
[IView::IGetSectionLineStrings Method](#)
[IView::EnumSectionLines Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSectionLineCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSectionLineCount Method (IView)

Obsolete. Superseded by [IView::GetSectionLineCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionLineCount( _  
    ByRef Size As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Size As System.Integer  
Dim value As System.Integer  
  
value = instance.GetSectionLineCount(Size)
```

C#

```
System.int GetSectionLineCount(  
    out System.int Size  
)
```

C++/CLI

```
System.int GetSectionLineCount(  
& [Out] System.int Size  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size

Visual Basic for Applications (VBA) Syntax

See [View::GetSectionLineCount](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSectionLineCount2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSectionLineCount2 Method (IView)

Gets the number of section lines in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionLineCount2( _  
    ByRef Size As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Size As System.Integer  
Dim value As System.Integer  
  
value = instance.GetSectionLineCount2(Size)
```

C#

```
System.int GetSectionLineCount2(  
    out System.int Size  
)
```

C++/CLI

```
System.int GetSectionLineCount2(  
    & [Out] System.int Size  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size
Size, which includes an extra double per section line containing the layer ID for the section line

Return Value

Number of section lines in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetSectionLineCount2](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSection Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::GetSectionLineStrings Method](#)
[IView::IGetSection Method](#)
[IView::IGetSectionLineInfo2 Method](#)
[IView::IGetSectionLineStrings Method](#)
[IView::EnumSectionLines Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

GetSectionLineInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSectionLineInfo Method (IView)

Obsolete. Superseded by [IView::GetSectionLineInfo2](#) and [IView::GetSectionLineInfo2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionLineInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSectionLineInfo()
```

C#

```
System.object GetSectionLineInfo()
```

C++/CLI

```
System.Object^ GetSectionLineInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetSectionLineInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

GetSectionLineInfo2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSectionLineInfo2 Method (IView)

Gets all of the information about the section lines in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionLineInfo2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSectionLineInfo2()
```

C#

```
System.object GetSectionLineInfo2()
```

C++/CLI

```
System.Object^ GetSectionLineInfo2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetSectionLineInfo2](#).

Remarks

This method gets all of the information on section lines in the view. Before using this method, you can use [View::GetSectionLineCount2](#) to determine the size of the data being returned.

The return value is the following array of doubles:

```
[ numSectionLines, layer, [ numSegments, [ lineType, startPt[3], endPt[3] ], arrowStart1[3], arrowEnd1[3], arrowWidth1, arrowHeight1, arrowStyle1, arrowStart2[3], arrowEnd2[3], arrowWidth2, arrowHeight2, arrowStyle2, textPt1[3], textPt2[3], textHeight ] ]
```

where:

numSectionLines = number of section lines in this view. See also [View::GetSectionLineCount2](#).

layer = layer information.

The following set of data repeats itself for each section line in the view. The number of times the information is given is *numSectionLines*:

numSegments = number of line segments in this section line

The following three variables repeat themselves for each segment in the current section line. The number of times the information is given is *numSegments*:

lineType = linetype for this line segment. See [swLineTypes_e](#).

startPt[3] = X,Y,Z start point for the current segment of this section line.

endPt[3] = X,Y,Z end point for the current segment of this section line.

arrowStart1[3] = X,Y,Z start point for arrow head 1 on this section line.

arrowEnd1[3] = X,Y,Z end point for arrow head 1 on this section line.

arrowWidth1 = width of arrow 1 on this section line.

arrowHeight1 = height of arrow 1 on this section line.

arrowStyle1 = style of arrow 1 on this section line.

arrowStart2[3] = X,Y,Z start point for arrow head 2 on this section line.

arrowEnd2[3] = X,Y,Z end point for arrow head 2 on this section line.

arrowWidth2 = width of arrow 2 on this section line.

arrowHeight2 = height of arrow 2 on this section line.

arrowStyle2 = style of arrow 2 on this section line.

textPt1[3] = X,Y,Z point for the text location near arrow 1.

textPt2[3] = X,Y,Z point for the text location near arrow 2.

textHeight = text height in meters.

To get the actual text value, use [View::GetSectionLineStrings](#) or [View::IGetSectionLineStrings](#).

The number of line segments, line segment geometry, and line type returned depend on the drawing's display standard.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetSectionLineInfo2 Method](#)
[IView::IGetSection Method](#)
[IView::IGetSectionLines Method](#)
[IView::GetSection Method](#)
[IView::GetSectionLines Method](#)
[IView::EnumSectionLines Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

GetSectionLines Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSectionLines Method (IView)

Gets the section lines in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionLines() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSectionLines()
```

C#

```
System.object GetSectionLines()
```

C++/CLI

```
System.Object^ GetSectionLines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [section lines](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetSectionLines](#).

Example

[Get Section View \(VBA\)](#)

Remarks

This method returns the section lines regardless if the view is visible. If the view is hidden, the section lines are still returned.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IView::EnumSectionLines Method](#)
[IView::GetSection Method](#)
[IView::GetSectionLineCount2 Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::GetSectionLineStrings Method](#)
[IView::IGetSection Method](#)
[IView::IGetSectionLineInfo2 Method](#)
[IView::IGetSectionLines Method](#)
[IView::IGetSectionLineStrings Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSectionLineStrings Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSectionLineStrings Method (IView)

Gets an array of strings; each string represents the text label for a section line in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionLineStrings() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSectionLineStrings()
```

C#

```
System.Object GetSectionLineStrings()
```

C++/CLI

```
System.Object^ GetSectionLineStrings();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings with one string for each section line in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetSectionLineStrings](#).

Remarks

To determine the number of the strings returned, call [IView::GetSectionLineCount2](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::EnumSectionLines Method](#)
[IView::GetSection Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::GetSectionLines Method](#)
[IView::IGetSection Method](#)
[IView::IGetSectionLineInfo2 Method](#)
[IView::IGetSectionLines Method](#)
[IView::IGetSectionLineStrings Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSFSymbolCount Method (IView)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSFSymbolCount Method (IView)

Gets the number of surface finish symbols on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSFSymbolCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetSFSymbolCount()
```

C#

```
System.int GetSFSymbolCount()
```

C++/CLI

```
System.int GetSFSymbolCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Total number of surface finish symbols on this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetSFSymbolCount](#).

Example

[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Call this method before calling [View::IGetSFSymbols](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSFSymbols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSFSymbols Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSFSymbols Method (IView)

Gets all of the surface finish symbols in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSFSymbols() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSFSymbols()
```

C#

```
System.object GetSFSymbols()
```

C++/CLI

```
System.Object^ GetSFSymbols();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [surface finish symbols](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetSFSymbols](#).

Example

[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

Use this method to obtain the array of surface finish symbols all at once instead of calling [IView::GetFirstSFSymbol](#) and then repeatedly calling [ISFSymbol::GetNext](#) to obtain the remaining surface finish symbols in the drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSFSymbolCount Method](#)
[IView::IGetSFSymbols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketch Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSketch Method (IView)

Gets the sketch used by this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketch() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSketch()
```

C#

```
System.object GetSketch()
```

C++/CLI

```
System.Object^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetSketch](#).

Example

[Get Hatching Data \(VBA\)](#)
[Get Polyline Information \(VBA\)](#)
[Get Sketch Point's View \(VBA\)](#)
[Insert and Position DXF File in Drawing \(VBA\)](#)
[Get Area Hatch Data \(VBA\)](#)
[Get Area Hatch Data \(VB.NET\)](#)
[Get Area Hatch Data \(C#\)](#)

Remarks

Each drawing view contains an underlying sketch. The user can activate the sketch for a drawing view by double-clicking the view. Once the drawing view is active, you can add sketch directly to the view's sketch.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetSketch Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchPictureCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSketchPictureCount Method (IView)

Gets the number of sketch pictures imported to this view when a drawing is created from a part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchPictureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetSketchPictureCount()
```

C#

```
System.int GetSketchPictureCount()
```

C++/CLI

```
System.int GetSketchPictureCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch pictures in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetSketchPictureCount](#).

Remarks

Only sketch pictures orthogonal to this view are counted.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSketchPictures Method](#)
[IView::IGetSketchPictures Method](#)

Availability

GetSketchPictures Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSketchPictures Method (IView)

Gets all of the sketch pictures imported to this view when a drawing is created from a part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchPictures() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetSketchPictures()
```

C#

```
System.object GetSketchPictures()
```

C++/CLI

```
System.Object^ GetSketchPictures();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [ISketchPictures](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetSketchPictures](#).

Remarks

Only sketch pictures orthogonal to this view are returned.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSketchPictures Method](#)
[IView::GetSketchPictureCount Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetSMBoundingBoxDisplayData Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSMBoundingBoxDisplayData Method (IView)

Obsolete. Superseded by [IView::GetSMBoundingBoxDisplayData2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSMBoundingBoxDisplayData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSMBoundingBoxDisplayData()
```

C#

```
System.Object GetSMBoundingBoxDisplayData()
```

C++/CLI

```
System.Object^ GetSMBoundingBoxDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Display data](#) of boundary-box sketch of a flat-pattern drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetSMBoundingBoxDisplayData](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSMBoundingBoxDisplayData Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSMBoundingBoxDisplayData2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSMBoundingBoxDisplayData2 Method (IView)

Gets the boundary-box sketch display data of a flat-pattern drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSMBoundingBoxDisplayData2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSMBoundingBoxDisplayData2()
```

C#

```
System.Object GetSMBoundingBoxDisplayData2()
```

C++/CLI

```
System.Object^ GetSMBoundingBoxDisplayData2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Display data](#) of boundary-box sketch of a flat-pattern drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetSMBoundingBoxDisplayData2](#).

Example

[Get Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(VBA\)](#)
[Get Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(VB.NET\)](#)
[Get Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSolidHatchCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSolidHatchCount Method (IView)

Gets the number of visible solid-fill hatches in a detail, break, or crop view and the size of the array for their boundary data.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSolidHatchCount( _  
    ByRef ArraySize As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ArraySize As System.Integer  
Dim value As System.Integer  
  
value = instance.GetSolidHatchCount(ArraySize)
```

C#

```
System.int GetSolidHatchCount(  
    out System.int ArraySize  
)
```

C++/CLI

```
System.int GetSolidHatchCount(  
& [Out] System.int ArraySize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize
Number of solid-fill hatches

Return Value

Size of the array for the solid-fill hatches boundary data

Visual Basic for Applications (VBA) Syntax

See [View::GetSolidHatchCount](#).

Example

[Get Solid-fill Hatch Information \(VB.NET\)](#)
[Get Solid-fill Hatch Information \(VBA\)](#)
[Get Solid-fill Hatch Information \(C#\)](#)

Remarks

To get information about solid-fill hatches in drawing views, use [IView::GetFaceHatchCount](#), [IView::GetFaceHatches](#), and [IView::IGetFaceHatches](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSolidHatchInfo Method](#)
[IView::IGetSolidHatchInfo Method](#)
[ISketch::GetSketchHatches Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSolidHatchInfo Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSolidHatchInfo Method (IView)

Gets the boundary data for all visible solid-fill hatches in a detail, break, or crop view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSolidHatchInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSolidHatchInfo()
```

C#

```
System.object GetSolidHatchInfo()
```

C++/CLI

```
System.Object^ GetSolidHatchInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetSolidHatchInfo](#).

Example

[Get Solid-fill Hatch Information \(VB.NET\)](#)
[Get Solid-fill Hatch Information \(VBA\)](#)
[Get Solid-fill Hatch Information \(C#\)](#)

Remarks

The return value, which is an array of doubles, describes the geometry for each boundary loop in each visible solid-fill hatch in a detail or broken view. The first two array elements indicate:

- [0] 1 if the loop is an outer loop, which is the first loop in the boundary, or 0 if the loop is an inner loop in the boundary
- [1] Number of polylines in the loop

The remaining array elements describe the polyline data and include information about these types of boundary segments:

- arcs: Returned using a center point, radius, and start and stop location
- ellipses: Returned as equation parameters
- splines: Returned as equation parameters
- straight lines: Returned as tessellated polylines

The format of the remaining array elements ([2], [3] ...) of polyline data is as follows:

[*Type*, *GeomDataSize*, *GeomData[]*, *LineColor*, *LineStyle*, *LineFont*, *LineWeight*, *LayerID*, *LayerOverride*, *NumPolyPoints*, [*x,y,z*]]

where:

Type = underlying geometry type, possible values are:

- 0 = Polyline type
- 1 = Arc or Circle type

GeomDataSize = number of elements in the *GeomData* array, for *Type* = 0 this will be 0.

GeomData[] = geometric data that can be used to represent the underlying geometry type. The data returned in this array is based on the underlying geometry type:

- *Type* = 0. This array is empty
- *Type* = 1. [*centerPtX*, *centerPtY*, *centerPtZ*, *startPtX*, *startPtY*, *startPtZ*, *endPtX*, *endPtY*, *endPtZ*, *normalX*, *normalY*, *normalZ*]

LineColor = polyline color. This value is determined either by the explicitly set value or by the layer that the polyline is on.

LineStyle = value combines polyline font and weight information. This value can be used as an input to *GetLineFontInfo* and *GetLineFontName*. If this value is -1, then the user has probably modified the line display manually in the drawing and you should use the *LineFont* and *LineWeight* return values to recreate the exact polyline style.

LineFont = value is used for polyline font information. This value can be used as an input to the *GetLineFontInfo2* and *GetLineFontName2* functions. This value will only be valid if *LineStyle* is -1.

LineWeight = polyline weight where Thin = 0.0, Normal = 1.0, Thick = 2.0. This value will only be valid if *LineStyle* is -1.

LayerID = integer value indicating which layer holds this polyline. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) and [ILayerMgr::!GetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

NumPolyPoints = number of XYZ points found in the [*x,y,z*] return value.

[*x,y,z*] = array of points used to describe the polyline. This array has *NumPolyPoints* points. This data will be returned for every polyline regardless of *Type*.

To get information about solid-fill hatches in drawing views, use [IView::GetFaceHatchCount](#), [IView::GetFaceHatches](#), and [IView::!GetFaceHatches](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::!GetSolidHatchInfo Method](#)
[IView::GetSolidHatchCount Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetSplineCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSplineCount Method (IView)

Gets the number of splines in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplineCount( _  
    ByRef PointCount As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim PointCount As System.Integer  
Dim value As System.Integer  
  
value = instance.GetSplineCount(PointCount)
```

C#

```
System.int GetSplineCount(  
    out System.int PointCount  
)
```

C++/CLI

```
System.int GetSplineCount(  
& [Out] System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointCount
Number of doubles (see [IView::GetSplines3](#) or [IView::IGetSplines3](#) Remarks)

Return Value

Number of splines in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetSplineCount](#).

See Also

[IView Interface](#)

[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSplines Method (IView)

Obsolete. Superseded by [IView::GetSplines3](#) and [IView::IGetSplines3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplines() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSplines()
```

C#

```
System.Object GetSplines()
```

C++/CLI

```
System.Object^ GetSplines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetSplines](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplines2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetSplines2 Method (IView)

Obsolete. Superseded by [IView::GetSplines3](#) and [IView::IGetSplines3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplines2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetSplines2()
```

C#

```
System.Object GetSplines2()
```

C++/CLI

```
System.Object^ GetSplines2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetSplines2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplines3 Method (IView)

[See Also](#)



Gets all of the splines added by a user in the drawing view.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSplines3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetSplines3()
```

C#

```
System.Object GetSplines3()
```

C++/CLI

```
System.Object^ GetSplines3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetSplines3](#).

Remarks

This method only returns splines that were sketched by a user in this drawing view. Use [IView::GetPolylines6](#) or [IView::IGetPolylines6](#) to access the solid model's projected display data in the drawing view.

Format of return values is an array of doubles with the format:

[[*Color*, *LineType*, *LineStyleIndex*, *LineWidth*, *LayerID*, *LayerOverride*, *NumSplinePoints*, [*x,y,z*]]]

Color = COLORREF returned as an integer. Return value could be 0 or -1 for default color.

LineType = line type. Valid returns as defined in [swLineTypes_e](#). A lineType is a combination of a lineStyle and lineWeight.

LineStyleIndex = line style. Valid line styles as defined in [swLineStyles_e](#).

LineWidth = integer value defining the line width. Valid width values as defined in [swLineWeights_e](#).

LayerID = integer value indicating which layer holds this entity. Obtain the [ILayer](#) object by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::IGetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

This complete set of data repeats itself for each spline found in the view. For each spline, the array returned contains the color, line type, number of spline points in the spline, and X,Y,Z value for each of those points. Therefore, the [*x,y,z*] parameter is an array of *NumSplinePoints*, which can vary in size from spline to spline.

The [*x,y,z*] points for each spline are not the same as the points used to generate the spline. This method tessellates the spline based on the display quality and place points along the spline appropriately.

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (for example, the 0,0 origin being the lower-left corner of the sheet), then combine this data with the three return values from [IView::GetXForm](#) or [IView::IGetXForm](#).

To determine data size needed in this method, use [IView::GetSplineCount](#) or get the number of elements in the array returned by this method.

If you are using COM, then this method must be preceded by a call to [IView::GetSplineCount](#) to determine memory allocation and to perform the actual gathering of spline data.

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetSplines3 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotationCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetTableAnnotationCount Method (IView)

Gets the number of table annotations in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetTableAnnotationCount()
```

C#

```
System.int GetTableAnnotationCount()
```

C++/CLI

```
System.int GetTableAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Total number of table annotations on this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetTableAnnotationCount](#).

Remarks

Call this method before calling [IView::IGetTableAnnotations](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotations Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetTableAnnotations Method (IView)

Gets all of the table annotations on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetTableAnnotations()
```

C#

```
System.Object GetTableAnnotations()
```

C++/CLI

```
System.Object^ GetTableAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [table annotations](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetTableAnnotations](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

This method can be used to obtain the array of table annotations all at once instead of calling [IView::GetFirstTableAnnotation](#) and then repeatedly calling [ITableAnnotation::GetNext](#) to obtain the table annotations.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetTableAnnotationCount Method](#)
[IView::IGetTableAnnotations Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTemporaryAxes Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetTemporaryAxes Method (IView)

Gets the information of the temporary axes displayed in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTemporaryAxes() As System.Object
```

```
Dim instance As IView
Dim value As System.Object

value = instance.GetTemporaryAxes()
```

C#

```
System.object GetTemporaryAxes()
```

C++/CLI

```
System.Object^ GetTemporaryAxes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of double of the information about the temporary axes in this view (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetTemporaryAxes](#).

Example

[Get Temporary Axes in Each Drawing View \(VBA\)](#)

Remarks

This array contains the start and end points, in that order, of temporary axes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetTemporaryAxesCount Method](#)
[IView::IGetTemporaryAxes Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTemporaryAxesCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetTemporaryAxesCount Method (IView)

Gets the number of temporary axes in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTemporaryAxesCount() As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IView
Dim value As System.Integer

value = instance.GetTemporaryAxesCount()
```

C#

```
System.int GetTemporaryAxesCount()
```

C++/CLI

```
System.int GetTemporaryAxesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of temporary axes in this view

Visual Basic for Applications (VBA) Syntax

See [View::GetTemporaryAxesCount](#).

Example

[Get Temporary Axes in Each Drawing View \(VBA\)](#)

Remarks

Call this method before calling [IView::GetTemporaryAxes](#) to get the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUniqueName Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetUniqueName Method (IView)

Gets the unique name of this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUniqueName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.String

value = instance.GetUniqueName()
```

C#

```
System.string GetUniqueName()
```

C++/CLI

```
System.String^ GetUniqueName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of this section view

Visual Basic for Applications (VBA) Syntax

See [View::GetUniqueName](#).

Example

[Get Unique Name of Section View \(VBA\)](#)
[Get Unique Name of Section View \(VB.NET\)](#)
[Get Unique Name of Section View \(C#\)](#)

Remarks

Before selecting a specific section view using [IModelDocExtension::SelectByID2](#), call this method to get the unique name of the section view in "Drawing Viewnumber" format.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetName2 Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseParentDisplayMode Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetUseParentDisplayMode Method (IView)

Gets whether the view is using its parent settings or if it is using its own local settings.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseParentDisplayMode() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

value = instance.GetUseParentDisplayMode()
```

C#

```
System.bool GetUseParentDisplayMode()
```

C++/CLI

```
System.bool GetUseParentDisplayMode();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if view is using its parent settings, false if using its own local settings

Visual Basic for Applications (VBA) Syntax

See [View::GetUseParentDisplayMode](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayMode2 Method](#)
[IView::SetDisplayMode3 Method](#)

Availability

GetUserPoints Method (IView)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetUserPoints Method (IView)

Obsolete. Superseded by [IView::GetUserPoints2](#) and [IView::IGetUserPoints2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetUserPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetUserPoints()
```

C#

```
System.object GetUserPoints()
```

C++/CLI

```
System.Object^ GetUserPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::GetUserPoints](#).

See Also

[IView Interface](#)
[IView Members](#)

GetUserPoints2 Method (IView)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetUserPoints2 Method (IView)

Gets all of the information about all of the user points in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUserPoints2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetUserPoints2()
```

C#

```
System.object GetUserPoints2()
```

C++/CLI

```
System.Object^ GetUserPoints2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetUserPoints2](#).

Remarks

The return value is the following array of doubles:

[*Color*, *LineStyleIndex*, *LineWidth*, *LayerID*, *LayerOverride*, *ptLoc*[3] ...]

Color = COLORREF returned as an integer. Return value could be 0 or -1 for default color.

LineStyleIndex = line style. Valid line styles can be found in the [swLineStyles_e](#) enumeration.

LineWidth = integer value defining the line width. Valid width values can be found in the [swLineWeights_e](#) enumeration.

LayerID = integer value indicating which layer holds this entity. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::IGetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if LayerOverride was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

ptLoc[3] = an array of 3 doubles (X,Y,Z) describing the point location

...

This set of data repeats for each user point in the view. The size of the array is (NumPts * 8). To determine the number of points in the view, see [IView::GetUserPointsCount](#).

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (that is, the 0,0 origin being the lower-left corner of the sheet), then combine this data with the three return values from [IView::GetXForm](#) or [IView::IGetXForm](#).

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetUserPoints2 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUserPointsCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetUserPointsCount Method (IView)

Gets the number of user points in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUserPointsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer
```

```
value = instance.GetUserPointsCount()
```

C#

```
System.int GetUserPointsCount()
```

C++/CLI

```
System.int GetUserPointsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of user points found in the view

Visual Basic for Applications (VBA) Syntax

See [View::GetUserPointsCount](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetUserPoints2 Method](#)
[IView::IGetUserPoints2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetViewXform Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetViewXform Method (IView)

Gets the transform from model space origin to drawing space origin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetViewXform() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetViewXform()
```

C#

```
System.object GetViewXform()
```

C++/CLI

```
System.Object^ GetViewXform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetViewXform](#).

Remarks

The return value is formatted as the following array of 13 doubles:

- [0-8] is a 3x3 matrix of the view rotation

- [9-11] is a 1x3 vector of translation
- [12] is the scaling of the transformation

[IView::GetXform](#) and [IView::IGetXform](#) return the location of the drawing view center with respect to the drawing origin.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetViewXform Method](#)
[IView::ModelToViewTransform Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVisible Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetVisible Method (IView)

Gets the visibility of this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisible() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

value = instance.GetVisible()
```

C#

```
System.bool GetVisible()
```

C++/CLI

```
System.bool GetVisible();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the view is be visible, false if not

Visual Basic for Applications (VBA) Syntax

See [View::GetVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::SetVisible Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVisibleComponentCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetVisibleComponentCount Method (IView)

Gets the number of visible components in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleComponentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetVisibleComponentCount()
```

C#

```
System.int GetVisibleComponentCount()
```

C++/CLI

```
System.int GetVisibleComponentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of visible components

Visual Basic for Applications (VBA) Syntax

See [View::GetVisibleComponentCount](#).

Example

[Get Visible Components and Entities in Drawing View \(VBA\)](#)

Remarks

Visible components are components not completely obscured by other components in the view.

Call this method before calling [IView::IGetVisibleComponents](#) to get the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IView::EnumHiddenComponents2 Method](#)
[IView::GetVisibleComponents Method](#)
[IView::GetVisibleEntities Method](#)
[IView::GetVisibleEntityCount Method](#)
[IView::IGetVisibleEntities Method](#)
[IView::GetHiddenComponents Method](#)
[IView::EnumHiddenComponents2 Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVisibleComponents Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetVisibleComponents Method (IView)

Gets the visible components in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleComponents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
value = instance.GetVisibleComponents()
```

C#

```
System.Object GetVisibleComponents()
```

C++/CLI

```
System.Object^ GetVisibleComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Visible [components](#) in this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetVisibleComponents](#).

Example

[Get All Edges in Visible Component in Drawing View \(VBA\)](#)
[Get All Visible Components in Drawing View \(VBA\)](#)
[Get Visible Components and Entities in Drawing View \(VBA\)](#)

Remarks

Visible components are components not completely obscured by other components in the view.

NOTE: This method does not retrieve a complete component object. For example, the component returned by this method does not support [IComponent2::GetBodies3](#) (returns null). To retrieve a visible component that fully supports [IComponent2](#) methods and properties, call:

1. [IView::GetVisibleDrawingComponents](#)
2. [IDrawingComponent::Component](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetVisibleComponentCount Method](#)
[IView::GetVisibleEntities Method](#)
[IView::GetVisibleEntityCount Method](#)
[IView::IGetVisibleComponents Method](#)
[IView::IGetVisibleEntities Method](#)
[IView::GetHiddenComponents Method](#)
[IView::EnumHiddenComponents2 Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVisibleDrawingComponents Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetVisibleDrawingComponents Method (IView)

Gets all of the unobscured drawing components in this drawing view of an assembly drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleDrawingComponents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetVisibleDrawingComponents()
```

C#

```
System.Object GetVisibleDrawingComponents()
```

C++/CLI

```
System.Object^ GetVisibleDrawingComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Visible [IDrawingComponent](#)s in this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetVisibleDrawingComponents](#).

Example

'VBA

```
'-----
' Preconditions:
' 1. Open a drawing document of an assembly that contains Drawing View1
'    with one or more visible drawing components.
' 2. Open the Immediate window.
'
```

```
' Postconditions:
' 1. Gets the visible drawing components and their names.
' 2. Examine the Immediate window.
'-----
```

Option Explicit

```
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim swModelDocExt As SldWorks.ModelDocExtension
Dim swSelMgr As SldWorks.SelectionMgr
Dim swView As SldWorks.View
Dim swDrComp As SldWorks.DrawingComponent
Dim swComp As Component2
Dim vComps As Variant
Dim vBodies As Variant
Dim boolstatus As Boolean
Dim itr As Long
```

Sub main()

```
    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
    Set swModelDocExt = swModel.Extension
    Set swSelMgr = swModel.SelectionManager
    boolstatus = swModel.ActivateView("Drawing View1")
    boolstatus = swModelDocExt.SelectByID2("Drawing View1", "DRAWINGVIEW", 0, 0, 0, False, 0, Nothing, 0)
    Set swView = swSelMgr.GetSelectedObject6(1, -1)
    swModel.ClearSelection2 True
```

```
'Get all visible components in Drawing View1
vComps = swView.GetVisibleDrawingComponents
```

```
'Print the number of visible components
Debug.Print "Number of components:"
Debug.Print " " & UBound(vComps) + 1
```

```
'Iterate through the visible components and print each one's name
Debug.Print "Names of drawing view components and the referenced assembly component names:"
For itr = 0 To UBound(vComps)
    Debug.Print ""
    Set swDrComp = vComps(itr)
    Debug.Print " " & swDrComp.Name
    Set swComp = swDrComp.Component
```

```

'Print the referenced assembly component name
If Not swComp Is Nothing Then
    Debug.Print "    " & swComp.Name2
    Call swComp.GetBodies3(swAllBodies, vBodies)
End If
Next itr
End Sub

```

Example

[Get Visible Drawing Components \(VB.NET\)](#)
[Get Visible Drawing Components \(C#\)](#)

Remarks

Visible components are components not completely obscured by other components in the view.

After calling this method to retrieve the visible drawing components, use [IDrawingComponent::Component](#) to get a component object that fully supports all of the [IComponent2](#) methods and properties.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetVisibleComponents Method \(\)](#)
[IView::GetVisibleEntities2 Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVisibleEntities Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetVisibleEntities Method (IView)

Obsolete. Superseded by [IView::GetVisibleEntities2](#).

.NET Syntax

Visual Basic (Declaration)

```

Function GetVisibleEntities( _
    ByVal LpViewComponent As Component2, _
    ByVal EntityType As System.Integer _
) As System.Object

```

Visual Basic (Usage)

```

Dim instance As IView
Dim LpViewComponent As Component2
Dim EntityType As System.Integer
Dim value As System.Object

value = instance.GetVisibleEntities(LpViewComponent, EntityType)

```

C#

```

System.object GetVisibleEntities(
    Component2 LpViewComponent,
    System.int EntityType
)

```

C++/CLI



```
System.Object^ GetVisibleEntities(  
& Component2^ LpViewComponent,  
& System.int EntityType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpViewComponent
[Component](#) from which to get EntityType
EntityType
Type of entity as defined in [swViewEntityType_e](#)

Return Value

Array of the specified visible entities

Visual Basic for Applications (VBA) Syntax

See [View::GetVisibleEntities](#).

Remarks

Visible entities are only those entities not completely obscured by other entities in the view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetVisibleEntityCount Method](#)
[IView::IGetVisibleEntities Method](#)
[IView::IGetVisibleComponents Method](#)
[IView::GetVisibleComponents Method](#)
[IView::GetVisibleComponentCount Method](#)
[IView::GetHiddenComponents Method](#)
[IView::EnumHiddenComponents2 Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetVisibleEntities2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetVisibleEntities2 Method (IView)

Gets the visible entities of the specified type for the specified component in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleEntities2( _  
    ByVal LpViewComponent As Component2, _  
    ByVal EntityType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim LpViewComponent As Component2  
Dim EntityType As System.Integer  
Dim value As System.Object  
  
value = instance.GetVisibleEntities2(LpViewComponent, EntityType)
```

C#

```
System.object GetVisibleEntities2(  
    Component2 LpViewComponent,
```

```
System.int EntityType  
)
```

C++/CLI

```
System.Object^ GetVisibleEntities2(  
& Component2^ LpViewComponent,  
& System.int EntityType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpViewComponent
[Component](#) from which to get [EntityType](#)
EntityType
Type of entity as defined in [swViewEntityType_e](#)

Return Value

Array of the visible entities of [EntityType](#) in [LpViewComponent](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetVisibleEntities2](#).

Example

[Get Visible Components and Entities in Drawing View \(VBA\)](#)
[Get Visible Components and Entities in Drawing View \(VB.NET\)](#)
[Get Visible Components and Entities in Drawing View \(C#\)](#)

Remarks

Visible entities are entities that are not completely obscured by other entities in the view.

The difference between this method and the now obsolete [IView::GetVisibleEntities](#) method is that this method supports silhouette edges ([EntityType](#) = [swViewEntityType_e.swViewEntityType_SilhouetteEdge](#)).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetVisibleEntities2 Method \(\)](#)
[IView::GetVisibleEntityCount2 Method \(\)](#)
[IView::GetVisibleComponents Method \(\)](#)
[IView::GetVisibleComponentCount Method \(\)](#)
[IView::IGetVisibleComponents Method \(\)](#)
[IView::GetHiddenComponents Method \(\)](#)
[IView::EnumHiddenComponents2 Method \(\)](#)
[IView::GetVisibleDrawingComponents Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVisibleEntityCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : [GetVisibleEntityCount Method \(IView\)](#)

Obsolete. Superseded by [IView::GetVisibleEntityCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleEntityCount( _  
    ByVal LpViewComponent As Component2, _  
    ByVal EntityType As System.Integer _  
) As System.Integer
```

```
Dim instance As IView
Dim LpViewComponent As Component2
Dim EntityType As System.Integer
Dim value As System.Integer

value = instance.GetVisibleEntityCount(LpViewComponent, EntityType)
```

C#

```
System.int GetVisibleEntityCount(
    Component2 LpViewComponent,
    System.int EntityType
)
```

C++/CLI

```
System.int GetVisibleEntityCount(
    & Component2^ LpViewComponent,
    & System.int EntityType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpViewComponent

[Component](#) from which to get the visible EntityType

EntityType

Type of entity as defined in [swViewEntityType_e](#)

Return Value

Number of specified entities in LpViewComponent

Visual Basic for Applications (VBA) Syntax

See [View::GetVisibleEntityCount](#).

Remarks

Visible entities are only those entities not completely obscured by other entities in the view.

Call this method before calling [IView::IGetVisibleEntities](#) to get the size of the array for that method.

See Also

[IView Interface](#)

[IView Members](#)

[IView::GetVisibleEntities Method](#)

[IView::GetVisibleComponentCount Method](#)

[IView::GetVisibleComponents Method](#)

[IView::IGetVisibleComponents Method](#)

[IView::GetHiddenComponents Method](#)

[IView::EnumHiddenComponents2 Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0