

SOLIDWORKS API (.NET VBA C#) — Reference (326/337): View (part 6 of 10)

SOLIDWORKS API Documentation (converted from CHM)

IView (part 6 of 10) (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVisibleEntityCount2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetVisibleEntityCount2 Method (IView)

Gets the number of visible entities of the specified type for the specified component in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleEntityCount2( _  
    ByVal LpViewComponent As Component2, _  
    ByVal EntityType As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim LpViewComponent As Component2  
Dim EntityType As System.Integer  
Dim value As System.Integer  
  
value = instance.GetVisibleEntityCount2(LpViewComponent, EntityType)
```

C#

```
System.int GetVisibleEntityCount2(  
    Component2 LpViewComponent,  
    System.int EntityType  
)
```

C++/CLI

```
System.int GetVisibleEntityCount2(  
& Component2^ LpViewComponent,  
& System.int EntityType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpViewComponent
[Component](#) from which to get the visible [EntityType](#)
EntityType

Type of entity as defined in [swViewEntityType_e](#)

Return Value

Number of visible entities of [EntityType](#) in [LpViewComponent](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetVisibleEntityCount2](#).

Example

[Hide and Show All Edges in Drawing View \(C#\)](#)
[Hide and Show All Edges in Drawing View \(VB.NET\)](#)
[Hide and Show All Edges in Drawing View \(VBA\)](#)

Remarks

Visible entities are entities that are not completely obscured by other entities in the view.

Call this method to get the size of the array returned by [IView::IGetVisibleEntities2](#).

The difference between this method and the now obsolete [IView::GetVisibleEntityCount](#) method is that this method gets the correct number of silhouette edges ([EntityType](#) = [swViewEntityType_e](#).[swViewEntityType](#) [SilhouetteEdge](#)).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetVisibleEntities2 Method \(\)](#)
[IView::GetVisibleComponentCount Method \(\)](#)
[IView::GetVisibleComponents Method \(\)](#)
[IView::IGetVisibleComponents Method \(\)](#)
[IView::GetHiddenComponents Method \(\)](#)
[IView::EnumHiddenComponents2 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetWeldBeadCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetWeldBeadCount Method (IView)

Gets the number of weld beads on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWeldBeadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.GetWeldBeadCount()
```

C#

```
System.int GetWeldBeadCount()
```

C++/CLI

```
System.int GetWeldBeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Total number of weld beads on this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetWeldBeadCount](#).

Remarks

Call this method before calling [IView::IGetWeldBeads](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetWeldBeads Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetWeldBeads Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetWeldBeads Method (IView)

Gets all of the weld beads on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWeldBeads() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetWeldBeads()
```

C#

```
System.object GetWeldBeads()
```

C++/CLI

```
System.Object^ GetWeldBeads();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [weld beads](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetWeldBeads](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

Use this method to obtain the array of weld beads all at once instead of calling [IView::GetFirstWeldBead](#) and then repeatedly calling [IWeldBead::GetNext](#) to obtain the weld beads.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetWeldBeadCount Method](#)
[IView::IGetWeldBeads Method](#)
[IView::GetFirstWeldBead Method](#)
[IWeldBead::GetNext Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWeldSymbolCount Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetWeldSymbolCount Method (IView)

Gets the number of weld symbols on this drawing view.

Visual Basic (Declaration)

```
Function GetWeldSymbolCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.GetWeldSymbolCount()
```

C#

```
System.int GetWeldSymbolCount()
```

C++/CLI

```
System.int GetWeldSymbolCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Total number of weld symbols on this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetWeldSymbolCount](#).

Remarks

Call this method before calling [IView::IGetWeldSymbols](#) to determine the size of the array for that method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetWeldSymbols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetWeldSymbols Method (IView)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetWeldSymbols Method (IView)

Gets all of the weld symbols on this drawing view.

Visual Basic (Declaration)

```
Function GetWeldSymbols() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetWeldSymbols()
```

C#

```
System.object GetWeldSymbols()
```

C++/CLI

```
System.Object^ GetWeldSymbols();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [weld symbols](#)

Visual Basic for Applications (VBA) Syntax

See [View::GetWeldSymbols](#).

Example

[Get Annotations Arrays \(VBA\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(C#\)](#)

Remarks

This method can be used to obtain the array of annotations all at once instead of calling [IView::GetFirstWeldSymbol](#) and then repeatedly calling [IWeldSymbol::GetNext](#) to obtain the annotations.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetWeldSymbolCount Method](#)
[IView::IWeldSymbols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWitnessEntitiesCount Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetWitnessEntitiesCount Method (IView)

Gets the number of virtual sharp witness lines in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWitnessEntitiesCount( _  
    ByRef Size As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Size As System.Integer  
Dim value As System.Integer  
  
value = instance.GetWitnessEntitiesCount(Size)
```

C#

```
System.int GetWitnessEntitiesCount(  
    out System.int Size  
)
```

C++/CLI

```
System.int GetWitnessEntitiesCount(
& [Out] System.int Size
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size
Size of the virtual sharp witness line data array (see **Remarks**)

Return Value

Number of virtual sharp witness lines in this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::GetWitnessEntitiesCount](#).

Example

[Get Virtual Sharp Witness Line Data \(VBA\)](#)
[Get Virtual Sharp Witness Line Data \(VB.NET\)](#)
[Get Virtual Sharp Witness Line Data \(C#\)](#)

Remarks

Call this method to get the sizes of the arrays returned by [IView::GetWitnessGeomInfo](#) and [IView::IGetWitnessGeomInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWitnessGeomInfo Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetWitnessGeomInfo Method (IView)

Gets the geometry data for all of the virtual sharp witness lines in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWitnessGeomInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetWitnessGeomInfo()
```

C#

```
System.object GetWitnessGeomInfo()
```

C++/CLI

```
System.Object^ GetWitnessGeomInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetWitnessGeomInfo](#).

Example

[Get Virtual Sharp Witness Line Data \(C#\)](#)
[Get Virtual Sharp Witness Line Data \(VB.NET\)](#)
[Get Virtual Sharp Witness Line Data \(VBA\)](#)

Remarks

This method returns an array containing the following data for each virtual sharp in the view:

color_value,
[swLineStyles_e](#) option (-1 if no line style is specified),
[swLineWeights_e](#) option (-1 if no line weight is specified),
layer ID (-1 if no layer is specified),
[swLayerOverride_e](#) option,
0 (**NOTE:** 0 = witness line data),
number (m) of witness lines,
witness line 1[start_point[x,y,z], end_point[x,y,z&cd;
...
witness line m[start_point[x,y,z], end_point[x,y,z&cd;,
1 (**NOTE:** 1 = witness arc data),
number (n) of witness arcs,
witness arc 1[start_point[x,y,z], end_point[x,y,z], center_point[x,y,z], normal_point[x,y,z&cd;
...
witness arc n[start_point[x,y,z], end_point[x,y,z], center_point[x,y,z], normal_point[x,y,z&cd;]

Where:

color_value = MAX(MIN(*red_rgb_value*,255),0) + MAX(MIN(*green_rgb_value*,255),0)*16*16 +
MAX(MIN(*blue_rgb_value*,255),0)*16*16*16

Call [View::GetWitnessEntitiesCount](#) to get the size of the array returned by this method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetWitnessGeomInfo Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetXform Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : GetXform Method (IView)

Gets the matrix used for displaying this drawing view.

.NET Syntax

Visual Basic (Declaration)

Function GetXform() As System.Object

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

value = instance.GetXform()
```

C#

```
System.object GetXform()
```

C++/CLI

```
System.Object^ GetXform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 3 doubles that describe the location and scale of the drawing view (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::GetXform](#).

Remarks

The first two values returned are the X and Y locations of the view relative to the sheet origin, and the third value returned is the scale of the drawing view.

Because of a Microsoft compilation issue, the Dispatch name generated in the **swdisp.h** and **swdisp.cpp** files for the Dispatch version of this method is GetXform (with a lower-case letter f). To work around this:

- Use GetXform in your code instead of GetXForm.
- or -
- Modify the swdisp.h and swdisp.cpp files so that the declaration for GetXForm in the [IView](#) object is changed to GetXform. Remember to change it when you upgrade the SOLIDWORKS Design software.

[IView::GetViewXform](#) and [IView::IGetViewXform](#) get the transform from model space origin to drawing space origin.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetXform Method](#)
[IView::ISetXform Method](#)
[IView::SetXform Method](#)
[IView::ModelToViewTransform Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasDesignTable Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : HasDesignTable Method (IView)

Gets whether this drawing view has a design table associated with it.

.NET Syntax

Visual Basic (Declaration)

```
Function HasDesignTable() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

value = instance.HasDesignTable()
```

C#

```
System.bool HasDesignTable()
```

C++/CLI

```
System.bool HasDesignTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this drawing view has a design table, false if not

Visual Basic for Applications (VBA) Syntax

See [View::HasDesignTable](#).

Example

[Get Excel Design Table Worksheet \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDesignTableExtent Method](#)
[IView::IGetDesignTableExtent Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

HiddenEdges Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : HiddenEdges Property (IView)

Gets the hidden edges in the drawing view or sets the hidden edges in the drawing view to be visible.

.NET Syntax

Visual Basic (Declaration)

```
Property HiddenEdges As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object  
  
instance.HiddenEdges = value  
value = instance.HiddenEdges
```

C#

```
System.object HiddenEdges {get; set;}
```

C++/CLI

```
property System.Object^ HiddenEdges {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of hidden [edges](#)

Visual Basic for Applications (VBA) Syntax

See [View::HiddenEdges](#).

Example

[Hide and Show All Edges in Drawing View \(C#\)](#)
[Hide and Show All Edges in Drawing View \(VB.NET\)](#)
[Hide and Show All Edges in Drawing View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IDrawingDoc::HideEdge Method](#)
[IDrawingDoc::ShowEdge Method](#)

Availability

SOLIDWORKS 2008 SP5, Revision Number 16.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAnnotations Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetAnnotations Method (IView)

Gets the annotations in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotations( _  
    ByVal NumAnnotations As System.Integer _  
) As Annotation
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim NumAnnotations As System.Integer  
Dim value As Annotation  
  
value = instance.IGetAnnotations(NumAnnotations)
```

C#

```
Annotation IGetAnnotations(  
    System.int NumAnnotations  
)
```

C++/CLI

```
Annotation^ IGetAnnotations(  
& System.int NumAnnotations  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumAnnotations
Number of annotations

Return Value

- in-process, unmanaged C++: Pointer to an array of [annotations](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IView::GetAnnotationCount](#) before calling this method to get the value for NumAnnotations.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetAnnotations Method](#)
[IView::GetFirstAnnotation3 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetArcs Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetArcs Method (IView)

Obsolete. Superseded by [IView::GetArcs4](#) and [IView::IGetArcs4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcs() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetArcs()
```

C#

```
System.double IGetArcs()
```

C++/CLI

```
System.double IGetArcs();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetArcs](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetArcs2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetArcs2 Method (IView)

Obsolete. Superseded by [IView::GetArcs4](#) and [IView::IGetArcs4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcs2() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetArcs2()
```

C#

```
System.double IGetArcs2()
```

C++/CLI

```
System.double IGetArcs2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetArcs2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetArcs3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetArcs3 Method (IView)

Obsolete. Superseded by [IView::GetArcs4](#) and [IView::IGetArcs4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcs3() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetArcs3()
```

C#

```
System.double IGetArcs3()
```

C++/CLI

```
System.double IGetArcs3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetArcs3](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetArcs4 Method (IView)

[See Also](#)



Gets all of the information for all of the arcs added by a user in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcs4() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double

value = instance.IGetArcs4()
```

C#

```
System.double IGetArcs4()
```

C++/CLI

```
System.double IGetArcs4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

This method only returns arcs that were sketched by a user in a drawing view. Use [IView::GetPolylines6](#) or [IView::IGetPolylines6](#) to access the solid model's projected display data in the drawing view.

Return value is an array of doubles with the format:

[*Color*, *LineType*, *LineStyleIndex*, *LineWidth*, *LayerID*, *LayerOverride*, *StartPt*[3], *EndPt*[3], *CenterPt*[3], *RotDir*, ...]

where:

- *Color* - COLORREF returned as an integer. Return value could be 0 or -1 for default color.
- *LineType* - Line type. Valid returns as defined in [swLineTypes_e](#). A *LineType* is a combination of a line style and line weight.
- *LineStyleIndex* - Line style. Valid line styles as defined in [swLineStyles_e](#) enumeration.
- *LineWidth* - Integer value defining the line width. Valid width values as defined in [swLineWeights_e](#).
- *LayerID* - Integer value indicating which layer holds this entity. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::IGetLayerById](#).
- *LayerOverride* - Integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, the color and style have been specifically set for this item and may not match the default values associated with this item's layer.
- *StartPt*[3] - An array of 3 doubles (X,Y,Z) describing the start point.
- *EndPt*[3] - An array of 3 doubles (X,Y,Z) describing the end point. If the arc is closed, then *EndPt*[3] is the same point as the StartPt.
- *CenterPt*[3] - An array of 3 doubles (X,Y,Z) describing the center point.
- *RotDir* - Rotational direction (CW = -1, CCW = 1)

...

This set of data repeats for each arc in the View. The size of the array is (NumArcs * 16). To determine the number of arcs, use [IView::GetArcCount](#).

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (for example, the 0,0 origin being the lower-left corner of the sheet), then you should combine this data with the three return values from [IView::GetXForm](#) or [IView::IGetXForm](#).

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetArcs4 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBaseView Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetBaseView Method (IView)

Gets the base (parent) view used to create this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBaseView() As View
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As View  
  
value = instance.IGetBaseView()
```

C#

```
View IGetBaseView()
```

C++/CLI

```
View^ IGetBaseView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Base [view](#)

Visual Basic for Applications (VBA) Syntax

See [View::IGetBaseView](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBaseView Method](#)
[IView::GetNextView Method](#)
[IView::IGetNextView Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::IGetFirstView Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBendLines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetBendLines Method (IView)

Gets the bendlines in a [flat-pattern drawing view](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBendLines( _  
    ByVal NumberOfBendLine As System.Integer _  
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim NumberOfBendLine As System.Integer  
Dim value As SketchSegment  
  
value = instance.IGetBendLines(NumberOfBendLine)
```

C#

```
SketchSegment IGetBendLines(  
    System.int NumberOfBendLine  
)
```

C++/CLI

```
SketchSegment^ IGetBendLines(  
& System.int NumberOfBendLine  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumberOfBendLine
Number of [bendlines](#) in a flat-pattern drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of bendlines in a flat-pattern view
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IView::GetBendLineCount](#) to get NumberOfBendLine.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBendLines Method](#)
[ISketchSegment::IsBendLine Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBodies Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetBodies Method (IView)

Gets the bodies of a multibody part in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IView
Dim Count As System.Integer
Dim value As Body2

value = instance.IGetBodies(Count)
```

C#

```
Body2 IGetBodies(
    System.int Count
)
```

C++/CLI

```
Body2^ IGetBodies(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of bodies of a multibody part in the drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [bodies](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IView::GetBodiesCount](#) to get the value of Count.

See Also

[IView Interface](#)
[IView Members](#)
[IView::ISetBodies Method](#)
[IView::Bodies Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBomTable Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetBomTable Method (IView)

Gets the BOM table found in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBomTable() As BomTable
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As BomTable

value = instance.IGetBomTable()
```

C#

```
BomTable IGetBomTable()
```

C++/CLI

```
BomTable^ IGetBomTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[BOM table](#)

Visual Basic for Applications (VBA) Syntax

See [View::IGetBomTable](#).

Remarks

This method only returns a BOM table if there is a Microsoft Excel-based BOM for the drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBomTable Method](#)
[InsertBomTable Method](#)
[InsertBomTable2 Method](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOMName Method](#)
[IView::InsertBomTable Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBreakLineInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetBreakLineInfo Method (IView)

Obsolete. Superseded by [IView::IGetBreakLineInfo2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBreakLineInfo( _  
    ByVal ArraySize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ArraySize As System.Integer  
Dim value As System.Double  
  
value = instance.IGetBreakLineInfo(ArraySize)
```

C#

```
System.double IGetBreakLineInfo(  
    System.int ArraySize  
)
```

C++/CLI

```
System.double IGetBreakLineInfo(  
& System.int ArraySize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize
Number of break lines

Return Value

Array of break line information (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IGetBreakLineInfo](#).

Remarks

Before calling this method, call [View::GetBreakLineCount](#) to get the value for ArraySize.

The return value is the following array of doubles:

[*breaklineStyle*, [*color*, *lineType*, *lineStyleIndex*, *lineWeight*, *layerId*,
layerOverride, *number of lines*, *number of arcs*], *line data or arc data*]

<i>breaklineStyle</i>	Valid returns are found in swBreakLineStyle_e
<i>color</i>	COLORREF returned as an integer. Return value could be 0 or -1 for default color
<i>lineType</i>	Valid returns are found in swLineTypes_e . A lineType is a combination of a lineStyle and lineWeight.
<i>LineStyleIndex</i>	Valid line styles can be found in swLineStyles_e .
<i>lineWeight</i>	An integer value defining the line width. Valid width values can be found in swLineWeights_e .
<i>layerId</i>	An integer value indicating which layer holds this entity. The ILayer object can be obtained by passing this integer value to ILayerMgr::GetLayerById and ILayerMgr::IGetLayerId .
<i>layerOverride</i>	An integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: • color = 0x1 • style = 0x2 • width = 0x4 Therefore, if LayerOverride is returned as 3, then the color and style were specifically set for this item and may not match the default values associated with this item's layer.
Number of lines	Number of pairs of lines in the break line.
Number of arcs	Number of pairs of arcs in the break line.

Each break line is a pair of line segments:

For...	Then...
swBreakLineStraight	Each has 1 line for a total of 4 points: • LineStartPt[3] • Line1EngPt[3] • Line2StartPt[3] • Line2EndPt[3]
swBreakLineZigZag	Each has 5 lines
swBreakLine_SmallZigZag	Each has 5 lines
swBreakLine_Curve	Each has 2 arcs; data is packed as follows: • arcDirection • startPoint • EndPoint • CenterPoint

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLineInfo Method](#)
[IView::GetBreakLines Method](#)
[IView::IGetBreakLines Method](#)
[IView::IsBroken Method](#)
[IView::BreakLineGap Property](#)
[IView::InsertBreak Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBreakLineInfo2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetBreakLineInfo2 Method (IView)

Gets information for all of the break lines in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBreakLineInfo2(  
    ByVal ArraySize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ArraySize As System.Integer  
Dim value As System.Double  
  
value = instance.IGetBreakLineInfo2(ArraySize)
```

C#

```
System.double IGetBreakLineInfo2(  
    System.int ArraySize  
)
```

C++/CLI

```
System.double IGetBreakLineInfo2(  
& System.int ArraySize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize
Number of break lines

Return Value

- in-process, unmanaged C++: Pointer to an array of break line information (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IView::GetBreakLineCount2](#) to get the value for ArraySize.

The return value is a one-dimensional array consisting of the following data:

[*breakLineStyle*, *color*, *lineType*, *lineStyleIndex*, *lineWeight*, *layerId*,
layerOverride, *numLines*, *numArcs*, *numSplines*, [break line data]]

where:

breakLineStyle

Break line style as defined in [swBreakLineStyle_e](#)

<i>color</i>	COLORREF returned as an integer; 0 or -1 for default color
<i>lineType</i>	Line type as defined in swLineTypes_e ; lineType is a combination of a lineStyle and lineWeight
<i>lineStyleIndex</i>	Line style as defined in swLineStyles_e
<i>lineWeight</i>	Line width as defined in swLineWeights_e
<i>layerId</i>	An integer value indicating which layer holds this entity; ILayer can be obtained by passing this integer value to ILayerMgr::GetLayerById and ILayerMgr::IGetLayerId
<i>layerOverride</i>	An integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. Valid bit values as defined in swLayerOverride_e: • color = 0x1 • style = 0x2 • width = 0x4 Therefore, if LayerOverride is returned as 3, then the color and style are specifically set for this item; may not match the default values associated with this item's layer.
<i>numLines</i>	Number of line segments if a straight or zig zag break
<i>numArcs</i>	Number of arc lines if a curve break
<i>numSplines</i>	Number of spline lines if a jagged break

If the break line style is swBreakLineStyle_e...

swBreakLine_Straight

swBreakLine_ZigZag

swBreakLine_SmallZigZag

swBreakLine_Curve

swBreakLine_Jagged

Then [*break line data*] is packed with...

12 doubles (2 lines * 1 segment * 2 points * 3 coordinates)

60 doubles (2 lines * 5 segments * 2 points * 3 coordinates)

60 doubles (2 lines * 5 segments * 2 points * 3 coordinates)

for each arc line in the break:

- arc direction (1 double)
- start point (3 doubles)
- end point (3 doubles)
- center point (3 doubles)

for each spline line in the break:

- n (1 integer)
- $3*n$ doubles (n points * 3 coordinates)

where:

n is the number of spline points generated based on the jagged cut shape intensity selected by the user in the Break View Property Manager

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLineInfo2 Method](#)
[IView::GetBreakLines Method](#)
[IView::IGetBreakLines Method](#)
[IView::IsBroken Method](#)
[IView::BreakLineGap Property](#)
[IView::InsertBreak Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBreakLines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetBreakLines Method (IView)

Gets the all of the breaks in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBreakLines( _  
    ByVal Count As System.Integer _  
) As BreakLine
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Count As System.Integer  
Dim value As BreakLine  
  
value = instance.IGetBreakLines(Count)
```

C#

```
BreakLine IGetBreakLines(  
    System.int Count  
)
```

C++/CLI

```
BreakLine^ IGetBreakLines(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of breaks in the view

Return Value

- in-process, unmanaged C++: Pointer to an array of [breaks](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IView::GetBreakLineCount](#) to get the value for Count.

This method gets all of the breaks in the view, regardless if the view is broken. A drawing view can have break lines that are not applied. To determine whether a view is broken, use [IView::IsBroken](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLineInfo Method](#)
[IView::GetBreakLines Method](#)
[IView::IGetBreakLineInfo Method](#)
[IView::BreakLineGap Property](#)
[IView::InsertBreak Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBreakOutSections Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetBreakOutSections Method (IView)

Gets all of the broken-out sections in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBreakOutSections( _  
    ByVal Count As System.Integer _  
) As Feature
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim Count As System.Integer  
Dim value As Feature  
  
value = instance.IGetBreakOutSections(Count)
```

C#

```
Feature IGetBreakOutSections(  
    System.int Count  
)
```

C++/CLI

```
Feature^ IGetBreakOutSections(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of broken-out sections in this view

Return Value

- In-process, unmanaged C++: Pointer to an array of broken-out section [features](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IView::GetBreakOutSectionCount](#) to get the value for Count.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakOutSections Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetCenterLines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetCenterLines Method (IView)

Gets all of the centerlines on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCenterLines( _  
    ByVal NumCenterLine As System.Integer _  
) As Centerline
```

Visual Basic (Usage)



```
Dim instance As IView
Dim NumCenterLine As System.Integer
Dim value As Centerline

value = instance.IGetCenterLines(NumCenterLine)
```

C#

```
Centerline IGetCenterLines(
    System.int NumCenterLine
)
```

C++/CLI

```
Centerline^ IGetCenterLines(
    & System.int NumCenterLine
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumCenterLine
Total number of centerlines on this drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [centerlines](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of centerlines all at once instead of calling [IView::GetFirstCenterLine](#) and then repeatedly calling [ICenterLine::GetNext](#) to obtain the remaining centerlines on the drawing view.

Before calling this method, call [IView::GetCenterLineCount](#) to get the value for numCenterLine.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterLines Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetCenterMarkInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetCenterMarkInfo Method (IView)

Gets information about each center mark that is a feature in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCenterMarkInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double

value = instance.IGetCenterMarkInfo()
```

C#

```
System.double IGetCenterMarkInfo()
```

C++/CLI

```
System.double IGetCenterMarkInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IGetCenterMarkInfo](#).

Remarks

Center marks are now annotations. Previously, center marks were features. This method is only valid for center marks that are features.

The return value is the following array of doubles:

```
[ numCenterMarks, [ numCenterMarkLines, lineType1, plus1StartPt[3], plus1EndPt[3], lineType2, plus2StartPt[3], plus2EndPt[3], [ lineType, lineStartPt[3], lineEndPt[3] ] ] ]
```

where:

numCenterMarks = is the number of center marks in this view. See also [IView::GetCenterMarkCount2](#).

The following set of data repeats itself for each center mark in the view. The number of times the information is given is *numCenterMarks*:

numCenterMarkLines = number of centermark lines in the current center mark. Every center mark has at least two lines. These two lines represent the plus at the center of the circle.

lineType1 = line type associated with the first plus-sign line. See the [swLineTypes_e](#) enumeration.

plus1StartPt[3] = X,Y,Z start point of the first line in the plus sign.

plus1EndPt[3] = X,Y,Z end point of the first line in the plus sign.

lineType2 = line type associated with the second plus-sign line. See the [swLineTypes_e](#) enumeration.

plus2StartPt[3] = X,Y,Z start point of the second line in the plus sign.

plus2EndPt[3] = X,Y,Z end point of the second line in the plus sign.

This set of data also repeats itself for the remaining centermark lines in this particular center mark. The number of times this information is given is (*numCenterMarkLines* - 2):

LineType = line type associated with the second plus-sign line. See the [swLineTypes_e](#) enumeration.

lineStartPt[3] = X,Y,Z start point for this centermark line.

lineEndPt[3] = X,Y,Z end point for this centermark line.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterMarkInfo Method](#)
[IView::GetCenterMarks Method](#)
[IView::IGetCenterMarks Method](#)
[ICenterMark Interface](#)
[IView::AutoInsertCenterMarks Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetCenterMarks Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetCenterMarks Method (IView)

Gets all of the center marks that are features in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCenterMarks( _  
    ByVal Count As System.Integer _  
) As CenterMark
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Count As System.Integer  
Dim value As CenterMark  
  
value = instance.IGetCenterMarks(Count)
```

C#

```
CenterMark IGetCenterMarks(  
    System.int Count  
)
```

C++/CLI

```
CenterMark^ IGetCenterMarks(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of center marks that are features in the view

Return Value

- in-process, unmanaged C++; Pointer to an array of [centermarks](#) that are features in this view
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IView::GetCenterMarkCount2](#) to get the value for Count.

Center marks are now annotations. Previously, center marks were features. This method returns an empty array for center marks that are annotations; thus, this method is only valid for center marks that are features. See [ICenterMark](#) for details.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCenterMarkInfo Method](#)
[IView::GetCenterMarks Method](#)
[IView::IGetCenterMarkInfo Method](#)
[ICenterMark Interface](#)
[IView::AutoInsertCenterMarks Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetCThreads Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetCThreads Method (IView)

Gets all of the cosmetic threads on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCThreads( _  
    ByVal NumCThread As System.Integer _
```

) As CThread

Visual Basic (Usage)



```
Dim instance As IView  
Dim NumCThread As System.Integer  
Dim value As CThread  
  
value = instance.IGetCThreads(NumCThread)
```

C#

```
CThread IGetCThreads(  
    System.int NumCThread  
)
```

C++/CLI

```
CThread^ IGetCThreads(  
& System.int NumCThread  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumCThread

Total number of cosmetic threads on the drawing view.

Return Value

- in-process, unmanaged C++: Pointer to an array of [cosmetic threads](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of cosmetic threads all at once instead of calling [IView::GetFirstCThread](#) and then repeatedly calling [ICThread::GetNext](#) to obtain the remaining cosmetic threads on the drawing view.

Before calling this method, call [IView::GetCThreadCount](#) to get the value for numCThread.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetCThreadCount Method](#)
[IView::GetCThreads Method](#)
[IView::GetFirstCThread Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDatumOrigins Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDatumOrigins Method (IView)

Gets all of the datum origins on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDatumOrigins(  
    ByVal NumDatumOrigin As System.Integer _  
) As DatumOrigin
```

Visual Basic (Usage)



```
Dim instance As IView
Dim NumDatumOrigin As System.Integer
Dim value As DatumOrigin

value = instance.IGetDatumOrigins(NumDatumOrigin)
```

C#

```
DatumOrigin IGetDatumOrigins(
    System.int NumDatumOrigin
)
```

C++/CLI

```
DatumOrigin^ IGetDatumOrigins(
    & System.int NumDatumOrigin
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumDatumOrigin
Total number of datum origins on the drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [datum origins](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of datum origins all at once instead of calling [IView::GetFirstDatumOrigin](#) and then repeatedly calling [IDatumOrigin::GetNext](#) to obtain the remaining datum origins on this drawing view.

Before calling this method, call [IView::GetDatumOriginCount](#) to get the value for numDatumOrigin.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumOriginCount Method](#)
[IView::GetDatumOrigins Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDatumPoints Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDatumPoints Method (IView)

Obsolete. Superseded by [IView::GetDatumPoints2](#) and [IView::IGetDatumPoints2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDatumPoints() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double

value = instance.IGetDatumPoints()
```

C#

```
System.double IGetDatumPoints()
```

C++/CLI

```
System.double IGetDatumPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDatumPoints](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDatumPoints2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDatumPoints2 Method (IView)

Gets all of the information about all the datum points in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDatumPoints2() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetDatumPoints2()
```

C#

```
System.double IGetDatumPoints2()
```

C++/CLI

```
System.double IGetDatumPoints2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Return value is an array of doubles with the format:

[*Color*, *LineStyleIndex*, *LineWidth*, *LayerID*, *LayerOverride*, *ptLoc*[3] ...]

Color = COLORREF returned as an integer. Return value can be 0 or -1 for default color.

LineStyleIndex = line style. Valid line styles as defined in [swLineStyles e](#).

LineWidth = integer value defining the line width. Valid width values as defined in [swLineWeights e](#).

LayerID = integer value indicating which layer holds this entity. This integer value is the array index value into the layerList array. The layerList array can be obtained using [ILayerMgr::GetLayerList](#) or [ILayerMgr::IGetLayerList](#). A value of 1 indicates that this item is not on a layer.

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the [ILayer](#) default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style :

0x2, and width = 0x4. Therefore, if *LayerOverride* is returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

ptLoc[3] = array of 3 doubles (X,Y,Z) describing the point location

...

This entire set of data repeats for each datum point in the view. The size of the array is (NumPts * 8). To determine the number of points, use [IView::GetDatumPointsCount](#).

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (for example, the 0,0 origin being the lower-left corner of the sheet), then combine this data with the three return values from [IView::GetXForm](#) or [IView::IGetXForm](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumPoints2 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDatumTags Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDatumTags Method (IView)

Gets all the datum tags on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDatumTags( _  
    ByVal NumDatumTag As System.Integer _  
) As DatumTag
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim NumDatumTag As System.Integer  
Dim value As DatumTag  
  
value = instance.IGetDatumTags(NumDatumTag)
```

C#

```
DatumTag IGetDatumTags(  
    System.int NumDatumTag  
)
```

C++/CLI

```
DatumTag^ IGetDatumTags(  
& System.int NumDatumTag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumDatumTag
Total number of datum tags on the drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [datum tags](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of datum tags all at once instead of calling [IView::GetFirstDatumTag](#) and then repeatedly calling [IDatumTag::GetNext](#) to obtain the remaining datum tags on this drawing view.

Before calling this method, call [IView::GetDatumTagCount](#) to get the value for numDatumTag.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumTagCount Method](#)
[IView::GetDatumTags Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDatumTargetSyms Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDatumTargetSyms Method (IView)

Gets all of the datum target symbols on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDatumTargetSyms( _  
    ByVal NumDatumTargetSym As System.Integer _  
) As DatumTargetSym
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim NumDatumTargetSym As System.Integer  
Dim value As DatumTargetSym  
  
value = instance.IGetDatumTargetSyms(NumDatumTargetSym)
```

C#

```
DatumTargetSym IGetDatumTargetSyms(  
    System.int NumDatumTargetSym  
)
```

C++/CLI

```
DatumTargetSym^ IGetDatumTargetSyms(  
& System.int NumDatumTargetSym  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumDatumTargetSym

Total number of datum target symbols on the drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [datum target symbols](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of datum target symbols all at once instead of calling [IView::GetFirstDatumTargetSym](#) and then repeatedly calling [IDatumTargetSym::GetNext](#) to obtain the remaining datum target symbols on this drawing view.

Before calling this method, call [IView::GetDatumTargetSymCount](#) to get the value for numDatumTargetSym.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDatumTargetSyms Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDependentViews Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDependentViews Method (IView)

Gets either all, or only the specified, dependent views in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDependentViews( _  
    ByVal AllViews As System.Boolean, _  
    ByVal SpecificViewType As System.Integer, _  
    ByVal DependentViewCount As System.Integer _  
    ) As View
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim AllViews As System.Boolean  
Dim SpecificViewType As System.Integer  
Dim DependentViewCount As System.Integer  
Dim value As View  
  
value = instance.IGetDependentViews(AllViews, SpecificViewType, DependentViewCount)
```

C#

```
View IGetDependentViews(  
    System.bool AllViews,  
    System.int SpecificViewType,  
    System.int DependentViewCount  
)
```

C++/CLI

```
View^ IGetDependentViews(  
& System.bool AllViews,  
& System.int SpecificViewType,  
& System.int DependentViewCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AllViews
True to get all of the dependent views in this view, false to get only the SpecificViewType views in this view
SpecificViewType
Type of dependent view as defined in [swDrawingViewTypes_e](#)
DependentViewCount
Number of dependent views

Return Value

Array of dependent [views](#)

Visual Basic for Applications (VBA) Syntax

See [View::IGetDependentViews](#).

Remarks

Call [IView::GetDependentViewCount](#) before calling this method to get the value of DependentViewCount.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDependentViews Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDesignTableExtent Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDesignTableExtent Method (IView)

Gets the size and location of the design table associated with this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDesignTableExtent() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetDesignTableExtent()
```

C#

```
System.double IGetDesignTableExtent()
```

C++/CLI

```
System.double IGetDesignTableExtent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 6 doubles; the lower left (x,y,z) and upper right (x,y,z) values indicating the design table extents; values are in meters and refer to drawing view space

Visual Basic for Applications (VBA) Syntax

See [View::IGetDesignTableExtent](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::HasDesignTable Method](#)
[IView::GetDesignTableExtent Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDetail Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDetail Method (IView)

Gets the detail circle for this detail view.

 .NET Syntax

Visual Basic (Declaration)

Function IGetDetail() As DetailCircle

Visual Basic (Usage)

 Copy Code

Dim instance As [IView](#)
Dim value As DetailCircle

value = instance.IGetDetail()

C#

DetailCircle IGetDetail()

C++/CLI

DetailCircle^ IGetDetail();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Detail circle](#)

 Visual Basic for Applications (VBA) Syntax

See [View::IGetDetail](#).

 See Also

[IView Interface](#)
[IView Members](#)
[GetDetailCircleCount2 Method](#)
[IView::GetDetailCircleInfo2 Method](#)
[IView::GetDetailCircles Method](#)
[IView::GetDetailCircleStrings Method](#)
[IView::IGetDetailCircleInfo2 Method](#)
[IView::IGetDetailCircles Method](#)
[IView::IGetDetailCircleStrings Method](#)

 Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

IGetDetailCircleInfo Method (IView)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDetailCircleInfo Method (IView)

Obsolete. Superseded by [IView::GetDetailCircleInfo2](#) and [IView::IGetDetailCircleInfo2](#).

 .NET Syntax

Visual Basic (Declaration)

Function IGetDetailCircleInfo() As System.Double

Visual Basic (Usage)

 Copy Code

Dim instance As [IView](#)
Dim value As System.Double

value = instance.IGetDetailCircleInfo()

C#

```
System.double IGetDetailCircleInfo()
```

C++/CLI

```
System.double IGetDetailCircleInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDetailCircleInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDetailCircleInfo2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDetailCircleInfo2 Method (IView)

Gets all of the information about each detail circle in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDetailCircleInfo2( _  
    ByVal ArraySize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ArraySize As System.Integer  
Dim value As System.Double  
  
value = instance.IGetDetailCircleInfo2(ArraySize)
```

C#

```
System.double IGetDetailCircleInfo2(  
    System.int ArraySize  
)
```

C++/CLI

```
System.double IGetDetailCircleInfo2(  
& System.int ArraySize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize

Extra double for each detail circle; this array entity contains the layer ID for the detail circle, and it is the first entity in the array for each detail circle (see **Remarks**)

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IGetDetailCircleInfo2](#).

Remarks

The return value is the following array of doubles:

```
[ numDetailCircles, [ layer, centerPt[3], startPt[3], endPt[3], lineType, textPt[3], textHeight, numArrows, [ arrowTip[3], arrowComponent[3], arrowWidth, arrowHeight, arrowStyle ] ] ]
```

where:

numDetailCircles = the number of detail circles in this view. See also [IView::GetDetailCircleCount2](#).

The following set of data repeats itself for each detail circle in the view. The number of times the following information is given is *numDetailCircles*:

layer = integer value indicating which layer holds this entity. Obtain the [ILayer](#) object by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::IGetLayerById](#).

centerPt[3] = X,Y,Z center point for this detail circle

startPt[3] = X,Y,Z start point for this detail circle

endPt[3] = X,Y,Z end point for this detail circle

lineType = line type for this detail circle as defined in [swLineTypes_e](#)

textPt[3] = X,Y,Z point for the text location.

textHeight = text height in meters

numArrows = number of arrows for this detail circle.

The following set of data repeats itself for each arrow in the current detail circle. The number of times the following information is given is *numArrows*:

arrowTip[3] = X,Y,Z start point for this arrow head

arrowComponent[3] = X,Y,Z component for this arrow head

arrowWidth = width of this arrow head

arrowHeight = height of this arrow head

arrowStyle = style of this arrow head as defined in [swArrowStyle_e](#)

To get the actual text value, see [IView::GetDetailCircleStrings](#) or [IView::IGetDetailCircleStrings](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetDetail Method](#)
[IView::IGetDetailCircles Method](#)
[IView::GetDetail Method](#)
[IView::GetDetailCircleInfo2 Method](#)
[IView::GetDetailCircles Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDetailCircles Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDetailCircles Method (IView)

Gets the detail circles in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDetailCircles( _  
    ByVal NumDetailCircles As System.Integer _  
) As DetailCircle
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim NumDetailCircles As System.Integer  
Dim value As DetailCircle  
  
value = instance.IGetDetailCircles(NumDetailCircles)
```



C#

```
DetailCircle IGetDetailCircles(  
    System.int NumDetailCircles  
)
```

C++/CLI

```
DetailCircle^ IGetDetailCircles(  
&    System.int NumDetailCircles  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumDetailCircles

Number of detail circles in the view

Return Value

- in-process, unmanaged C++: Pointer to an array of [detail circles](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [In-process Methods](#) for details about this type of method.

Call [IView::GetDetailCircleCount2](#) to get the value for NumDetailCircles.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDetail Method](#)
[IView::GetDetailCircleInfo2 Method](#)
[IView::GetDetailCircleStrings Method](#)
[IView::IGetDetail Method](#)
[IView::IGetDetailCircleInfo2 Method](#)
[IView::IGetDetailCircleStrings Method](#)
[IView::GetDetailCircles Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDetailCircleStrings Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDetailCircleStrings Method (IView)

Gets an array of strings; each string represents the text label for a detail circle in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDetailCircleStrings() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.IGetDetailCircleStrings()
```

C#

```
System.string IGetDetailCircleStrings()
```

C++/CLI

```
System.String^ IGetDetailCircleStrings();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of strings with one string for each detail circle in the view
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [in-process Methods](#) for details about this type of method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDetail Method](#)
[IView::GetDetailCircleCount2 Method](#)
[IView::GetDetailCircleInfo2 Method](#)
[IView::GetDetailCircles Method](#)
[IView::GetDetailCircleStrings Method](#)
[IView::IGetDetail Method](#)
[IView::IGetDetailCircleInfo2 Method](#)
[IView::IGetDetailCircles Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDimensionDisplayInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayInfo Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayInfo5](#) and [IView::IGetDimensionDisplayInfo5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetDimensionDisplayInfo()
```

C#

```
System.double IGetDimensionDisplayInfo()
```

C++/CLI

```
System.double IGetDimensionDisplayInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [IView::IGetDimensionDisplayInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDimensionDisplayInfo2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayInfo2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayInfo5](#) and [IView::IGetDimensionDisplayInfo5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayInfo2() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetDimensionDisplayInfo2()
```

C#

```
System.double IGetDimensionDisplayInfo2()
```

C++/CLI

```
System.double IGetDimensionDisplayInfo2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionDisplayInfo2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDimensionDisplayInfo3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayInfo3 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayInfo5](#) and [IView::IGetDimensionDisplayInfo5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayInfo3() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetDimensionDisplayInfo3()
```

C#

```
System.double IGetDimensionDisplayInfo3()
```

C++/CLI

```
System.double IGetDimensionDisplayInfo3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionDisplayInfo3](#).

See Also

[IView Interface](#)
[IView Members](#)

IGetDimensionDisplayInfo4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayInfo4 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayInfo5](#) and [IView::IGetDimensionDisplayInfo5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayInfo4( _  
    ByVal ArraySize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ArraySize As System.Integer  
Dim value As System.Double  
  
value = instance.IGetDimensionDisplayInfo4(ArraySize)
```

C#

```
System.double IGetDimensionDisplayInfo4(  
    System.int ArraySize  
)
```

C++/CLI

```
System.double IGetDimensionDisplayInfo4(  
& System.int ArraySize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionDisplayInfo4](#).

See Also

[IView Interface](#)
[IView Members](#)

IGetDimensionDisplayInfo5 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayInfo5 Method (IView)

Gets the display dimension information for the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayInfo5( _  
    ByVal ArraySize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim ArraySize As System.Integer
Dim value As System.Double

value = instance.IGetDimensionDisplayInfo5(ArraySize)
```

C#

```
System.double IGetDimensionDisplayInfo5(
    System.int ArraySize
)
```

C++/CLI

```
System.double IGetDimensionDisplayInfo5(
    & System.int ArraySize
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize
Number of items in the array

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionDisplayInfo5](#).

Remarks

Before calling this method, call [IView::GetDimensionDisplayInfoSize2](#) to get the value for ArraySize.

The data returned is an array of doubles as follows:

```
dimensionCount, [lineCount, [lineSegmentCount [StartPt[3], endPt[3] ] ], arcCount, [arcSegmentCount, [arcCenter[3],
[StartPt[3], EndPt[3] ] ], arrowCount, [ arrowTipPt[3], arrowVector[3], arrowWidth, arrowHeight ], tolType, isDual, showParens,
textAngle, value1Pos[3], tolmax1Pos[3], tolmin1Pos[3], value2Pos[3], tolmax2Pos[3], tolmin2Pos[3], prefixPos[3], suffixPos[3],
tolbox1Corner1[3], tolbox1Corner2[3], tolbox2Corner1[3], tolbox2Corner2[3], parenArc1Start[3], parenArc1End[3],
parenArc1Center[3], parenArc1Vector[3], parenArc2Start[3], parenArc2End[3], parenArc2Center[3], parenArc2Vector[3],
callout1TextPos[3], callout2TextPos[3] ]
```

where:

dimensionCount = number of dimensions found in the drawing sheet or drawing view

For each dimension:

lineCount = number of extension and leader lines for this dimension

For each line:

StartPt[3] = array of three doubles representing the line start point

EndPt[3] = array of three doubles representing the line end point

Repeating the *StartPt*[3] and *EndPt*[3] pair up to *lineSegmentCount*

arcCount = number of leader lines which are arcs for this dimension

For each arc:

arcCenter[3] = array of three doubles representing the arc center point

StartPt[3] = array of three doubles representing the arc start point

EndPt[3] = array of three doubles representing the arc end point

Repeating the *arcCenter*[3], *StartPt*[3], and *EndPt*[3] group up to *arcSegmentCount*

arrowCount = number of arrowheads for this dimension

arrowTipPt[3] = array of three doubles representing the arrowhead tip location

arrowVector[3] = array of three doubles representing the arrow direction

arrowWidth = arrowhead width

arrowHeight = arrowhead height

Repeating the *arrowTipPt*[3], *arrowVector*[3], *arrowWidth* and *arrowHeight* group up to *arrowCount* arrowheads

tolType = tolerance type as defined in [swTolType_e](#)

isDual = True if this dimension is a dual dimension, false otherwise

showParens = True if parenthesis are shown, false otherwise

The next 25 values represent text angle and positioning. All text positions are the upper-left corner of the string.

textAngle = text angle in radians (counter clockwise from +ve x-axis)

value1Pos[3] = XYZ position of text 1; the position is the upper-left corner of the actual string

tolmax1Pos[3] = XYZ position of maximum tolerance text 1

tolmin1Pos[3] = XYZ position of minimum tolerance text 1

value2Pos[3] = XYZ position of text 2; data returned is only valid if *isDual* is true

tolmax2Pos[3] = XYZ position of maximum tolerance text 2; data returned is valid when *isDual* is true

tolmin2Pos[3] = XYZ position of minimum tolerance text 2; data returned is valid when *isDual* is true

prefixPos[3] = XYZ position of prefix text

suffixPos[3] = XYZ position of suffix text

The next 12 values represent the box corners for dimensions with swTolBASIC tolerance types:

tolbox1Corner1[3] = XYZ corner 1 of tolerance box 1

tolbox1Corner2[3] = XYZ corner 2 of tolerance box 1

tolbox2Corner1[3] = XYZ corner 1 of tolerance box 2; data returned is valid when *isDual* is true

tolbox2corner2[3] = XYZ corner 2 of tolerance box 2; data returned is valid when *isDual* is true

The next 24 values are valid when *showParens* is True; for example, when this is a reference dimension.

parenArc1Start[3] = XYZ start point of the arc representing parenthesis 1

parenArc1End[3] = XYZ end point of the arc representing parenthesis 1

parenArc1Center[3] = XYZ center point of the arc representing parenthesis 1

parenArc1Vector[3] = XYZ reference direction for the arc representing parenthesis 1

parenArc2Start[3] = XYZ start point of the arc representing parenthesis 2

parenArc2End[3] = XYZ end point of the arc representing parenthesis 2

parenArc2Center[3] = XYZ center point of the arc representing parenthesis 2

parenArc2Vector[3] = XYZ reference direction for the arc representing parenthesis 2

callout1TextPos[3] = XYZ position of first callout text (text above)

callout2TextPos[3] = XYZ position of second callout text (text below)

Repeating the entire *lineCount callout2TextPos* group up to *dimensionCount* dimensions

For example, if a particular sheet or view had two dimensions, and the first dimension had three lines, zero arcs, and two arrows, and the second dimension had two lines, one arc, and two arrows, then array returned would be as follows:

[2, **3**, line1StartPtx, y, z, line1EndPtx, y, z, line2StartPtx, y, z, line2EndPtx, y, z, line3StartPtx, y, z, line3EndPtx, y, z, **0**, **2**,
arrow1TipPtx, y, z, arrow1Vectorx, y, z, arrow1Width, arrow1Height, arrow2TipPtx, y, z, arrow2Vectorx, y, z, arrow2Width,
arrow2Height, tolType, isDual, showParens, textAngle, value1Posx, y, z, tolmax1Posx, y, z, tolmin1Posx, y, z, value2Posx, y, z,
tolmax2Posx, y, z, tolmin2Posx, y, z, prefixPosx, y, z, suffixPosx, y, z, tolbox1Corner1x, y, z, tolbox1Corner2x, y, z, tolbox2Corner1x, y, z,
tolbox2Corner2x, y, z, parenArc1Startx, y, z, parenArc1Endx, y, z, parenArc1Centerx, y, z, parenArc1Vectorx, y, z, parenArc2Startx,
y, z, parenArc2Endx, y, z, parenArc2Centerx, y, z, parenArc2Vectorx, y, z, callout1TextPosx, y, z, callout2TextPosx, y, z, **2**,
line1StartPtx, y, z, line1EndPtx, y, z, line2StartPtx, y, z, line2EndPtx, y, z, **1**, arc1Vertexx, y, z, arc1StartPtx, y, z, arc1EndPtx, y, z, **2**,
arrow1TipPtx, y, z, arrow1Vectorx, y, z, arrow1Width, arrow1Height, arrow2TipPtx, y, z, arrow2Vectorx, y, z, arrow2Width,
arrow2Height, tolType, isDual, showParens, textAngle, value1Posx, y, z, tolmax1Posx, y, z, tolmin1Posx, y, z, value2Posx, y, z,
tolmax2Posx, y, z, tolmin2Posx, y, z, prefixPosx, y, z, suffixPosx, y, z, tolbox1Corner1x, y, z, tolbox1Corner2x, y, z

where the **3**, **0**, **2** and **2**, **1**, **2** represent the number of lines, arcs and arrows for each of the two dimensions. The information for the second dimension is underlined to distinguish it from information returned for the first dimension.

This method does not support [hole callouts](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionCount4 Method](#)
[IView::GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::IGetDimensionDisplayString4 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::IGetDimensionString4 Method](#)
[IView::ProjectedDimensions Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDimensionDisplayString Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayString Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayString4](#) and [IView::IGetDimensionDisplayString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayString() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.IGetDimensionDisplayString()
```

C#

```
System.string IGetDimensionDisplayString()
```

C++/CLI

```
System.String^ IGetDimensionDisplayString();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionDisplayString](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDimensionDisplayString2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayString2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayString4](#) and [IView::IGetDimensionDisplayString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayString2() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.IGetDimensionDisplayString2()
```

C#

```
System.string IGetDimensionDisplayString2()
```

C++/CLI

```
System.String^ IGetDimensionDisplayString2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionDisplayString2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDimensionDisplayString3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayString3 Method (IView)

Obsolete. Superseded by [IView::GetDimensionDisplayString4](#) and [IView::IGetDimensionDisplayString4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayString3() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.IGetDimensionDisplayString3()
```

C#

```
System.string IGetDimensionDisplayString3()
```

C++/CLI

```
System.String^ IGetDimensionDisplayString3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionDisplayString3](#).

See Also

[IView Interface](#)
[IView Members](#)

IGetDimensionDisplayString4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionDisplayString4 Method (IView)

Gets all of the dimension text in the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionDisplayString4() As System.String
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.String

value = instance.IGetDimensionDisplayString4()
```

C#

```
System.string IGetDimensionDisplayString4()
```

C++/CLI

```
System.String^ IGetDimensionDisplayString4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings containing the dimension text (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionDisplayString4](#).

Remarks

For each dimension in the drawing sheet or drawing view, this method returns 10 strings. If any of the dimension strings are not used, then those strings are returned as empty strings.

[*value1, tolMax1 tolMin1, value2, tolMax2, tolMin2, prefix, suffix, callout1, callout2*]

This set of data is returned for each dimension in the view. See [IView::GetDimensionCount4](#) to determine the number of dimensions in the drawing sheet or drawing view.

NOTES:

- A previous version of this method, [IView::GetDimensionDisplayString2](#) or [IView::IGetDimensionDisplayString2](#), detects and overlooks dangling dimensions. These method, [IView::GetDimensionDisplayString4](#) and [IView::IGetDimensionDisplayString4](#), do not overlook nor do they indicate that any dimensions are dangling. Use [IView::GetDimensionDisplayString2](#) if you need dangling dimensions detected and overlooked.
- This method does not support [hole callouts](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionCount4 Method](#)
[IView::GetDimensionDisplayInfo5 Method](#)
[IView::GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::IGetDimensionDisplayInfo5 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::IGetDimensionString4 Method](#)
[IView::ProjectedDimensions Property](#)
[IView::GetFirstDisplayDimension5 Method](#)

Availability

IGetDimensionIds Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionIds Method (IView)

Obsolete. Superseded by [IView::GetDimensionIds4](#) and [IView::IGetDimensionIds4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionIds() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.IGetDimensionIds()
```

C#

```
System.string IGetDimensionIds()
```

C++/CLI

```
System.String^ IGetDimensionIds();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionIds](#).

See Also

[IView Interface](#)
[IView Members](#)

IGetDimensionIds2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionIds2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionIds4](#) and [IView::IGetDimensionIds4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionIds2() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.IGetDimensionIds2()
```

C#

```
System.string IGetDimensionIds2()
```

C++/CLI

```
System.String^ IGetDimensionIds2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionIds2](#).

See Also

[View Interface](#)
[View Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDimensionIds3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionIds3 Method (IView)

Obsolete. Superseded by [IView::GetDimensionIds4](#) and [IView::IGetDimensionIds4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionIds3() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.IGetDimensionIds3()
```

C#

```
System.string IGetDimensionIds3()
```

C++/CLI

```
System.String^ IGetDimensionIds3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionIds3](#).

See Also

[View Interface](#)
[View Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDimensionIds4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionIds4 Method (IView)

Gets the dimension names from the current drawing sheet or the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionIds4() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String
```

```
value = instance.IGetDimensionIds4()
```

C#

```
System.string IGetDimensionIds4()
```

C++/CLI

```
System.String^ IGetDimensionIds4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of strings; each string represents one dimension name from the current drawing sheet or current drawing view
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The order of the dimension names returned align with the order of information returned from [IView::GetDimensionInfo6](#) or [IView::IGetDimensionInfo6](#). This alignment of information is valid as long as the calls to this method and [IView::GetDimensionInfo6](#) or [IView::IGetDimensionInfo6](#) are made consecutively.

One string is returned for each dimension in the view. See [IView::GetDimensionCount4](#) to determine the number of dimensions in the view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionDisplayInfo5 Method](#)
[GetDimensionDisplayInfoSize2 Method](#)
[IView::GetDimensionDisplayString4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::GetFirstDisplayDimension5 Method](#)
[IView::IGetDimensionDisplayInfo5 Method](#)
[IView::IGetDimensionDisplayString4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::IGetDimensionString4 Method](#)
[IView::ProjectedDimensions Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDimensionInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : [IGetDimensionInfo Method \(IView\)](#)

Obsolete. Superseded by [IView::GetDimensionInfo6](#) and [IView::IGetDimensionInfo6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionInfo() As System.Double
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetDimensionInfo()
```

C#

```
System.double IGetDimensionInfo()
```

C++/CLI

```
System.double IGetDimensionInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDimensionInfo2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetDimensionInfo2 Method (IView)

Obsolete. Superseded by [IView::GetDimensionInfo6](#) and [IView::IGetDimensionInfo6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensionInfo2() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetDimensionInfo2()
```

C#

```
System.double IGetDimensionInfo2()
```

C++/CLI

```
System.double IGetDimensionInfo2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetDimensionInfo2](#).

See Also

[IView Interface](#)
[IView Members](#)