

SOLIDWORKS API (.NET VBA C#) — Reference (328/337): View (part 8 of 10)

SOLIDWORKS API Documentation (converted from CHM)

IView (part 8 of 10) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetProjectionLines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetProjectionLines Method (IView)

Gets the projection lines (arrows) in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetProjectionLines( _  
    ByVal Count As System.Integer _  
) As ProjectionArrow
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Count As System.Integer  
Dim value As ProjectionArrow  
  
value = instance.IGetProjectionLines(Count)
```

C#

```
ProjectionArrow IGetProjectionLines(  
    System.int Count  
)
```

C++/CLI

```
ProjectionArrow^ IGetProjectionLines(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of projection lines

Return Value

- in-process, unmanaged C++: Pointer to an array of [projection lines](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This method only works for base drawing views; it does not work for projected or auxiliary views.

Multiple projection lines can exist in a view. This method returns the interface for each projection line so that an application such as DXF/DWG translation can create the projection lines with the base drawing view rather than creating those lines when cycling through the views and finding a projected or auxiliary view.

Before calling this method, call [IView::GetProjectionLineCount](#) to get the value for Count.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetProjectionLines Method](#)
[IView::GetProjectionArrow Method](#)
[IView::GetBaseView Method](#)
[IView::IGetBaseView Method](#)
[IView::IGetProjectionArrow Method](#)

Availability

IGetRelatedTangentEdges Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetRelatedTangentEdges Method (IView)

Gets the visible tangent edges for the specified bendline in a [flat-pattern drawing view](#).

VB.NET Syntax

Visual Basic (Declaration)

```
Function IGetRelatedTangentEdges( _
    ByVal BendLine As SketchSegment, _
    ByVal NumOfTangentEdges As System.Integer _
) As Edge
```

Visual Basic (Usage)



```
Dim instance As IView
Dim BendLine As SketchSegment
Dim NumOfTangentEdges As System.Integer
Dim value As Edge

value = instance.IGetRelatedTangentEdges(BendLine, NumOfTangentEdges)
```

C#

```
Edge IGetRelatedTangentEdges(
    SketchSegment BendLine,
    System.int NumOfTangentEdges
)
```

C++/CLI

```
Edge^ IGetRelatedTangentEdges(
    & SketchSegment^ BendLine,
    & System.int NumOfTangentEdges
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BendLine

Bendline whose visible tangent edges you want (see **Remarks**)

NumOfTangentEdges

Number of visible tangent edges for the specified bendline

Return Value

- in-process, unmanaged C++: Pointer to an array of visible tangent [edges](#) for the specified bendline
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IView::GetRelatedTangentEdgeCount](#) to get NumOfTangentEdges.

Hidden tangent edges are not returned by this method. Call [IDrawingDoc::ViewTangentEdges](#) to change the visibility of tangent edges in a drawing.

Call [IView::GetBendLineCount](#) to get the number of bendlines in a flat-pattern drawing view. Call [IView::GetBendLines](#) or [IView::IGetBendLines](#) to get an array of bendlines for a flat-pattern drawing view. Use the value returned by IView::GetBendLineCount to determine the index of the bendline in the array of bendlines you want.

See Also

[IView Interface](#)

[IView Members](#)

[IView::GetRelatedTangentEdges Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetRevisionClouds Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetRevisionClouds Method (IView)

Gets all of the revision cloud annotations in this view.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetRevisionClouds( _  
    ByVal NumRevClouds As System.Integer _  
) As RevisionCloud
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim NumRevClouds As System.Integer  
Dim value As RevisionCloud  
  
value = instance.IGetRevisionClouds(NumRevClouds)
```

C#

```
RevisionCloud IGetRevisionClouds(  
    System.int NumRevClouds  
)
```

C++/CLI

```
RevisionCloud^ IGetRevisionClouds(  
& System.int NumRevClouds  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumRevClouds

Number of revision cloud annotations in this view (see **Remarks**)

Return Value

- in-process, unmanaged C++: Pointer to an array of [revision cloud annotations](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IView::GetRevisionCloudCount](#) to populate NumRevClouds.

See Also

[IView Interface](#)

[IView Members](#)

[IView::GetFirstRevisionCloud Method \(\)](#)

[IView::GetRevisionClouds Method \(\)](#)

[IView::IGetFirstRevisionCloud Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSection Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSection Method (IView)

Gets the section for this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSection() As DrSection
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As DrSection

value = instance.IGetSection()
```

C#

```
DrSection IGetSection()
```

C++/CLI

```
DrSection^ IGetSection();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Section](#) for this section view

Visual Basic for Applications (VBA) Syntax

See [View::IGetSection](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::EnumSectionLines Method](#)
[IView::GetSection Method](#)
[IView::GetSectionLineCount2 Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::GetSectionLineStrings Method](#)
[IView::IGetSectionLineInfo2 Method](#)
[IView::IGetSectionLines Method](#)
[IView::IGetSectionLineStrings Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSectionLineInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSectionLineInfo Method (IView)

Obsolete. Superseded by [IView::GetSectionLineInfo2](#) and [IView::GetSectionLineInfo2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSectionLineInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double
```

```
value = instance.IGetSectionLineInfo()
```

C#

```
System.double IGetSectionLineInfo()
```

C++/CLI

```
System.double IGetSectionLineInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetSectionLineInfo](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSectionLineInfo2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSectionLineInfo2 Method (IView)

Gets all of the information about the section lines in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSectionLineInfo2( _  
    ByVal ArraySize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ArraySize As System.Integer  
Dim value As System.Double  
  
value = instance.IGetSectionLineInfo2(ArraySize)
```

C#

```
System.double IGetSectionLineInfo2(  
    System.int ArraySize  
)
```

C++/CLI

```
System.double IGetSectionLineInfo2(  
&    System.int ArraySize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize
Number of section lines

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IGetSectionLineInfo2](#).

Remarks

This method gets all of the information on section lines in the view. Before using this method, call [IView::GetSectionLineCount2](#) to get the value for ArraySize.

The return value is the following array of doubles:

```
[ numSectionLines, layer, [ numSegments, [ lineType, startPt[3], endPt[3] ], arrowStart1[3], arrowEnd1[3], arrowWidth1, arrowHeight1, arrowStyle1, arrowStart2[3], arrowEnd2[3], arrowWidth2, arrowHeight2, arrowStyle2, textPt1[3], textPt2[3], textHeight ] ]
```

where:

numSectionLines = number of section lines in this view. See also [IView::GetSectionLineCount2](#).

layer = layer information.

The following set of data repeats itself for each section line in the view. The number of times the information is given is numSectionLines:

numSegments = number of line segments in this section line

The following three variables repeat themselves for each segment in the current section line. The number of times the information is given is numSegments:

lineType = linetype for this line segment. See [swLineTypes_e](#).

startPt[3] = X,Y,Z start point for the current segment of this section line.

endPt[3] = X,Y,Z end point for the current segment of this section line.

arrowStart1[3] = X,Y,Z start point for arrow head 1 on this section line.

arrowEnd1[3] = X,Y,Z end point for arrow head 1 on this section line.

arrowWidth1 = width of arrow 1 on this section line.

arrowHeight1 = height of arrow 1 on this section line.

arrowStyle1 = style of arrow 1 on this section line.

arrowStart2[3] = X,Y,Z start point for arrow head 2 on this section line.

arrowEnd2[3] = X,Y,Z end point for arrow head 2 on this section line.

arrowWidth2 = width of arrow 2 on this section line.

arrowHeight2 = height of arrow 2 on this section line.

arrowStyle2 = style of arrow 2 on this section line.

textPt1[3] = X,Y,Z point for the text location near arrow 1.

textPt2[3] = X,Y,Z point for the text location near arrow 2.

textHeight = text height in meters.

To get the actual text value, use [IView::GetSectionLineStrings](#) or [IView::IGetSectionLineStrings](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSection Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::GetSectionLines Method](#)
[IView::EnumSectionLines Method](#)
[IView::IGetSection Method](#)
[IView::IGetSectionLines Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSectionLines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSectionLines Method (IView)

Gets the section lines in the view.

.NET Syntax

Visual Basic (Declaration)

Function IGetSectionLines() As DrSection

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As DrSection
```

```
value = instance.IGetSectionLines()
```

C#

```
DrSection IGetSectionLines()
```

C++/CLI

```
DrSection^ IGetSectionLines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [section lines](#)
- VB.NET, C#, or C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This method returns the section lines regardless if the view is visible. If the view is hidden, then section lines are still returned.

See Also

[IView Interface](#)
[IView Members](#)
[IView::EnumSectionLines Method](#)
[IView::GetSection Method](#)
[IView::GetSectionLineCount2 Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::GetSectionLineStrings Method](#)
[IView::IGetSection Method](#)
[IView::IGetSectionLineInfo2 Method](#)
[IView::IGetSectionLineStrings Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSectionLineStrings Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSectionLineStrings Method (IView)

Gets an array of strings; each string represents the text label for a section line in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSectionLineStrings() As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String
```

```
value = instance.IGetSectionLineStrings()
```

C#

```
System.string IGetSectionLineStrings()
```

```
System.String^ IGetSectionLineStrings();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of strings with one string for each section line in the view
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

To determine the number of the strings returned, call [IView::GetSectionLineCount2](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::EnumSectionLines Method](#)
[IView::GetSection Method](#)
[IView::GetSectionLineCount2 Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::GetSectionLines Method](#)
[IView::IGetSection Method](#)
[IView::IGetSectionLineInfo2 Method](#)
[IView::IGetSectionLines Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSFSymbols Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSFSymbols Method (IView)

Gets all of the surface finish symbols in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSFSymbols( _
    ByVal NumSFSymbol As System.Integer _
) As SFSymbol
```

Visual Basic (Usage)



```
Dim instance As IView
Dim NumSFSymbol As System.Integer
Dim value As SFSymbol

value = instance.IGetSFSymbols(NumSFSymbol)
```

C#

```
SFSymbol IGetSFSymbols(
    System.int NumSFSymbol
)
```

C++/CLI

```
SFSymbol^ IGetSFSymbols(
    & System.int NumSFSymbol
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumSFSymbol
Total number of surface finish symbols this drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [surface finish symbols](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of multi-jog leaders all at once instead of calling [IView::GetFirstSFSymbol](#) and then repeatedly calling [ISFSymbol::GetNext](#) to obtain the remaining multi-jog leaders in the drawing view.

Before calling this method, call [IView::GetSFSymbolCount](#) to get the value for numSFSymbol.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSFSymbols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSketch Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSketch Method (IView)

Gets the sketch used by this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSketch() As Sketch
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As Sketch
```

```
value = instance.IGetSketch()
```

C#

```
Sketch IGetSketch()
```

C++/CLI

```
Sketch^ IGetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [View::IGetSketch](#).

Remarks

Each drawing view contains an underlying sketch. The user can activate the sketch for a drawing view by double-clicking the view. Once the drawing view is active, you can add sketch directly to the view's sketch.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSketch Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSketchPictures Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSketchPictures Method (IView)

Gets all of the sketch pictures imported to this view when a drawing is created from a part.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSketchPictures( _  
    ByVal Count As System.Integer _  
) As SketchPicture
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Count As System.Integer  
Dim value As SketchPicture  
  
value = instance.IGetSketchPictures(Count)
```

C#

```
SketchPicture IGetSketchPictures(  
    System.int Count  
)
```

C++/CLI

```
SketchPicture^ IGetSketchPictures(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of sketch pictures in this view

Return Value

- in-process, unmanaged C++: Pointer to an array of [ISketchPictures](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use [IView::GetSketchPictureCount](#) to populate the Count parameter before calling this method. Only sketch pictures orthogonal to this view are returned.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSketchPictures Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSMBoundingBoxDisplayData Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSMBoundingBoxDisplayData Method (IView)

Gets the boundary-box sketch display data of a flat-pattern drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSMBoundingBoxDisplayData() As DisplayData
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As DisplayData  
  
value = instance.IGetSMBoundingBoxDisplayData()
```

C#

```
DisplayData IGetSMBoundingBoxDisplayData()
```

C++/CLI

```
DisplayData^ IGetSMBoundingBoxDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Display data](#) of boundary-box sketch of a flat-pattern drawing view

Visual Basic for Applications (VBA) Syntax

See [View::IGetSMBoundingBoxDisplayData](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetSMBoundingBoxDisplayData Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSolidHatchInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSolidHatchInfo Method (IView)

Gets the boundary data for all visible solid-fill hatches in a detail, break, or crop view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSolidHatchInfo( _  
    ByVal ArraySize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ArraySize As System.Integer  
Dim value As System.Double  
  
value = instance.IGetSolidHatchInfo(ArraySize)
```

C#

```
System.double IGetSolidHatchInfo(  
    System.int ArraySize  
)
```

C++/CLI

```
System.double IGetSolidHatchInfo(  
& System.int ArraySize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize

Size of array to allocate for the boundary data as determined by [IView::GetSolidHatchCount](#)

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The return value, which is an array of doubles, describes the geometry for each hatch boundary loop in each visible solid-fill hatch in a detail or broken view. The first two array elements indicate:

- [0] 1 if the loop is an outer loop, which is the first loop in the boundary, or 0 if the loop is an inner loop in the boundary
- [1] Number of polylines in the loop

The remaining array elements describe the polyline data and include information about these types of boundary segments:

- arcs: Returned using a center point, radius, and start and stop location
- ellipses: Returned as equation parameters
- splines: Returned as equation parameters
- straight lines: Returned as tessellated polylines

The format of the remaining array elements ([2], [3], ...) of polyline data is as follows:

[*Type*, *GeomDataSize*, *GeomData*[], *LineColor*, *LineStyle*, *LineFont*, *LineWeight*, *LayerID*, *LayerOverride*, *NumPolyPoints*, [x,y,z]]

where:

Type = underlying geometry type, possible values are:

- 0 = Polyline type
- 1 = Arc or Circle type

GeomDataSize = number of elements in the *GeomData* array, for *Type* = 0 this will be 0.

GeomData[] = geometric data that can be used to represent the underlying geometry type. The data returned in this array is based on the underlying geometry type:

- *Type* = 0. This array is empty
- *Type* = 1. [*centerPtX*, *centerPtY*, *centerPtZ*, *startPtX*, *startPtY*, *startPtZ*, *endPtX*, *endPtY*, *endPtZ*, *normalX*, *normalY*, *normalZ*]

LineColor = polyline color. This value is determined either by the explicitly set value or by the layer that the polyline is on.

LineStyle = value combines polyline font and weight information. This value can be used as an input to [GetLineFontInfo](#) and [GetLineFontName](#). If this value is -1, then the user has probably modified the line display manually in the drawing and you should use the *LineFont* and *LineWeight* return values to recreate the exact polyline style.

LineFont = value is used for polyline font information. This value can be used as an input to the [GetLineFontInfo2](#) and [GetLineFontName2](#) functions. This value will only be valid if *LineStyle* is -1.

LineWeight = polyline weight where Thin = 0.0, Normal = 1.0, Thick = 2.0. This value will only be valid if *LineStyle* is -1.

LayerID = integer value indicating which layer holds this polyline. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) and [ILayerMgr::iGetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

NumPolyPoints = number of XYZ points found in the [x,y,z] return value.

[x,y,z] = array of points used to describe the polyline. This array has *NumPolyPoints* points. This data will be returned for every polyline regardless of *Type*.

To get information about solid-fill hatches in drawing views, use [IView::GetFaceHatchCount](#), [IView::GetFaceHatches](#), and [IView::IGetFaceHatches](#).

 See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSolidHatchInfo Method](#)
[ISketch::GetSketchHatches Method](#)

 Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSplines Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSplines Method (IView)

Obsolete. Superseded by [IView::GetSplines3](#) and [IView::IGetSplines3](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetSplines() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double

value = instance.IGetSplines()
```

C#

```
System.double IGetSplines()
```

C++/CLI

```
System.double IGetSplines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [View::IGetSplines](#).

 See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSplines2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSplines2 Method (IView)

Obsolete. Superseded by [IView::GetSplines3](#) and [IView::IGetSplines3](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetSplines2() As System.Double
```

```
Dim instance As IView
Dim value As System.Double

value = instance.IGetSplines2()
```

C#

```
System.double IGetSplines2()
```

C++/CLI

```
System.double IGetSplines2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetSplines2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSplines3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetSplines3 Method (IView)

Gets all of the splines added by a user in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSplines3() As System.Double
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.Double

value = instance.IGetSplines3()
```

C#

```
System.double IGetSplines3()
```

C++/CLI

```
System.double IGetSplines3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

This method only returns splines that were sketched by a user in this drawing view. Use [IView::GetPolylines6](#) or [IView::IGetPolylines6](#) to access the solid model's projected display data in the drawing view.

Format of return values is an array of doubles with the format:

```
[ [ Color, LineType, LineStyleIndex, LineWidth, LayerID, LayerOverride, NumSplinePoints, [x,y,z] ] ]
```

Color = COLORREF returned as an integer. Return value could be 0 or -1 for default color.

LineType = line type. Valid returns as defined in [swLineTypes e](#). A lineType is a combination of a lineStyle and lineWeight.

LineStyleIndex = line style. Valid line styles as defined in [swLineStyles e](#).

LineWidth = integer value defining the line width. Valid width values as defined in [swLineWeights e](#).

LayerID = integer value indicating which layer holds this entity. Obtain the [ILayer](#) object by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::!GetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if *LayerOverride* was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

This complete set of data repeats itself for each spline found in the view. For each spline, the array returned contains the color, line type, number of spline points in the spline, and X,Y,Z value for each of those points. Therefore, the *[x,y,z]* parameter is an array of *NumSplinePoints*, which can vary in size from spline to spline.

The *[x,y,z]* points for each spline are not the same as the points used to generate the spline. This method tessellates the spline based on the display quality and place points along the spline appropriately.

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (for example, the 0,0 origin being the lower-left corner of the sheet), then combine this data with the three return values from [IView::GetXForm](#) or [IView::!GetXForm](#).

To determine data size needed in this method, use [IView::GetSplineCount](#) or get the number of elements in the array returned by this method.

If you are using COM, then this method must be preceded by a call to [IView::GetSplineCount](#) to determine memory allocation and to perform the actual gathering of spline data.

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetSplines3 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTableAnnotations Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetTableAnnotations Method (IView)

Gets all of the table annotations in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTableAnnotations( _  
    ByVal NumTableAnnotation As System.Integer _  
) As TableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim NumTableAnnotation As System.Integer  
Dim value As TableAnnotation
```

```
value = instance.IGetTableAnnotations(NumTableAnnotation)
```

C#

```
TableAnnotation IGetTableAnnotations(  
    System.int NumTableAnnotation  
)
```

C++/CLI

```
TableAnnotation^ IGetTableAnnotations(  
& System.int NumTableAnnotation  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumTableAnnotation

Total number of table annotations in this drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [table annotations](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of table annotations all at once instead of calling [IView::GetFirstTableAnnotation](#) and then repeatedly calling [ITableAnnotation::GetNext](#) to obtain the table annotations in the drawing view.

Before calling this method, call [IView::GetTableAnnotationCount](#) to get the value for numTableAnnotations.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTemporaryAxes Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetTemporaryAxes Method (IView)

Gets the information of the temporary axes displayed in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTemporaryAxes( _  
    ByVal TempAxesCount As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim TempAxesCount As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTemporaryAxes(TempAxesCount)
```

C#

```
System.double IGetTemporaryAxes(  
    System.int TempAxesCount  
)
```

C++/CLI

```
System.double IGetTemporaryAxes(  
& System.int TempAxesCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TempAxesCount
Number of temporary axes
\\

Visual Basic for Applications (VBA) Syntax

See [View::IGetTemporaryAxes](#).

Remarks

Call [IView::GetTemporaryAxesCount](#) before calling this method to get the value for TempAxesCount.

This array contains the start and end points, in that order, of temporary axes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetTemporaryAxes Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetUserPoints Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetUserPoints Method (IView)

Obsolete. Superseded by [IView::GetUserPoints2](#) and [IView::IGetUserPoints2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetUserPoints() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double

value = instance.IGetUserPoints()
```

C#

```
System.double IGetUserPoints()
```

C++/CLI

```
System.double IGetUserPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::IGetUserPoints](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetUserPoints2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetUserPoints2 Method (IView)

Gets all of the information about all of the user points in this view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetUserPoints2() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double

value = instance.IGetUserPoints2()
```

C#

```
System.double IGetUserPoints2()
```

C++/CLI

```
System.double IGetUserPoints2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of doubles:

[*Color*, *LineStyleIndex*, *LineWidth*, *LayerID*, *LayerOverride*, *ptLoc*[3] ...]

Color = COLORREF returned as an integer. Return value could be 0 or -1 for default color.

LineStyleIndex = line style. Valid line styles can be found in the [swLineStyles_e](#) enumeration.

LineWidth = integer value defining the line width. Valid width values can be found in the [swLineWeights_e](#) enumeration.

LayerID = integer value indicating which layer holds this entity. The [ILayer](#) object can be obtained by passing this integer value to [ILayerMgr::GetLayerById](#) or [ILayerMgr::!GetLayerById](#).

LayerOverride = integer with bit flags set to determine which properties, if any, have been overridden with respect to the Layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if LayerOverride was returned as 3, you know the color and style have been specifically set for this item and may not match the default values associated with this item's layer.

ptLoc[3] = an array of 3 doubles (X,Y,Z) describing the point location

...

This set of data repeats for each user point in the view. The size of the array is (NumPts * 8). To determine the number of points in the view, see [IView::GetUserPointsCount](#).

The data returned from this method is in terms of view space. If you want the data in terms of sheet space (that is, the 0,0 origin being the lower-left corner of the sheet), then combine this data with the three return values from [IView::GetXForm](#) or [IView::!GetXForm](#).

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetUserPoints2 Method](#)

Availability

IGetViewXform Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetViewXform Method (IView)

Gets the transform from model space origin to drawing space origin.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetViewXform() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double

value = instance.IGetViewXform()
```

C#

```
System.double IGetViewXform()
```

C++/CLI

```
System.double IGetViewXform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IGetViewXform](#).

Remarks

The return value is formatted as the following array of 13 doubles:

- [0-8] is a 3x3 matrix of the view rotation
- [9-11] is a 1x3 vector of translation
- [12] is the scaling of the transformation

[IView::GetXform](#) and [IView::IGetXform](#) return the location of the drawing view center with respect to the drawing origin.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetViewXform Method](#)
[IView::ModelToViewTransform Property](#)

IGetVisibleComponents Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetVisibleComponents Method (IView)

Gets the visible components in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVisibleComponents( _  
    ByVal ViewComponentCount As System.Integer _  
) As Component2
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ViewComponentCount As System.Integer  
Dim value As Component2  
  
value = instance.IGetVisibleComponents(ViewComponentCount)
```

C#

```
Component2 IGetVisibleComponents(  
    System.int ViewComponentCount  
)
```

C++/CLI

```
Component2^ IGetVisibleComponents(  
& System.int ViewComponentCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ViewComponentCount
Number of visible components

Return Value

Visible [components](#) in this drawing view

Visual Basic for Applications (VBA) Syntax

See [View::IGetVisibleComponents](#).

Remarks

Visible components are only those components not completely obscured by other components in the view.
Call [IView::GetVisibleComponentCount](#) before calling this method to get the value of ViewComponentCount.

See Also

[IView Interface](#)
[IView Members](#)
[IView::EnumHiddenComponents2 Method](#)
[IView::GetHiddenComponents Method](#)
[IView::GetVisibleComponents Method](#)
[IView::GetVisibleEntities Method](#)
[IView::GetVisibleEntityCount Method](#)
[IView::IGetVisibleEntities Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetVisibleEntities Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetVisibleEntities Method (IView)

Obsolete. Superseded by [IView::IGetVisibleEntities2](#)

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetVisibleEntities( _
    ByVal LpViewComponent As Component2, _
    ByVal EntityType As System.Integer, _
    ByVal ViewEntityCount As System.Integer _
) As Entity
```

Visual Basic (Usage)



```
Dim instance As IView
Dim LpViewComponent As Component2
Dim EntityType As System.Integer
Dim ViewEntityCount As System.Integer
Dim value As Entity

value = instance.IGetVisibleEntities(LpViewComponent, EntityType, ViewEntityCount)
```

C#

```
Entity IGetVisibleEntities(
    Component2 LpViewComponent,
    System.int EntityType,
    System.int ViewEntityCount
)
```

C++/CLI

```
Entity^ IGetVisibleEntities(
    & Component2^ LpViewComponent,
    & System.int EntityType,
    & System.int ViewEntityCount
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[LpViewComponent](#)
[Component](#) from which to get [EntityType](#)
[EntityType](#)
 Type of entity as defined in [swViewEntityType_e](#)
[ViewEntityCount](#)
 Number of specified visible entities

Return Value

Array of the specified visible entities

Remarks

Visible entities are only those entities not completely obscured by other entities in the view.

Call [IView::GetVisibleEntityCount](#) before calling this method to get the value of [ViewEntityCount](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetVisibleEntities Method](#)
[IView::GetVisibleComponentCount Method](#)
[IView::GetVisibleComponents Method](#)
[IView::EnumHiddenComponents2 Method](#)
[IView::GetHiddenComponents Method](#)
[IView::IGetVisibleComponents Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

Gets the visible entities of the specified type for the specified component in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVisibleEntities2( _
    ByVal LpViewComponent As Component2, _
    ByVal EntityType As System.Integer, _
    ByVal ViewEntityCount As System.Integer _
) As Entity
```

Visual Basic (Usage)



```
Dim instance As IView
Dim LpViewComponent As Component2
Dim EntityType As System.Integer
Dim ViewEntityCount As System.Integer
Dim value As Entity

value = instance.IGetVisibleEntities2(LpViewComponent, EntityType, ViewEntityCount)
```

C#

```
Entity IGetVisibleEntities2(
    Component2 LpViewComponent,
    System.int EntityType,
    System.int ViewEntityCount
)
```

C++/CLI

```
Entity^ IGetVisibleEntities2(
    & Component2^ LpViewComponent,
    & System.int EntityType,
    & System.int ViewEntityCount
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpViewComponent
[Component](#) from which to get EntityType
EntityType
 Type of entity as defined in [swViewEntityType_e](#)
ViewEntityCount
 Number of visible entities of EntityType in LpViewComponent

Return Value

- In-process, unmanaged C++: Pointer to an array of visible entities
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Visible entities are entities that are not completely obscured by other entities in the view.

Call [IView::GetVisibleEntityCount2](#) before calling this method to get the value of ViewEntityCount.

The difference between this method and the now obsolete IView::IGetVisibleEntities method is that this method supports silhouette edges (EntityType = swViewEntityType_e.swViewEntityType_SilhouetteEdge).

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetVisibleEntities2 Method \(\)](#)
[IView::GetVisibleComponentCount Method \(\)](#)
[IView::GetVisibleComponents Method \(\)](#)
[IView::GetHiddenComponents Method \(\)](#)

[IView::EnumHiddenComponents2 Method \(\)](#)
[IView::IGetVisibleComponents Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetWeldBeads Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetWeldBeads Method (IView)

Gets all of the weld beads on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetWeldBeads(  
    ByVal NumWeldBead As System.Integer _  
) As WeldBead
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim NumWeldBead As System.Integer  
Dim value As WeldBead  
  
value = instance.IGetWeldBeads(NumWeldBead)
```

C#

```
WeldBead IGetWeldBeads(  
    System.int NumWeldBead  
)
```

C++/CLI

```
WeldBead^ IGetWeldBeads(  
& System.int NumWeldBead  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumWeldBead

Total number of weld beads on this drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [weld beads](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of weld beads all at once instead of calling [IView::GetFirstWeldBead](#) and then repeatedly calling [IWeldBead::GetNext](#) to obtain the weld beads in the drawing view.

Before calling this method, call [IView::GetWeldBeadCount](#) to get the value for numWeldBead.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetWeldBeads Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

IGetWeldSymbols Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetWeldSymbols Method (IView)

Gets all of the weld symbols on this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetWeldSymbols( _
    ByVal NumWeldSymbol As System.Integer _
) As WeldSymbol
```

Visual Basic (Usage)



```
Dim instance As IView
Dim NumWeldSymbol As System.Integer
Dim value As WeldSymbol

value = instance.IGetWeldSymbols(NumWeldSymbol)
```

C#

```
WeldSymbol IGetWeldSymbols(
    System.int NumWeldSymbol
)
```

C++/CLI

```
WeldSymbol^ IGetWeldSymbols(
    & System.int NumWeldSymbol
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumWeldSymbol
Total number of weld symbols on this drawing view

Return Value

- in-process, unmanaged C++: Pointer to an array of [weld symbols](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use this method to obtain the array of weld symbols all at once instead of calling [IView::GetFirstWeldSymbol](#) and then repeatedly calling [IWeldSymbol::GetNext](#) to obtain the weld symbols in the drawing view.

Before calling this method, call [IView::GetWeldSymbolCount](#) to get the value for numWeldSymbol.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetWeldSymbols Method](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

IGetWitnessGeomInfo Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetWitnessGeomInfo Method (IView)

Gets the geometry data for all of the virtual sharp witness lines in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetWitnessGeomInfo( _  
    ByVal ArraySize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ArraySize As System.Integer  
Dim value As System.Double  
  
value = instance.IGetWitnessGeomInfo(ArraySize)
```

C#

```
System.double IGetWitnessGeomInfo(  
    System.int ArraySize  
)
```

C++/CLI

```
System.double IGetWitnessGeomInfo(  
& System.int ArraySize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArraySize

Size of the virtual sharp witness line geometry data array (see **Remarks**)

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This method returns an array containing the following data for each virtual sharp in the view:

[color_value](#),
[swLineStyles_e](#) option (-1 if no line style is specified),
[swLineWeights_e](#) option (-1 if no line weight is specified),
layer ID (-1 if no layer is specified),
[swLayerOverride_e](#) option,
0 (**NOTE:** 0 = witness line data),
number (m) of witness lines,
witness line 1[start_point[x,y,z], end_point[x,y,z&cd;
...
witness line m[start_point[x,y,z], end_point[x,y,z&cd;,
1 (**NOTE:** 1 = witness arc data),
number (n) of witness arcs,
witness arc 1[start_point[x,y,z], end_point[x,y,z], center_point[x,y,z], normal_point[x,y,z&cd;
...
witness arc n[start_point[x,y,z], end_point[x,y,z], center_point[x,y,z], normal_point[x,y,z&cd;]

Where:

$color_value = \text{MAX}(\text{MIN}(red_rgb_value, 255), 0) + \text{MAX}(\text{MIN}(green_rgb_value, 255), 0) * 16 * 16 + \text{MAX}(\text{MIN}(blue_rgb_value, 255), 0) * 16 * 16 * 16$

Before calling this method, call [IView::GetWitnessEntitiesCount](#) to get the size of the array returned by this method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetWitnessGeomInfo Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetXform Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IGetXform Method (IView)

Gets the matrix used for displaying this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetXform() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
value = instance.IGetXform()
```

C#

```
System.double IGetXform()
```

C++/CLI

```
System.double IGetXform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 3 doubles that describe the location and scale of the drawing view (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IGetXform](#).

Remarks

The first two values returned are the X and Y locations of the view relative to the sheet origin, and the third value returned is the scale of the drawing view.

Because of a Microsoft compilation issue, the Dispatch name generated in the **swdisp.h** and **swdisp.cpp** files for the Dispatch version of this method is GetXform (with a lower-case letter f). To work around this:

- Use GetXform in your code instead of GetXForm.
- or -
- Modify the swdisp.h and swdisp.cpp files so that the declaration for GetXForm in the [IView](#) object is changed to GetXform. Remember to change it when you upgrade the SOLIDWORKS Design software.

[IView::GetViewXform](#) and [IView::IGetViewXform](#) get the transform from model space origin to drawing space origin.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetXform Method](#)
[IView::ISetXform Method](#)
[IView::SetXform Method](#)
[IView::ModelToViewTransform Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertBomTable Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBomTable Method (IView)

Inserts a Bill of Materials (BOM) table for this drawing view using Microsoft Excel.

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertBomTable( _  
    ByVal Template As System.String, _  
    ByVal Xloc As System.Double, _  
    ByVal Yloc As System.Double, _  
    ByRef Errors As System.Integer _  
    ) As BomTable
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Template As System.String  
Dim Xloc As System.Double  
Dim Yloc As System.Double  
Dim Errors As System.Integer  
Dim value As BomTable  
  
value = instance.IInsertBomTable(Template, Xloc, Yloc, Errors)
```

C#

```
BomTable IInsertBomTable(  
    System.string Template,  
    System.double Xloc,  
    System.double Yloc,  
    out System.int Errors  
)
```

C++/CLI

```
BomTable^ IInsertBomTable(  
    & System.String^ Template,  
    & System.double Xloc,  
    & System.double Yloc,  
    & [Out] System.int Errors  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Template

File name of the template to use to create this BOM

Xloc

X coordinate of the location of the BOM

Yloc

Y coordinate of the location of the BOM

Errors

Status of the BOM creation operation as defined in [swBOMConfigurationCreationErrors_e](#)

Return Value

[BOM table](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertBomTable](#).

Remarks

This method creates a default BOM table at the specified location, using the given template. There are some user preferences that control the default appearance of the table; set them before calling this method to create a BOM that looks like you want it to look. See:

- [ISldWorks::SetUserPreferenceToggle](#) values swBOMConfigurationLocked, swBOMConfigurationUseDocumentFont, swBOMConfigurationUseSummaryInfo, swBOMConfigurationAlignBottom, swBOMContentsDisplayAtTop, swBOMControlldFromAssembly, swBOMControlMissingRows, and swBOMControlSplitTable
- [ISldWorks::SetUserPreferenceIntegerValue](#) values swBOMConfigurationAnchorType, swBOMConfigurationWhatToShow, swBOMControlMissingRowDisplay, and swBOMControlSplitDirection
- [ISldWorks::SetUserPreferenceDoubleValue](#) value swBOMControlSplitHeight

The Template argument is the full path name of the BOM template to use in creating this BOM. If you specify only a file name with no directory, SOLIDWORKS looks for it in *install_dir\lang\local language*. If the file name is blank, the template uses the **bomtemp.xls** file in that directory.

The Xloc and Yloc arguments are the (X,Y) drawing location where the BOM is anchored. To get the drawing origin from the drawing view origin, use [View::GetXform](#) or [View::IGetXform](#). To get the drawing view extents on the drawing, use [View::GetOutline](#) or [View::IGetOutline](#).

If the BOM creation fails, the Dispatch pointer that is returned is null. If you want more information about why the operation failed, use the Errors argument. You can pass in null as the Errors argument if you are not interested in the specific information.

NOTE: Use [View::InsertBomTable2](#) to insert a BOM using SOLIDWORKS table functionality.

See Also

[IView Interface](#)
[IView Members](#)
[IView::InsertBomTable Method](#)
[IView::SetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOMName Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportAnnotations Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ImportAnnotations Method (IView)

Imports the specified annotations into this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub ImportAnnotations( _  
    ByVal IncludeDesignAnnotations As System.Boolean, _  
    ByVal IncludeCosmeticThreads As System.Boolean, _  
    ByVal IncludeDimXpertAnnotations As System.Boolean, _  
    ByVal IncludeHiddenFeatureItems As System.Boolean, _  
    ByVal Include3DViewAnnotations As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim IncludeDesignAnnotations As System.Boolean  
Dim IncludeCosmeticThreads As System.Boolean  
Dim IncludeDimXpertAnnotations As System.Boolean  
Dim IncludeHiddenFeatureItems As System.Boolean  
Dim Include3DViewAnnotations As System.Boolean  
  
instance.ImportAnnotations(IncludeDesignAnnotations, IncludeCosmeticThreads,  
    IncludeDimXpertAnnotations, IncludeHiddenFeatureItems, Include3DViewAnnotations)
```

C#

```

void ImportAnnotations(
    System.bool IncludeDesignAnnotations,
    System.bool IncludeCosmeticThreads,
    System.bool IncludeDimXpertAnnotations,
    System.bool IncludeHiddenFeatureItems,
    System.bool Include3DViewAnnotations
)

```

C++/CLI

```

void ImportAnnotations(
& System.bool IncludeDesignAnnotations,
& System.bool IncludeCosmeticThreads,
& System.bool IncludeDimXpertAnnotations,
& System.bool IncludeHiddenFeatureItems,
& System.bool Include3DViewAnnotations
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IncludeDesignAnnotations

True to import design annotations, false to not

IncludeCosmeticThreads

True to import cosmetic threads, false to not

IncludeDimXpertAnnotations

True to import DimXpert annotations, false to not

IncludeHiddenFeatureItems

True to import hidden feature items, false to not

Include3DViewAnnotations

True to import 3D view annotations, false to not

Visual Basic for Applications (VBA) Syntax

See [View::ImportAnnotations](#).

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertAlternateView Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertAlternateView Method (IView)

Inserts an **Alternate Position View** of the currently selected drawing view.

.NET Syntax

Visual Basic (Declaration)

```

Function InsertAlternateView(
    ByVal ConfigurationName As System.String _
) As View

```

Visual Basic (Usage)



```

Dim instance As IView
Dim ConfigurationName As System.String
Dim value As View

value = instance.InsertAlternateView(ConfigurationName)

```

C#

```
View InsertAlternateView(  
    System.string ConfigurationName  
)
```

C++/CLI

```
View^ InsertAlternateView(  
& System.String^ ConfigurationName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigurationName
Name of the configuration (see **Remarks**)

Return Value

Alternate [drawing view](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertAlternateView](#).

Example

[Insert Alternate Position View \(VBA\)](#)

Remarks

Before using this method, you must select a drawing view on which to superimpose the **Alternate Position View**.

If you specify a non-existent configuration for ConfigurationName, then it is created using all default settings. The new configuration is identical to the currently selected configuration. The user can then open the assembly, edit the configuration, and update the drawing view

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBendTable Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBendTable Method (IView)

Inserts a bend table for this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBendTable( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal StartValue As System.String, _  
    ByVal TableTemplate As System.String _  
) As BendTableAnnotation
```

Visual Basic (Usage)

 Copy Code

```

Dim instance As IView
Dim UseAnchorPoint As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim AnchorType As System.Integer
Dim StartValue As System.String
Dim TableTemplate As System.String
Dim value As BendTableAnnotation

```

```
value = instance.InsertBendTable(UseAnchorPoint, X, Y, AnchorType, StartValue, TableTemplate)
```

C#

```

BendTableAnnotation InsertBendTable(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.string StartValue,
    System.string TableTemplate
)

```

C++/CLI

```

BendTableAnnotation^ InsertBendTable(
    & System.bool UseAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.String^ StartValue,
    & System.String^ TableTemplate
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

True to insert the bend table at the sheet format anchor point, false to insert it at the point specified by the X and Y parameters of this method

X

X-coordinate for placement of the bend table; valid only when UseAnchorPoint is false

Y

Y-coordinate for placement of the bend table; valid only when UseAnchorPoint is false

AnchorType

Anchor type as defined in [swBomConfigurationAnchorType_e](#)

StartValue

Starting datum tag; a value from A to Z for letter tags; a positive integer for number tags

TableTemplate

Full pathname of the template (e.g., *install_dir\lang\language\bendtable-standard.sldbndtbt*)

Return Value

[IBendTableAnnotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertBendTable](#).

Example

[Insert Bend Table \(VBA\)](#)
[Insert Bend Table \(VB.NET\)](#)
[Insert Bend Table \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IBendTable Interface](#)
[IPartDoc::InsertBendTable Method\(\)](#)

Availability

InsertBomTable Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBomTable Method (IView)

Inserts a Bill of Materials (BOM) table for this drawing view using Microsoft Excel.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBomTable( _  
    ByVal Template As System.String, _  
    ByVal Xloc As System.Double, _  
    ByVal Yloc As System.Double, _  
    ByRef Errors As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Template As System.String  
Dim Xloc As System.Double  
Dim Yloc As System.Double  
Dim Errors As System.Integer  
Dim value As System.Object  
  
value = instance.InsertBomTable(Template, Xloc, Yloc, Errors)
```

C#

```
System.Object InsertBomTable(  
    System.string Template,  
    System.double Xloc,  
    System.double Yloc,  
    out System.int Errors  
)
```

C++/CLI

```
System.Object^ InsertBomTable(  
& System.String^ Template,  
& System.double Xloc,  
& System.double Yloc,  
& [Out] System.int Errors  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Template

File name of the template to use to create this BOM

Xloc

X coordinate of the location of the BOM

Yloc

Y coordinate of the location of the BOM

Errors

Status of the BOM creation operation as defined in [swBOMConfigurationCreationErrors_e](#)

Return Value

[BOM table](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertBomTable](#).

Remarks

This method creates a default BOM table at the specified location, using the given template. There are some user preferences that control the default appearance of the table; set them before calling this method to create a BOM that looks like you want it to look. See:

- [ISldWorks::SetUserPreferenceToggle](#) values swBOMConfigurationLocked, swBOMConfigurationUseDocumentFont, swBOMConfigurationUseSummaryInfo, swBOMConfigurationAlignBottom, swBOMContentsDisplayAtTop, swBOMControlIdFromAssembly, swBOMControlMissingRows, and swBOMControlSplitTable
- [ISldWorks::SetUserPreferenceIntegerValue](#) values swBOMConfigurationAnchorType, swBOMConfigurationWhatToShow, swBOMControlMissingRowDisplay, and swBOMControlSplitDirection
- [ISldWorks::SetUserPreferenceDoubleValue](#) value swBOMControlSplitHeight

The Template argument is the full path name of the BOM template to use in creating this BOM. If you specify only a file name with no directory, SOLIDWORKS looks for it in install_dir\lang\local language. If the file name is blank, the template uses the **bomtemp.xls** file in that directory.

The Xloc and Yloc arguments are the (X,Y) drawing location where the BOM is anchored. To get the drawing origin from the drawing view origin, use [IView::GetXform](#) or [IView::IGetXform](#). To get the drawing view extents on the drawing, use [IView::GetOutline](#) or [IView::IGetOutline](#).

If the BOM creation fails, the Dispatch pointer that is returned is null or nothing. If you want more information about why the operation failed, use the Errors argument. You can pass null or nothing as the Errors argument if you are not interested in the specific information.

NOTE: Use [IView::InsertBomTable2](#) to insert a BOM using SOLIDWORKS table functionality.

See Also

[IView Interface](#)
[IView Members](#)
[IView::InsertBomTable Method](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOMName Method](#)
[IView::SetKeepLinkedToBOM Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertBomTable2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBomTable2 Method (IView)

Obsolete. Superseded by [IView::InsertBomTable3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBomTable2( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal BomType As System.Integer, _  
    ByVal Configuration As System.String, _  
    ByVal TableTemplate As System.String _  
    ) As BomTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseAnchorPoint As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim AnchorType As System.Integer  
Dim BomType As System.Integer  
Dim Configuration As System.String  
Dim TableTemplate As System.String  
Dim value As BomTableAnnotation
```

```
value = instance.InsertBomTable2(UseAnchorPoint, X, Y, AnchorType, BomType, Configuration,  
    TableTemplate)
```

C#

```

BomTableAnnotation InsertBomTable2(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.int BomType,
    System.string Configuration,
    System.string TableTemplate
)

```

C++/CLI

```

BomTableAnnotation^ InsertBomTable2(
    & System.bool UseAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.int BomType,
    & System.String^ Configuration,
    & System.String^ TableTemplate
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true and the appropriate sheet format anchor point exists, then insert table at this point; if false, then use the values specified for the X and Y arguments as the insertion point

X

X coordinate for the placement of the BOM table

Y

Y coordinate for the placement of the BOM table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

BomType

Type of BOM table as defined by [swBomType_e](#)

Configuration

Name of the configuration for this BOM table (see **Remarks**)

TableTemplate

Path and filename of the template that you want to use that corresponds to this type of table (see **Remarks**)

Return Value

[BOM table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertBomTable2](#).

Example

[Insert BOM Table \(C#\)](#)

[Insert BOM Table \(VB.NET\)](#)

[Insert Bom Table \(VBA\)](#)

Remarks

If BomType is swBomType_TopLevelOnly, then do not specify Configuration. Instead, use [IBomFeature::GetConfigurations](#) or [IBomFeature::!GetConfigurations](#) and [IBomFeature::SetConfigurations](#) or [IBomFeature::!SetConfigurations](#) to work with configurations in BOM tables.

If the drawing was created using a configuration other than the Default configuration, then the configuration active at the time the drawing was created is the configuration used in the BOM table when an empty string is specified for the Configuration parameter.

By default, the BOM table templates are in the *install_dir\lang<language>* folder and have a filename extension of *.sldbomtbt*. The template and table must be of the same type. For example, you could specify *C:\Program Files\SOLIDWORKS\lang\English\bom-standard.sldbomtbt* for TableTemplate if you wanted to insert an English-version of the standard BOM table template.

If the BOM table is a parts-only or indented-style BOM and the Configuration specified is invalid, then the BOM is not created.

NOTE: Use [IView::InsertBomTable](#) or [IView::!InsertBomTable](#) to insert a BOM using Microsoft Excel.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOMName Method](#)
[IView::SetKeepLinkedToBOM Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertBomTable3 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBomTable3 Method (IView)

Obsolete. Superseded by [IView::InsertBomTable4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBomTable3( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal BomType As System.Integer, _  
    ByVal Configuration As System.String, _  
    ByVal TableTemplate As System.String, _  
    ByVal Hidden As System.Boolean _  
) As BomTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseAnchorPoint As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim AnchorType As System.Integer  
Dim BomType As System.Integer  
Dim Configuration As System.String  
Dim TableTemplate As System.String  
Dim Hidden As System.Boolean  
Dim value As BomTableAnnotation  
  
value = instance.InsertBomTable3(UseAnchorPoint, X, Y, AnchorType, BomType, Configuration,  
TableTemplate, Hidden)
```

C#

```
BomTableAnnotation InsertBomTable3(  
    System.bool UseAnchorPoint,  
    System.double X,  
    System.double Y,  
    System.int AnchorType,  
    System.int BomType,  
    System.string Configuration,  
    System.string TableTemplate,  
    System.bool Hidden  
)
```

C++/CLI

```
BomTableAnnotation^ InsertBomTable3(  
& System.bool UseAnchorPoint,  
& System.double X,  
& System.double Y,  
& System.int AnchorType,  
& System.int BomType,  
& System.String^ Configuration,
```

```
& System.String^ TableTemplate,  
& System.bool Hidden  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true and the appropriate sheet format anchor point exists, then insert table at this point; if false, then use the values specified for the X and Y arguments as the insertion point

X

X coordinate for the placement of the BOM table

Y

Y coordinate for the placement of the BOM table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

BomType

Type of BOM table as defined by [swBomType_e](#)

Configuration

Name of the configuration for this BOM table (see **Remarks**)

TableTemplate

Path and filename of the template that you want to use that corresponds to this type of table (see **Remarks**)

Hidden

True to hide the BOM table, false to show it

Return Value

[BOM table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertBomTable3](#).

Remarks

If BomType is swBomType_TopLevelOnly, then do not specify Configuration. Instead, use [IBomFeature::GetConfigurations](#) or [IBomFeature::!GetConfigurations](#) and [IBomFeature::SetConfigurations](#) or [IBomFeature::!SetConfigurations](#) to work with configurations in BOM tables.

If the drawing was created using a configuration other than the Default configuration, then the configuration active at the time the drawing was created is the configuration used in the BOM table when an empty string is specified for the Configuration parameter.

BOM table templates are in the *install_dir\lang\<language>* folder and have a filename extension of *.sldbomtbt*. The template and table must be of the same type. For example, you could specify *C:\Program Files\SOLIDWORKS\lang\English\bom-standard.sldbomtbt* for TableTemplate if you wanted to insert an English-version of the standard BOM table template.

If the BOM table is a parts-only or indented-style BOM and the Configuration specified is invalid, then the BOM is not created.

NOTE: Use [View::InsertBomTable](#) or [View::!InsertBomTable](#) to insert a BOM using Microsoft Excel.

See Also

[IView Interface](#)

[IView Members](#)

[IView::GetKeepLinkedToBOM Method](#)

[IView::GetKeepLinkedToBOMName Method](#)

[IView::SetKeepLinkedToBOM Method](#)

[IModelDocExtension::InsertBomTable2 Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBomTable4 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBomTable4 Method (IView)

Obsolete. Superseded by [IView::InsertBomTable5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBomTable4( _  
    ByVal UseAnchorPoint As System.Boolean, _
```

```

    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal AnchorType As System.Integer, _
    ByVal BomType As System.Integer, _
    ByVal Configuration As System.String, _
    ByVal TableTemplate As System.String, _
    ByVal Hidden As System.Boolean, _
    ByVal IndentedNumberingType As System.Integer, _
    ByVal DetailedCutList As System.Boolean _
) As BomTableAnnotation

```

Visual Basic (Usage)



```

Dim instance As IView
Dim UseAnchorPoint As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim AnchorType As System.Integer
Dim BomType As System.Integer
Dim Configuration As System.String
Dim TableTemplate As System.String
Dim Hidden As System.Boolean
Dim IndentedNumberingType As System.Integer
Dim DetailedCutList As System.Boolean
Dim value As BomTableAnnotation

```

```

value = instance.InsertBomTable4(UseAnchorPoint, X, Y, AnchorType, BomType, Configuration,
TableTemplate, Hidden, IndentedNumberingType, DetailedCutList)

```

C#

```

BomTableAnnotation InsertBomTable4(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.int BomType,
    System.string Configuration,
    System.string TableTemplate,
    System.bool Hidden,
    System.int IndentedNumberingType,
    System.bool DetailedCutList
)

```

C++/CLI

```

BomTableAnnotation^ InsertBomTable4(
    & System.bool UseAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.int BomType,
    & System.String^ Configuration,
    & System.String^ TableTemplate,
    & System.bool Hidden,
    & System.int IndentedNumberingType,
    & System.bool DetailedCutList
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true and the appropriate sheet format anchor point exists, then insert table at this point; if false, then use the values specified for the X and Y arguments as the insertion point

X

X coordinate for the placement of the BOM table

Y

Y coordinate for the placement of the BOM table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

BomType

Type of BOM table as defined by [swBomType_e](#)

Configuration

Name of the configuration for this BOM table (see **Remarks**)

TableTemplate
Path and filename of the template that you want to use that corresponds to this type of table (see **Remarks**)
Hidden
True to hide the BOM table, false to show it
IndentedNumberingType
Type of numbering as defined by [swNumberingType_e](#); valid only for BomType = swBomType_e.swBomType_Indented
DetailedCutList
True to show the detailed cut list, false to not; valid only for BomType = swBomType_e.swBomType_Indented

Return Value

[BOM table annotation](#)

 Visual Basic for Applications (VBA) Syntax

See [View::InsertBomTable4](#).

 Remarks

If BomType is swBomType_TopLevelOnly, then do not specify Configuration. Instead, use [IBomFeature::GetConfigurations](#) or [IBomFeature::IGetConfigurations](#) and [IBomFeature::SetConfigurations](#) or [IBomFeature::ISetConfigurations](#) to work with configurations in BOM tables.

If the drawing was created using a configuration other than the Default configuration, then the configuration active at the time the drawing was created is the configuration used in the BOM table when an empty string is specified for the Configuration parameter.

BOM table templates are in the *install_dir\lang\<language>* folder and have a filename extension of **.sldbomtbt**. The template and table must be of the same type. For example, you could specify **C:\Program Files\SOLIDWORKS\lang\English\bom-standard.sldbomtbt** for TableTemplate if you wanted to insert an English-version of the standard BOM table template.

If the BOM table is a parts-only or indented-style BOM and the Configuration specified is invalid, then the BOM is not created.

If the **Restrict top-level only BOMs to one configuration** option on the **Document Properties > Tables > Bill of Materials** dialog or [IModelDocExtension::GetUserPreferenceToggle\(swUserPreferenceToggle_e.swOneConfigOnlyTopLevelBom\)](#) returns true, then only the active or default configuration of the drawing view is inserted in the BOM.

NOTE: Use [View::InsertBomTable](#) or [View::IInsertBomTable](#) to insert a BOM using Microsoft Excel.

 See Also

[IView Interface](#)
[IView Members](#)
[IModelDocExtension::InsertBomTable3 Method](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOMName Method](#)
[IView::SetKeepLinkedToBOM Method](#)
[IBomFeature::NumberingTypeOnIndentedBOM Property](#)

 Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBomTable5 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBomTable5 Method (IView)

Obsolete. Superseded by [IView::InsertBomTable6](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function InsertBomTable5( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal BomType As System.Integer, _  
    ByVal Configuration As System.String, _  
    ByVal TableTemplate As System.String, _  
    ByVal Hidden As System.Boolean, _  
    ByVal IndentedNumberingType As System.Integer, _  
    ByVal DetailedCutList As System.Boolean, _
```

```
ByVal DissolvePartLevelRows As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseAnchorPoint As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim AnchorType As System.Integer  
Dim BomType As System.Integer  
Dim Configuration As System.String  
Dim TableTemplate As System.String  
Dim Hidden As System.Boolean  
Dim IndentedNumberingType As System.Integer  
Dim DetailedCutList As System.Boolean  
Dim DissolvePartLevelRows As System.Boolean  
Dim value As System.Object
```

```
value = instance.InsertBomTable5(UseAnchorPoint, X, Y, AnchorType, BomType, Configuration,  
TableTemplate, Hidden, IndentedNumberingType, DetailedCutList, DissolvePartLevelRows)
```

C#

```
System.object InsertBomTable5(  
    System.bool UseAnchorPoint,  
    System.double X,  
    System.double Y,  
    System.int AnchorType,  
    System.int BomType,  
    System.string Configuration,  
    System.string TableTemplate,  
    System.bool Hidden,  
    System.int IndentedNumberingType,  
    System.bool DetailedCutList,  
    System.bool DissolvePartLevelRows  
)
```

C++/CLI

```
System.Object^ InsertBomTable5(  
& System.bool UseAnchorPoint,  
& System.double X,  
& System.double Y,  
& System.int AnchorType,  
& System.int BomType,  
& System.String^ Configuration,  
& System.String^ TableTemplate,  
& System.bool Hidden,  
& System.int IndentedNumberingType,  
& System.bool DetailedCutList,  
& System.bool DissolvePartLevelRows  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true and the appropriate sheet format anchor point exists, then insert table at this point; if false, then use the values specified for the X and Y arguments as the insertion point

X

X coordinate for the placement of the BOM table

Y

Y coordinate for the placement of the BOM table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

BomType

Type of BOM table as defined by [swBomType_e](#)

Configuration

Name of the configuration for this BOM table (see **Remarks**)

TableTemplate

Path and filename of the template that you want to use that corresponds to this type of table (see **Remarks**)

Hidden

True to hide the BOM table, false to show it

IndentedNumberingType

Type of numbering as defined by [swNumberingType_e](#); valid only for BomType = swBomType_e.swBomType_Indented

DetailedCutList

True to show the detailed cut list, false to not

DissolvePartLevelRows
True to dissolve part level rows, false to not; valid only when DetailedCutList is true

Return Value

[BOM table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertBomTable5](#).

Remarks

If BomType is swBomType_TopLevelOnly, then do not specify Configuration. Instead, use [IBomFeature::GetConfigurations](#) or [IBomFeature::!GetConfigurations](#) and [IBomFeature::SetConfigurations](#) or [IBomFeature::!SetConfigurations](#) to work with configurations in BOM tables.

If the drawing was created using a configuration other than the Default configuration, then the configuration active at the time the drawing was created is the configuration used in the BOM table when an empty string is specified for the Configuration parameter.

BOM table templates are in the *install_dir\lang\<language>* folder and have a filename extension of *.sldbomtbt*. The template and table must be of the same type. For example, you could specify **C:\Program Files\SOLIDWORKS\lang\English\bom-standard.sldbomtbt** for TableTemplate if you wanted to insert an English-version of the standard BOM table template.

If the BOM table is a parts-only or indented-style BOM and the Configuration specified is invalid, then the BOM is not created.

If the **Restrict top-level only BOMs to one configuration** option on the **Document Properties > Tables > Bill of Materials** dialog or [IModelDocExtension::GetUserPreferenceToggle\(swUserPreferenceToggle_e.swOneConfigOnlyTopLevelBom\)](#) returns true, then only the active or default configuration of the drawing view is inserted in the BOM.

NOTE: Use [IView::InsertBomTable](#) or [IView::!InsertBomTable](#) to insert a BOM using Microsoft Excel.

See Also

[IView Interface](#)
[IView Members](#)
[IModelDocExtension::InsertBomTable4 Method \(\)](#)
[IBomFeature::DissolvePartLevelRows Property \(\)](#)
[IBomFeature::NumberingTypeOnIndentedBOM Property \(\)](#)
[IView::GetKeepLinkedToBOM Method \(\)](#)
[IView::GetKeepLinkedToBOMName Method \(\)](#)
[IView::SetKeepLinkedToBOM Method \(\)](#)

Availability

SOLIDWORKS 2024 FCS, Revision Number 32

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBomTable6 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBomTable6 Method (IView)

Inserts a bill of materials (BOM) table for this drawing view using SOLIDWORKS table functionality.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBomTable6( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal BomType As System.Integer, _  
    ByVal Configuration As System.String, _  
    ByVal TableTemplate As System.String, _  
    ByVal Hidden As System.Boolean, _  
    ByVal IndentedNumberingType As System.Integer, _  
    ByVal DetailedCutList As System.Boolean, _  
    ByVal DissolvePartLevelRows As System.Boolean, _  
    ByVal DisplayAsOneItem As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)

```

Dim instance As IView
Dim UseAnchorPoint As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim AnchorType As System.Integer
Dim BomType As System.Integer
Dim Configuration As System.String
Dim TableTemplate As System.String
Dim Hidden As System.Boolean
Dim IndentedNumberingType As System.Integer
Dim DetailedCutList As System.Boolean
Dim DissolvePartLevelRows As System.Boolean
Dim DisplayAsOneItem As System.Boolean
Dim value As System.Object

value = instance.InsertBomTable6(UseAnchorPoint, X, Y, AnchorType, BomType, Configuration,
TableTemplate, Hidden, IndentedNumberingType, DetailedCutList, DissolvePartLevelRows,
DisplayAsOneItem)

```

C#

```

System.object InsertBomTable6(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.int BomType,
    System.string Configuration,
    System.string TableTemplate,
    System.bool Hidden,
    System.int IndentedNumberingType,
    System.bool DetailedCutList,
    System.bool DissolvePartLevelRows,
    System.bool DisplayAsOneItem
)

```

C++/CLI

```

System.Object^ InsertBomTable6(
    & System.bool UseAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.int BomType,
    & System.String^ Configuration,
    & System.String^ TableTemplate,
    & System.bool Hidden,
    & System.int IndentedNumberingType,
    & System.bool DetailedCutList,
    & System.bool DissolvePartLevelRows,
    & System.bool DisplayAsOneItem
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true and the appropriate sheet format anchor point exists, then insert table at this point; if false, then use the values specified for the X and Y arguments as the insertion point

X

X coordinate for the placement of the BOM table

Y

Y coordinate for the placement of the BOM table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

BomType

Type of BOM table as defined by [swBomType_e](#)

Configuration

Name of the configuration for this BOM table (see **Remarks**)

TableTemplate

Path and filename of the template that you want to use that corresponds to this type of table (see **Remarks**)

Hidden

True to hide the BOM table, false to show it

IndentedNumberingType

Type of numbering as defined by [swNumberingType_e](#); valid only for BomType = swBomType_e.swBomType_Indented

DetailedCutList
True to show the detailed cut list, false to not
DissolvePartLevelRows
True to dissolve part level rows, false to not; valid only when DetailedCutList is true
DisplayAsOneItem
True to group into one item number, false to display separately

Return Value

[BOM table annotation](#)

 Visual Basic for Applications (VBA) Syntax

See [View::InsertBomTable6](#).

 Example

[Dissolve Subassembly in a BOM Table \(VBA\)](#)
[Dissolve Subassembly in a BOM Table \(VB.NET\)](#)
[Dissolve Subassembly in a BOM Table \(C#\)](#)
[Insert and Show BOM Table and BOM Balloon \(VBA\)](#)
[Insert and Show BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert and Show BOM Table and BOM Balloon \(C#\)](#)

 Remarks

If BomType is swBomType_TopLevelOnly, then do not specify Configuration. Instead, use [IBomFeature::GetConfigurations](#) and [IBomFeature::SetConfigurations](#) to work with configurations in BOM tables.

If the drawing was created using a configuration other than the Default configuration, then the configuration active at the time the drawing was created is the configuration used in the BOM table when an empty string is specified for the Configuration parameter.

BOM table templates are in the *install_dir\lang\<language>* folder and have a filename extension of **.sldbombt**. The template and table must be of the same type. For example, you could specify **C:\Program Files\SOLIDWORKS\lang\English\bom-standard.sldbombt** for TableTemplate if you wanted to insert an English-version of the standard BOM table template.

If the BOM table is a parts-only or indented-style BOM and the Configuration specified is invalid, then the BOM is not created.

If the **Restrict top-level only BOMs to one configuration** option on the **Document Properties > Tables > Bill of Materials** dialog or [IModelDocExtension::GetUserPreferenceToggle\(swUserPreferenceToggle_e.swOneConfigOnlyTopLevelBom\)](#) returns true, then only the active or default configuration of the drawing view is inserted in the BOM.

NOTE: Use [IView::InsertBomTable](#) to insert a BOM using Microsoft Excel.

 See Also

[IView Interface](#)
[IView Members](#)
[IModelDocExtension::InsertBomTable4 Method \(\)](#)
[IBomFeature::DissolvePartLevelRows Property \(\)](#)
[IBomFeature::NumberingTypeOnIndentedBOM Property \(\)](#)
[IView::GetKeepLinkedToBOM Method \(\)](#)
[IView::GetKeepLinkedToBOMName Method \(\)](#)
[IView::SetKeepLinkedToBOM Method \(\)](#)

 Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBreak Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBreak Method (IView)

Obsolete. Superseded by [IView::InsertBreak2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function InsertBreak( _
    ByVal Orientation As System.Integer, _
    ByVal Position1 As System.Double, _
    ByVal Position2 As System.Double, _
    ByVal Style As System.Integer _
) As BreakLine
```

Visual Basic (Usage)



```
Dim instance As IView
Dim Orientation As System.Integer
Dim Position1 As System.Double
Dim Position2 As System.Double
Dim Style As System.Integer
Dim value As BreakLine

value = instance.InsertBreak(Orientation, Position1, Position2, Style)
```

C#

```
BreakLine InsertBreak(
    System.int Orientation,
    System.double Position1,
    System.double Position2,
    System.int Style
)
```

C++/CLI

```
BreakLine^ InsertBreak(
    & System.int Orientation,
    & System.double Position1,
    & System.double Position2,
    & System.int Style
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Orientation

Horizontal or vertical cut as defined in [swBreakLineOrientation_e](#)

Position1

Location of the first line in the break (see **Remarks**)

Position2

Location of the second line in the break (see **Remarks**)

Style

Cut style as defined in [swBreakLineStyle_e](#)

Return Value

[Break line](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertBreak](#).

Remarks

A break in a drawing view consists of a pair of lines. This method inserts the break lines at the locations indicated by Position1 and Position2.

If the orientation of the break is...	Then Position1 and Position2 are...
Horizontal	Y values, relative to the drawing view origin, indicating where along the Y axis to place the breaks
Vertical	X values, relative to the drawing view origin, indicating where along the X axis to place the breaks

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLineCount Method](#)
[IView::GetBreakLineInfo Method](#)
[IView::GetBreakLines Method](#)
[IView::IGetBreakLineInfo Method](#)
[IView::IGetBreakLines Method](#)
[IView::BreakLineGap Property](#)
[IView::IsBroken Method](#)
[IDrawingDoc::BreakView Method](#)
[IBreakLine::Style Property\(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBreak2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBreak2 Method (IView)

Obsolete. Superseded by [IView::InsertBreak3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBreak2( _  
    ByVal Orientation As System.Integer, _  
    ByVal Position1 As System.Double, _  
    ByVal Position2 As System.Double, _  
    ByVal Style As System.Integer, _  
    ByVal ShapeIntensity As System.Integer _  
) As BreakLine
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Orientation As System.Integer  
Dim Position1 As System.Double  
Dim Position2 As System.Double  
Dim Style As System.Integer  
Dim ShapeIntensity As System.Integer  
Dim value As BreakLine
```

```
value = instance.InsertBreak2(Orientation, Position1, Position2, Style, ShapeIntensity)
```

C#

```
BreakLine InsertBreak2(  
    System.int Orientation,  
    System.double Position1,  
    System.double Position2,  
    System.int Style,  
    System.int ShapeIntensity  
)
```

C++/CLI

```
BreakLine^ InsertBreak2(  
& System.int Orientation,  
& System.double Position1,  
& System.double Position2,  
& System.int Style,  
& System.int ShapeIntensity  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Orientation
Horizontal or vertical cut as defined in [swBreakLineOrientation_e](#)

Position1
Location of the first line in the break (see **Remarks**)

Position2
Location of the second line in the break (see **Remarks**)

Style
Break line style as defined in [swBreakLineStyle_e](#)

ShapeIntensity
Shape intensity for jagged cut break lines only; valid range is 1 (most) through 5 (least)

Return Value

[Break line](#)

 Visual Basic for Applications (VBA) Syntax

See [View::InsertBreak2](#).

 Remarks

A break in a drawing view consists of a pair of break lines. This method inserts the break lines at the locations indicated by Position1 and Position2.

If the orientation of the break is...	Then Position1 and Position2 are...
Horizontal	Y values relative to the drawing view origin, indicating where along the Y axis to place the breaks
Vertical	X values relative to the drawing view origin, indicating where along the X axis to place the breaks

 See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLineCount2 Method \(\)](#)
[IView::GetBreakLineInfo2 Method \(\)](#)
[IView::GetBreakLines Method \(\)](#)
[IView::IsBroken Method \(\)](#)
[IView::BreakLineGap Property \(\)](#)
[IDrawingDoc::BreakView Method \(\)](#)

 Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBreak3 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertBreak3 Method (IView)

Inserts the specified type of break at the specified location in this drawing view.

 .NET Syntax

Visual Basic (Declaration)

```
Function InsertBreak3( _  
    ByVal Orientation As System.Integer, _  
    ByVal Position1 As System.Double, _  
    ByVal Position2 As System.Double, _  
    ByVal Style As System.Integer, _  
    ByVal ShapeIntensity As System.Integer, _  
    ByVal BreakSketchBlocks As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```

Dim instance As IView
Dim Orientation As System.Integer
Dim Position1 As System.Double
Dim Position2 As System.Double
Dim Style As System.Integer
Dim ShapeIntensity As System.Integer
Dim BreakSketchBlocks As System.Boolean
Dim value As System.Object

```

```

value = instance.InsertBreak3(Orientation, Position1, Position2, Style, ShapeIntensity,
BreakSketchBlocks)

```

C#

```

System.object InsertBreak3(
    System.int Orientation,
    System.double Position1,
    System.double Position2,
    System.int Style,
    System.int ShapeIntensity,
    System.bool BreakSketchBlocks
)

```

C++/CLI

```

System.Object^ InsertBreak3(
    & System.int Orientation,
    & System.double Position1,
    & System.double Position2,
    & System.int Style,
    & System.int ShapeIntensity,
    & System.bool BreakSketchBlocks
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Orientation

Horizontal or vertical cut as defined in [swBreakLineOrientation_e](#)

Position1

Location of the first line in the break (see **Remarks**)

Position2

Location of the second line in the break (see **Remarks**)

Style

Break line style as defined in [swBreakLineStyle_e](#)

ShapeIntensity

Shape intensity for jagged cut break lines only; valid range is 1 (most) through 5 (least)

BreakSketchBlocks

True to break sketch blocks, false to not

Return Value

[Break line](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertBreak3](#).

Example

[Insert Jagged Cut Break \(VBA\)](#)
[Insert Jagged Cut Break \(VB.NET\)](#)
[Insert Jagged Cut Break \(C#\)](#)

Remarks

A break in a drawing view consists of a pair of break lines. This method inserts the break lines at the locations indicated by Position1 and Position2.

If the orientation of the break is...	Then Position1 and Position2 are...
Horizontal	Y values relative to the drawing view origin, indicating where along the Y axis to place the breaks
Vertical	X values relative to the drawing view origin, indicating where along the X axis to place the breaks

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBreakLineCount2 Method \(\)](#)
[IView::GetBreakLineInfo2 Method \(\)](#)
[IView::GetBreakLines Method \(\)](#)
[IView::IsBroken Method \(\)](#)
[IView::BreakLineGap Property \(\)](#)
[IDrawingDoc::BreakView Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertCutListPropertyNote Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertCutListPropertyNote Method (IView)

Inserts a note that contains all of the cut list item properties of a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCutListPropertyNote( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IView
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double

instance.InsertCutListPropertyNote(X, Y, Z)
```

C#

```
void InsertCutListPropertyNote(
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
void InsertCutListPropertyNote(
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
 x coordinate of the note
Y
 y coordinate of the note

Z
z coordinate of the note

Visual Basic for Applications (VBA) Syntax

See [View::InsertCutListPropertyNote](#).

Example

[Insert Cut List Item Property Note \(VBA\)](#)
[Insert Cut List Item Property Note \(VB.NET\)](#)
[Insert Cut List Item Property Note \(C#\)](#)

Remarks

This method requires a flat pattern drawing view.

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertHoleTable Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertHoleTable Method (IView)

Obsolete. Superseded by [View::InsertHoleTable2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertHoleTable( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal TableTemplate As System.String _  
    ) As HoleTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseAnchorPoint As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim AnchorType As System.Integer  
Dim TableTemplate As System.String  
Dim value As HoleTableAnnotation
```

```
value = instance.InsertHoleTable(UseAnchorPoint, X, Y, AnchorType, TableTemplate)
```

C#

```
HoleTableAnnotation InsertHoleTable(  
    System.bool UseAnchorPoint,  
    System.double X,  
    System.double Y,  
    System.int AnchorType,  
    System.string TableTemplate  
)
```

```
HoleTableAnnotation^ InsertHoleTable(
& System.bool UseAnchorPoint,
& System.double X,
& System.double Y,
& System.int AnchorType,
& System.String^ TableTemplate
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If True and the appropriate sheet format anchor point exists, then insert table at this point; if false, then use the values specified for the X and Y arguments as the insertion point

X

X coordinate for the placement of this hole table

Y

Y coordinate for the placement of this hole table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

TableTemplate

Path and filename of the template that you want to use that corresponds to this type of table (see **Remarks**)

Return Value

[Hole table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertHoleTable](#).

Remarks

This method requires ordered preselection of various entities:

- datum = 1
- hole = 2
- x axis = 4
- y axis = 8

See [IModelDocExtension::SelectByID2](#) for details.

By default, the hole table templates are in the <install_dir>\lang\<language> folder and have a filename extension of **.sldholtbt**. The template and table must be of the same type. For example, you could specify **C:\Program Files\SOLIDWORKS\lang\English\standard hole table--letters.sldholelbt** for TableTemplate if you wanted to insert an English-version of the standard hole letters table template.

See Also

[IView Interface](#)

[IView Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertHoleTable2 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertHoleTable2 Method (IView)

Obsolete. Superseded by [IView::InsertHoleTable3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertHoleTable2( _
    ByVal UseAnchorPoint As System.Boolean, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal AnchorType As System.Integer, _
    ByVal StartValue As System.String, _
    ByVal TableTemplate As System.String _
) As HoleTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IView
Dim UseAnchorPoint As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim AnchorType As System.Integer
Dim StartValue As System.String
Dim TableTemplate As System.String
Dim value As HoleTableAnnotation
```

```
value = instance.InsertHoleTable2(UseAnchorPoint, X, Y, AnchorType, StartValue, TableTemplate)
```

C#

```
HoleTableAnnotation InsertHoleTable2(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.string StartValue,
    System.string TableTemplate
)
```

C++/CLI

```
HoleTableAnnotation^ InsertHoleTable2(
    & System.bool UseAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.String^ StartValue,
    & System.String^ TableTemplate
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true, and the sheet format anchor point exists, then insert table at the anchor point; if false, then insert the table at the location specified by the X and Y parameters

X

X coordinate in meters for the anchor of this hole table

Y

Y coordinate in meters for the anchor of this hole table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

StartValue

Starting value for datum tags; a letter from A to Z, if TableTemplate uses letter tags; a positive integer, if TableTemplate uses number tags (see **Remarks**)

TableTemplate

Path and filename of the table template that corresponds to the table you want to use (see **Remarks**)

Return Value

[Hole table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertHoleTable2](#).

Example

 Remarks

This method inserts a table with the following information for selected holes:

- Datum tag
- X-location of hole center
- Y-location of hole center
- Size

This method displays datum tags next to holes that have been pre-selected in the view. The location of the datum tags is relative to a datum origin that is also pre-selected in the view.

Before calling this method, call [IModelDocExtension::SelectByID2](#) to select the datum origin, hole edges, and faces (for multiple holes) as follows:

Selection	Mark
Datum origin vertex	1
Hole edges and faces	2
Datum origin x axis direction reference	4
Datum origin y axis direction reference	8

Specify TableTemplate using a hole table template (*.sldholtbt) in *install_dir\lang\language*.

Specify a TableTemplate and StartValue that matches the table you want to create. For example, to insert a hole table with letter tags, specify TableTemplate using *install_dir\lang\English\standard hole table--letters.sldholtbt* and specify StartValue using a letter from A to Z.

 See Also

[IView Interface](#)
[IView Members](#)

 Availability

SOLIDWORKS 2011 SP02, Revision 19.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertHoleTable3 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertHoleTable3 Method (IView)

Inserts a hole table in this drawing view.

 .NET Syntax

Visual Basic (Declaration)

```
Function InsertHoleTable3(  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal StartValue As System.String, _  
    ByVal Template As System.String, _  
    ByVal TagOrder As System.Integer, _  
    ByVal TagType As System.Integer, _  
    ByVal ManualTags As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseAnchorPoint As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim AnchorType As System.Integer
```

```

Dim StartValue As System.String
Dim Template As System.String
Dim TagOrder As System.Integer
Dim TagType As System.Integer
Dim ManualTags As System.Object
Dim value As System.Object

```

```

value = instance.InsertHoleTable3(UseAnchorPoint, X, Y, AnchorType, StartValue, Template,
TagOrder, TagType, ManualTags)

```

C#

```

System.object InsertHoleTable3(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.string StartValue,
    System.string Template,
    System.int TagOrder,
    System.int TagType,
    System.object ManualTags
)

```

C++/CLI

```

System.Object^ InsertHoleTable3(
& System.bool UseAnchorPoint,
& System.double X,
& System.double Y,
& System.int AnchorType,
& System.String^ StartValue,
& System.String^ Template,
& System.int TagOrder,
& System.int TagType,
& System.Object^ ManualTags
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true, and the sheet format anchor point exists, then insert table at the anchor point; if false, then insert the table at the location specified by the X and Y parameters

X

X coordinate in meters for the anchor of this hole table

Y

Y coordinate in meters for the anchor of this hole table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

StartValue

Starting value for the specified TagType

Template

Path and filename of the hole table template that corresponds to the hole table you want to create (see **Remarks**)

TagOrder

Tag numbering as defined in [swHoleTableTagOrder_e](#)

TagType

Tag type as defined in [swHoleTableTagStyle_e](#)

ManualTags

Array of custom tags; valid only if TagType is swHoleTableTagStyle_e.swHoleTable_ManualTags

Return Value

[Hole table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertHoleTable3](#).

Example

[Insert Hole Table \(VBA\)](#)
[Insert Hole Table \(VB.NET\)](#)
[Insert Hole Table \(C#\)](#)

Remarks

This method inserts a hole table with the following information for selected holes:

- Datum tag
- X-location of hole center
- Y-location of hole center
- Size of the hole

This method displays datum tags next to holes that have been pre-selected in the view. The location of the datum tags is relative to a datum origin that is also pre-selected in the view.

Before calling this method, call [IModelDocExtension::SelectByID2](#) to select the datum origin, hole edges, and faces (for multiple holes) as follows:

Selection	Mark
Datum origin vertex	1
Hole edges and faces	2
Datum origin x axis direction reference	4
Datum origin y axis direction reference	8

Specify Template using a hole table template (*.sldholtbt):

- in `install_dir\lang\language`.
- that matches the table you want to create. For example, to insert a hole table with letter tags, specify Template using `install_dir\lang\English\standard hole table--letters.sldholtbt`.

See Also

[View Interface](#)
[View Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0