

SOLIDWORKS API (.NET VBA C#) — Reference (329/337): View (part 9 of 10)

SOLIDWORKS API Documentation (converted from CHM)

IView (part 9 of 10) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertPunchTable Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertPunchTable Method (IView)

Inserts a punch table in the flat pattern drawing view of a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertPunchTable( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal StartValue As System.String, _  
    ByVal TableTemplate As System.String _  
) As PunchTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseAnchorPoint As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim AnchorType As System.Integer  
Dim StartValue As System.String  
Dim TableTemplate As System.String  
Dim value As PunchTableAnnotation
```

```
value = instance.InsertPunchTable(UseAnchorPoint, X, Y, AnchorType, StartValue, TableTemplate)
```

C#

```
PunchTableAnnotation InsertPunchTable(  
    System.bool UseAnchorPoint,  
    System.double X,  
    System.double Y,  
    System.int AnchorType,  
    System.string StartValue,  
    System.string TableTemplate  
)
```

C++/CLI

```
PunchTableAnnotation^ InsertPunchTable(  
& System.bool UseAnchorPoint,  
& System.double X,  
& System.double Y,  
& System.int AnchorType,  
& System.String^ StartValue,  
& System.String^ TableTemplate  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true, and the sheet format anchor point exists, then insert table at the anchor point; if false, then insert the table at the location specified by the X and Y parameters

X

X coordinate for the anchor of this punch table

Y

Y coordinate for the anchor of this punch table

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

StartValue

Starting value for datum tags; a letter from A to Z, if TableTemplate uses letter tags; a positive integer, if TableTemplate uses number tags (see **Remarks**)

TableTemplate

Path and filename of the table template that corresponds to the type of table you want to use (see **Remarks**)

Return Value

[IPunchTableAnnotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertPunchTable](#).

Example

[Insert Punch Table \(VBA\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(C#\)](#)

Remarks

Punch tables contain information about the punches that are created by forming tools in sheet metal parts. This method inserts a punch table with the following information for pre-selected punches:

Column	Description
TAG	Datum tag added to each punch in the flat pattern view
PUNCH ID	Property of the forming tool or library feature
X Location	Distance from the x-axis to the point of insertion of the forming tool in the flat pattern view
Y Location	Distance from the y-axis to the point of insertion of the forming tool in the flat pattern view
ANGLE	Angle between the x-axis and the forming tool
QUANTITY	Number of times that the punch occurs in the flat pattern view

The locations of the datum tags are relative to a datum origin that is pre-selected in the view.

Before calling this method, call [IModelDocExtension::SelectByID2](#) to select the datum origin, punch edges, and punch faces (for multiple punches) as follows:

Selection	Mark
Datum origin vertex	1
Punch edges and faces	2
Datum origin x-axis direction reference	4
Datum origin y-axis direction reference	8

Specify TableTemplate using a punch table template (*.sldpuntbt) in *install_dir\lang\language*.

Specify a StartValue that matches the table you want to create. For example, to insert a punch table with letter tags, specify a StartValue with a letter from A to Z.

See Also

[IView Interface](#)
[IView Members](#)
[IPunchTable Interface](#)
[IFeatureManager::CreateFormTool Method](#)
[ILibraryFormToolFeatureData Interface](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

InsertViewAsBlock Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertViewAsBlock Method (IView)

Creates a sketch block from this view and aligns the specified manipulator point with the specified sketch block position on the drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertViewAsBlock( _  
    ByVal InsertionPoint As MathPoint, _  
    ByVal Position As MathPoint _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim InsertionPoint As MathPoint  
Dim Position As MathPoint  
Dim value As System.Boolean  
  
value = instance.InsertViewAsBlock(InsertionPoint, Position)
```

C#

```
System.bool InsertViewAsBlock(  
    MathPoint InsertionPoint,  
    MathPoint Position  
)
```

C++/CLI

```
System.bool InsertViewAsBlock(  
& MathPoint^ InsertionPoint,  
& MathPoint^ Position  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InsertionPoint

[IMathPoint](#) in this view where the manipulator of the new [sketch block](#) is located

Position

[IMathPoint](#) on the drawing sheet where the new sketch block manipulator is positioned

Return Value

True if the view is successfully converted to a sketch block, false if not

Visual Basic for Applications (VBA) Syntax

See [View::InsertViewAsBlock](#).

Example

[Convert Drawing Views to Sketch Blocks \(VBA\)](#)
[Convert Drawing Views to Sketch Blocks \(VB.NET\)](#)
[Convert Drawing Views to Sketch Blocks \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::ReplaceViewWithBlock Method](#)
[IView::ReplaceViewWithSketch Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertWeldmentTable Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertWeldmentTable Method (IView)

Inserts a weldment cut-list table into this drawing view.

.NET Syntax

```

Function InsertWeldmentTable( _
    ByVal UseAnchorPoint As System.Boolean, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal AnchorType As System.Integer, _
    ByVal Configuration As System.String, _
    ByVal TableTemplate As System.String _
) As WeldmentCutListAnnotation

```

```

Dim instance As IView
Dim UseAnchorPoint As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim AnchorType As System.Integer
Dim Configuration As System.String
Dim TableTemplate As System.String
Dim value As WeldmentCutListAnnotation

value = instance.InsertWeldmentTable(UseAnchorPoint, X, Y, AnchorType, Configuration,
TableTemplate)

```

```

WeldmentCutListAnnotation InsertWeldmentTable(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.string Configuration,
    System.string TableTemplate
)

```

```

WeldmentCutListAnnotation^ InsertWeldmentTable(
    & System.bool UseAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.String^ Configuration,
    & System.String^ TableTemplate
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true and the appropriate sheet format anchor point exists, then insert table at this point; if false, then use the values specified for the X and Y arguments as the insertion point

X

X coordinate for the placement of the weldment cut-list table; valid only if UserAnchorPoint = False

Y

Y coordinate for the placement of the weldment cut-list table; valid only if UseAnchorPoint = False

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

Configuration

Name of the "As Welded" configuration for the weldment cut-list table

TableTemplate

Path and filename of the template that corresponds to this type of table (see **Remarks**)

Return Value

[Weldment cut-list annotation](#)

Visual Basic for Applications (VBA) Syntax

See [View::InsertWeldmentTable](#).

Example

[Insert Weldment Cut List Table \(VBA\)](#)
[Insert Weldment Cut List Table \(VB.NET\)](#)
[Insert Weldment Cut List Table \(C#\)](#)

Remarks

The weldment cut-list table template installed with SOLIDWORKS is <SOLIDWORKS_install_dir>\lang\<language>\cut list.sldwtdtbl.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOMName Method](#)
[IView::SetKeepLinkedToBOM Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertWeldTable Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : InsertWeldTable Method (IView)

Inserts a weld table into this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertWeldTable( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal IncludeAnnotations As System.Boolean, _  
    ByVal CombineSameType As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal Configuration As System.String, _  
    ByVal TableTemplate As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseAnchorPoint As System.Boolean  
Dim IncludeAnnotations As System.Boolean  
Dim CombineSameType As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim AnchorType As System.Integer  
Dim Configuration As System.String  
Dim TableTemplate As System.String  
Dim value As System.Boolean
```

```
value = instance.InsertWeldTable(UseAnchorPoint, IncludeAnnotations, CombineSameType, X, Y,  
AnchorType, Configuration, TableTemplate)
```

C#

```
System.bool InsertWeldTable(  
    System.bool UseAnchorPoint,  
    System.bool IncludeAnnotations,  
    System.bool CombineSameType,  
    System.double X,  
    System.double Y,  
    System.int AnchorType,  
    System.string Configuration,
```

```
        System.string TableTemplate
    )
}
```

C++/CLI

```
System.bool InsertWeldTable(
& System.bool UseAnchorPoint,
& System.bool IncludeAnnotations,
& System.bool CombineSameType,
& System.double X,
& System.double Y,
& System.int AnchorType,
& System.String^ Configuration,
& System.String^ TableTemplate
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true and the appropriate sheet format anchor point exists, then insert the table at the anchor point; if false, then use the values specified for the X and Y arguments as the insertion point

IncludeAnnotations

True to include weld symbols not attached to cosmetic weld features, false to not

CombineSameType

True to group welds having the same weld symbol and weld size, false to not

X

X coordinate in meters for the placement of the weld table; valid only if UseAnchorPoint = False

Y

Y coordinate in meters for the placement of the weld table; valid only if UseAnchorPoint = False

AnchorType

Anchor type as defined by [swBomConfigurationAnchorType_e](#)

Configuration

Name of the part configuration for which to insert the weld table

TableTemplate

Path and filename of the template that corresponds to this type of table (see **Remarks**)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [View::InsertWeldTable](#).

Example

[Insert Weld Table \(VBA\)](#)

[Insert Weld Table \(VB.NET\)](#)

[Insert Weld Table \(C#\)](#)

Remarks

The weld table template installed with SOLIDWORKS is <SOLIDWORKS_install_dir>\lang\<language>\weldtable-standard.sldwldtbt.

See Also

[IView Interface](#)

[IView Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPosition Property (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IPosition Property (IView)

Gets or sets the X and Y location of the model view's geometric center, relative to the drawing sheet origin.

.NET Syntax

Visual Basic (Declaration)

Property IPosition As System.Double

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
instance.IPosition = value  
  
value = instance.IPosition
```

C#

```
System.double IPosition {get; set;}
```

C++/CLI

```
property System.double IPosition {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of 2 doubles (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [View::IPosition](#).

Remarks

Any view alignments that might affect this view are handled the same way as if you were using the SOLIDWORKS Design user interface to draw the view to move it. If it is aligned with another view, it will only be allowed to move along the alignment vector. If it has child views that are aligned with it, those views will also be moved along with this view.

Changing this property can cause changes to the graphics of the drawing. After making all the view-related changes, call [IModelDoc2::EditRebuild3](#) to regenerate the drawing to see these changes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::Position Property](#)
[IView::SetXform Method](#)
[IView::IGetXform Method](#)
[IView::IGetXform Method](#)
[IView::GetXform Method](#)
[IView::GetViewXform Method](#)
[IView::IGetViewXform Method](#)
[IView::ModelToViewTransform Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsBroken Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsBroken Method (IView)

Gets whether the drawing view is displayed with a break.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBroken() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean
```

```
value = instance.IsBroken()
```

C#

```
System.bool IsBroken()
```

C++/CLI

```
System.bool IsBroken();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the view is displayed with a break, false if not

Visual Basic for Applications (VBA) Syntax

See [View::IsBroken](#).

Remarks

This method indicates if the view is displayed broken, not if the view has break lines.

A drawing view can have break lines without the break being applied. To determine if a view has break lines, use [View::GetBreakLineCount](#) or [View::GetBreakLines](#) or [View::IGetBreakLines](#).

See Also

[IView Interface](#)
[IView Members](#)
[View::IGetBreakLineInfo Method](#)
[View::GetBreakLineCount Method](#)
[View::GetBreakLineInfo Method](#)
[View::BreakLineGap Property](#)
[View::InsertBreak Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IScaleRatio Property (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IScaleRatio Property (IView)

Gets or sets the scale of the drawing view, returning the results in ratio format (n:n).

.NET Syntax

Visual Basic (Declaration)

```
Property IScaleRatio As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Double  
  
instance.IScaleRatio = value  
value = instance.IScaleRatio
```

C#

```
System.double IScaleRatio {get; set;}
```

C++/CLI

```
property System.double IScaleRatio {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of 2 doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::IScaleRatio](#).

Remarks

The two values represent the two numbers if the scale is described as a ratio. The first value is the numerator; the second value is the denominator. This is what the scale is when represented as n:n.

This property and [IView::ScaleDecimal](#) contain the same information, but use the value in a different form.

- IView::ScaleRatio returns the scale as a ratio of two numbers.
- IView::ScaleDecimal returns the scale as a decimal number.

For example, if View::ScaleRatio returns 3 2 or 3:2, then IView::ScaleDecimal would return 1.5.

Changing this property may cause changes to the graphics of the drawing. After making all of the view-related changes, call [IModelDoc2::EditRebuild3](#) to regenerate the drawing to see these changes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::UseParentScale Property](#)
[IView::UseSheetScale Property](#)
[IView::ScaleRatio Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsCropped Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsCropped Method (IView)

Get whether this drawing view is cropped.

.NET Syntax

Visual Basic (Declaration)

```
Function IsCropped() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IView
Dim value As System.Boolean

value = instance.IsCropped()
```

C#

```
System.bool IsCropped()
```

C++/CLI

```
System.bool IsCropped();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the drawing view is cropped, false if not



Visual Basic for Applications (VBA) Syntax

See [View::IsCropped](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::Crop2 Method \(\)](#)
[IView::CropViewJaggedOutline Property \(\)](#)
[IView::CropViewJaggedShapeIntensity Property \(\)](#)
[IView::CropViewNoOutline Property \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISelectEntity Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ISelectEntity Method (IView)

Selects an entity in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function ISelectEntity( _  
    ByVal Entity As Entity, _  
    ByVal AppendFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Entity As Entity  
Dim AppendFlag As System.Boolean  
Dim value As System.Boolean  
  
value = instance.ISelectEntity(Entity, AppendFlag)
```

C#

```
System.bool ISelectEntity(  
    Entity Entity,  
    System.bool AppendFlag  
)
```

C++/CLI

```
System.bool ISelectEntity(  
& Entity^ Entity,  
& System.bool AppendFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entity

[Entity](#)

AppendFlag

True appends the entity to the selection list, false replaces the selection list with the entity

Return Value

True if the entity was selected, false if not

Visual Basic for Applications (VBA) Syntax

See [View::ISelectEntity](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::ISelectEntity Method](#)
[IModelDocExtension::SelectAll Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetBodies Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ISetBodies Method (IView)

Sets the bodies of a multibody part to include in the view.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetBodies( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArray As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Count As System.Integer  
Dim BodyArray As Body2  
  
instance.ISetBodies(Count, BodyArray)
```

C#

```
void ISetBodies(  
    System.int Count,  
    ref Body2 BodyArray  
)
```

C++/CLI

```
void ISetBodies(  
& System.int Count,  
& Body2^% BodyArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of bodies in a multibody part

BodyArray

- in-process, unmanaged C++: Pointer to an array of [bodies](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

- See [In-process Methods](#) for details about this type of method.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IGetBodies Method](#)
[IView::Bodies Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetXform Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ISetXform Method (IView)

Sets the matrix used for display of this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetXform( _  
    ByRef Transform As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Transform As System.Double  
Dim value As System.Boolean  
  
value = instance.ISetXform(Transform)
```

C#

```
System.bool ISetXform(  
    ref System.double Transform  
)
```

C++/CLI

```
System.bool ISetXform(  
& System.double% Transform  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Transform

Array of 3 doubles (see **Remarks**)

Return Value

True if transform successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [View::ISetXform](#).

Remarks

The 3 doubles are the X and Y position of the view, relative to the sheet origin, and the scale of the view.

Any view alignments that might affect this view are handled the same way as if you were using the user interface to draw the view to move it. If it is aligned with another view, then it will only move along the alignment vector. If it has child views that are aligned with it, then those views will also be moved along with this view.

Calling this method is equivalent to setting the [IView::Position](#) or [IView::IPosition](#) property (to set X and Y), and the [IView::ScaleDecimal](#) property (to set the scale).

To get the view matrix, use [IView::GetXform](#) or [IView::IGetXform](#) method.

Using this method may cause changes to the graphics of the drawing. Once all the view-related changes have been made, the user should call [IModelDoc2::EditRebuild3](#) to regenerate the drawing, in order to see these changes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::SetXform Method](#)
[IView::GetViewXform Method](#)
[IView::IGetViewXform Method](#)
[IView::ModelToViewTransform Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsExploded Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsExploded Method (IView)

Gets whether the drawing view is currently showing the assembly as exploded or collapsed.

.NET Syntax

Visual Basic (Declaration)

```
Function IsExploded() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
value = instance.IsExploded()
```

C#

```
System.bool IsExploded()
```

C++/CLI

```
System.bool IsExploded();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this drawing view is showing an exploded assembly view, false if collapsed

Visual Basic for Applications (VBA) Syntax

See [View::IsExploded](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::ShowExploded Method \(\)](#)
[IModelDocExtension::IsExploded Method \(\)](#)
[IAssemblyDoc::AutoExplode Method \(\)](#)
[IAssemblyDoc::CreateExplodedView Method \(\)](#)
[IAssemblyDoc::GetExplodedViewConfigurationName Method \(\)](#)
[IAssemblyDoc::GetExplodedViewCount2 Method \(\)](#)
[IAssemblyDoc::GetExplodedViewNames2 Method \(\)](#)
[IAssemblyDoc::ShowExploded2 Method \(\)](#)
[IAssemblyDoc::ViewCollapseAssembly Method \(\)](#)
[IAssemblyDoc::ViewExplodeAssembly Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsFlatPatternView Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsFlatPatternView Method (IView)

Gets whether a drawing view is a flat-pattern drawing view.

.NET Syntax

Visual Basic (Declaration)

Function IsFlatPatternView() As System.Boolean

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

value = instance.IsFlatPatternView()
```

C#

```
System.bool IsFlatPatternView()
```

C++/CLI

```
System.bool IsFlatPatternView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this drawing view is a flat-pattern drawing view, false if not

Visual Basic for Applications (VBA) Syntax

See [View::IsFlatPatternView](#).

Example

[Get Tangent Edges of Bendlines \(VB.NET\)](#)
[Get Tangent Edges of Bendlines \(VBA\)](#)
[Get Tangent Edges of Bendlines \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView3 Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsLightweight Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsLightweight Method (IView)

Gets whether the drawing view is lightweight.

.NET Syntax

Visual Basic (Declaration)

```
Function IsLightweight() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

value = instance.IsLightweight()
```

C#

```
System.bool IsLightweight()
```

C++/CLI

```
System.bool IsLightweight();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if lightweight, false if not

Visual Basic for Applications (VBA) Syntax

See [View::IsLightweight](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::SetLightweightToResolved Method](#)
[IView::SetResolvedToLightweight Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsModelBreakState Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsModelBreakState Method (IView)

Gets whether this drawing view is a Model Break View.

.NET Syntax

Visual Basic (Declaration)

```
Function IsModelBreakState() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
value = instance.IsModelBreakState()
```

C#

```
System.bool IsModelBreakState()
```

C++/CLI

```
System.bool IsModelBreakState();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a Model Break View, false if not

Visual Basic for Applications (VBA) Syntax

See [View::IsModelBreakState](#).

Example

[Get and Set Model Break View Display \(VBA\)](#)
[Get and Set Model Break View Display \(VB.NET\)](#)
[Get and Set Model Break View Display \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::ShowModelBreakState Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsModelLoaded Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsModelLoaded Method (IView)

Gets whether the model is loaded in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IsModelLoaded() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
value = instance.IsModelLoaded()
```

C#

```
System.bool IsModelLoaded()
```

C++/CLI

```
System.bool IsModelLoaded();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the model has been loaded, false if not

Visual Basic for Applications (VBA) Syntax

See [View::IsModelLoaded](#).

Remarks

If the drawing document was loaded as Detached, then the return value will be false. To load the model, use [IView::LoadModel](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IsModelOutOfDate Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsModelOutOfDate Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsModelOutOfDate Method (IView)

Gets whether the model in this drawing view is up-to-date with the current model.

.NET Syntax

Visual Basic (Declaration)

```
Function IsModelOutOfDate() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
value = instance.IsModelOutOfDate()
```

C#

```
System.bool IsModelOutOfDate()
```

C++/CLI

```
System.bool IsModelOutOfDate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the view is out of date, false if not

Visual Basic for Applications (VBA) Syntax

See [View::IsModelOutOfDate](#).

Remarks

A model can be out-of-date in a Detached drawing where the model is not loaded, if any of the views in any of the sheets in the drawing refers to a model that has been modified and saved to disk since this drawing was last saved. This situation is flagged upon opening a document as well.

If you are using [ISldWorks::OpenDoc6](#) with the silent option enabled, this warning is returned via the Warnings argument by value `swFileLoadWarning_ModelOutOfDate`. If you print this drawing and have the `swRapidDraftPrintOutOfSynchWaterMark` user preference enabled (see [ISldWorks::SetUserPreferenceToggle](#)), then the printout will indicate this drawing as being out-of-synch.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IsModelLoaded Method](#)
[IView::LoadModel Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsPerspectiveView Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : IsPerspectiveView Method (IView)

Gets whether this drawing view is showing a perspective view of the model.

.NET Syntax

Visual Basic (Declaration)

```
Function IsPerspectiveView() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean
```

```
value = instance.IsPerspectiveView()
```

C#

```
System.bool IsPerspectiveView()
```

C++/CLI

```
System.bool IsPerspectiveView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if perspective view is shown, false if not

Visual Basic for Applications (VBA) Syntax

See [View::IsPerspectiveView](#).

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LinkParentConfiguration Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : LinkParentConfiguration Property (IView)

Gets or sets whether to link a projected or auxiliary view with the parent configuration.

.NET Syntax

Visual Basic (Declaration)

```
Property LinkParentConfiguration As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

instance.LinkParentConfiguration = value

value = instance.LinkParentConfiguration
```

C#

```
System.bool LinkParentConfiguration {get; set;}
```

C++/CLI

```
property System.bool LinkParentConfiguration {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to link a projected or auxiliary view with the parent configuration, false to not

Visual Basic for Applications (VBA) Syntax

See [View::LinkParentConfiguration](#).

Example

[Link Projected View to Parent Configuration \(C#\)](#)
[Link Projected View to Parent Configuration \(VB.NET\)](#)
[Link Projected View to Parent Configuration \(VBA\)](#)

Remarks

After setting this property, call [IModelDoc2::EditRebuild3](#).

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LoadModel Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : LoadModel Method (IView)

Loads the model if the model has not already been loaded for this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function LoadModel() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.LoadModel()
```

C#

```
System.int LoadModel()
```

C++/CLI

```
System.int LoadModel();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

0 if the model was loaded, -1 if not

Visual Basic for Applications (VBA) Syntax

See [View::LoadModel](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IsModelLoaded Method](#)
[IView::IsModelOutOfDate Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MergeBendTags Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : MergeBendTags Method (IView)

Merges or unmerges bend tags in drawings of sheet metal parts.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function MergeBendTags( _  
    ByVal Merge As System.Boolean, _  
    ByVal BendNotes As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Merge As System.Boolean  
Dim BendNotes As System.Object  
Dim value As System.Boolean  
  
value = instance.MergeBendTags(Merge, BendNotes)
```

C#

```
System.bool MergeBendTags(  
    System.bool Merge,  
    System.object BendNotes  
)
```

C++/CLI

```
System.bool MergeBendTags(  
& System.bool Merge,  
& System.Object^ BendNotes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Merge

True to merge bend tags, false to unmerge a merged bend tag

BendNotes

Array of two or more bend [tags](#) to merge or an array of one merged bend tag to unmerge

Return Value

True if the bend tags are merged or a merged bend tag is unmerged, false if not

Visual Basic for Applications (VBA) Syntax

See [View::MergeBendTags](#).

Example

[Merge and Unmerge Bend Tags \(C#\)](#)

[Merge and Unmerge Bend Tags \(VB.NET\)](#)

[Merge and Unmerge Bend Tags \(VBA\)](#)

Remarks

To...

Do...

Merge two or more bend tags	1. Select the bend tags to merge. 2. Select the drawing view in which the bend tags exist. 3. Call this method with the Merge parameter set to true. 4. Rebuild the drawing.
Unmerge a merged bend tag	1. Select the drawing view in which the merged bend tag exists. 2. Activate the drawing view in which the merged bend tag exists. 3. Select the merged bend tag to unmerge. 4. Call this method with the Merge parameter set to false.

See Also

[IView Interface](#)
[IView Members](#)
[INote.IsBendLineNote Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ModelToViewTransform Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ModelToViewTransform Property (IView)

Gets the math transform to go from model to drawing view space.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property ModelToViewTransform As MathTransform
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As MathTransform

instance.ModelToViewTransform = value

value = instance.ModelToViewTransform
```

C#

```
MathTransform ModelToViewTransform {get; set;}
```

C++/CLI

```
property MathTransform^ ModelToViewTransform {
    MathTransform^ get();
    void set ( & MathTransform^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Math transform](#)

Visual Basic for Applications (VBA) Syntax

See [View::ModelToViewTransform](#).

Example

[Dimension Edge in Drawing \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)

[IView::GetViewXform Method](#)
[IView::GetXform Method](#)
[IView::IGetViewXform Method](#)
[IView::IGetXform Method](#)
[IView::ISetXform Method](#)
[IView::SetXform Method](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : Name Property (IView)

Obsolete. Superseded by [IView::GetName2](#) and [IView::SetName2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::Name](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Position Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : Position Property (IView)

Gets or sets the X and Y location of the model view's geometric center, relative to the drawing sheet origin.

.NET Syntax

Visual Basic (Declaration)

```
Property Position As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Object
```

```
instance.Position = value
```

```
value = instance.Position
```

C#

```
System.Object Position {get; set;}
```

C++/CLI

```
property System.Object^ Position {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of 2 doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::Position](#).

Example

[Insert and Position DXF File in Drawing \(VBA\)](#)
[Reposition Drawing Views to Avoid Overlap \(VBA\)](#)
[Get View Bounding Box and Position \(C#\)](#)
[Get View Bounding Box and Position \(VB.NET\)](#)
[Get View Bounding Box and Position \(VBA\)](#)

Remarks

Any view alignments that might affect this view are handled the same way as if you were using the SOLIDWORKS Design user interface to draw the view to move it. If it is aligned with another view, it will only be allowed to move along the alignment vector. If it has child views that are aligned with it, those views will also be moved along with this view.

Changing this property can cause changes to the graphics of the drawing. After making all the view-related changes, call [IModelDoc2::EditRebuild3](#) to regenerate the drawing to see these changes.

To move a drawing view independently of its child views, use [IView::SetViewPosition](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IPosition Property](#)
[IView::ModelToViewTransform Property](#)
[IView::SetXform Method](#)
[IView::ISetXform Method](#)
[IView::IGetXform Method](#)
[IView::IGetViewXform Method](#)
[IView::GetXform Method](#)
[IView::GetViewXform Method](#)
[IView::PositionLocked Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

PositionLocked Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : PositionLocked Property (IView)

Gets or sets whether this drawing view's position is locked.

.NET Syntax

Visual Basic (Declaration)

```
Property PositionLocked As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

instance.PositionLocked = value

value = instance.PositionLocked
```

C#

```
System.bool PositionLocked {get; set;}
```

C++/CLI

```
property System.bool PositionLocked {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if view position is locked, false if not

Visual Basic for Applications (VBA) Syntax

See [View::PositionLocked](#).

Example

[Get View Bounding Box and Position \(VBA\)](#)
[Get View Bounding Box and Position \(VB.NET\)](#)
[Get View Bounding Box and Position \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::Position Property](#)

Availability

SOLIDWORKS 2016 SP2, Revision Number 24.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

ProjectedDimensions Property (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ProjectedDimensions Property (IView)

Gets or sets whether dimensions in this view are true or projected.

.NET Syntax

Visual Basic (Declaration)

```
Property ProjectedDimensions As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

instance.ProjectedDimensions = value

value = instance.ProjectedDimensions
```

C#

```
System.bool ProjectedDimensions {get; set;}
```

C++/CLI

```
property System.bool ProjectedDimensions {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the dimensions in this drawing view are projected measurements, false if the dimensions in this drawing view are true measurements

Visual Basic for Applications (VBA) Syntax

See [View::ProjectedDimensions](#).

Remarks

Existing dimensions in this drawing view are deleted when this property is changed.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDimensionCount4 Method](#)
[IView::GetDimensionIds4 Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::GetDimensionString4 Method](#)
[IView::IGetDimensionIds4 Method](#)
[IView::IGetDimensionInfo6 Method](#)
[IView::IGetDimensionString4 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReferencedConfiguration Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ReferencedConfiguration Property (IView)

Gets or sets the configuration referenced by this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Property ReferencedConfiguration As System.String
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.String  
  
instance.ReferencedConfiguration = value  
  
value = instance.ReferencedConfiguration
```

C#

```
System.string ReferencedConfiguration {get; set;}
```

C++/CLI

```
property System.String^ ReferencedConfiguration {  
    System.String^ get();  
}
```

```
void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the configuration for the drawing view

Visual Basic for Applications (VBA) Syntax

See [View::ReferencedConfiguration](#).

Example

[Get Configurations Referenced in View \(C#\)](#)
[Get Configurations Referenced in View \(VB.NET\)](#)
[Get Configurations Referenced in View \(VBA\)](#)

Remarks

After changing the configuration, you must call [IModelDoc2::EditRebuild3](#) to see the changes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetReferencedModelName Method](#)
[IView::ReferencedDocument Property](#)
[IView::ReferencedConfigurationID Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferencedConfigurationID Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ReferencedConfigurationID Property (IView)

Gets the persistent reference ID of the configuration referenced in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferencedConfigurationID As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
value = instance.ReferencedConfigurationID
```

C#

```
System.int ReferencedConfigurationID {get;}
```

C++/CLI

```
property System.int ReferencedConfigurationID {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Referenced configuration's persistent reference ID

Visual Basic for Applications (VBA) Syntax

See [View::ReferencedConfigurationID](#).

Example

[Get Configurations Referenced in View \(C#\)](#)
[Get Configurations Referenced in View \(VB.NET\)](#)
[Get Configurations Referenced in View \(VBA\)](#)

Remarks

See [Persistent Reference IDs](#) for more information.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetReferencedModelName Method \(\)](#)
[IView::ReferencedConfiguration Property \(\)](#)
[IView::ReferencedDocument Property \(\)](#)
[IModelDocExtension::GetObjectByPersistReference3 Method \(\)](#)
[IModelDocExtension::GetPersistReference3 Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferencedDocument Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ReferencedDocument Property (IView)

Gets the document referenced by this drawing view.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ReferencedDocument As ModelDoc2

Visual Basic (Usage)



```
Dim instance As IView
Dim value As ModelDoc2

value = instance.ReferencedDocument
```

C#

```
ModelDoc2 ReferencedDocument {get;}
```

C++/CLI

```
property ModelDoc2^ ReferencedDocument {
    ModelDoc2^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Model document](#)

Visual Basic for Applications (VBA) Syntax

See [View::ReferencedDocument](#).

Example

[Get Document Referenced by Drawing View \(VBA\)](#)
[Set Body for View \(C#\)](#)
[Set Body for View \(VB.NET\)](#)
[Set Body for View \(VBA\)](#)

Remarks

Because section views do not have referenced documents, this method returns an empty string for this type of view. Instead, use [IView::GetBaseView](#) or [IView::!GetBaseView](#) to get the parent view of a section, and then get its referenced document from that view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::ReferencedConfiguration Property](#)
[IView::GetReferencedModelName Method](#)
[IView::ReferencedConfigurationID Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveAlignment Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : RemoveAlignment Method (IView)

Removes the alignment from this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub RemoveAlignment()
```

Visual Basic (Usage)



```
Dim instance As IView  
instance.RemoveAlignment()
```

C#

```
void RemoveAlignment()
```

C++/CLI

```
void RemoveAlignment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::RemoveAlignment](#).

Remarks

Using this method on a view only removes the alignment information from that view. It does not remove the alignments any child views have with this view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::AlignWithView Method](#)
[IView::UseDefaultAlignment Method](#)
[IView::GetAlignment Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReplaceViewWithBlock Method (IView)

[See Also](#) [Example](#)



Converts this view into a sketch block with the specified manipulator location.

.NET Syntax

Visual Basic (Declaration)

```
Function ReplaceViewWithBlock( _
    ByVal InsertionPoint As MathPoint _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IView
Dim InsertionPoint As MathPoint
Dim value As System.Boolean

value = instance.ReplaceViewWithBlock(InsertionPoint)
```

C#

```
System.bool ReplaceViewWithBlock(
    MathPoint InsertionPoint
)
```

C++/CLI

```
System.bool ReplaceViewWithBlock(
    & MathPoint^ InsertionPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InsertionPoint
[IMathPoint](#) in this view where the manipulator of the new [sketch block](#) is located

Return Value

True if the view is successfully replaced with a sketch block, false if not

Visual Basic for Applications (VBA) Syntax

See [View::ReplaceViewWithBlock](#).

Example

[Convert Drawing Views to Sketch Blocks \(VBA\)](#)
[Convert Drawing Views to Sketch Blocks \(VB.NET\)](#)
[Convert Drawing Views to Sketch Blocks \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::InsertViewAsBlock Method](#)
[IView::ReplaceViewWithSketch Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

ReplaceViewWithSketch Method (IView)

See Also [Example](#)



Converts this view into a sketch.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ReplaceViewWithSketch() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
value = instance.ReplaceViewWithSketch()
```

C#

```
System.bool ReplaceViewWithSketch()
```

C++/CLI

```
System.bool ReplaceViewWithSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the view is successfully replaced with a [sketch](#), false if not

Visual Basic for Applications (VBA) Syntax

See [View::ReplaceViewWithSketch](#).

Example

[Convert Drawing Views to Sketch Blocks \(VBA\)](#)
[Convert Drawing Views to Sketch Blocks \(VB.NET\)](#)
[Convert Drawing Views to Sketch Blocks \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::ReplaceViewWithBlock Method](#)
[IView::InsertViewAsBlock Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ResetSketchVisibility Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ResetSketchVisibility Method (IView)

Resets the visibility of the sketches in the drawing view so that the drawing view reflects the model.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ResetSketchVisibility()
```

Visual Basic (Usage)



```
Dim instance As IView  
  
instance.ResetSketchVisibility()
```

C#

```
void ResetSketchVisibility()
```

C++/CLI

```
void ResetSketchVisibility();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::ResetSketchVisibility](#).

Example

[Reset Visibility of Sketches in Drawing View \(C#\)](#)
[Reset Visibility of Sketches in Drawing View \(VB.NET\)](#)
[Reset Visibility of Sketches in Drawing View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2011 SP01, Revision Number 19.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

RootDrawingComponent Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : RootDrawingComponent Property (IView)

Obsolete. Superseded by [IView::RootDrawingComponent2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property RootDrawingComponent As DrawingComponent
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As DrawingComponent  
  
value = instance.RootDrawingComponent
```

C#

```
DrawingComponent RootDrawingComponent {get;}
```

C++/CLI

```
property DrawingComponent^ RootDrawingComponent {  
    DrawingComponent^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Drawing component](#)

Visual Basic for Applications (VBA) Syntax

See [View::RootDrawingComponent](#).

Example

[Create Section View at Specified Location \(VBA\)](#)
[Get Components Properties in Drawing View \(VBA\)](#)
[Hide Drawing Components \(VBA\)](#)
[Put Assembly Components in Drawing View on Different Layers \(VBA\)](#)
[Get Components in Drawing View \(C#\)](#)
[Get Components in Drawing View \(VB.NET\)](#)
[Get Components in Drawing View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RootDrawingComponent2 Property (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : RootDrawingComponent2 Property (IView)

Gets the root component of this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property RootDrawingComponent2( _  
    ByVal InChildContext As System.Boolean _  
) As DrawingComponent
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim InChildContext As System.Boolean  
Dim value As DrawingComponent  
  
value = instance.RootDrawingComponent2(InChildContext)
```

C#

```
DrawingComponent RootDrawingComponent2(  
    System.bool InChildContext  
) {get;}
```

C++/CLI

```
property DrawingComponent^ RootDrawingComponent2 {  
    DrawingComponent^ get(System.bool InChildContext);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InChildContext

True to return the temporary root component of this section view, false to return the root drawing component of this view's parent view (see **Remarks**)

Property Value

[Drawing component](#)

Visual Basic for Applications (VBA) Syntax

See [View::RootDrawingComponent2](#).

Remarks

For all drawing views except section views, this property returns the root drawing component of the drawing view's parent view. For section views only, this property returns the root drawing component of the temporary assembly that is created specifically for the section view. To access the real root drawing component of the section view, first call [IView::GetBaseView](#) to get the section view's base view. Then use this property to get the root drawing drawing component.

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2026 SP02, Revision Number 34.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ScaleDecimal Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ScaleDecimal Property (IView)

Gets or sets the scale of the drawing view, returning the results in decimal format.

.NET Syntax

Visual Basic (Declaration)

```
Property ScaleDecimal As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Double

instance.ScaleDecimal = value
value = instance.ScaleDecimal
```

C#

```
System.double ScaleDecimal {get; set;}
```

C++/CLI

```
property System.double ScaleDecimal {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Drawing view scale

Visual Basic for Applications (VBA) Syntax

See [View::ScaleDecimal](#).

Example

[Set View Scale \(VBA\)](#)

Remarks

[IView::ScaleRatio](#) or [IView::!ScaleRatio](#) and this property contain the same information, but use the value in different ways:

- [IView::ScaleRatio](#) gets or sets the scale as a ratio of two numbers.
- [IView::ScaleDecimal](#) returns the scale as a decimal number.

For example, if [View::ScaleRatio](#) returns 3 2 or 3:2, then [IView::ScaleDecimal](#) would return 1.5.

Changing this property can cause changes to the graphics of the drawing. After making all the of the view-related changes, call the [IModelDoc2::EditRebuild2](#) method to regenerate the drawing to see these changes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::UseParentScale Property](#)
[IView::UseSheetScale Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ScaleHatchPattern Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ScaleHatchPattern Property (IView)

Gets or sets whether to scale the hatch pattern to the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Property ScaleHatchPattern As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Boolean

instance.ScaleHatchPattern = value
value = instance.ScaleHatchPattern
```

C#

```
System.bool ScaleHatchPattern {get; set;}
```

C++/CLI

```
property System.bool ScaleHatchPattern {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to scale the hatch pattern to the drawing view, false to not

Visual Basic for Applications (VBA) Syntax

See [View::ScaleHatchPattern](#).

Example

[Get Area Hatch Data \(C#\)](#)
[Get Area Hatch Data \(VB.NET\)](#)
[Get Area Hatch Data \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetFaceHatchCount Method \(\)](#)
[IView::GetFaceHatches Method \(\)](#)
[IModelDoc2::InsertHatchedFace Method \(\)](#)

Availability

ScaleRatio Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ScaleRatio Property (IView)

Gets or sets the scale of the drawing view, returning the results in ratio format (n:n).

.NET Syntax

Visual Basic (Declaration)

Property ScaleRatio As System.Object

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Object

instance.ScaleRatio = value

value = instance.ScaleRatio
```

C#

```
System.Object ScaleRatio {get; set;}
```

C++/CLI

```
property System.Object^ ScaleRatio {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of 2 doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [View::ScaleRatio](#).

Example

[Set View Scale \(VBA\)](#)

Remarks

The two values represent the two numbers if the scale is described as a ratio. The first value is the numerator; the second value is the denominator. This is what the scale is when represented as n:n.

This property and [IView::ScaleDecimal](#) contain the same information, but use the value in a different form.

- IView::ScaleRatio returns the scale as a ratio of two numbers.
- IView::ScaleDecimal returns the scale as a decimal number.

For example, if View::ScaleRatio returns 3 2 or 3:2, then IView::ScaleDecimal would return 1.5.

Changing this property may cause changes to the graphics of the drawing. After making all of the view-related changes, call [IModelDoc2::EditRebuild3](#) to regenerate the drawing to see these changes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::IScaleRatio Property](#)
[IView::UseParentScale Property](#)
[IView::UseSheetScale Property](#)

SelectEntity Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SelectEntity Method (IView)

Selects an entity in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function SelectEntity( _  
    ByVal Entity As System.Object, _  
    ByVal AppendFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Entity As System.Object  
Dim AppendFlag As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SelectEntity(Entity, AppendFlag)
```

C#

```
System.bool SelectEntity(  
    System.object Entity,  
    System.bool AppendFlag.  
)
```

C++/CLI

```
System.bool SelectEntity(  
& System.Object^ Entity,  
& System.bool AppendFlag.  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entity

[Entity](#)

AppendFlag

True appends the entity to the selection list, false replaces the selection list with the entity

Visual Basic for Applications (VBA) Syntax

See [View::SelectEntity](#).

Example

[Create Layer for Selected View \(VBA\)](#)

[Dimension Edge in Drawing \(VBA\)](#)

[Select Entity in Drawing View \(VBA\)](#)

See Also

[IView Interface](#)

[IView Members](#)

[IView::SelectEntity Method](#)

[IModelDocExtension::SelectAll Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetBendNoteTextFormat Method (IView)

Sets the text format of all bend notes in this drawing view of a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBendNoteTextFormat( _  
    ByVal Format As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Format As System.String  
Dim value As System.Boolean  
  
value = instance.SetBendNoteTextFormat(Format)
```

C#

```
System.bool SetBendNoteTextFormat(  
    System.string Format  
)
```

C++/CLI

```
System.bool SetBendNoteTextFormat(  
& System.String^ Format  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Format

Format in which to display all bend notes in this drawing view of a sheet metal part (see **Remarks**)

Return Value

True if format is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [View::SetBendNoteTextFormat](#).

Remarks

Before calling this method, call [IView::GetBendNoteAttributeString](#) to specify Format.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetBendNoteTextFormat Method](#)
[IView::ShowSheetMetalBendNotes Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDisplayMode Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetDisplayMode Method (IView)

Obsolete. Superseded by [IView::SetDisplayMode3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDisplayMode( _  
    ByVal DisplayIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim DisplayIn As System.Integer  
  
instance.SetDisplayMode(DisplayIn)
```

C#

```
void SetDisplayMode(  
    System.int DisplayIn  
)
```

C++/CLI

```
void SetDisplayMode(  
&    System.int DisplayIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayIn

Visual Basic for Applications (VBA) Syntax

See [View::SetDisplayMode](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDisplayMode2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetDisplayMode2 Method (IView)

Obsolete. Superseded by [IView::SetDisplayMode3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetDisplayMode2( _  
    ByVal Mode As System.Integer, _  
    ByVal Facetted As System.Boolean, _  
    ByVal Edges As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Mode As System.Integer  
Dim Facetted As System.Boolean  
Dim Edges As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.SetDisplayMode2(Mode, Facetted, Edges)
```

C#

```
System.bool SetDisplayMode2(  
    System.int Mode,  
    System.bool Facetted,  
    System.bool Edges  
)
```

C++/CLI

```
System.bool SetDisplayMode2(  
& System.int Mode,  
& System.bool Facetted,  
& System.bool Edges  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Mode

Facetted

Edges

Visual Basic for Applications (VBA) Syntax

See [View::SetDisplayMode2](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDisplayMode3 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetDisplayMode3 Method (IView)

Obsolete. Superseded by [IView::SetDisplayMode4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetDisplayMode3( _  
    ByVal UseParent As System.Boolean, _  
    ByVal Mode As System.Integer, _  
    ByVal Facetted As System.Boolean, _  
    ByVal Edges As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseParent As System.Boolean  
Dim Mode As System.Integer  
Dim Facetted As System.Boolean  
Dim Edges As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.SetDisplayMode3(UseParent, Mode, Facetted, Edges)
```

C#

```
System.bool SetDisplayMode3(
    System.bool UseParent,
    System.int Mode,
    System.bool Facetted,
    System.bool Edges
)
```

C++/CLI

```
System.bool SetDisplayMode3(
    & System.bool UseParent,
    & System.int Mode,
    & System.bool Facetted,
    & System.bool Edges
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseParent

True to use the parent's setting, false to use its own local settings

Mode

Display mode of the drawing view as defined in [swDisplayMode_e](#)

Facetted

True if the geometry is displayed with draft quality, false if it is displayed with precision quality (see **Remarks**)

Edges

True if edges are displayed when this view is in shaded mode, false if not

Return Value

True if the setting of the display mode was successful, false if not

Visual Basic for Applications (VBA) Syntax

See [View::SetDisplayMode3](#).

Example

[Set View Display Mode \(C++\)](#)

[Change Display Mode to Draft Quality \(VBA\)](#)

[Get Number of Polylines in Shaded Mode Drawing View \(VBA\)](#)

Remarks

The contents of a drawing view can be displayed in different modes, including Wireframe, HLR (Hidden Lines Removed), and HLV (Hidden Line: Visible), and Shaded. This is what the Mode argument indicates, and these values are contained in swDisplayMode_e. To display a drawing view shaded with edges, set swDrawingsDefaultDisplayTypeHLREdgesWhenShaded to True and set Mode to swSHADED.

This enumeration also contains three other values, swFACETED_WIREFRAME, swFACETED_HIDDEN_GREY, and swFACETEDHIDDEN, which indicate faceted display of geometry. However, in this method, the Facetted argument is how faceted display is indicated, and if any of those three values are used in the Mode argument, they are treated the same as swWIREFRAME, sw_HIDDEN_GREY, and sw_HIDDEN, respectively.

To determine if...

Edges are displayed when this view is in shaded mode

This view is displayed with faceted geometry

The display mode of this drawing view

Then use...

[IView::GetDisplayEdgesInShadedMode](#)

[IView::GetFacettedHlrDisplay](#)

[IView::GetDisplayMode2](#)

Although you cannot switch a drawing view from precision quality to draft quality, the geometry can still be displayed in draft quality if that is how your user preferences indicate new drawings views should be created. Once the drawing view has precision quality, whether you created it that way or changed it to that after its creation, you cannot change it to draft quality.

NOTE: Displaying geometry precisely can increase display quality, but can decrease performance. Setting the Facetted argument to True can increase performance, but can decrease display quality.

See Also

[IView Interface](#)

[IView Members](#)

[IView::UpdateViewDisplayGeometry Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDisplayMode4 Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetDisplayMode4 Method (IView)

Sets the display mode of this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDisplayMode4( _  
    ByVal UseParent As System.Boolean, _  
    ByVal Mode As System.Integer, _  
    ByVal Faceted As System.Boolean, _  
    ByVal Edges As System.Boolean, _  
    ByVal CThreadHighQuality As System.Boolean _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim UseParent As System.Boolean  
Dim Mode As System.Integer  
Dim Faceted As System.Boolean  
Dim Edges As System.Boolean  
Dim CThreadHighQuality As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetDisplayMode4(UseParent, Mode, Faceted, Edges, CThreadHighQuality)
```

C#

```
System.bool SetDisplayMode4(  
    System.bool UseParent,  
    System.int Mode,  
    System.bool Faceted,  
    System.bool Edges,  
    System.bool CThreadHighQuality  
)
```

C++/CLI

```
System.bool SetDisplayMode4(  
& System.bool UseParent,  
& System.int Mode,  
& System.bool Faceted,  
& System.bool Edges,  
& System.bool CThreadHighQuality  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseParent

True to use the parent's settings, false to use this drawing view's local settings (see **Remarks**)

Mode

Display mode of the drawing view as defined in [swDisplayMode_e](#) (see **Remarks**)

Faceted

True for draft quality, false for precision quality (see **Remarks**)

Edges

True if edges are displayed when this view is in shaded mode, false if not

CThreadHighQuality

True for precision quality cosmetic threads, false for draft quality

Return Value

True if the display mode is reset, false if not

Visual Basic for Applications (VBA) Syntax

See [View::SetDisplayMode4](#).

Example

'VBA

'-----

' Preconditions:

- ' 1. Open a drawing and select a drawing view.
- ' 2. Open the Immediate window.

'

' Postconditions:

- ' 1. Gets the selected view's current display mode properties.
- ' 2. Resets the display mode properties.
- ' 3. Gets the new display mode properties.
- ' 4. Examine the Immediate window.

'-----

Option Explicit

Sub main()

```
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim swDraw As SldWorks.DrawingDoc
Dim swSheet As SldWorks.Sheet
Dim swView As SldWorks.View
Dim bRet As Boolean
Dim swSelectionMgr As SldWorks.SelectionMgr
```

```
Set swApp = SolidWorks.SldWorks
Set swModel = swApp.ActiveDoc
Set swDraw = swModel
Set swSheet = swDraw.GetCurrentSheet
Set swSelectionMgr = swModel.SelectionManager
```

```
Set swView = swSelectionMgr.GetSelectedObject6(1, -1)
```

```
Debug.Print "====Current Display Mode===="
Debug.Print ""
```

```
Dim UseParentProp As Boolean
UseParentProp = swView.GetUseParentDisplayMode
Debug.Print "Using parent view's display mode? " & UseParentProp
```

```
Dim displayMode As Long
displayMode = swView.GetDisplayMode2
Debug.Print "Current display mode as defined by swDisplayMode_e: " & displayMode
```

```
Dim Faceted As Boolean
Faceted = swView.GetFacettedHlrDisplay
Debug.Print "Display faceted?: " & Faceted
```

```
Dim EdgesMode As Boolean
EdgesMode = swView.GetDisplayEdgesInShadedMode
Debug.Print "Display edges when the view is in shaded mode? " & EdgesMode
```

```
Dim cThreadQuality As Boolean
cThreadQuality = swView.GetCThreadQuality
Debug.Print "Precision quality for cosmetic threads? " & swView.GetCThreadQuality
```

```
swView.SetDisplayMode4 False, 3, True, False, True
```

```
Debug.Print "====After Re-setting Display Mode===="
Debug.Print ""
Debug.Print "Using parent view's display mode? " & swView.GetUseParentDisplayMode
Debug.Print "Current display mode as defined by swDisplayMode_e: " & swView.GetDisplayMode2
Debug.Print "Display faceted? " & swView.GetFacettedHlrDisplay
Debug.Print "Display edges when the view is in shaded mode? " & swView.GetDisplayEdgesInShadedMode
Debug.Print "Precision quality for cosmetic threads? " & swView.GetCThreadQuality
```

End Sub

Example

[Set Display Mode of View \(VB.NET\)](#)
[Set Display Mode of View \(C#\)](#)

Remarks

If UseParent is true and a parent view:

- Exists, then this method's Mode, Faceted, and Edges parameters are ignored.
- Does not exist, then this method does not change the current display mode of this drawing view.

Mode specifies the drawing view display as defined by swDisplayMode_e.:

- swWIREFRAME
- swHIDDEN (Hidden Lines Removed)
- swHIDDEN_GREYED (Hidden Lines Visible)
- swSHADED
- swSHADED_EDGES

swDisplayMode_e also contains three other values that seem to indicate faceted (draft) geometry:

- swFACETED_WIREFRAME
- swFACETED_HIDDEN_GREYED
- swFACETED_HIDDEN

However in this method, you must use the Faceted parameter (not the Mode parameter) to specify draft or precision quality. If you specify Mode with swFACETED_WIREFRAME, swFACETED_HIDDEN_GREYED, or swFACETED_HIDDEN, then SOLIDWORKS instead uses swWIREFRAME, swHIDDEN_GREYED, or swHIDDEN.

NOTE: Just as displaying geometry precisely can decrease performance, setting the Faceted argument to true (draft quality) can increase performance.

To determine for this view...

Whether its edges are displayed when it's in shaded mode

Whether its geometry is faceted

Its current display mode

Whether its parent's display mode is being used

Its cosmetic thread display quality

Use...

[IView::GetDisplayEdgesInShadedMode](#)

[IView::GetFacettedHlrDisplay](#)

[IView::GetDisplayMode2](#)

[IView::GetUseParentDisplayMode](#)

[IView::GetCThreadQuality](#)

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDisplayTangentEdges Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetDisplayTangentEdges Method (IView)

Obsolete. Superseded by [IView::SetDisplayTangentEdges2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDisplayTangentEdges( _  
    ByVal DisplayIn As System.Boolean _  
)
```

Visual Basic (Usage)

```
Dim instance As IView  
Dim DisplayIn As System.Boolean  
  
instance.SetDisplayTangentEdges(DisplayIn)
```



C#

```
void SetDisplayTangentEdges(  
    System.bool DisplayIn  
)
```

C++/CLI

```
void SetDisplayTangentEdges(  
& System.bool DisplayIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayIn

Visual Basic for Applications (VBA) Syntax

See [View::SetDisplayTangentEdges](#).

See Also

[IView Interface](#)
[IView Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDisplayTangentEdges2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetDisplayTangentEdges2 Method (IView)

Sets the tangent edge display mode of the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDisplayTangentEdges2( _  
    ByVal DisplayIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim DisplayIn As System.Integer  
  
instance.SetDisplayTangentEdges2(DisplayIn)
```

C#

```
void SetDisplayTangentEdges2(  
    System.int DisplayIn  
)
```

C++/CLI

```
void SetDisplayTangentEdges2(  
& System.int DisplayIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayIn

Tangent edge display mode as defined in [swDisplayTangentEdges_e](#)

Visual Basic for Applications (VBA) Syntax

See [View::SetDisplayTangentEdges2](#).

Remarks

Tangent edges are the transition lines between, for example, a blend and a face.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayTangentEdges2 Method](#)
[IView::GetDisplayEdgesInShadedMode Method](#)
[IView::GetDisplayMode2 Method](#)
[IView::GetUseParentDisplayMode Method](#)
[IView::UpdateViewDisplayGeometry Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetKeepLinkedToBOM Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetKeepLinkedToBOM Method (IView)

Sets whether this drawing view is linked to the specified BOM or weldment cut-list table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetKeepLinkedToBOM( _  
    ByVal Linked As System.Boolean, _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Linked As System.Boolean  
Dim Name As System.String  
Dim value As System.Boolean  
  
value = instance.SetKeepLinkedToBOM(Linked, Name)
```

C#

```
System.bool SetKeepLinkedToBOM(  
    System.bool Linked,  
    System.string Name  
)
```

C++/CLI

```
System.bool SetKeepLinkedToBOM(  
& System.bool Linked,  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Linked

True to set a drawing view to the specified BOM or weldment cut-list table, false to not

Name

Name of the BOM or weldment cut-list table to which to link this drawing view

Return Value

True if the BOM or weldment cut-list table is linked to this drawing view, false if not

Visual Basic for Applications (VBA) Syntax

See [View::SetKeepLinkedToBOM](#).

Remarks

This method returns false if the string specified for Name does not correspond to the name of a BOM or weldment cut-list table feature created for the model in this drawing view.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetKeepLinkedToBOM Method](#)
[IView::GetKeepLinkedToBOMName Method](#)
[IView::InsertBomTable Method](#)
[IView::InsertBomTable2 Method](#)
[IView::InsertWeldmentTable Method](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLightweightToResolved Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetLightweightToResolved Method (IView)

Changes the drawing view from lightweight to resolved.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetLightweightToResolved()
```

Visual Basic (Usage)



```
Dim instance As IView  
instance.SetLightweightToResolved()
```

C#

```
void SetLightweightToResolved()
```

C++/CLI

```
void SetLightweightToResolved();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::SetLightweightToResolved](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IsLightweight Method](#)
[IView::SetResolvedToLightweight Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetMirrorViewOrientation Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetMirrorViewOrientation Method (IView)

Sets whether to mirror this view.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMirrorViewOrientation( _  
    ByVal BSetIsMirrorView As System.Boolean, _  
    ByVal BMirrorVieworientation As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim BSetIsMirrorView As System.Boolean  
Dim BMirrorVieworientation As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetMirrorViewOrientation(BSetIsMirrorView, BMirrorVieworientation)
```

C#

```
System.bool SetMirrorViewOrientation(  
    System.bool BSetIsMirrorView,  
    System.int BMirrorVieworientation  
)
```

C++/CLI

```
System.bool SetMirrorViewOrientation(  
& System.bool BSetIsMirrorView,  
& System.int BMirrorVieworientation  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BSetIsMirrorView

True to mirror the view, false to not

BMirrorVieworientation

Orientation of the mirror view as defined in [swMirrorViewPositions_e](#)

Return Value

True if the method executed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [View::SetMirrorViewOrientation](#).

Example

[Mirror View \(C#\)](#)
[Mirror View \(VB.NET\)](#)
[Mirror View \(VBA\)](#)

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetMirrorViewOrientation Method \(\)](#)

Availability

SetName2 Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetName2 Method (IView)

Sets the name of this drawing view, as displayed in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function SetName2( _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Name As System.String  
Dim value As System.Boolean  
  
value = instance.SetName2(Name)
```

C#

```
System.bool SetName2(  
    System.string Name  
)
```

C++/CLI

```
System.bool SetName2(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Name of drawing view

Return Value

True if the name of the drawing view is set, false if not

Visual Basic for Applications (VBA) Syntax

See [View::SetName2](#).

Remarks

The drawing view name that you specify:

- must be unique in the FeatureManager design tree.
- not contain any of the SOLIDWORKS reserved special characters.

If either of these conditions is not met, then this method returns false and the name of the drawing view is not changed.

You cannot change the drawing view name for detail views and section views. If you attempt to do so, then false is returned and the drawing view name is not changed.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetName2 Method](#)

Availability

SetResolvedToLightweight Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetResolvedToLightweight Method (IView)

Changes the drawing view from resolved to lightweight.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetResolvedToLightweight()
```

Visual Basic (Usage)



```
Dim instance As IView
```

```
instance.SetResolvedToLightweight()
```

C#

```
void SetResolvedToLightweight()
```

C++/CLI

```
void SetResolvedToLightweight();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::SetResolvedToLightweight](#).

See Also

[IView Interface](#)

[IView Members](#)

[IView::SetLightweightToResolved Method](#)

[IView::IsLightweight Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SetViewPosition Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetViewPosition Method (IView)

Moves this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function SetViewPosition( _  
    ByVal Position As System.Object, _  
    ByVal MoveChildViews As System.Boolean _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Position As System.Object  
Dim MoveChildViews As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.SetViewPosition(Position, MoveChildViews)
```

C#

```
System.bool SetViewPosition(  
    System.object Position,  
    System.bool MoveChildViews  
)
```

C++/CLI

```
System.bool SetViewPosition(  
& System.Object^ Position,  
& System.bool MoveChildViews  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Position

Array of two doubles giving the new x,y position of this drawing view relative to the sheet origin (see **Remarks**)

MoveChildViews

True to also move child views, false to not

Return Value

True if view position successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [View::SetViewPosition](#).

Remarks

Take careful note of view alignments when specifying Position. Any view alignments that might affect this view are handled the same way as if you were using the SOLIDWORKS Design user interface to draw the view to move it. If this view is aligned with another view, it will only be allowed to move along the alignment vector.

See Also

[IView Interface](#)

[IView Members](#)

[DDrawingDocEvents_ViewPositionChangeNotifyEventHandler Delegate \(IView\)](#)

[IView::Position Property \(\)](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetVisible Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetVisible Method (IView)

Sets the visibility of this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVisible( _  
    ByVal Visible As System.Boolean, _  
    ByVal DependentsToo As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Visible As System.Boolean  
Dim DependentsToo As System.Boolean  
  
instance.SetVisible(Visible, DependentsToo)
```

C#

```
void SetVisible(  
    System.bool Visible,  
    System.bool DependentsToo  
)
```

C++/CLI

```
void SetVisible(  
& System.bool Visible,  
& System.bool DependentsToo  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Visible

True to set the view to visible, false to not

DependentsToo

True to set the dependents of this view to visible, false to not

Visual Basic for Applications (VBA) Syntax

See [View::SetVisible](#).

See Also

[IView Interface](#)

[IView Members](#)

[IView::GetVisible Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 10.0