

SOLIDWORKS API (NET VBA C#) — Reference

(330/337): IView (part 10 of 10)

SOLIDWORKS API Documentation (converted from CHM)

IView (part 10 of 10) (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetXform Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SetXform Method (IView)

Sets the matrix used for display of this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function SetXform( _  
    ByVal Transform As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim Transform As System.Object  
Dim value As System.Boolean  
  
value = instance.SetXform(Transform)
```

C#

```
System.bool SetXform(  
    System.object Transform  
)
```

C++/CLI

```
System.bool SetXform(  
& System.Object^ Transform  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Transform
Array of 3 doubles (see **Remarks**)

Return Value

True if transform successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [View::SetXform](#).

Remarks

The 3 doubles are the X and Y position of the view, relative to the sheet origin, and the scale of the view.

Any view alignments that might affect this view are handled the same way as if you were using the user interface to draw the view to move it. If it is aligned with another view, then it will only move along the alignment vector. If it has child views that are aligned with it, then those views will also be moved along with this view.

Calling this method is equivalent to setting the [IView::Position](#) or [IView::IPosition](#) property (to set X and Y), and the [IView::ScaleDecimal](#) property (to set the scale).

To get the view matrix, use [IView::GetXform](#) or [IView::IGetXform](#) method.

Using this method may cause changes to the graphics of the drawing. Once all the view-related changes have been made, the user should call [IModelDoc2::EditRebuild3](#) to regenerate the drawing, in order to see these changes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::ISetXform Method](#)
[IView::GetXform Method](#)
[IView::IGetXform Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Sheet Property (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : Sheet Property (IView)

Gets the sheet on which this drawing view exists.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Sheet As Sheet

Visual Basic (Usage)



```
Dim instance As IView
Dim value As Sheet

value = instance.Sheet
```

C#

```
Sheet Sheet {get;}
```

C++/CLI

```
property Sheet^ Sheet {
    Sheet^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Sheet](#)

Visual Basic for Applications (VBA) Syntax

See [View::Sheet](#).

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowExploded Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ShowExploded Method (IView)

Shows an exploded assembly in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function ShowExploded( _
    ByVal ShowIt As System.Boolean _
) As System.Boolean
```

```
Dim instance As IView
Dim ShowIt As System.Boolean
Dim value As System.Boolean

value = instance.ShowExploded(ShowIt)
```

C#

```
System.bool ShowExploded(
    System.bool ShowIt
)
```

C++/CLI

```
System.bool ShowExploded(
    & System.bool ShowIt
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ShowIt

True if you want this drawing view to display the exploded state of the current assembly configuration, false if you want this drawing view to display the collapsed state

Return Value

True if successful in displaying the exploded assembly state, false if not

Visual Basic for Applications (VBA) Syntax

See [View::ShowExploded](#).

Remarks

The explode state that is displayed is based on the current assembly configuration used by this drawing view

See Also

[IView Interface](#)
[IView Members](#)
[IView::IsExploded Method \(\)](#)
[IModelDocExtension::IsExploded Method \(\)](#)
[IAssemblyDoc::AutoExplode Method \(\)](#)
[IAssemblyDoc::CreateExplodedView Method \(\)](#)
[IAssemblyDoc::GetExplodedViewConfigurationName Method \(\)](#)
[IAssemblyDoc::GetExplodedViewCount2 Method \(\)](#)
[IAssemblyDoc::GetExplodedViewNames2 Method \(\)](#)
[IAssemblyDoc::ShowExploded2 Method \(\)](#)
[IAssemblyDoc::ViewCollapseAssembly Method \(\)](#)
[IAssemblyDoc::ViewExplodeAssembly Method \(\)](#)

Availability

ShowModelBreakState Method (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ShowModelBreakState Method (IView)

Sets whether to display the specified Model Break View.

.NET Syntax

Visual Basic (Declaration)

```
Function ShowModelBreakState( _
    ByVal ShowIt As System.Boolean, _
```

```
ByVal BreakName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim ShowIt As System.Boolean  
Dim BreakName As System.String  
Dim value As System.Boolean  
  
value = instance.ShowModelBreakState(ShowIt, BreakName)
```

C#

```
System.bool ShowModelBreakState(  
    System.bool ShowIt,  
    System.string BreakName  
)
```

C++/CLI

```
System.bool ShowModelBreakState(  
& System.bool ShowIt,  
& System.String^ BreakName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ShowIt

True to display the Model Break View specified in BreakName, false to not

BreakName

Name of Model Break View to display

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [View::ShowModelBreakState](#).

Example

[Get and Set Model Break View Display \(VBA\)](#)

[Get and Set Model Break View Display \(VB.NET\)](#)

[Get and Set Model Break View Display \(C#\)](#)

See Also

[IView Interface](#)

[IView Members](#)

[IView::IsModelBreakState Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Release Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowSheetMetalBendNotes Property (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : ShowSheetMetalBendNotes Property (IView)

Gets or sets whether to show sheet metal bend notes.

.NET Syntax

Visual Basic (Declaration)

Property ShowSheetMetalBendNotes As System.Boolean

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
instance.ShowSheetMetalBendNotes = value  
  
value = instance.ShowSheetMetalBendNotes
```

C#

```
System.bool ShowSheetMetalBendNotes {get; set;}
```

C++/CLI

```
property System.bool ShowSheetMetalBendNotes {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to show sheet metal bend notes, false to not

Visual Basic for Applications (VBA) Syntax

See [View::ShowSheetMetalBendNotes](#).

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SuppressState Property (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : SuppressState Property (IView)

Gets or sets the view suppress state.

.NET Syntax

Visual Basic (Declaration)

Property SuppressState As System.Integer

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Integer  
  
instance.SuppressState = value  
  
value = instance.SuppressState
```

C#

```
System.int SuppressState {get; set;}
```

C++/CLI

```
property System.int SuppressState {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- NO_SUPPRESS = 0
- HALF_SUPPRESS = 1
- FULL_SUPPRESS = 2

Visual Basic for Applications (VBA) Syntax

See [View::SuppressState](#).

See Also

[IView Interface](#)
[IView Members](#)
[IDrawingDoc::SuppressView Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : Type Property (IView)

Gets the drawing view type.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

value = instance.Type
```

C#

```
System.int Type {get;}
```

C++/CLI

```
property System.int Type {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of drawing view as defined by [swDrawingViewTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [View::Type](#).

Example

[Get Drawing View Names and Types \(VBA\)](#)
[Activate Each View on Current Sheet \(VBA\)](#)
[Get Components Properties in Drawing View \(VBA\)](#)
[Get Section View \(VBA\)](#)
[Hide Drawing Components \(VBA\)](#)

[Put Assembly Components in Drawing View on Different Layers \(VBA\)](#)
[Get Arrow in Projected View \(C#\)](#)
[Get Arrow in Projected View \(VB.NET\)](#)
[Get Arrow in Projected View \(VBA\)](#)
[Get Drawing View Names and Types \(VB.NET\)](#)
[Get Drawing View Names and Types \(C#\)](#)

See Also

[IView Interface](#)
[IView Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdateViewDisplayGeometry Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : UpdateViewDisplayGeometry Method (IView)

Updates the displayed geometry for a drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub UpdateViewDisplayGeometry()
```

Visual Basic (Usage)



```
Dim instance As IView  
instance.UpdateViewDisplayGeometry()
```

C#

```
void UpdateViewDisplayGeometry()
```

C++/CLI

```
void UpdateViewDisplayGeometry();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::UpdateViewDisplayGeometry](#).

Remarks

This method accesses new view geometry before Microsoft has repainted the window. For example, this can occur if you were changing the display mode of the drawing view from HLR to HLV and wanted immediate access to the polylines in that drawing view.

Because Microsoft controls repainting the window, you do not have access to your drawing view changes until control is returned. However, using this method immediately updates the view geometry for your purposes.

See Also

[IView Interface](#)
[IView Members](#)
[IView::GetDisplayMode2 Method](#)
[IView::SetDisplayMode3 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultAlignment Method (IView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : UseDefaultAlignment Method (IView)

Restores the default alignment for this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub UseDefaultAlignment()
```

Visual Basic (Usage)



```
Dim instance As IView  
  
instance.UseDefaultAlignment()
```

C#

```
void UseDefaultAlignment()
```

C++/CLI

```
void UseDefaultAlignment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View::UseDefaultAlignment](#).

Remarks

The default alignment for a view depends on the [view type](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::AlignWithView Method](#)
[IView::GetAlignment Method](#)
[IView::RemoveAlignment Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseParentScale Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : UseParentScale Property (IView)

Gets or sets the drawing view's scale to match the parent drawing view's scale.

.NET Syntax

Visual Basic (Declaration)

```
Property UseParentScale As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IView  
Dim value As System.Boolean  
  
instance.UseParentScale = value  
  
value = instance.UseParentScale
```

C#

```
System.bool UseParentScale {get; set;}
```

C++/CLI

```
property System.bool UseParentScale {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the drawing view's scale is set to be the same as the parent's drawing view scale, false if the drawing view scale is independent of the parent's drawing view scale

Visual Basic for Applications (VBA) Syntax

See [View::UseParentScale](#).

Example

[Set View Scale Opposite Parent View Scale \(VBA\)](#)

Remarks

Changing this property can cause changes to the graphics of the drawing. After making all of the view-related changes, call the [IModelDoc2::EditRebuild3](#) method to regenerate the drawing to see these changes.

To set the drawing view's scale to be the same as the drawing sheet's scale, use [IView::UseSheetScale](#).

See Also

[IView Interface](#)
[IView Members](#)
[IView::IScaleRatio Property](#)
[IView::ScaleRatio Property](#)
[IView::ScaleDecimal Property](#)

Availability

SOLIDWORKS 2004 SP5, Revision Number 12.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseSheetScale Property (IView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView Interface](#) : UseSheetScale Property (IView)

Gets or sets whether the scale of the drawing view is the same as the scale of the drawing sheet on which this view is located.

.NET Syntax

Visual Basic (Declaration)

```
Property UseSheetScale As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView
Dim value As System.Integer

instance.UseSheetScale = value

value = instance.UseSheetScale
```

C#

```
System.int UseSheetScale {get; set;}
```

C++/CLI

```
property System.int UseSheetScale {
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

1 if the view scale is the same as the sheet scale, 0 if the view scale is independent of the sheet scale

Visual Basic for Applications (VBA) Syntax

See [View::UseSheetScale](#).

Example

[Set View Scale \(VBA\)](#)

Remarks

If the property is 0, then it is possible that the view scale is the same as the sheet scale.

Changing this property can cause changes to the graphics of the drawing. After making all of the view-related changes, call the [IModelDoc2::EditRebuild3](#) method to regenerate the drawing to see these changes.

To set the drawing view's scale to be the same as the parent's drawing sheet's scale, use [View::UseParentScale](#).

See Also

[View Interface](#)
[View Members](#)
[View::ScaleRatio Property](#)
[View::ScaleDecimal Property](#)
[View::ScaleRatio Property](#)