

SOLIDWORKS API (NET VBA C#) — Reference (331/337): IView3D-IWeldmentBeadFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IView3D (Type)

IView3D Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IView3D Interface

Allows access to a 3D View of a part or assembly.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IView3D
```

Visual Basic (Usage)

```
Dim instance As IView3D
```

C#

```
public interface IView3D
```

C++/CLI

```
public interface class IView3D
```

Visual Basic for Applications (VBA) Syntax

See [View3D](#).

Example

[Capture 3D View \(VBA\)](#)
[Capture 3D View \(VB.NET\)](#)
[Capture 3D View \(C#\)](#)

Remarks

This interface supports SOLIDWORKS Model Based Definition (MBD), which is an integrated drawingless manufacturing solution for SOLIDWORKS. Use [ISldWorks::LoadAddIn](#) to load the MBD add-in.

See the SOLIDWORKS Help for details about MBD.

Accessors

[IModelDocExtension::Capture3DView](#)

[IModelDocExtension::Get3DView](#)

[IModelDocExtension::Get3DViews](#)

Access Diagram

[View3D](#)

See Also

[IView3D Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::Get3DViewCount Method \(\)](#)
[IModelDocExtension::Get3DViewNames Method \(\)](#)
[IModelDocExtension::Refresh3DViews Method \(\)](#)
[IMBD3DPdfData Interface](#)

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IView3D Interface

The following tables list the members exposed by [IView3D](#).

 Public Properties

Name	Description
 AnnotationViews	Gets or sets the annotation views assigned to this 3D View.
 AnnotationViews2	Gets the annotation views assigned to this 3D View.
 ConfigurationName	Gets or sets the name of this 3D View's configuration.
 DisplayMode	Gets or sets the display mode of this 3D View.
 DisplayState	Gets or sets the name this 3D View's display state.
 ModelBreakViewName	Gets the name of the Model Break View in this 3D View.
 Name	Gets or sets the name of this 3D View.
 Rotation	Gets or sets the 3D View rotation with respect to the Front view.
 Scale	Gets or sets this 3D View's scale.
 Translation	Gets or sets the translation vector of this 3D View.

[Top](#)

 Public Methods

Name	Description
 Activate	Activates this 3D View.
 Deactivate	Restores the previously backed-up model state of a 3D View.
 Get3DViewAnnotationTextScale	Gets the annotation text scale for this 3D View.

[Top](#)

 See Also

[IView3D Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::Get3DViewCount Method \(\)](#)
[IModelDocExtension::Get3DViewNames Method \(\)](#)
[IModelDocExtension::Refresh3DViews Method \(\)](#)
[IMBD3DPdfData Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IView3D Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IView3D Interface

For a list of all members of this type, see [IView3D members](#).

 Public Methods

Name	Description
 Activate	Activates this 3D View.
 Deactivate	Restores the previously backed-up model state of a 3D View.
 Get3DViewAnnotationTextScale	Gets the annotation text scale for this 3D View.

[Top](#)

 See Also

[IView3D Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::Get3DViewCount Method \(\)](#)
[IModelDocExtension::Get3DViewNames Method \(\)](#)
[IModelDocExtension::Refresh3DViews Method \(\)](#)
[IMBD3DPdfData Interface](#)

IView3D Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IView3D Interface

For a list of all members of this type, see [IView3D members](#).

Public Properties

Name	Description
 AnnotationViews	Gets or sets the annotation views assigned to this 3D View.
 AnnotationViews2	Gets the annotation views assigned to this 3D View.
 ConfigurationName	Gets or sets the name of this 3D View's configuration.
 DisplayMode	Gets or sets the display mode of this 3D View.
 DisplayState	Gets or sets the name this 3D View's display state.
 ModelBreakViewName	Gets the name of the Model Break View in this 3D View.
 Name	Gets or sets the name of this 3D View.
 Rotation	Gets or sets the 3D View rotation with respect to the Front view.
 Scale	Gets or sets this 3D View's scale.
 Translation	Gets or sets the translation vector of this 3D View.

[Top](#)

See Also

[IView3D Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::Get3DViewCount Method \(\)](#)
[IModelDocExtension::Get3DViewNames Method \(\)](#)
[IModelDocExtension::Refresh3DViews Method \(\)](#)
[IMBD3DPdfData Interface](#)

Activate Method (IView3D)

[See Also](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : Activate Method (IView3D)

Activates this 3D View.

.NET Syntax

Visual Basic (Declaration)

```
Sub Activate( _  
    ByVal SaveLastState As System.Boolean _  
)
```

Visual Basic (Usage)

```
Dim instance As IView3D  
Dim SaveLastState As System.Boolean  
  
instance.Activate(SaveLastState)
```

C#

```
void Activate(  
    System.bool SaveLastState  
)
```

C++/CLI

```
void Activate(  
&    System.bool SaveLastState
```



)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SaveLastState

True to back up the previous model state prior to activating this 3D View, false to not back up the previous model state prior to activating this 3D view

Visual Basic for Applications (VBA) Syntax

See [View3D::Activate](#).

Example

See the [IView3D](#) examples.

Remarks

The model state includes the model's:

- active configuration
- display state
- explode, section, or Model Break view state
- view orientation, including pan and zoom

See Also

[IView3D Interface](#)

[IView3D Members](#)

[IView3D::Deactivate Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AnnotationViews Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : AnnotationViews Property (IView3D)

Gets or sets the annotation views assigned to this 3D View.

.NET Syntax

Visual Basic (Declaration)

```
Property AnnotationViews As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView3D
Dim value As System.Object

instance.AnnotationViews = value
value = instance.AnnotationViews
```

C#

```
System.object AnnotationViews {get; set;}
```

C++/CLI

```
property System.Object^ AnnotationViews {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IAnnotationView](#)s

Visual Basic for Applications (VBA) Syntax

See [View3D::AnnotationViews](#).

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AnnotationViews2 Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : AnnotationViews2 Property (IView3D)

Gets the annotation views assigned to this 3D View.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property AnnotationViews2 As System.Object
```

Visual Basic (Usage)



```
Dim instance As IView3D  
Dim value As System.Object  
  
value = instance.AnnotationViews2
```

C#

```
System.Object AnnotationViews2 {get;}
```

C++/CLI

```
property System.Object^ AnnotationViews2 {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IAnnotationView](#)

Visual Basic for Applications (VBA) Syntax

See [View3D::AnnotationViews2](#).

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ConfigurationName Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : ConfigurationName Property (IView3D)

Gets or sets the name of this 3D View's configuration.

.NET Syntax

Visual Basic (Declaration)

```
Property ConfigurationName As System.String
```

Visual Basic (Usage)



```
Dim instance As IView3D
Dim value As System.String

instance.ConfigurationName = value

value = instance.ConfigurationName
```

C#

```
System.string ConfigurationName {get; set;}
```

C++/CLI

```
property System.String^ ConfigurationName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Configuration name

Visual Basic for Applications (VBA) Syntax

See [View3D::ConfigurationName](#).

Example

See the [IView3D](#) examples.

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Deactivate Method (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : Deactivate Method (IView3D)

Restores the previously backed-up model state of a 3D View.

.NET Syntax

Visual Basic (Declaration)

```
Sub Deactivate()
```

Visual Basic (Usage)



```
Dim instance As IView3D
```

```
instance.Deactivate()
```

C#

```
void Deactivate()
```

C++/CLI

```
void Deactivate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [View3D::Deactivate](#).

Remarks

The model state includes the model's:

- active configuration
- display state
- explode, section, or Model Break view state
- view orientation, including pan and zoom

Restoring the previously backed-up model state of a 3D View might not be this 3D View.

For example:

1. Call [IView3D::Activate](#) and set the SaveLastState parameter to true (i.e., previous model state backed up) for 3DView1.
2. Call [IView3D::Activate](#) and set the SaveLastState parameter to false (i.e., previous model state not backed up) for 3DView2.
3. Call [IView3D::Deactivate](#) for 3DView1 or 3DView2, then the model state prior to activating 3DView1 is restored.

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayMode Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : DisplayMode Property (IView3D)

Gets or sets the display mode of this 3D View.

.NET Syntax

Visual Basic (Declaration)

```
Property DisplayMode As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IView3D  
Dim value As System.Integer  
  
instance.DisplayMode = value  
  
value = instance.DisplayMode
```

C#

```
System.int DisplayMode {get; set;}
```

C++/CLI

```
property System.int DisplayMode {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Display mode as defined in [swDisplayMode](#) e

Visual Basic for Applications (VBA) Syntax

See [View3D::DisplayMode](#).

Example

See the [IView3D](#) examples.

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayState Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : DisplayState Property (IView3D)

Gets or sets the name this 3D View's display state.

.NET Syntax

Visual Basic (Declaration)

```
Property DisplayState As System.String
```

Visual Basic (Usage)

```
Dim instance As IView3D
Dim value As System.String

instance.DisplayState = value
value = instance.DisplayState
```

C#

```
System.string DisplayState {get; set;}
```

C++/CLI

```
property System.String^ DisplayState {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Display state name

Visual Basic for Applications (VBA) Syntax

See [View3D::DisplayState](#).

Example

See the [View3D](#) examples.

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Get3DViewAnnotationTextScale Method (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : Get3DViewAnnotationTextScale Method (IView3D)

Gets the annotation text scale for this 3D View.

.NET Syntax

Visual Basic (Declaration)

```
Sub Get3DViewAnnotationTextScale( _  
    ByRef Scale1 As System.Double, _  
    ByRef Scale2 As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IView3D  
Dim Scale1 As System.Double  
Dim Scale2 As System.Double  
  
instance.Get3DViewAnnotationTextScale(Scale1, Scale2)
```

C#

```
void Get3DViewAnnotationTextScale(  
    out System.double Scale1,  
    out System.double Scale2  
)
```

C++/CLI

```
void Get3DViewAnnotationTextScale(  
& [Out] System.double Scale1,  
& [Out] System.double Scale2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Scale1
Numerator of the scale ratio (n:n)
Scale2
Denominator of the scale ratio (n:n)

Visual Basic for Applications (VBA) Syntax

See [View3D::Get3DViewAnnotationTextScale](#).

Remarks

This method gets the **Text scale** on the Annotation Properties dialog that appears when you RMB on the Annotations folder in the FeatureManager design tree.

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ModelBreakViewName Property (IView3D)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : ModelBreakViewName Property (IView3D)

Gets the name of the Model Break View in this 3D View.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ModelBreakViewName As System.String
```

Visual Basic (Usage)



```
Dim instance As IView3D
Dim value As System.String

value = instance.ModelBreakViewName
```

C#

```
System.string ModelBreakViewName {get;}
```

C++/CLI

```
property System.String^ ModelBreakViewName {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the Model Break View in this 3D View

Visual Basic for Applications (VBA) Syntax

See [View3D::ModelBreakViewName](#).

Example

[Capture 3D View \(C#\)](#)
[Capture 3D View \(VB.NET\)](#)
[Capture 3D View \(VBA\)](#)

See Also

[IView3D Interface](#)
[IView3D Members](#)
[IModelDocExtension::GetModelBreakViewNames Method\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : Name Property (IView3D)

Gets or sets the name of this 3D View.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IView3D  
Dim value As System.String
```

```
instance.Name = value
```

```
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of this 3D View

Visual Basic for Applications (VBA) Syntax

See [View3D::Name](#).

Example

See the [IView3D](#) examples.

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Rotation Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : Rotation Property (IView3D)

Gets or sets the 3D View rotation with respect to the Front view.

.NET Syntax

Visual Basic (Declaration)

```
Property Rotation As MathTransform
```

Visual Basic (Usage)



```
Dim instance As IView3D
Dim value As MathTransform

instance.Rotation = value

value = instance.Rotation
```

C#

```
MathTransform Rotation {get; set;}
```

C++/CLI

```
property MathTransform^ Rotation {
    MathTransform^ get();
    void set ( & MathTransform^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IMathTransform](#)

Visual Basic for Applications (VBA) Syntax

See [View3D::Rotation](#).

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Scale Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : Scale Property (IView3D)

Gets or sets this 3D View's scale.

.NET Syntax

Visual Basic (Declaration)

```
Property Scale As System.Double
```

Visual Basic (Usage)



```
Dim instance As IView3D
Dim value As System.Double

instance.Scale = value

value = instance.Scale
```

C#

```
System.double Scale {get; set;}
```

C++/CLI

```
property System.double Scale {
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Scale of this 3D View

Visual Basic for Applications (VBA) Syntax

See [View3D::Scale](#).

Example

See the [IView3D](#) examples.

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Translation Property (IView3D)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IView3D Interface](#) : Translation Property (IView3D)

Gets or sets the translation vector of this 3D View.

.NET Syntax

Visual Basic (Declaration)

Property Translation As MathVector

Visual Basic (Usage)



```
Dim instance As IView3D  
Dim value As MathVector  
  
instance.Translation = value  
value = instance.Translation
```

C#

```
MathVector Translation {get; set;}
```

C++/CLI

```
property MathVector^ Translation {  
    MathVector^ get();  
    void set ( & MathVector^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Translation [vector](#)

Visual Basic for Applications (VBA) Syntax

See [View3D::Translation](#).

See Also

[IView3D Interface](#)
[IView3D Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

IWeldBead (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWeldBead Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldBead Interface

Allows access to weld bead annotations.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWeldBead
```

Visual Basic (Usage)

```
Dim instance As IWeldBead
```

C#

```
public interface IWeldBead
```

C++/CLI

```
public interface class IWeldBead
```

Visual Basic for Applications (VBA) Syntax

See [WeldBead](#).

Example

[Get Weld Bead Symbol Data \(VBA\)](#)
[Get Weld Bead Symbol Data \(VB.NET\)](#)
[Get Weld Bead Symbol Data \(C#\)](#)

Accessors

[IView::GetFirstWeldBead](#)
[IView::GetWeldBeads](#) and [IView::IGetWeldBeads](#)
[IWeldBead::GetNext](#)

Access Diagram

[WeldBead](#)

See Also

[IWeldBead Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)
[IWeldmentBeadFeatureData Interface](#)
[IAssemblyDoc::InsertWeld Method](#)
[IAssemblyDoc::InsertWeld2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWeldBead Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldBead Interface

For a list of all members of this type, see [IWeldBead members](#).

Public Methods

Name	Description
 GetAnnotation	Gets the annotation for this weld bead.
 GetNext	Gets the next weld bead annotation in the drawing view.

[Top](#)

See Also

[IWeldBead Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)
[IWeldmentBeadFeatureData Interface](#)
[IAssemblyDoc::InsertWeld Method](#)
[IAssemblyDoc::InsertWeld2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IWeldBead Interface Members

[See Also](#) [Properties](#) [Methods](#)

	SolidWorks.Interop.sldworks Namespace : IWeldBead Interface
---	---

The following tables list the members exposed by [IWeldBead](#).

Public Properties

Name	Description
 SolidFill	Gets or sets whether to fill the weld bead annotation.

[Top](#)

Public Methods

Name	Description
 GetAnnotation	Gets the annotation for this weld bead.
 GetNext	Gets the next weld bead annotation in the drawing view.

[Top](#)

See Also

[IWeldBead Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)
[IWeldmentBeadFeatureData Interface](#)
[IAssemblyDoc::InsertWeld Method](#)
[IAssemblyDoc::InsertWeld2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IWeldBead Interface Properties

[See Also](#)

	SolidWorks.Interop.sldworks Namespace : IWeldBead Interface
---	---

For a list of all members of this type, see [IWeldBead members](#).

Public Properties

Name	Description
 SolidFill	Gets or sets whether to fill the weld bead annotation.

[Top](#)

See Also

[IWeldBead Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)
[IWeldmentBeadFeatureData Interface](#)
[IAssemblyDoc::InsertWeld Method](#)
[IAssemblyDoc::InsertWeld2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAnnotation Method (IWeldBead)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldBead Interface](#) : GetAnnotation Method (IWeldBead)

Gets the annotation for this weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IWeldBead  
Dim value As Annotation  
  
value = instance.GetAnnotation()
```

C#

```
Annotation GetAnnotation()
```

C++/CLI

```
Annotation^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [WeldBead::GetAnnotation](#).

Example

See the [IWeldBead](#) examples.

See Also

[IWeldBead Interface](#)
[IWeldBead Members](#)
[WeldBead::GetNext Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (IWeldBead)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldBead Interface](#) : GetNext Method (IWeldBead)

Gets the next weld bead annotation in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As WeldBead
```

Visual Basic (Usage)



```
Dim instance As IWeldBead  
Dim value As WeldBead
```

```
value = instance.GetNext()
```

C#

```
WeldBead GetNext()
```

C++/CLI

```
WeldBead^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [weld bead](#)

Visual Basic for Applications (VBA) Syntax

See [WeldBead::GetNext](#).

Example

See the [IWeldBead](#) examples.

See Also

[IWeldBead Interface](#)
[IWeldBead Members](#)
[IView::GetFirstWeldBead Method](#)
[WeldBead::GetAnnotation Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SolidFill Property (IWeldBead)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldBead Interface](#) : SolidFill Property (IWeldBead)

Gets or sets whether to fill the weld bead annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property SolidFill As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldBead  
Dim value As System.Boolean  
  
instance.SolidFill = value  
  
value = instance.SolidFill
```

C#

```
System.bool SolidFill {get; set;}
```

C++/CLI

```
property System.bool SolidFill {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to fill the weld bead, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldBead::SolidFill](#).

Example

See the [IWeldBead](#) examples.

Remarks

To get the triangular-shaped weld treatment, use the polygon-related [IDisplayData](#) APIs, which provide you with the geometry information. See the example for more information.

See Also

[IWeldBead Interface](#)
[IWeldBead Members](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

IWeldmentBeadFeatureData (Type)

IWeldmentBeadFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentBeadFeatureData Interface

Allows access to a weldment bead feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWeldmentBeadFeatureData
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData
```

C#

```
public interface IWeldmentBeadFeatureData
```

C++/CLI

```
public interface class IWeldmentBeadFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData](#).

Example

[Modify Fillet Weld Bead \(VBA\)](#)
[Modify Fillet Weld Bead \(VB.NET\)](#)
[Modify Fillet Weld Bead \(C#\)](#)

Remarks

A bead can be applied to two sides: arrow or other. All of these methods and properties use one of these sides as input. A staggered type of weld bead requires applying the weld bead to both sides.

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[WeldmentBeadFeatureData](#)

See Also

[IWeldmentBeadFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFilletBeadFeature Method](#)
[IWeldBead Interface](#)
[IFeatureManager::InsertFilletBeadFeature3 Method](#)
[IAssemblyDoc::InsertWeld Method](#)
[IAssemblyDoc::InsertWeld2 Method](#)

IWeldmentBeadFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentBeadFeatureData Interface

For a list of all members of this type, see [IWeldmentBeadFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this weld bead.
 GetFaces	Gets the sets of faces whose edges intersection defines the edges to which the weld bead is applied.
 GetFacesCount	Gets the number of faces in each sets of faces whose intersection defines the edges to which this weld bead is applied.
 GetVirtualEdges	Gets the edges to which the weld bead is applied.
 GetVirtualEdgesCount	Gets the number of edges to which the weld bead is applied.
 IGetFaces	Gets the sets of faces whose edges intersection defines the edges to which the weld bead is applied.
 IGetVirtualEdges	Gets the edges to which the weld bead is applied.
 ISetFaces	Sets the faces to which to apply the weld bead.
 ISetVirtualEdges	Sets the edges to which to apply this weld bead.
 ReleaseSelectionAccess	Releases access to the selections that define this weld bead.
 SetFaces	Sets the faces to which to apply the weld bead.
 SetVirtualEdges	Sets the edges to which to apply this weld bead.

[Top](#)

See Also

[IWeldmentBeadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFilletBeadFeature Method](#)
[IWeldBead Interface](#)
[IFeatureManager::InsertFilletBeadFeature3 Method](#)
[IAssemblyDoc::InsertWeld Method](#)
[IAssemblyDoc::InsertWeld2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWeldmentBeadFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : [IWeldmentBeadFeatureData Interface](#)

The following tables list the members exposed by [IWeldmentBeadFeatureData](#).

Public Properties

Name	Description
 BeadLength	Gets or sets the length of each bead segment of the weld bead.
 BeadPitch	Gets or sets the distance between the start of each weld bead.
 BeadSize	Gets or sets the length of the leg of the weld bead.
 BeadType	Gets or sets the type of weld bead.
 TangentPropagation	Gets or sets whether to propagate the weld bead along the tangent.
 UseOtherSide	Gets or sets whether to apply the weld bead to both sides of the intersecting faces.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this weld bead.
 GetFaces	Gets the sets of faces whose edges intersection defines the edges to which the weld bead is applied.
 GetFacesCount	Gets the number of faces in each sets of faces whose intersection defines the edges to which this weld bead is applied.
 GetVirtualEdges	Gets the edges to which the weld bead is applied.
 GetVirtualEdgesCount	Gets the number of edges to which the weld bead is applied.

	IGetFaces	Gets the sets of faces whose edges intersection defines the edges to which the weld bead is applied.
	IGetVirtualEdges	Gets the edges to which the weld bead is applied.
	ISetFaces	Sets the faces to which to apply the weld bead.
	ISetVirtualEdges	Sets the edges to which to apply this weld bead.
	ReleaseSelectionAccess	Releases access to the selections that define this weld bead.
	SetFaces	Sets the faces to which to apply the weld bead.
	SetVirtualEdges	Sets the edges to which to apply this weld bead.

[Top](#)

 See Also

[IWeldmentBeadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFilletBeadFeature Method](#)
[IWeldBead Interface](#)
[IFeatureManager::InsertFilletBeadFeature3 Method](#)
[IAssemblyDoc::InsertWeld Method](#)
[IAssemblyDoc::InsertWeld2 Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IWeldmentBeadFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [IWeldmentBeadFeatureData Interface](#)

For a list of all members of this type, see [IWeldmentBeadFeatureData members](#).

 Public Properties

Name	Description
 BeadLength	Gets or sets the length of each bead segment of the weld bead.
 BeadPitch	Gets or sets the distance between the start of each weld bead.
 BeadSize	Gets or sets the length of the leg of the weld bead.
 BeadType	Gets or sets the type of weld bead.
 TangentPropagation	Gets or sets whether to propagate the weld bead along the tangent.
 UseOtherSide	Gets or sets whether to apply the weld bead to both sides of the intersecting faces.

[Top](#)

 See Also

[IWeldmentBeadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFilletBeadFeature Method](#)
[IWeldBead Interface](#)
[IFeatureManager::InsertFilletBeadFeature3 Method](#)
[IAssemblyDoc::InsertWeld Method](#)
[IAssemblyDoc::InsertWeld2 Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

AccessSelections Method (IWeldmentBeadFeatureData)

[See Also](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : [AccessSelections Method \(IWeldmentBeadFeatureData\)](#)

Gains access to the selections that define this weld bead.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal PTopDoc As ModelDoc2, _  
    ByVal PComponent As Component2 _  
) As System.Boolean
```

```
Dim instance As IWeldmentBeadFeatureData
Dim PTopDoc As ModelDoc2
Dim PComponent As Component2
Dim value As System.Boolean

value = instance.AccessSelections(PTopDoc, PComponent)
```

C#

```
System.bool AccessSelections(
    ModelDoc2 PTopDoc,
    Component2 PComponent
)
```

C++/CLI

```
System.bool AccessSelections(
    & ModelDoc2^ PTopDoc,
    & Component2^ PComponent
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PTopDoc

Top-level document

PComponent

Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::AccessSelections](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IWeldmentBeadFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IWeldmentBeadFeatureData Interface](#)

[IWeldmentBeadFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

BeadLength Property (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : BeadLength Property (IWeldmentBeadFeatureData)

Gets or sets the length of each bead segment of the weld bead.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property BeadLength( _  
    ByVal Side As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim value As System.Double  
  
instance.BeadLength(Side) = value  
  
value = instance.BeadLength(Side)
```

C#

```
System.double BeadLength(  
    System.int Side  
) {get; set;}
```

C++/CLI

```
property System.double BeadLength {  
    System.double get(System.int Side);  
    void set (System.int Side, System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side
Side as defined in [swWeldBeadSide_e](#)

Property Value

Length of weld bead

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::BeadLength](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

This property is only valid for intermittent or staggered types of weld beads. Use [IWeldmentBeadFeatureData::BeadType](#) to determine the type of weld bead.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0



Gets or sets the distance between the start of each weld bead.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property BeadPitch( _  
    ByVal Side As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim value As System.Double  
  
instance.BeadPitch(Side) = value  
  
value = instance.BeadPitch(Side)
```

C#

```
System.double BeadPitch(  
    System.int Side  
) {get; set;}
```

C++/CLI

```
property System.double BeadPitch {  
    System.double get(System.int Side);  
    void set (System.int Side, System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Side as defined by [swWeldBeadSide_e](#)

Property Value

Pitch

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::BeadPitch](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

This property is only valid for intermittent or staggered types of weld beads. Use [IWeldmentBeadFeatureData::BeadType](#) to determine the type of weld bead.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)

Availability

BeadSize Property (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : BeadSize Property (IWeldmentBeadFeatureData)

Gets or sets the length of the leg of the weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Property BeadSize( _  
    ByVal Side As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim value As System.Double
```

```
instance.BeadSize(Side) = value
```

```
value = instance.BeadSize(Side)
```

C#

```
System.double BeadSize(  
    System.int Side  
) {get; set;}
```

C++/CLI

```
property System.double BeadSize {  
    System.double get(System.int Side);  
    void set (System.int Side, System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Side as defined by [swWeldBeadSide_e](#)

Property Value

Length of the leg

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::BeadSize](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)

Availability

BeadType Property (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : BeadType Property (IWeldmentBeadFeatureData)

Gets or sets the type of weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Property BeadType( _  
    ByVal Side As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim value As System.Integer
```

```
instance.BeadType(Side) = value
```

```
value = instance.BeadType(Side)
```

C#

```
System.int BeadType(  
    System.int Side  
) {get; set;}
```

C++/CLI

```
property System.int BeadType {  
    System.int get(System.int Side);  
    void set (System.int Side, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Side as defined in [swWeldBeadSide_e](#)

Property Value

Type as defined in [swWeldBeadType_e](#)

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::BeadType](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::UseOtherSide Property](#)

Availability

GetFaces Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : GetFaces Method (IWeldmentBeadFeatureData)

Gets the sets of faces whose edges intersection defines the edges to which the weld bead is applied.

.NET Syntax

Visual Basic (Declaration)

```

Sub GetFaces( _
    ByVal Side As System.Integer, _
    ByRef FaceSet1 As System.Object, _
    ByRef FaceSet2 As System.Object _
)

```

Visual Basic (Usage)



```

Dim instance As IWeldmentBeadFeatureData
Dim Side As System.Integer
Dim FaceSet1 As System.Object
Dim FaceSet2 As System.Object

instance.GetFaces(Side, FaceSet1, FaceSet2)

```

C#

```

void GetFaces(
    System.int Side,
    out System.object FaceSet1,
    out System.object FaceSet2
)

```

C++/CLI

```

void GetFaces(
    & System.int Side,
    & [Out] System.Object^ FaceSet1,
    & [Out] System.Object^ FaceSet2
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Side as defined in [swWeldBeadSide_e](#)

FaceSet1

First set of [faces](#)

FaceSet2

Second set of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::GetFaces](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

After using this method, use [IWeldmentBeadFeatureData::GetVirtualEdges](#) to get the new intersections. Then use [IWeldmentBeadFeatureData::SetVirtualEdges](#) to specify the edges to which you want the weld bead applied. By default, [IWeldmentBeadFeatureData::SetFaces](#) creates the bead on all virtual edges. [IWeldmentBeadFeatureData::SetVirtualEdges](#) lets you exclude any of these edges.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::IGetFaces Method](#)
[IWeldmentBeadFeatureData::GetFacesCount Method](#)
[IWeldmentBeadFeatureData::SetFaces Method](#)
[IWeldmentBeadFeatureData::ISetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacesCount Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : GetFacesCount Method (IWeldmentBeadFeatureData)

Gets the number of faces in each sets of faces whose intersection defines the edges to which this weld bead is applied.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetFacesCount( _  
    ByVal Side As System.Integer, _  
    ByRef FaceSet1Count As System.Integer, _  
    ByRef FaceSet2Count As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim FaceSet1Count As System.Integer  
Dim FaceSet2Count As System.Integer  
  
instance.GetFacesCount(Side, FaceSet1Count, FaceSet2Count)
```

C#

```
void GetFacesCount(  
    System.int Side,  
    out System.int FaceSet1Count,  
    out System.int FaceSet2Count  
)
```

C++/CLI

```
void GetFacesCount(  
& System.int Side,  
& [Out] System.int FaceSet1Count,  
& [Out] System.int FaceSet2Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side
Side as defined in [swWeldBeadSide_e](#)
FaceSet1Count
Number of faces in first set of faces
FaceSet2Count
Number of faces in second set of faces

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::GetFacesCount](#).

Remarks

Call this method before calling [IWeldmentBeadFeatureData::!GetFaces](#).

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::GetFaces Method](#)
[IWeldmentBeadFeatureData::!SetFaces Method](#)
[IWeldmentBeadFeatureData::SetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVirtualEdges Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : GetVirtualEdges Method (IWeldmentBeadFeatureData)

Gets the edges to which the weld bead is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVirtualEdges( _  
    ByVal FromFeature As System.Boolean, _  
    ByVal Side As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim FromFeature As System.Boolean  
Dim Side As System.Integer  
Dim value As System.Object  
  
value = instance.GetVirtualEdges(FromFeature, Side)
```

C#

```
System.object GetVirtualEdges(  
    System.bool FromFeature,  
    System.int Side  
)
```

C++/CLI

```
System.Object^ GetVirtualEdges(  
& System.bool FromFeature,  
& System.int Side  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFeature

True gets the virtual edges used by the feature, false gets all of the virtual edges

Side

Side as defined in [swWeldBeadSide_e](#)

Return Value

Array of the [edges](#)

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::GetVirtualEdges](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

Do not perform any operations on the returned edges as they are only temporary to help you decide which edges to keep for this weld bead.

After using [IWeldmentBeadFeatureData::SetFaces](#), use [IWeldmentBeadFeatureData::GetVirtualEdges](#) to get the new intersections. Then use [IWeldmentBeadFeatureData::SetVirtualEdges](#) to specify the edges to which you want the weld bead applied. By default, [IWeldmentBeadFeatureData::SetFaces](#) creates the bead on all virtual edges; [IWeldmentBeadFeatureData::SetVirtualEdges](#) lets you exclude any of these edges.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::GetVirtualEdgesCount Method](#)
[IWeldmentBeadFeatureData::GetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::SetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::SetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVirtualEdgesCount Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : GetVirtualEdgesCount Method (IWeldmentBeadFeatureData)

Gets the number of edges to which the weld bead is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVirtualEdgesCount( _  
    ByVal FromFeature As System.Boolean, _  
    ByVal Side As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim FromFeature As System.Boolean  
Dim Side As System.Integer  
Dim value As System.Integer
```

```
value = instance.GetVirtualEdgesCount(FromFeature, Side)
```

C#

```
System.int GetVirtualEdgesCount(  
    System.bool FromFeature,  
    System.int Side  
)
```

C++/CLI

```
System.int GetVirtualEdgesCount(  
& System.bool FromFeature,  
& System.int Side  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFeature
True gets the virtual edges used by the feature, false gets all of the virtual edges
Side
Side as defined in [swWeldBeadSide_e](#)

Return Value

Number of edges

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::GetVirtualEdgesCount](#).

Remarks

Call this method before calling [IWeldmentBeadFeatureData::GetVirtualEdges](#).

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::GetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::ISetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::SetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::ISetFaces Method](#)
[IWeldmentBeadFeatureData::SetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaces Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : IGetFaces Method (IWeldmentBeadFeatureData)

Gets the sets of faces whose edges intersection defines the edges to which the weld bead is applied.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetFaces( _  
    ByVal Side As System.Integer, _  
    ByVal Count1 As System.Integer, _  
    ByRef FaceSet1 As Face2, _  
    ByVal Count2 As System.Integer, _  
    ByRef FaceSet2 As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim Count1 As System.Integer  
Dim FaceSet1 As Face2  
Dim Count2 As System.Integer  
Dim FaceSet2 As Face2  
  
instance.IGetFaces(Side, Count1, FaceSet1, Count2, FaceSet2)
```

C#

```

void IGetFaces(
    System.int Side,
    System.int Count1,
    out Face2 FaceSet1,
    System.int Count2,
    out Face2 FaceSet2
)

```

C++/CLI

```

void IGetFaces(
    & System.int Side,
    & System.int Count1,
    & [Out] Face2^ FaceSet1,
    & System.int Count2,
    & [Out] Face2^ FaceSet2
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Side as defined in [swWeldBeadSide_e](#)

Count1

Number of faces in first set of faces

FaceSet1

- in-process, unmanaged C++: Pointer to an array of the first set of [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Count2

Number of faces in second set of faces

FaceSet2

- in-process, unmanaged C++: Pointer to an array of the second set of [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Before calling this method, call [IWeldmentBeadFeatureData::GetFacesCount](#).

After using this method, use [IWeldmentBeadFeatureData::IGetVirtualEdges](#) to get the new intersections. Then use [IWeldmentBeadFeatureData::ISetVirtualEdges](#) to specify the edges to which you want the weld bead applied. By default, [WeldmentBeadFeatureData::SetFaces](#) creates the bead on all virtual edges. [IWeldmentBeadFeatureData::ISetVirtualEdges](#) lets you exclude any of these edges.

See Also

[IWeldmentBeadFeatureData Interface](#)

[IWeldmentBeadFeatureData Members](#)

[IWeldmentBeadFeatureData::GetFaces Method](#)

[IWeldmentBeadFeatureData::GetVirtualEdges Method](#)

[IWeldmentBeadFeatureData::GetVirtualEdgesCount Method](#)

[IWeldmentBeadFeatureData::SetFaces Method](#)

[IWeldmentBeadFeatureData::SetVirtualEdges Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetVirtualEdges Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : IGetVirtualEdges Method (IWeldmentBeadFeatureData)

Gets the edges to which the weld bead is applied.

.NET Syntax

Visual Basic (Declaration)

```

Function IGetVirtualEdges( _
    ByVal FromFeature As System.Boolean, _

```

```

    ByVal Side As System.Integer, _
    ByVal Count As System.Integer _
) As Edge

```

Visual Basic (Usage)



```

Dim instance As IWeldmentBeadFeatureData
Dim FromFeature As System.Boolean
Dim Side As System.Integer
Dim Count As System.Integer
Dim value As Edge

value = instance.IGetVirtualEdges(FromFeature, Side, Count)

```

C#

```

Edge IGetVirtualEdges(
    System.bool FromFeature,
    System.int Side,
    System.int Count
)

```

C++/CLI

```

Edge^ IGetVirtualEdges(
    & System.bool FromFeature,
    & System.int Side,
    & System.int Count
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFeature

True gets the virtual edges used by the feature, false gets all of the virtual edges

Side

Side as defined in [swWeldBeadSide_e](#)

Count

Number of edges to which weld bead applied

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Do not perform any operations on the returned edges as they are only temporary to help you decide which edges to keep for this weld bead.

Call [IWeldmentBeadFeatureData::GetVirtualEdgesCount](#) to get the number of edges.

After using [IWeldmentBeadFeatureData::SetFaces](#), use [IWeldmentBeadFeatureData::IGetVirtualEdges](#) to get the new intersections. Then use [IWeldmentBeadFeatureData::ISetVirtualEdges](#) to specify the edges to which you want the weld bead applied. By default, [IWeldmentBeadFeatureData::ISetFaces](#) creates the bead on all virtual edges; [IWeldmentBeadFeatureData::ISetVirtualEdges](#) lets you exclude any of these edges.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::GetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::SetFaces Method](#)
[IWeldmentBeadFeatureData::SetVirtualEdges Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0



Sets the faces to which to apply the weld bead.

VB.NET Syntax

Visual Basic (Declaration)

```
Function ISetFaces( _  
    ByVal Side As System.Integer, _  
    ByVal Count1 As System.Integer, _  
    ByRef FaceSet1 As Face2, _  
    ByVal Count2 As System.Integer, _  
    ByRef FaceSet2 As Face2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim Count1 As System.Integer  
Dim FaceSet1 As Face2  
Dim Count2 As System.Integer  
Dim FaceSet2 As Face2  
Dim value As System.Boolean  
  
value = instance.ISetFaces(Side, Count1, FaceSet1, Count2, FaceSet2)
```

C#

```
System.bool ISetFaces(  
    System.int Side,  
    System.int Count1,  
    ref Face2 FaceSet1,  
    System.int Count2,  
    ref Face2 FaceSet2  
)
```

C++/CLI

```
System.bool ISetFaces(  
& System.int Side,  
& System.int Count1,  
& Face2^% FaceSet1,  
& System.int Count2,  
& Face2^% FaceSet2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Side as defined in [swWeldBeadSide_e](#)

Count1

Number of faces in the first set of faces

FaceSet1

- in-process, unmanaged C++: Pointer to an array of the first set of [faces](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Count2

Number of faces in the second set of faces

FaceSet2

- in-process, unmanaged C++: Pointer to an array of the second set of [faces](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

Return Value

True if the weld bead is applied to the specified faces, false if not

Remarks

Although you must select planar faces for the face sets, fillet weld beads can follow non-planar, tangent contours when you set [IWeldmentBeadFeatureData::TangentPropagation](#) to TRUE.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::SetFaces Method](#)
[IWeldmentBeadFeatureData::IGetFaces Method](#)
[IWeldmentBeadFeatureData::GetFacesCount Method](#)
[IWeldmentBeadFeatureData::GetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetVirtualEdges Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : ISetVirtualEdges Method (IWeldmentBeadFeatureData)

Sets the edges to which to apply this weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetVirtualEdges( _  
    ByVal Side As System.Integer, _  
    ByVal Count As System.Integer, _  
    ByRef EdgesIn As Edge _  
)
```

Visual Basic (Usage)

```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim Count As System.Integer  
Dim EdgesIn As Edge  
  
instance.ISetVirtualEdges(Side, Count, EdgesIn)
```

C#

```
void ISetVirtualEdges(  
    System.int Side,  
    System.int Count,  
    ref Edge EdgesIn  
)
```

C++/CLI

```
void ISetVirtualEdges(  
& System.int Side,  
& System.int Count,  
& Edge^% EdgesIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Side as defined in [swWeldBeadSide_e](#)

Count

Number of edges to which to apply this weld bead

EdgesIn

- in-process, unmanaged C++: Pointer to an array of [edges](#) to which to apply this weld bead

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

After using [IWeldmentBeadFeatureData::!SetFaces](#), use [IWeldmentBeadFeatureData::!GetVirtualEdges](#) to get the new intersections. Then use [IWeldmentBeadFeatureData::!SetVirtualEdges](#) to specify the edges to which you want the weld bead applied. By default, [IWeldmentBeadFeatureData::!SetFaces](#) creates the bead on all virtual edges. [IWeldmentBeadFeatureData::!SetVirtualEdges](#) lets you exclude any of these edges.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::SetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::SetFaces Method](#)
[IWeldmentBeadFeatureData::!GetVirtualEdges Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : ReleaseSelectionAccess Method (IWeldmentBeadFeatureData)

Releases access to the selections that define this weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::ReleaseSelectionAccess](#).

Remarks

[IWeldmentBeadFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [!Feature::ModifyDefinition](#) or [!Feature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SetFaces Method (IWeldmentBeadFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : SetFaces Method (IWeldmentBeadFeatureData)

Sets the faces to which to apply the weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFaces( _  
    ByVal Side As System.Integer, _  
    ByVal FaceSet1 As System.Object, _  
    ByVal FaceSet2 As System.Object _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim FaceSet1 As System.Object  
Dim FaceSet2 As System.Object  
Dim value As System.Boolean  
  
value = instance.SetFaces(Side, FaceSet1, FaceSet2)
```

C#

```
System.bool SetFaces(  
    System.int Side,  
    System.object FaceSet1,  
    System.object FaceSet2  
)
```

C++/CLI

```
System.bool SetFaces(  
& System.int Side,  
& System.Object^ FaceSet1,  
& System.Object^ FaceSet2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Side as defined in [swWeldBeadSide_e](#)

FaceSet1

First set of [faces](#) to which to apply the weld bead

FaceSet2

Second set of [faces](#) to which to apply the weld bead

Return Value

True if the weld bead is applied to the specified faces, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::SetFaces](#).

Example

[Change Weld Bead Faces \(VBA\)](#)

Remarks

Although you must select planar faces for the face sets, fillet weld beads can follow non-planar, tangent contours when you set [IWeldmentBeadFeatureData::TangentPropagation](#) to TRUE.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::ISetFaces Method](#)
[IWeldmentBeadFeatureData::IGetFaces Method](#)
[IWeldmentBeadFeatureData::GetFacesCount Method](#)
[IWeldmentBeadFeatureData::GetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetVirtualEdges Method (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : SetVirtualEdges Method (IWeldmentBeadFeatureData)

Sets the edges to which to apply this weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVirtualEdges( _  
    ByVal Side As System.Integer, _  
    ByVal EdgesIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim Side As System.Integer  
Dim EdgesIn As System.Object  
  
instance.SetVirtualEdges(Side, EdgesIn)
```

C#

```
void SetVirtualEdges(  
    System.int Side,  
    System.object EdgesIn  
)
```

C++/CLI

```
void SetVirtualEdges(  
& System.int Side,  
& System.Object^ EdgesIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side
Side as defined in [swWeldBeadSide_e](#)
EdgesIn
Array of [edges](#) to which to apply this weld bead

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::SetVirtualEdges](#).

Remarks

After using [IWeldmentBeadFeatureData::SetFaces](#), use [IWeldmentBeadFeatureData::GetVirtualEdges](#) to get the new intersections. Then use [IWeldmentBeadFeatureData::SetVirtualEdges](#) to specify the edges to which you want the weld bead applied. By default, [IWeldmentBeadFeatureData::SetFaces](#) creates the bead on all virtual edges. [IWeldmentBeadFeatureData::SetVirtualEdges](#) lets you exclude any of these edges.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::ISetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::ISetFaces Method](#)
[IWeldmentBeadFeatureData::IGetVirtualEdges Method](#)
[IWeldmentBeadFeatureData::GetVirtualEdgesCount Method](#)
[IWeldmentBeadFeatureData::GetVirtualEdges Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TangentPropagation Property (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : TangentPropagation Property (IWeldmentBeadFeatureData)

Gets or sets whether to propagate the weld bead along the tangent.

.NET Syntax

Visual Basic (Declaration)

Property TangentPropagation As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim value As System.Boolean
```

```
instance.TangentPropagation = value  
value = instance.TangentPropagation
```

C#

```
System.bool TangentPropagation {get; set;}
```

C++/CLI

```
property System.bool TangentPropagation {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate the weld bead along the tangent, false to not

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::TangentPropagation](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)
[IWeldmentBeadFeatureData::BeadLength Property](#)
[IWeldmentBeadFeatureData::BeadPitch Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseOtherSide Property (IWeldmentBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentBeadFeatureData Interface](#) : UseOtherSide Property (IWeldmentBeadFeatureData)

Gets or sets whether to apply the weld bead to both sides of the intersecting faces.

.NET Syntax

Visual Basic (Declaration)

```
Property UseOtherSide As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldmentBeadFeatureData  
Dim value As System.Boolean
```

```
instance.UseOtherSide = value
```

```
value = instance.UseOtherSide
```

C#

```
System.bool UseOtherSide {get; set;}
```

C++/CLI

```
property System.bool UseOtherSide {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to apply the weld bead to both sides, false to not

Visual Basic for Applications (VBA) Syntax

See [WeldmentBeadFeatureData::UseOtherSide](#).

Example

See the [IWeldmentBeadFeatureData](#) examples.

Remarks

This property is valid, and optional, for full length and intermittent weld beads only. Use [IWeldmentBeadFeatureData::BeadType](#) to determine the type of weld bead.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentBeadFeatureData Interface](#)
[IWeldmentBeadFeatureData Members](#)

