

SOLIDWORKS API (.NET VBA C#) — Reference

(332/337): IWeldmentCutListAnnotation- IWeldmentTrimExtendFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IWeldmentCutListAnnotation (Type)

IWeldmentCutListAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentCutListAnnotation Interface

Allows access to the annotations in a [weldment cut list](#) table.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWeldmentCutListAnnotation
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListAnnotation
```

C#

```
public interface IWeldmentCutListAnnotation
```

C++/CLI

```
public interface class IWeldmentCutListAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListAnnotation](#).

Example

[Sort Table \(C#\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(VBA\)](#)

Accessors

[IView::InsertWeldmentTable](#)
[IWeldmentCutListFeature::GetTableAnnotations](#) and [IWeldmentCutListFeature::!GetTableAnnotations](#)

Access Diagram

[WeldmentCutListAnnotation](#)

See Also

[IWeldmentCutListAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IWeldmentCutListFeature Interface](#)
[TableAnnotation Interface](#)

IWeldmentCutListAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentCutListAnnotation Interface

The following tables list the members exposed by [IWeldmentCutListAnnotation](#).

Public Properties

Name	Description
WeldmentCutListFeature	Gets the weldment cut list feature for this weldment cut list table annotation.



[Top](#)

Public Methods

Name	Description
 GetAllCustomProperties	Gets the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.
 GetAllCustomPropertiesCount	Gets the number of items in the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.
 GetColumnCustomProperty	Gets the custom property for the specified user-defined column.
 IGetAllCustomProperties	Gets the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.
 SetColumnCustomProperty	Sets the custom property of the specified user-defined column.
 Sort	Sorts this weldment cut list by the specified column in the specified sorting direction.

[Top](#)

See Also

[IWeldmentCutListAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IWeldmentCutListFeature Interface](#)
[ITableAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWeldmentCutListAnnotation Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentCutListAnnotation Interface

For a list of all members of this type, see [IWeldmentCutListAnnotation members](#).

Public Methods

Name	Description
 GetAllCustomProperties	Gets the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.
 GetAllCustomPropertiesCount	Gets the number of items in the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.
 GetColumnCustomProperty	Gets the custom property for the specified user-defined column.
 IGetAllCustomProperties	Gets the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.
 SetColumnCustomProperty	Sets the custom property of the specified user-defined column.
 Sort	Sorts this weldment cut list by the specified column in the specified sorting direction.

[Top](#)

See Also

[IWeldmentCutListAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IWeldmentCutListFeature Interface](#)
[ITableAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWeldmentCutListAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentCutListAnnotation Interface

For a list of all members of this type, see [IWeldmentCutListAnnotation members](#).

Public Properties

Name	Description
 WeldmentCutListFeature	Gets the weldment cut list feature for this weldment cut list table annotation.

[Top](#)

See Also

[IWeldmentCutListAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IWeldmentCutListFeature Interface](#)
[ITableAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAllCustomProperties Method (IWeldmentCutListAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListAnnotation Interface](#) : GetAllCustomProperties Method (IWeldmentCutListAnnotation)

Gets the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAllCustomProperties() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListAnnotation  
Dim value As System.Object  
  
value = instance.GetAllCustomProperties()
```

C#

```
System.object GetAllCustomProperties()
```

C++/CLI

```
System.Object^ GetAllCustomProperties();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings of available custom properties

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListAnnotation::GetAllCustomProperties](#).

Example

[Get Weldment Cut List Feature and Annotations \(VBA\)](#)
[Get Weldment Cut List Feature and Annotations \(VB.NET\)](#)
[Get Weldment Cut List Feature and Annotations \(C#\)](#)

Remarks

The list of available custom properties includes all of the items in the weldment cut list table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListAnnotation Members](#)
[IWeldmentCutListAnnotation::GetAllCustomPropertiesCount Method](#)
[IWeldmentCutListAnnotation::IWeldmentCutListAnnotation.GetAllCustomProperties Method](#)
[IWeldmentCutListAnnotation::GetColumnCustomProperty Method](#)
[IWeldmentCutListAnnotation::SetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAllCustomPropertiesCount Method (IWeldmentCutListAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListAnnotation Interface](#) : GetAllCustomPropertiesCount Method (IWeldmentCutListAnnotation)

Gets the number of items in the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAllCustomPropertiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListAnnotation  
Dim value As System.Integer  
  
value = instance.GetAllCustomPropertiesCount()
```

C#

```
System.int GetAllCustomPropertiesCount()
```

C++/CLI

```
System.int GetAllCustomPropertiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of available custom properties

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListAnnotation::GetAllCustomPropertiesCount](#).

Example

[Get Weldment Cut List Feature and Annotations \(VBA\)](#)
[Get Weldment Cut List Feature and Annotations \(VB.NET\)](#)
[Get Weldment Cut List Feature and Annotations \(C#\)](#)

Remarks

Call this method before calling [IWeldmentCutListAnnotation::IGetAllCustomProperties](#).

The list of possible custom properties includes all of the items in the weldment cut list table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListAnnotation Members](#)
[IWeldmentCutListAnnotation::GetAllCustomProperties Method](#)
[IWeldmentCutListAnnotation::GetColumnCustomProperty Method](#)
[IWeldmentCutListAnnotation::SetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetColumnCustomProperty Method (IWeldmentCutListAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListAnnotation Interface](#) : GetColumnCustomProperty Method (IWeldmentCutListAnnotation)

Gets the custom property for the specified user-defined column.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetColumnCustomProperty( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListAnnotation  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetColumnCustomProperty(Index)
```

C#

```
System.string GetColumnCustomProperty(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetColumnCustomProperty(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Column for which to get the custom property

Return Value

Custom property for this user-defined column

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListAnnotation::GetColumnCustomProperty](#).

Remarks

This method returns an empty string if the column is not a user-defined column.

To get the list of custom properties, use [IWeldmentCutListAnnotation::GetAllCustomProperties](#) or [IWeldmentCutListAnnotation::IGetAllCustomProperties](#). The list of possible custom properties includes all of the items in the weldment cut list annotation table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListAnnotation Members](#)
[IWeldmentCutListAnnotation::SetColumnCustomProperty Method](#)
[IWeldmentCutListAnnotation::GetAllCustomPropertiesCount Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAllCustomProperties Method (IWeldmentCutListAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListAnnotation Interface](#) : [IGetAllCustomProperties Method \(IWeldmentCutListAnnotation\)](#)

Gets the list of available custom properties that could be used for a custom properties column in this weldment cut list table annotation.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetAllCustomProperties( _  
    ByVal Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListAnnotation  
Dim Count As System.Integer  
Dim value As System.String  
  
value = instance.IGetAllCustomProperties(Count)
```

C#

```
System.string IGetAllCustomProperties(  
    System.int Count  
)
```

C++/CLI

```
System.String^ IGetAllCustomProperties(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of available custom properties

Return Value

- in-process, unmanaged C++: Pointer to an array of strings of available custom properties
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IWeldmentCutListAnnotation::GetAllCustomPropertiesCount](#) to get Count.

The list of available custom properties includes all of the items in the weldment cut list table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListAnnotation Members](#)
[IWeldmentCutListAnnotation::GetAllCustomProperties Method](#)
[IWeldmentCutListAnnotation::GetColumnCustomProperty Method](#)
[IWeldmentCutListAnnotation::SetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetColumnCustomProperty Method (IWeldmentCutListAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListAnnotation Interface](#) : SetColumnCustomProperty Method (IWeldmentCutListAnnotation)

Sets the custom property of the specified user-defined column.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetColumnCustomProperty( _
    ByVal Index As System.Integer, _
    ByVal CustomProp As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListAnnotation
Dim Index As System.Integer
Dim CustomProp As System.String
Dim value As System.Boolean

value = instance.SetColumnCustomProperty(Index, CustomProp)
```

C#

```
System.bool SetColumnCustomProperty(
    System.int Index,
    System.string CustomProp
)
```

C++/CLI

```
System.bool SetColumnCustomProperty(
    & System.int Index,
    & System.String^ CustomProp
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Column for which to get the custom property
CustomProp
Custom property for this user-defined column

Return Value

True if the custom property is set, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListAnnotation::SetColumnCustomProperty](#).

Remarks

Use this method to create a user-defined column where each row in the column is automatically filled in with the custom property value for that particular configuration. The default title for the column is the name of the custom property. If the specified custom property is not a valid custom property, then each row in the column remains empty.

To create a user-defined column that is not attached to a custom property; for example, you want to fill in each row of the column yourself, use this method with the CustomProp value specified as the title of the column.

To get the list of available custom properties, use [IWeldmentCutListAnnotation::GetAllCustomProperties](#) or [IWeldmentCustListAnnotation::!GetAllCustomProperties](#). The list of available custom properties includes all of the items in the weldment cut-list table, which includes items from the file summary items and file custom properties that have been set.

This method returns false if the column is not a user-defined column, and no action is taken.

See Also

[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListAnnotation Members](#)
[IWeldmentCutListAnnotation::GetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

Sort Method (IWeldmentCutListAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListAnnotation Interface](#) : Sort Method (IWeldmentCutListAnnotation)

Sorts this weldment cut list by the specified column in the specified sorting direction.

.NET Syntax

Visual Basic (Declaration)

```
Function Sort( _  
    ByVal ColumnIndex As System.Integer, _  
    ByVal SortAscending As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListAnnotation  
Dim ColumnIndex As System.Integer  
Dim SortAscending As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.Sort(ColumnIndex, SortAscending)
```

C#

```
System.bool Sort(  
    System.int ColumnIndex,  
    System.bool SortAscending  
)
```

C++/CLI

```
System.bool Sort(  
& System.int ColumnIndex,  
& System.bool SortAscending  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ColumnIndex

0-based index of column to sort by (see **Remarks**)

SortAscending

True to sort ascending, false to sort descending

Return Value

True if sorted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListAnnotation::Sort](#).

Example

[Sort Table \(VBA\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(C#\)](#)

Remarks

Weldment cut lists must be sorted by any column except Item Number.

See [Sorting Tables](#) for more information.

See Also

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

WeldmentCutListFeature Property (IWeldmentCutListAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListAnnotation Interface](#) : WeldmentCutListFeature Property (IWeldmentCutListAnnotation)

Gets the weldment cut list feature for this weldment cut list table annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property WeldmentCutListFeature As WeldmentCutListFeature
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListAnnotation  
Dim value As WeldmentCutListFeature  
  
value = instance.WeldmentCutListFeature
```

C#

```
WeldmentCutListFeature WeldmentCutListFeature {get;}
```

C++/CLI

```
property WeldmentCutListFeature^ WeldmentCutListFeature {  
    WeldmentCutListFeature^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Weldment cut list feature](#)

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListAnnotation::WeldmentCutListFeature](#).

See Also

[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListAnnotation Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

IWeldmentCutListFeature (Type)

IWeldmentCutListFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentCutListFeature Interface

Allows access to a weldment cut list feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWeldmentCutListFeature
```

Visual Basic (Usage)

```
Dim instance As IWeldmentCutListFeature
```

C#

```
public interface IWeldmentCutListFeature
```

C++/CLI

```
public interface class IWeldmentCutListFeature
```

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature](#).

Example

[Get Weldment Cut List Feature and Annotations \(VBA\)](#)
[Get Weldment Cut List Feature and Annotations \(VB.NET\)](#)
[Get Weldment Cut List Feature and Annotations \(C#\)](#)

Accessors

[IFeature::GetSpecificFeature2](#)
[IWeldmentCutListAnnotation::WeldmentCutListFeature](#)

Access Diagram

[WeldmentCutListFeature](#)

See Also

[IWeldmentCutListFeature Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWeldmentCutList Method](#)
[IWeldmentCutListAnnotation Interface](#)
[IFeatureManager::InsertWeldmentCutList2 Method](#)

IWeldmentCutListFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentCutListFeature Interface

The following tables list the members exposed by [IWeldmentCutListFeature](#).

Public Properties

Name	Description
------	-------------

 Configuration	Gets or sets the name of the configuration for this weldment cut list table.
 KeepCurrentItemNumbers	Gets or sets whether item numbers are kept with their rows when columns are sorted or reordered in this weldment cut list table.
 KeepMissingItems	Gets or sets whether to continue to show cut list items that were deleted from the weldment in the weldment cut list table.
 SequenceStartNumber	Gets or sets the starting sequence number for this weldment cut list table.
 StrikeoutMissingItems	Gets or sets whether to strike out missing items in the weldment cut list table.

[Top](#)

Public Methods

Name	Description
 GetFeature	Gets the feature for this weldment cut list table.
 GetReferencedModelName	Gets the name of the referenced model.
 GetTableAnnotationCount	Gets the number of weldment cut list annotations for this weldment cut list table.
 GetTableAnnotations	Gets the weldment cut list annotations for this weldment cut list table.
 IGetTableAnnotations	Gets the weldment cut list annotations for this weldment cut list table.

[Top](#)

See Also

[IWeldmentCutListFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWeldmentCutList Method](#)
[IWeldmentCutListAnnotation Interface](#)
[IFeatureManager::InsertWeldmentCutList2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWeldmentCutListFeature Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentCutListFeature Interface

For a list of all members of this type, see [IWeldmentCutListFeature members](#).

Public Methods

Name	Description
 GetFeature	Gets the feature for this weldment cut list table.
 GetReferencedModelName	Gets the name of the referenced model.
 GetTableAnnotationCount	Gets the number of weldment cut list annotations for this weldment cut list table.
 GetTableAnnotations	Gets the weldment cut list annotations for this weldment cut list table.
 IGetTableAnnotations	Gets the weldment cut list annotations for this weldment cut list table.

[Top](#)

See Also

[IWeldmentCutListFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWeldmentCutList Method](#)
[IWeldmentCutListAnnotation Interface](#)
[IFeatureManager::InsertWeldmentCutList2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWeldmentCutListFeature Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentCutListFeature Interface

For a list of all members of this type, see [IWeldmentCutListFeature members](#).

Public Properties

Name	Description
------	-------------

 Configuration	Gets or sets the name of the configuration for this weldment cut list table.
 KeepCurrentItemNumbers	Gets or sets whether item numbers are kept with their rows when columns are sorted or reordered in this weldment cut list table.
 KeepMissingItems	Gets or sets whether to continue to show cut list items that were deleted from the weldment in the weldment cut list table.
 SequenceStartNumber	Gets or sets the starting sequence number for this weldment cut list table.
 StrikeoutMissingItems	Gets or sets whether to strike out missing items in the weldment cut list table.

[Top](#)

See Also

[IWeldmentCutListFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWeldmentCutList Method](#)
[IWeldmentCutListAnnotation Interface](#)
[IFeatureManager::InsertWeldmentCutList2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Configuration Property (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : Configuration Property (IWeldmentCutListFeature)

Gets or sets the name of the configuration for this weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

Property Configuration As System.String

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature
Dim value As System.String
```

```
instance.Configuration = value
```

```
value = instance.Configuration
```

C#

```
System.string Configuration {get; set;}
```

C++/CLI

```
property System.String^ Configuration {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the configuration shown in the weldment cut list table

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::Configuration](#).

Example

See the [IWeldmentCutListFeature](#) examples.

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : GetFeature Method (IWeldmentCutListFeature)

Gets the feature for this weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Feature](#) for this weldment cut list table

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::GetFeature](#).

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetReferencedModelName Method (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : GetReferencedModelName Method (IWeldmentCutListFeature)

Gets the name of the referenced model.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferencedModelName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature
Dim value As System.String

value = instance.GetReferencedModelName()
```

C#

```
System.string GetReferencedModelName()
```

C++/CLI

```
System.String^ GetReferencedModelName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of referenced model

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::GetReferencedModelName](#).

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)

Availability

SOLIDWORKS 2023 SP1, Revision Number 31.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotationCount Method (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : GetTableAnnotationCount Method (IWeldmentCutListFeature)

Gets the number of weldment cut list annotations for this weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature
Dim value As System.Integer

value = instance.GetTableAnnotationCount()
```

C#

```
System.int GetTableAnnotationCount()
```

C++/CLI

```
System.int GetTableAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of weldment cut list annotations for this weldment cut list table

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::GetTableAnnotationCount](#).

Remarks

Call this method before calling [IWeldmentCutListFeature::IGetTableAnnotations](#) to get the size of the array for that method.

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)
[IWeldmentCutListFeature::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotations Method (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : GetTableAnnotations Method (IWeldmentCutListFeature)

Gets the weldment cut list annotations for this weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature  
Dim value As System.Object  
  
value = instance.GetTableAnnotations()
```

C#

```
System.object GetTableAnnotations()
```

C++/CLI

```
System.Object^ GetTableAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [weldment cut-list annotations](#) for this weldment cut list table

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::GetTableAnnotations](#).

Example

See the [IWeldmentCutListFeature](#) examples.

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)
[IWeldmentCutListFeature::IGetTableAnnotations Method](#)
[IWeldmentCutListFeature::GetTableAnnotationCount Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

IGetTableAnnotations Method (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : IGetTableAnnotations Method (IWeldmentCutListFeature)

Gets the weldment cut list annotations for this weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTableAnnotations( _  
    ByVal Count As System.Integer _  
) As WeldmentCutListAnnotation
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature  
Dim Count As System.Integer  
Dim value As WeldmentCutListAnnotation  
  
value = instance.IGetTableAnnotations(Count)
```

C#

```
WeldmentCutListAnnotation IGetTableAnnotations(  
    System.int Count  
)
```

C++/CLI

```
WeldmentCutListAnnotation^ IGetTableAnnotations(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of weldment cut list annotations for this weldment cut list feature

Return Value

- in-process, unmanaged C++: Pointer to an array of [weldment cut-list annotations](#) for this weldment cut list table
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IWeldmentCutListFeature::GetTableAnnotationCount](#) to get Count.

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)
[IWeldmentCutListFeature::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

KeepCurrentItemNumbers Property (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : KeepCurrentItemNumbers Property (IWeldmentCutListFeature)

Gets or sets whether item numbers are kept with their rows when columns are sorted or reordered in this weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

Property KeepCurrentItemNumbers As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature
Dim value As System.Boolean

instance.KeepCurrentItemNumbers = value
value = instance.KeepCurrentItemNumbers
```

C#

```
System.bool KeepCurrentItemNumbers {get; set;}
```

C++/CLI

```
property System.bool KeepCurrentItemNumbers {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to keep item numbers with their rows when columns are sorted or reordered, false to not

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::KeepCurrentItemNumbers](#).

Example

See the [IWeldmentCutListFeature](#) examples.

See Also

[IWeldmentCutListFeature Interface](#)
[WeldmentCutListFeature Members](#)
[IWeldmentCutListFeature::KeepMissingItems Property](#)
[IWeldmentCutListFeature::SequenceStartNumber Property](#)
[IWeldmentCutListFeature::StrikeoutMissingItems Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepMissingItems Property (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : KeepMissingItems Property (IWeldmentCutListFeature)

Gets or sets whether to continue to show cut list items that were deleted from the weldment in the weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

Property KeepMissingItems As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature
Dim value As System.Boolean

instance.KeepMissingItems = value

value = instance.KeepMissingItems
```

C#

```
System.bool KeepMissingItems {get; set;}
```

C++/CLI

```
property System.bool KeepMissingItems {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to keep missing cut list items, false to not

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::KeepMissingItems](#).

Remarks

Use [IWeldmentCutListFeature::StrikeoutMissingItems](#) to determine if deleted items are to be shown with strikeout formatting in the weldment cut list table.

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)
[IWeldmentCutListFeature::KeepCurrentItemNumbers Property](#)
[IWeldmentCutListFeature::SequenceStartNumber Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SequenceStartNumber Property (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : SequenceStartNumber Property (IWeldmentCutListFeature)

Gets or sets the starting sequence number for this weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

```
Property SequenceStartNumber As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature
Dim value As System.Integer

instance.SequenceStartNumber = value

value = instance.SequenceStartNumber
```

C#

```
System.int SequenceStartNumber {get; set;}
```

C++/CLI

```
property System.int SequenceStartNumber {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Starting sequence number for this weldment cut list table

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::SequenceStartNumber](#).

Example

See the [IWeldmentCutListFeature](#) examples.

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)
[IWeldmentCutListFeature::KeepCurrentItemNumbers Property](#)
[IWeldmentCutListFeature::KeepMissingItems Property](#)
[IWeldmentCutListFeature::StrikeoutMissingItems Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StrikeoutMissingItems Property (IWeldmentCutListFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentCutListFeature Interface](#) : StrikeoutMissingItems Property (IWeldmentCutListFeature)

Gets or sets whether to strike out missing items in the weldment cut list table.

.NET Syntax

Visual Basic (Declaration)

```
Property StrikeoutMissingItems As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldmentCutListFeature  
Dim value As System.Boolean
```

```
instance.StrikeoutMissingItems = value
```

```
value = instance.StrikeoutMissingItems
```

C#

```
System.bool StrikeoutMissingItems {get; set;}
```

C++/CLI

```
property System.bool StrikeoutMissingItems {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to strike out missing items in the weldment cut list table, false to not

Visual Basic for Applications (VBA) Syntax

See [WeldmentCutListFeature::StrikeoutMissingItems](#).

Example

See the [IWeldmentCutListFeature](#) examples.

Remarks

Use [IWeldmentCutListFeature::KeepMissingItems](#) to determine if missing cut list items are to be shown in the weldment cut list table.

See Also

[IWeldmentCutListFeature Interface](#)
[IWeldmentCutListFeature Members](#)
[IWeldmentCutListFeature::KeepCurrentItemNumbers Property](#)
[IWeldmentCutListFeature::SequenceStartNumber Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

IWeldmentTrimExtendFeatureData (Type)

IWeldmentTrimExtendFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentTrimExtendFeatureData Interface

Allows access to the data that defines a weldment trim extend feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWeldmentTrimExtendFeatureData
```

Visual Basic (Usage)

```
Dim instance As IWeldmentTrimExtendFeatureData
```

C#

```
public interface IWeldmentTrimExtendFeatureData
```

C++/CLI

```
public interface class IWeldmentTrimExtendFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData](#).

Example

[Get Weldment Trim Extend Corner Type \(VBA\)](#)
[Get Weldment Trim Extend Corner Type \(VB.NET\)](#)
[Get Weldment Trim Extend Corner Type \(C#\)](#)

Remarks

Only bodies created by weldment features can be trimmed and extended. Only End Trim corner types can have multiple target and boundary bodies to trim. All other corner types can have only one target and boundary body to trim. For all other corner types, first valid body specified is used if more than one body is specified.

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[WeldmentTrimExtendFeatureData](#)

See Also

[IWeldmentTrimExtendFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWeldmentTrimFeature2 Method](#)
[IFeatureManager::InsertWeldmentTrimFeature Method](#)

IWeldmentTrimExtendFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentTrimExtendFeatureData Interface

The following tables list the members exposed by [IWeldmentTrimExtendFeatureData](#).

Public Properties

Name	Description
 BodiesToBeTrimmed	Gets or sets the bodies to trim.
 CornerType	Gets or sets the corner type.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this weldment trim extend feature.
 GetBodiesToBeTrimmedCount	Gets the number of bodies to trim.
 GetTrimmingBoundary	Gets the entities used to define the trimming boundaries.
 GetTrimmingBoundaryCount	Gets the number of trimming boundaries.
 IGetBodiesToBeTrimmed	Gets the bodies to trim.
 IGetTrimmingBoundary	Gets the entities used to define the trimming boundaries.
 ISetBodiesToBeTrimmed	Sets the bodies to trim.
 ISetTrimmingBoundary	Gets the entities used to define the trimming boundaries.
 ReleaseSelectionAccess	Releases the selections that define this weldment trim extend feature.
 SetTrimmingBoundary	Sets the trimming boundaries for this weldment trim extend feature.

[Top](#)

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWeldmentTrimFeature2 Method](#)
[IFeatureManager::InsertWeldmentTrimFeature Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IWeldmentTrimExtendFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldmentTrimExtendFeatureData Interface

For a list of all members of this type, see [IWeldmentTrimExtendFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this weldment trim extend feature.
 GetBodiesToBeTrimmedCount	Gets the number of bodies to trim.
 GetTrimmingBoundary	Gets the entities used to define the trimming boundaries.
 GetTrimmingBoundaryCount	Gets the number of trimming boundaries.
 IGetBodiesToBeTrimmed	Gets the bodies to trim.
 IGetTrimmingBoundary	Gets the entities used to define the trimming boundaries.
 ISetBodiesToBeTrimmed	Sets the bodies to trim.
 ISetTrimmingBoundary	Gets the entities used to define the trimming boundaries.
 ReleaseSelectionAccess	Releases the selections that define this weldment trim extend feature.
 SetTrimmingBoundary	Sets the trimming boundaries for this weldment trim extend feature.

[Top](#)

See Also

IWeldmentTrimExtendFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : [IWeldmentTrimExtendFeatureData Interface](#)

For a list of all members of this type, see [IWeldmentTrimExtendFeatureData members](#).

Public Properties

Name	Description
 BodiesToBeTrimmed	Gets or sets the bodies to trim.
 CornerType	Gets or sets the corner type.

[Top](#)

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWeldmentTrimFeature2 Method](#)
[IFeatureManager::InsertWeldmentTrimFeature Method](#)

AccessSelections Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : [AccessSelections Method \(IWeldmentTrimExtendFeatureData\)](#)

Gains access to the selections that define this weldment trim extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal PTopDoc As ModelDoc2, _  
    ByVal PComponent As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim PTopDoc As ModelDoc2  
Dim PComponent As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(PTopDoc, PComponent)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 PTopDoc,  
    Component2 PComponent  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ PTopDoc,  
& Component2^ PComponent  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PTopDoc
Top-level document

PComponent
Component in which the feature is to be modified

Return Value

TRUE if the selections are successfully accessed, FALSE if not

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [WeldmentTrimExtendFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BodiesToBeTrimmed Property (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : BodiesToBeTrimmed Property (IWeldmentTrimExtendFeatureData)

Gets or sets the bodies to trim.

.NET Syntax

Visual Basic (Declaration)

Property BodiesToBeTrimmed As System.Object

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim value As System.Object
```

```
instance.BodiesToBeTrimmed = value
```

```
value = instance.BodiesToBeTrimmed
```

C#

```
System.object BodiesToBeTrimmed {get; set;}
```

C++/CLI

```
property System.Object^ BodiesToBeTrimmed {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Bodies](#) to trim (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData::BodiesToBeTrimmed](#).

Remarks

Only end-trim corner types (swEndConditionTrim) can have multiple bodies to trim. Use [IWeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

You must set the bodies to trim and set the [trimming boundary](#) if changing a corner type.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)
[IWeldmentTrimExtendFeatureData::GetBodiesToBeTrimmedCount Method](#)
[IWeldmentTrimExtendFeatureData::IGetBodiesToBeTrimmed Method](#)
[IWeldmentTrimExtendFeatureData::ISetBodiesToBeTrimmed Method](#)
[IWeldmentTrimExtendFeatureData::BodiesToBeTrimmed Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CornerType Property (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : CornerType Property (IWeldmentTrimExtendFeatureData)

Gets or sets the corner type.

.NET Syntax

Visual Basic (Declaration)

Property CornerType As System.Integer

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim value As System.Integer
```

```
instance.CornerType = value
```

```
value = instance.CornerType
```

C#

```
System.int CornerType {get; set;}
```

C++/CLI

```
property System.int CornerType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of corner as defined in [swSolidworksWeldmentEndCondOptions_e](#) (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData::CornerType](#).

Example

See the [IWeldmentTrimExtendFeatureData](#) examples.

Remarks

You must set the bodies to trim and the trimming boundary when changing the corner type.

Valid values for type are:

- swEndConditionButt1
- swEndConditionButt2
- swEndConditionMiter
- swEndConditionTrim

These values are not valid for type:

- swEndConditionNone
- swEndConditionUseDefault

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)
[IWeldmentTrimExtendFeatureData::BodiesToBeTrimmed Property](#)
[IWeldmentTrimExtendFeatureData::!SetBodiesToBeTrimmed Method](#)
[IWeldmentTrimExtendFeatureData::!GetBodiesToBeTrimmed Method](#)
[IWeldmentTrimExtendFeatureData::GetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::!GetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::!SetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::SetTrimmingBoundary Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBodiesToBeTrimmedCount Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : GetBodiesToBeTrimmedCount Method (IWeldmentTrimExtendFeatureData)

Gets the number of bodies to trim.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodiesToBeTrimmedCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim value As System.Integer  
  
value = instance.GetBodiesToBeTrimmedCount()
```

C#

```
System.int GetBodiesToBeTrimmedCount()
```

C++/CLI

```
System.int GetBodiesToBeTrimmedCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bodies to trim

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData::GetBodiesToBeTrimmedCount](#).

Remarks

Only end-trim corner types (swEndConditionTrim) can have multiple bodies to trim. Use [IWeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

Call this method before calling [IWeldmentTrimExtendFeatureData::IGetBodiesToBeTrimmed](#) to get the size of the array for that method.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)
[IWeldmentTrimExtendFeatureData::ISetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::BodiesToBeTrimmed Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrimmingBoundary Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : GetTrimmingBoundary Method (IWeldmentTrimExtendFeatureData)

Gets the entities used to define the trimming boundaries.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimmingBoundary( _  
    ByRef Type As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim Type As System.Integer  
Dim value As System.Object  
  
value = instance.GetTrimmingBoundary(Type)
```

C#

```
System.object GetTrimmingBoundary(  
    out System.int Type  
)
```

C++/CLI

```
System.Object^ GetTrimmingBoundary(  
& [Out] System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of trimming boundary:

- swSelSOLIDBODIES
- SwSelFACES

Return Value

Array of the entities that define the trimming boundaries

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData::GetTrimmingBoundary](#).

Remarks

Only end-trim corner types (swEndConditionTrim) can have multiple boundaries. Use [WeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[WeldmentTrimExtendFeatureData Members](#)
[WeldmentTrimExtendFeatureData::GetTrimmingBoundaryCount Method](#)
[WeldmentTrimExtendFeatureData::!GetTrimmingBoundary Method](#)
[WeldmentTrimExtendFeatureData::!SetTrimmingBoundary Method](#)
[WeldmentTrimExtendFeatureData::SetTrimmingBoundary Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrimmingBoundaryCount Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : GetTrimmingBoundaryCount Method (IWeldmentTrimExtendFeatureData)

Gets the number of trimming boundaries.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimmingBoundaryCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim value As System.Integer  
  
value = instance.GetTrimmingBoundaryCount()
```

C#

```
System.int GetTrimmingBoundaryCount()
```

C++/CLI

```
System.int GetTrimmingBoundaryCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of trimming boundaries

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData::GetTrimmingBoundaryCount](#).

Remarks

Only end-trim corner types (swEndConditionTrim) can have multiple boundaries. Use [WeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

Call this method before calling [IWeldmentTrimExtendFeaturdata::!GetTrimmingBoundary](#)

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)
[IWeldmentTrimExtendFeatureData::GetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::!SetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::SetTrimmingBoundary Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBodiesToBeTrimmed Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : IGetBodiesToBeTrimmed Method (IWeldmentTrimExtendFeatureData)

Gets the bodies to trim.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBodiesToBeTrimmed( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim Count As System.Integer  
Dim value As Body2
```

```
value = instance.IGetBodiesToBeTrimmed(Count)
```

C#

```
Body2 IGetBodiesToBeTrimmed(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetBodiesToBeTrimmed(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of bodies to trim

Return Value

- in-process, unmanaged C++: Pointer to an array of [bodies](#) to trim (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Only end-trim corner types (swEndConditionTrim) can have multiple bodies to trim. Use [IWeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

Before calling this method, call [IWeldmentTrimExtendFeatureData::GetBodiesToBeTrimmedCount](#) to get Count.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTrimmingBoundary Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : IGetTrimmingBoundary Method (IWeldmentTrimExtendFeatureData)

Gets the entities used to define the trimming boundaries.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTrimmingBoundary( _  
    ByVal Count As System.Integer, _  
    ByRef Type As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim Count As System.Integer  
Dim Type As System.Integer  
Dim value As System.Object  
  
value = instance.IGetTrimmingBoundary(Count, Type)
```

C#

```
System.object IGetTrimmingBoundary(  
    System.int Count,  
    out System.int Type  
)
```

C++/CLI

```
System.Object^ IGetTrimmingBoundary(  
    & System.int Count,  
    & [Out] System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of trimming boundaries

Type

Type of trimming boundary:

- swSelSOLIDBODIES
- SwSelFACES

Return Value

- in-process, unmanaged C++: Pointer to an array of entities that define the trimming boundaries
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Only end-trim corner types (swEndConditionTrim) can have multiple boundaries. Use [IWeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

Before calling this method, call [IWeldmentTrimExtendFeatureData::GetTrimmingBoundaryCount](#) to get Count.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)
[IWeldmentTrimExtendFeatureData::GetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::ISetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::SetTrimmingBoundary Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetBodiesToBeTrimmed Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : ISetBodiesToBeTrimmed Method (IWeldmentTrimExtendFeatureData)

Sets the bodies to trim.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetBodiesToBeTrimmed( _  
    ByVal Count As System.Integer, _  
    ByRef BodiesIn As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim Count As System.Integer  
Dim BodiesIn As Body2  
  
instance.ISetBodiesToBeTrimmed(Count, BodiesIn)
```

C#

```
void ISetBodiesToBeTrimmed(  
    System.int Count,  
    ref Body2 BodiesIn  
)
```

C++/CLI

```
void ISetBodiesToBeTrimmed(  
& System.int Count,  
& Body2^% BodiesIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of bodies to trim

BodiesIn

- in-process, unmanaged C++: Pointer to an array of [bodies](#) to trim (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Only end-trim corner types (swEndConditionTrim) can have multiple bodies to trim. Use [IWeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)
[IWeldmentTrimExtendFeatureData::GetBodiesToBeTrimmedCount Method](#)
[IWeldmentTrimExtendFeatureData::IGetBodiesToBeTrimmed Method](#)
[IWeldmentTrimExtendFeatureData::BodiesToBeTrimmed Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetTrimmingBoundary Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : ISetTrimmingBoundary Method (IWeldmentTrimExtendFeatureData)

Gets the entities used to define the trimming boundaries.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetTrimmingBoundary( _  
    ByVal Count As System.Integer, _  
    ByRef TrimBoundArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim Count As System.Integer  
Dim TrimBoundArr As System.Object  
  
instance.ISetTrimmingBoundary(Count, TrimBoundArr)
```

C#

```
void ISetTrimmingBoundary(  
    System.int Count,  
    ref System.object TrimBoundArr  
)
```

C++/CLI

```
void ISetTrimmingBoundary(  
& System.int Count,  
& System.Object^% TrimBoundArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of trimming boundaries

TrimBoundArr

- in-process, unmanaged C++: Pointer to an array of entities that define the trimming boundaries (see **Remarks**)
 - Solid bodies created by weldment members

- or -

- Planar faces on non-weldment members, or planar faces on weldment members, or both
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Return Value

Entities that define the trimming boundaries

Remarks

Faces are valid for end-trim corner types only. You can only specify multiple trimming boundaries for end-trim corner types. Use [IWeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

You must set the [bodies to trim](#) and set the trimming boundary if changing a corner type.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)
[IWeldmentTrimExtendFeatureData::SetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::!GetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::GetTrimmingBoundaryCount Method](#)
[IWeldmentTrimExtendFeatureData::GetTrimmingBoundary Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : ReleaseSelectionAccess Method (IWeldmentTrimExtendFeatureData)

Releases the selections that define this weldment trim extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData::ReleaseSelectionAccess](#).

Remarks

[IWeldmentTrimExtendFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SetTrimmingBoundary Method (IWeldmentTrimExtendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldmentTrimExtendFeatureData Interface](#) : SetTrimmingBoundary Method (IWeldmentTrimExtendFeatureData)

Sets the trimming boundaries for this weldment trim extend feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTrimmingBoundary( _  
    ByVal TrimBoundVar As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IWeldmentTrimExtendFeatureData  
Dim TrimBoundVar As System.Object  
  
instance.SetTrimmingBoundary(TrimBoundVar)
```

C#

```
void SetTrimmingBoundary(  
    System.object TrimBoundVar  
)
```

C++/CLI

```
void SetTrimmingBoundary(  
& System.Object^ TrimBoundVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrimBoundVar
Number of trimming boundaries

Return Value

Array of trimming boundaries:

- Solid bodies created by weldment members
- or -
- Planar faces on non-weldment members, or planar faces on weldment members, or both

See **Remarks**.

Visual Basic for Applications (VBA) Syntax

See [WeldmentTrimExtendFeatureData::SetTrimmingBoundary](#).

Remarks

Faces are valid for end-trim corner types only. You can only specify multiple trimming boundaries for end-trim corner types. Use [IWeldmentTrimExtendFeatureData::CornerType](#) to determine the type of corner.

You must set the [bodies to trim](#) and set the trimming boundary if changing a corner type.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWeldmentTrimExtendFeatureData Interface](#)
[IWeldmentTrimExtendFeatureData Members](#)
[IWeldmentTrimExtendFeatureData::GetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::GetTrimmingBoundary Method](#)

[IWeldmentTrimExtendFeatureData::IGetTrimmingBoundary Method](#)
[IWeldmentTrimExtendFeatureData::GetTrimmingBoundaryCount Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0