

SOLIDWORKS API (.NET VBA C#) — Reference (333/337): IWeldSymbol

SOLIDWORKS API Documentation (converted from CHM)

IWeldSymbol (Type)

IWeldSymbol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldSymbol Interface

Allows access to weld symbols.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWeldSymbol
```

Visual Basic (Usage)

```
Dim instance As IWeldSymbol
```

C#

```
public interface IWeldSymbol
```

C++/CLI

```
public interface class IWeldSymbol
```

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol](#).

Example

[Insert Weld Symbol Example \(VBA\)](#)
[Insert Weld Symbol Example \(VB.NET\)](#)
[Insert Weld Symbol Example \(C#\)](#)

Accessors

[IAnnotation::GetSpecificAnnotation](#) and [IAnnotation::IGetSpecificAnnotation](#)
[ICosmeticWeldBeadFeatureData::WeldSymbol](#)
[IModelDoc2::InsertWeldSymbol3](#) and [IModelDoc2::InsertWeldSymbol3](#)
[IView::GetFirstWeldSymbol](#) and [IView::IGetFirstWeldSymbol](#)
[IView::GetWeldSymbols](#) and [IView::IGetWeldSymbols](#)
[IWeldSymbol::GetNext](#) and [IWeldSymbol::IGetNext](#)

Access Diagram

[WeldSymbol](#)

See Also

[IWeldSymbol Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertWeldSymbol3 Method](#)
[IAnnotation Interface](#)

IWeldSymbol Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldSymbol Interface

For a list of all members of this type, see [IWeldSymbol members](#).

Public Methods

Name	Description
 GetAnnotation	Gets the annotation for this weld symbol.
 GetArcAtIndex	Gets information for the specified arc.
 GetArcCount	Gets the number of arcs in this weld symbol.
 GetArrowHeadAtIndex	Gets information on the specified arrowhead in this weld symbol.
 GetArrowHeadCount	Gets the number of arrow heads in the weld symbol.
 GetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
 GetContour	Gets the contour settings for this weld symbol.
 GetFieldWeld	Gets the field or site weld property of this weld symbol.
 GetLeaderAtIndex	Gets information about the specified leader on this symbol.
 GetLeaderCount	Gets the number of leaders on this symbol.
 GetLineAtIndex	Gets information for the specified line.
 GetLineCount	Gets the number of line segments in this weld symbol.
 GetNext	Gets the next weld symbol in the drawing view.
 GetPeripheral	Gets whether this is a peripheral weld.
 GetProcess	Gets whether the indication of welding process flag is set on this weld symbol.
 GetProcessReference	Gets whether there is a reference box around the indication of welding process text.
 GetStagger	Gets whether this weld symbol is a stagger weld.
 GetSymmetric	Gets whether this weld symbol is a symmetric weld.
 GetText	Gets individual pieces of text from the weld symbol.
 GetTextAngleAtIndex	Gets the text angle for the specified piece of text in this weld symbol.
 GetTextAtIndex	Gets the specified text from this weld symbol.
 GetTextCount	Gets the number of text items in the weld symbol.
 GetTextHeightAtIndex	Gets the text height for the specified piece of text in this weld symbol.
 GetTextInvertAtIndex	Gets whether the text has been mirrored (reflected) about the X axis; any reflection is applied after text rotation.
 GetTextPositionAtIndex	Gets the text's offset relative to the note's text point.
 GetTextRefPositionAtIndex	Gets the specified text's reference position in this weld symbol (that is, upper left, lower left, center).
 GetTriangleAtIndex	Gets the triangle at the specified index.
 GetTriangleCount	Gets the number of triangles in this weld symbol.
 HasExtraLeader	Gets whether this symbol has an extra leader.
 IGetAnnotation	Gets the annotation for this weld symbol.
 IGetArcAtIndex	Gets information for the specified arc.
 IGetArrowHeadAtIndex	Gets information on the specified arrowhead in this weld symbol.
 IGetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
 IGetLeaderAtIndex	Gets information about the specified leader on this symbol.
 IGetLineAtIndex	Gets information for the specified line.
 IGetNext	Gets the next weld symbol in the view.
 IGetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
 IGetTriangleAtIndex	Gets the triangle at the specified index.
 IsAttached	Gets whether this symbol is attached.
 SetFieldWeld	Sets the field or site weld property of this weld symbol.

 SetPeripheral	Sets the peripheral property of this weld symbol.
 SetProcess	Sets the values related to the indication of welding process for this weld symbol.
 SetStagger	Sets the stagger property of this weld symbol.
 SetSymmetric	Sets whether this weld symbol is a symmetric weld.
 SetText	Sets the text and symbols in the upper or lower portion of the weld symbol.

[Top](#)

See Also

[IWeldSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertWeldSymbol3 Method](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWeldSymbol Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWeldSymbol Interface

The following tables list the members exposed by [IWeldSymbol](#).

Public Methods

Name	Description
 GetAnnotation	Gets the annotation for this weld symbol.
 GetArcAtIndex	Gets information for the specified arc.
 GetArcCount	Gets the number of arcs in this weld symbol.
 GetArrowHeadAtIndex	Gets information on the specified arrowhead in this weld symbol.
 GetArrowHeadCount	Gets the number of arrow heads in the weld symbol.
 GetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
 GetContour	Gets the contour settings for this weld symbol.
 GetFieldWeld	Gets the field or site weld property of this weld symbol.
 GetLeaderAtIndex	Gets information about the specified leader on this symbol.
 GetLeaderCount	Gets the number of leaders on this symbol.
 GetLineAtIndex	Gets information for the specified line.
 GetLineCount	Gets the number of line segments in this weld symbol.
 GetNext	Gets the next weld symbol in the drawing view.
 GetPeripheral	Gets whether this is a peripheral weld.
 GetProcess	Gets whether the indication of welding process flag is set on this weld symbol.
 GetProcessReference	Gets whether there is a reference box around the indication of welding process text.
 GetStagger	Gets whether this weld symbol is a stagger weld.
 GetSymmetric	Gets whether this weld symbol is a symmetric weld.
 GetText	Gets individual pieces of text from the weld symbol.
 GetTextAngleAtIndex	Gets the text angle for the specified piece of text in this weld symbol.
 GetTextAtIndex	Gets the specified text from this weld symbol.
 GetTextCount	Gets the number of text items in the weld symbol.
 GetTextHeightAtIndex	Gets the text height for the specified piece of text in this weld symbol.
 GetTextInvertAtIndex	Gets whether the text has been mirrored (reflected) about the X axis; any reflection is applied after text rotation.
 GetTextPositionAtIndex	Gets the text's offset relative to the note's text point.

	GetTextRefPositionAtIndex	Gets the specified text's reference position in this weld symbol (that is, upper left, lower left, center).
	GetTriangleAtIndex	Gets the triangle at the specified index.
	GetTriangleCount	Gets the number of triangles in this weld symbol.
	HasExtraLeader	Gets whether this symbol has an extra leader.
	IGetAnnotation	Gets the annotation for this weld symbol.
	IGetArcAtIndex	Gets information for the specified arc.
	IGetArrowHeadAtIndex	Gets information on the specified arrowhead in this weld symbol.
	IGetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
	IGetLeaderAtIndex	Gets information about the specified leader on this symbol.
	IGetLineAtIndex	Gets information for the specified line.
	IGetNext	Gets the next weld symbol in the view.
	IGetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
	IGetTriangleAtIndex	Gets the triangle at the specified index.
	IsAttached	Gets whether this symbol is attached.
	SetFieldWeld	Sets the field or site weld property of this weld symbol.
	SetPeripheral	Sets the peripheral property of this weld symbol.
	SetProcess	Sets the values related to the indication of welding process for this weld symbol.
	SetStagger	Sets the stagger property of this weld symbol.
	SetSymmetric	Sets whether this weld symbol is a symmetric weld.
	SetText	Sets the text and symbols in the upper or lower portion of the weld symbol.

[Top](#)

 See Also

[IWeldSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertWeldSymbol3 Method](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (IWeldSymbol)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetAnnotation Method (IWeldSymbol)

Gets the annotation for this weld symbol.

 .NET Syntax

Visual Basic (Declaration)

Function GetAnnotation() As System.Object

Visual Basic (Usage)

```
Dim instance As IWeldSymbol  
Dim value As System.Object  
  
value = instance.GetAnnotation()
```

C#

System.object GetAnnotation()

C++/CLI

System.Object^ GetAnnotation();



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)

Remarks

This method obtains the owning [IAnnotation](#) object, which is a higher-level object that contains methods that are general to all types of annotations.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetArcAtIndex Method (IWeldSymbol)

Gets information for the specified arc.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetArcAtIndex(Index)
```

C#

```
System.object GetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArcAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arc where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetArcAtIndex](#).

Remarks

The return value is the following array of doubles :

[*lineType*, *startPt*[3], *endPt*[3], *centerPt*[3], *rotationDir*]

where:

<i>lineType</i>	= line type as defined in swLineTypes_e .
<i>startPt</i> [3]	= XYZ arc start point.
<i>endPt</i> [3]	= XYZ arc end point.
<i>centerPt</i> [3]	= XYZ arc center point.
<i>rotationDir</i>	= value is a BOOLEAN returned as a double and represents the rotation direction, where CCW = TRUE and CW = FALSE.

See Also

- [IWeldSymbol Interface](#)
- [IWeldSymbol Members](#)
- [IWeldSymbol::GetArcCount Method](#)
- [IWeldSymbol::GetArcAtIndex Method](#)

GetArcCount Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetArcCount Method (IWeldSymbol)

Gets the number of arcs in this weld symbol.

.NET Syntax

Visual Basic (Declaration)

Function GetArcCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim value As System.Integer

value = instance.GetArcCount()
```

C#

System.int GetArcCount()

C++/CLI

System.int GetArcCount();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arcs

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetArcCount](#).

Example

See the [IWeldSymbol](#) examples.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[WeldSymbol::GetArcAtIndex Method](#)
[WeldSymbol::!GetArcAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetArrowHeadAtIndex Method (IWeldSymbol)

Gets information on the specified arrowhead in this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetArrowHeadAtIndex(Index)
```

C#

```
System.object GetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArrowHeadAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arrow head where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetArrowHeadAtIndex](#).

Remarks

The return value is the following array of doubles :

[[arrowHeadPt\[3\]](#), [arrowHeadDir\[3\]](#), [arrowHeadWidth](#), [arrowHeadHeight](#), [arrowHeadStyle](#)]

where:

arrowHeadPt[3]	= XYZ arrow head tip location.
arrowHeadDir[3]	= XYZ arrow head direction.
arrowHeadWidth	= arrow head width where the width is measured along the arrow head direction.
arrowHeadHeight	= arrow head height.
arrowHeadStyle	= arrow head style (that is, open, closed, and so on) as defined in swArrowStyle e .

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetArrowHeadCount Method](#)
[IWeldSymbol::GetArrowHeadInfo Method](#)
[IWeldSymbol::IGetArrowHeadAtIndex Method](#)
[IWeldSymbol::IGetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadCount Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetArrowHeadCount Method (IWeldSymbol)

Gets the number of arrow heads in the weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Integer  
  
value = instance.GetArrowHeadCount()
```

C#

```
System.int GetArrowHeadCount()
```

C++/CLI

```
System.int GetArrowHeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arrow heads

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetArrowHeadCount](#).

Example

See the [IWeldSymbol](#) examples.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetArrowHeadAtIndex Method](#)
[IWeldSymbol::GetArrowHeadInfo Method](#)

GetArrowHeadInfo Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetArrowHeadInfo Method (IWeldSymbol)

Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Object  
  
value = instance.GetArrowHeadInfo()
```

C#

```
System.object GetArrowHeadInfo()
```

C++/CLI

```
System.Object^ GetArrowHeadInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetArrowHeadInfo](#).

Remarks

This information returned by this method is independent of whether this weld symbol has an arrowhead.

Format of return information is the following array of doubles:

```
retval[0] = arrow length (that is, leader into arrowhead)  
retval[1] = arrowhead length  
retval[2] = arrowhead width  
retval[3] = arrowhead style as defined in swArrowStyle\_e
```

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetArrowHeadAtIndex Method](#)
[IWeldSymbol::GetArrowHeadCount Method](#)
[IWeldSymbol::IGetArrowHeadAtIndex Method](#)
[IWeldSymbol::IGetArrowHeadInfo Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

GetContour Method (IWeldSymbol)

[See Also](#)



Gets the contour settings for this weld symbol.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetContour( _  
    ByVal Top As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Top As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetContour(Top)
```

C#

```
System.int GetContour(  
    System.bool Top  
)
```

C++/CLI

```
System.int GetContour(  
& System.bool Top  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Top

If true, then get the contour setting for the portion of the symbol above the horizontal line; if false, then get the contour setting for the portion of the symbol below the horizontal line

Return Value

Contour setting as defined by [swWeldSymbolContourTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetContour](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

To set the contour settings for a weld symbol, use [IWeldSymbol::SetText](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

Availability

SOLIDWORKS 99, datecode 1999207



Gets the field or site weld property of this weld symbol.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetFieldWeld() As System.Integer
```

Visual Basic (Usage) 

```
Dim instance As IWeldSymbol
Dim value As System.Integer

value = instance.GetFieldWeld()
```

C#

```
System.int GetFieldWeld()
```

C++/CLI

```
System.int GetFieldWeld();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Value indicating whether this is a field or site weld, and, if so, whether the flag points up or down as defined in [swWeldSymbolField_e](#)

 Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetFieldWeld](#).

 Example

See the [IWeldSymbol](#) examples.

 Remarks

To set the field or site weld property of a weld symbol, use [IWeldSymbol::SetFieldWeld](#).

 See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

 Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help [Send comments on this topic.](#)

GetLeaderAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetLeaderAtIndex Method (IWeldSymbol)

Gets information about the specified leader on this symbol.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderAtIndex( _
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage) 

```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetLeaderAtIndex(Index)
```

C#

```
System.Object GetLeaderAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetLeaderAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of leader

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetLeaderAtIndex](#).

Remarks

There can be 0, 1 or 2 lines used with the leader line. If the weld symbol is not attached, then there are 0 lines; otherwise, you can have a straight leaderline (1 line) or a bent leaderline (2 lines). You must infer the number of leaderlines based on `IsAttached()` and `HasExtraLeader()`.

- `IsAttached() == false` implies no leaderline and no leaderline points (*PointCount*=0).
- `HasExtraLeader() == false` means that this is a straight leaderline and 1 line (*PointCount*=2)
- `HasExtraLeader() == true` means that this is a bent leaderline and 2 lines (*PointCount*=3)

Format of return information is the following array of doubles:

retval[0] = x-coordinate of first leader point

retval[1] = y-coordinate of first leader point

retval[2] = z-coordinate of first leader point

retval[3] = x-coordinate of second leader point

retval[4] = y-coordinate of second leader point

retval[5] = z-coordinate of second leader point

retval[6] = x-coordinate of third leader point

retval[7] = y-coordinate of third leader point

retval[8] = z-coordinate of third leader point

Use [IWeldSymbol::GetLeaderCount](#) to see how many leaders there are on the weld symbol.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetLeaderCount Method](#)
[IWeldSymbol::HasExtraLeader Method](#)
[IWeldSymbol::GetLeaderAtIndex Method](#)

GetLeaderCount Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetLeaderCount Method (IWeldSymbol)

Gets the number of leaders on this symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Integer  
  
value = instance.GetLeaderCount()
```

C#

```
System.int GetLeaderCount()
```

C++/CLI

```
System.int GetLeaderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of leaders on the symbol

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetLeaderCount](#).

Example

See the [IWeldSymbol](#) examples.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetLeaderAtIndex Method](#)
[IWeldSymbol::GetLeaderAtIndex Method](#)
[IWeldSymbol::HasExtraLeader Method](#)

GetLineAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetLineAtIndex Method (IWeldSymbol)

Gets information for the specified line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetLineAtIndex(Index)
```

C#

```
System.Object GetLineAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetLineAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the line where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetLineAtIndex](#).

Remarks

The return value is the following array of doubles :

$[\textit{lineType}, \textit{startPt}[3], \textit{endPt}[3]]$

where:

<i>lineType</i>	= line type as defined in swLineTypes_e
<i>startPt</i> [3]	= XYZ line start point
<i>endPt</i> [3]	= XYZ line end point

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetLineCount Method](#)
[IWeldSymbol::IGetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineCount Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetLineCount Method (IWeldSymbol)

Gets the number of line segments in this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Integer  
  
value = instance.GetLineCount()
```

C#

```
System.int GetLineCount()
```

C++/CLI

```
System.int GetLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of line segments

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetLineCount](#).

Example

See the [IWeldSymbol](#) examples.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetLineAtIndex Method](#)
[IWeldSymbol::GetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNext Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetNext Method (IWeldSymbol)

Gets the next weld symbol in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [weld symbol](#) in the drawing view

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetNext](#).

 See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IView::GetFirstWeldSymbol Method](#)
[IView::IGetFirstWeldSymbol Method](#)
[IWeldSymbol::IGetNext Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPeripheral Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetPeripheral Method (IWeldSymbol)

Gets whether this is a peripheral weld.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetPeripheral() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Boolean  
  
value = instance.GetPeripheral()
```

C#

```
System.bool GetPeripheral()
```

C++/CLI

```
System.bool GetPeripheral();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a peripheral weld, false if not

 Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetPeripheral](#).

 Example

See the [IWeldSymbol](#) examples.

 Remarks

To set the peripheral property of a weld symbol, use [IWeldSymbol::SetPeripheral](#).

 See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

 Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProcess Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetProcess Method (IWeldSymbol)

Gets whether the indication of welding process flag is set on this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProcess() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Boolean  
  
value = instance.GetProcess()
```

C#

```
System.bool GetProcess()
```

C++/CLI

```
System.bool GetProcess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the indication of welding process flag is set, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetProcess](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

Get:

- Text related to the indication of welding process using [IWeldSymbol::GetText](#).
- Flag that indicates whether a reference box exists around this text using [IWeldSymbol::GetProcessReference](#).

Set all of the indication of welding process values (flag, text, and reference) using [IWeldSymbol::SetProcess](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::SetText Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProcessReference Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetProcessReference Method (IWeldSymbol)

Gets whether there is a reference box around the indication of welding process text.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetProcessReference() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Boolean  
  
value = instance.GetProcessReference()
```

C#

```
System.bool GetProcessReference()
```

C++/CLI

```
System.bool GetProcessReference();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if there is a reference box around the process text, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetProcessReference](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

Get:

- Flag that tells whether or not the indication of welding process flag is set on this weld symbol using [IWeldSymbol::GetProcess](#).
- Text related to the indication of welding process using [IWeldSymbol::GetText](#).

Set all of the indication of welding process values (flag, text, and reference) using [IWeldSymbol::SetProcess](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::SetText Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetStagger Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetStagger Method (IWeldSymbol)

Gets whether this weld symbol is a stagger weld.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetStagger() As System.Boolean
```

```
Dim instance As IWeldSymbol
Dim value As System.Boolean

value = instance.GetStagger()
```

C#

```
System.bool GetStagger()
```

C++/CLI

```
System.bool GetStagger();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this is a stagger weld, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetStagger](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

To set the weld symbol to a stagger weld, use [IWeldSymbol::SetStagger](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSymmetric Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetSymmetric Method (IWeldSymbol)

Gets whether this weld symbol is a symmetric weld.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSymmetric() As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IWeldSymbol
Dim value As System.Integer

value = instance.GetSymmetric()
```

C#

```
System.int GetSymmetric()
```

C++/CLI

```
System.int GetSymmetric();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Value indicating whether this is a symmetric weld, and if not, whether the dashed line is above or below the horizontal line as defined in [swWeldSymbolSymmetric_e](#)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetSymmetric](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

To set a weld symbol to a symmetric weld, use [IWeldSymbol::SetSymmetric](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetText Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetText Method (IWeldSymbol)

Gets individual pieces of text from the weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetText( _  
    ByVal WhichText As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim WhichText As System.Integer  
Dim value As System.String
```

```
value = instance.GetText(WhichText)
```

C#

```
System.string GetText(  
    System.int WhichText  
)
```

C++/CLI

```
System.String^ GetText(  
& System.int WhichText  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichText

Text to retrieve as defined in [swWeldSymbolTextTypes_e](#)

Return Value

Text

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetText](#).

Remarks

To set the individual pieces of text for a weld symbol, use [IWeldSymbol::SetText](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetTextAngleAtIndex Method](#)
[IWeldSymbol::GetTextAtIndex Method](#)
[IWeldSymbol::GetTextCount Method](#)
[IWeldSymbol::GetTextHeightAtIndex Method](#)
[IWeldSymbol::GetTextInvertAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::GetTextRefPositionAtIndex Method](#)
[IWeldSymbol::IGetTextPositionAtIndex Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextAngleAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTextAngleAtIndex Method (IWeldSymbol)

Gets the text angle for the specified piece of text in this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAngleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextAngleAtIndex(Index)
```

C#

```
System.double GetTextAngleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextAngleAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the piece of text where the index begins at 0

Return Value

Text angle for the specified piece of text in radians; the angle is measured CCW from the X axis

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTextAngleAtIndex](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetTextAtIndex Method](#)
[IWeldSymbol::GetText Method](#)
[IWeldSymbol::GetTextCount Method](#)
[IWeldSymbol::GetTextHeightAtIndex Method](#)
[IWeldSymbol::GetTextInvertAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::GetTextRefPositionAtIndex Method](#)
[IWeldSymbol::IGetTextPositionAtIndex Method](#)
[IWeldSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTextAtIndex Method (IWeldSymbol)

Gets the specified text from this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAtIndex(  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetTextAtIndex(Index)
```

C#

```
System.string GetTextAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetTextAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the piece of text where the index begins at 0

Return Value

Text

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTextAtIndex](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[WeldSymbol::GetText Method](#)
[IWeldSymbol::GetTextAngleAtIndex Method](#)
[IWeldSymbol::GetTextCount Method](#)
[IWeldSymbol::GetTextHeightAtIndex Method](#)
[IWeldSymbol::GetTextInvertAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::GetTextRefPositionAtIndex Method](#)
[IWeldSymbol::IGetTextPositionAtIndex Method](#)
[IWeldSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextCount Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTextCount Method (IWeldSymbol)

Gets the number of text items in the weld symbol.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetTextCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Integer  
  
value = instance.GetTextCount()
```

C#

```
System.int GetTextCount()
```

C++/CLI

```
System.int GetTextCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of text items

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTextCount](#).

Example

See the [IWeldSymbol](#) examples.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[WeldSymbol::GetText Method](#)
[IWeldSymbol::GetTextAngleAtIndex Method](#)
[IWeldSymbol::GetTextAtIndex Method](#)
[IWeldSymbol::GetTextHeightAtIndex Method](#)
[IWeldSymbol::GetTextInvertAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::GetTextRefPositionAtIndex Method](#)
[IWeldSymbol::IGetTextPositionAtIndex Method](#)
[IWeldSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextHeightAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTextHeightAtIndex Method (IWeldSymbol)

Gets the text height for the specified piece of text in this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextHeightAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextHeightAtIndex(Index)
```

C#

```
System.double GetTextHeightAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextHeightAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired piece of text where the index begins at 0

Return Value

Text height for the specified piece of text in meters

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTextHeightAtIndex](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetText Method](#)
[IWeldSymbol::GetTextAngleAtIndex Method](#)
[IWeldSymbol::GetTextAtIndex Method](#)
[IWeldSymbol::GetTextCount Method](#)
[IWeldSymbol::GetTextInvertAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::GetTextRefPositionAtIndex Method](#)
[IWeldSymbol::IGetTextPositionAtIndex Method](#)
[IWeldSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextInvertAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTextInvertAtIndex Method (IWeldSymbol)

Gets whether the text has been mirrored (reflected) about the X axis; any reflection is applied after text rotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextInvertAtIndex( _
    ByVal Index As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim Index As System.Integer
Dim value As System.Integer

value = instance.GetTextInvertAtIndex(Index)
```

C#

```
System.int GetTextInvertAtIndex(
    System.int Index
)
```

C++/CLI

```
System.int GetTextInvertAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the piece of text where the index begins at 0

Return Value

Text item's invert flag

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTextInvertAtIndex](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetText Method](#)
[IWeldSymbol::GetTextAngleAtIndex Method](#)
[IWeldSymbol::GetTextAtIndex Method](#)
[IWeldSymbol::GetTextCount Method](#)
[IWeldSymbol::GetTextHeightAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::GetTextRefPositionAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextPositionAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTextPositionAtIndex Method (IWeldSymbol)

Gets the text's offset relative to the note's text point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextPositionAtIndex( _
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetTextPositionAtIndex(Index)
```

C#

```
System.Object GetTextPositionAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetTextPositionAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTextPositionAtIndex](#).

Remarks

The return value is the following array of doubles:

$[\text{textPtX}, \text{textPtY}, \text{textPtZ}]$

where these text position values are offset values from the origin of this weld symbol.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetText Method](#)
[IWeldSymbol::GetTextAngleAtIndex Method](#)
[IWeldSymbol::GetTextAtIndex Method](#)
[IWeldSymbol::GetTextCount Method](#)
[IWeldSymbol::GetTextHeightAtIndex Method](#)
[IWeldSymbol::GetTextInvertAtIndex Method](#)
[IWeldSymbol::GetTextRefPositionAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextRefPositionAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTextRefPositionAtIndex Method (IWeldSymbol)

Gets the specified text's reference position in this weld symbol (that is, upper left, lower left, center).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextRefPositionAtIndex( _
    ByVal Index As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim Index As System.Integer
Dim value As System.Integer

value = instance.GetTextRefPositionAtIndex(Index)
```

C#

```
System.int GetTextRefPositionAtIndex(
    System.int Index
)
```

C++/CLI

```
System.int GetTextRefPositionAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the piece of text where the index begins at 0

Return Value

Reference position of the specified text item as defined in [swTextPosition_e](#)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTextRefPositionAtIndex](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetText Method](#)
[IWeldSymbol::GetTextAngleAtIndex Method](#)
[IWeldSymbol::GetTextAtIndex Method](#)
[IWeldSymbol::GetTextCount Method](#)
[IWeldSymbol::GetTextHeightAtIndex Method](#)
[IWeldSymbol::GetTextInvertAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTriangleAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTriangleAtIndex Method (IWeldSymbol)

Gets the triangle at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleAtIndex( _
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IWeldSymbol
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetTriangleAtIndex(Index)
```

C#



```
System.Object GetTriangleAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetTriangleAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the triangle where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTriangleAtIndex](#).

Remarks

The return value is the following array of doubles :

$[\textit{vertexPt1}[3], \textit{vertexPt2}[3], \textit{vertexPt3}[3], \textit{isFilled}, \textit{lineType}]$

where:

<i>vertexPt1</i> [3]	= first XYZ vertex point
<i>vertexPt2</i> [3]	= second XYZ vertex point
<i>vertexPt3</i> [3]	= third XYZ vertex point
<i>isFilled</i>	= boolean returned as a double; 1.0 if the triangle is filled, 0.0 if not
<i>lineType</i>	= the line type as defined in swLineTypes_e

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetTriangleCount Method](#)
[IWeldSymbol::IGetTriangleAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTriangleCount Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : GetTriangleCount Method (IWeldSymbol)

Gets the number of triangles in this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim value As System.Integer

value = instance.GetTriangleCount()
```

C#

```
System.int GetTriangleCount()
```

C++/CLI

```
System.int GetTriangleCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of triangles

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::GetTriangleCount](#).

Example

See the [IWeldSymbol](#) examples.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetTriangleAtIndex Method](#)
[IWeldSymbol::!GetTriangleAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

HasExtraLeader Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : HasExtraLeader Method (IWeldSymbol)

Gets whether this symbol has an extra leader.

.NET Syntax

Visual Basic (Declaration)

```
Function HasExtraLeader() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Boolean  
  
value = instance.HasExtraLeader()
```

C#

```
System.bool HasExtraLeader()
```

C++/CLI

```
System.bool HasExtraLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if extra leader line exists, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::HasExtraLeader](#).

Example

See the [IWeldSymbol](#) examples.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetLeaderAtIndex Method](#)
[IWeldSymbol::GetLeaderCount Method](#)
[IWeldSymbol::IGetLeaderAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAnnotation Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IGetAnnotation Method (IWeldSymbol)

Gets the annotation for this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As Annotation  
  
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::IGetAnnotation](#).

Remarks

This method obtains the owning [IAnnotation](#) object, which is a higher-level object that contains methods that are general to all types of annotations.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArcAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IGetArcAtIndex Method (IWeldSymbol)

Gets information for the specified arc.

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetArcAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArcAtIndex(Index)
```

C#

```
System.double IGetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArcAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the arc where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

 Remarks

The return value is the following array of doubles :

[*lineType*, *startPt*[3], *endPt*[3], *centerPt*[3], *rotationDir*]

where:

<i>lineType</i>	= line type as defined in swLineTypes_e .
<i>startPt</i> [3]	= XYZ arc start point.
<i>endPt</i> [3]	= XYZ arc end point.
<i>centerPt</i> [3]	= XYZ arc center point.
<i>rotationDir</i>	= value is a boolean returned as a double and represents the rotation direction, where CCW = 1.0 and CW = 0.0.

 See Also

- [IWeldSymbol Interface](#)
- [IWeldSymbol Members](#)
- [IWeldSymbol::GetArcAtIndex Method](#)
- [IWeldSymbol::GetArcCount Method](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)

```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArrowHeadAtIndex(Index)
```

C#

```
System.double IGetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArrowHeadAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the arrow head where the index begins at

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of doubles :

[*arrowHeadPt*[3], *arrowHeadDir*[3], *arrowHeadWidth*, *arrowHeadHeight*, *arrowHeadStyle*]

where:

<i>arrowHeadPt</i> [3]	= XYZ arrow head tip location.
<i>arrowHeadDir</i> [3]	= XYZ arrow head direction.
<i>arrowHeadWidth</i>	= arrow head width where the width is measured along the arrow head direction.
<i>arrowHeadHeight</i>	= arrow head height.
<i>arrowHeadStyle</i>	= arrow head style (that is, open, closed, and so on) as defined in swArrowStyle_e .

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetArrowHeadAtIndex Method](#)
[IWeldSymbol::GetArrowHeadCount Method](#)
[IWeldSymbol::GetArrowHeadInfo Method](#)
[IWeldSymbol::IGetArrowHeadInfo Method](#)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IGetArrowHeadInfo Method (IWeldSymbol)

Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As System.Double  
  
value = instance.IGetArrowHeadInfo()
```

C#

```
System.double IGetArrowHeadInfo()
```

C++/CLI

```
System.double IGetArrowHeadInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The information returned is independent of whether this weld symbol has an arrowhead.

Format of return information is the following array of doubles:

```
retval[0] = arrow length (that is, leader into arrowhead)  
retval[1] = arrowhead length  
retval[2] = arrowhead width  
retval[3] = arrowhead style as defined in swArrowStyle\_e
```

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetArrowHeadAtIndex Method](#)
[IWeldSymbol::GetArrowHeadCount Method](#)
[IWeldSymbol::GetArrowHeadInfo Method](#)
[IWeldSymbol::GetArrowHeadAtIndex Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLeaderAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IGetLeaderAtIndex Method (IWeldSymbol)

Gets information about the specified leader on this symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLeaderAtIndex( _
    ByVal Index As System.Integer, _
    ByRef PointCount As System.Integer _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim Index As System.Integer
Dim PointCount As System.Integer
Dim value As System.Double

value = instance.IGetLeaderAtIndex(Index, PointCount)
```

C#

```
System.double IGetLeaderAtIndex(
    System.int Index,
    out System.int PointCount
)
```

C++/CLI

```
System.double IGetLeaderAtIndex(
    & System.int Index,
    & [Out] System.int PointCount
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of leader

PointCount

Number of (x,y,z) points returned in the array

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

There can be 0, 1 or 2 lines used with the leader line. If the weld symbol is not attached, then there are 0 lines; otherwise, you can have a straight leaderline (1 line) or a bent leaderline (2 lines). You must infer the number of leaderlines based on `IsAttached()` and `HasExtraLeader()`.

- `IsAttached() == false` implies no leaderline and no leaderline points (*PointCount*=0).
- `HasExtraLeader() == false` means that this is a straight leaderline and 1 line (*PointCount*=2)
- `HasExtraLeader() == true` means that this is a bent leaderline and 2 lines (*PointCount*=3)

Format of return information is the following array of doubles:

retval[0] = x-coordinate of first leader point

retval[1] = y-coordinate of first leader point

retval[2] = z-coordinate of first leader point

retval[3] = x-coordinate of second leader point

retval[4] = y-coordinate of second leader point

retval[5] = z-coordinate of second leader point

retval[6] = x-coordinate of third leader point

retval[7] = y-coordinate of third leader point

retval[8] = z-coordinate of third leader point

Use [IWeldSymbol::GetLeaderCount](#) to see how many leaders there are on the weld symbol.

 See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetLeaderAtIndex Method](#)
[IWeldSymbol::HasExtraLeader Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLineAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IGetLineAtIndex Method (IWeldSymbol)

Gets information for the specified line.

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetLineAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetLineAtIndex(Index)
```

C#

```
System.double IGetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetLineAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the line where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

 Remarks

The return value is the following array of doubles :

$[\textit{lineType}, \textit{startPt}[3], \textit{endPt}[3]]$

where:

<i>lineType</i>	= line type as defined in swLineTypes_e
<i>startPt</i> [3]	= XYZ line start point
<i>endPt</i> [3]	= XYZ line end point

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetLineAtIndex Method](#)
[IWeldSymbol::GetLineCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IGetNext Method (IWeldSymbol)

Gets the next weld symbol in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As WeldSymbol
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim value As WeldSymbol  
  
value = instance.IGetNext()
```

C#

```
WeldSymbol IGetNext()
```

C++/CLI

```
WeldSymbol^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [weld symbol](#) in the drawing view

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::IGetNext](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetNext Method](#)
[IView::GetFirstWeldSymbol Method](#)
[IView::IGetFirstWeldSymbol Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTextPositionAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IGetTextPositionAtIndex Method (IWeldSymbol)

Gets the text item's offset relative to note's text point.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim Index As System.Integer
Dim value As System.Double

value = instance.IGetTextPositionAtIndex(Index)
```

C#

```
System.double IGetTextPositionAtIndex(
    System.int Index
)
```

C++/CLI

```
System.double IGetTextPositionAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the piece of text where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of doubles:

$[\text{textPtX}, \text{textPtY}, \text{textPtZ}]$

where these text position values are offset values from the origin of this weld symbol.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetText Method](#)
[IWeldSymbol::GetTextAngleAtIndex Method](#)
[IWeldSymbol::GetTextAtIndex Method](#)
[IWeldSymbol::GetTextCount Method](#)
[IWeldSymbol::GetTextHeightAtIndex Method](#)
[IWeldSymbol::GetTextInvertAtIndex Method](#)
[IWeldSymbol::GetTextPositionAtIndex Method](#)
[IWeldSymbol::GetTextRefPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTriangleAtIndex Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IGetTriangleAtIndex Method (IWeldSymbol)

Gets the triangle at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTriangleAtIndex( _
    ByVal Index As System.Integer _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol
Dim Index As System.Integer
Dim value As System.Double
```

```
value = instance.IGetTriangleAtIndex(Index)
```

C#

```
System.double IGetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the triangle where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of doubles :

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	= first XYZ vertex point
<i>vertexPt2</i> [3]	= second XYZ vertex point
<i>vertexPt3</i> [3]	= third XYZ vertex point
<i>isFilled</i>	= Boolean returned as a double; 1.0 if the triangle is filled, 0.0 if not
<i>lineType</i>	= line type as defined in swLineTypes_e

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::GetTriangleAtIndex Method](#)
[IWeldSymbol::GetTriangleCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsAttached Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : IsAttached Method (IWeldSymbol)

Gets whether this symbol is attached.

.NET Syntax

Visual Basic (Declaration)

```
Function IsAttached() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IWeldSymbol  
Dim value As System.Boolean  
  
value = instance.IsAttached()
```



C#

```
System.bool IsAttached()
```

C++/CLI

```
System.bool IsAttached();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the weld symbol is attached with a leaderline, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::IsAttached](#).

Example

See the [IWeldSymbol](#) examples.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFieldWeld Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : SetFieldWeld Method (IWeldSymbol)

Sets the field or site weld property of this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFieldWeld( _  
    ByVal FieldWeld As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim FieldWeld As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetFieldWeld(FieldWeld)
```

C#

```
System.bool SetFieldWeld(  
    System.int FieldWeld  
)
```

C++/CLI

```
System.bool SetFieldWeld(  
    & System.int FieldWeld  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldWeld

Value indicating whether this is to be a field or site weld, and, if so, whether the flag points up or down as defined in [swWeldSymbolField_e](#)

Return Value

True if the field or site weld setting is set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [IWeldSymbol::SetFieldWeld](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

To retrieve the field or site weld property of a weld symbol, use [IWeldSymbol::GetFieldWeld](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPeripheral Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : SetPeripheral Method (IWeldSymbol)

Sets the peripheral property of this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPeripheral( _  
    ByVal Peripheral As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Peripheral As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetPeripheral(Peripheral)
```

C#

```
System.bool SetPeripheral(  
    System.bool Peripheral  
)
```

C++/CLI

```
System.bool SetPeripheral(  
& System.bool Peripheral  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Peripheral

True if a peripheral weld, false if not

Return Value

True if the peripheral weld setting is set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [IWeldSymbol::SetPeripheral](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

To retrieve the peripheral property of a weld symbol, use [IWeldSymbol::GetPeripheral](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetProcess Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : SetProcess Method (IWeldSymbol)

Sets the values related to the indication of welding process for this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetProcess( _  
    ByVal Process As System.Boolean, _  
    ByVal Text As System.String, _  
    ByVal Reference As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Process As System.Boolean  
Dim Text As System.String  
Dim Reference As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetProcess(Process, Text, Reference)
```

C#

```
System.bool SetProcess(  
    System.bool Process,  
    System.string Text,  
    System.bool Reference  
)
```

C++/CLI

```
System.bool SetProcess(  
& System.bool Process,  
& System.String^ Text,  
& System.bool Reference  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Process

True to set the indication of welding process flag, false to not

Text

Text related to the indication of welding process

Reference

True to place a reference box around the process text, false to not

Return Value

True if the indication of welding process is set, false if not

Visual Basic for Applications (VBA) Syntax

See [IWeldSymbol::SetProcess](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

Get:

- Flag that indicates whether the indication of welding process flag is set on this weld symbol using [IWeldSymbol::GetProcess](#).
- Text related to the indication of welding process using [IWeldSymbol::GetText](#).
- Flag that indicates whether a reference box exists around this text using [IWeldSymbol::GetProcessReference](#).

The text and reference box are visible if Process is true.

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)
[IWeldSymbol::SetText Method](#)

Availability

SetStagger Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : SetStagger Method (IWeldSymbol)

Sets the stagger property of this weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetStagger( _  
    ByVal Stagger As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Stagger As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.SetStagger(Stagger)
```

C#

```
System.bool SetStagger(  
    System.bool Stagger  
)
```

C++/CLI

```
System.bool SetStagger(  
& System.bool Stagger  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Stagger

True if this is a stagger weld, false if not

Return Value

True if the stagger weld setting is set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::SetStagger](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

To retrieve the stagger property of a weld symbol, use [IWeldSymbol::GetStagger](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSymmetric Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : SetSymmetric Method (IWeldSymbol)

Sets whether this weld symbol is a symmetric weld.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSymmetric( _  
    ByVal Symmetric As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IWeldSymbol  
Dim Symmetric As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetSymmetric(Symmetric)
```

C#

 Copy Code

```
System.bool SetSymmetric(  
    System.int Symmetric  
)
```

C++/CLI

```
System.bool SetSymmetric(  
& System.int Symmetric  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Symmetric

Value indicating whether this should be a symmetric weld, and if not, whether the dashed line is above or below the horizontal line as defined in [swWeldSymbolSymmetric_e](#)

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::SetSymmetric](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

To get whether a weld symbol is a symmetric weld, use [IWeldSymbol::GetSymmetric](#).

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetText Method (IWeldSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWeldSymbol Interface](#) : SetText Method (IWeldSymbol)

Sets the text and symbols in the upper or lower portion of the weld symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetText( _  
    ByVal Top As System.Boolean, _  
    ByVal Left As System.String, _  
    ByVal Symbol As System.String, _  
    ByVal Right As System.String, _  
    ByVal Stagger As System.String, _  
    ByVal Contour As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWeldSymbol  
Dim Top As System.Boolean  
Dim Left As System.String  
Dim Symbol As System.String
```

```
Dim Right As System.String
Dim Stagger As System.String
Dim Contour As System.Integer
Dim value As System.Boolean
```

```
value = instance.SetText(Top, Left, Symbol, Right, Stagger, Contour)
```

C#

```
System.bool SetText(
    System.bool Top,
    System.string Left,
    System.string Symbol,
    System.string Right,
    System.string Stagger,
    System.int Contour
)
```

C++/CLI

```
System.bool SetText(
    & System.bool Top,
    & System.String^ Left,
    & System.String^ Symbol,
    & System.String^ Right,
    & System.String^ Stagger,
    & System.int Contour
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Top

True to set the text in the portion of the symbol above the horizontal line, false to set the text in the portion of the symbol below the horizontal line

Left

Text to the left of the weld symbol

Symbol

Text representing the weld symbol (see **Remarks**)

Right

Text to the right of the weld symbol

Stagger

Text to the right of the stagger symbol (see **Remarks**)

Contour

Contour setting as defined in [swWeldSymbolContourTypes_e](#) (see **Remarks**)

Return Value

True if the text and symbols are set, false if not

Visual Basic for Applications (VBA) Syntax

See [WeldSymbol::SetText](#).

Example

See the [IWeldSymbol](#) examples.

Remarks

To get the individual pieces of text for a weld symbol, use [IWeldSymbol::GetText](#). To get the contour setting for a weld symbol, use [IWeldSymbol::GetContour](#).

The stagger text that is specified is only visible if this option is enabled. See [IWeldSymbol::GetStagger](#) to see the current setting and [IWeldSymbol::SetStagger](#) to enable or disable that option.

A list of weld symbol names can be found in the text file [gtol.sym](#), typically installed at **C:\ProgramData\SolidWorks\SolidWorks 20nn\lang\english**. Specify Symbol with one of the currently supported ISO weld symbols:

- BUTT
- BUSQ
- BUSV

- BUSB
- BUSVBR
- BUSBR
- BUSU
- BUSJ
- BACK
- FILL
- PLUG
- SPOT
- SEAM
- SEAMC
- JSPT
- JSM

See Also

[IWeldSymbol Interface](#)
[IWeldSymbol Members](#)

Availability

SOLIDWORKS 99, datecode 1999207