

SOLIDWORKS API (.NET VBA C#) — Reference

(334/337): IWidthMateFeatureData- IWizardHoleFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IWidthMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IWidthMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWidthMateFeatureData Interface

Allows access to width mate feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWidthMateFeatureData
```

Visual Basic (Usage)



```
Dim instance As IWidthMateFeatureData
```

C#

```
public interface IWidthMateFeatureData
```

C++/CLI

```
public interface class IWidthMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [WidthMateFeatureData](#).

Example

[Create and Edit Width Mate \(VBA\)](#)
[Create and Edit Width Mate \(C#\)](#)

Remarks

A width mate constrains a tab between two planar faces.

[IMateFeatureData](#) is the parent of this advanced mate interface.

To create a width mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [IWidthMateFeatureData::TabSelection](#) or use [IModelDocExtension::SelectByID2](#) to pre-select the tab using Mark = 16.
3. Specify [IWidthMateFeatureData::WidthSelection](#) or use [IModelDocExtension::SelectByID2](#) to pre-select the width using Mark = 1.
4. Specify [IWidthMateFeatureData::ConstraintType](#).
5. Specify other properties of the WidthMateFeatureData object as required.

To edit a width mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a WidthMateFeatureData object.
3. Modify the WidthMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete a width mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[WidthMateFeatureData](#)

See Also

[IWidthMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IWidthMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWidthMateFeatureData Interface

The following tables list the members exposed by [IWidthMateFeatureData](#).

Public Properties

Name	Description
ConstraintType	Gets or sets the type of constraint for this width mate.
DistanceFromEnd	Gets or sets the distance from the end of this width mate.
FlipDimension	Gets or sets whether to move entities to opposite sides of the dimension of this width mate.
PercentDistanceFromEnd	Gets or sets the percentage of distance from the end of this width mate.
TabSelection	Gets or sets the tab references for this width mate.
WidthSelection	Gets or sets the width references for this width mate.

[Top](#)

See Also

[IWidthMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWidthMateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWidthMateFeatureData Interface

For a list of all members of this type, see [IWidthMateFeatureData members](#).

Public Properties

Name	Description
ConstraintType	Gets or sets the type of constraint for this width mate.
DistanceFromEnd	Gets or sets the distance from the end of this width mate.
FlipDimension	Gets or sets whether to move entities to opposite sides of the dimension of this width mate.
PercentDistanceFromEnd	Gets or sets the percentage of distance from the end of this width mate.
TabSelection	Gets or sets the tab references for this width mate.
WidthSelection	Gets or sets the width references for this width mate.

[Top](#)

See Also

[IWidthMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConstraintType Property (IWidthMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWidthMateFeatureData Interface](#) : ConstraintType Property (IWidthMateFeatureData)

Gets or sets the type of constraint for this width mate.

.NET Syntax

Visual Basic (Declaration)

Property ConstraintType As System.Integer

Visual Basic (Usage)



```
Dim instance As IWidthMateFeatureData
Dim value As System.Integer

instance.ConstraintType = value
value = instance.ConstraintType
```

C#

```
System.int ConstraintType {get; set;}
```

C++/CLI

```
property System.int ConstraintType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Constraint type as defined in [swMateWidthOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [WidthMateFeatureData::ConstraintType](#).

See Also

[IWidthMateFeatureData Interface](#)
[IWidthMateFeatureData Members](#)
[IWidthMateFeatureData::DistanceFromEnd Property \(\)](#)
[IWidthMateFeatureData::FlipDimension Property \(\)](#)
[IWidthMateFeatureData::PercentDistanceFromEnd Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DistanceFromEnd Property (IWidthMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWidthMateFeatureData Interface](#) : DistanceFromEnd Property (IWidthMateFeatureData)

Gets or sets the distance from the end of this width mate.

.NET Syntax

Visual Basic (Declaration)

```
Property DistanceFromEnd As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWidthMateFeatureData
Dim value As System.Double

instance.DistanceFromEnd = value
value = instance.DistanceFromEnd
```

C#

```
System.double DistanceFromEnd {get; set;}
```

C++/CLI

```
property System.double DistanceFromEnd {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance from the end

Visual Basic for Applications (VBA) Syntax

See [WidthMateFeatureData::DistanceFromEnd](#).

Remarks

This property is valid only if [WidthMateFeatureData::ConstraintType](#) is set to [swMateWidthOptions_e.swMateWidth_Dimension](#).

See Also

[IWidthMateFeatureData Interface](#)
[WidthMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipDimension Property (IWidthMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWidthMateFeatureData Interface](#) : FlipDimension Property (IWidthMateFeatureData)

Gets or sets whether to move entities to opposite sides of the dimension of this width mate.

.NET Syntax

Visual Basic (Declaration)

```
Property FlipDimension As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWidthMateFeatureData
Dim value As System.Boolean
```

```
instance.FlipDimension = value
```

```
value = instance.FlipDimension
```

C#

```
System.bool FlipDimension {get; set;}
```

C++/CLI

```
property System.bool FlipDimension {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the dimension, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WidthMateFeatureData::FlipDimension](#).

Remarks

This property is valid only if [IWidthMateFeatureData::ConstraintType](#) is set to [swMateWidthOptions_e.swMateWidth_Dimension](#) or [swMateWidth_Percent](#).

See Also

[IWidthMateFeatureData Interface](#)
[IWidthMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PercentDistanceFromEnd Property (IWidthMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWidthMateFeatureData Interface](#) : PercentDistanceFromEnd Property (IWidthMateFeatureData)

Gets or sets the percentage of distance from the end of this width mate.

.NET Syntax

Visual Basic (Declaration)

```
Property PercentDistanceFromEnd As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWidthMateFeatureData  
Dim value As System.Double  
  
instance.PercentDistanceFromEnd = value  
  
value = instance.PercentDistanceFromEnd
```

C#

```
System.double PercentDistanceFromEnd {get; set;}
```

C++/CLI

```
property System.double PercentDistanceFromEnd {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Percentage of distance from the end

Visual Basic for Applications (VBA) Syntax

See [WidthMateFeatureData::PercentDistanceFromEnd](#).

Remarks

This property is valid only if [IWidthMateFeatureData::ConstraintType](#) is set to [swMateWidthOptions_e.swMateWidth_Percent](#).

See Also

[IWidthMateFeatureData Interface](#)
[IWidthMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TabSelection Property (IWidthMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWidthMateFeatureData Interface](#) : TabSelection Property (IWidthMateFeatureData)

Gets or sets the tab references for this width mate.

.NET Syntax

Visual Basic (Declaration)

```
Property TabSelection As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWidthMateFeatureData  
Dim value As System.Object
```

```
instance.TabSelection = value
```

```
value = instance.TabSelection
```

C#

```
System.object TabSelection {get; set;}
```

C++/CLI

```
property System.Object^ TabSelection {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of tab entities (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WidthMateFeatureData::TabSelection](#).

Remarks

The tab entities can include:

- Two parallel planar [faces](#)
- Two non-parallel planar faces
- One cylindrical face or [axis](#)

See Also

[IWidthMateFeatureData Interface](#)
[IWidthMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

WidthSelection Property (IWidthMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWidthMateFeatureData Interface](#) : WidthSelection Property (IWidthMateFeatureData)

Gets or sets the width references for this width mate.

.NET Syntax

Visual Basic (Declaration)

```
Property WidthSelection As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWidthMateFeatureData  
Dim value As System.Object  
  
instance.WidthSelection = value  
  
value = instance.WidthSelection
```

C#

```
System.Object WidthSelection {get; set;}
```

C++/CLI

```
property System.Object^ WidthSelection {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of planar [faces](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WidthMateFeatureData.WidthSelection](#).

Remarks

The planar faces can include:

- Two parallel planar faces
- Two non-parallel planar faces

See Also

[IWidthMateFeatureData Interface](#)
[IWidthMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IWizardHoleFeatureData (Type)

IWizardHoleFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWizardHoleFeatureData Interface

Obsolete. Superseded by [IWizardHoleFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWizardHoleFeatureData
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
```

C#

```
public interface IWizardHoleFeatureData
```

C++/CLI

```
public interface class IWizardHoleFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData](#).

See Also

[IWizardHoleFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IWizardHoleFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWizardHoleFeatureData Interface

For a list of all members of this type, see [IWizardHoleFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Obsolete. Superseded by IWizardHoleFeatureData2::AccessSelections .
IAccessSelections	Obsolete. Superseded by IWizardHoleFeatureData2::IAccessSelections .
ReleaseSelectionAccess	Obsolete. Superseded by IWizardHoleFeatureData2::ReleaseSelectionAccess .

[Top](#)

See Also

[IWizardHoleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IWizardHoleFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWizardHoleFeatureData Interface

The following tables list the members exposed by [IWizardHoleFeatureData](#).

Public Properties

Name	Description
 CounterBoreDepth	Obsolete. Superseded by IWizardHoleFeatureData2::CounterBoreDepth .
 CounterBoreDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::CounterBoreDiameter .
 CounterDrillAngle	Obsolete. Superseded by IWizardHoleFeatureData2::CounterDrillAngle .
 CounterDrillDepth	Obsolete. Superseded by IWizardHoleFeatureData2::CounterDrillDepth .
 CounterDrillDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::CounterDrillDiameter .
 CounterSinkAngle	Obsolete. Superseded by IWizardHoleFeatureData2::CounterSinkAngle .
 CounterSinkDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::CounterSinkDiameter .
 Depth	Obsolete. Superseded by IWizardHoleFeatureData2::Depth .
 Diameter	Obsolete. Superseded by IWizardHoleFeatureData2::Diameter .
 DrillAngle	Obsolete. Superseded by IWizardHoleFeatureData2::DrillAngle .
 EndCondition	Obsolete. Superseded by IWizardHoleFeatureData2::EndCondition .
 Face	Obsolete. Superseded by IWizardHoleFeatureData2::Face .
 FarCounterSinkAngle	Obsolete. Superseded by IWizardHoleFeatureData2::FarCounterSinkAngle .
 FarCounterSinkDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::FarCounterSinkDiameter .
 FastenerSize	Obsolete. Superseded by IWizardHoleFeatureData2::FastenerSize . NOTE: This property is a get-only property. Set is not implemented.
 FastenerType	Obsolete. Superseded by IWizardHoleFeatureData2::FastenerType2 . NOTE: This property is a get-only property. Set is not implemented.
 HeadClearance	Obsolete. Superseded by IWizardHoleFeatureData2::HeadClearance .
 HoleDepth	Obsolete. Superseded by IWizardHoleFeatureData2::HoleDepth .
 HoleDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::HoleDiameter .
 IFace	Obsolete. Superseded by IWizardHoleFeatureData2::IFace .
 IVertex	Obsolete. Superseded by IWizardHoleFeatureData2::IVertex .
 MajorDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::MajorDiameter .
 MidCounterSinkAngle	Obsolete. Superseded by IWizardHoleFeatureData2::MidCounterSinkAngle .
 MidCounterSinkDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::MidCounterSinkDiameter .
 MinorDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::MinorDiameter .
 NearCounterSinkAngle	Obsolete. Superseded by IWizardHoleFeatureData2::NearCounterSinkAngle .
 NearCounterSinkDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::NearCounterSinkDiameter .
 Standard	Obsolete. Superseded by IWizardHoleFeatureData2::Standard2 . NOTE: This property is a get-only property. Set is not implemented.
 TapDrillDepth	Obsolete. Superseded by IWizardHoleFeatureData2::TapDrillDepth .
 TapDrillDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::TapDrillDiameter .
 ThreadAngle	Obsolete. Superseded by IWizardHoleFeatureData2::ThreadAngle .
 ThreadDepth	Obsolete. Superseded by IWizardHoleFeatureData2::ThreadDepth .
 ThreadDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::ThreadDiameter .
 ThruHoleDepth	Obsolete. Superseded by IWizardHoleFeatureData2::ThruHoleDepth .
 ThruHoleDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::ThruHoleDiameter .
 ThruTapDrillDepth	Obsolete. Superseded by IWizardHoleFeatureData2::ThruTapDrillDepth .

 ThruTapDrillDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::ThruTapDrillDiameter .
 Type	Obsolete. Superseded by IWizardHoleFeatureData2::Type .
 Vertex	Obsolete. Superseded by IWizardHoleFeatureData2::Vertex .

[Top](#)

Public Methods

Name	Description
 AccessSelections	Obsolete. Superseded by IWizardHoleFeatureData2::AccessSelections .
 IAccessSelections	Obsolete. Superseded by IWizardHoleFeatureData2::IAccessSelections .
 ReleaseSelectionAccess	Obsolete. Superseded by IWizardHoleFeatureData2::ReleaseSelectionAccess .

[Top](#)

See Also

[IWizardHoleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IWizardHoleFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IWizardHoleFeatureData Interface

For a list of all members of this type, see [IWizardHoleFeatureData members](#).

Public Properties

Name	Description
 CounterBoreDepth	Obsolete. Superseded by IWizardHoleFeatureData2::CounterBoreDepth .
 CounterBoreDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::CounterBoreDiameter .
 CounterDrillAngle	Obsolete. Superseded by IWizardHoleFeatureData2::CounterDrillAngle .
 CounterDrillDepth	Obsolete. Superseded by IWizardHoleFeatureData2::CounterDrillDepth .
 CounterDrillDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::CounterDrillDiameter .
 CounterSinkAngle	Obsolete. Superseded by IWizardHoleFeatureData2::CounterSinkAngle .
 CounterSinkDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::CounterSinkDiameter .
 Depth	Obsolete. Superseded by IWizardHoleFeatureData2::Depth .
 Diameter	Obsolete. Superseded by IWizardHoleFeatureData2::Diameter .
 DrillAngle	Obsolete. Superseded by IWizardHoleFeatureData2::DrillAngle .
 EndCondition	Obsolete. Superseded by IWizardHoleFeatureData2::EndCondition .
 Face	Obsolete. Superseded by IWizardHoleFeatureData2::Face .
 FarCounterSinkAngle	Obsolete. Superseded by IWizardHoleFeatureData2::FarCounterSinkAngle .
 FarCounterSinkDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::FarCounterSinkDiameter .
 FastenerSize	Obsolete. Superseded by IWizardHoleFeatureData2::FastenerSize . NOTE: This property is a get-only property. Set is not implemented.
 FastenerType	Obsolete. Superseded by IWizardHoleFeatureData2::FastenerType2 . NOTE: This property is a get-only property. Set is not implemented.
 HeadClearance	Obsolete. Superseded by IWizardHoleFeatureData2::HeadClearance .
 HoleDepth	Obsolete. Superseded by IWizardHoleFeatureData2::HoleDepth .
 HoleDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::HoleDiameter .
IFace	Obsolete. Superseded by IWizardHoleFeatureData2::IFace .

		
	IVertex	Obsolete. Superseded by IWizardHoleFeatureData2::IVertex .
	MajorDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::MajorDiameter .
	MidCounterSinkAngle	Obsolete. Superseded by IWizardHoleFeatureData2::MidCounterSinkAngle .
	MidCounterSinkDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::MidCounterSinkDiameter .
	MinorDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::MinorDiameter .
	NearCounterSinkAngle	Obsolete. Superseded by IWizardHoleFeatureData2::NearCounterSinkAngle .
	NearCounterSinkDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::NearCounterSinkDiameter .
	Standard	Obsolete. Superseded by IWizardHoleFeatureData2::Standard2 . NOTE: This property is a get-only property. Set is not implemented.
	TapDrillDepth	Obsolete. Superseded by IWizardHoleFeatureData2::TapDrillDepth .
	TapDrillDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::TapDrillDiameter .
	ThreadAngle	Obsolete. Superseded by IWizardHoleFeatureData2::ThreadAngle .
	ThreadDepth	Obsolete. Superseded by IWizardHoleFeatureData2::ThreadDepth .
	ThreadDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::ThreadDiameter .
	ThruHoleDepth	Obsolete. Superseded by IWizardHoleFeatureData2::ThruHoleDepth .
	ThruHoleDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::ThruHoleDiameter .
	ThruTapDrillDepth	Obsolete. Superseded by IWizardHoleFeatureData2::ThruTapDrillDepth .
	ThruTapDrillDiameter	Obsolete. Superseded by IWizardHoleFeatureData2::ThruTapDrillDiameter .
	Type	Obsolete. Superseded by IWizardHoleFeatureData2::Type .
	Vertex	Obsolete. Superseded by IWizardHoleFeatureData2::Vertex .

[Top](#)

See Also

[IWizardHoleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : AccessSelections Method (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::AccessSelections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::AccessSelections](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CounterBoreDepth Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : CounterBoreDepth Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::CounterBoreDepth](#).

.NET Syntax

Visual Basic (Declaration)

```
Property CounterBoreDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.CounterBoreDepth = value
```

```
value = instance.CounterBoreDepth
```

C#

```
System.double CounterBoreDepth {get; set;}
```

C++/CLI

```
property System.double CounterBoreDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::CounterBoreDepth](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CounterBoreDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : CounterBoreDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::CounterBoreDiameter](#).

.NET Syntax

Visual Basic (Declaration)

Property CounterBoreDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double  
  
instance.CounterBoreDiameter = value  
  
value = instance.CounterBoreDiameter
```

C#

```
System.double CounterBoreDiameter {get; set;}
```

C++/CLI

```
property System.double CounterBoreDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::CounterBoreDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CounterDrillAngle Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : CounterDrillAngle Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::CounterDrillAngle](#).

.NET Syntax

Visual Basic (Declaration)

Property CounterDrillAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.CounterDrillAngle = value  
value = instance.CounterDrillAngle
```

C#

```
System.double CounterDrillAngle {get; set;}
```

C++/CLI

```
property System.double CounterDrillAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::CounterDrillAngle](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CounterDrillDepth Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : CounterDrillDepth Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::CounterDrillDepth](#).

.NET Syntax

Visual Basic (Declaration)

```
Property CounterDrillDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double  
  
instance.CounterDrillDepth = value  
value = instance.CounterDrillDepth
```

C#

```
System.double CounterDrillDepth {get; set;}
```

C++/CLI

```
property System.double CounterDrillDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::CounterDrillDepth](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

CounterDrillDiameter Property (IWizardHoleFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : CounterDrillDiameter Property (IWizardHoleFeatureData)**Obsolete.** Superseded by [IWizardHoleFeatureData2::CounterDrillDiameter](#).

.NET Syntax

Visual Basic (Declaration)

Property CounterDrillDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
Dim value As System.Double
```

```
instance.CounterDrillDiameter = value
```

```
value = instance.CounterDrillDiameter
```

C#

```
System.double CounterDrillDiameter {get; set;}
```

C++/CLI

```
property System.double CounterDrillDiameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::CounterDrillDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

CounterSinkAngle Property (IWizardHoleFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : CounterSinkAngle Property (IWizardHoleFeatureData)**Obsolete.** Superseded by [IWizardHoleFeatureData2::CounterSinkAngle](#).

.NET Syntax

Visual Basic (Declaration)

Property CounterSinkAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
Dim value As System.Double
```

```
instance.CounterSinkAngle = value
```

```
value = instance.CounterSinkAngle
```

C#

```
System.double CounterSinkAngle {get; set;}
```

C++/CLI

```
property System.double CounterSinkAngle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::CounterSinkAngle](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CounterSinkDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : CounterSinkDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::CounterSinkDiameter](#).

.NET Syntax

Visual Basic (Declaration)

```
Property CounterSinkDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.CounterSinkDiameter = value
```

```
value = instance.CounterSinkDiameter
```

C#

```
System.double CounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double CounterSinkDiameter {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::CounterSinkDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Depth Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : Depth Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::Depth](#).

.NET Syntax

Visual Basic (Declaration)

Property Depth As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.Depth = value
```

```
value = instance.Depth
```

C#

```
System.double Depth {get; set;}
```

C++/CLI

```
property System.double Depth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::Depth](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Diameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : Diameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::Diameter](#).

.NET Syntax

Visual Basic (Declaration)

Property Diameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.Diameter = value
```

```
value = instance.Diameter
```

C#

```
System.double Diameter {get; set;}
```

C++/CLI

```
property System.double Diameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::Diameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DrillAngle Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : DrillAngle Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::DrillAngle](#).

.NET Syntax

Visual Basic (Declaration)

Property DrillAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double  
  
instance.DrillAngle = value  
  
value = instance.DrillAngle
```

C#

```
System.double DrillAngle {get; set;}
```

C++/CLI

```
property System.double DrillAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::DrillAngle](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EndCondition Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : EndCondition Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::EndCondition](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Property EndCondition As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Integer  
  
instance.EndCondition = value  
value = instance.EndCondition
```

C#

```
System.int EndCondition {get; set;}
```

C++/CLI

```
property System.int EndCondition {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::EndCondition](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Face Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : Face Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::Face](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Property Face As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Object  
  
instance.Face = value  
value = instance.Face
```

C#

```
System.object Face {get; set;}
```

C++/CLI

```
property System.Object^ Face {  
    System.Object^ get();
```

```
void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::Face](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FarCounterSinkAngle Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : FarCounterSinkAngle Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::FarCounterSinkAngle](#).

.NET Syntax

Visual Basic (Declaration)

```
Property FarCounterSinkAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.FarCounterSinkAngle = value  
value = instance.FarCounterSinkAngle
```

C#

```
System.double FarCounterSinkAngle {get; set;}
```

C++/CLI

```
property System.double FarCounterSinkAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::FarCounterSinkAngle](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FarCounterSinkDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : FarCounterSinkDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::FarCounterSinkDiameter](#).

.NET Syntax

Visual Basic (Declaration)

Property FarCounterSinkDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
Dim value As System.Double

instance.FarCounterSinkDiameter = value
value = instance.FarCounterSinkDiameter
```

C#

```
System.double FarCounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double FarCounterSinkDiameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::FarCounterSinkDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerSize Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : FastenerSize Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::FastenerSize](#).

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property FastenerSize As System.String

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
Dim value As System.String

instance.FastenerSize = value
value = instance.FastenerSize
```

C#

```
System.string FastenerSize {get; set;}
```

C++/CLI

```
property System.String^ FastenerSize {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::FastenerSize](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FastenerType Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : FastenerType Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::FastenerType2](#).

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property FastenerType As System.String
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.String
```

```
instance.FastenerType = value
```

```
value = instance.FastenerType
```

C#

```
System.string FastenerType {get; set;}
```

C++/CLI

```
property System.String^ FastenerType {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::FastenerType](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

HeadClearance Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : HeadClearance Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::HeadClearance](#).

.NET Syntax

Visual Basic (Declaration)

Property HeadClearance As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double  
  
instance.HeadClearance = value  
value = instance.HeadClearance
```

C#

```
System.double HeadClearance {get; set;}
```

C++/CLI

```
property System.double HeadClearance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::HeadClearance](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

HoleDepth Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : HoleDepth Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::HoleDepth](#).

.NET Syntax

Visual Basic (Declaration)

Property HoleDepth As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double  
  
instance.HoleDepth = value  
value = instance.HoleDepth
```

C#

```
System.double HoleDepth {get; set;}
```

C++/CLI

```
property System.double HoleDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::HoleDepth](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

HoleDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : HoleDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::HoleDiameter](#).

.NET Syntax

Visual Basic (Declaration)

```
Property HoleDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.HoleDiameter = value
```

```
value = instance.HoleDiameter
```

C#

```
System.double HoleDiameter {get; set;}
```

C++/CLI

```
property System.double HoleDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::HoleDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : IAccessSelections Method (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::IAccessSelections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _
```

```
ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::IAccessSelections](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFace Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : IFace Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::IFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Property IFace As Face
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As Face
```

```
instance.IFace = value
```

```
value = instance.IFace
```

C#

```
Face IFace {get; set;}
```

C++/CLI

```
property Face^ IFace {
    Face^ get();
    void set ( & Face^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::IFace](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IVertex Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : IVertex Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::IVertex](#).

.NET Syntax

Visual Basic (Declaration)

Property IVertex As Vertex

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
Dim value As Vertex
```

```
instance.IVertex = value
```

```
value = instance.IVertex
```

C#

```
Vertex IVertex {get; set;}
```

C++/CLI

```
property Vertex^ IVertex {
    Vertex^ get();
    void set ( & Vertex^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::IVertex](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MajorDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : MajorDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::MajorDiameter](#).

.NET Syntax

Visual Basic (Declaration)

Property MajorDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.MajorDiameter = value
```

```
value = instance.MajorDiameter
```

C#

```
System.double MajorDiameter {get; set;}
```

C++/CLI

```
property System.double MajorDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::MajorDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MidCounterSinkAngle Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : MidCounterSinkAngle Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::MidCounterSinkAngle](#).

.NET Syntax

Visual Basic (Declaration)

Property MidCounterSinkAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.MidCounterSinkAngle = value
```

```
value = instance.MidCounterSinkAngle
```

C#

```
System.double MidCounterSinkAngle {get; set;}
```

C++/CLI

```
property System.double MidCounterSinkAngle {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::MidCounterSinkAngle](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

MidCounterSinkDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : MidCounterSinkDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::MidCounterSinkDiameter](#).

.NET Syntax

Visual Basic (Declaration)

```
Property MidCounterSinkDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double  
  
instance.MidCounterSinkDiameter = value  
value = instance.MidCounterSinkDiameter
```

C#

```
System.double MidCounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double MidCounterSinkDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::MidCounterSinkDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

MinorDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : MinorDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::MinorDiameter](#).

.NET Syntax

Visual Basic (Declaration)

Property MinorDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.MinorDiameter = value
```

```
value = instance.MinorDiameter
```

C#

```
System.double MinorDiameter {get; set;}
```

C++/CLI

```
property System.double MinorDiameter {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::MinorDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

NearCounterSinkAngle Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : NearCounterSinkAngle Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::NearCounterSinkAngle](#).

.NET Syntax

Visual Basic (Declaration)

Property NearCounterSinkAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.NearCounterSinkAngle = value
```

```
value = instance.NearCounterSinkAngle
```

C#

```
System.double NearCounterSinkAngle {get; set;}
```

C++/CLI

```
property System.double NearCounterSinkAngle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::NearCounterSinkAngle](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

NearCounterSinkDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : NearCounterSinkDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::NearCounterSinkDiameter](#).

.NET Syntax

Visual Basic (Declaration)

Property NearCounterSinkDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
Dim value As System.Double

instance.NearCounterSinkDiameter = value
value = instance.NearCounterSinkDiameter
```

C#

```
System.double NearCounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double NearCounterSinkDiameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::NearCounterSinkDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : ReleaseSelectionAccess Method (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::ReleaseSelectionAccess](#).

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::ReleaseSelectionAccess](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Standard Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : Standard Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::Standard2](#).

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Standard As System.String
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.String
```

```
instance.Standard = value
```

```
value = instance.Standard
```

C#

```
System.string Standard {get; set;}
```

C++/CLI

```
property System.String^ Standard {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::Standard](#).

See Also

TapDrillDepth Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : TapDrillDepth Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::TapDrillDepth](#).

.NET Syntax

Visual Basic (Declaration)

```
Property TapDrillDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.TapDrillDepth = value
```

```
value = instance.TapDrillDepth
```

C#

```
System.double TapDrillDepth {get; set;}
```

C++/CLI

```
property System.double TapDrillDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::TapDrillDepth](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

TapDrillDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : TapDrillDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::TapDrillDiameter](#).

.NET Syntax

Visual Basic (Declaration)

```
Property TapDrillDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.TapDrillDiameter = value
```

```
value = instance.TapDrillDiameter
```

C#

```
System.double TapDrillDiameter {get; set;}
```

C++/CLI

```
property System.double TapDrillDiameter {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::TapDrillDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThreadAngle Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : ThreadAngle Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::ThreadAngle](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ThreadAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.ThreadAngle = value
```

```
value = instance.ThreadAngle
```

C#

```
System.double ThreadAngle {get; set;}
```

C++/CLI

```
property System.double ThreadAngle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::ThreadAngle](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThreadDepth Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : ThreadDepth Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::ThreadDepth](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ThreadDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.ThreadDepth = value
```

```
value = instance.ThreadDepth
```

C#

```
System.double ThreadDepth {get; set;}
```

C++/CLI

```
property System.double ThreadDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::ThreadDepth](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThreadDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : ThreadDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::ThreadDiameter](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ThreadDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.ThreadDiameter = value  
value = instance.ThreadDiameter
```

C#

```
System.double ThreadDiameter {get; set;}
```

C++/CLI

```
property System.double ThreadDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::ThreadDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThruHoleDepth Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : ThruHoleDepth Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::ThruHoleDepth](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ThruHoleDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double  
  
instance.ThruHoleDepth = value  
value = instance.ThruHoleDepth
```

C#

```
System.double ThruHoleDepth {get; set;}
```

C++/CLI

```
property System.double ThruHoleDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::ThruHoleDepth](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

ThruHoleDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : ThruHoleDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::ThruHoleDiameter](#).

.NET Syntax

Visual Basic (Declaration)

Property ThruHoleDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
Dim value As System.Double
```

```
instance.ThruHoleDiameter = value
```

```
value = instance.ThruHoleDiameter
```

C#

```
System.double ThruHoleDiameter {get; set;}
```

C++/CLI

```
property System.double ThruHoleDiameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::ThruHoleDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)

[IWizardHoleFeatureData Members](#)

ThruTapDrillDepth Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : ThruTapDrillDepth Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::ThruTapDrillDepth](#).

.NET Syntax

Visual Basic (Declaration)

Property ThruTapDrillDepth As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData
Dim value As System.Double
```

```
instance.ThruTapDrillDepth = value
```

```
value = instance.ThruTapDrillDepth
```

C#

```
System.double ThruTapDrillDepth {get; set;}
```

C++/CLI

```
property System.double ThruTapDrillDepth {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::ThruTapDrillDepth](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThruTapDrillDiameter Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : ThruTapDrillDiameter Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::ThruTapDrillDiameter](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ThruTapDrillDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Double
```

```
instance.ThruTapDrillDiameter = value
```

```
value = instance.ThruTapDrillDiameter
```

C#

```
System.double ThruTapDrillDiameter {get; set;}
```

C++/CLI

```
property System.double ThruTapDrillDiameter {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::ThruTapDrillDiameter](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : Type Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::Type](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::Type](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Vertex Property (IWizardHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData Interface](#) : Vertex Property (IWizardHoleFeatureData)

Obsolete. Superseded by [IWizardHoleFeatureData2::Vertex](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Vertex As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData  
Dim value As System.Object
```

```
instance.Vertex = value
```

```
value = instance.Vertex
```

C#

```
System.object Vertex {get; set;}
```

C++/CLI

```
property System.Object^ Vertex {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData::Vertex](#).

See Also

[IWizardHoleFeatureData Interface](#)
[IWizardHoleFeatureData Members](#)