

SOLIDWORKS API (.NET VBA C#) — Reference (335/337): IWizardHoleFeatureData2 (part 1 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IWizardHoleFeatureData2 (part 1 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IWizardHoleFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWizardHoleFeatureData2 Interface

Allows access to Hole Wizard hole or slot feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IWizardHoleFeatureData2

Visual Basic (Usage)



Dim instance As [IWizardHoleFeatureData2](#)

C#

public interface IWizardHoleFeatureData2

C++/CLI

public interface class IWizardHoleFeatureData2

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2](#).

Example

[Create Holes Using Hole Wizard and Sketch Points \(VBA\)](#)
[Create Hole Wizard Feature Data Object and Hole Wizard Feature \(VBA\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VBA\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VB.NET\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(C#\)](#)
[Create Holes Using Hole Wizard and Sketch Points \(VB.NET\)](#)
[Create Holes Using Hole Wizard and Sketch Points \(C#\)](#)
[Insert Hole Wizard Slot and Hole \(C#\)](#)
[Insert Hole Wizard Slot and Hole \(VB.NET\)](#)
[Insert Hole Wizard Slot and Hole \(VBA\)](#)
[Get and Add Sketch Points in Hole Wizard Feature \(C#\)](#)
[Get and Add Sketch Points in Hole Wizard Feature \(VB.NET\)](#)
[Get and Add Sketch Points in Hole Wizard Feature \(VBA\)](#)

Remarks

Valid types of slots are counterbore, countersink, or straight.

See [Hole Wizard Features and WizardHoleFeatureData2 Objects](#).

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[WizardHoleFeatureData2](#)

See Also

[IWizardHoleFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::HoleWizard5 Method](#)
[ISimpleHoleFeatureData2 Interface](#)
[Hole Wizard Feature Types and Their Valid Properties](#)

IWizardHoleFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWizardHoleFeatureData2 Interface

The following tables list the members exposed by [IWizardHoleFeatureData2](#).

Public Properties

Name	Description
AssemblyFeatureScope	Gets or sets whether to use scope for this assembly Hole Wizard feature.
AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the Hole Wizard feature to affect in a multibody part.
AutoSelectComponents	Gets or sets whether to auto-select all components that this assembly Hole Wizard feature affects in model.
CosmeticThreadType	Gets or sets the type of cosmetic thread for this tap or pipe-tap Hole Wizard feature.
CounterBoreDepth	Gets or sets the Hole Wizard feature counterbore depth.
CounterBoreDiameter	Gets or sets the Hole Wizard feature counterbore diameter.
CounterDrillAngle	Gets or sets the Hole Wizard feature counterdrill angle.
CounterDrillDepth	Gets or sets the Hole Wizard feature counterdrill depth.
CounterDrillDiameter	Gets or sets the Hole Wizard feature counterdrill diameter.
CounterSinkAngle	Gets or sets the angle of the Hole Wizard countersink feature.
CounterSinkDiameter	Gets or sets the diameter of the Hole Wizard countersink feature.
Depth	Gets or sets the Hole Wizard feature hole depth.
Diameter	Gets or sets the diameter of the Hole Wizard feature.
DrillAngle	Gets or sets the drill angle for a Hole Wizard feature.
EndCondition	Gets or sets the Hole Wizard feature end condition type.
Face	Gets the end-condition face of the Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.
FarCounterSinkAngle	Gets or sets the angle of the far side Hole Wizard countersink feature.
FarCounterSinkDiameter	Gets or sets the diameter of the far side Hole Wizard countersink feature.
FarSideCounterSink	Gets whether the far side option is selected for the Hole Wizard countersink feature. NOTE: This property is a get-only property. Set is not implemented.
FastenerSize	Gets the fastener size for this Wizard Hole feature. NOTE: This property is a get-only property. Set is not implemented.
FastenerType	Obsolete. Superseded by IWizardHoleFeatureData2::FastenerType2 . NOTE: This property is a get-only property. Set is not implemented.
FastenerType2	Gets the fastener type for this Wizard Hole feature. NOTE: This property is a get-only property. Set is not implemented.
FeatureScope	Gets or sets whether to use scope for the Hole Wizard feature in a multibody part.
FeatureScopeBodies	Gets or sets the solid bodies that the Hole Wizard feature affects in a multibody part.
HeadClearance	Gets or sets the head clearance for this Wizard Hole feature.
HeadClearanceType	Gets the type of head clearance for this countersink Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.
HoleDepth	Gets or sets the Hole Wizard feature hole depth.
HoleDiameter	Gets or sets the Hole Wizard feature hole diameter.

		
 HoleFit	Gets or sets the Hole Wizard feature fit information.	
 IFace	Gets the end-condition face of the Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.	
 IVertex	Gets the end-condition vertex for the Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.	
 Length	Gets or sets the length of a Hole Wizard slot feature.	
 MajorDiameter	Gets or sets the Hole Wizard feature major diameter for a tapered hole.	
 MidCounterSinkAngle	Gets or sets the angle of the Hole Wizard middle countersink feature.	
 MidCounterSinkDiameter	Gets or sets the diameter of the Hole Wizard middle countersink feature.	
 MinorDiameter	Gets or sets the Hole Wizard feature minor diameter for a tapered hole.	
 NearCounterSinkAngle	Gets or sets the angle of the near side Hole Wizard countersink feature.	
 NearCounterSinkDiameter	Gets or sets the diameter of the near side Hole Wizard countersink feature.	
 NearSideCounterSink	Gets whether the near side option is selected for the Hole Wizard countersink feature. NOTE: This property is a get-only property. Set is not implemented.	
 OffsetDistance	Gets or sets the offset distance from the selected face, surface, or plane for this Hole Wizard feature.	
 PropagateFeatureToParts	Gets whether to propagate this assembly Hole Wizard feature to the parts that it affects in this model.	
 ReverseDirection	Gets or sets the direction of the Hole Wizard feature.	
 Standard	Gets the design standard for this Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.	
 Standard2	Gets the design standard for this Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.	
 TapDrillDepth	Gets or sets the Hole Wizard feature tap drill depth.	
 TapDrillDiameter	Gets or sets the Hole Wizard feature tap drill diameter.	
 TapType	Gets or sets the helicoil standard for this Hole Wizard feature.	
 ThreadAngle	Gets or sets the Hole Wizard feature thread angle.	
 ThreadClass	Gets or sets the thread class for this Hole Wizard feature..	
 ThreadDepth	Gets or sets the Hole Wizard feature thread depth.	
 ThreadDiameter	Gets or sets the Hole Wizard feature thread diameter.	
 ThreadEndCondition	Gets or sets the thread end condition for this Hole Wizard feature.	
 ThruHoleDepth	Gets or sets the Hole Wizard feature through hole depth.	
 ThruHoleDiameter	Gets or sets the Hole Wizard feature through-hole diameter.	
 ThruTapDrillDepth	Gets or sets the Hole Wizard feature through-tap drill depth.	
 ThruTapDrillDiameter	Gets or sets the Hole Wizard feature through-tap drill diameter.	
 Type	Gets the Hole Wizard feature type. NOTE: This property is a get-only property. Set is not implemented.	
 UnderHeadCounterSink	Gets or sets whether the Hole Wizard feature is an underhead counter sink.	
 UnderHeadCounterSinkAngle	Gets or sets the Hole Wizard feature underhead counter sink angle.	
 UnderHeadCounterSinkDiameter	Gets or sets the Hole Wizard feature underhead counter sink diameter.	
 Vertex	Gets the end-condition vertex for the Hole Wizard feature.	

NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the Hole Wizard feature.
 ChangeStandard	Sets the standard for all of the parameters of the Hole Wizard feature that are driven by the database.
 GetEndConditionReference	Gets the reference entity that defines the end condition for this Hole Wizard feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the Hole Wizard feature in a multibody part.
 GetSketchPointCount	Gets the number of center-hole sketch points in this Hole Wizard feature.
 GetSketchPoints	Gets the center-hole sketch points in this Hole Wizard feature.
 IAccessSelections	Gains access to the selections used to define the Hole Wizard feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the Hole Wizard feature affects in a multibody part.
 IGetSketchPoints	Gets the center-hole sketch points in this Hole Wizard feature.
 InitializeHole	Initializes a newly created Hole Wizard feature data object.
 ISetFeatureScopeBodies	Sets the solid bodies that the Hole Wizard feature affects in the multibody part.
 ReleaseSelectionAccess	Releases access to the selections used to define the Hole Wizard feature.
 RestoreDefaultValues	Restores default values for this Hole Wizard hole or slot.
 SetEndConditionReference	Sets the reference entity that defines the end condition for this Hole Wizard feature.

[Top](#)

See Also

[IWizardHoleFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::HoleWizard5 Method](#)
[ISimpleHoleFeatureData2 Interface](#)
[Hole Wizard Feature Types and Their Valid Properties](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWizardHoleFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWizardHoleFeatureData2 Interface

For a list of all members of this type, see [IWizardHoleFeatureData2 members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the Hole Wizard feature.
 ChangeStandard	Sets the standard for all of the parameters of the Hole Wizard feature that are driven by the database.
 GetEndConditionReference	Gets the reference entity that defines the end condition for this Hole Wizard feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the Hole Wizard feature in a multibody part.
 GetSketchPointCount	Gets the number of center-hole sketch points in this Hole Wizard feature.
 GetSketchPoints	Gets the center-hole sketch points in this Hole Wizard feature.
 IAccessSelections	Gains access to the selections used to define the Hole Wizard feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the Hole Wizard feature affects in a multibody part.
 IGetSketchPoints	Gets the center-hole sketch points in this Hole Wizard feature.
 InitializeHole	Initializes a newly created Hole Wizard feature data object.
 ISetFeatureScopeBodies	Sets the solid bodies that the Hole Wizard feature affects in the multibody part.
 ReleaseSelectionAccess	Releases access to the selections used to define the Hole Wizard feature.



[RestoreDefaultValues](#)

Restores default values for this Hole Wizard hole or slot.

[SetEndConditionReference](#)

Sets the reference entity that defines the end condition for this Hole Wizard feature.

[Top](#)

See Also

[IWizardHoleFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::HoleWizard5 Method](#)
[ISimpleHoleFeatureData2 Interface](#)
[Hole Wizard Feature Types and Their Valid Properties](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IWizardHoleFeatureData2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWizardHoleFeatureData2 Interface

For a list of all members of this type, see [IWizardHoleFeatureData2 members](#).

Public Properties

Name	Description
 AssemblyFeatureScope	Gets or sets whether to use scope for this assembly Hole Wizard feature.
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the Hole Wizard feature to affect in a multibody part.
 AutoSelectComponents	Gets or sets whether to auto-select all components that this assembly Hole Wizard feature affects in model.
 CosmeticThreadType	Gets or sets the type of cosmetic thread for this tap or pipe-tap Hole Wizard feature.
 CounterBoreDepth	Gets or sets the Hole Wizard feature counterbore depth.
 CounterBoreDiameter	Gets or sets the Hole Wizard feature counterbore diameter.
 CounterDrillAngle	Gets or sets the Hole Wizard feature counterdrill angle.
 CounterDrillDepth	Gets or sets the Hole Wizard feature counterdrill depth.
 CounterDrillDiameter	Gets or sets the Hole Wizard feature counterdrill diameter.
 CounterSinkAngle	Gets or sets the angle of the Hole Wizard countersink feature.
 CounterSinkDiameter	Gets or sets the diameter of the Hole Wizard countersink feature.
 Depth	Gets or sets the Hole Wizard feature hole depth.
 Diameter	Gets or sets the diameter of the Hole Wizard feature.
 DrillAngle	Gets or sets the drill angle for a Hole Wizard feature.
 EndCondition	Gets or sets the Hole Wizard feature end condition type.
 Face	Gets the end-condition face of the Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.
 FarCounterSinkAngle	Gets or sets the angle of the far side Hole Wizard countersink feature.
 FarCounterSinkDiameter	Gets or sets the diameter of the far side Hole Wizard countersink feature.
 FarSideCounterSink	Gets whether the far side option is selected for the Hole Wizard countersink feature. NOTE: This property is a get-only property. Set is not implemented.
 FastenerSize	Gets the fastener size for this Wizard Hole feature. NOTE: This property is a get-only property. Set is not implemented.
 FastenerType	Obsolete. Superseded by IWizardHoleFeatureData2::FastenerType2 . NOTE: This property is a get-only property. Set is not implemented.
 FastenerType2	Gets the fastener type for this Wizard Hole feature.

NOTE: This property is a get-only property. Set is not implemented.

	FeatureScope	Gets or sets whether to use scope for the Hole Wizard feature in a multibody part.
	FeatureScopeBodies	Gets or sets the solid bodies that the Hole Wizard feature affects in a multibody part.
	HeadClearance	Gets or sets the head clearance for this Wizard Hole feature.
	HeadClearanceType	Gets the type of head clearance for this countersink Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.
	HoleDepth	Gets or sets the Hole Wizard feature hole depth.
	HoleDiameter	Gets or sets the Hole Wizard feature hole diameter.
	HoleFit	Gets or sets the Hole Wizard feature fit information.
	IFace	Gets the end-condition face of the Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.
	IVertex	Gets the end-condition vertex for the Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.
	Length	Gets or sets the length of a Hole Wizard slot feature.
	MajorDiameter	Gets or sets the Hole Wizard feature major diameter for a tapered hole.
	MidCounterSinkAngle	Gets or sets the angle of the Hole Wizard middle countersink feature.
	MidCounterSinkDiameter	Gets or sets the diameter of the Hole Wizard middle countersink feature.
	MinorDiameter	Gets or sets the Hole Wizard feature minor diameter for a tapered hole.
	NearCounterSinkAngle	Gets or sets the angle of the near side Hole Wizard countersink feature.
	NearCounterSinkDiameter	Gets or sets the diameter of the near side Hole Wizard countersink feature.
	NearSideCounterSink	Gets whether the near side option is selected for the Hole Wizard countersink feature. NOTE: This property is a get-only property. Set is not implemented.
	OffsetDistance	Gets or sets the offset distance from the selected face, surface, or plane for this Hole Wizard feature.
	PropagateFeatureToParts	Gets whether to propagate this assembly Hole Wizard feature to the parts that it affects in this model.
	ReverseDirection	Gets or sets the direction of the Hole Wizard feature.
	Standard	Gets the design standard for this Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.
	Standard2	Gets the design standard for this Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.
	TapDrillDepth	Gets or sets the Hole Wizard feature tap drill depth.
	TapDrillDiameter	Gets or sets the Hole Wizard feature tap drill diameter.
	TapType	Gets or sets the helicoil standard for this Hole Wizard feature.
	ThreadAngle	Gets or sets the Hole Wizard feature thread angle.
	ThreadClass	Gets or sets the thread class for this Hole Wizard feature..
	ThreadDepth	Gets or sets the Hole Wizard feature thread depth.
	ThreadDiameter	Gets or sets the Hole Wizard feature thread diameter.
	ThreadEndCondition	Gets or sets the thread end condition for this Hole Wizard feature.
	ThruHoleDepth	Gets or sets the Hole Wizard feature through hole depth.
	ThruHoleDiameter	Gets or sets the Hole Wizard feature through-hole diameter.
	ThruTapDrillDepth	Gets or sets the Hole Wizard feature through-tap drill depth.

		
 ThruTapDrillDiameter	Gets or sets the Hole Wizard feature through-tap drill diameter.	
 Type	Gets the Hole Wizard feature type. NOTE: This property is a get-only property. Set is not implemented.	
 UnderHeadCounterSink	Gets or sets whether the Hole Wizard feature is an underhead counter sink.	
 UnderHeadCounterSinkAngle	Gets or sets the Hole Wizard feature underhead counter sink angle.	
 UnderHeadCounterSinkDiameter	Gets or sets the Hole Wizard feature underhead counter sink diameter.	
 Vertex	Gets the end-condition vertex for the Hole Wizard feature. NOTE: This property is a get-only property. Set is not implemented.	

[Top](#)

See Also

[IWizardHoleFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::HoleWizard5 Method](#)
[ISimpleHoleFeatureData2 Interface](#)
[Hole Wizard Feature Types and Their Valid Properties](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : AccessSelections Method (IWizardHoleFeatureData2)

Gains access to the selections used to define the Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
 Top-level document
Component
 Component in which the feature is to be modified

Return Value

TRUE if the selections are successfully accessed, FALSE if not

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [WizardHoleFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AssemblyFeatureScope Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : AssemblyFeatureScope Property (IWizardHoleFeatureData2)

Gets or sets whether to use scope for this assembly Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

Property AssemblyFeatureScope As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Boolean
```

```
instance.AssemblyFeatureScope = value  
value = instance.AssemblyFeatureScope
```

C#

```
System.bool AssemblyFeatureScope {get; set;}
```

C++/CLI

```
property System.bool AssemblyFeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use feature scope, false to not

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::AssemblyFeatureScope](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::AutoSelect Property](#)
[IWizardHoleFeatureData2::AutoSelectComponents Property](#)
[IWizardHoleFeatureData2::PropagateFeatureToParts Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AutoSelect Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : AutoSelect Property (IWizardHoleFeatureData2)

Gets or sets whether to automatically select all or only specific bodies for the Hole Wizard feature to affect in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property AutoSelect As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Boolean

instance.AutoSelect = value
value = instance.AutoSelect
```

C#

```
System.bool AutoSelect {get; set;}
```

C++/CLI

```
property System.bool AutoSelect {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies, false to select specific bodies for [IWizardHoleFeatureData2::FeatureScopeBodies](#) or [IWizardHoleFeatureData2::!SetFeatureScopeBodies](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::AutoSelect](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IWizardHoleFeatureData2::!GetFeatureScopeBodies Method](#)

[IWizardHoleFeatureData2::FeatureScope Property](#)
[IWizardHoleFeatureData2::AutoSelectComponents Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoSelectComponents Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : AutoSelectComponents Property (IWizardHoleFeatureData2)

Gets or sets whether to auto-select all components that this assembly Hole Wizard feature affects in model.

.NET Syntax

Visual Basic (Declaration)

Property AutoSelectComponents As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Boolean
```

```
instance.AutoSelectComponents = value  
value = instance.AutoSelectComponents
```

C#

```
System.bool AutoSelectComponents {get; set;}
```

C++/CLI

```
property System.bool AutoSelectComponents {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to auto-select all affected components, false to not (use the selected components only or set [IWizardHoleFeatureData2::AutoSelect](#) to true).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::AutoSelectComponents](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::AssemblyFeatureScope Property](#)
[IWizardHoleFeatureData2::PropagateFeatureToParts Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ChangeStandard Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ChangeStandard Method (IWizardHoleFeatureData2)

Sets the standard for all of the parameters of the Hole Wizard feature that are driven by the database.

.NET Syntax

```
Function ChangeStandard( _
    ByVal Standard As System.Integer, _
    ByVal FastenerType As System.Integer, _
    ByVal SSize As System.String _
) As System.Boolean
```



```
Dim instance As IWizardHoleFeatureData2
Dim Standard As System.Integer
Dim FastenerType As System.Integer
Dim SSize As System.String
Dim value As System.Boolean

value = instance.ChangeStandard(Standard, FastenerType, SSize)
```

```
System.bool ChangeStandard(
    System.int Standard,
    System.int FastenerType,
    System.string SSize
)
```

```
System.bool ChangeStandard(
    & System.int Standard,
    & System.int FastenerType,
    & System.String^ SSize
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Standard

Standard as defined in [swWzdHoleStandards_e](#)

FastenerType

Fastener type as defined in [swWzdHoleStandardFastenerTypes_e](#)

SSize

Fastener size

Return Value

True if the standard is changed, false if not

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ChangeStandard](#).

Remarks

Use this method to change [fastener size](#), [fastener type](#), and [design standard](#) of a Hole Wizard feature.

If changing the standard requires you to change the type, then you must call [IWizardHoleFeatureData2::Type](#) before calling [IWizardHoleFeatureData2::ChangeStandard](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : CosmeticThreadType Property (IWizardHoleFeatureData2)

Gets or sets the type of cosmetic thread for this tap or pipe-tap Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CosmeticThreadType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Integer
```

```
instance.CosmeticThreadType = value
```

```
value = instance.CosmeticThreadType
```

C#

```
System.int CosmeticThreadType {get; set;}
```

C++/CLI

```
property System.int CosmeticThreadType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of cosmetic thread as defined in [swWzdHoleCosmeticThreadTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::CosmeticThreadType](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CounterBoreDepth Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : CounterBoreDepth Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature counterbore depth.

.NET Syntax

Visual Basic (Declaration)

Property CounterBoreDepth As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.CounterBoreDepth = value

value = instance.CounterBoreDepth
```

C#

```
System.double CounterBoreDepth {get; set;}
```

C++/CLI

```
property System.double CounterBoreDepth {
    System.double get();
    void set ( &    System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Counterbore depth

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::CounterBoreDepth](#).

Example

See [Create Holes Using Hole Wizard](#) and [Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for swCounterBored and swCounterBoredDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterBoreDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CounterBoreDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : CounterBoreDiameter Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature counterbore diameter.

.NET Syntax

Visual Basic (Declaration)

```
Property CounterBoreDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.CounterBoreDiameter = value

value = instance.CounterBoreDiameter
```

C#

```
System.double CounterBoreDiameter {get; set;}
```

C++/CLI

```
property System.double CounterBoreDiameter {
    System.double get();
    void set ( &    System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Counterbore diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::CounterBoreDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for swCounterBored and swCounterBoredDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterBoreDepth Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CounterDrillAngle Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : CounterDrillAngle Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature counterdrill angle.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property CounterDrillAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.CounterDrillAngle = value
```

```
value = instance.CounterDrillAngle
```

C#

```
System.double CounterDrillAngle {get; set;}
```

C++/CLI

```
property System.double CounterDrillAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Counter drill angle

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::CounterDrillAngle](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for swCounterDrilled and swCounterDrilledDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterDrillDepth Property](#)
[IWizardHoleFeatureData2::CounterDrillDiameter Property](#)
[IWizardHoleFeaturData2::CounterDrillAngle Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CounterDrillDepth Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : CounterDrillDepth Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature counterdrill depth.

.NET Syntax

Visual Basic (Declaration)

```
Property CounterDrillDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.CounterDrillDepth = value
```

```
value = instance.CounterDrillDepth
```

C#

```
System.double CounterDrillDepth {get; set;}
```

C++/CLI

```
property System.double CounterDrillDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Counterdrill depth

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::CounterDrillDepth](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for swCounterDrilled and swCounterDrilledDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterDrillAngle Property](#)
[IWizardHoleFeatureData2::CounterDrillDiameter Property](#)
[IWizardHoleFeaturData2::DrillAngle Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CounterDrillDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : CounterDrillDiameter Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature counterdrill diameter.

.NET Syntax

Visual Basic (Declaration)

```
Property CounterDrillDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double  
  
instance.CounterDrillDiameter = value  
  
value = instance.CounterDrillDiameter
```

C#

```
System.double CounterDrillDiameter {get; set;}
```

C++/CLI

```
property System.double CounterDrillDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Counterdrill diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::CounterDrillDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for swCounterDrilled and swCounterDrilledDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterDrillAngle Property](#)
[IWizardHoleFeatureData2::CounterDrillDepth Property](#)
[IWizardHoleFeaturData2::DrillAngle Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CounterSinkAngle Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : CounterSinkAngle Property (IWizardHoleFeatureData2)

Gets or sets the angle of the Hole Wizard countersink feature.

.NET Syntax

Visual Basic (Declaration)

Property CounterSinkAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.CounterSinkAngle = value
```

```
value = instance.CounterSinkAngle
```

C#

```
System.double CounterSinkAngle {get; set;}
```

C++/CLI

```
property System.double CounterSinkAngle {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Countersink angle

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::CounterSinkAngle](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [WizardHoleFeatureData2](#).

Remarks

This property is relevant only for swCounterSunk and swCounterSunkDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::FarCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::NearCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::NearCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::FarCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::NearSideCounterSink Property](#)
[IWizardHoleFeatureData2::FarSideCounterSink Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CounterSinkDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : CounterSinkDiameter Property (IWizardHoleFeatureData2)

Gets or sets the diameter of the Hole Wizard countersink feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CounterSinkDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double  
  
instance.CounterSinkDiameter = value  
  
value = instance.CounterSinkDiameter
```

C#

```
System.double CounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double CounterSinkDiameter {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Countersink diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::CounterSinkDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [WizardHoleFeatureData2](#).

Remarks

This property is relevant only for swCounterSunk and swCounterSunkDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterSinkAngle Property](#)
[IWizardHoleFeatureData2::FarCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::FarCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::NearCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::NearCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::FarSideCounterSink Property](#)
[IWizardHoleFeatureData2::NearSideCounterSink Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Depth Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : Depth Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature hole depth.

.NET Syntax

Visual Basic (Declaration)

Property Depth As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.Depth = value
```

```
value = instance.Depth
```

C#

```
System.double Depth {get; set;}
```

C++/CLI

```
property System.double Depth {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole depth

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::Depth](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [WizardHoleFeatureData2](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::HoleDepth Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Diameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : Diameter Property (IWizardHoleFeatureData2)

Gets or sets the diameter of the Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

Property Diameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double  
  
instance.Diameter = value  
value = instance.Diameter
```

C#

```
System.double Diameter {get; set;}
```

C++/CLI

```
property System.double Diameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::Diameter](#).

Example

See [Create Holes Using Hole Wizard](#) and [Sketch Points](#) examples in [WizardHoleFeatureData2](#).

Remarks

This property does not support `swTapered` and `swTaperedDrilled` holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DrillAngle Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : DrillAngle Property (IWizardHoleFeatureData2)

Gets or sets the drill angle for a Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Property DrillAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double  
  
instance.DrillAngle = value  
value = instance.DrillAngle
```

C#

```
System.double DrillAngle {get; set;}
```

C++/CLI

```
property System.double DrillAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Drill angle

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::DrillAngle](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for swSimpleDrilled, swTaperedDrilled, swCounterBoreDrilled, swCounterSunkDrilled, and swCounterDrilledDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterDrillAngle Property](#)
[IWizardHoleFeatureData2::CounterDrillDepth Property](#)
[IWizardHoleFeatureData2::CounterDrillDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndCondition Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : EndCondition Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature end condition type.

.NET Syntax

Visual Basic (Declaration)

Property EndCondition As System.Integer

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Integer
```

```
instance.EndCondition = value
```

```
value = instance.EndCondition
```

C#

```
System.int EndCondition {get; set;}
```

C++/CLI

```
property System.int EndCondition {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition type as defined in [swEndConditions_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::EndCondition](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::GetEndConditionReference Method](#)
[IWizardHoleFeatureData2::SetEndConditionReference Method](#)
[IWizardHoleFeatureData2::Face Property](#)
[IWizardHoleFeatureData2::IFace Property](#)
[IWizardHoleFeatureData2::IVertex Property](#)
[IWizardHoleFeatureData2::Vertex Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Face Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : Face Property (IWizardHoleFeatureData2)

Gets the end-condition face of the Hole Wizard feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Face As System.Object

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Object
```

```
instance.Face = value
```

```
value = instance.Face
```

C#

```
System.object Face {get; set;}
```

C++/CLI

```
property System.Object^ Face {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Face](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::Face](#).

Example

[Create Holes Using Hole Wizard and Sketch Points \(VBA\)](#)

Remarks

To set the end condition to a face, use [IWizardHoleFeatureData2::SetEndConditionReference](#).

See [Accessing Selections that Define Features](#) for additional details on using this property

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::IFace Property](#)
[IWizardHoleFeatureData2::GetEndConditionReference Method](#)
[IWizardHoleFeatureData2::EndCondition Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FarCounterSinkAngle Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : FarCounterSinkAngle Property (IWizardHoleFeatureData2)

Gets or sets the angle of the far side Hole Wizard countersink feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FarCounterSinkAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.FarCounterSinkAngle = value
```

```
value = instance.FarCounterSinkAngle
```

C#

```
System.double FarCounterSinkAngle {get; set;}
```

C++/CLI

```
property System.double FarCounterSinkAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Far side countersink angle

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::FarCounterSinkAngle](#).

Example

[Select Near and Far Side Hole Wizard Countersink Options \(C#\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VB.NET\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VBA\)](#)

Remarks

This property is relevant only for swCounterSunk and swCounterSunkDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::FarCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::CounterSinkAngle Property](#)
[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::NearCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::NearCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::FarSideCounterSink Property](#)
[IWizardHoleFeatureData2::NearSideCounterSink Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FarCounterSinkDiameter Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : FarCounterSinkDiameter Property (IWizardHoleFeatureData2)

Gets or sets the diameter of the far side Hole Wizard countersink feature.

.NET Syntax

Visual Basic (Declaration)

Property FarCounterSinkDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.FarCounterSinkDiameter = value
```

```
value = instance.FarCounterSinkDiameter
```

C#

```
System.double FarCounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double FarCounterSinkDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Far side countersink diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::FarCounterSinkDiameter](#).

Example

[Select Near and Far Side Hole Wizard Countersink Options \(VBA\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VB.NET\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(C#\)](#)

Remarks

This property is relevant only for swCounterSunk and swCounterSunkDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterSinkAngle Property](#)
[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::FarCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::NearCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::NearCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::NearSideCounterSink Property](#)
[IWizardHoleFeatureData2::FarSideCounterSink Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FarSideCounterSink Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : FarSideCounterSink Property (IWizardHoleFeatureData2)

Gets whether the far side option is selected for the Hole Wizard countersink feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property FarSideCounterSink As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Boolean
```

```
instance.FarSideCounterSink = value
```

```
value = instance.FarSideCounterSink
```

C#

```
System.bool FarSideCounterSink {get; set;}
```

C++/CLI

```
property System.bool FarSideCounterSink {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the far side option for the countersink Hole Wizard feature is selected, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::FarSideCounterSink](#).

Example

[Select Near and Far Side Hole Wizard Countersink Options \(C#\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VB.NET\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VBA\)](#)

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::NearSideCounterSink Property](#)
[IWizardHoleFeatureData2::NearCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::NearCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::CounterSinkAngle Property](#)

[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)

Availability

SOLIDWORKS 2011 SP05, Revision Number 19.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerSize Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : FastenerSize Property (IWizardHoleFeatureData2)

Gets the fastener size for this Wizard Hole feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property FastenerSize As System.String
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.String  
  
instance.FastenerSize = value  
  
value = instance.FastenerSize
```

C#

```
System.string FastenerSize {get; set;}
```

C++/CLI

```
property System.String^ FastenerSize {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fastener size

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::FastenerSize](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

To set the fastener size for a Hole Wizard feature, use [IWizardHoleFeatureData2::ChangeStandard](#). To modify this property, use [IModeler::CopyWizardHole](#) or [IModeler::ICopyWizardHole](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::FastenerType2 Property](#)
[IWizardHoleFeatureData2::Standard2 Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerType Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : FastenerType Property (IWizardHoleFeatureData2)

Obsolete. Superseded by [IWizardHoleFeatureData2::FastenerType2](#).

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property FastenerType As System.String
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.String

instance.FastenerType = value
value = instance.FastenerType
```

C#

```
System.string FastenerType {get; set;}
```

C++/CLI

```
property System.String^ FastenerType {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::FastenerType](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerType2 Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : FastenerType2 Property (IWizardHoleFeatureData2)

Gets the fastener type for this Wizard Hole feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property FastenerType2 As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Integer

instance.FastenerType2 = value

value = instance.FastenerType2
```

C#

```
System.int FastenerType2 {get; set;}
```

C++/CLI

```
property System.int FastenerType2 {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fastener type as defined in [swWzdHoleStandardFastenerTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::FastenerType2](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

To set the fastener size for a Hole Wizard feature, use [IWizardHoleFeatureData2::ChangeStandard](#). To modify this property, use [IModeler::CopyWizardHole](#) or [IModeler::ICopyWizardHole](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::FastenerSize Property](#)
[IWizardHoleFeatureData2::Standard2 Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScope Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : FeatureScope Property (IWizardHoleFeatureData2)

Gets or sets whether to use scope for the Hole Wizard feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureScope As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Boolean
```



```
instance.FeatureScope = value  
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get; set;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

When set to...	Then...
True	Only the specified bodies in the multibody part are affected by the Hole Wizard feature
False	All of the bodies in the multibody part are affected by the Hole Wizard feature

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::FeatureScope](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IWizardHoleFeatureData2::IGetFeatureScopeBodies Method](#)
[IWizardHoleFeatureData2::ISetFeatureScopeBodies Method](#)
[IWizardHoleFeatureData2::AutoSelect Property](#)
[IWizardHoleFeatureData2::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScopeBodies Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : FeatureScopeBodies Property (IWizardHoleFeatureData2)

Gets or sets the solid bodies that the Hole Wizard feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureScopeBodies As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Object  
  
instance.FeatureScopeBodies = value  
value = instance.FeatureScopeBodies
```

C#

```
System.Object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of solid [bodies](#) that the Hole Wizard feature affects

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::FeatureScopeBodies](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IWizardHoleFeatureData2::IGetFeatureScopeBodies Method](#)
[IWizardHoleFeatureData2::ISetFeatureScopeBodies Method](#)
[IWizardHoleFeatureData2::AutoSelect Property](#)
[IWizardHoleFeatureData2::FeatureScope Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEndConditionReference Method (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : GetEndConditionReference Method (IWizardHoleFeatureData2)

Gets the reference entity that defines the end condition for this Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndConditionReference( _  
    ByRef ReferenceType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IWizardHoleFeatureData2  
Dim ReferenceType As System.Integer  
Dim value As System.Object
```

```
value = instance.GetEndConditionReference(ReferenceType)
```

C#

```
System.Object GetEndConditionReference(  
    out System.int ReferenceType  
)
```

C++/CLI



```
System.Object^ GetEndConditionReference(  
& [Out] System.int ReferenceType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ReferenceType

Reference type as defined in [swSelectionReferenceTypes_e](#)

Return Value

Reference entity

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::GetEndConditionReference](#).

Example

[Create Holes Using Hole Wizard and Sketch Points \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::SetEndConditionReference Method](#)
[IWizardHoleFeatureData2::EndCondition Property](#)
[IWizardHoleFeatureData2::Face Property](#)
[IWizardHoleFeatureData2::IFace Property](#)
[IWizardHoleFeatureData2::IVertex Property](#)
[IWizardHoleFeatureData2::Vertex Property](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeatureScopeBodiesCount Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : GetFeatureScopeBodiesCount Method (IWizardHoleFeatureData2)

Gets the number of solid bodies affected by the Hole Wizard feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureScopeBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Integer
```

```
value = instance.GetFeatureScopeBodiesCount()
```

C#

```
System.int GetFeatureScopeBodiesCount()
```

C++/CLI

```
System.int GetFeatureScopeBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of solid bodies affected

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::GetFeatureScopeBodiesCount](#).

Remarks

Call this method before calling [IWizardHoleFeatureData2::!GetFeatureScopeBodies](#).

If [IWizardHoleFeatureData2::FeatureScope](#) is false, then the return value is 0.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::!SetFeatureScopeBodies Method](#)
[IWizardHoleFeatureData2::AutoSelect Property](#)
[IWizardHoleFeatureData2::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchPointCount Method (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : GetSketchPointCount Method (IWizardHoleFeatureData2)

Gets the number of center-hole sketch points in this Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchPointCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Integer  
  
value = instance.GetSketchPointCount()
```

C#

```
System.int GetSketchPointCount()
```

C++/CLI

```
System.int GetSketchPointCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of center-hole sketch points

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::GetSketchPointCount](#).

Example

[Get and Add Sketch Points in Hole Wizard Feature \(C#\)](#)
[Get and Add Sketch Points in Hole Wizard Feature \(VB.NET\)](#)
[Get and Add Sketch Points in Hole Wizard Feature \(VBA\)](#)

Remarks

Call this method before calling [IWizardHoleFeatureData2::IGetSketchPoints](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::IGetSketchPoints Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchPoints Method (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : GetSketchPoints Method (IWizardHoleFeatureData2)

Gets the center-hole sketch points in this Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Object
```

```
value = instance.GetSketchPoints()
```

C#

```
System.object GetSketchPoints()
```

C++/CLI

```
System.Object^ GetSketchPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of center-hole [sketch points](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::GetSketchPoints](#).

Example

[Get and Add Sketch Points in Hole Wizard Feature \(C#\)](#)
[Get and Add Sketch Points in Hole Wizard Feature \(VB.NET\)](#)
[Get and Add Sketch Points in Hole Wizard Feature \(VBA\)](#)

Remarks

To add or remove sketch points in a Hole Wizard feature sketch (also called a location sketch), you must edit the sketch. After editing the sketch update the Hole Wizard feature by calling [IModelDoc2::ForceRebuild3](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::GetSketchPointCount Method](#)
[IWizardHoleFeatureData2::!GetSketchPoints Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HeadClearance Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : HeadClearance Property (IWizardHoleFeatureData2)

Gets or sets the head clearance for this Wizard Hole feature.

.NET Syntax

Visual Basic (Declaration)

Property HeadClearance As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.HeadClearance = value
```

```
value = instance.HeadClearance
```

C#

```
System.double HeadClearance {get; set;}
```

C++/CLI

```
property System.double HeadClearance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Head clearance

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::HeadClearance](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HeadClearanceType Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : HeadClearanceType Property (IWizardHoleFeatureData2)

Gets the type of head clearance for this countersink Hole Wizard feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property HeadClearanceType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Integer  
  
instance.HeadClearanceType = value  
  
value = instance.HeadClearanceType
```

C#

```
System.int HeadClearanceType {get; set;}
```

C++/CLI

```
property System.int HeadClearanceType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of head clearance as defined in [swWzdHoleCounterSinkHeadClearanceTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::HeadClearanceType](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::HeadClearance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HoleDepth Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



Gets or sets the Hole Wizard feature hole depth.

.NET Syntax

Visual Basic (Declaration)

Property HoleDepth As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.HoleDepth = value

value = instance.HoleDepth
```

C#

```
System.double HoleDepth {get; set;}
```

C++/CLI

```
property System.double HoleDepth {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole depth

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::HoleDepth](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Example

[Create Hole Wizard Feature Data Object and Hole Wizard Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::Depth Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Gets or sets the Hole Wizard feature hole diameter.

.NET Syntax

Visual Basic (Declaration)

```
Property HoleDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double  
  
instance.HoleDiameter = value  
value = instance.HoleDiameter
```

C#

```
System.double HoleDiameter {get; set;}
```

C++/CLI

```
property System.double HoleDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::HoleDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Example

[Create Hole Wizard Feature Data Object and Hole Wizard Feature \(VBA\)](#)

Remarks

This property is not relevant for swTapered and swTaperedDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::Diameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HoleFit Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : HoleFit Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature fit information.

.NET Syntax

Visual Basic (Declaration)

```
Property HoleFit As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Integer  
  
instance.HoleFit = value  
value = instance.HoleFit
```

C#

```
System.int HoleFit {get; set;}
```

C++/CLI

```
property System.int HoleFit {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fit information as defined by [swWzdHoleScrewClearanceTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::HoleFit](#).

Remarks

When this property is changed, the diameter of the Hole Wizard feature is changed as per the database. This property applies to counterbore and countersink Hole Wizard features only.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : IAccessSelections Method (IWizardHoleFeatureData2)

Gains access to the selections used to define the Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

```
Dim instance As IWizardHoleFeatureData2
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2.IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IWizardHoleFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IFace Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : IFace Property (IWizardHoleFeatureData2)

Gets the end-condition face of the Hole Wizard feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property IFace As Face2

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As Face2  
  
instance.IFace = value  
value = instance.IFace
```

C#

```
Face2 IFace {get; set;}
```

C++/CLI

```
property Face2^ IFace {  
    Face2^ get();  
    void set ( & Face2^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Face](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::IFace](#).

Remarks

To set the end condition to a face, use [IWizardHoleFeatureData2::SetEndConditionReference](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::Face Property](#)
[IWizardHoleFeatureData2::EndCondition Property](#)
[IWizardHoleFeatureData2::GetEndConditionReference Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFeatureScopeBodies Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : IGetFeatureScopeBodies Method (IWizardHoleFeatureData2)

Gets the solid bodies that the Hole Wizard feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeatureScopeBodies ( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim Count As System.Integer
Dim value As Body2

value = instance.IGetFeatureScopeBodies(Count)
```

C#

```
Body2 IGetFeatureScopeBodies(
    System.int Count
)
```

C++/CLI

```
Body2^ IGetFeatureScopeBodies(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

Return Value

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IWizardHoleFeatureData2::GetFeatureScopeBodiesCount](#) to get Count.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ISetFeatureScopeBodies Method](#)
[IWizardHoleFeatureData2::AutoSelect Property](#)
[IWizardHoleFeatureData2::FeatureScope Property](#)
[IWizardHoleFeatureData2::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSketchPoints Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : IGetSketchPoints Method (IWizardHoleFeatureData2)

Gets the center-hole sketch points in this Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSketchPoints( _
    ByVal NCount As System.Integer _
) As SketchPoint
```

Visual Basic (Usage)

```
Dim instance As IWizardHoleFeatureData2
Dim NCount As System.Integer
Dim value As SketchPoint

value = instance.IGetSketchPoints(NCount)
```



C#

```
SketchPoint IGetSketchPoints(  
    System.int NCount  
)
```

C++/CLI

```
SketchPoint^ IGetSketchPoints(  
& System.int NCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NCount

Number of center-hole sketch points

Return Value

Array of center-hole [sketch points](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::IGetSketchPoints](#).

Remarks

Before calling this method, call [IWizardHoleFeatureData2::GetSketchPointCount](#) to get NCount.

To add or remove sketch points in a Hole Wizard feature sketch (also called a location sketch), you must edit the sketch. After editing the sketch update the Hole Wizard feature by calling [IModelDoc2::ForceRebuild3](#).

See Also

[IWizardHoleFeatureData2 Interface](#)

[IWizardHoleFeatureData2 Members](#)

[IWizardHoleFeatureData2::GetSketchPoints Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InitializeHole Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : InitializeHole Method (IWizardHoleFeatureData2)

Initializes a newly created Hole Wizard feature data object.

.NET Syntax

Visual Basic (Declaration)

```
Sub InitializeHole( _  
    ByVal GenericHoleType As System.Integer, _  
    ByVal StdIndex As System.Integer, _  
    ByVal FastnerType As System.Integer, _  
    ByVal SSize As System.String, _  
    ByVal EndType As System.Integer _  
)
```

Visual Basic (Usage)

```
Dim instance As IWizardHoleFeatureData2  
Dim GenericHoleType As System.Integer  
Dim StdIndex As System.Integer  
Dim FastnerType As System.Integer
```



```
Dim SSize As System.String
Dim EndType As System.Integer
```

```
instance.InitializeHole(GenericHoleType, StdIndex, FastnerType, SSize, EndType)
```

C#

```
void InitializeHole(
    System.int GenericHoleType,
    System.int StdIndex,
    System.int FastnerType,
    System.string SSize,
    System.int EndType
)
```

C++/CLI

```
void InitializeHole(
    & System.int GenericHoleType,
    & System.int StdIndex,
    & System.int FastnerType,
    & System.String^ SSize,
    & System.int EndType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GenericHoleType

Hole type as defined in [swWzdGeneralHoleTypes_e](#)

StdIndex

Standard as defined in [swWzdHoleStandards_e](#)

FastnerType

Screw type as defined in [swWzdHoleStandardFastenerTypes_e](#)

SSize

Size of the hole

EndType

End type as defined in [swEndConditions_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::InitializeHole](#).

Remarks

See Also

[IWizardHoleFeatureData2 Interface](#)

[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFeatureScopeBodies Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ISetFeatureScopeBodies Method (IWizardHoleFeatureData2)

Sets the solid bodies that the Hole Wizard feature affects in the multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFeatureScopeBodies( _
    ByVal Count As System.Integer, _
```

```
ByRef BodyArr As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim Count As System.Integer  
Dim BodyArr As Body2  
  
instance.ISetFeatureScopeBodies(Count, BodyArr)
```

C#

```
void ISetFeatureScopeBodies(  
    System.int Count,  
    ref Body2 BodyArr  
)
```

C++/CLI

```
void ISetFeatureScopeBodies(  
& System.int Count,  
& Body2^% BodyArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

BodyArr

Array of solid [bodies](#) of size Count

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ISetFeatureScopeBodies](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IWizardHoleFeatureData2::ISetFeatureScopeBodies Method](#)
[IWizardHoleFeatureData2::FeatureScope Property](#)
[IWizardHoleFeatureData2::FeatureScopeBodies Property](#)
[IWizardHoleFeatureData2::Vertex Property](#)
[IWizardHoleFeatureData2::IVertex Property](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IVertex Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : IVertex Property (IWizardHoleFeatureData2)

Gets the end-condition vertex for the Hole Wizard feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property IVertex As Vertex

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As Vertex

instance.IVertex = value

value = instance.IVertex
```

C#

```
Vertex IVertex {get; set;}
```

C++/CLI

```
property Vertex^ IVertex {
    Vertex^ get();
    void set ( & Vertex^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Vertex](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::IVertex](#).

Remarks

To if end condition is to a vertex, use [IWizardHoleFeatureData2::SetEndConditionReference](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::Vertex Property](#)
[IWizardHoleFeatureData2::EndCondition Property](#)
[IWizardHoleFeatureData2::GetEndConditionReference Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Length Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : Length Property (IWizardHoleFeatureData2)

Gets or sets the length of a Hole Wizard slot feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Length As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.Length = value
```

```
value = instance.Length
```

C#

```
System.double Length {get; set;}
```

C++/CLI

```
property System.double Length {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of slot

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::Length](#).

Example

[Insert Hole Wizard Slot and Hole \(C#\)](#)
[Insert Hole Wizard Slot and Hole \(VB.NET\)](#)
[Insert Hole Wizard Slot and Hole \(VBA\)](#)

Remarks

This property is only valid for slots.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MajorDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : MajorDiameter Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature major diameter for a tapered hole.

.NET Syntax

Visual Basic (Declaration)

```
Property MajorDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.MajorDiameter = value
```

```
value = instance.MajorDiameter
```

C#

```
System.double MajorDiameter {get; set;}
```

```
property System.double MajorDiameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Major diameter for a tapered hole

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::MajorDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [WizardHoleFeatureData2](#).

Remarks

This property is relevant only for swTapered and swTaperedDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::MinorDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MidCounterSinkAngle Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : MidCounterSinkAngle Property (IWizardHoleFeatureData2)

Gets or sets the angle of the Hole Wizard middle countersink feature.

.NET Syntax

Visual Basic (Declaration)

```
Property MidCounterSinkAngle As System.Double
```

Visual Basic (Usage)

```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.MidCounterSinkAngle = value
value = instance.MidCounterSinkAngle
```

C#

```
System.double MidCounterSinkAngle {get; set;}
```

```
property System.double MidCounterSinkAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Middle countersink angle

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::MidCounterSinkAngle](#).

Example

[Create Holes Using Hole Wizard and Sketch Points \(VBA\)](#)

Remarks

This property is relevant only for swCounterSunk and swCounterSunkDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterSinkAngle Property](#)
[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::FarCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::FarCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::NearCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::NearCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::NearSideCounterSink Property](#)
[IWizardHoleFeatureData2::FarSideCounterSink Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MidCounterSinkDiameter Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : MidCounterSinkDiameter Property (IWizardHoleFeatureData2)

Gets or sets the diameter of the Hole Wizard middle countersink feature.

.NET Syntax

Visual Basic (Declaration)

```
Property MidCounterSinkDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.MidCounterSinkDiameter = value
```

```
value = instance.MidCounterSinkDiameter
```

C#

```
System.double MidCounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double MidCounterSinkDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Middle countersink diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::MidCounterSinkDiameter](#).

Example

[Create Holes Using Hole Wizard and Sketch Points \(VBA\)](#)

Remarks

This property is relevant only for swCounterSunk and swCounterSunkDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2.CounterSinkAngle Property](#)
[IWizardHoleFeatureData2.CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2.FarCounterSinkAngle Property](#)
[IWizardHoleFeatureData2.FarCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2.MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2.NearCounterSinkAngle Property](#)
[IWizardHoleFeatureData2.NearCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2.FarSideCounterSink Property](#)
[IWizardHoleFeatureData2.NearSideCounterSink Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0