

SOLIDWORKS API (.NET VBA C#) — Reference (336/337): IWizardHoleFeatureData2 (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IWizardHoleFeatureData2 (part 2 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MinorDiameter Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : MinorDiameter Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature minor diameter for a tapered hole.

.NET Syntax

Visual Basic (Declaration)

Property MinorDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.MinorDiameter = value
value = instance.MinorDiameter
```

C#

```
System.double MinorDiameter {get; set;}
```

C++/CLI

```
property System.double MinorDiameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Minor diameter for a tapered hole

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::MinorDiameter](#).

Example

[Create Holes Using Hole Wizard and Sketch Points \(VBA\)](#)

Remarks

This property is relevant only for swTapered and swTaperedDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::MajorDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

NearCounterSinkAngle Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : NearCounterSinkAngle Property (IWizardHoleFeatureData2)

Gets or sets the angle of the near side Hole Wizard countersink feature.

.NET Syntax

Visual Basic (Declaration)

```
Property NearCounterSinkAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.NearCounterSinkAngle = value
```

```
value = instance.NearCounterSinkAngle
```

C#

```
System.double NearCounterSinkAngle {get; set;}
```

C++/CLI

```
property System.double NearCounterSinkAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Near side countersink angle

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::NearCounterSinkAngle](#).

Example

[Select Near and Far Side Hole Wizard Countersink Options \(VBA\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VB.NET\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(C#\)](#)

Remarks

This property is relevant only for swCounterSunk and swCounterSunkDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::NearCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::FarCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::FarCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::CounterSinkAngle Property](#)
[IWizardHoleFeatureData2::NearSideCounterSink Property](#)
[IWizardHoleFeatureData2::FarSideCounterSink Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

NearCounterSinkDiameter Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : NearCounterSinkDiameter Property (IWizardHoleFeatureData2)

Gets or sets the diameter of the near side Hole Wizard countersink feature.

.NET Syntax

Visual Basic (Declaration)

```
Property NearCounterSinkDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double  
  
instance.NearCounterSinkDiameter = value  
  
value = instance.NearCounterSinkDiameter
```

C#

```
System.double NearCounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double NearCounterSinkDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Near side countersink diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::NearCounterSinkDiameter](#).

Example

[Select Near and Far Side Hole Wizard Countersink Options \(C#\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VB.NET\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VBA\)](#)

Remarks

This property is relevant only for swCounterSunk and swCounterSunkDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::CounterSinkAngle Property](#)
[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::FarCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::FarCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::NearCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::FarSideCounterSink Property](#)
[IWizardHoleFeatureData2::NearSideCounterSink Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

NearSideCounterSink Property (IWizardHoleFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : NearSideCounterSink Property (IWizardHoleFeatureData2)

Gets whether the near side option is selected for the Hole Wizard countersink feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property NearSideCounterSink As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Boolean  
  
instance.NearSideCounterSink = value  
  
value = instance.NearSideCounterSink
```

C#

```
System.bool NearSideCounterSink {get; set;}
```

C++/CLI

```
property System.bool NearSideCounterSink {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the near side option for the countersink Hole Wizard feature is selected, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::NearSideCounterSink](#).

Example

[Select Near and Far Side Hole Wizard Countersink Options \(C#\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VB.NET\)](#)
[Select Near and Far Side Hole Wizard Countersink Options \(VBA\)](#)

Remarks

If you set this property to true, you must also set [IWizardHoleFeatureData2::NearCounterSinkDiameter](#) to an appropriate value in meters and [IWizardHoleFeatureData2::NearCounterSinkAngle](#) to an appropriate value in radians to modify the Hole Wizard feature definition. If you do not set the diameter and angle to their proper values, then this method has no effect.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::FarSideCounterSink Property](#)
[IWizardHoleFeatureData2::FarCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::FarCounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::CounterSinkAngle Property](#)
[IWizardHoleFeatureData2::CounterSinkDiameter Property](#)
[IWizardHoleFeatureData2::MidCounterSinkAngle Property](#)
[IWizardHoleFeatureData2::MidCounterSinkDiameter Property](#)

Availability

OffsetDistance Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : OffsetDistance Property (IWizardHoleFeatureData2)

Gets or sets the offset distance from the selected face, surface, or plane for this Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

Property OffsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.OffsetDistance = value
```

```
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::OffsetDistance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

PropagateFeatureToParts Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : PropagateFeatureToParts Property (IWizardHoleFeatureData2)

Gets whether to propagate this assembly Hole Wizard feature to the parts that it affects in this model.

.NET Syntax

Visual Basic (Declaration)

Property PropagateFeatureToParts As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Boolean  
  
instance.PropagateFeatureToParts = value  
value = instance.PropagateFeatureToParts
```

C#

```
System.bool PropagateFeatureToParts {get; set;}
```

C++/CLI

```
property System.bool PropagateFeatureToParts {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate this assembly Hole Wizard feature to the parts that it affects in the model, false to not

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::PropagateFeatureToParts](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::AssemblyFeatureScope Property](#)
[IWizardHoleFeatureData2::AutoSelect Property](#)
[IWizardHoleFeatureData2::AutoSelectComponents Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ReleaseSelectionAccess Method (IWizardHoleFeatureData2)

Releases access to the selections used to define the Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ReleaseSelectionAccess](#).

Remarks

[IWizardHoleFeatureData2::AccessSelections](#) and [IWizardHoleFeatureData2::!AccessSelections](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RestoreDefaultValues Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : RestoreDefaultValues Method (IWizardHoleFeatureData2)

Restores default values for this Hole Wizard hole or slot.

.NET Syntax

Visual Basic (Declaration)

```
Sub RestoreDefaultValues()
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
instance.RestoreDefaultValues()
```

C#

```
void RestoreDefaultValues()
```

C++/CLI

```
void RestoreDefaultValues();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::RestoreDefaultValues](#).

Remarks

This method is not valid for legacy hole types.

See Also

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ReverseDirection Property (IWizardHoleFeatureData2)

Gets or sets the direction of the Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction, false to not

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ReverseDirection](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEndConditionReference Method (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : SetEndConditionReference Method (IWizardHoleFeatureData2)

Sets the reference entity that defines the end condition for this Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEndConditionReference( _  
    ByVal PDisp As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim PDisp As System.Object  
  
instance.SetEndConditionReference(PDisp)
```

C#

```
void SetEndConditionReference(  
    System.object PDisp  
)
```

C++/CLI

```
void SetEndConditionReference(  
    & System.Object^ PDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PDisp
Reference entity that defines the end condition

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::SetEndConditionReference](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::GetEndConditionReference Method](#)
[IWizardHoleFeatureData2::EndCondition Property](#)
[IWizardHoleFeatureData2::Face Property](#)
[IWizardHoleFeatureData2::IFace Property](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Standard Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : Standard Property (IWizardHoleFeatureData2)

Gets the design standard for this Hole Wizard feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Standard As System.String

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.String

instance.Standard = value

value = instance.Standard
```

C#

```
System.string Standard {get; set;}
```

C++/CLI

```
property System.String^ Standard {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Design standard

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::Standard](#).

Remarks

To set the fastener size, use [IWizardHoleFeatureData2::ChangeStandard](#). To modify this property, use [IModeler::CopyWizardHole](#) and [IModeler::ICopyWizardHole](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::Standard2 Property \(\)](#)
[IWizardHoleFeatureData2::FastenerSize Property \(\)](#)
[IWizardHoleFeatureData2::FastenerType2 Property \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Standard2 Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : Standard2 Property (IWizardHoleFeatureData2)

Gets the design standard for this Hole Wizard feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Standard2 As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Integer

instance.Standard2 = value

value = instance.Standard2
```

C#

```
System.int Standard2 {get; set;}
```

C++/CLI

```
property System.int Standard2 {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Design standard as defined in [swWzdHoleStandards_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::Standard2](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

If the Wizard Hole is using a copied/custom standard, then this property returns -1. In that case, use [IWizardHoleFeatureData2::Standard](#) to get the copied/custom standard.

To set the fastener size, use [IWizardHoleFeatureData2::ChangeStandard](#). To modify this property, use [IModeler::CopyWizardHole](#) and [IModeler::ICopyWizardHole](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::FastenerSize Property](#)
[IWizardHoleFeatureData2::FastenerType2 Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TapDrillDepth Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : TapDrillDepth Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature tap drill depth.

.NET Syntax

Visual Basic (Declaration)

```
Property TapDrillDepth As System.Double
```

Visual Basic (Usage)



Copy Code

```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.TapDrillDepth = value

value = instance.TapDrillDepth
```

C#

```
System.double TapDrillDepth {get; set;}
```

C++/CLI

```
property System.double TapDrillDepth {
    System.double get();
    void set ( &    System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tap drill depth

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::TapDrillDepth](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for:

- swTapBlind
- swTapBlindCounterSinkTop
- swTapThru
- swTapThruCounterSinkBottom
- swTapThruCounterSinkTop
- swTapThruCounterSinkTopBottom

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::TapDrillDiameter Property](#)
[IWizardHoleFeatureData2::TapType Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDepth Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TapDrillDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : TapDrillDiameter Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature tap drill diameter.

.NET Syntax

```
Property TapDrillDiameter As System.Double
```



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double
```

```
instance.TapDrillDiameter = value
```

```
value = instance.TapDrillDiameter
```

```
System.double TapDrillDiameter {get; set;}
```

```
property System.double TapDrillDiameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tap drill diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::TapDrillDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for:

- swTapBlind
- swTapBlindCounterSinkTop
- swTapThru
- swTapThruCounterSinkBottom
- swTapThruCounterSinkTop
- swTapThruCounterSinkTopBottom

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::TapDrillDepth Property](#)
[IWizardHoleFeatureData2::TapType Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDepth Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

Gets or sets the helicoil standard for this Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

Property TapType As System.Integer

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Integer

instance.TapType = value

value = instance.TapType
```

C#

```
System.int TapType {get; set;}
```

C++/CLI

```
property System.int TapType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Helicoil standard as defined in [swWzdHoleHcoilTapTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::TapType](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::TapDrillDepth Property](#)
[IWizardHoleFeatureData2::TapDrillDiameter Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDepth Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDiameter Property](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadAngle Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThreadAngle Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature thread angle.

.NET Syntax

Visual Basic (Declaration)

Property ThreadAngle As System.Double

Visual Basic (Usage)

```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.ThreadAngle = value

value = instance.ThreadAngle
```

C#

```
System.double ThreadAngle {get; set;}
```

C++/CLI

```
property System.double ThreadAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread angle

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThreadAngle](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is relevant only for threaded holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThreadClass Property](#)
[IWizardHoleFeatureData2::ThreadDepth Property](#)
[IWizardHoleFeatureData2::ThreadDiameter Property](#)
[IWizardHoleFeatureData2::ThreadEndCondition Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadClass Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThreadClass Property (IWizardHoleFeatureData2)

Gets or sets the thread class for this Hole Wizard feature..

.NET Syntax

Visual Basic (Declaration)

```
Property ThreadClass As System.String
```

Visual Basic (Usage)

```
Dim instance As IWizardHoleFeatureData2
Dim value As System.String

instance.ThreadClass = value

value = instance.ThreadClass
```

C#

```
System.string ThreadClass {get; set;}
```

C++/CLI

```
property System.String^ ThreadClass {
    System.String^ get();
    void set ( &    System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

One of the following thread classes:

- 1B
- 2B
- 3B

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThreadClass](#).

Remarks

This property is relevant only for the ANSI inch standard.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThreadAngle Property](#)
[IWizardHoleFeatureData2::ThreadDepth Property](#)
[IWizardHoleFeatureData2::ThreadDiameter Property](#)
[IWizardHoleFeatureData2::ThreadEndCondition Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThreadDepth Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThreadDepth Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature thread depth.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property ThreadDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double
```

```
instance.ThreadDepth = value  
value = instance.ThreadDepth
```

C#

```
System.double ThreadDepth {get; set;}
```

C++/CLI

```
property System.double ThreadDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread depth

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThreadDepth](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThreadAngle Property](#)
[IWizardHoleFeatureData2::ThreadClass Property](#)
[IWizardHoleFeatureData2::ThreadEndCondition Property](#)
[IWizardHoleFeatureData2::ThreadClass Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThreadDiameter Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature thread diameter.

.NET Syntax

Visual Basic (Declaration)

```
Property ThreadDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.ThreadDiameter = value
```

```
value = instance.ThreadDiameter
```

C#

```
System.double ThreadDiameter {get; set;}
```

C++/CLI

```
property System.double ThreadDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThreadDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThreadAngle Property](#)
[IWizardHoleFeatureData2::ThreadClass Property](#)
[IWizardHoleFeatureData2::ThreadDepth Property](#)
[IWizardHoleFeatureData2::ThreadEndCondition Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadEndCondition Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThreadEndCondition Property (IWizardHoleFeatureData2)

Gets or sets the thread end condition for this Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ThreadEndCondition As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Integer
```

```
instance.ThreadEndCondition = value
```

```
value = instance.ThreadEndCondition
```

C#

```
System.int ThreadEndCondition {get; set;}
```

C++/CLI

```
property System.int ThreadEndCondition {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread end condition as defined in [swWzdHoleThreadEndCondition](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThreadEndCondition](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThreadAngle Property](#)
[IWizardHoleFeatureData2::ThreadClass Property](#)
[IWizardHoleFeatureData2::ThreadDepth Property](#)
[IWizardHoleFeatureData2::ThreadDiameter Property](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThruHoleDepth Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThruHoleDepth Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature through hole depth.

.NET Syntax

Visual Basic (Declaration)

```
Property ThruHoleDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.ThruHoleDepth = value
value = instance.ThruHoleDepth
```

C#

```
System.double ThruHoleDepth {get; set;}
```

C++/CLI

```
property System.double ThruHoleDepth {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Through hole depth

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThruHoleDepth](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

For through holes, the depths depend on the geometry. Do not rely on the Set version of this property to set depths.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThruHoleDiameter Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDepth Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThruHoleDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThruHoleDiameter Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature through-hole diameter.

.NET Syntax

Visual Basic (Declaration)

Property ThruHoleDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.ThruHoleDiameter = value
```

```
value = instance.ThruHoleDiameter
```

C#

```
System.double ThruHoleDiameter {get; set;}
```

C++/CLI

```
property System.double ThruHoleDiameter {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Through-hole diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThruHoleDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is not relevant for swTapered and swTaperedDrilled holes.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThruHoleDepth Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDepth Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThruTapDrillDepth Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThruTapDrillDepth Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature through-tap drill depth.

.NET Syntax

Visual Basic (Declaration)

Property ThruTapDrillDepth As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double
```

```
instance.ThruTapDrillDepth = value
```

```
value = instance.ThruTapDrillDepth
```

C#

```
System.double ThruTapDrillDepth {get; set;}
```

C++/CLI

```
property System.double ThruTapDrillDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Through-tap drill depth

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThruTapDrillDepth](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

For through holes, the depths depend on the geometry. Do not rely on the Set version of this property to set depths.

This property is only relevant for:

- swTapBlind
- swTapBlindCounterSinkTop
- swTapThru
- swTapThruCounterSinkBottom
- swTapThruCounterSinkTop
- swTapThruCounterSinkTopBottom

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThruHoleDepth Property](#)
[IWizardHoleFeatureData2::ThruHoleDiameter Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDiameter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThruTapDrillDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : ThruTapDrillDiameter Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature through-tap drill diameter.

Visual Basic Syntax

Visual Basic (Declaration)

Property ThruTapDrillDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double  
  
instance.ThruTapDrillDiameter = value  
value = instance.ThruTapDrillDiameter
```

C#

```
System.double ThruTapDrillDiameter {get; set;}
```

C++/CLI

```
property System.double ThruTapDrillDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Through-tap drill diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::ThruTapDrillDiameter](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

This property is only relevant for:

- swTapBlind
- swTapBlindCounterSinkTop
- swTapThru
- swTapThruCounterSinkBottom
- swTapThruCounterSinkTop
- swTapThruCounterSinkTopBottom

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::ThruHoleDepth Property](#)
[IWizardHoleFeatureData2::ThruHoleDiameter Property](#)
[IWizardHoleFeatureData2::ThruTapDrillDepth Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : Type Property (IWizardHoleFeatureData2)

Gets the Hole Wizard feature type.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type as defined in [swWzdHoleTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::Type](#).

Example

See [Create Holes Using Hole Wizard and Sketch Points](#) examples in [IWizardHoleFeatureData2](#).

Remarks

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UnderHeadCounterSink Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : UnderHeadCounterSink Property (IWizardHoleFeatureData2)

Gets or sets whether the Hole Wizard feature is an underhead counter sink.

.NET Syntax

Visual Basic (Declaration)

Property UnderHeadCounterSink As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Boolean

instance.UnderHeadCounterSink = value

value = instance.UnderHeadCounterSink
```

C#

```
System.bool UnderHeadCounterSink {get; set;}
```

C++/CLI

```
property System.bool UnderHeadCounterSink {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if an underhead counter sink, false if not

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::UnderHeadCounterSink](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::UnderHeadCounterSinkAngle Property \(\)](#)
[IWizardHoleFeatureData2::UnderHeadCounterSinkDiameter Property \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UnderHeadCounterSinkAngle Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : UnderHeadCounterSinkAngle Property (IWizardHoleFeatureData2)

Gets or sets the Hole Wizard feature underhead counter sink angle.

.NET Syntax

Visual Basic (Declaration)

```
Property UnderHeadCounterSinkAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2  
Dim value As System.Double  
  
instance.UnderHeadCounterSinkAngle = value  
value = instance.UnderHeadCounterSinkAngle
```

C#

```
System.double UnderHeadCounterSinkAngle {get; set;}
```

C++/CLI

```
property System.double UnderHeadCounterSinkAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Underhead counter sink angle

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::UnderHeadCounterSinkAngle](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::UnderHeadCounterSink Property \(\)](#)
[IWizardHoleFeatureData2::UnderHeadCounterSinkDiameter Property \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UnderHeadCounterSinkDiameter Property (IWizardHoleFeatureData2)

[See Also](#)



Gets or sets the Hole Wizard feature underhead counter sink diameter.

.NET Syntax

Visual Basic (Declaration)

Property UnderHeadCounterSinkDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Double

instance.UnderHeadCounterSinkDiameter = value

value = instance.UnderHeadCounterSinkDiameter
```

C#

```
System.double UnderHeadCounterSinkDiameter {get; set;}
```

C++/CLI

```
property System.double UnderHeadCounterSinkDiameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Underhead counter sink diameter

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::UnderHeadCounterSinkDiameter](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::UnderHeadCounterSink Property \(\)](#)
[IWizardHoleFeatureData2::UnderHeadCounterSinkAngle Property \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

Vertex Property (IWizardHoleFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWizardHoleFeatureData2 Interface](#) : Vertex Property (IWizardHoleFeatureData2)

Gets the end-condition vertex for the Hole Wizard feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Vertex As System.Object

Visual Basic (Usage)



```
Dim instance As IWizardHoleFeatureData2
Dim value As System.Object
```

```
instance.Vertex = value
```

```
value = instance.Vertex
```

C#

```
System.Object Vertex {get; set;}
```

C++/CLI

```
property System.Object^ Vertex {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Vertex](#)

Visual Basic for Applications (VBA) Syntax

See [WizardHoleFeatureData2::Vertex](#).

Remarks

To set the end condition to a vertex, use [IWizardHoleFeatureData2::SetEndConditionReference](#).

See Also

[IWizardHoleFeatureData2 Interface](#)
[IWizardHoleFeatureData2 Members](#)
[IWizardHoleFeatureData2::IVertex Property](#)
[IWizardHoleFeatureData2::EndCondition Property](#)
[IWizardHoleFeatureData2::GetEndConditionReference Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0