

SOLIDWORKS API (.NET VBA C#) — Reference

(337/337): IWrapSketchFeatureData-

SolidWorks.Interop.sldworks

SOLIDWORKS API Documentation (converted from CHM)

IWrapSketchFeatureData (Type)

IWrapSketchFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWrapSketchFeatureData Interface

Allows access to a wrap feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IWrapSketchFeatureData
```

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData
```

C#

```
public interface IWrapSketchFeatureData
```

C++/CLI

```
public interface class IWrapSketchFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData](#).

Example

[Change Wrap Feature Face \(C#\)](#)
[Change Wrap Feature Face \(VB.NET\)](#)
[Change Wrap Feature Face \(VBA\)](#)
[Create Wrap Feature on Multiple Faces \(C#\)](#)
[Create Wrap Feature on Multiple Faces \(VB.NET\)](#)
[Create Wrap Feature on Multiple Faces \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[WrapSketchFeatureData](#)

See Also

[IWrapSketchFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWrapFeature Method](#)

IWrapSketchFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWrapSketchFeatureData Interface

For a list of all members of this type, see [IWrapSketchFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Gains access to the selections that define this wrap feature.



[ReleaseSelectionAccess](#)

Releases access to the selections that define this wrap feature.

[Top](#)

See Also

[IWrapSketchFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertWrapFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWrapSketchFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWrapSketchFeatureData Interface

The following tables list the members exposed by [IWrapSketchFeatureData](#).

Public Properties

Name	Description
 Face	Gets where this face was applied for this wrap feature or sets the face where to apply this wrap feature.
 PullDirection	Gets or sets the pull direction for this wrap feature.
 ReverseDirection	Gets or sets whether or not to reverse the direction of the wrap feature.
 SourceSketch	Gets or sets the sketch for this wrap feature.
 Thickness	Gets or sets the thickness of this wrap feature.
 Type	Gets or sets the type of wrap for this wrap feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this wrap feature.
 ReleaseSelectionAccess	Releases access to the selections that define this wrap feature.

[Top](#)

See Also

[IWrapSketchFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertWrapFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IWrapSketchFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IWrapSketchFeatureData Interface

For a list of all members of this type, see [IWrapSketchFeatureData members](#).

Public Properties

Name	Description
 Face	Gets where this face was applied for this wrap feature or sets the face where to apply this wrap feature.
 PullDirection	Gets or sets the pull direction for this wrap feature.
 ReverseDirection	Gets or sets whether or not to reverse the direction of the wrap feature.
 SourceSketch	Gets or sets the sketch for this wrap feature.
 Thickness	Gets or sets the thickness of this wrap feature.
 Type	Gets or sets the type of wrap for this wrap feature.

[Top](#)

See Also

[IWrapSketchFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertWrapFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IWrapSketchFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWrapSketchFeatureData Interface](#) : AccessSelections Method (IWrapSketchFeatureData)

Gains access to the selections that define this wrap feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

TRUE if the selections are successfully accessed, FALSE if not

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData::AccessSelections](#).

Example

[Change Wrap Feature Face \(C#\)](#)
[Change Wrap Feature Face \(VB.NET\)](#)
[Change Wrap Feature Face \(VBA\)](#)

Remarks

To modify a feature in a...

Then...

Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IWrapFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IWrapSketchFeatureData Interface](#)
[IWrapSketchFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Face Property (IWrapSketchFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWrapSketchFeatureData Interface](#) : Face Property (IWrapSketchFeatureData)

Gets where this face was applied for this wrap feature or sets the face where to apply this wrap feature.

.NET Syntax

Visual Basic (Declaration)

Property Face As Face2

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData
Dim value As Face2
```

```
instance.Face = value
```

```
value = instance.Face
```

C#

```
Face2 Face {get; set;}
```

C++/CLI

```
property Face2^ Face {
    Face2^ get();
    void set ( &    Face2^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Face](#)

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData::Face](#).

Example

[Change Wrap Feature Face \(C#\)](#)
[Change Wrap Feature Face \(VB.NET\)](#)
[Change Wrap Feature Face \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWrapSketchFeatureData Interface](#)
[IWrapSketchFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PullDirection Property (IWrapSketchFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWrapSketchFeatureData Interface](#) : PullDirection Property (IWrapSketchFeatureData)

Gets or sets the pull direction for this wrap feature.

.NET Syntax

Visual Basic (Declaration)

Property PullDirection As System.Object

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData  
Dim value As System.Object
```

```
instance.PullDirection = value
```

```
value = instance.PullDirection
```

C#

```
System.object PullDirection {get; set;}
```

C++/CLI

```
property System.Object^ PullDirection {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer one of the following entities as defined in [swSelectType_e](#):

- swSelDATUMAXES
- swSelDATUMPLANES
- swSelEDGES
- swSelEXTSKETCHPOINTS
- swSelEXTSKETCHSEGS
- swSelFACES
- swSelLOCATIONS

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData::PullDirection](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWrapSketchFeatureData Interface](#)
[IWrapSketchFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IWrapSketchFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWrapSketchFeatureData Interface](#) : ReleaseSelectionAccess Method (IWrapSketchFeatureData)

Releases access to the selections that define this wrap feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData::ReleaseSelectionAccess](#).

Remarks

[IWrapFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IWrapSketchFeatureData Interface](#)
[IWrapSketchFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IWrapSketchFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWrapSketchFeatureData Interface](#) : ReverseDirection Property (IWrapSketchFeatureData)

Gets or sets whether or not to reverse the direction of the wrap feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData
Dim value As System.Boolean

instance.ReverseDirection = value
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

TRUE to reverse direction, FALSE to not

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData::ReverseDirection](#).

Example

See [IWrapSketchFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWrapSketchFeatureData Interface](#)
[IWrapSketchFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SourceSketch Property (IWrapSketchFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWrapSketchFeatureData Interface](#) : SourceSketch Property (IWrapSketchFeatureData)

Gets or sets the sketch for this wrap feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property SourceSketch As Sketch

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData
Dim value As Sketch

instance.SourceSketch = value
value = instance.SourceSketch
```

C#

```
Sketch SourceSketch {get; set;}
```

C++/CLI

```
property Sketch^ SourceSketch {
    Sketch^ get();
    void set ( & Sketch^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData::SourceSketch](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWrapSketchFeatureData Interface](#)
[IWrapSketchFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Thickness Property (IWrapSketchFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWrapSketchFeatureData Interface](#) : Thickness Property (IWrapSketchFeatureData)

Gets or sets the thickness of this wrap feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Thickness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData
Dim value As System.Double

instance.Thickness = value
value = instance.Thickness
```

C#

```
System.double Thickness {get; set;}
```

C++/CLI

```
property System.double Thickness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thickness

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData::Thickness](#).

Example

See [IWrapSketchFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWrapSketchFeatureData Interface](#)
[IWrapSketchFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (IWrapSketchFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IWrapSketchFeatureData Interface](#) : Type Property (IWrapSketchFeatureData)

Gets or sets the type of wrap for this wrap feature.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IWrapSketchFeatureData
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of wrap as defined in [swWrapSketchType_e](#)

Visual Basic for Applications (VBA) Syntax

See [WrapSketchFeatureData::Type](#).

Example

See [IWrapSketchFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IWrapSketchFeatureData Interface](#)
[IWrapSketchFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SolidWorks.Interop.sldworks Namespace

[See Also](#) [Inheritance Hierarchy](#)

 SOLIDWORKS API

 Interfaces

Interface	Description
IAdvancedHoleElementData	Allows access to Advanced Hole element data.
IAdvancedHoleFeatureData	Allows access to the Advanced Hole feature data.
IAdvancedSaveAsOptions	Allows access to all File > Save As options when saving a SOLIDWORKS Part, Assembly, or Drawing.
IAdvancedSelectionCriteria	Allows access to advanced component selection criteria for an assembly.
IAngleMateFeatureData	Allows access to an angle mate or a limit angle mate feature.
IAnimation	This interface is: • obsolete and has not been superseded. • nonfunctional in SOLIDWORKS 2008 and later. Use the interfaces related to motion studies introduced in SOLIDWORKS 2008 to access animation and simulation.
IAnnotation	Allows access to notes, weld symbols, datum tags, display dimensions, blocks, cosmetic threads, center marks, centerlines, and other annotation types.
IAnnotationView	Allows access to annotation views in parts and assemblies.
IAppearanceSetting	Allows access to visual property settings.
IAssemblyDoc	Allows access to functions that perform assembly operations; for example, adding new components, adding mate conditions, hiding, and exploding components.
IAttribute	Allows access to an attribute's values.
IAttributeDef	Allows access to an attribute definition.
IAutoBalloonOptions	Allows access to auto balloon options.
IBalloonOptions	Allows access to balloon options.
IBalloonStack	Allows access to the properties that apply to a balloon stack, such as the direction of the stack.
IBaseFlangeFeatureData	Allows access to a sheet metal base flange feature.
IBeltChainFeatureData	Allows access to a Belt/Chain assembly feature.
IBendsFeatureData	Allows access to a Flatten-Bends/Process-Bends feature.
IBendTable	Allows access to a bend table feature.
IBendTableAnnotation	Allows access to a bend table annotation.
IBlockDefinition	Obsolete. Superseded by ISketchBlockDefinition .
IBlockInstance	Obsolete. Superseded by ISketchBlockInstance .
IBody	Obsolete. Superseded by IBody2 .
IBody2	Allows access to the faces on a body and the ability to create surfaces for sewing into a body object.
IBodyFolder	Allows access to the bodies in solid, surface, and various weldment folders.
IBomFeature	Allows access to the BOM table feature.
IBomTable	Allows access to BOM table information and values. IMPORTANT: You can no longer insert IBomTable objects; you can now only insert IBomTableAnnotation objects. IBomTable objects are not and cannot be converted to IBomTableAnnotation objects. Use the IBomTable APIs for legacy BOM tables only.
IBomTableAnnotation	Allows access to the IBomFeature object for this table annotation.
IBomTableSortData	Allows access to the sort data of an IBomTableAnnotation .
IBoundaryBossFeatureData	Allows access to a boundary feature that is a boss or base.
IBoundingBoxFeatureData	Allows access to a bounding box feature.
IBreakCornerFeatureData	Allows access to a break corner feature.
IBreakLine	Allows access to information about a break line in a drawing view .
IBrokenOutSectionFeatureData	Allows access to the broken-out section feature data of a drawing view.
IBSurfParamData	Allows access to the parameterization data of a B-spline surface.
ICallout	Allows add-in applications to manipulate single and multi-row callouts.
ICalloutAngleVariable	Allows access to an angle variable in a hole callout.
ICalloutLengthVariable	Allows access to a length variable in a hole callout.
ICalloutStringVariable	Allows access to a string variable in a hole callout.
ICalloutVariable	Allows access to a hole callout.
ICamera	Allows access to the camera feature.
ICamFollowerMateFeatureData	Allows access to a cam-follower mate feature.
ICavityFeatureData	Allows access to a cavity feature.
ICenterLine	Allows access to a centerline.
ICenterMark	Allows access to a center mark or center mark set in a drawing view .
ICenterOfMass	Allows access to the centers of mass in a drawing view .
IChainPatternFeatureData	Allows access to a chain component pattern feature.

IChamferFeatureData	Obsolete. Superseded by IChamferFeatureData2
IChamferFeatureData2	Allows access to a chamfer feature.
ICircularPatternFeatureData	Allows access to a circular pattern feature.
IClearanceResult	Allows you to access the results of clearance verification .
IClearanceVerificationMgr	Allows you to check the clearance between selected components and/or faces in assemblies.
IClosedCornerFeatureData	Allows access to a closed corner feature.
ICoEdge	Allows access to the underlying edge and loop as well as various coedge data.
ICoincidentMateFeatureData	Allows access to a coincident mate feature.
ICollision	Allows access to collision data.
ICollisionDetectionGroup	Allows access to collision detection groups.
ICollisionDetectionManager	Allows access to the collision detection manager.
IColorTable	Allows access to the color definitions used in SOLIDWORKS.
ICombineBodiesFeatureData	Allows access to a combine feature.
ICommandGroup	Allows add-in applications to create toolbars and menu items, including flyout toolbars and submenus, and add them to the ICommandManager .
ICommandManager	Allows add-in applications to add and remove CommandGroups (menus and toolbars) to the CommandManager.
ICommandTab	Allows add-in applications to create tabs and add them to the CommandManager . The add-in application must create and clean up its own tabs.
ICommandTabBox	Allows add-in applications to create CommandManager tab boxes and add them to a CommandManager tab. The add-in application must create and clean-up its own tab boxes.
IComment	Allows access to the comments in the Comment folder in the FeatureManager design tree.
ICommentFolder	Allows access to the Comment folder in the FeatureManager design tree.
IComplexCornerTreatmentFeatureData	Allows access to a complex corner treatment feature of a structure system.
IComponent	Obsolete. Superseded by IComponent2
IComponent2	Allows access to the components within assemblies.
ICompositeCurveFeatureData	Allows access to a composite curve feature.
IConcentricMateFeatureData	Allows access to a concentric mate feature.
IConfiguration	Allows you to manage different part or assembly states.
IConfigurationManager	Allows access to a configuration in a model.
IConnectionPointFeatureData	Allows access to a connection point feature.
IConvertSolidFeatureData	Allows access to a convert solid feature.
ICoordinateSystemElement	Allows access to a coordinate system element.
ICoordinateSystemFeatureData	Allows access to a coordinate system feature.
ICoreFeatureData	Allows access to a core feature.
ICornerManagementFolder	Allows access to a corner management folder in a structure system.
ICornerMember	Allows access to a corner member of a complex or two member structure system corner treatment feature.
ICornerReliefFeatureData	Allows access to sheet metal corner relief feature data.
ICornerTreatmentFeatureData	Allows access to a corner treatment feature of a structure system.
ICornerTreatmentGroupFolder	Allows access to a corner treatment group folder of a structure system.
ICosmeticThreadFeatureData	Allows access to a cosmetic thread feature.
ICosmeticWeldBeadFeatureData	Allows access to a cosmetic weld bead feature.
ICosmeticWeldBeadFolder	Allows access to the properties of cosmetic weld beads.
ICounterboreElementData	Allows access to the data of a counterbore hole element in an Advanced Hole.
ICountersinkElementData	Allows access to the data of a countersink hole element in an Advanced Hole.
ICrossBreakFeatureData	Gets or sets cross break feature data.
ICThread	Allows access to a cosmetic thread.
ICurve	Allows access to a curve and its parameters in their native form or in terms of b-curve data.
ICurveDrivenPatternFeatureData	Allows access to a curve-driven pattern feature.
ICurveParamData	Allows access to curve parameterization data.
ICustomBendAllowance	Allows access to the custom bend allowance of a feature.
ICustomPropertyManager	Allows access to the custom properties.
ICustomSymbol	Obsolete. Superseded by ISketchBlockDefinition and ISketchBlockInstance.
ICutListItem	Allows access to a configuration-specific cut list folder.
ICutListSortOptions	Allows access to cut list sorting options.
IDatumOrigin	Allows access to datum origin annotations.
IDatumTag	Allows access to display information for datum tags.
IDatumTargetSym	Allows access to display information for datum target symbol annotations.
IDecal	Allows access to the decals in models.
IDeleteBodyFeatureData	Allows access to a Body-Delete/Keep feature.
IDeleteFaceFeatureData	Allows access to a DeleteFace feature.
IDerivedPartFeatureData	Allows access to a derived part feature.
IDerivedPatternFeatureData	Allows access to a derived pattern feature.
IDesignTable	Allows access to design table information and values.
IDetailCircle	Allows access to a detail circle.
IDiagnoseResult	Get the gaps and coedges in each gap on this body.
IDimension	Allows you to get and set dimension values and tolerances.
IDimensionSensorData	Allows access to a Measurement (dimension) sensor feature.
IDimensionTolerance	Allows you to get and set dimension tolerances.
IDimPatternFeatureData	Allows access to a variable pattern feature, which uses a table to store the dimensions and values of the pattern instances.
IDimXpertManager	Allows you to get the DimXpert schema for a configuration.
IDisplayData	Allows access to display information for certain items, including reference planes and reference axes shown in a drawing view.
IDisplayDimension	Represents instances of dimensions displayed in parts , assemblies , drawings and sensors .
IDisplayStateSetting	Allows access to display state settings.
IDistanceMateFeatureData	Allows access to a distance mate or a limit distance mate feature.
IDocumentSpecification	Allows you to specify how to open a model document. Use this interface's properties before calling ISldWorks::OpenDoc2 to specify how you want to open a model document.
IDomeFeatureData	Obsolete. Superseded by IDomeFeatureData2

IDomeFeatureData2	Allows access to a dome feature.
IDowelSymbol	Allows access to a dowel symbol.
IDraftFeatureData	Obsolete. Superseded by IDraftFeatureData2.
IDraftFeatureData2	Allows access to a draft feature.
IDragArrowManipulator	Allows access to drag arrows, which are called handles in the SOLIDWORKS Design user interface.
IDragOperator	Allows access to settings for the Move Components command in the SOLIDWORKS Design user-interface.
IDrawingComponent	Represents the referenced component in a drawing view.
IDrawingDoc	Allows access to functions that perform drawing operations.
IDrSection	Allows access to a section view in a drawing.
IDSPBRMaterial	Allows access to Dassault Systemes Physically Based Rendering (DSPBR) material object.
IEdge	Allows access to its defining coedge, and adjacent faces, and its underlying curve and vertices as well as edge data.
IEdgeFlangeFeatureData	Allows access to a sheet metal edge flange feature.
IEdgePoint	Allows access to a midpoint on an edge or an endpoint or midpoint on a reference curve .
IEndCapFeatureData	Allows access to an end-cap feature.
IEntity	Allows access to an attribute instance that is stored on an entity.
IEnumBodies	Obsolete. Superseded by IEnumBodies2.
IEnumBodies2	Allows access to bodies enumeration.
IEnumCoEdges	Allows access to a coedges enumeration.
IEnumComponents	Obsolete. Superseded by IEnumComponents2.
IEnumComponents2	Allows access to a components enumeration.
IEnumDisplayDimensions	Allows access to a display dimensions enumeration.
IEnumDocuments	Obsolete. Superseded by IEnumDocuments2.
IEnumDocuments2	Allows access to a documents enumeration.
IEnumDrSections	Allows access to a section views enumeration.
IEnumEdges	Allows access to an edges enumeration.
IEnumFaces	Obsolete. Superseded by IEnumFaces2.
IEnumFaces2	Allows access to a faces enumeration.
IEnumLoops	Obsolete. Superseded by IEnumLoops2.
IEnumLoops2	Allows access to a loops enumeration.
IEnumModelViews	Allows access to a model views enumeration.
IEnumSketchHatches	Allows access to a sketch hatches enumeration.
IEnumSketchPoints	Allows access to a sketch points enumeration.
IEnumSketchSegments	Allows access to the sketch segments enumeration.
IEnvironment	Allows you to analyze the text and geometry used to create a geometric tolerance symbol.
IEquationMgr	Maintains a list of all of the existing equations in a model.
IExplodeStep	Allows access to an explode step in the explode view of the active assembly configuration.
IExportPdfData	Allows access to the PDF export data interface, which allows you to save: - one or more drawing sheets to PDF. - parts and assemblies to 3D PDF.
IExtrudeFeatureData	Obsolete. Superseded by IExtrudeFeatureData2.
IExtrudeFeatureData2	Allows access to an extrusion feature.
IFace	Obsolete. Superseded by IFace2.
IFace2	Allows access to the underlying edge, loop, and surface to the owning body or feature, and to face tessellation, trim data.
IFaceDecalProperties	Allow access to the properties of decals applied to faces in models.
IFaceHatch	Represents a cross-hatch, which is automatically added by SOLIDWORKS when you create a section view , aligned section view, break view, or detail view .
IFacet	Allows access to a triangular facet of a mesh or graphics body.
IFamilyTableAnnotation	Allows access to the family table annotation.
IFamilyTableFeature	Allows access to the family table feature.
IFaultEntity	Identifies entities with faults and types of faults.
IFeatMgrView	Allows access to a view (tab) in the FeatureManager design tree.
IFeature	Allows access to the feature type, name, parameter data, and the next feature in the FeatureManager design tree.
IFeatureFolder	Allows access to the contents of feature folders in the FeatureManager design tree.
IFeatureManager	Allows you to create features.
IFeatureStatistics	Allows access to the feature statistics in a part document.
IFillPatternFeatureData	Allows access to a fill pattern feature.
IFillSurfaceFeatureData	Allows access to a fill-surface feature.
IFlatPatternFeatureData	Allows access to a Flat-Pattern feature.
IFlatPatternFolder	Allows access to the flat-pattern folder in the FeatureManager design tree.
IFlyoutGroup	Allows access to a flyout menu.
IFoldsFeatureData	Allows access to a fold feature.
IFrame	Allows access to SOLIDWORKS frames, including model windows, menus, and toolbars.
IFreePointCurveFeatureData	Allows access to a curve created using X, Y, Z coordinates for the points.
IGearMateFeatureData	Allows access to gear mate features.
IGeneralTableAnnotation	Allows access to the general table annotation.
IGeneralTableFeature	Allows access to the general table feature.
IGeneralToleranceTableAnnotation	Allows access to the general tolerance table annotation.
IGeneralToleranceTableFeature	Allows access to the general tolerance table feature.
IGraphicsBody	Allows access to a graphics body.
IGroundPlaneFeatureData	Allows access to a ground plane feature.
IGtol	Allows you to get and set geometric tolerance (GTol) parameters.
IGtolFrame	Allows access to indicators and XML strings for symbols in a Gtol feature control frame.
IGussetFeatureData	Allows access to a weldment gusset feature.
IHealEdgesFeatureData	Allows access to a heal edges feature.

IHelixFeatureData	Allows access to a helix feature.
IHemFeatureData	Allows access to a hem feature.
IHingeMateFeatureData	Allows access to a hinge mate feature.
IHoleDataTable	Allows access to Hole Wizard fastener tables.
IHoleSeriesFeatureData	Obsolete. Superseded by IHoleSeriesFeatureData2.
IHoleSeriesFeatureData2	Allows access to the data that defines a hole series feature.
IHoleStandardsData	Allows access to Hole Wizard standards data.
IHoleTable	Allows access to a hole table feature in a drawing document.
IHoleTableAnnotation	Accesses the hole table annotation.
IImport3DInterconnectData	Allows access to 3D Interconnect feature data.
IImportDxfDwgData	Allows you to specify values when importing or inserting DXF/DWG data.
IImportedCurveFeatureData	Allows access to an imported curve feature.
IImportIgesData	Allows you to specify levels and values when importing IGES data.
IImportStepData	Allows you to specify values when importing STEP data.
IIndentFeatureData	Allows access to an indent feature.
IInstanceToVaryOptions	Allows access to options for varying the dimensions and locations of instances in patterns for parts.
IInterference	Allows access to the components that interfere when interference detection is calculated.
IInterferenceDetectionMgr	Allows you to run interference detection on an assembly to determine whether components interfere with each other.
IIntersectFeatureData	Allows access to an intersect feature.
IJogFeatureData	Allows access to a jog feature.
IJoinFeatureData	Allows access to a join feature.
ILayer	Allows access to the properties and items on a layer, including the color, width, name, etc., used to define the layer.
ILayerMgr	Allows you to manage a drawing document's layers.
ILibraryFeatureData	Allows access to library feature data.
ILibraryFormToolFeatureData	Allows access to library forming tool feature data.
ILight	Allows access to the light feature.
ILightDialog	Obtained from a LightingDialogCreateNotify event.
ILinearCouplerMateFeatureData	Allows access to linear/linear coupler mate feature data.
ILinearPatternFeatureData	Allows access to a linear pattern feature.
ILocalCircularPatternFeatureData	Allows access to a circular component pattern feature in an assembly.
ILocalCurvePatternFeatureData	Allows access to a curve-driven component pattern feature in an assembly.
ILocalLinearPatternFeatureData	Allows access to a linear component pattern feature in an assembly.
ILocalSketchPatternFeatureData	Allows access to a sketch-driven component pattern feature in an assembly.
ILockMateFeatureData	Allows access to lock mate features.
ILoftedBendsFeatureData	Allows access to display information for a lofted bends feature.
ILoftFeatureData	Allows access to a loft feature.
ILoop	Obsolete. Superseded by ILoop2.
ILoop2	Allows access to the owning face and to the list of edges and coedges contained in the loop.
IMacroFeatureData	Allows access to the data that defines a macro feature.
IMagneticLine	Allows access to a magnetic line.
IManipulator	Allows access to a manipulator, which is similar to the triad or the drag arrow (also called a handle), in a SOLIDWORKS part or assembly document.
IMassProperty	Obsolete. Superseded by IMassProperty2.
IMassProperty2	Allows access to individual mass properties as found in the Mass Properties dialog box.
IMassPropertyOverrideOptions	Allows access to mass property override options.
IMate	Obsolete. Superseded by IMate2.
IMate2	Allows access to various assembly mate parameters.
IMateControllerFeatureData	Allows access to a mate controller feature.
IMateEntity	Obsolete. Superseded by IMateEntity2.
IMateEntity2	Allows access to mated entities and the assembly mate definition.
IMateFeatureData	Allows access to mate feature data.
IMateInPlace	Allows access to an Inplace (coincident) mate, which is created when you insert a component in the context of an assembly.
IMateLoadReference	Allows access to mate load references.
IMateReference	Allows access to a mate reference, which specifies one or more entities of a component to use for automatic mating.
IMaterialVisualPropertiesData	Allows access to a material on a part.
IMathPoint	Provides a simplified interface for manipulating math-point objects' data and ways to create other math objects.
IMathTransform	Provides a simplified interface for manipulating transformation matrix data.
IMathUtility	Provides access to the SOLIDWORKS math objects. These objects can simplify commonly used math calculations used with many API functions.
IMathVector	Provides a simplified interface for manipulating math vectors.
IMBD3DPdfData	Gains access to the details for publishing a SOLIDWORKS MBD 3D PDF.
IMBDSTEP242Data	Allows access to the details for publishing a SOLIDWORKS MBD 3D STEP242 file.
IMeasure	Allows access to the measure tool.
IMeshBody	Allows access to a mesh body.
IMessageBarDefinition	Allows access to a message bar in an add-in.
IMidSurface	Obsolete. Superseded by IMidSurface3.
IMidSurface2	Obsolete. Superseded by IMidSurface3.
IMidSurface3	Allows access to a midsurface feature.
IMirrorComponentFeatureData	Allows access to a mirror component feature.
IMirrorPartFeatureData	Allows access to a mirror part feature.
IMirrorPatternFeatureData	Allows access to a mirror pattern feature.
IMirrorSolidFeatureData	Allows access to a mirror solid feature.
IMiterFlangeFeatureData	Allows access to a miter flange feature.
IModelDoc	Obsolete. Superseded by IModelDoc2.
IModelDoc2	Allows access to SOLIDWORKS documents: parts, assemblies, and drawings.

IModelDocExtension	Allows access to the model.
IModeler	Provides an interface to temporary body objects.
IModelView	Allows you access to the model view's orientation, translation, and the Microsoft handle to the window.
IModelViewManager	Allows access to the model view.
IModelWindow	Allows access to SOLIDWORKS model windows.
IMotionPlotAxisFeatureData	Allows access to a plot's x- and y-axis feature data.
IMotionPlotFeatureData	Allows access to a plot's feature data.
IMouse	Allows access to the mouse in a model view.
IMoveCopyBodyFeatureData	Allows access to a move/copy body feature.
IMoveFaceFeatureData	Allows access to Move Face features.
IMultiJogLeader	Allows access to display information for multi-jog leaders.
INote	Allows you to get standard note information.
IOneBendFeatureData	Allows access to a bend feature (sharp bend, round bend, or flat bend).
IPackAndGo	Allows access to Pack and Go.
IPageSetup	Allows access to a number of properties related to printer and page setup, including page header and footer information.
IParagraphs	Allows access to paragraphs in note annotations.
IParallelMateFeatureData	Allows access to a parallel mate feature.
IParameter	Allows you to get and set values in an attribute.
IPartDoc	Provides access to functions that perform operations on parts in part documents.
IPartExplodeStep	Allows access to the explode step of an explode view of a multibody part.
IPartialEdgeFilletData	Allows access to partial fillet/chamfer properties.
IPartingLineFeatureData	Allows access to a parting line feature.
IPartingSurfaceFeatureData	Allows access to a parting surface feature.
IPerpendicularMateFeatureData	Allows access to a perpendicular mate feature.
IPlaneManipulator	Allows access to a plane that has a manipulator.
IPLMObjectSpecification	Allows access to a SOLIDWORKS Design connected to the 3DEXPERIENCE platform document specification.
IPMIDatumData	Allows access to the Product and Manufacturing Information (PMI) for a datum annotation in a STEP 242 model.
IPMIDatumFeature	Allows access to a Product and Manufacturing Information (PMI) datum feature.
IPMIDatumTarget	Allows access to a Product and Manufacturing Information (PMI) datum target.
IPMIDimensionData	Allows access to the Product and Manufacturing Information (PMI) for a dimension annotation in a STEP 242 model.
IPMIDimensionItem	Allows access to a Product and Manufacturing Information (PMI) dimension item.
IPMIFrameData	Allows access to a Product and Manufacturing Information (PMI) Gtol frame.
IPMIGtolBoxData	Allows access to a Product and Manufacturing Information (PMI) Gtol tolerance box.
IPMIGtolData	Allows access to the Product and Manufacturing Information (PMI) for a Gtol annotation in a STEP 242 model.
IPMIGtolFrameDatum	Allows access to a Product and Manufacturing Information (PMI) Gtol datum box.
IPrimaryMemberFacePlaneIntersectionFeatureData	Allows access to a structure system member created along the intersection of a face or surface with a plane.
IPrimaryMemberPathSegmentFeatureData	Allows access to a structure system member created along path segments in a sketch.
IPrimaryMemberPointLengthFeatureData	Allows access to a structure system member originating at a point and extending to a specified end condition.
IPrimaryMemberRefPlaneFeatureData	Allows access to a structure system member created along the intersection of two or more planes.
IPrimaryStructuralMemberFeatureData	Allows access to a primary structure system member.
IPrint3DDialog	Allows access to the Print 3D dialog.
IPrintSpecification	Allows access to a document's printing specification.
IProfileCenterMateFeatureData	Allows access to profile center mate feature data.
IProfileGroupFolder	Allows access to a structure system profile group folder.
IProjectionArrow	Allows access to a projection arrow.
IProjectionCurveFeatureData	Allows access to a projection curve feature.
IPropertyManagerPage	Obsolete. Superseded by IPropertyManagerPage2.
IPropertyManagerPage2	Provides add-in applications the ability to display and use views that have the look and feel of SOLIDWORKS PropertyManager pages.
IPropertyManagerPageActiveX	Allows you to access a PropertyManager page ActiveX control.
IPropertyManagerPageBitmap	Allows you to access a PropertyManager page bitmap.
IPropertyManagerPageBitmapButton	Allows you to access a PropertyManager page bitmap button control.
IPropertyManagerPageButton	Allows you to access a PropertyManager page button control.
IPropertyManagerPageCheckbox	Allows you to access a PropertyManager page check box.
IPropertyManagerPageCombobox	Allows you to access a PropertyManager page combo box control.
IPropertyManagerPageControl	Provides a set of methods and properties common to all PropertyManager page controls.
IPropertyManagerPageGroup	Allows you to access a PropertyManager page group control.
IPropertyManagerPageLabel	Allows you to access a PropertyManager page label control.
IPropertyManagerPageListbox	Allows you to access a PropertyManager page list box control.
IPropertyManagerPageNumberbox	Allows you to access a PropertyManager page number box control.
IPropertyManagerPageOption	Allows you to access to a PropertyManager page radio button control.
IPropertyManagerPageSelectionbox	Allows you to access a PropertyManager page selection box control.
IPropertyManagerPageSlider	Allows you to access a PropertyManager page slider control.
IPropertyManagerPageTab	Allows you to access a PropertyManager page tab control.
IPropertyManagerPageTextbox	Allows you to access a PropertyManager page text box control.
IPropertyManagerPageWindowFromHandle	Allows you to access a PropertyManager page .NET control.
IPunchTable	Allows access to punch table information and values.
IPunchTableAnnotation	Allows access to a punch table annotation.
IRackPinionMateFeatureData	Allows access to a rack and pinion mate feature.
IRayTraceRenderer	Allows access to ray-trace rendering engines.
IRayTraceRendererOptions	Allows access to a ray-trace rendering engine's options.
IRefAxis	Allows access to reference axis definitions.
IRefAxisFeatureData	Allows access to reference axis feature data.
IReferenceCurve	Allows access to reference curves.
IReferencePointCurveFeatureData	Allows access to reference-point curve feature data.

IRefPlane	Allows access to reference plane definitions.
IRefPlaneFeatureData	Allows access to reference plane feature data.
IRefPoint	Allows access to reference points.
IRefPointFeatureData	Allows access to reference point feature data.
IRenamedDocumentReferences	Allows you to update references to a renamed file in unopened documents.
IRenderMaterial	Use to apply appearances to models. NOTE: In SOLIDWORKS 2008 and later, materials are called appearances. RealView Graphics must be enabled to see any applied appearances.
IReplaceFaceFeatureData	Allows access to Replace Face feature data.
IRevisionCloud	Allows access to a revision cloud annotation.
IRevisionTableAnnotation	Accesses the revision table annotation.
IRevisionTableFeature	Allows access to the revision table feature.
IRevolveFeatureData	Obsolete. Superseded by IRevolveFeatureData2
IRevolveFeatureData2	Allows access to a revolve feature.
IRibFeatureData	Obsolete. Superseded by IRibFeatureData2
IRibFeatureData2	Allows access to a rib feature.
IRipFeatureData	Allows access to a rip feature.
IRoutingSettings	Allows access to various routing settings including those specified in Tools > Options > System Options > Routing .
IRuledSurfaceFeatureData	Allows access to a ruled-surface feature.
ISafeArrayUtility	Access the ISafeArrayUtility interface, which can: - get an unpacked array of native SOLIDWORKS Dispatch-based objects of the same data type and return a packed Variant SafeArray to use in methods that requires passing a packed Variant SafeArray. - get a packed Variant SafeArray and return an unpacked array of native SOLIDWORKS Dispatch-based objects of the same data type. - get a Variant SafeArray and return the number of SafeArray objects in the Variant SafeArray and their data type. - get and put a value in a Variant SafeArray of the same data type.
ISaveBodyFeatureData	Allows access to a Save Bodies feature.
ISaveTo3DExperienceOptions	Allows access to options for saving a document in SOLIDWORKS Design connected to the 3DEXPERIENCE platform .
IScaleFeatureData	Allows access to a scale feature.
IScrewMateFeatureData	Allows access to a screw mate feature.
ISecondaryMemberBetweenPointsFeatureData	Allows access to a secondary structure system member that is created between the end points on primary structure system member pairs.
ISecondaryMemberSupportPlaneFeatureData	Allows access to a secondary structure system member that is created on a plane between primary structure system member pairs.
ISecondaryMemberUpToMembersFeatureData	Allows access to a secondary structure system up-to member that is created between a selected point and one or more primary structure system members or between one or more point-member pairs.
ISecondaryStructuralMemberFeatureData	Allows access to a secondary structure system member.
ISectionViewData	Allows you to create and access section views in parts and assemblies.
ISelectData	Allows you to select objects.
ISelectionMgr	Allows you to get information about selected objects, obtain API objects representing the selected item, and get your selection coordinates interpreted in model or sketch space.
ISelectionSet	Allows access to a selection set.
ISelectionSetFolder	Allows access to the Selection Sets folder.
ISelectionSetItem	Allows access to a selection set item.
ISensor	Allows access to a sensor, which can monitor selected properties of parts and assemblies and alert you when the sensor's values deviate from the specified limits.
ISFSymbol	Allows access to display information for surface finish symbols.
ISheet	Allows access to a sheet and objects on the sheet such as BOM tables .
ISheetMetalFeatureData	Allows access to a sheet metal feature.
ISheetMetalFolder	Allows access to a sheet metal folder feature in the FeatureManager design tree.
ISheetMetalGaugeTableParameters	Allows access to sheet metal gauge table parameters.
IShellFeatureData	Allows access to a shell feature.
IShutOffSurfaceFeatureData	Allows access to a shut-off surface feature.
ISilhouetteEdge	Allows you to access silhouette edges in drawing documents.
ISimpleCornerTreatmentFeatureData	Allows access to a simple corner treatment feature of a structure system.
ISimpleFilletFeatureData	Obsolete. Superseded by ISimpleFilletFeatureData2
ISimpleFilletFeatureData2	Allows access to a simple fillet feature.
ISimpleHoleFeatureData	Obsolete. Superseded by ISimpleHoleFeatureData2
ISimpleHoleFeatureData2	Allows access to a simple hole feature.
ISimulation	This interface is: - obsolete and has not been superseded. - nonfunctional in SOLIDWORKS 2008 and later. Use the interfaces related to motion studies introduced in SOLIDWORKS 2008 to access animation and simulation.
ISimulation3DContactFeatureData	Allows access to a 3D Contact feature in SOLIDWORKS Motion studies.
ISimulationDamperFeatureData	Allows access to a damper feature in SOLIDWORKS Motion studies.
ISimulationForceFeatureData	Allows access to a force or torque feature in SOLIDWORKS Motion studies.
ISimulationGravityFeatureData	Allows access to a gravity feature in SOLIDWORKS Motion studies.
ISimulationLinearSpringFeatureData	Obsolete. Superseded by ISimulationSpringFeatureData
ISimulationMotorFeatureData	Allows access to the data that defines linear or rotary motors in SOLIDWORKS Motion studies.
ISimulationSpringFeatureData	Allows access to the data that defines a simulation spring feature in SOLIDWORKS Motion studies.
ISketch	Allows access to sketch entities and to extract information about sketch elements, the sketch orientation, and so on.
ISketchArc	Provides access to properties and methods for sketched arc entities.
ISketchBlockDefinition	Allows access to information about a block definition.
ISketchBlockInstance	Allows access to block instances.

ISketchContour	Provides access to sketch contours.
ISketchBendFeatureData	Allows access to a sheet metal sketched bend feature.
ISketchEllipse	Provides access to sketched ellipse entities.
ISketchHatch	Represents an area hatch, which is inserted into a SOLIDWORKS drawing polygon or component face when you click Insert > Annotations > Area Hatch/Fill in a SOLIDWORKS drawing.
ISketchLine	Provides access to sketched line entities.
ISketchManager	Provides access to sketch-creation routines.
ISketchParabola	Provides access to sketched parabolas.
ISketchPath	Provides access to the methods and properties for paths in sketches.
ISketchPatternFeatureData	Allows access to a sketch-driven pattern feature in a part.
ISketchPicture	Provides access to pictures on sketches (i.e., .bmp , .gif , .jpg , .jpeg , .tif , and .wmf).
ISketchPoint	Provides access to sketch point entities.
ISketchRegion	Provides access to sketch regions.
ISketchRelation	Provides access to the entities for a sketch relation.
ISketchRelationManager	Provides access to all sketch relations.
ISketchSegment	Provides access to functions that are common among sketch entities.
ISketchSlot	Accesses a sketch slot.
ISketchSpline	Provides access to sketched spline entities.
ISketchText	Provides access to sketched text entities.
ISldWorks	Provides direct and indirect access to all other interfaces exposed in the SOLIDWORKS API.
ISlicingData	Allows access to slicing tool data.
ISlotMateFeatureData	Allows access to a slot mate feature.
ISmartComponentFeatureData	Allows access to a Smart Component.
ISMCornerReliefData	Allows access to sheet metal corner relief data.
ISMGussetFeatureData	Allows access to a sheet metal gusset feature.
ISMNormalCutFeatureData	Obsolete. Superseded by ISMNormalCutFeatureData2.
ISMNormalCutFeatureData2	Allows access to a sheet metal normal cut feature.
ISMNormalCutGroupData	Allows access to a sheet metal normal cut feature's cut-extrude face group.
ISnapShot	Allows access to the snapshot of the graphics area of an assembly opened in Large Design Review mode.
ISplineHandle	Provides access to spline handles.
ISplineParamData	Allows access to the parameterization data of a spline.
ISplitBodyFeatureData	Allows access to a Split feature.
ISplitLineFeatureData	Allows access to a split line feature.
ISpring	Allows access to the geometry of a spring.
IStackedBalloonOptions	Allows access to stacked balloon options.
IStatusBarPane	Controls user-created status bar panes in the lower-right corner of the SOLIDWORKS status bar.
IStraightElementData	Allows access to the data of a simple hole element in an Advanced Hole.
IStraightTapElementData	Allows access to the data of a straight tap hole element in an Advanced Hole.
IStructuralMemberFeatureData	Allows access to a structural member.
IStructuralMemberGroup	Allows access to a weldment structural-member group.
IStructureSystemFolder	Allows access to a structure system folder.
IStructureSystemMemberFeatureData	Allows access to a structure system member.
IStructureSystemMemberProfile	Allows access to a structure system member profile.
IStructureSystemSplitMember	Allows access to a structure system split member.
ISurface	Used as the underlying definition of a face.
ISurfaceCutFeatureData	Allows access to a surface-cut feature.
ISurfaceExtendFeatureData	Allows access to a surface-extend feature.
ISurfaceFlattenFeatureData	Allows access to a surface-flatten feature.
ISurfaceKnitFeatureData	Allows access to a Surface-Knit feature.
ISurfaceOffsetFeatureData	Allows access to a surface offset feature.
ISurfaceParameterizationData	Allows access to the parameterization data of a surface.
ISurfacePlanarFeatureData	Allows access to a planar surface feature.
ISurfaceRadiateFeatureData	Allows access to a surface radiate feature.
ISurfaceTrimFeatureData	Allows access to a surface trim feature.
ISurfExtrudeFeatureData	Allows access to an extruded surface feature.
ISurfRevolveFeatureData	Allows access to a surface revolve feature.
ISweepFeatureData	Allows access to a sweep feature.
ISweptFlangeFeatureData	Allows access to a sheet metal swept flange feature.
ISwOLEObject	Allows access to an OLE object.
ISwPEClassFactory	Allows access to the callback object used by ISwPEManager to send a license key back to SOLIDWORKS for SOLIDWORKS Partner entitlement verification.
ISwPEToken	*For future use*
ISWPropertySheet	Allows applications to add pages to certain property sheets that are exported by the SOLIDWORKS Design application.
ISwScene	Allows access to the scene of a model.
ISymmetricMateFeatureData	Allows access to symmetry mate feature data.
ITabAndSlotFeatureData	Allows access to a tab and slot feature.
ITabAndSlotGroupData	Allows access to a tab and slot feature group.
ITableAnchor	Allows access to the data that defines a table anchor feature.
ITableAnnotation	Provides access to table annotations.
ITablePatternFeatureData	Allows access to a table-driven pattern feature.
ITangentMateFeatureData	Allows access to a tangent mate feature.
ITaperedTapElementData	Allows access to the data of a tapered tap hole element in an Advanced Hole.
ITaskpaneView	Provides access to an application-level Task Pane.
ITessellation	Used to gather tessellation information from a SOLIDWORKS body.
ITextAndCustomProperty	Gains access to the text and custom properties in a theme of a SOLIDWORKS MBD 3D PDF .
ITextFormat	Allows access to and control of the formatting of text used in annotations.

ITexture	Use to apply 2D textures to part and assembly documents for a more realistic finish.
IThickenFeatureData	Allows access to a thicken feature.
IThreadFeatureData	Allows access to a thread feature.
ITitleBlock	Allows access to the title block in this sheet.
ITitleBlockTableAnnotation	Provides access to title block table annotations.
ITitleBlockTableFeature	Provides access to title block table features.
IToolingSplitFeatureData	Allows access to a tooling-split feature.
ITreeControlItem	Allows you to traverse items in the FeatureManager design tree exactly as they appear in the FeatureManager design tree.
ITriadManipulator	
Allows access to triad manipulators, which are: • Similar to the SOLIDWORKS triad. • Used to move and rotate assembly components, move/copy bodies, and so on.	
ITwoMemberCornerTreatmentFeatureData	Allows access to a two member corner treatment feature of a structure system.
IUniversalJointMateFeatureData	Allows access to a universal joint mate feature.
IUserNotificationDefinition	Allows access to a user notification of an add-in.
IUserProgressBar	Allows access to a progress indicator that indicates how much longer a SOLIDWORKS operation will take.
IUserUnit	Allows you to manage units.
IVariableFilletFeatureData	Obsolete. Superseded by VariableFilletFeatureData2 .
IVariableFilletFeatureData2	Allows access to a variable radius fillet feature.
IVersionCompatibilityItem	Describes a reason a document cannot be saved to the file format of a previous version of SOLIDWORKS.
IVertex	Represents the start or end of an edge .
IView	Represents drawing views found in a drawing document.
IView3D	Allows access to a 3D View of a part or assembly.
IWeldBead	Allows access to weld bead annotations.
IWeldmentBeadFeatureData	Allows access to a weldment bead feature.
IWeldmentCutListAnnotation	Allows access to the annotations in a weldment cut list table.
IWeldmentCutListFeature	Allows access to a weldment cut list feature.
IWeldmentTrimExtendFeatureData	Allows access to the data that defines a weldment trim extend feature.
IWeldSymbol	Allows access to weld symbols.
IWidthMateFeatureData	Allows access to width mate feature data.
IWizardHoleFeatureData	Obsolete. Superseded by IWizardHoleFeatureData2 .
IWizardHoleFeatureData2	Allows access to Hole Wizard hole or slot feature data.
IWrapSketchFeatureData	Allows access to a wrap feature.

Delegates

Delegate	Description
DAssemblyDocEvents_ActiveAnnotationViewChangeNotifyEventHandler	Fired when the user changes the annotation view.
DAssemblyDocEvents_ActiveConfigChangeNotifyEventHandler	Fired when the user switches to a different configuration.
DAssemblyDocEvents_ActiveConfigChangePostNotifyEventHandler	Post-notifies the user program when the user has switched to a different configuration.
DAssemblyDocEvents_ActiveDisplayStateChangePostNotifyEventHandler	Fired after the display state of a configuration is changed or after a configuration is changed.
DAssemblyDocEvents_ActiveDisplayStateChangePreNotifyEventHandler	Fired before the display state of a configuration is changed or before a configuration is changed.
DAssemblyDocEvents_ActiveViewChangeNotifyEventHandler	Fired when the active view changes.
DAssemblyDocEvents_AddCustomPropertyNotifyEventHandler	Post-notifies the user program when the user adds a custom property.
DAssemblyDocEvents_AddDependencyNotifyEventHandler	Fired when the assembly references the specified document for the first time.
DAssemblyDocEvents_AddItemNotifyEventHandler	Notifies the user when a component is added to the FeatureManager design tree.
DAssemblyDocEvents_AddMatePostNotify2EventHandler	Fired after one or more mates are created in an assembly.
DAssemblyDocEvents_AddMatePostNotifyEventHandler	Obsolete. Superseded by DAssemblyDocEvents_AddMatePostNotify2EventHandler .
DAssemblyDocEvents_AssemblyElectricalDataUpdateNotifyEventHandler	Fired when the SOLIDWORKS Design software updates the electrical data.
DAssemblyDocEvents_AutoSaveNotifyEventHandler	Fired when the assembly document is automatically saved.
DAssemblyDocEvents_AutoSaveToStorageNotifyEventHandler	Fired when the assembly document is automatically saved to third-party IStream storage.
DAssemblyDocEvents_AutoSaveToStorageStoreNotifyEventHandler	Fired when the assembly document is automatically saved to third-party IStorage storage.
DAssemblyDocEvents_BeginInContextEditNotifyEventHandler	Notifies the application that the user is starting to edit an assembly component within the context of the assembly (inside the assembly document window).
DAssemblyDocEvents_BodyVisibleChangeNotifyEventHandler	Notifies the application that the visible state of a body within this assembly has changed.
DAssemblyDocEvents_ChangeCustomPropertyNotifyEventHandler	Post-notifies the user program when the user has changed a custom property.
DAssemblyDocEvents_ClearSelectionsNotifyEventHandler	Notifies the user program when selections are cleared using Clear Selections .
DAssemblyDocEvents_CloseDesignTableNotifyEventHandler	Pre-notifies your application that a design table that was being edited is about to be closed.
DAssemblyDocEvents_CommandManagerTabActivatedPreNotifyEventHandler	Pre-notifies you that a SOLIDWORKS CommandManager tab is about to be activated.
DAssemblyDocEvents_ComponentConfigurationChangeNotifyEventHandler	Fired when a reference component's configuration is being changed in an assembly.
DAssemblyDocEvents_ComponentDisplayModeChangePostNotifyEventHandler	Fired after a reference component's display mode is changed in an assembly.
DAssemblyDocEvents_ComponentDisplayModeChangePreNotifyEventHandler	Fired before a reference component's display mode is changed in an assembly.
DAssemblyDocEvents_ComponentDisplayStateChangeNotifyEventHandler	Fired when the display state, such as shaded, wireframe, and so on, of a component is changed.
DAssemblyDocEvents_ComponentMoveNotify2EventHandler	Post-notification that is sent when a user releases the mouse button indicating that the components have been moved to the desired destination.
DAssemblyDocEvents_ComponentMoveNotifyEventHandler	Obsolete. Superseded by DAssemblyDocEvents_ComponentMoveNotify2EventHandler2
DAssemblyDocEvents_ComponentReferredDisplayStateChangeNotifyEventHandler	Fired when a component's referenced display state changes.
DAssemblyDocEvents_ComponentReorganizeNotifyEventHandler	Fired when one or more components are reorganized in an assembly or sub-assembly.
DAssemblyDocEvents_ComponentStateChangeNotify2EventHandler	Obsolete. Superseded by DAssemblyDocEvents_ComponentStateChangeNotify3EventHandler
DAssemblyDocEvents_ComponentStateChangeNotify3EventHandler	Fired whenever the state of a component within this assembly changes.
DAssemblyDocEvents_ComponentStateChangeNotifyEventHandler	Obsolete. Superseded by DAssemblyDocEvents_ComponentStateChangeNotify2EventHandler .
DAssemblyDocEvents_ComponentVisibleChangeNotifyEventHandler	Fired when a component is changed to hidden or shown.
DAssemblyDocEvents_ComponentVisualPropertiesChangeNotifyEventHandler	Fired when a visual property, such as color, transparency, and so on, of a component is changed.
DAssemblyDocEvents_ConfigurationChangeNotifyEventHandler	Gets information about an object or feature that has had one of its configurable parameters changed.
DAssemblyDocEvents_DeleteCustomPropertyNotifyEventHandler	Post-notifies the user program when the user deletes a custom property.

DAssemblyDocEvents_DeleteDependencyNotifyEventHandler	Fired when the assembly no longer references the specified document.
DAssemblyDocEvents_DeletetItemNotifyEventHandler	Notifies the user program when an item is deleted from one of the SOLIDWORKS Design tree structures (for example, the FeatureManager design tree or the ConfigurationManager tree).
DAssemblyDocEvents_DeletetItemPreNotifyEventHandler	Notifies the user program when an item is about to be deleted from one of the SOLIDWORKS tree structures (for example, the FeatureManager design tree or the ConfigurationManager tree).
DAssemblyDocEvents_DeleteSelectionPreNotifyEventHandler	Pre-notifies the user program when the selection is deleted.
DAssemblyDocEvents_DestroyNotify2EventHandler	Pre-notifies the user program when an assembly document is about to be destroyed.
DAssemblyDocEvents_DestroyNotifyEventHandler	Obsolete. Superseded by DAssemblyDocEvents_DestroyNotify2EventHandler.
DAssemblyDocEvents_DimensionChangeNotifyEventHandler	Fired when a dimension is changed through the Dimension dialog.
DAssemblyDocEvents_DisplayPaneCollapseNotifyEventHandler	Fired when the display pane collapses in this assembly.
DAssemblyDocEvents_DisplayPaneExpandNotifyEventHandler	Fired when the display pane expands in this assembly.
DAssemblyDocEvents_DragStateChangeNotifyEventHandler	Fired when starting or stopping the dragging of an Instant3D manipulator.
DAssemblyDocEvents_DynamicHighlightNotifyEventHandler	Post-notifies the application when dynamic highlighting of the selected object changes from on to off, and vice versa.
DAssemblyDocEvents_EndInContextEditNotifyEventHandler	Notifies the application that the user is done editing an assembly component within the context of the assembly (inside the assembly document window).
DAssemblyDocEvents_EquationEditorPostNotifyEventHandler	Notifies your application that the equation editor is being destroyed.
DAssemblyDocEvents_EquationEditorPreNotifyEventHandler	Notifies your application that the equation editor has been constructed.
DAssemblyDocEvents_FeatureEditPreNotifyEventHandler	Pre-notifies the user program when the user edits the definition of a selected feature.
DAssemblyDocEvents_FeatureManagerFilterStringChangeNotifyEventHandler	Fired when text is typed in the FeatureManager design tree filter or IModelDocExtension::FeatureManagerFilterString is called.
DAssemblyDocEvents_FeatureManagerTabActivatedNotifyEventHandler	Fired when the active tab in the Manager Pane changes.
DAssemblyDocEvents_FeatureManagerTabActivatedPreNotifyEventHandler	Fired before the active tab in the Manager Pane changes.
DAssemblyDocEvents_FeatureManagerTreeRebuildNotifyEventHandler	Post-notifies the user program when the active document's FeatureManager design tree is being rebuilt.
DAssemblyDocEvents_FeatureSketchEditPreNotifyEventHandler	Pre-notifies the user program when the user edits the definition of a sketch.
DAssemblyDocEvents_FileDropNotifyEventHandler	Fired when a part is dropped from File Explorer into an assembly.
DAssemblyDocEvents_FileDropPostNotifyEventHandler	Post-notifies user applications when a part is dropped from File Explorer into an assembly.
DAssemblyDocEvents_FileDropPreNotifyEventHandler	Pre-notifies user applications before a part is dropped from File Explorer into an assembly document.
DAssemblyDocEvents_FileReloadCancelNotifyEventHandler	Fired if the IAssembly event FileReloadNotify is canceled.
DAssemblyDocEvents_FileReloadNotifyEventHandler	Post-notifies the user program when an assembly document is reloaded.
DAssemblyDocEvents_FileReloadPreNotifyEventHandler	Pre-notifies the user program when an assembly document is reloaded.
DAssemblyDocEvents_FileSaveAsNotify2EventHandler	Pre-notifies the user program when a file is about to be saved with a new name and passes the new document name. This event is sent before SOLIDWORKS Design displays the File Save dialog.
DAssemblyDocEvents_FileSaveAsNotifyEventHandler	Obsolete. Superseded by DAssemblyDocEvents_FileSaveAsNotify2EventHandler.
DAssemblyDocEvents_FileSaveNotifyEventHandler	Pre-notifies the user program when a file is about to be saved and passes the current document name.
DAssemblyDocEvents_FileSavePostCancelNotifyEventHandler	Fired if FileSavePostNotify is not fired.
DAssemblyDocEvents_FileSavePostNotifyEventHandler	Post-notifies the user program when a file is saved in SOLIDWORKS Design.
DAssemblyDocEvents_FlipLoopNotifyEventHandler	Notifies your program when a loop flips.
DAssemblyDocEvents_InsertTableNotifyEventHandler	Notifies your program when a table has been inserted in an assembly.
DAssemblyDocEvents_InterferenceNotifyEventHandler	Notifies your program about an interference between parts in the assembly during the Move/Rotate Component command.
DAssemblyDocEvents_LargeDesignReviewStateChangeNotifyEventHandler	Fired when the Large Design Review state changes in this assembly.
DAssemblyDocEvents_LightingDialogCreateNotifyEventHandler	Fired when a lighting dialog has been opened by the user.
DAssemblyDocEvents_LoadFromStorageNotifyEventHandler	Fired when it is safe to load data from third-party IStream storage.
DAssemblyDocEvents_LoadFromStorageStoreNotifyEventHandler	Fired when it is safe to load data from third-party IStorage storage.
DAssemblyDocEvents_ModifyNotifyEventHandler	Fired when a document is marked dirty for the first time.
DAssemblyDocEvents_ModifyTableNotifyEventHandler	Notifies your program when a table has been modified in an assembly.
DAssemblyDocEvents_NewSelectionNotifyEventHandler	Post-notifies the user program when the selection list has changed.
DAssemblyDocEvents_OpenDesignTableNotifyEventHandler	Post-notifies your application that a design table has been opened for editing.
DAssemblyDocEvents_PreRenameItemNotifyEventHandler	Fired when a component document in an assembly is about to be renamed.
DAssemblyDocEvents_PromptBodiesToKeepNotifyEventHandler	Generated when a body is cut into multiple bodies.
DAssemblyDocEvents_PublishTo3DPDFNotifyEventHandler	Fired when publishing an assembly document to SOLIDWORKS MBD 3D PDF.
DAssemblyDocEvents_RedoPostNotifyEventHandler	Fired after a Redo operation occurs in an assembly document.
DAssemblyDocEvents_RedoPreNotifyEventHandler	Fired before a Redo operation occurs in an assembly document.
DAssemblyDocEvents_RegenNotifyEventHandler	Pre-notifies the user program when an assembly document is about to be rebuilt.
DAssemblyDocEvents_RegenPostNotify2EventHandler	Post-notifies the user program when an assembly document is rebuilt.
DAssemblyDocEvents_RegenPostNotifyEventHandler	Obsolete. Superseded by DAssemblyDocEvents_RegenPostNotify2EventHandler.
DAssemblyDocEvents_RenamedDocumentNotifyEventHandler	Fired when saving an assembly document in which a renamed component file is referenced by other assembly documents.
DAssemblyDocEvents_RenameDisplayTitleNotifyEventHandler	Fired when the display title changes for an item in the FeatureManager design tree.
DAssemblyDocEvents_RenameItemNotifyEventHandler	Fired when an item is renamed in one of the SOLIDWORKS Design tree structures, such as the FeatureManager design tree or the ConfigurationManager tree.
DAssemblyDocEvents_SaveToStorageNotifyEventHandler	Fired when it is safe to save data to third-party IStream storage.
DAssemblyDocEvents_SaveToStorageStoreNotifyEventHandler	Fired when it is safe to save data to third-party IStorage storage.
DAssemblyDocEvents_SelectiveOpenPostNotifyEventHandler	Post-notifies the user program when assembly components are selected for Quick View/Selective Open.
DAssemblyDocEvents_SensorAlertPreNotifyEventHandler	Fired before a sensor's value deviates from its limits in an assembly document.
DAssemblyDocEvents_SketchSolveNotifyEventHandler	Fired whenever the sketch is solved, for example, when dragging a sketch entity, adding or editing relations, changing dimensions, and so on.
DAssemblyDocEvents_SolidBodyFolderReorderNotifyEventHandler	Fired with a solid body folder is reordered, e.g., using IModelDocExtension::ReorderFeature2 .
DAssemblyDocEvents_SuppressionStateChangeNotifyEventHandler	Fired when the suppression state of a feature changes.
DAssemblyDocEvents_UndoPostNotifyEventHandler	Fired after an Undo operation occurs in an assembly document.
DAssemblyDocEvents_UndoPreNotifyEventHandler	Fired before an Undo operation occurs in an assembly document.
DAssemblyDocEvents_UnitsChangeNotifyEventHandler	Fired when the document units change.
DAssemblyDocEvents_UserSelectionPostNotifyEventHandler	Fired after an entity is selected in an assembly document.
DAssemblyDocEvents_UserSelectionPreNotifyEventHandler	Fired when an interactive user moves the cursor over or clicks a model view in an assembly document.
DAssemblyDocEvents_ViewNewNotify2EventHandler	Post-notifies the user program when a new view model window has been created.
DAssemblyDocEvents_ViewNewNotifyEventHandler	Obsolete. Superseded by DAssemblyDocEvents_ViewNewNotify2EventHandler

DDrawingDocEvents_ActivateSheetPostNotifyEventHandler	Notifies the user program after activating the drawing sheet.
DDrawingDocEvents_ActivateSheetPreNotifyEventHandler	Notifies the user program before activating the drawing sheet.
DDrawingDocEvents_ActiveConfigChangeNotifyEventHandler	Pre-notifies the user program when the user is about to switch to a different configuration.
DDrawingDocEvents_ActiveConfigChangePostNotifyEventHandler	Post-notifies the user program when the user has switched to a different configuration.
DDrawingDocEvents_AddCustomPropertyNotifyEventHandler	Post-notifies the user program when the user has added a custom property.
DDrawingDocEvents_AddDependencyNotifyEventHandler	Fired when the drawing references the specified document for the first time.
DDrawingDocEvents_AddItemNotifyEventHandler	Notifies the user program when an item is added to one of the SOLIDWORKS tree structures (for example, FeatureManager design tree, ConfigurationManager tree, and so on).
DDrawingDocEvents_AutoSaveNotifyEventHandler	Fired when the drawing document is automatically saved.
DDrawingDocEvents_AutoSaveToStorageNotifyEventHandler	Fired when the drawing document is automatically saved to third-party IStream storage.
DDrawingDocEvents_AutoSaveToStorageStoreNotifyEventHandler	Fired when the drawing document is automatically saved to third-party IStorage storage.
DDrawingDocEvents_ChangeCustomPropertyNotifyEventHandler	Post-notifies the user program when the user has changed a custom property.
DDrawingDocEvents_ClearSelectionsNotifyEventHandler	Notifies the user program when selections are cleared using Clear Selections .
DDrawingDocEvents_CommandManagerTabActivatedPreNotifyEventHandler	Pre-notifies you that a SOLIDWORKS CommandManager tab is about to be activated.
DDrawingDocEvents_DeleteCustomPropertyNotifyEventHandler	Post-notifies the user program when the user deletes a custom property.
DDrawingDocEvents_DeleteDependencyNotifyEventHandler	Fired when the drawing no longer references the specified document.
DDrawingDocEvents_DeleteItemNotifyEventHandler	Notifies the user program when an item is deleted from one of the SOLIDWORKS tree structures (for example, the FeatureManager design tree or the ConfigurationManager tree).
DDrawingDocEvents_DeleteItemPreNotifyEventHandler	Notifies the user program when an item is about to be deleted from one of the SOLIDWORKS tree structures (for example, the FeatureManager design tree or the ConfigurationManager tree).
DDrawingDocEvents_DeleteSelectionPreNotifyEventHandler	Pre-notifies the user program when the selection is deleted.
DDrawingDocEvents_DestroyNotify2EventHandler	Pre-notifies the user program when a drawing document is about to be destroyed.
DDrawingDocEvents_DestroyNotifyEventHandler	Obsolete. Superseded by DDrawingDocEvents_DestroyNotify2EventHandler.
DDrawingDocEvents_DimensionChangeNotifyEventHandler	Fired when a dimension is changed through the Dimension dialog.
DDrawingDocEvents_DisplayPaneCollapseNotifyEventHandler	Fired when a display pane is collapsed in this drawing.
DDrawingDocEvents_DisplayPaneExpandNotifyEventHandler	Fired when a display pane is expanded in this drawing.
DDrawingDocEvents_DrawingStateChangeNotifyEventHandler	Fired when a drawing's state changes.
DDrawingDocEvents_DynamicHighlightNotifyEventHandler	Post-notifies the application when dynamic highlighting of the selected object changes from on to off, and vice versa.
DDrawingDocEvents_EquationEditorPostNotifyEventHandler	Notifies your application that the equation editor is being destroyed.
DDrawingDocEvents_EquationEditorPreNotifyEventHandler	Notifies your application that an equation editor has been constructed.
DDrawingDocEvents_FeatureManagerTabActivatedNotifyEventHandler	Fired when the active tab in the Manager Pane changes.
DDrawingDocEvents_FeatureManagerTabActivatedPreNotifyEventHandler	Fired before the active tab in the Manager Pane changes.
DDrawingDocEvents_FeatureManagerTreeRebuildNotifyEventHandler	Post-notifies the user program when the active document's FeatureManager design tree is being rebuilt.
DDrawingDocEvents_FileReloadPreNotifyEventHandler	Pre-notifies the user application when a drawing document is reloaded.
DDrawingDocEvents_FileSaveAsNotify2EventHandler	Sends pre-notification before displaying the File, Save dialog.
DDrawingDocEvents_FileSaveAsNotifyEventHandler	Obsolete. Superseded by DDrawingDocEvents_FileSaveAsNotify2EventHandler.
DDrawingDocEvents_FileSaveNotifyEventHandler	Pre-notifies the user program when a file is about to be saved and passes the current document name.
DDrawingDocEvents_FileSavePostCancelNotifyEventHandler	Fired if FileSavePostNotify is not fired.
DDrawingDocEvents_FileSavePostNotifyEventHandler	Post-notifies the user program when a drawing is saved in SOLIDWORKS.
DDrawingDocEvents_InsertTableNotifyEventHandler	Notifies your program when a table has been inserted in a drawing.
DDrawingDocEvents_LoadFromStorageNotifyEventHandler	Fired when it is safe to load data from third-party IStream storage.
DDrawingDocEvents_LoadFromStorageStoreNotifyEventHandler	Fired when it is safe to load data from third-party IStorage storage.
DDrawingDocEvents_ModifyNotifyEventHandler	Fired when a document is marked as dirty for the first time.
DDrawingDocEvents_ModifyTableNotifyEventHandler	Notifies your program when a table has been modified in a drawing.
DDrawingDocEvents_NewSelectionNotifyEventHandler	Post-notifies the user program when the selection list has changed.
DDrawingDocEvents_RedoPostNotifyEventHandler	Fired after a Redo operation occurs in a drawing document.
DDrawingDocEvents_RedoPreNotifyEventHandler	Fired before a Redo operation occurs in a drawing document.
DDrawingDocEvents_RegenNotifyEventHandler	Pre-notifies the user program when a drawing document is about to be regenerated.
DDrawingDocEvents_RegenPostNotifyEventHandler	Post-notifies the user program when a drawing document has been regenerated.

DDrawingDocEvents_RenameDisplayTitleNotifyEventHandler	Notifies the user program when the display title changes for an item in the FeatureManager design tree.
DDrawingDocEvents_RenameItemNotifyEventHandler	Notifies the user program when an item is renamed in one of the SOLIDWORKS tree structures (for example, such as the FeatureManager design tree or the ConfigurationManager tree).
DDrawingDocEvents_SaveToStorageNotifyEventHandler	Fired when it is safe to save data to third-party IStream storage.
DDrawingDocEvents_SaveToStorageStoreNotifyEventHandler	Fired when it is safe to save data to third-party IStorage storage.
DDrawingDocEvents_SketchSolveNotifyEventHandler	Fired whenever the sketch is solved; for example, when dragging a sketch entity, adding or editing relations, changing dimensions, and so on. This event returns the name of the sketch feature being updated.
DDrawingDocEvents_UndoPostNotifyEventHandler	Fired after an Undo action occurs in a drawing document.
DDrawingDocEvents_UndoPreNotifyEventHandler	Fired before an Undo action occurs in a drawing document.
DDrawingDocEvents_UnitsChangeNotifyEventHandler	Raised when document units change.
DDrawingDocEvents_UserSelectionPostNotifyEventHandler	Fired after an entity is selected in a drawing document.
DDrawingDocEvents_UserSelectionPreNotifyEventHandler	Fired when an interactive user moves the cursor over or clicks a drawing view in a drawing document.
DDrawingDocEvents_ViewCreatePreNotifyEventHandler	Pre-notifies the user application when a drawing view is about to be created.
DDrawingDocEvents_ViewNewNotify2EventHandler	Post-notifies the user program when a new view window is created.
DDrawingDocEvents_ViewNewNotifyEventHandler	Obsolete. Superseded by DDrawingDocEvents_ViewNewNotify2EventHandler .
DDrawingDocEvents_ViewPositionChangeNotifyEventHandler	Post-notifies the user program when a drawing view changes position.
DFeatMgrViewEvents_ActivateNotifyEventHandler	Post-notifies the user program once a FeatureManager design tree view is activated and returns the view handle.
DFeatMgrViewEvents_DeactivateNotifyEventHandler	Post-notifies the user program once a FeatureManager design tree view is deactivated and returns the view handle.
DFeatMgrViewEvents_DestroyNotifyEventHandler	Pre-notifies the user program when a FeatureManager design tree view is about to be destroyed and returns the view handle.
DModelViewEvents_BufferSwapNotifyEventHandler	Fired from the model view immediately before the buffers are swapped when rendering shaded graphics in OpenGL.
DModelViewEvents_DestroyNotify2EventHandler	Pre-notifies the user program when a model view is about to be destroyed.
DModelViewEvents_DestroyNotifyEventHandler	Obsolete. Superseded by DModelViewEvents_DestroyNotify2EventHandler .
DModelViewEvents_DisplayModeChangePostNotifyEventHandler	Post-notifies the user program when a model view display mode is changed.
DModelViewEvents_DisplayModeChangePreNotifyEventHandler	Pre-notifies the user program when a model view display mode is about to be changed.
DModelViewEvents_GraphicsRenderPostNotifyEventHandler	Fired after all SOLIDWORKS graphics are drawn, including SOLIDWORKS model, sketch, dimension, and annotation graphics.
DModelViewEvents_PerspectiveViewNotifyEventHandler	Post-notifies the user program when the perspective view is changed (for example, if the user rotates the perspective view).
DModelViewEvents_PrintNotify2EventHandler	Notifies the user program when a document is printed.
DModelViewEvents_PrintNotifyEventHandler	Obsolete. Superseded by DModelViewEvents_PrintNotify2EventHandler .
DModelViewEvents_RenderLayer0NotifyEventHandler	Fired whenever SOLIDWORKS renders to Layer0.
DModelViewEvents_RepaintNotifyEventHandler	Pre-notifies the user program when a view is about to be repainted and returns the paint type.
DModelViewEvents_RepaintPostNotifyEventHandler	Post-notifies the user program when a view has been repainted.
DModelViewEvents_UserClearSelectionsNotifyEventHandler	Fired when a user: 1. Clicks the right-mouse button when the pointer is over a selection box on a PropertyManager page. 2. Selects Clear Selections on the short-cut menu.
DModelViewEvents_ViewChangeNotifyEventHandler	Post-notifies the user program when a view is altered and returns the new transform matrix of the view.
DMouseEvents_MouseLBtnDbClickNotifyEventHandler	Fired when the left-mouse button is double-clicked.
DMouseEvents_MouseLBtnDownNotifyEventHandler	Fired when the left-mouse button is pressed down.
DMouseEvents_MouseLBtnUpNotifyEventHandler	Fired when the left-mouse button is released after being pressed.
DMouseEvents_MouseMBtnDbClickNotifyEventHandler	Fired when the middle-mouse button is double-clicked.
DMouseEvents_MouseMBtnDownNotifyEventHandler	Fired when the middle-mouse button is pressed down.
DMouseEvents_MouseMBtnUpNotifyEventHandler	Fired when the middle-mouse button is released after being pressed.
DMouseEvents_MouseMoveNotifyEventHandler	Fired when the mouse pointer is moved.
DMouseEvents_MouseNotifyEventHandler	Fired whenever a mouse event occurs.
DMouseEvents_MouseRBtnDbClickNotifyEventHandler	Fired when the right-mouse button is double-clicked.
DMouseEvents_MouseRBtnDownNotifyEventHandler	Fired when the right-mouse button is pressed down.
DMouseEvents_MouseRBtnUpNotifyEventHandler	Fired when the right-mouse button is released after being pressed down.
DMouseEvents_MouseSelectNotifyEventHandler	Fired when the user makes a selection in the model view using the mouse.

DPartDocEvents_ActiveAnnotationViewChangeNotifyEventHandler	Fired when the user changes the annotation view.
DPartDocEvents_ActiveConfigChangeNotifyEventHandler	Fired with the user switches to a different configuration.
DPartDocEvents_ActiveConfigChangePostNotifyEventHandler	Post-notifies the user program when the user has switched to a different configuration.
DPartDocEvents_ActiveDisplayStateChangePostNotifyEventHandler	Fired after the display state of a configuration is changed or after a configuration is changed.
DPartDocEvents_ActiveDisplayStateChangePreNotifyEventHandler	Fired before the display state of a configuration is changed or before a configuration is changed.
DPartDocEvents_ActiveViewChangeNotifyEventHandler	Fired when the active view changes.
DPartDocEvents_AddCustomPropertyNotifyEventHandler	Post-notifies the user program when the user has added a custom property.
DPartDocEvents_AddDependencyNotifyEventHandler	Fired when the part references the specified document for the first time.
DPartDocEvents_AddItemNotifyEventHandler	Fired when an item is added to one of the SOLIDWORKS tree structures such as the FeatureManager design tree and the ConfigurationManager.
DPartDocEvents_AutoSaveNotifyEventHandler	Fired when the part document is automatically saved.
DPartDocEvents_AutoSaveToStorageNotifyEventHandler	Fired when the part document is automatically saved to third-party IStream storage.
DPartDocEvents_AutoSaveToStorageStoreNotifyEventHandler	Fired when the part document is automatically saved to third-party IStorage storage.
DPartDocEvents_BodyVisibleChangeNotifyEventHandler	Fired whenever the visible state of a body within this part changes.
DPartDocEvents_ChangeCustomPropertyNotifyEventHandler	Post-notifies the user program when the user has changed a custom property.
DPartDocEvents_ClearSelectionsNotifyEventHandler	Notifies the user program when selections are cleared using Clear Selections .
DPartDocEvents_CloseDesignTableNotifyEventHandler	Pre-notifies your application that a design table that was opened for editing is about to be closed.
DPartDocEvents_CommandManagerTabActivatedPreNotifyEventHandler	Pre-notifies you that a SOLIDWORKS CommandManager tab is about to be activated.
DPartDocEvents_ConfigurationChangeNotifyEventHandler	Gets information about an object or feature that has had one if its configurable parameters changed.
DPartDocEvents_ConvertToBodiesPostNotifyEventHandler	Fired after the Convert to Bodies dialog closes.
DPartDocEvents_ConvertToBodiesPreNotifyEventHandler	Fired before the Convert to Bodies dialog opens.
DPartDocEvents_DeleteCustomPropertyNotifyEventHandler	Post-notifies the user program when the user has deleted a custom property.
DPartDocEvents_DeleteDependencyNotifyEventHandler	Fired when the part no longer references the specified document.
DPartDocEvents_DeleteItemNotifyEventHandler	Notifies the user program when an item is deleted from one of the SOLIDWORKS tree structures, such as the FeatureManager design tree and the ConfigurationManager.
DPartDocEvents_DeleteItemPreNotifyEventHandler	Notifies the user program when an item is about to be deleted from one of the SOLIDWORKS tree structures, such as the FeatureManager design tree and the ConfigurationManager.
DPartDocEvents_DeleteSelectionPreNotifyEventHandler	Pre-notifies the user when the selection is deleted.
DPartDocEvents_DestroyNotify2EventHandler	Pre-notifies the user program when a part document is about to be destroyed.
DPartDocEvents_DestroyNotifyEventHandler	Obsolete. Superseded by DPartDocEvents_DestroyNotify2EventHandler.
DPartDocEvents_DimensionChangeNotifyEventHandler	Fired when a dimension is changed through the Dimension dialog.
DPartDocEvents_DisplayPaneCollapseNotifyEventHandler	Fired when the Display Pane collapses in this part.
DPartDocEvents_DisplayPaneExpandNotifyEventHandler	Fired when the Display Pane expands in this part.
DPartDocEvents_DragStateChangeNotifyEventHandler	Fired when starting or stopping the dragging of an Instant3D manipulator.
DPartDocEvents_DynamicHighlightNotifyEventHandler	Post-notifies the application when dynamic highlighting of the selected object changes from on to off, and vice versa.
DPartDocEvents_EquationEditorPostNotifyEventHandler	Notifies your application that the equation editor is being destroyed.
DPartDocEvents_EquationEditorPreNotifyEventHandler	Notifies your application that an the equation editor has been constructed.
DPartDocEvents_FeatureEditPreNotifyEventHandler	Pre-notifies the user program when the user edits the definition of a selected feature.
DPartDocEvents_FeatureManagerFilterStringChangeNotifyEventHandler	Fired when text is typed in the FeatureManager design tree filter or IModelDocExtension::FeatureManagerFilterString is called.
DPartDocEvents_FeatureManagerTabActivatedNotifyEventHandler	Fired when the active tab changes in the Manager Pane.
DPartDocEvents_FeatureManagerTabActivatedPreNotifyEventHandler	Fired before the active tab in the Manager Pane changes.
DPartDocEvents_FeatureManagerTreeRebuildNotifyEventHandler	Post-notifies the user program when the active document's FeatureManager design tree is being rebuilt.
DPartDocEvents_FeatureSketchEditPreNotifyEventHandler	Pre-notifies the user program when the user edits the definition of a sketch.
DPartDocEvents_FileDropPostNotifyEventHandler	Post-notifies user applications when a part is dropped from File Explorer into a part document.
DPartDocEvents_FileDropPreNotifyEventHandler	Pre-notifies user applications before a part is dropped from File Explorer into a part document.
DPartDocEvents_FileReloadCancelNotifyEventHandler	Fired if FileReloadNotify is canceled.
DPartDocEvents_FileReloadNotifyEventHandler	Post-notifies the user program when a part document is reloaded.
DPartDocEvents_FileReloadPreNotifyEventHandler	Pre-notifies the user program when an part document is reloaded
DPartDocEvents_FileSaveAsNotify2EventHandler	Sends pre-notification before displaying the File, Save dialog.
DPartDocEvents_FileSaveAsNotifyEventHandler	Obsolete. Superseded by DPartDocEvents_FileSaveAsNotify2EventHandler.
DPartDocEvents_FileSaveNotifyEventHandler	Pre-notifies the user program when a file is about to be saved and passes the current document name.
DPartDocEvents_FileSavePostNotifyEventHandler	Fired if FileSavePostNotify is not fired.
DPartDocEvents_FileSavePostNotifyEventHandler	Post-notifies the user program when a part document is saved.
DPartDocEvents_FlipLoopNotifyEventHandler	Fired when a loop is flipped.
DPartDocEvents_InsertTableNotifyEventHandler	Notifies your program when a table has been inserted in a part.
DPartDocEvents_LightingDialogCreateNotifyEventHandler	Fired when a lighting dialog has been opened by the user.
DPartDocEvents_LoadFromStorageNotifyEventHandler	Fired when it is safe to load data from third-party IStream storage.
DPartDocEvents_LoadFromStorageStoreNotifyEventHandler	Fired when it is safe to load data from third-party IStorage storage.
DPartDocEvents_ModifyNotifyEventHandler	Notifies the user program when a document is marked as dirty for the first time.
DPartDocEvents_ModifyTableNotifyEventHandler	Notifies your program when a table has been modified in a part.
DPartDocEvents_NewSelectionNotifyEventHandler	Post-notifies the user program when the selection list has changed.
DPartDocEvents_OpenDesignTableNotifyEventHandler	Post-notifies your application that a design table has been opened for editing.
DPartDocEvents_PreRenameItemNotifyEventHandler	Fired when a part document referenced by other documents is about to be renamed.
DPartDocEvents_PromptBodiesToKeepNotifyEventHandler	Generated when a body is cut into multiple bodies.
DPartDocEvents_PublishTo3DPDFNotifyEventHandler	Fired when publishing a part document to SOLIDWORKS MBD 3D PDF.
DPartDocEvents_RedoPostNotifyEventHandler	Fired after a Redo operation occurs in a part document.
DPartDocEvents_RedoPreNotifyEventHandler	Fired before a Redo operation occurs in a part document.
DPartDocEvents_RegenNotifyEventHandler	Pre-notifies the user program when a part document is about to be rebuilt.

DPartDocEvents_RegenPostNotify2EventHandler	Post-notifies the user program when a part document has been rebuilt or rolled back.
DPartDocEvents_RegenPostNotifyEventHandler	Obsolete. Superseded by DPartDocEvents_RegenPostNotify2EventHandler .
DPartDocEvents_RenamedDocumentNotifyEventHandler	Fired when saving a document in which a renamed part file is referenced by other documents.
DPartDocEvents_RenameDisplayTitleNotifyEventHandler	Fired when the display title is changed for an item in the FeatureManager design tree.
DPartDocEvents_RenameItemNotifyEventHandler	Fired when an item is renamed in one of the SOLIDWORKS tree structures, such as the FeatureManager design tree or the ConfigurationManager.
DPartDocEvents_SaveToStorageNotifyEventHandler	Fired when it is safe to save data to third-party IStream storage.
DPartDocEvents_SaveToStorageStoreNotifyEventHandler	Fired when it is safe to save data to third-party IStorage storage.
DPartDocEvents_SensorAlertPreNotifyEventHandler	Fired before a sensor's value deviates from its limits in a part document.
DPartDocEvents_SketchSolveNotifyEventHandler	Fired whenever the sketch is solved; for example, when dragging a sketch entity, adding or editing relations, changing dimensions, and so on. This event returns the name of the sketch feature being updated.
DPartDocEvents_SolidBodyFolderReorderNotifyEventHandler	Fired when a solid body folder is reordered, e.g., using IModelDocExtension::ReorderFeature2 .
DPartDocEvents_SuppressionStateChangeNotifyEventHandler	Fired when the suppression state of a feature changes.
DPartDocEvents_UndoPostNotifyEventHandler	Fired after an Undo action occurs in a part document.
DPartDocEvents_UndoPreNotifyEventHandler	Fired before an Undo operation occurs in a part document.
DPartDocEvents_UnitsChangeNotifyEventHandler	Generated when document units change.
DPartDocEvents_UserSelectionPostNotifyEventHandler	Fired after an entity is selected in a part document.
DPartDocEvents_UserSelectionPreNotifyEventHandler	Fired when an interactive user moves the cursor over or clicks a model view in a part document.
DPartDocEvents_ViewNewNotify2EventHandler	Post-notifies the user program when a new model view window is created. For example, this event is sent for each new model view created by the window split bar.
DPartDocEvents_ViewNewNotifyEventHandler	Obsolete. Superseded by DPartDocEvents_ViewNewNotify2EventHandler .
DPartDocEvents_WeldmentCutListUpdatePostNotifyEventHandler	Post-notifies the user program when the weldment cut list in this part is updated.
DSldWorksEvents_ActiveDocChangeNotifyEventHandler	Post-notifies the user program when the active window has changed. This change can be between windows of the same document or between windows of different documents.
DSldWorksEvents_ActiveModelDocChangeNotifyEventHandler	Post-notifies the user program when the active IModelDoc2 object has changed.
DSldWorksEvents_BackgroundProcessingEndNotifyEventHandler	Notifies the user program when background processing has ended.
DSldWorksEvents_BackgroundProcessingStartNotifyEventHandler	Notifies the user program when background processing has started.
DSldWorksEvents_Begin3DInterconnectTranslationNotifyEventHandler	Notifies the user program when the SOLIDWORKS application starts to import or export a third-party native CAD file.
DSldWorksEvents_BeginRecordNotifyEventHandler	Notifies the user program when a macro recording has started.
DSldWorksEvents_BeginTranslationNotifyEventHandler	Notifies the user program when the SOLIDWORKS application starts to import a file.
DSldWorksEvents_CommandCloseNotifyEventHandler	Fired when a command, including a PropertyManager page, is okay'd or canceled by a user.
DSldWorksEvents_CommandOpenPreNotifyEventHandler	Fired before a command, including a PropertyManager page, executes or opens.
DSldWorksEvents_DestroyNotifyEventHandler	Sent to an MFC-based or a COM-based DLL add-in when the SOLIDWORKS session is about to be destroyed.
DSldWorksEvents_DisplayPaneActivationNotifyEventHandler	Fired when the Display Pane is activated.
DSldWorksEvents_DocumentConversionNotifyEventHandler	Post-notifies the user program that a file has been converted from an older version of SOLIDWORKS during the open operation.
DSldWorksEvents_DocumentLoadNotify2EventHandler	Post-notifies the user program when a SOLIDWORKS document is loaded.
DSldWorksEvents_DocumentLoadNotifyEventHandler	Obsolete. Superseded by DSldWorksEvents_DocumentLoadNotify2EventHandler .
DSldWorksEvents_End3DInterconnectTranslationNotifyEventHandler	Notifies the user program when the SOLIDWORKS application is finished importing or exporting a third-party native CAD file.
DSldWorksEvents_EndRecordNotifyEventHandler	Notifies the user program when a macro recording has ended, including if the user cancels the recording (i.e., the user cancels out of the Save As dialog and says No to the Continue recording? dialog).
DSldWorksEvents_EndTranslationNotifyEventHandler	Notifies the user program when the SOLIDWORKS application is finished importing a file.
DSldWorksEvents_FileCloseNotifyEventHandler	Notifies the user program when SOLIDWORKS is finished closing a file.
DSldWorksEvents_FileNewNotify2EventHandler	Post-notifies the user program when a new file is created.
DSldWorksEvents_FileNewNotifyEventHandler	Obsolete. Superseded by DSldWorksEvents_FileNewNotify2EventHandler .
DSldWorksEvents_FileNewPreNotifyEventHandler	Fired before a new document is created using either the SOLIDWORKS API or the SOLIDWORKS application.
DSldWorksEvents_FileOpenNotify2EventHandler	Post-notifies the user program when an existing file has been opened.
DSldWorksEvents_FileOpenNotifyEventHandler	Obsolete. Superseded by DSldWorksEvents_FileOpenNotify2EventHandler .
DSldWorksEvents_FileOpenPostNotifyEventHandler	Post-notifies the user program when a file has been opened.
DSldWorksEvents_FileOpenPreNotifyEventHandler	Pre-notifies the user program of a FileOpenNotify2 event.
DSldWorksEvents_InterfaceBrightnessThemeChangeNotifyEventHandler	Notifies an add-in when the SOLIDWORKS background changes.
DSldWorksEvents_LightSheetCreateNotifyEventHandler	Fired when a lighting sheet has been created.
DSldWorksEvents_NonNativeFileOpenNotifyEventHandler	Fired when non-native SOLIDWORKS files are opened.
DSldWorksEvents_On3DExperienceStateChangeNotifyEventHandler	Fired when 3DExperience changes state.
DSldWorksEvents_OnIdleNotifyEventHandler	Fired after all of the messages have been processed, included posted repaints; therefore, eliminating the need to call IModelDoc2::GraphicsRedraw2 .
DSldWorksEvents_PromptForFilenameNotifyEventHandler	Fired when a dependent document is missing from the file being opened.

DSldWorksEvents_PromptForMultipleFileNamesNotifyEventHandler	Fired when any dependent documents are missing from the file being opened.
DSldWorksEvents_PropertySheetCreateNotifyEventHandler	Notifies the user program when an exported ISWPropertySheet is created so that the application can add pages to it.
DSldWorksEvents_ReferencedFilePreNotify2EventHandler	Notifies the user program before SOLIDWORKS opens the specified file with the specified status.
DSldWorksEvents_ReferencedFilePreNotifyEventHandler	Obsolete. Superseded by DSldWorksEvents_ReferencedFilePreNotify2EventHandler .
DSldWorksEvents_ReferenceNotFoundNotifyEventHandler	Notifies the user program before SOLIDWORKS displays a dialog box prompting the end-user to browse for the referenced file.
DSldWorksEvents_TaskPaneCollapseNotifyEventHandler	Fired when the Task Pane collapses.
DSldWorksEvents_TaskPaneExpandNotifyEventHandler	Fired when the Task Pane expands.
DSldWorksEvents_TaskPaneHideNotifyEventHandler	Fired when the Task Pane hides.
DSldWorksEvents_TaskPanePinnedNotifyEventHandler	Fired when the Task Pane is pinned.
DSldWorksEvents_TaskPaneShowNotifyEventHandler	Fired when the Task Pane displays.
DSldWorksEvents_TaskPaneUnpinnedNotifyEventHandler	Fired when the Task Pane is unpinned.
DSWPropertySheetEvents_CreateControlNotifyEventHandler	Fired when the ActiveX control is created on the property page.
DSWPropertySheetEvents_DestroyNotifyEventHandler	Fired when the property sheet is in the process of being destroyed.
DSWPropertySheetEvents_HelpNotifyEventHandler	Fired when the Help button is clicked on a property sheet.
DSWPropertySheetEvents_OnCancelNotifyEventHandler	Fired when the Cancel button on the property sheet is clicked. Your add-in can perform clean-up activities in this event.
DSWPropertySheetEvents_OnOKNotifyEventHandler	Fired when the OK button on the property sheet is clicked.
DTaskpaneViewEvents_TaskPaneActivateNotifyEventHandler	Post-notifies the user program when an application-level Task Pane view is activated.
DTaskpaneViewEvents_TaskPaneDeactivateNotifyEventHandler	Post-notifies the user program when an application-level Task Pane view is deactivated.
DTaskpaneViewEvents_TaskPaneDestroyNotifyEventHandler	Pre-notifies the user program when an application-level Task Pane view is about to be destroyed.
DTaskpaneViewEvents_TaskPaneToolBarButtonClickedEventHandler	Fired when a toolbar button on the Task Pane is clicked.

See Also

[SolidWorks.Interop.sldworks Assembly](#)