

SOLIDWORKS API (VB6 COM) — Reference (55/102): ModelDoc (part 1 of 4)

SOLIDWORKS API Documentation (converted from CHM)

ModelDoc (part 1 of 4) (Type)

SOLIDWORKS Type Library

ModelDoc Object

 Object Model

ModelDoc

EnumModelViews

GetPropertyManagerPage (PropertyManagerPage)

IActiveView (ModelView)

IAddDiameterDimension2 (DisplayDimension)

IAddDimension2 (DisplayDimension)

IAddHorizontalDimension2 (DisplayDimension)

IAddRadialDimension2 (DisplayDimension)

IAddVerticalDimension2 (DisplayDimension)

ICreateArc2 (SketchSegment)

ICreateCircle2 (SketchSegment)

ICreateCircleByRadius2 (SketchSegment)

ICreateClippedSplines (EnumSketchSegments)

ICreateEllipse2 (SketchSegment)

ICreateEllipticalArc2 (SketchSegment)

ICreateFeatureMgrView (FeatMgrView)

ICreateFeatureMgrView2 (FeatMgrView)

ICreateFeatureMgrView3 (FeatMgrView)

ICreateLine2 (SketchSegment)

ICreatePlaneAtAngle2 (RefPlane)

ICreatePlaneAtOffset2 (RefPlane)

ICreatePlaneAtSurface2 (RefPlane)

ICreatePlanePerCurveAndPassPoint2 (RefPlane)

ICreatePlaneThru3Points2 (RefPlane)

ICreatePoint2 (SketchPoint)

ICreateSpline (SketchSegment)

ICreateSplineByEqnParams (SketchSegment)

ICreateSplinesByEqnParams (EnumSketchSegments)

IFeatureByPositionReverse (Feature)

IFeatureReferenceCurve (ReferenceCurve)

IFirstFeature (Feature)

- IGetActiveConfiguration (Configuration)
- IGetActiveSketch (Sketch)
- IGetActiveSketch2 (Sketch)
- IGetColorTable (ColorTable)
- IGetConfigurationByName (Configuration)
- IGetDesignTable (DesignTable)
- IGetDetailingDefaults (DetailingDefaults)
- IGetFirstAnnotation (Annotation)
- IGetFirstAnnotation2 (Annotation)
- IGetFirstModelView (ModeView)
- IGetLayerManager (LayerMgr)
- IGetNext (ModelDoc)
- IGetUserPreferenceTextFormat (TextFormat)
- IGetUserUnit (UserUnit)
- IInsertBOMBalloon2 (Note)
- IInsertDatumTag2 (DatumTag)
- IInsertGtol (Gtol)
- IInsertMidSurfaceExt (MidSurface)
- IInsertNote (Note)
- IInsertProjectedSketch2 (Feature)
- IInsertWeldSymbol3 (WeldSymbol)
- IParameter (Dimension)
- ISelectionManager (SelectionMgr)

SOLIDWORKS Type Library

ModelDoc Object Members

Public Methods

[ActivateFeatureMgrView](#)

[ActivateSelectedFeature](#)

[AddConfiguration](#)

[AddConfiguration2](#)

[AddCustomInfo](#)

[AddCustomInfo2](#)

[AddCustomInfo3](#)

	AddDiameterDimension
	AddDiameterDimension2
	AddDimension
	AddDimension2
	AddFeatureMgrView
	AddFeatureMgrView2
	AddFeatureMgrView3
	AddHorizontalDimension
	AddHorizontalDimension2
	AddIns
	AddLightSource
	AddLightSourceExtProperty
	AddLightToScene
	AddPropertyExtension
	AddRadialDimension
	AddRadialDimension2
	AddRelation
	AddSceneExtProperty
	AddVerticalDimension
	AddVerticalDimension2
	AlignDimensions
	AlignOrdinate
	AlignParallelDimensions
	AndSelect
	AndSelectByID
	AndSelectByMark
	AutoInferToggle
	AutoSolveToggle
	BlankRefGeom
	BlankSketch
	BreakAllExternalReferences
	BreakDimensionAlignment
	ChangeSketchPlane
	ClearSelection
	ClearUndoList
	Close
	CloseFamilyTable
	ClosePrintPreview
	Create3PointArc
	CreateArc
	CreateArc2
	CreateArcByCenter
	CreateArcDB

	<u>CreateArcVB</u>
	<u>CreateCenterLine</u>
	<u>CreateCenterLineVB</u>
	<u>CreateCircle</u>
	<u>CreateCircle2</u>
	<u>CreateCircleByRadius</u>
	<u>CreateCircleByRadius2</u>
	<u>CreateCircleDB</u>
	<u>CreateCircleVB</u>
	<u>CreateCircularSketchStepAndRepeat</u>
	<u>CreateClippedSplines</u>
	<u>CreateEllipse</u>
	<u>CreateEllipse2</u>
	<u>CreateEllipseVB</u>
	<u>CreateEllipticalArc2</u>
	<u>CreateEllipticalArcByCenter</u>
	<u>CreateEllipticalArcByCenterVB</u>
	<u>CreateFeatureMgrView</u>
	<u>CreateFeatureMgrView2</u>
	<u>CreateFeatureMgrView3</u>
	<u>CreateGroup</u>
	<u>CreateLine</u>
	<u>CreateLine2</u>
	<u>CreateLinearSketchStepAndRepeat</u>
	<u>CreateLineDB</u>
	<u>CreateLineVB</u>
	<u>CreatePlaneAtAngle</u>
	<u>CreatePlaneAtAngle2</u>
	<u>CreatePlaneAtOffset</u>
	<u>CreatePlaneAtOffset2</u>
	<u>CreatePlaneAtSurface</u>
	<u>CreatePlaneAtSurface2</u>
	<u>CreatePlaneFixed</u>
	<u>CreatePlanePerCurveAndPassPoint</u>
	<u>CreatePlanePerCurveAndPassPoint2</u>
	<u>CreatePlaneThru3Points</u>
	<u>CreatePlaneThru3Points2</u>
	<u>CreatePoint</u>
	<u>CreatePoint2</u>
	<u>CreatePointDB</u>
	<u>CreateSpline</u>
	<u>CreateSplineByEqnParams</u>
	<u>CreateSplinesByEqnParams</u>

	<u>CreateTangentArc</u>
	<u>CreateTangentArc2</u>
	<u>DeActivateFeatureMgrView</u>
	<u>DebugCheckBody</u>
	<u>DebugCheckIgesGeom</u>
	<u>DeleteAllRelations</u>
	<u>DeleteBendTable</u>
	<u>DeleteBkgImage</u>
	<u>DeleteConfiguration</u>
	<u>DeleteConfiguration2</u>
	<u>DeleteCustomInfo</u>
	<u>DeleteCustomInfo2</u>
	<u>DeleteDesignTable</u>
	<u>DeleteFeatureMgrView</u>
	<u>DeleteLightSource</u>
	<u>DeleteNamedView</u>
	<u>DeleteSelection</u>
	<u>DeriveSketch</u>
	<u>DeSelectByID</u>
	<u>DimPreferences</u>
	<u>DragTo</u>
	<u>DrawLightIcons</u>
	<u>EditBalloonProperties</u>
	<u>EditClearAll</u>
	<u>EditConfiguration</u>
	<u>EditConfiguration2</u>
	<u>EditCopy</u>
	<u>EditCut</u>
	<u>EditDatumTargetSymbol</u>
	<u>EditDelete</u>
	<u>EditDimensionProperties</u>
	<u>EditDimensionProperties2</u>
	<u>EditOrdinate</u>
	<u>EditRebuild3</u>
	<u>EditRedo</u>
	<u>EditRollback</u>
	<u>EditRollback2</u>
	<u>EditRoute</u>
	<u>EditSeedFeat</u>
	<u>EditSketch</u>
	<u>EditSketchOrSingleSketchFeature</u>
	<u>EditSuppress</u>
	<u>EditSuppress2</u>

 EditUndo
 EditUnsuppress
 EditUnsuppress2
 EditUnsuppressDependent
 EditUnsuppressDependent2
 EntityProperties
 EnumModelViews
 FeatEdit
 FeatEditDef
 FeatureBoss
 FeatureBossThicken
 FeatureBossThicken2
 FeatureBossThin
 FeatureByPositionReverse
 FeatureChamfer
 FeatureChamferType
 FeatureCirPattern
 FeatureCut
 FeatureCut2
 FeatureCut3
 FeatureCut4
 FeatureCutThicken
 FeatureCutThicken2
 FeatureCutThin
 FeatureExtruRefSurface
 FeatureFillet
 FeatureFillet2
 FeatureFillet3
 FeatureFillet4
 FeatureLinearPattern
 FeatureReferenceCurve
 FeatureRevolve2
 FeatureRevolveCut2
 FeatureSketchDrivenPattern
 FileReload
 FileSummaryInfo
 FirstFeature
 FontBold
 FontFace
 FontItalic
 FontPoints
 FontUnderline
 FontUnits

	ForceRebuild3
	GetActiveConfiguration
	GetActiveSketch
	GetActiveSketch2
	GetAddToDB
	GetAmbientLightProperties
	GetAngularUnits
	GetArcCentersDisplayed
	GetBendState
	GetBlockingState
	GetColorTable
	GetConfigurationByName
	GetConfigurationCount
	GetConfigurationNames
	GetConsiderLeadersAsLines
	GetCoordinateSystemXformByName
	GetCurrentCoordinateSystemName
	GetCustomInfoCount
	GetCustomInfoCount2
	GetCustomInfoNames
	GetCustomInfoNames2
	GetCustomInfoType
	GetCustomInfoType2
	GetCustomInfoType3
	GetDefaultTextHeight
	GetDependencies
	GetDependencies2
	GetDesignTable
	GetDetailingDefaults
	GetDirectionLightProperties
	GetDisplayWhenAdded
	GetEntityName
	GetExternalReferenceName
	GetFeatureCount
	GetFeatureManagerWidth
	GetFirstAnnotation
	GetFirstAnnotation2
	GetFirstModelView
	GetGridSettings
	GetInferenceMode
	GetLayerManager
	GetLightSourceCount
	GetLightSourceExtProperty

	GetLightSourceIdFromName
	GetLightSourceName
	GetLineCount
	GetLines
	GetMassProperties
	GetMassProperties2
	GetModelViewCount
	GetModelViewNames
	GetNext
	GetNumDependencies
	GetPathName
	GetPointLightProperties
	GetPopupMenuMode
	GetPropertyExtension
	GetPropertyManagerPage
	GetRayIntersectionsPoints
	GetRayIntersectionsTopology
	GetSaveFlag
	GetSceneBkgDIB
	GetSceneExtProperty
	GetSpotlightProperties
	GetStandardViewRotation
	GetTessellationQuality
	GetTitle
	GetToolBarVisibility
	GetType
	GetUnits
	GetUpdateStamp
	GetUserPreferenceDoubleValue
	GetUserPreferenceIntegerValue
	GetUserPreferenceStringValue
	GetUserPreferenceTextFormat
	GetUserPreferenceToggle
	GetUserUnit
	GetVisibilityOfConstructPlanes
	GraphicsRedraw
	GraphicsRedraw2
	GridOptions
	HideComponent2
	HideCosmeticThread
	HideDimension
	HideFeatureDimensions
	HideShowBodies

	<u>HideSolidBody</u>
	<u>HoleWizard</u>
	<u>IAddDiameterDimension2</u>
	<u>IAddDimension2</u>
	<u>IAddHorizontalDimension2</u>
	<u>IAddRadialDimension2</u>
	<u>IAddVerticalDimension2</u>
	<u>ICreateArc</u>
	<u>ICreateArc2</u>
	<u>ICreateCenterLine</u>
	<u>ICreateCircle2</u>
	<u>ICreateCircleByRadius</u>
	<u>ICreateCircleByRadius2</u>
	<u>ICreateClippedSplines</u>
	<u>ICreateEllipse</u>
	<u>ICreateEllipse2</u>
	<u>ICreateEllipticalArc2</u>
	<u>ICreateEllipticalArcByCenter</u>
	<u>ICreateFeatureMgView</u>
	<u>ICreateFeatureMgView2</u>
	<u>ICreateFeatureMgView3</u>
	<u>ICreateLine</u>
	<u>ICreateLine2</u>
	<u>ICreatePlaneAtAngle2</u>
	<u>ICreatePlaneAtOffset2</u>
	<u>ICreatePlaneAtSurface2</u>
	<u>ICreatePlaneFixed</u>
	<u>ICreatePlanePerCurveAndPassPoint2</u>
	<u>ICreatePlaneThru3Points2</u>
	<u>ICreatePoint2</u>
	<u>ICreateSpline</u>
	<u>ICreateSplineByEqnParams</u>
	<u>ICreateSplinesByEqnParams</u>
	<u>IFeatureByPositionReverse</u>
	<u>IFeatureFillet2</u>
	<u>IFeatureFillet3</u>
	<u>IFeatureFillet4</u>
	<u>IFeatureReferenceCurve</u>
	<u>IFirstFeature</u>
	<u>IGet3rdPartyStorage</u>
	<u>IGetActiveConfiguration</u>
	<u>IGetActiveSketch</u>
	<u>IGetActiveSketch2</u>

	<u>IGetAngularUnits</u>
	<u>IGetColorTable</u>
	<u>IGetConfigurationByName</u>
	<u>IGetConfigurationNames</u>
	<u>IGetCoordinateSystemXformByName</u>
	<u>IGetCustomInfoNames</u>
	<u>IGetCustomInfoNames2</u>
	<u>IGetDependencies</u>
	<u>IGetDependencies2</u>
	<u>IGetDesignTable</u>
	<u>IGetDetailingDefaults</u>
	<u>IGetEntityName</u>
	<u>IGetFirstAnnotation</u>
	<u>IGetFirstAnnotation2</u>
	<u>IGetFirstModeView</u>
	<u>IGetLayerManager</u>
	<u>IGetLines</u>
	<u>IGetMassProperties</u>
	<u>IGetMassProperties2</u>
	<u>IGetModelViewNames</u>
	<u>IGetNext</u>
	<u>IGetNumDependencies</u>
	<u>IGetNumDependencies2</u>
	<u>IGetRayIntersectionsPoints</u>
	<u>IGetRayIntersectionsTopology</u>
	<u>IGetStandardViewRotation</u>
	<u>IGetUnits</u>
	<u>IGetUserPreferenceTextFormat</u>
	<u>IGetUserUnit</u>
	<u>IGetVersionHistoryCount</u>
	<u>InsertBOMBalloon2</u>
	<u>InsertDatumTag2</u>
	<u>InsertGtol</u>
	<u>InsertMidSurfaceExt</u>
	<u>InsertNote</u>
	<u>InsertProjectedSketch2</u>
	<u>InsertWeldSymbol3</u>
	<u>IListExternalFileReferences</u>
	<u>IMultiSelectByRay</u>
	<u>Insert3DSketch</u>
	<u>Insert3DSketch2</u>
	<u>Insert3DSplineCurve</u>
	<u>InsertAxis</u>

	InsertBendTableEdit
	InsertBendTableNew
	InsertBendTableOpen
	InsertBkgImage
	InsertBOMBalloon
	InsertBOMBalloon2
	InsertCompositeCurve
	InsertConnectionPoint
	InsertCoordinateSystem
	InsertCosmeticThread
	InsertCurveFile
	InsertCurveFileBegin
	InsertCurveFileEnd
	InsertCurveFilePoint
	InsertCutBlend
	InsertCutBlend2
	InsertCutBlend3
	InsertCutBlend4
	InsertCutSurface
	InsertCutSwept
	InsertCutSwept2
	InsertCutSwept3
	InsertCutSwept4
	InsertDatumTag2
	InsertDatumTargetSymbol
	InsertDeleteFace
	InsertDeleteHole
	InsertDome
	InsertExtendSurface
	InsertFamilyTableEdit
	InsertFamilyTableNew
	InsertFamilyTableOpen
	InsertFeatureShell
	InsertFeatureShellAddThickness
	InsertFramePoint
	InsertGtol
	InsertHatchedFace
	InsertHelix
	InsertLibraryFeature
	InsertLofRefSurface
	InsertLofRefSurface2
	InsertMIDraft
	InsertMIDraft2

	InsertMidSurfaceExt
	InsertNewNote3
	InsertNote
	InsertObject
	InsertObjectFromFile
	InsertOffsetSurface
	InsertPlanarRefSurface
	InsertPoint
	InsertProjectedSketch
	InsertProjectedSketch2
	InsertProtrusionBlend
	InsertProtrusionBlend2
	InsertProtrusionBlend3
	InsertProtrusionBlend4
	InsertProtrusionSwept
	InsertProtrusionSwept2
	InsertProtrusionSwept3
	InsertProtrusionSwept4
	InsertRadiateSurface
	InsertRefPoint
	InsertRevolvedRefSurface
	InsertRib
	InsertRib2
	InsertRoutePoint
	InsertScale
	InsertSewRefSurface
	InsertShape
	InsertSheetMetal3dBend
	InsertSheetMetalBaseFlange
	InsertSheetMetalClosedCorner
	InsertSheetMetalFold
	InsertSheetMetalMiterFlange
	InsertSheetMetalUnfold
	InsertSketch
	InsertSketch2
	InsertSplinePoint
	InsertSplitLineProject
	InsertSplitLineSil
	InsertSurfaceFinishSymbol2
	InsertSweepRefSurface
	InsertSweepRefSurface2
	InsertTangencySurface
	InsertWeldSymbol2

	InsertWeldSymbol3
	InspectCurvature
	IParameter
	IRayIntersections
	IRelease3rdPartyStorage
	IsActive
	IsEditingSelf
	ISelectByRay
	ISetAngularUnits
	ISetNextSelectionGroupId
	ISetUserPreferenceTextFormat
	IsExploded
	ISketchSplineByEqnParams
	IsLightLockedToModel
	IsOpenedReadOnly
	IsOpenedViewOnly
	IsTessellationValid
	IVersionHistory
	LBDownAt
	LBUpAt
	Lights
	ListExternalFileReferences
	ListExternalFileReferencesCount
	Lock
	LockAllExternalReferences
	LockFramePoint
	LockLightToModel
	MultiSelectByRay
	NameView
	ObjectDisplayAsIcon
	ObjectDisplayContent
	ObjectResetsize
	Parameter
	ParentChildRelationship
	Paste
	PostTrimSurface
	PreTrimSurface
	PrintDirect
	PrintOut
	PrintOut2
	PrintPreview
	PropertySheet
	Quit

 RayIntersections
 ReattachOrdnate
 Rebuild
 RemoveGroups
 RemoveInspectCurvature
 RemoveItemsFromGroup
 ResetBlockingState
 ResetConfiguration
 ResetLightSourceExtProperty
 ResetPropertyExtension
 ResetSceneExtProperty
 Save
 Save2
 SaveAs
 SaveAs2
 SaveAs3
 SaveAsSilent
 SaveBMP
 SaveSilent
 Scale
 ScreenRotate
 Select
 SelectAt
 SelectByID
 SelectByMark
 SelectByName
 SelectByRay
 SelectedEdgeProperties
 SelectedFaceProperties
 SelectedFeatureProperties
 SelectLoop
 SelectMidpoint
 SelectSketchArc
 SelectSketchItem
 SelectSketchLine
 SelectSketchPoint
 SelectSketchSpline
 SelectTangency
 SetAddToDB
 SetAmbientLightProperties
 SetAngularUnits
 SetArcCentersDisplayed
 SetBendState

	SetBlockingState
	SetConsiderLeadersAsLines
	SetDirectionLightProperties
	SetDisplayWhenAdded
	SetFeatureManagerWidth
	SetInferenceMode
	SetLightSourceName
	SetLightSourcePropertyValuesVB
	SetNextSelectionGroupId
	SetParamValue
	SetPickMode
	SetPointLightProperties
	SetPopupMenuMode
	SetReadOnlyState
	SetSaveAsFileName
	SetSaveFlag
	SetSceneBkgDIB
	SetSpotlightProperties
	SetTessellationQuality
	SetTitle2
	SetToolbarVisibility
	SetUnits
	SetUserPreferenceDoubleValue
	SetUserPreferenceIntegerValue
	SetUserPreferenceStringoValue
	SetUserPreferenceTextFormat
	SetUserPreferenceToggle
	ShowComponent2
	ShowConfiguration
	ShowConfiguration2
	ShowCosmeticThread
	ShowFeatureDimensions
	ShowNamedView
	ShowNamedView2
	ShowSolidBody
	SimpleHole
	SimpleHole2
	SimplifySpline
	Sketch3DIntersections
	SketchAddConstraints
	SketchAlign
	SketchArc
	SketchCenterline

	SketchChamfer
	SketchCircle
	SketchConstrainCoincident
	SketchConstrainConcentric
	SketchConstrainParallel
	SketchConstrainPerp
	SketchConstrainTangent
	SketchConstraintsDel
	SketchConstraintsDelAll
	SketchConvertIsoCurves
	SketchFiller
	SketchFillet1
	SketchFillet2
	SketchMirror
	SketchModifyFlip
	SketchModifyRotate
	SketchModifyScale
	SketchModifyTranslate
	SketchOffset
	SketchOffset2
	SketchOffsetEdges
	SketchOffsetEntities
	SketchOffsetEntities2
	SketchParabola
	SketchPoint
	SketchPolygon
	SketchRectangle
	SketchRectangleAtAnyAngle
	SketchSpline
	SketchSplineByEqnParams
	SketchSplineByEqnParams2
	SketchTangentArc
	SketchTrim
	SketchUndo
	SketchUseEdge
	SketchUseEdge2
	SketchUseEdgeCrtline
	SkToolsAutoConstr
	SplitClosedSegment
	SplitOpenSegment
	Toolbars
	ToolsConfiguration
	ToolsDistance

 ToolsGrid
 ToolsMacro
 ToolsMassProps
 ToolsSketchScale
 ToolsSketchTranslate
 UnBlankRefGeom
 UnblankSketch
 UnderiveSketch
 UnLock
 UnlockAllExternalReferences
 UnlockFramePoint
 UserFavors
 UserPreferences
 VersionHistory
 ViewConstrain
 ViewDispCoordinateSystems
 ViewDisplayCurvature
 ViewDisplayFaceted
 ViewDisplayHiddengreyed
 ViewDisplayHiddenremoved
 ViewDisplayShaded
 ViewDisplayWireframe
 ViewDispOrigins
 ViewDispRefaxes
 ViewDispRefplanes
 ViewDispRefPoints
 ViewDispTempRefaxes
 ViewQoSShading
 ViewOrientationUndo
 ViewRotate
 ViewRotateminusx
 ViewRotateminusy
 ViewRotateminusz
 ViewRotateplusx
 ViewRotateplusy
 ViewRotateplusz
 ViewRotXMinusNinety
 ViewRotXPlusNinety
 ViewRotYMinusNinety
 ViewRotYPlusNinety
 ViewRwShading
 ViewTranslate
 ViewTranslateminusx

 ViewTranslateMinus
 ViewTranslatePlus
 ViewTranslatePlusY
 ViewZoomIn
 ViewZoomOut
 ViewZoomTo
 ViewZoomTo2
 ViewZoomToFit
 ViewZoomToFit2
 ViewZoomToSelection
 WindowRedraw

Public Properties

 ActiveView
 CustomInfo
 CustomInfo2
 IActiveView
 ILightSourcePropertyValues
 IMaterialPropertyValues
 ISelectionManager
 LengthUnit
 LightSourcePropertyValues
 LightSourceUserName
 MaterialIdName
 MaterialPropertyValues
 MaterialUserName
 PrintSetup
 SceneBkgImageFileName
 SceneName
 SceneUserName
 SelectionManager
 ShowFeatureErrorDialog
 SummaryInfo
 Visible

SOLIDWORKS Type Library

ActivateFeatureMgrView Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ActivateFeatureMgrView( _
    ByRef AppView As Long _
) As Long
```

SOLIDWORKS Type Library

ActivateSelectedFeature Method (ModelDoc)

Syntax

```
Public Sub ActivateSelectedFeature()
```

ActiveView Property (ModelDoc)

```
Public Property ActiveView As Object
```

AddConfiguration Method (ModelDoc)

```
Public Sub AddConfiguration( _
    ByVal Name As String, _
    ByVal Comment As String, _
    ByVal AlternateName As String, _
    ByVal SuppressByDefault As Boolean, _
    ByVal HideByDefault As Boolean, _
    ByVal MinFeatureManager As Boolean, _
    ByVal InheritProperties As Boolean, _
    ByVal Flags As ULong _
)
```

AddConfiguration2 Method (ModelDoc)

```
Public Function AddConfiguration2( _
    ByVal Name As String, _
    ByVal Comment As String, _
    ByVal AlternateName As String, _
    ByVal SuppressByDefault As Boolean, _
    ByVal HideByDefault As Boolean, _
    ByVal MinFeatureManager As Boolean, _
    ByVal InheritProperties As Boolean, _
    ByVal Flags As ULong _
) As Boolean
```

AddCustomInfo Method (ModelDoc)

```
Public Function AddCustomInfo( _
    ByVal FieldName As String, _
    ByVal FieldType As String, _
    ByVal FieldValue As String _
) As Boolean
```

AddCustomInfo2 Method (ModelDoc)

```
Public Function AddCustomInfo2( _
    ByVal FieldName As String, _
    ByVal FieldType As Long, _
```

```
ByVal FieldValue As String _  
) As Boolean
```

SOLIDWORKS Type Library

AddCustomInfo3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddCustomInfo3( _  
    ByVal Configuration As String, _  
    ByVal FieldName As String, _  
    ByVal FieldType As Long, _  
    ByVal FieldValue As String _  
) As Boolean
```

SOLIDWORKS Type Library

AddDiameterDimension Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDiameterDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AddDiameterDimension2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDiameterDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

SOLIDWORKS Type Library

AddDimension Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AddDimension2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

SOLIDWORKS Type Library

AddFeatureMgrView Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddFeatureMgrView( _  
    ByRef Bitmap As Long, _  
    ByRef AppView As Long _  
) As Boolean
```

SOLIDWORKS Type Library

AddFeatureMgrView2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddFeatureMgrView2( _  
    ByRef Bitmap As Long, _  
    ByRef AppView As Long, _  
    ByVal ToolTip As String _  
) As Boolean
```

SOLIDWORKS Type Library

AddFeatureMgrView3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddFeatureMgrView3( _  
    ByRef Bitmap As Long, _  
    ByRef AppView As Long, _  
    ByVal ToolTip As String, _  
    ByVal WhichPane As Long _  
) As Boolean
```

SOLIDWORKS Type Library

AddHorizontalDimension Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddHorizontalDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AddHorizontalDimension2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddHorizontalDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

SOLIDWORKS Type Library

AddIns Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AddIns()
```

SOLIDWORKS Type Library

AddLightSource Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddLightSource( _  
    ByVal IdName As String, _  
    ByVal LTyp As Integer, _  
    ByVal UserName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddLightSourceExtProperty Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddLightSourceExtProperty( _  
    ByVal ID As Long, _  
    ByVal PropertyExtension As Variant _  
    ) As Long
```

SOLIDWORKS Type Library

AddLightToScene Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddLightToScene( _  
    ByVal LpszNewValue As String _  
    ) As Long
```

SOLIDWORKS Type Library

AddPropertyExtension Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddPropertyExtension( _  
    ByVal PropertyExtension As Variant _  
    ) As Long
```

SOLIDWORKS Type Library

AddRadialDimension Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddRadialDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddRadialDimension2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddRadialDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Object
```


AddRelation Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub AddRelation( _  
    ByVal RelStr As String _  
)
```

AddSceneExtProperty Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddSceneExtProperty( _  
    ByVal PropertyExtension As Variant _  
) As Long
```

AddVerticalDimension Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddVerticalDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

AddVerticalDimension2 Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddVerticalDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

AlignDimensions Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub AlignDimensions()
```

AlignOrdinate Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub AlignOrdinate()
```

AlignParallelDimensions Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub AlignParallelDimensions()
```

SOLIDWORKS Type Library

AndSelect Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AndSelect( _  
    ByVal SelID As String, _  
    ByVal SelParams As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
)
```

SOLIDWORKS Type Library

AndSelectByID Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AndSelectByID( _  
    ByVal SelID As String, _  
    ByVal SelParams As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AndSelectByMark Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AndSelectByMark( _  
    ByVal SelID As String, _  
    ByVal SelParams As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal Mark As Long _  
) As Boolean
```

SOLIDWORKS Type Library

AutoInferToggle Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AutoInferToggle()
```

SOLIDWORKS Type Library

AutoSolveToggle Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AutoSolveToggle()
```

SOLIDWORKS Type Library

BlankRefGeom Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub BlankRefGeom()
```

SOLIDWORKS Type Library

BlankSketch Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub BlankSketch()
```

SOLIDWORKS Type Library

BreakAllExternalReferences Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub BreakAllExternalReferences()
```

SOLIDWORKS Type Library

BreakDimensionAlignment Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub BreakDimensionAlignment()
```

SOLIDWORKS Type Library

ChangeSketchPlane Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function ChangeSketchPlane() As Boolean
```

SOLIDWORKS Type Library

ClearSelection Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ClearSelection()
```

SOLIDWORKS Type Library

ClearUndoList Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ClearUndoList()
```

SOLIDWORKS Type Library

Close Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub Close()
```

SOLIDWORKS Type Library

CloseFamilyTable Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub CloseFamilyTable()
```

SOLIDWORKS Type Library

ClosePrintPreview Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ClosePrintPreview()
```

SOLIDWORKS Type Library

Create3PointArc Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Create3PointArc( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double, _  
    ByVal P3x As Double, _  
    ByVal P3y As Double, _  
    ByVal P3z As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateArc Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateArc( _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant, _  
    ByVal P3 As Variant, _  
    ByVal Dir As Integer _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateArc2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateArc2( _  
    ByVal XC As Double, _  
    ByVal YC As Double, _  
    ByVal Zc As Double, _  
    ByVal Xp1 As Double, _  
    ByVal Yp1 As Double, _  
    ByVal Zp1 As Double, _  
    ByVal Xp2 As Double, _  
    ByVal Yp2 As Double, _  
    ByVal Zp2 As Double, _  
    ByVal Direction As Integer _  
    ) As Object
```

SOLIDWORKS Type Library

CreateArcByCenter Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateArcByCenter( _
    ByVal P1x As Double, _
    ByVal P1y As Double, _
    ByVal P1z As Double, _
    ByVal P2x As Double, _
    ByVal P2y As Double, _
    ByVal P2z As Double, _
    ByVal P3x As Double, _
    ByVal P3y As Double, _
    ByVal P3z As Double _
) As Boolean
```

SOLIDWORKS Type Library

CreateArcDB Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function CreateArcDB( _
    ByVal X1 As Double, _
    ByVal Y1 As Double, _
    ByVal Z1 As Double, _
    ByVal X2 As Double, _
    ByVal Y2 As Double, _
    ByVal Z2 As Double, _
    ByVal X3 As Double, _
    ByVal Y3 As Double, _
    ByVal Z3 As Double, _
    ByVal Dir As Integer _
) As Boolean
```

SOLIDWORKS Type Library

CreateArcVB Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub CreateArcVB( _
    ByVal P1x As Double, _
    ByVal P1y As Double, _
    ByVal P1z As Double, _
    ByVal P2x As Double, _
    ByVal P2y As Double, _
    ByVal P2z As Double, _
    ByVal P3x As Double, _
    ByVal P3y As Double, _
    ByVal P3z As Double, _
    ByVal Dir As Integer _
)
```

SOLIDWORKS Type Library

CreateCenterLine Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function CreateCenterLine( _
    ByVal P1 As Variant, _
    ByVal P2 As Variant _
) As Boolean
```

SOLIDWORKS Type Library

CreateCenterLineVB Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub CreateCenterLineVB( _
    ByVal X1 As Double, _
    ByVal Y1 As Double, _
    ByVal Z1 As Double, _
    ByVal X2 As Double, _
    ByVal Y2 As Double, _
    ByVal Z2 As Double _
)
```

SOLIDWORKS Type Library

CreateCircle Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircle( _
    ByVal P1x As Double, _
    ByVal P1y As Double, _
    ByVal P1z As Double, _
    ByVal P2x As Double, _
    ByVal P2y As Double, _
    ByVal P2z As Double _
) As Boolean
```

SOLIDWORKS Type Library

CreateCircle2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircle2( _
    ByVal XC As Double, _
    ByVal YC As Double, _
    ByVal Zc As Double, _
    ByVal Xp As Double, _
    ByVal Yp As Double, _
    ByVal Zp As Double _
) As Object
```

SOLIDWORKS Type Library

CreateCircleByRadius Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircleByRadius( _
    ByVal P1 As Variant, _
    ByVal Radius As Double _
) As Boolean
```

SOLIDWORKS Type Library

CreateCircleByRadius2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircleByRadius2( _
    ByVal XC As Double, _
    ByVal YC As Double, _
    ByVal Zc As Double, _
    ByVal Radius As Double _
) As Object
```

SOLIDWORKS Type Library

CreateCircleDB Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircleDB( _  
    ByVal Cx As Double, _  
    ByVal Cy As Double, _  
    ByVal Cz As Double, _  
    ByVal Radius As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateCircleVB Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreateCircleVB( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal Radius As Double _  
)
```

SOLIDWORKS Type Library

CreateCircularSketchStepAndRepeat Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircularSketchStepAndRepeat( _  
    ByVal ArcRadius As Double, _  
    ByVal ArcAngle As Double, _  
    ByVal PatternNum As Long, _  
    ByVal PatternSpacing As Double, _  
    ByVal PatternRotate As Boolean, _  
    ByVal DeleteInstances As String _  
) As Boolean
```

SOLIDWORKS Type Library

CreateClippedSplines Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateClippedSplines( _  
    ByVal ParamsIn As Variant, _  
    ByVal X1 As Double, _  
    ByVal Y1 As Double, _  
    ByVal X2 As Double, _  
    ByVal Y2 As Double _  
) As Variant
```

SOLIDWORKS Type Library

CreateEllipse Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipse( _  
    ByVal Center As Variant, _  
    ByVal Major As Variant, _  
    ByVal Minor As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

CreateEllipse2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipse2( _  
    ByVal CenterX As Double, _  
    ByVal CenterY As Double, _  
    ByVal CenterZ As Double, _  
    ByVal MajorX As Double, _  
    ByVal MajorY As Double, _  
    ByVal MajorZ As Double, _  
    ByVal MinorX As Double, _  
    ByVal MinorY As Double, _  
    ByVal MinorZ As Double _  
) As Object
```

SOLIDWORKS Type Library

CreateEllipseVB Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipseVB( _  
    ByVal CenterX As Double, _  
    ByVal CenterY As Double, _  
    ByVal CenterZ As Double, _  
    ByVal MajorX As Double, _  
    ByVal MajorY As Double, _  
    ByVal MajorZ As Double, _  
    ByVal MinorX As Double, _  
    ByVal MinorY As Double, _  
    ByVal MinorZ As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateEllipticalArc2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipticalArc2( _  
    ByVal CenterX As Double, _  
    ByVal CenterY As Double, _  
    ByVal CenterZ As Double, _  
    ByVal MajorX As Double, _  
    ByVal MajorY As Double, _  
    ByVal MajorZ As Double, _  
    ByVal MinorX As Double, _  
    ByVal MinorY As Double, _  
    ByVal MinorZ As Double, _  
    ByVal StartX As Double, _  
    ByVal StartY As Double, _  
    ByVal StartZ As Double, _  
    ByVal EndX As Double, _  
    ByVal EndY As Double, _  
    ByVal EndZ As Double _  
) As Object
```

SOLIDWORKS Type Library

CreateEllipticalArcByCenter Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipticalArcByCenter( _  
    ByVal Center As Variant, _  
    ByVal Major As Variant, _  
    ByVal Minor As Variant, _  
    ByVal Start As Variant, _
```



```
ByVal End As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

CreateEllipticalArcByCenterVB Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipticalArcByCenterVB( _  
    ByVal CenterX As Double, _  
    ByVal CenterY As Double, _  
    ByVal CenterZ As Double, _  
    ByVal MajorX As Double, _  
    ByVal MajorY As Double, _  
    ByVal MajorZ As Double, _  
    ByVal MinorX As Double, _  
    ByVal MinorY As Double, _  
    ByVal MinorZ As Double, _  
    ByVal StartX As Double, _  
    ByVal StartY As Double, _  
    ByVal StartZ As Double, _  
    ByVal EndX As Double, _  
    ByVal EndY As Double, _  
    ByVal EndZ As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateFeatureMgrView Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureMgrView( _  
    ByRef Bitmap As Long _  
) As Object
```

SOLIDWORKS Type Library

CreateFeatureMgrView2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureMgrView2( _  
    ByRef Bitmap As Long, _  
    ByVal ToolTip As String _  
) As Object
```

SOLIDWORKS Type Library

CreateFeatureMgrView3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureMgrView3( _  
    ByRef Bitmap As Long, _  
    ByVal ToolTip As String, _  
    ByVal WhichPane As Long _  
) As Object
```

SOLIDWORKS Type Library

CreateGroup Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreateGroup()
```

SOLIDWORKS Type Library

CreateLine Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function CreateLine( _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateLine2 Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function CreateLine2( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double _  
    ) As Object
```

SOLIDWORKS Type Library

CreateLinearSketchStepAndRepeat Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function CreateLinearSketchStepAndRepeat( _  
    ByVal NumX As Long, _  
    ByVal NumY As Long, _  
    ByVal SpacingX As Double, _  
    ByVal SpacingY As Double, _  
    ByVal AngleX As Double, _  
    ByVal AngleY As Double, _  
    ByVal DeleteInstances As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateLineDB Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function CreateLineDB( _  
    ByVal Sx As Double, _  
    ByVal Sy As Double, _  
    ByVal Sz As Double, _  
    ByVal Ex As Double, _  
    ByVal Ey As Double, _  
    ByVal Ez As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateLineVB Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub CreateLineVB( _  
    ByVal X1 As Double, _  
    ByVal Y1 As Double, _  
    ByVal Z1 As Double, _  
    ByVal X2 As Double, _  
    ByVal Y2 As Double, _  
    ByVal Z2 As Double _  
)
```

SOLIDWORKS Type Library

CreatePlaneAtAngle Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreatePlaneAtAngle( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean _  
)
```

SOLIDWORKS Type Library

CreatePlaneAtAngle2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtAngle2( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreatePlaneAtOffset Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreatePlaneAtOffset( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean _  
)
```

SOLIDWORKS Type Library

CreatePlaneAtOffset2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtOffset2( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreatePlaneAtSurface Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreatePlaneAtSurface( _  
    ByVal InterIndex As Integer, _  
    ByVal ProjOpt As Boolean, _  
    ByVal ReverseDir As Boolean, _  
    ByVal NormalPlane As Boolean, _  
    ByVal Angle As Double _  
)
```

SOLIDWORKS Type Library

CreatePlaneAtSurface2 Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtSurface2( _  
    ByVal InterIndex As Integer, _  
    ByVal ProjOpt As Boolean, _  
    ByVal ReverseDir As Boolean, _  
    ByVal NormalPlane As Boolean, _  
    ByVal Angle As Double _  
) As Object
```

SOLIDWORKS Type Library

CreatePlaneFixed Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneFixed( _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant, _  
    ByVal P3 As Variant, _  
    ByVal UseGlobal As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

CreatePlanePerCurveAndPassPoint Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreatePlanePerCurveAndPassPoint( _  
    ByVal OrigAtCurve As Boolean _  
)
```

SOLIDWORKS Type Library

CreatePlanePerCurveAndPassPoint2 Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlanePerCurveAndPassPoint2( _  
    ByVal OrigAtCurve As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreatePlaneThru3Points Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreatePlaneThru3Points()
```

SOLIDWORKS Type Library

CreatePlaneThru3Points2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneThru3Points2() As Object
```

SOLIDWORKS Type Library

CreatePoint Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePoint( _  
    ByVal PointX As Double, _  
    ByVal PointY As Double, _  
    ByVal PointZ As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreatePoint2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePoint2( _  
    ByVal PointX As Double, _  
    ByVal PointY As Double, _  
    ByVal PointZ As Double _  
) As Object
```

SOLIDWORKS Type Library

CreatePointDB Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePointDB( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateSpline Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSpline( _  
    ByVal PointData As Variant _  
) As Object
```

SOLIDWORKS Type Library

CreateSplineByEqnParams Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSplineByEqnParams( _  
    ByVal ParamsIn As Variant _  
) As Object
```

SOLIDWORKS Type Library

CreateSplinesByEqnParams Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSplinesByEqnParams( _  
    ByVal ParamsIn As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

CreateTangentArc Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTangentArc( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateTangentArc2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTangentArc2( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double, _  
    ByVal ArcTypeIn As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

CustomInfo Property (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CustomInfo( _  
    ByVal FieldName As String _  
    ) As String
```

SOLIDWORKS Type Library

CustomInfo2 Property (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CustomInfo2( _  
    ByVal Configuration As String, _  
    ByVal FieldName As String _  
    ) As String
```

SOLIDWORKS Type Library

DeActivateFeatureMgrView Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeActivateFeatureMgrView( _  
    ByRef AppView As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

DebugCheckBody Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub DebugCheckBody()
```

SOLIDWORKS Type Library

DebugCheckIgesGeom Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub DebugCheckIgesGeom()
```

SOLIDWORKS Type Library

DeleteAllRelations Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteAllRelations()
```

SOLIDWORKS Type Library

DeleteBendTable Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteBendTable()
```

SOLIDWORKS Type Library

DeleteBkgImage Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteBkgImage()
```

SOLIDWORKS Type Library

DeleteConfiguration Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteConfiguration( _  
    ByVal ConfigurationName As String _  
)
```

SOLIDWORKS Type Library

DeleteConfiguration2 Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteConfiguration2( _  
    ByVal ConfigurationName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteCustomInfo Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteCustomInfo( _  
    ByVal FieldName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteCustomInfo2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteCustomInfo2( _  
    ByVal Configuration As String, _  
    ByVal FieldName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteDesignTable Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteDesignTable()
```

SOLIDWORKS Type Library

DeleteFeatureMgrView Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteFeatureMgrView( _  
    ByRef AppView As Long _  
)
```

SOLIDWORKS Type Library

DeleteLightSource Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteLightSource( _  
    ByVal ID As Long _  
)
```

SOLIDWORKS Type Library

DeleteNamedView Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteNamedView( _  
    ByVal ViewName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteSelection Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteSelection( _  
    ByVal ConfirmFlag As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

DeriveSketch Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeriveSketch()
```

SOLIDWORKS Type Library

DeSelectByID Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeSelectByID( _  
    ByVal SelID As String, _  
    ByVal SelParams As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

DimPreferences Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DimPreferences()
```

SOLIDWORKS Type Library

DragTo Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DragTo( _  
    ByVal Flags As Long, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    )
```

SOLIDWORKS Type Library

DrawLightIcons Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DrawLightIcons()
```

SOLIDWORKS Type Library

EditBalloonProperties Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EditBalloonProperties( _  
    ByVal Style As Long, _  
    ByVal Size As Long, _  
    ByVal UpperTextStyle As Long, _  
    ByVal UpperText As String, _  
    ByVal LowerTextStyle As Long, _  
    ByVal LowerText As String _  
    ) As Object
```

SOLIDWORKS Type Library

EditClearAll Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditClearAll()
```

SOLIDWORKS Type Library

EditConfiguration Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditConfiguration( _  
    ByVal Name As String, _  
    ByVal NewName As String, _  
    ByVal Comment As String, _  
    ByVal AlternateName As String, _  
    ByVal SuppressByDefault As Boolean, _  
    ByVal HideByDefault As Boolean, _  
    ByVal MinFeatureManager As Boolean, _  
    ByVal InheritProperties As Boolean, _  
    ByVal Flags As ULong _  
)
```

SOLIDWORKS Type Library

EditConfiguration2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EditConfiguration2( _  
    ByVal Name As String, _  
    ByVal NewName As String, _  
    ByVal Comment As String, _  
    ByVal AlternateName As String, _  
    ByVal SuppressByDefault As Boolean, _  
    ByVal HideByDefault As Boolean, _  
    ByVal MinFeatureManager As Boolean, _  
    ByVal InheritProperties As Boolean, _  
    ByVal Flags As ULong _  
) As Boolean
```

SOLIDWORKS Type Library

EditCopy Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditCopy()
```

SOLIDWORKS Type Library

EditCut Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditCut()
```

SOLIDWORKS Type Library

EditDatumTargetSymbol Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EditDatumTargetSymbol( _
    ByVal Datum1 As String, _
    ByVal Datum2 As String, _
    ByVal Datum3 As String, _
    ByVal AreaStyle As Integer, _
    ByVal AreaOutside As Boolean, _
    ByVal Value1 As Double, _
    ByVal Value2 As Double, _
    ByVal ValueStr1 As String, _
    ByVal ValueStr2 As String, _
    ByVal ArrowsSmart As Boolean, _
    ByVal ArrowStyle As Integer, _
    ByVal LeaderLineStyle As Integer, _
    ByVal LeaderBent As Boolean, _
    ByVal ShowArea As Boolean, _
    ByVal ShowSymbol As Boolean _
) As Boolean
```

SOLIDWORKS Type Library

EditDelete Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditDelete()
```

SOLIDWORKS Type Library

EditDimensionProperties Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EditDimensionProperties( _
    ByVal TolType As Long, _
    ByVal TolMax As Double, _
    ByVal TolMin As Double, _
    ByVal TolMaxFit As String, _
    ByVal TolMinFit As String, _
    ByVal UseDocPrec As Boolean, _
    ByVal Precision As Long, _
    ByVal ArrowsIn As Long, _
    ByVal UseDocArrows As Boolean, _
    ByVal Arrow1 As Long, _
    ByVal Arrow2 As Long _
) As Boolean
```

SOLIDWORKS Type Library

EditDimensionProperties2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EditDimensionProperties2( _
    ByVal TolType As Long, _
    ByVal TolMax As Double, _
    ByVal TolMin As Double, _
    ByVal TolMaxFit As String, _
    ByVal TolMinFit As String, _
    ByVal UseDocPrec As Boolean, _
    ByVal Precision As Long, _
    ByVal ArrowsIn As Long, _
    ByVal UseDocArrows As Boolean, _
    ByVal Arrow1 As Long, _
    ByVal Arrow2 As Long, _
    ByVal PrefixText As String, _
    ByVal SuffixText As String, _
    ByVal ShowValue As Boolean, _
```

```
ByVal CalloutText1 As String, _  
ByVal CalloutText2 As String, _  
ByVal CenterText As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

EditOrdinate Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditOrdinate()
```

SOLIDWORKS Type Library

EditRebuild3 Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function EditRebuild3() As Boolean
```

SOLIDWORKS Type Library

EditRedo Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditRedo( _  
    ByVal NSteps As ULong _  
)
```

SOLIDWORKS Type Library

EditRollback Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function EditRollback() As Boolean
```

SOLIDWORKS Type Library

EditRollback2 Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function EditRollback2() As Boolean
```

SOLIDWORKS Type Library

EditRoute Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditRoute()
```