

SOLIDWORKS API (VB6 COM) — Reference (64/102): ModelDocExtension (part 1 of 3)

SOLIDWORKS API Documentation (converted from CHM)

ModelDocExtension (part 1 of 3) (Type)

SOLIDWORKS Type Library

ModelDocExtension Object

 Object Model

ModelDocExtension

- AddComment (Comment)
- AppPageSetup (PageSetup)
- Capture3DView (View3D)
- CreateBalloonOptions (BalloonOptions)
- CreateCallout (Callout)
- CreateDecal (Decal)
- CreateMassProperty (MassProperty)
- CreateMeasure (Measure)
- CreateOLEObject (SwOLEObject)
- CreateRenderMaterial (RenderMaterial)
- CreateStackedBalloonOptions (StackedBalloonOptions)
- CreateStructureSystem (Feature)
- CreateTexture (Texture)
- CustomPropertyManager
- DimXpertManager
- Document (ModelDoc2)
- Get3DView (View3D)
- GetAppearanceSetting (AppearanceSetting)
- GetCameraById (Camera)
- GetCameraDefinition (Camera)
- GetCoordinateSystemTransformByName (MathTransform)
- GetDecal (Decal)
- GetDisplayStateSetting (DisplayStateSetting)
- GetGeneralTableAnnotation (TableAnnotation)
- GetLastFeatureAdded (Feature)
- GetMaterial (RenderMaterial)
- GetModeView (ModelView)
- GetPackAndGo (PackAndGo)
- GetPrint3DDialog (Print3DDialog)
- GetTexture (Texture)

- GetUserPreferenceTextFormat (TextFormat)
- ICreateOLEObject (SwOLEObject)
- IGetAnnotations (Annotation)
- IGetAnnotationViews (AnnotationView)
- IGetDecals (Decal)
- IGetModeViews (ModeView)
- IGetRenderMaterials (RenderMaterial)
- InsertAnnotationFavorite (Annotation)
- InsertAnnotationView (AnnotationView)
- InsertBOMBalloon2 (Note)
- InsertBomTable (BomTableAnnotation)
- InsertBomTable2 (BomTableAnnotation)
- InsertBomTable3 (BomTableAnnotation)
- InsertCamera (Camera)
- InsertDatumTargetSymbol2 (DatumTargetSym)
- InsertDatumTargetSymbol3 (DatumTargetSym)
- InsertGeneralTableAnnotation (TableAnnotation)
- InsertGeneralToleranceTableAnnotation (GeneralToleranceTableAnnotation)
- InsertObjectFromFile (SwOLEObject)
- InsertStackedBalloon (Note)
- InsertStackedBalloon2 (Note)
- InsertSurfaceFinishSymbol3 (SFSymbol)
- InsertTitleBlockTable (TitleBlockTableAnnotation)

SOLIDWORKS Type Library

ModelDocExtension Object Members

Public Methods

- [ActivateFeatureMgrViewx64](#)
- [AddAngularRunningDim](#)
- [AddComment](#)
- [AddDecal](#)
- [AddDefaultRenderMaterial](#)
- [AddDimension](#)
- [AddDisplayStateSpecificRenderMaterial](#)

 AddFeatureMgrView3x64
 AddOrdinateDimension
 AddOrUpdateSearchData
 AddPathLengthDim
 AddRenderMaterial
 AddSpecificDimension
 AddSymmetricDimension
 AlignDimensions
 AlignRunningDimension
 ApplyFormatPainterToAll
 ApplyTexture
 BreakAllExternalFileReferences2
 Capture3DView
 ChangeSketchPlane
 CheckVersionCompatibility
 CloseMessageBar
 CloseUserNotification
 Compare3DPMI
 CopyDraftingStandard
 Create3DBoundingBox
 CreateAdvancedHoleElementData
 CreateBalloonOptions
 CreateCallout
 CreateDecal
 CreateMassProperty
 CreateMassProperty2
 CreateMeasure
 CreateOLEObject
 CreatePresentation
 CreatePresentation2
 CreateRenderMaterial
 CreateStackedBalloonOptions
 CreateStructureSystem
 CreateStructureSystemMemberData
 CreateTexture
 DeActivateFeatureMgrViewx64
 DeleteAllDecals
 DeleteAttachment
 DeleteDecal
 DeleteDisplayStyleSpecificRenderMaterial
 DeleteDraftingStandard
 DeleteFeatureMgrView64
 DeleteRenderMaterial

	<u>DeleteScene</u>
	<u>DeleteSearchData</u>
	<u>DeleteSelection2</u>
	<u>EditBalloonProperties</u>
	<u>EditBalloonProperties2</u>
	<u>EditDimensionProperties</u>
	<u>EditRebuildAll</u>
	<u>FindTrackedObjects</u>
	<u>FinishRecordingUndoObject</u>
	<u>FinishRecordingUndoObject2</u>
	<u>ForceRebuildAll</u>
	<u>GeodesicSketchOffset</u>
	<u>Get3DExperienceModelType</u>
	<u>Get3DView</u>
	<u>Get3DViewCount</u>
	<u>Get3DViewNames</u>
	<u>Get3DViews</u>
	<u>GetActiveAnnotationView</u>
	<u>GetActivePropertyManagerPage</u>
	<u>GetAdvancedSaveAsOptions</u>
	<u>GetAdvancedSpotLightProperties</u>
	<u>GetAnnotationCount</u>
	<u>GetAnnotations</u>
	<u>GetAnnotationsByType</u>
	<u>GetAppearanceSetting</u>
	<u>GetAttachmentCount</u>
	<u>GetAttachments</u>
	<u>GetCalloutVariableString</u>
	<u>GetCameraById</u>
	<u>GetCameraCount</u>
	<u>GetCameraDefinition</u>
	<u>GetCommandTabs</u>
	<u>GetCoordinateSystemTransformByName</u>
	<u>GetCorresponding</u>
	<u>GetCorresponding2</u>
	<u>GetCorrespondingEntity</u>
	<u>GetCorrespondingEntity2</u>
	<u>GetCostingManager</u>
	<u>GetCSYSDistances</u>
	<u>GetCSYSEulersAngularRotation</u>
	<u>GetCSYSXYZAngularRotation</u>
	<u>GetDecal</u>
	<u>GetDecals</u>

	<u>GetDecalsCount</u>
	<u>GetDependencies</u>
	<u>GetDisplayStateSetting</u>
	<u>GetDraftingStandardNames</u>
	<u>GetFlattenSheetMetalPersistReference</u>
	<u>GetGeneralTableAnnotation</u>
	<u>GetKeepLightInRenderScene</u>
	<u>GetLastFeatureAdded</u>
	<u>GetLicenseType</u>
	<u>GetLightEnabledInRender</u>
	<u>GetMassProperties</u>
	<u>GetMassProperties2</u>
	<u>GetMaterial</u>
	<u>GetMaterialPropertyValues</u>
	<u>GetMBD3DPdfData</u>
	<u>GetMBDSTEP242Data</u>
	<u>GetModelBreakViewNames</u>
	<u>GetModelView</u>
	<u>GetModelViewCount</u>
	<u>GetModelViews</u>
	<u>GetMotionStudyManager</u>
	<u>GetNamedViewRotation</u>
	<u>GetObjectByPersistReference</u>
	<u>GetObjectByPersistReference2</u>
	<u>GetObjectByPersistReference3</u>
	<u>GetObjectId</u>
	<u>GetOLEObjectCount</u>
	<u>GetOLEObjects</u>
	<u>GetPackAndGo</u>
	<u>GetParameterValue</u>
	<u>GetPersistReference</u>
	<u>GetPersistReference3</u>
	<u>GetPersistReferenceCount</u>
	<u>GetPersistReferenceCount3</u>
	<u>GetPLMID</u>
	<u>GetPrint3DDialog</u>
	<u>GetPrintSpecification</u>
	<u>GetRenderCustomReferences</u>
	<u>GetRenderMaterials</u>
	<u>GetRenderMaterials2</u>
	<u>GetRenderMaterialsCount</u>
	<u>GetRenderMaterialsCount2</u>
	<u>GetRenderStockReferences</u>

	<u>GetRoutingComponentManager</u>
	<u>GetScanto3D</u>
	<u>GetSceneBgDIBx64</u>
	<u>GetSearchData</u>
	<u>GetSearchDataCount</u>
	<u>GetSectionProperties</u>
	<u>GetSectionProperties2</u>
	<u>GetSheetMetalObjectsByPersistReference</u>
	<u>GetSphericalBoxDiameter</u>
	<u>GetStream</u>
	<u>GetSunLightAdvancedPropertyValues</u>
	<u>GetSunLightSourcePropertyValues</u>
	<u>GetSustainability</u>
	<u>GetTemplateSheetMetal</u>
	<u>GetTexture</u>
	<u>GetUserPreferenceDouble</u>
	<u>GetUserPreferenceDoubleValueRange</u>
	<u>GetUserPreferenceInteger</u>
	<u>GetUserPreferenceString</u>
	<u>GetUserPreferenceTextFormat</u>
	<u>GetUserPreferenceToggle</u>
	<u>GetVisibleBox</u>
	<u>GetWhatsWrong</u>
	<u>GetWhatsWrongCount</u>
	<u>HasDesignTable</u>
	<u>HasLegacyCThreads</u>
	<u>HasMaterialPropertyValues</u>
	<u>HasRenamedDocuments</u>
	<u>HideDecal</u>
	<u>HideFeatureManager</u>
	<u>IAddDisplayStateSpecificRenderMaterial</u>
	<u>ICChangeSketchPlane</u>
	<u>ICreateOLEObject</u>
	<u>IDeleteDisplayStateSpecificRenderMaterial</u>
	<u>IEditDimensionProperties</u>
	<u>IGet3rdPartyStorageStore</u>
	<u>IGetAnnotations</u>
	<u>IGetAnnotationViews</u>
	<u>IGetAttachments</u>
	<u>IGetDecals</u>
	<u>IGetFlattenSheetMetalPersistReference</u>
	<u>IGetMassProperties</u>
	<u>IGetMaterialPropertyValues</u>

	<u>IGetModelViews</u>
	<u>IGetNamedViewRotation</u>
	<u>IGetObjectByPersistReference</u>
	<u>IGetObjectByPersistReference2</u>
	<u>IGetObjectByPersistReference3</u>
	<u>IGetOLEObjects</u>
	<u>IGetPersistReference</u>
	<u>IGetPersistReference3</u>
	<u>IGetRenderMaterials</u>
	<u>IGetSearchData</u>
	<u>IGetSectionProperties</u>
	<u>IGetSectionProperties2</u>
	<u>IGetSheetMetalObjectsByPersistReference</u>
	<u>IListExternalFileReferences</u>
	<u>IMultiSelect</u>
	<u>InsertAnnotationFavorite</u>
	<u>InsertAnnotationView</u>
	<u>InsertAttachment</u>
	<u>InsertBOMBalloon</u>
	<u>InsertBOMBalloon2</u>
	<u>InsertBomTable</u>
	<u>InsertBomTable2</u>
	<u>InsertBomTable3</u>
	<u>InsertBomTable4</u>
	<u>InsertCamera</u>
	<u>InsertChainDimensions</u>
	<u>InsertDatumTargetSymbol2</u>
	<u>InsertDatumTargetSymbol3</u>
	<u>InsertDeleteFace</u>
	<u>InsertDwgOrDxfFile</u>
	<u>InsertGeneralTableAnnotation</u>
	<u>InsertGeneralToleranceTableAnnotation</u>
	<u>InsertObjectFromFile</u>
	<u>InsertScene</u>
	<u>InsertStackedBalloon</u>
	<u>InsertStackedBalloon2</u>
	<u>InsertSurfaceFinishSymbol3</u>
	<u>InsertTitleBlockTable</u>
	<u>InstallModelColorizer</u>
	<u>IPrintOut2</u>
	<u>IPrintOut3</u>
	<u>IRelease3rdPartyStorageStore</u>
	<u>IRemoveMaterialProperty</u>

	IsAbbreviatedViewActive
	IsConverted
	IsDisplayPaneVisible
	IsMaterialPropertyValues
	IsExploded
	IsFutureVersion
	IsSamePersistentID
	IsVirtualComponent
	IsVirtualComponent2
	IsVirtualComponent3
	JogDimension
	ListExternalFileReferences
	ListExternalFileReferences2
	ListExternalFileReferencesCount
	LoadDraftingStandard
	Make3DExperienceCompatible
	MoveDecal
	MoveOrCopy
	MultiSelect
	MultiSelect2
	PrintOut
	PrintOut2
	PrintOut3
	PrintOut4
	PublishSTEP242File
	PublishSTEP242File2
	PublishTo3DPDF
	PurgeDisplayState
	RayIntersections
	Rebuild
	Refresh3DViews
	ReJogRunningDimension
	ReleaseStream
	ReloadOrReplace
	ReloadWithReferences
	RemoveMaterialProperty
	RemoveModelColorizer
	RemoveTexture
	RemoveTexture2
	RemoveTextureByDisplayState
	RemoveVisibleBox
	RenameDocument
	RenameDraftingStandard

	<u>ReorderFeature</u>
	<u>ReorderFeature2</u>
	<u>ResetStandardViews</u>
	<u>ReverseDecalsOrder</u>
	<u>RotateOrCopy</u>
	<u>RunCommand</u>
	<u>SaveAs</u>
	<u>SaveAs2</u>
	<u>SaveAs3</u>
	<u>SaveDeFeaturedFile</u>
	<u>SaveDraftingStandard</u>
	<u>SavePackAndGo</u>
	<u>SaveSelection</u>
	<u>SaveTo3DEXperience</u>
	<u>SaveViewToSolidworks</u>
	<u>ScaleOrCopy</u>
	<u>SelectAll</u>
	<u>SelectByID</u>
	<u>SelectByID2</u>
	<u>SelectByRay</u>
	<u>SetAdvancedSpotLightProperties</u>
	<u>SetApiUndoObject</u>
	<u>SetKeepLightInRenderScene</u>
	<u>SetLightEnabledInRender</u>
	<u>SetMaterialPropertyValues</u>
	<u>SetParameterValue</u>
	<u>SetSceneBgDIBx64</u>
	<u>SetSunLightAdvancedPropertyValues</u>
	<u>SetSunLightSourcePropertyValues</u>
	<u>SetTexture</u>
	<u>SetTextureByDisplayState</u>
	<u>SetTopLevelTransparency</u>
	<u>SetUserPreferenceDouble</u>
	<u>SetUserPreferenceInteger</u>
	<u>SetUserPreferenceString</u>
	<u>SetUserPreferenceTextFormat</u>
	<u>SetUserPreferenceToggle</u>
	<u>SetVisibleBox</u>
	<u>ShowMessageBar</u>
	<u>ShowModelBreakView</u>
	<u>ShowSmartMessage</u>
	<u>ShowUserNotification</u>
	<u>SketchBoxSelect</u>

 SketchOffsetOnSurface
 StartFormatPainter
 StartRecordingUndoObject
 StopFormatPainter
 Stretch
 UpdateExternalFileReferences
 UpdateFrozenFeatures
 UpdateRenderMaterialsInSceneGraph
 UpdateStandardViews
 UpdateSunLight
 UpgradeLegacyCThreads
 UpgradeLegacyCustomProperties
 ViewZoomToSheet

Public Properties

 ActiveCommandTab
 ActiveCommandTabIndex
 AnnotationViewCount
 AnnotationViews
 AppPageSetup
 ClearLastActiveConfigModel
 CommandTabVisible
 CustomPropertyBuilderTemplate
 CustomPropertyManager
 DimXpntManager
 DisplayMode
 DisplayStateSpecMaterialPropertyValues
 DisplayTitle
 Document
 FeatureManagerFilterString
 FlyoutFeatureTreeVisibility
 HasLegacyCustomProperties
 IncludeMassPropertiesOfHiddenBodies
 LinkedDisplayState
 NeedsRebuild
 NeedsRebuild2
 ShowPartRebuildIndicators
 SunLightInformation
 ToolboxPartType
 Transparency
 UsePageSetup
 ViewDisplayRealView
 Visibility

ActivateFeatureMgrViewx64 Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ActivateFeatureMgrViewx64( _
    ByRef AppView As Unknown _
) As Long
```

ActiveCommandTab Property (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property ActiveCommandTab As String
```

ActiveCommandTabIndex Property (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property ActiveCommandTabIndex As Long
```

AddAngularRunningDim Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddAngularRunningDim( _
    ByVal DisplayAsChain As Boolean, _
    ByVal RunBidirectionally As Boolean, _
    ByVal ExtensionLineExtendsFromCenterOfSet As Boolean, _
    ByVal LocX As Double, _
    ByVal LocY As Double, _
    ByVal LocZ As Double, _
    ByRef RetVal As Long _
) As Variant
```

AddComment Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddComment( _
    ByVal Text As String _
) As Comment
```

AddDecal Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddDecal( _
    ByVal PDecal As Decal, _
    ByRef DecalID As Long _
) As Boolean
```

AddDefaultRenderMaterial Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDefaultRenderMaterial( _  
    ByVal PRenderMaterial As RenderMaterial, _  
    ByRef PwMaterialId As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddDimension Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal Direction As Long _  
    ) As Object
```

SOLIDWORKS Type Library

AddDisplayStateSpecificRenderMaterial Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDisplayStateSpecificRenderMaterial( _  
    ByVal PRenderMaterial As RenderMaterial, _  
    ByVal DisplayStateOption As Long, _  
    ByVal DisplayStateNames As Variant, _  
    ByRef PwMaterialId1 As Long, _  
    ByRef PwMaterialId2 As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddFeatureMgrView3x64 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddFeatureMgrView3x64( _  
    ByRef Bitmap As Unknown, _  
    ByRef AppView As Unknown, _  
    ByVal ToolTip As String, _  
    ByVal WhichPane As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddOrdinateDimension Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddOrdinateDimension( _  
    ByVal DimType As Long, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double _  
    ) As Long
```

SOLIDWORKS Type Library

AddOrUpdateSearchData Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddOrUpdateSearchData( _  
    ByVal AppName As String, _  
    ByVal AppKeyword As String, _  
    ByVal AppValue As String _  
) As Boolean
```

SOLIDWORKS Type Library

AddPathLengthDim Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddPathLengthDim( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

SOLIDWORKS Type Library

AddRenderMaterial Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddRenderMaterial( _  
    ByVal PRenderMaterial As RenderMaterial, _  
    ByRef PwMaterialId As Long _  
) As Boolean
```

SOLIDWORKS Type Library

AddSpecificDimension Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddSpecificDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal DimensionType As Long, _  
    ByRef Error As Long _  
) As Object
```

SOLIDWORKS Type Library

AddSymmetricDimension Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddSymmetricDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

SOLIDWORKS Type Library

AlignDimensions Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AlignDimensions( _  
    ByVal AlignType As Long, _  
    ByVal SpaceValue As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AlignRunningDimension Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Sub AlignRunningDimension()
```

SOLIDWORKS Type Library

AnnotationViewCount Property (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Property AnnotationViewCount As Long
```

SOLIDWORKS Type Library

AnnotationViews Property (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Property AnnotationViews As Variant
```

SOLIDWORKS Type Library

ApplyFormatPainterToAll Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Sub ApplyFormatPainterToAll()
```

SOLIDWORKS Type Library

ApplyTexture Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function ApplyTexture( _  
    ByVal Scale As Long, _  
    ByVal Angle As Double, _  
    ByVal TextureFilename As String, _  
    ByVal BlendColor As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

AppPageSetup Property (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Property AppPageSetup As PageSetup
```

SOLIDWORKS Type Library

BreakAllExternalFileReferences2 Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Sub BreakAllExternalFileReferences2( _  
    ByVal InsertFeatures As Boolean _  
    )
```

SOLIDWORKS Type Library

Capture3DView Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Capture3DView() As View3D
```

SOLIDWORKS Type Library

ChangeSketchPlane Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ChangeSketchPlane( _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

CheckVersionCompatibility Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CheckVersionCompatibility( _  
    ByVal Version As Long, _  
    ByVal showDialog As Long, _  
    ByRef Incompatibilities As Variant, _  
    ByRef Warnings As Variant _  
) As Long
```

SOLIDWORKS Type Library

ClearLastActiveConfigModel Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ClearLastActiveConfigModel As Boolean
```

SOLIDWORKS Type Library

CloseMessageBar Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CloseMessageBar( _  
    ByVal Handler As Object _  
)
```

SOLIDWORKS Type Library

CloseUserNotification Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CloseUserNotification( _  
    ByVal Handler As Object _  
)
```

SOLIDWORKS Type Library

CommandTabVisible Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CommandTabVisible( _  
    ByVal TabIndex As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

Compare3DPMI Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Compare3DPMI( _  
    ByVal ReferenceDocument As String, _  
    ByVal ModifiedDocument As String, _  
    ByVal ReportName As String, _  
    ByVal ReportFolderPath As String, _  
    ByVal ReportSaveOptions As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

CopyDraftingStandard Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CopyDraftingStandard( _  
    ByVal Name As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

Create3DBoundingBox Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Create3DBoundingBox()
```

SOLIDWORKS Type Library

CreateAdvancedHoleElementData Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateAdvancedHoleElementData( _  
    ByVal ElmType As Long _  
    ) As Object
```

SOLIDWORKS Type Library

CreateBalloonOptions Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateBalloonOptions() As BalloonOptions
```

SOLIDWORKS Type Library

CreateCallout Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCallout( _  
    ByVal NumberOfRows As Long, _  
    ByVal Handler As Object _  
    ) As Callout
```

SOLIDWORKS Type Library

CreateDecal Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDecal() As Decal
```

SOLIDWORKS Type Library

CreateMassProperty Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateMassProperty() As MassProperty
```

SOLIDWORKS Type Library

CreateMassProperty2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateMassProperty2() As Object
```

SOLIDWORKS Type Library

CreateMeasure Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateMeasure() As Measure
```

SOLIDWORKS Type Library

CreateOLEObject Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateOLEObject( _  
    ByVal Aspect As Long, _  
    ByVal Position As Variant, _  
    ByVal Buffer As Variant, _  
    ByRef ErrorCode As Long _  
) As SwOLEObject
```

SOLIDWORKS Type Library

CreatePresentation Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePresentation( _  
    ByVal PathName As String, _  
    ByVal ThemeXML As String, _  
    ByVal Options As Long, _  
    ByVal TextNameArray As Variant, _  
    ByVal TextArray As Variant, _  
    ByVal TextureArray As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

CreatePresentation2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreatePresentation2( _  
    ByVal PathName As String, _  
    ByVal ThemeXML As String, _  
    ByVal Options As Long, _  
    ByVal NamedViewArray As Variant, _  
    ByVal TextNameArray As Variant, _  
    ByVal TextArray As Variant _  
)
```

SOLIDWORKS Type Library

CreateRenderMaterial Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateRenderMaterial( _  
    ByVal PathName As String _  
) As RenderMaterial
```

SOLIDWORKS Type Library

CreateStackedBalloonOptions Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateStackedBalloonOptions() As StackedBalloonOptions
```

SOLIDWORKS Type Library

CreateStructureSystem Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateStructureSystem( _  
    ByVal PrimaryMembersData As Variant, _  
    ByVal SecondaryMembersData As Variant _  
) As Feature
```

SOLIDWORKS Type Library

CreateStructureSystemMemberData Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateStructureSystemMemberData( _  
    ByVal MemberType As Long _  
) As Object
```

SOLIDWORKS Type Library

CreateTexture Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTexture( _  
    ByVal MatName As String, _  
    ByVal Scale As Double, _  
    ByVal Angle As Double, _  
    ByVal Blend As Boolean _  
) As Texture
```

SOLIDWORKS Type Library

CustomPropertyBuilderTemplate Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CustomPropertyBuilderTemplate( _  
    ByVal WeldmentTemplate As Boolean _  
) As String
```

SOLIDWORKS Type Library

CustomPropertyManager Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CustomPropertyManager( _  
    ByVal ConfigName As String _  
) As CustomPropertyManager
```

SOLIDWORKS Type Library

DeActivateFeatureMgrViewx64 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeActivateFeatureMgrViewx64( _  
    ByRef AppView As Unknown _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteAllDecals Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteAllDecals() As Boolean
```

SOLIDWORKS Type Library

DeleteAttachment Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteAttachment( _  
    ByVal FileName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteDecal Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteDecal( _  
    ByVal DecalID As Long, _  
    ByVal BReassignIdsAndInvalidate As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteDisplayStateSpecificRenderMaterial Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteDisplayStateSpecificRenderMaterial( _  
    ByVal PwMaterialId1 As Variant, _  
    ByVal PwMaterialId2 As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteDraftingStandard Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteDraftingStandard() As Boolean
```

SOLIDWORKS Type Library

DeleteFeatureMgrViewx64 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteFeatureMgrViewx64( _  
    ByRef AppView As Unknown _  
)
```

SOLIDWORKS Type Library

DeleteRenderMaterial Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteRenderMaterial( _  
    ByVal PwMaterialId As Long, _  
    ByVal BReassignIdsAndInvalidate As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteScene Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteScene()
```

SOLIDWORKS Type Library

DeleteSearchData Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteSearchData( _  
    ByVal AppName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteSelection2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteSelection2( _  
    ByVal DeleteOptions As Long _  
) As Boolean
```

SOLIDWORKS Type Library

DimXpertManager Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property DimXpertManager( _  
    ByVal Configuration As String, _
```

```
ByVal CreateSchema As Boolean _  
) As DimXpertManager
```

SOLIDWORKS Type Library

DisplayMode Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property DisplayMode( _  
    ByVal Setting As DisplayStateSetting _  
) As Variant
```

SOLIDWORKS Type Library

DisplayStateSpecMaterialPropertyValues Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property DisplayStateSpecMaterialPropertyValues( _  
    ByVal Setting As DisplayStateSetting _  
) As Variant
```

SOLIDWORKS Type Library

DisplayTitle Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property DisplayTitle As String
```

SOLIDWORKS Type Library

Document Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Document As ModelDoc2
```

SOLIDWORKS Type Library

EditBalloonProperties Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EditBalloonProperties( _  
    ByVal Style As Long, _  
    ByVal Size As Long, _  
    ByVal UpperTextStyle As Long, _  
    ByVal UpperText As String, _  
    ByVal LowerTextStyle As Long, _  
    ByVal LowerText As String, _  
    ByVal CustomSize As Double, _  
    ByVal ShowQuantity As Boolean, _  
    ByVal QuantityPlacement As Integer, _  
    ByVal QuantityDenotationText As String _  
) As Object
```

SOLIDWORKS Type Library

EditBalloonProperties2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EditBalloonProperties2( _  
    ByVal Style As Long, _
```

```

    ByVal Size As Long, _
    ByVal UpperTextStyle As Long, _
    ByVal UpperText As String, _
    ByVal LowerTextStyle As Long, _
    ByVal LowerText As String, _
    ByVal CustomSize As Double, _
    ByVal ShowQuantity As Boolean, _
    ByVal QuantityPlacement As Integer, _
    ByVal QuantityDenotationText As String, _
    ByVal QuantityDistance As Double _
) As Object

```

SOLIDWORKS Type Library

EditDimensionProperties Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function EditDimensionProperties( _
    ByVal TolType As Long, _
    ByVal TolMax As Double, _
    ByVal TolMin As Double, _
    ByVal TolMaxFit As String, _
    ByVal TolMinFit As String, _
    ByVal UseDocPrec As Boolean, _
    ByVal Precision As Long, _
    ByVal ArrowsIn As Long, _
    ByVal UseDocArrows As Boolean, _
    ByVal Arrow1 As Long, _
    ByVal Arrow2 As Long, _
    ByVal PrefixText As String, _
    ByVal SuffixText As String, _
    ByVal ShowValue As Boolean, _
    ByVal CalloutText1 As String, _
    ByVal CalloutText2 As String, _
    ByVal DimensionLowerText As String, _
    ByVal CenterText As Boolean, _
    ByVal ConfigOption As Long, _
    ByVal ConfigNames As Variant _
) As Boolean

```

SOLIDWORKS Type Library

EditRebuildAll Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function EditRebuildAll() As Boolean

```

SOLIDWORKS Type Library

FeatureManagerFilterString Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Property FeatureManagerFilterString As String

```

SOLIDWORKS Type Library

FindTrackedObjects Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function FindTrackedObjects( _
    ByVal TrackingCookie As Long, _
    ByVal SearchObject As Object, _
    ByVal TypesFilter As Variant, _

```



```
ByVal TrackingIDs As Variant _  
) As Variant
```

SOLIDWORKS Type Library

FinishRecordingUndoObject Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function FinishRecordingUndoObject( _  
    ByVal UndoObjectName As String _  
) As Boolean
```

SOLIDWORKS Type Library

FinishRecordingUndoObject2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function FinishRecordingUndoObject2( _  
    ByVal UndoObjectName As String, _  
    ByVal MakeHidden As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

FlyoutFeatureTreeVisibility Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FlyoutFeatureTreeVisibility As Long
```

SOLIDWORKS Type Library

ForceRebuildAll Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ForceRebuildAll() As Boolean
```

SOLIDWORKS Type Library

GeodesicSketchOffset Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GeodesicSketchOffset( _  
    ByVal Offset As Double, _  
    ByVal Reverse As Boolean, _  
    ByVal MakeConstruct As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

Get3DExperienceModelType Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get3DExperienceModelType() As Long
```

SOLIDWORKS Type Library

Get3DView Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get3DView( _  
    ByVal Name As String _  
) As View3D
```

SOLIDWORKS Type Library

Get3DViewCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get3DViewCount() As Long
```

SOLIDWORKS Type Library

Get3DViewNames Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get3DViewNames() As Variant
```

SOLIDWORKS Type Library

Get3DViews Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get3DViews() As Variant
```

SOLIDWORKS Type Library

GetActiveAnnotationView Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetActiveAnnotationView() As Object
```

SOLIDWORKS Type Library

GetActivePropertyManagerPage Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetActivePropertyManagerPage() As String
```

SOLIDWORKS Type Library

GetAdvancedSaveAsOptions Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAdvancedSaveAsOptions( _  
    ByVal Options As Long _  
) As Object
```

SOLIDWORKS Type Library

GetAdvancedSpotLightProperties Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetAdvancedSpotLightProperties( _  
    ByVal Name As String, _  
    ByRef Exponent As Double, _  
    ByRef AttenuationConst As Double, _
```

```
ByRef AttenuationLinear As Double, _  
ByRef AttenuationQuad As Double _  
)
```

SOLIDWORKS Type Library

GetAnnotationCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotationCount() As Long
```

SOLIDWORKS Type Library

GetAnnotations Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotations() As Variant
```

SOLIDWORKS Type Library

GetAnnotationsByType Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotationsByType( _  
ByVal Type As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetAppearanceSetting Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAppearanceSetting() As AppearanceSetting
```

SOLIDWORKS Type Library

GetAttachmentCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAttachmentCount() As Long
```

SOLIDWORKS Type Library

GetAttachments Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAttachments( _  
ByRef LinkedVar As Variant _  
) As Variant
```

SOLIDWORKS Type Library

GetCalloutVariableString Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCalloutVariableString( _  
ByVal Variable As Long _  
) As String
```

SOLIDWORKS Type Library

GetCameraById Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCameraById( _  
    ByVal CameraId As Long _  
) As Camera
```

SOLIDWORKS Type Library

GetCameraCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCameraCount() As Long
```

SOLIDWORKS Type Library

GetCameraDefinition Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCameraDefinition() As Camera
```

SOLIDWORKS Type Library

GetCommandTabs Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCommandTabs() As Variant
```

SOLIDWORKS Type Library

GetCoordinateSystemTransformByName Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCoordinateSystemTransformByName( _  
    ByVal NameIn As String _  
) As MathTransform
```

SOLIDWORKS Type Library

GetCorresponding Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCorresponding( _  
    ByVal InputObject As Object _  
) As Object
```

SOLIDWORKS Type Library

GetCorresponding2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCorresponding2( _  
    ByVal InputObject As Object _  
) As Object
```

GetCorrespondingEntity Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetCorrespondingEntity( _  
    ByVal Entity As Object _  
) As Object
```

GetCorrespondingEntity2 Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetCorrespondingEntity2( _  
    ByVal Entity As Object _  
) As Object
```

GetCostingManager Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetCostingManager() As Object
```

GetCSYSDistances Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetCSYSDistances( _  
    ByRef TotDistance As Double, _  
    ByRef XDistance As Double, _  
    ByRef YDistance As Double, _  
    ByRef ZDistance As Double _  
) As Boolean
```

GetCSYSEulersAngularRotation Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetCSYSEulersAngularRotation( _  
    ByRef phiAngle As Double, _  
    ByRef thetaAngle As Double, _  
    ByRef psiAngle As Double _  
) As Boolean
```

GetCSYSXYZAngularRotation Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetCSYSXYZAngularRotation( _  
    ByRef XAngle As Double, _  
    ByRef YAngle As Double, _  
    ByRef ZAngle As Double _  
) As Boolean
```

GetDecal Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDecal( _  
    ByVal ID As Long, _  
    ByVal Configuration As String _  
    ) As Decal
```

SOLIDWORKS Type Library

GetDecals Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDecals() As Variant
```

SOLIDWORKS Type Library

GetDecalsCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDecalsCount() As Long
```

SOLIDWORKS Type Library

GetDependencies Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDependencies( _  
    ByVal Traverseflag As Boolean, _  
    ByVal Searchflag As Boolean, _  
    ByVal AddReadOnlyInfo As Boolean, _  
    ByVal ListBrokenRefs As Boolean, _  
    ByVal AppendImportedPaths As Boolean _  
    ) As Variant
```

SOLIDWORKS Type Library

GetDisplayStateSetting Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDisplayStateSetting( _  
    ByVal Option As Long _  
    ) As DisplayStateSetting
```

SOLIDWORKS Type Library

GetDraftingStandardNames Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDraftingStandardNames() As Variant
```

SOLIDWORKS Type Library

GetFlattenSheetMetalPersistReference Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFlattenSheetMetalPersistReference( _  
    ByVal DispObj As Object _
```

) As Variant

SOLIDWORKS Type Library

GetGeneralTableAnnotation Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetGeneralTableAnnotation( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal TableTemplate As String, _  
    ByVal Rows As Long, _  
    ByVal Columns As Long _  
    ) As TableAnnotation
```

SOLIDWORKS Type Library

GetKeepLightInRenderScene Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetKeepLightInRenderScene( _  
    ByVal ID As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetLastFeatureAdded Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLastFeatureAdded() As Feature
```

SOLIDWORKS Type Library

GetLicenseType Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLicenseType() As Long
```

SOLIDWORKS Type Library

GetLightEnabledInRender Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLightEnabledInRender( _  
    ByVal ID As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetMassProperties Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMassProperties( _  
    ByVal Accuracy As Long, _  
    ByRef Status As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

GetMassProperties2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMassProperties2( _  
    ByVal Accuracy As Long, _  
    ByRef Status As Long, _  
    ByVal UseSelected As Boolean _  
    ) As Variant
```

SOLIDWORKS Type Library

GetMaterial Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMaterial( _  
    ByVal ID As Long, _  
    ByVal Configuration As String _  
    ) As RenderMaterial
```

SOLIDWORKS Type Library

GetMaterialPropertyValues Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMaterialPropertyValues( _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

GetMBD3DPdfData Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMBD3DPdfData() As Object
```

SOLIDWORKS Type Library

GetMBDSTEP242Data Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMBDSTEP242Data() As Object
```

SOLIDWORKS Type Library

GetModelBreakViewNames Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetModelBreakViewNames( _  
    ByRef Views As Variant _  
    ) As Long
```

SOLIDWORKS Type Library

GetModelView Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)


```
Public Function GetModelView( _  
    ByVal WindowID As Long, _  
    ByVal Row As Long, _  
    ByVal Col As Long _  
) As ModelView
```

SOLIDWORKS Type Library

GetModelViewCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetModelViewCount() As Long
```

SOLIDWORKS Type Library

GetModelViews Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetModelViews() As Variant
```

SOLIDWORKS Type Library

GetMotionStudyManager Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMotionStudyManager() As Object
```

SOLIDWORKS Type Library

GetNamedViewRotation Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNamedViewRotation( _  
    ByVal Name As String _  
) As Variant
```

SOLIDWORKS Type Library

GetObjectByPersistReference Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetObjectByPersistReference( _  
    ByVal PersistId As Variant _  
) As Object
```

SOLIDWORKS Type Library

GetObjectByPersistReference2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetObjectByPersistReference2( _  
    ByVal PersistId As Variant, _  
    ByRef ErrorCode As Long _  
) As Object
```

SOLIDWORKS Type Library

GetObjectByPersistReference3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetObjectByPersistReference3( _  
    ByVal PersistId As Variant, _  
    ByRef ErrorCode As Long _  
    ) As Object
```

SOLIDWORKS Type Library

GetObjectId Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetObjectId( _  
    ByVal Annotation As Annotation _  
    ) As Long
```

SOLIDWORKS Type Library

GetOLEObjectCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOLEObjectCount( _  
    ByVal Options As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetOLEObjects Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOLEObjects( _  
    ByVal Options As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

GetPackAndGo Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPackAndGo() As PackAndGo
```

SOLIDWORKS Type Library

GetParameterValue Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetParameterValue( _  
    ByVal DimName As String, _  
    ByVal Reserved As Long _  
    ) As Double
```

SOLIDWORKS Type Library

GetPersistReference Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPersistReference( _  
    ByVal DispObj As Object _  
    ) As Variant
```

SOLIDWORKS Type Library

GetPersistReference3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPersistReference3( _  
    ByVal DispObj As Object _  
    ) As Variant
```

SOLIDWORKS Type Library

GetPersistReferenceCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPersistReferenceCount( _  
    ByVal DispObj As Object _  
    ) As Long
```

SOLIDWORKS Type Library

GetPersistReferenceCount3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPersistReferenceCount3( _  
    ByVal DispObj As Object _  
    ) As Long
```

SOLIDWORKS Type Library

GetPLMID Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPLMID() As String
```

SOLIDWORKS Type Library

GetPrint3DDialog Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPrint3DDialog() As Print3DDialog
```

SOLIDWORKS Type Library

GetPrintSpecification Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPrintSpecification() As Object
```

SOLIDWORKS Type Library

GetRenderCustomReferences Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRenderCustomReferences() As Variant
```

SOLIDWORKS Type Library

GetRenderMaterials Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRenderMaterials() As Variant
```

SOLIDWORKS Type Library

GetRenderMaterials2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRenderMaterials2( _  
    ByVal DisplayStateOption As Long, _  
    ByVal DisplayStateNames As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

GetRenderMaterialsCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRenderMaterialsCount() As Long
```

SOLIDWORKS Type Library

GetRenderMaterialsCount2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRenderMaterialsCount2( _  
    ByVal DisplayStateOption As Long, _  
    ByVal DisplayStateNames As Variant _  
    ) As Long
```

SOLIDWORKS Type Library

GetRenderStockReferences Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRenderStockReferences() As Variant
```

SOLIDWORKS Type Library

GetRoutingComponentManager Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRoutingComponentManager() As Object
```

SOLIDWORKS Type Library

GetScanto3D Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetScanto3D() As Object
```

SOLIDWORKS Type Library

GetSceneBkgDIBx64 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSceneBkgDIBx64() As Unknown
```

SOLIDWORKS Type Library

GetSearchData Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSearchData( _  
    ByVal AppName As String, _  
    ByRef AppNames As Variant, _  
    ByRef NodeNames As Variant, _  
    ByRef NodeValues As Variant _  
    ) As Long
```

SOLIDWORKS Type Library

GetSearchDataCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSearchDataCount( _  
    ByVal AppName As String _  
    ) As Long
```

SOLIDWORKS Type Library

GetSectionProperties Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSectionProperties( _  
    ByVal Sections As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

GetSectionProperties2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSectionProperties2( _  
    ByVal Sections As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

GetSheetMetalObjectsByPersistReference Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSheetMetalObjectsByPersistReference( _  
    ByVal PersistId As Variant, _  
    ByRef ErrorCode As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

GetSphericalBoxDiameter Method (ModelDocExtension)

Syntax

```
Public Function GetSphericalBoxDiameter() As Double
```

SOLIDWORKS Type Library

GetStream Method (ModelDocExtension)

Visual Basic for Applications (VBA)

```
Public Function GetStream( _  
    ByVal StreamType As Long, _  
    ByRef ReadOnly As Boolean _  
) As Unknown
```

SOLIDWORKS Type Library

GetSunLightAdvancedPropertyValues Method (ModelDocExtension)

Visual Basic for Applications (VBA)

```
Public Function GetSunLightAdvancedPropertyValues( _  
    ByRef Haze As Double, _  
    ByRef SunDiameter As Double, _  
    ByRef GroundAlbedo As Long, _  
    ByRef SkyGamma As Double _  
) As Boolean
```

SOLIDWORKS Type Library

GetSunLightSourcePropertyValues Method (ModelDocExtension)

Visual Basic for Applications (VBA)

```
Public Function GetSunLightSourcePropertyValues( _  
    ByRef NorthDirection As MathVector, _  
    ByRef NorthLatitude As Double, _  
    ByRef EastLongitude As Double, _  
    ByRef TimeZone As Double, _  
    ByRef DateTime As String _  
) As Boolean
```