

SOLIDWORKS API (VB6 COM) — Reference (100/102): View (part 3 of 3)

SOLIDWORKS API Documentation (converted from CHM)

View (part 3 of 3) (Type)

SOLIDWORKS Type Library

IGetVisibleEntities Method (View)



Visual Basic for Applications (VBA)

```
Public Function IGetVisibleEntities( _  
    ByVal LpViewComponent As Component2, _  
    ByVal EntityType As Long, _  
    ByVal ViewEntityCount As Long _  
) As Entity
```

SOLIDWORKS Type Library

IGetVisibleEntities2 Method (View)



Visual Basic for Applications (VBA)

```
Public Function IGetVisibleEntities2( _  
    ByVal LpViewComponent As Component2, _  
    ByVal EntityType As Long, _  
    ByVal ViewEntityCount As Long _  
) As Entity
```

SOLIDWORKS Type Library

IGetWeldBeads Method (View)



Visual Basic for Applications (VBA)

```
Public Function IGetWeldBeads( _  
    ByVal NumWeldBead As Long _  
) As WeldBead
```

SOLIDWORKS Type Library

IGetWeldSymbols Method (View)



Visual Basic for Applications (VBA)

```
Public Function IGetWeldSymbols( _  
    ByVal NumWeldSymbol As Long _  
) As WeldSymbol
```

SOLIDWORKS Type Library

IGetWitnessGeomInfo Method (View)



Visual Basic for Applications (VBA)

```
Public Function IGetWitnessGeomInfo( _  
    ByVal ArraySize As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetXform Method (View)



Visual Basic for Applications (VBA)

```
Public Function IGetXform() As Double
```

SOLIDWORKS Type Library

InsertBomTable Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IInsertBomTable( _  
    ByVal Template As String, _  
    ByVal Xloc As Double, _  
    ByVal Yloc As Double, _  
    ByRef Errors As Long _  
) As BomTable
```

SOLIDWORKS Type Library

ImportAnnotations Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ImportAnnotations( _  
    ByVal IncludeDesignAnnotations As Boolean, _  
    ByVal IncludeCosmeticThreads As Boolean, _  
    ByVal IncludeDimXpertAnnotations As Boolean, _  
    ByVal IncludeHiddenFeatureItems As Boolean, _  
    ByVal Include3DViewAnnotations As Boolean _  
)
```

SOLIDWORKS Type Library

InsertAlternateView Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertAlternateView( _  
    ByVal ConfigurationName As String _  
) As View
```

SOLIDWORKS Type Library

InsertBendTable Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBendTable( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal StartValue As String, _  
    ByVal TableTemplate As String _  
) As BendTableAnnotation
```

SOLIDWORKS Type Library

InsertBomTable Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable( _  
    ByVal Template As String, _  
    ByVal Xloc As Double, _  
    ByVal Yloc As Double, _  
    ByRef Errors As Long _  
) As Object
```

SOLIDWORKS Type Library

InsertBomTable2 Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable2( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal BomType As Long, _  
    ByVal Configuration As String, _  
    ByVal TableTemplate As String _  
) As BomTableAnnotation
```

SOLIDWORKS Type Library

[InsertBomTable3 Method \(View\)](#)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable3( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal BomType As Long, _  
    ByVal Configuration As String, _  
    ByVal TableTemplate As String, _  
    ByVal Hidden As Boolean _  
) As BomTableAnnotation
```

SOLIDWORKS Type Library

[InsertBomTable4 Method \(View\)](#)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable4( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal BomType As Long, _  
    ByVal Configuration As String, _  
    ByVal TableTemplate As String, _  
    ByVal Hidden As Boolean, _  
    ByVal IndentedNumberingType As Long, _  
    ByVal DetailedCutList As Boolean _  
) As BomTableAnnotation
```

SOLIDWORKS Type Library

[InsertBomTable5 Method \(View\)](#)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable5( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal BomType As Long, _  
    ByVal Configuration As String, _  
    ByVal TableTemplate As String, _  
    ByVal Hidden As Boolean, _  
    ByVal IndentedNumberingType As Long, _  
    ByVal DetailedCutList As Boolean, _  
    ByVal DissolvePartLevelRows As Boolean _  
) As Object
```

 Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable6( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal BomType As Long, _  
    ByVal Configuration As String, _  
    ByVal TableTemplate As String, _  
    ByVal Hidden As Boolean, _  
    ByVal IndentedNumberingType As Long, _  
    ByVal DetailedCutList As Boolean, _  
    ByVal DissolvePartLevelRows As Boolean, _  
    ByVal DisplayAsOneItem As Boolean _  
) As Object
```

 Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBreak( _  
    ByVal Orientation As Long, _  
    ByVal Position1 As Double, _  
    ByVal Position2 As Double, _  
    ByVal Style As Long _  
) As BreakLine
```

 Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBreak2( _  
    ByVal Orientation As Long, _  
    ByVal Position1 As Double, _  
    ByVal Position2 As Double, _  
    ByVal Style As Long, _  
    ByVal ShapeIntensity As Long _  
) As BreakLine
```

 Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBreak3( _  
    ByVal Orientation As Long, _  
    ByVal Position1 As Double, _  
    ByVal Position2 As Double, _  
    ByVal Style As Long, _  
    ByVal ShapeIntensity As Long, _  
    ByVal BreakSketchBlocks As Boolean _  
) As Object
```

 Syntax

```
Public Sub InsertCutListPropertyNote( _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal Z As Double _
)
```

 Syntax

```
Public Function InsertHoleTable( _
    ByVal UseAnchorPoint As Boolean, _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal AnchorType As Long, _
    ByVal TableTemplate As String _
) As HoleTableAnnotation
```

 Syntax

```
Public Function InsertHoleTable2( _
    ByVal UseAnchorPoint As Boolean, _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal AnchorType As Long, _
    ByVal StartValue As String, _
    ByVal TableTemplate As String _
) As HoleTableAnnotation
```

 Syntax

```
Public Function InsertHoleTable3( _
    ByVal UseAnchorPoint As Boolean, _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal AnchorType As Long, _
    ByVal StartValue As String, _
    ByVal Template As String, _
    ByVal TagOrder As Long, _
    ByVal TagType As Long, _
    ByVal ManualTags As Variant _
) As Object
```

 Syntax

```
Public Function InsertPunchTable( _
    ByVal UseAnchorPoint As Boolean, _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal AnchorType As Long, _
    ByVal StartValue As String, _
)
```

```
ByVal TableTemplate As String _  
) As PunchTableAnnotation
```

SOLIDWORKS Type Library

InsertViewAsBlock Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertViewAsBlock( _  
    ByVal InsertionPoint As MathPoint, _  
    ByVal Position As MathPoint _  
) As Boolean
```

SOLIDWORKS Type Library

InsertWeldmentTable Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertWeldmentTable( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal Configuration As String, _  
    ByVal TableTemplate As String _  
) As WeldmentCutListAnnotation
```

SOLIDWORKS Type Library

InsertWeldTable Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertWeldTable( _  
    ByVal UseAnchorPoint As Boolean, _  
    ByVal IncludeAnnotations As Boolean, _  
    ByVal CombineSameType As Boolean, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal AnchorType As Long, _  
    ByVal Configuration As String, _  
    ByVal TableTemplate As String _  
) As Boolean
```

SOLIDWORKS Type Library

IPosition Property (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IPosition As Double
```

SOLIDWORKS Type Library

IsBroken Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsBroken() As Boolean
```

SOLIDWORKS Type Library

IScaleRatio Property (View)

Syntax

```
Public Property IScaleRatio As Double
```

SOLIDWORKS Type Library

IsCropped Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsCropped() As Boolean
```

SOLIDWORKS Type Library

ISelectEntity Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISelectEntity( _  
    ByVal Entity As Entity, _  
    ByVal AppendFlag As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

ISetBodies Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetBodies( _  
    ByVal Count As Long, _  
    ByVal BodyArray As Body2 _  
    )
```

SOLIDWORKS Type Library

ISetHiddenEdges Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetHiddenEdges( _  
    ByVal HiddenEdgeCount As Long, _  
    ByVal EdgeList As Edge _  
    )
```

SOLIDWORKS Type Library

ISetXform Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetXform( _  
    ByRef Transform As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

IsExploded Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsExploded() As Boolean
```

SOLIDWORKS Type Library

IsFlatPatternView Method (View)



Visual Basic for Applications (VBA)

```
Public Function IsFlatPatternView() As Boolean
```

SOLIDWORKS Type Library

IsLightweight Method (View)



Visual Basic for Applications (VBA)

```
Public Function IsLightweight() As Boolean
```

SOLIDWORKS Type Library

IsModelBreakState Method (View)



Visual Basic for Applications (VBA)

```
Public Function IsModelBreakState() As Boolean
```

SOLIDWORKS Type Library

IsModelLoaded Method (View)



Visual Basic for Applications (VBA)

```
Public Function IsModelLoaded() As Boolean
```

SOLIDWORKS Type Library

IsModelOutOfDate Method (View)



Visual Basic for Applications (VBA)

```
Public Function IsModelOutOfDate() As Boolean
```

SOLIDWORKS Type Library

IsPerspectiveView Method (View)



Visual Basic for Applications (VBA)

```
Public Function IsPerspectiveView() As Boolean
```

SOLIDWORKS Type Library

LinkParentConfiguration Property (View)



Visual Basic for Applications (VBA)

```
Public Property LinkParentConfiguration As Boolean
```

SOLIDWORKS Type Library

LoadModel Method (View)



Visual Basic for Applications (VBA)

```
Public Function LoadModel() As Long
```

SOLIDWORKS Type Library

MergeBendTags Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Function MergeBendTags( _  
    ByVal Merge As Boolean, _  
    ByVal BendNotes As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

ModelToViewTransform Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ModelToViewTransform As MathTransform
```

SOLIDWORKS Type Library

ModifyViewArrow Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ModifyViewArrow( _  
    ByVal DrawingViewNameIn As String, _  
    ByVal ArrowNameIn As String _  
    )
```

SOLIDWORKS Type Library

MoveViewArrow Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub MoveViewArrow( _  
    ByVal DrawingViewNameIn As String, _  
    ByVal Dx As Double, _  
    ByVal Dy As Double, _  
    ByVal Dz As Double _  
    )
```

SOLIDWORKS Type Library

Name Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Name As String
```

SOLIDWORKS Type Library

Position Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Position As Variant
```

SOLIDWORKS Type Library

PositionLocked Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PositionLocked As Boolean
```

SOLIDWORKS Type Library

ProjectedDimensions Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ProjectedDimensions As Boolean
```

SOLIDWORKS Type Library

ReferencedConfiguration Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ReferencedConfiguration As String
```

SOLIDWORKS Type Library

ReferencedConfigurationID Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ReferencedConfigurationID As Long
```

SOLIDWORKS Type Library

ReferencedDocument Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ReferencedDocument As ModelDoc2
```

SOLIDWORKS Type Library

RemoveAlignment Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveAlignment()
```

SOLIDWORKS Type Library

ReplaceViewWithBlock Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ReplaceViewWithBlock( _  
    ByVal InsertionPoint As MathPoint _  
) As Boolean
```

SOLIDWORKS Type Library

ReplaceViewWithSketch Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ReplaceViewWithSketch() As Boolean
```

SOLIDWORKS Type Library

ResetSketchVisibility Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ResetSketchVisibility()
```

SOLIDWORKS Type Library

RootDrawingComponent Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property RootDrawingComponent As DrawingComponent
```

SOLIDWORKS Type Library

RootDrawingComponent2 Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property RootDrawingComponent2( _  
    ByVal InChildContext As Boolean _  
) As DrawingComponent
```

SOLIDWORKS Type Library

ScaleDecimal Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ScaleDecimal As Double
```

SOLIDWORKS Type Library

ScaleHatchPattern Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ScaleHatchPattern As Boolean
```

SOLIDWORKS Type Library

ScaleRatio Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ScaleRatio As Variant
```

SOLIDWORKS Type Library

SelectEntity Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SelectEntity( _  
    ByVal Entity As Object, _  
    ByVal AppendFlag As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

SetBendNoteTextFormat Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetBendNoteTextFormat( _  
    ByVal Format As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetDisplayMode Method (View)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetDisplayMode( _  
    ByVal DisplayIn As Long _  
)
```

SOLIDWORKS Type Library

[SetDisplayMode2 Method \(View\)](#)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetDisplayMode2( _  
    ByVal Mode As Long, _  
    ByVal Facetted As Boolean, _  
    ByVal Edges As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

[SetDisplayMode3 Method \(View\)](#)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetDisplayMode3( _  
    ByVal UseParent As Boolean, _  
    ByVal Mode As Long, _  
    ByVal Facetted As Boolean, _  
    ByVal Edges As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

[SetDisplayMode4 Method \(View\)](#)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetDisplayMode4( _  
    ByVal UseParent As Boolean, _  
    ByVal Mode As Long, _  
    ByVal Faceted As Boolean, _  
    ByVal Edges As Boolean, _  
    ByVal CThreadHighQuality As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

[SetDisplayTangentEdges Method \(View\)](#)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetDisplayTangentEdges( _  
    ByVal DisplayIn As Boolean _  
)
```

SOLIDWORKS Type Library

[SetDisplayTangentEdges2 Method \(View\)](#)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetDisplayTangentEdges2( _  
    ByVal DisplayIn As Long _  
)
```

SetKeepLinkedToBOM Method (View) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetKeepLinkedToBOM( _  
    ByVal Linked As Boolean, _  
    ByVal Name As String _  
) As Boolean
```

SetLightweightToResolved Method (View) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub SetLightweightToResolved()
```

SetMirrorViewOrientation Method (View) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetMirrorViewOrientation( _  
    ByVal BSetIsMirrorView As Boolean, _  
    ByVal BMirrorVieworientation As Long _  
) As Boolean
```

SetName2 Method (View) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetName2( _  
    ByVal Name As String _  
) As Boolean
```

SetResolvedToLightweight Method (View) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub SetResolvedToLightweight()
```

SetViewPosition Method (View) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetViewPosition( _  
    ByVal Position As Variant, _  
    ByVal MoveChildViews As Boolean _  
) As Boolean
```

SetVisible Method (View) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub SetVisible( _  
    ByVal Visible As Boolean, _  
    ByVal DependentsToo As Boolean _  
)
```

SOLIDWORKS Type Library

SetXform Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetXform( _  
    ByVal Transform As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

Sheet Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Sheet As Sheet
```

SOLIDWORKS Type Library

ShowExploded Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ShowExploded( _  
    ByVal ShowIt As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

ShowModelBreakState Method (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ShowModelBreakState( _  
    ByVal ShowIt As Boolean, _  
    ByVal BreakName As String _  
) As Boolean
```

SOLIDWORKS Type Library

ShowSheetMetalBendNotes Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowSheetMetalBendNotes As Boolean
```

SOLIDWORKS Type Library

SuppressState Property (View)



Syntax

Visual Basic for Applications (VBA)

```
Public Property SuppressState As Long
```

SOLIDWORKS Type Library

Type Property (View)



Syntax

Public Property Type As Long

SOLIDWORKS Type Library

UpdateViewDisplayGeometry Method (View)



```
Public Sub UpdateViewDisplayGeometry()
```

SOLIDWORKS Type Library

UseDefaultAlignment Method (View)



```
Public Sub UseDefaultAlignment()
```

SOLIDWORKS Type Library

UseParentScale Property (View)



```
Public Property UseParentScale As Boolean
```

SOLIDWORKS Type Library

UseSheetScale Property (View)



```
Public Property UseSheetScale As Long
```