

SOLIDWORKS Command IDs (swcommands) — Reference (1/1): _namespace_hierarchy- swMouse_e

SOLIDWORKS API Documentation (converted from CHM)

namespace_hierarchy (Type)

SOLIDWORKS API Commands Enumeration

[Send comments on this topic.](#)

SolidWorks.Interop.swcommands Namespace Inheritance Hierarchy

[See Also](#)



 **Inheritance Hierarchy**

System.Object



See Also

[SolidWorks.Interop.swcommands Assembly](#)

SolidWorks.Interop.swcommands (Namespace Overview)

SOLIDWORKS API Commands Enumeration

[Send comments on this topic.](#)

SolidWorks.Interop.swcommands Namespace

See Also [Inheritance Hierarchy](#)



SOLIDWORKS toolbar, menu, and mouse command enumerations

Enumerations

Enumeration	Description
swCommands_e	SOLIDWORKS toolbar and menu commands.
swMouse_e	Mouse commands.

See Also

[SolidWorks.Interop.swcommands Assembly](#)

swCommands_e (Type)

SOLIDWORKS API Commands Enumeration

swCommands_e Enumeration

See Also

▼

SolidWorks.Interop.swcommands Namespace : swCommands_e Enumeration

SOLIDWORKS toolbar and menu commands.

[Send comments on this topic.](#)

Syntax

```
Visual Basic (Declaration)

Public Enum swCommands_e
    Inherits System.Enum

C#

public enum swCommands_e : System.Enum

C++/CLI

public enum class swCommands_e : public System.Enum
```

Members

Member	Description
swCommand_Border_Editor	3156; valid only for drawings in Edit Sheet Format mode (run swCommands_e.swCommands_Edit_Template before running this command); Sheet Format toolbar > Automatic Border
swCommand_Cartoon_Shading	3170; valid only for assemblies and parts; View toolbar > View Settings > Cartoon
swCommand_ChildReferenceArrow	3152; valid only for assemblies; Assembly toolbar > Dynamic Reference Visualization (Child)
swCommand_Component_Preview_Window	3171; valid only for assemblies; Assembly toolbar > Component Preview Window
swCommand_Delete_Selected_BE	3158; valid only for drawings in Edit Sheet Format mode while the Automatic Border PropertyManager page is open; selects all items in Delete List
swCommand_Deselect_All_Selected_BE	3160; valid only for drawings in Edit Sheet Format mode while the Automatic Border PropertyManager page is open; deselects all selections in Delete List
swCommand_Hide_Show_Primary_Planes	3169; valid only for parts; View toolbar > Hide / Show Primary Planes
swCommand_ReferenceArrow_PopUp	3151; valid only for assemblies; Assembly toolbar > Dynamic Reference Visualization (Parent)
swCommand_Restore_Selected_BE	3159; valid only for drawings in Edit Sheet Format mode while the Automatic Border PropertyManager page is open; restores the selected items in Delete List
swCommand_Sheet_Format	3155; valid only for drawings; View menu > Toolbars > Sheet Format
swCommand_TemporaryFixGroup	3162; valid only for assemblies; Assembly toolbar > Temporary Fix/Group
swCommands_2DTo3D	509; alternative to swCommands_Toolbar_2dto3d; View menu > Toolbars > 2D to 3D
swCommands_2DTo3DCut	394; valid only for parts with a single 2D sketch in edit mode; 2D to 3D toolbar > Convert to Cut
swCommands_2DTo3DMakeRefsketchBack	378; valid only for parts with a single 2D sketch in edit mode; 2D to 3D toolbar > Add to Back Sketch
swCommands_2DTo3DMakeRefsketchBottom	376; valid only for parts with a single 2D sketch in edit mode; 2D to 3D toolbar > Add to Bottom Sketch
swCommands_2DTo3DMakeRefsketchFront	373; valid only for parts with a single 2D sketch in edit mode; 2D to 3D toolbar > Add to Front Sketch
swCommands_2DTo3DMakeRefsketchLeft	377; valid only for parts with a 2D sketch in edit mode; 2D to 3D toolbar > Add to Left Sketch
swCommands_2DTo3DMakeRefsketchRight	375; valid only for parts with a 2D sketch in edit mode; 2D to 3D toolbar > Add to Right Sketch
swCommands_2DTo3DMakeRefsketchTop	374; valid only for parts with a 2D sketch in edit mode; 2D to 3D toolbar > Add to Top Sketch
swCommands_3DDrawingView	548; valid only for drawings; View toolbar > 3D Drawing View
swCommands_3DExperienceDesignEngineer	3288; launches 3DEXPERIENCE from SOLIDWORKS Simulation; Tools toolbar > 3DEXPERIENCE Simulation Connector
swCommands_3DPDF_ADD_ALL_3DVIEW	3401; MBD toolbar > Publish to 3D PDF > Include Primary Views > Select all views
swCommands_3dpmi	3212; opens the 3D PMI Compare PropertyManager page; Tools menu > 3D PMI Compare Wizard
swCommands_3dPrintValidation	3191; opens the 3-D Print Validation PropertyManager page; View toolbar > 3D Print Validation
swCommands_3DSketch	89; Sketch toolbar > 3D Sketch
swCommands_3DSketchOnPlane	567; valid only for pre-selected planes; Sketch toolbar > 3D Sketch On Plane
swCommands_3dTexturizeSolidSurface	3333; converts solid and surface bodies to texturized graphics bodies; Features toolbar > Texturize Bodies
swCommands_3PointArc	80; Sketch toolbar > 3 Point Arc
swCommands_Activate_And_Orient_Annotation_View	2230; valid only for inactive annotation views that are oriented; in the FeatureManager design tree, Annotations > annotation_view RMB menu > Activate and Reorient
swCommands_Activate_Annotation_View	2213; in the FeatureManager design tree, Annotations > annotation_view RMB menu > Activate
swCommands_Activate_Doc_Or_Journal	2059; in the FeatureManager design tree, Design Binder > doc_name RMB menu > Open
swCommands_Activate_Sheet	1206; valid for a selected drawing sheet that is not activated, current, or in edit mode; in the FeatureManager design tree, sheet RMB menu > Activate
swCommands_ActivateFlexiblePartComp	3418; Assembly toolbar > Make Part Flexible
swCommands_Add_Bends	2290; valid for SOLIDWORKS Electrical add-in and an open assembly with a selected route junction point, opens the Add Bends PropertyManager page; Electrical toolbar > Add Bends
swCommands_Add_Comment	2062; in the FeatureManager design tree, component_feature_or_sheet RMB menu > Comment > Add Comment
swCommands_Add_Configuration	1534; in the ConfigurationManager, configuration_name RMB menu > Add Configuration or Add Derived Configuration
swCommands_Add_Constraint_AlongX	2204; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Along X ; when the Line Properties PropertyManager page is open for a selected line in the graphics area, sel_line RMB context menu > Make AlongX
swCommands_Add_Constraint_AlongY	2205; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Along Y ; when the Line Properties PropertyManager page is open for a selected line in the graphics area, sel_line RMB context menu > Make AlongY
swCommands_Add_Constraint_AlongZ	2206; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Along Z ; when the Line Properties PropertyManager page is open for a selected line in the graphics area, sel_line RMB context menu > Make AlongZ
swCommands_Add_Constraint_Atinter	1719; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Intersection
swCommands_Add_Constraint_Atmid	1718; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Midpoint
swCommands_Add_Constraint_Atpierce	1724; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Pierce
swCommands_Add_Constraint_Coinc	1720; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Coincident
swCommands_Add_Constraint_Colinear	1712; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Colinear
swCommands_Add_Constraint_Concent	1717; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Concentric
swCommands_Add_Constraint_Coradial	1713; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Coradial
swCommands_Add_Constraint_Equalcurvature	1729; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Equal Curvature
swCommands_Add_Constraint_Equaltangent	1730; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Equal tangent
swCommands_Add_Constraint_Fix	1723; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Fix ; when the Line Properties PropertyManager page is open for a selected line in the graphics area, sel_line RMB context menu > Make Fixed
swCommands_Add_Constraint_G3Touch	3425; valid only for part sketches in edit mode with a multi-selected arc and spline, adds a continuous curvature variation relation to the selected arc and spline; in the Properties PropertyManager page click Add Relations > Torsion Continuity ; in the pop-up constraints dialog, click Make Torsion Continuity
swCommands_Add_Constraint_Horiz	1710; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Horizontal
swCommands_Add_Constraint_Merge	1725; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Merge
swCommands_Add_Constraint_Normal	1726; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Normal
swCommands_Add_Constraint_Onsurface	2217; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > On Surface

swCommands_Add_Constraint_Parallel	1715; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Parallel
swCommands_Add_Constraint_Parallelyz	1727; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Parallel YZ
swCommands_Add_Constraint_Parallelex	1728; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Parallel ZX
swCommands_Add_Constraint_Perp	1714; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Perpendicular
swCommands_Add_Constraint_Planar_Offset	3003; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Offset
swCommands_Add_Constraint_SameCurvelen	3153; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Equal Arc/Spline
swCommands_Add_Constraint_Samelen	1721; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Equal
swCommands_Add_Constraint_Sym	1722; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Symmetric
swCommands_Add_Constraint_Tanface	1731; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Tangent to Face
swCommands_Add_Constraint_Tang	1716; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Tangent
swCommands_Add_Constraint_Traction	1732; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Traction
swCommands_Add_Constraint_Vert	1711; accessible only for part sketches in edit mode where this relation is possible; click Sketch toolbar > Relations > Add Relation or Tools menu > Relations > Add ; select a sketch segment in the graphics area; in the Add Relations PropertyManager page click Add Relations > Vertical
swCommands_Add_Coverings	2286; valid for the SOLIDWORKS Routing add-in and a selected route segment in an open routing assembly, opens the Covering PropertyManager page; Routing Tools toolbar > Covering
swCommands_Add_Derived_Configuration	2461; in the ConfigurationManager, <i>configuration_name</i> RMB menu > Add Derived Configuration
swCommands_Add_Feature_Dims	1552; valid for dimensioned parts; in FeatureManager design tree, <i>feature_name</i> RMB menu > Show All Dimensions
swCommands_Add_Fitting	2285; valid for the SOLIDWORKS Routing add-in and a routing assembly; Piping or Flexible Tubing or User Defined toolbar > Add Fitting
swCommands_Add_OverallDim_To_ChainDim	3424; valid only if an overall chain dimension does not already exist for the chain dimension set, automatically adds an overall dimension between a selected dimension in the chain dimension set and the dimension(s) that are farthest from the selection, in both directions if applicable; RMB menu > Add Overall
swCommands_Add_Part_Block	2823; valid for blocks created in assembly layouts; in the FeatureManager design tree, <i>block_name</i> RMB menu > Make Part from Block
swCommands_Add_Slope	3103; valid for the SOLIDWORKS Routing add-in and a piping assembly, opens the Pipe Slope PropertyManager page; Piping toolbar > Add Slope
swCommands_Add_Split_Feat_To_Asm	1818; valid only for parts with a split feature; Insert menu > Features > Create Assembly
swCommands_Add_To_Bookmark	3514; valid only in SOLIDWORKS Design connected to the 3DEXPERIENCE platform, adds the current file to the bookmark folder; Lifecycle and Collaboration toolbar > Bookmarks > Add to Bookmark
swCommands_Add_To_CMarkSet	3131; valid only for drawings with a center mark set; in the graphics view, <i>center_mark</i> RMB menu > Add to Center Mark Set
swCommands_Add_To_Palette	2171; valid for parts with a selected geometric tolerance symbol, opens the Add to Library PropertyManager page; in the graphics area, <i>geo_to</i> RMB menu > Add to Library ; also valid for assemblies; in the FeatureManager design tree, <i>component_name</i> RMB menu > Add to Library
swCommands_Add_To_Recent_Bookmark	3525; valid only in SOLIDWORKS Design connected to the 3DEXPERIENCE platform, adds selected files and components to your recent bookmarks; Lifecycle and Collaboration toolbar > Bookmarks > Add to Recent Bookmark
swCommands_AddCurvatureControl	416; valid only for 2D spline sketches; Spline Tools toolbar > Add Curvature Control
swCommands_AddRelation	71; valid for sketches in edit mode; Dimensions/Relations toolbar > Add Relation
swCommands_AddRemove	515; valid for blocks in edit mode; Layout or Blocks toolbar > Add/Remove
swCommands_AddTangencyControl	415; valid only for 2D and 3D spline sketches; Spline Tools toolbar > Add Tangency Control
swCommands_AddTo_Chain_Dimension	3406; valid for a selected dimension in a chain dimension set; RMB menu > Add to Chain
swCommands_AdvancedHoleWizard	3172; opens the Hole Specification PropertyManager page; Features toolbar > Advanced Hole Wizard
swCommands_AdvancedStructuralMember	3335; creates a structural member feature by sweeping pre-defined profiles along user-defined paths; Structure System toolbar > Create Structure System
swCommands_Align	474; alternative to swCommands_Toolbar_Align; View menu > Toolbars > Align
swCommands_Align_Horz	1511; valid for drawing view items; in the graphics area, <i>view_item</i> RMB menu > Alignment > Align Horizontal by Origin
swCommands_Align_Horz_By_Center	695; valid for drawing view items; in the graphics area, <i>view_item</i> RMB menu > Alignment > Align Horizontal by Center
swCommands_Align_Ordinate	1505; valid for drawings of circles or arcs with angular running dimensions; in the graphics area, <i>angular_running_dimension</i> RMB menu > Display Options > Align Running Dimension
swCommands_Align_Vert	1512; valid for drawing view items; in the graphics area, <i>view_item</i> RMB menu > Alignment > Align Vertical by Origin
swCommands_Align_Vert_By_Center	694; valid for drawing view items; in the graphics area, <i>view_item</i> RMB menu > Alignment > Align Vertical by Center
swCommands_Align_With_Assy_Origin	2274; valid in assemblies after <i>component</i> RMB menu > Move with Triad command; in the graphics area, <i>triad_center_ball</i> RMB menu > Align with Assembly Origin
swCommands_Align_With_Comp_Origin	2273; valid in assemblies after <i>component</i> RMB menu > Move with Triad command; in the graphics area, <i>triad_center_ball</i> RMB menu > Align with Component Origin
swCommands_Align_With_Selection	2279; valid after <i>component</i> RMB menu > Move with Triad command in assembly; in the graphics area, <i>triad_ball_arrow</i> RMB menu > Align with selection
swCommands_AlignBetweenLines	579; valid in drawings where a dimension or annotation and two vertical or horizontal lines are selected; Align toolbar > Align Between Lines
swCommands_AlignBottom	310; valid for multi-selected annotations or dimensions; Align toolbar > Align Bottom
swCommands_AlignCollinearRadial	145; valid for multi-selected dimensions; Align toolbar > Align Collinear/Radial
swCommands_AlignedSectionView	108; valid for parts and assemblies; in the Section View Assist PropertyManager page; Cutting Line > Aligned
swCommands_AlignHorizontal	314; valid for multi-selected annotations or dimensions; Align toolbar > Align Horizontal
swCommands_AlignLeft	389; valid for selected text; Formatting toolbar > Align Left
swCommands_AlignParallelConcentric	146; valid for multi-selected dimensions; Align toolbar > Align Parallel/Concentric
swCommands_AlignRight	388; valid for selected text; Formatting toolbar > Align Right
swCommands_AlignSketch	379; valid for parts; 2D To 3D toolbar > Align Sketch or Tools > Sketch Tools > Align > Sketch
swCommands_AlignTop	309; valid for multi-selected annotations or dimensions; Align toolbar > Align Top
swCommands_AlignVertical	315; valid for multi-selected annotations or dimensions; Align toolbar > Align Vertical
swCommands_AlternatePositionView	357; valid for a selected drawing sheet with alternate position views; Drawing toolbar > Alternate Position View
swCommands_AlternativeHandwrittenDim_0	3388; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the first of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_1
swCommands_AlternativeHandwrittenDim_1	3389; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the second of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_2
swCommands_AlternativeHandwrittenDim_2	3390; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the third of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_3
swCommands_AlternativeHandwrittenDim_3	3391; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the fourth of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_4
swCommands_AlternativeHandwrittenDim_4	3392; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the fifth of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_5
swCommands_AlternativeHandwrittenDim_5	3393; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the sixth of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_6
swCommands_AlternativeHandwrittenDim_6	3394; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the seventh of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_7
swCommands_AlternativeHandwrittenDim_7	3395; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the eighth of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_8
swCommands_AlternativeHandwrittenDim_8	3396; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the ninth of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_9
swCommands_AlternativeHandwrittenDim_9	3397; valid only on supporting pen/stylus hardware, updates a selected handwritten dimension with the tenth of ten alternative values that were calculated from InkAnalysis handwriting recognition; RMB dimension context menu > alternative_value_10
swCommands_Ambient_Occlusion	3030; valid only if RealView Graphics is enabled in parts and assemblies; View toolbar > View Settings > Ambient Occlusion
swCommands_AnalysistoolsDraftAnalysis	2885; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Draft Analysis
swCommands_AnalysistoolsPartingLineAnalysis	2887; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Parting Line Analysis
swCommands_AnalysistoolsUndercutAnalysis	2886; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Undercut Analysis
swCommands_AngleSnap	536; valid during sketch creation only with parts that contain curves such as circles, arcs, fillets, parabolas, ellipses, partial ellipses, or splines; Quick Snaps toolbar > Angle Snap
swCommands_AngularOrdinateDimension	3068; valid only for arcs in drawing views; Dimensions/Relations toolbar > Angular Running Dimension
swCommands_Anim_Custom_Msg_Display_Camera_By_Name	2353; valid only in the context of Motion Studies for a selected Orientation and Camera View bar key; in the Motion Study gantt chart, <i>orientation_and_camera_views_time_bar_key</i> RMB menu > View Orientation > camera_view_name
swCommands_Anim_Custom_Msg_Display_Vw_By_Name	2352; valid only in the context of Motion Studies for a selected Orientation and Camera View bar key; in the Motion Study gantt chart, <i>orientation_and_camera_views_time_bar_key</i> RMB menu > View Orientation > view_name
swCommands_Anim_Edit_Dim	2798; valid only in the context of Motion Studies; in the MotionManager tree, <i>MateGroup1 > mate_name > mate_dimension</i> RMB menu > Edit Dimension
swCommands_Anim_Lock_Viewpoint	2644; valid only in the context of Motion Studies; in the MotionManager tree, Orientation and Camera Views RMB menu > Disable View Key Creation
swCommands_Anim_Suppress_Viewpoint	2643; valid only in the context of Motion Studies; in the MotionManager tree, Orientation and Camera Views RMB menu > Disable Playback of View Keys
swCommands_Anim_View_Back	2344; valid only in the context of Motion Studies for a selected Orientation and Camera View time bar; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Back
swCommands_Anim_View_Back	2348; valid only in the context of Motion Studies for a selected Orientation and Camera View time bar; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Bottom RMB > Camera View
swCommands_Anim_View_Camera	2354; valid only in the context of Motion Studies with a camera view and for a selected Orientation and Camera View time bar; in the Motion Study gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Dimetric
swCommands_Anim_View_Dimetric	2351; valid only in the context of Motion Studies and a selected Orientation and Camera View time bar; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Dimetric
swCommands_Anim_View_Front	2343; valid only in the context of Motion Studies and a selected Orientation and Camera View time bar; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Front
swCommands_Anim_View_Isometric	2349; valid only in the context of Motion Studies and a selected Orientation and Camera View time bar; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Isometric
swCommands_Anim_View_Left	2345; valid only in the context of Motion Studies and a selected Orientation and Camera View time bar; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Left
swCommands_Anim_View_Right	2346; valid only in the context of Motion Studies and a selected Orientation and Camera View row; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Right
swCommands_Anim_View_Top	2347; valid only in the context of Motion Studies and a selected Orientation and Camera View time bar; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Top
swCommands_Anim_View_Trimetric	2350; valid only in the context of Motion Studies and a selected Orientation and Camera View time bar; in the gantt chart, <i>orientation_and_camera_views_time_bar</i> RMB menu > View Orientation > Trimetric
swCommands_Animation_CancelSolver	2929; Motion Study tab RMB menu > Cancel Solver Status
swCommands_Animation_Delete	2144; Motion Study tab RMB menu > Delete
swCommands_Animation_Duplicate	2827; Motion Study tab RMB menu > Duplicate

swCommands_Animation_Ff	1962; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Fast Forward
swCommands_Animation_Goto_End	1963; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; End
swCommands_Animation_Goto_Start	1959; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Start
swCommands_Animation_MoveCurTime	2918; valid only in the context of Motion Studies; opens the Edit Time dialog; in Motion Study gantt chart; RMB menu > Move Time Bar
swCommands_Animation_New	2142; valid for assemblies; Assembly toolbar > New Motion Study
swCommands_Animation_Pause	1964; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Pause
swCommands_Animation_Play	1961; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Play
swCommands_Animation_Play_Fast	1971; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Fast Play
swCommands_Animation_Play_From_Start	657; MotionManager toolbar > Play from Start
swCommands_Animation_Play_Loop	1968; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Playback Mode: Loop
swCommands_Animation_Play_Normal	1967; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Playback Mode: Normal
swCommands_Animation_Play_Reciprocate	1969; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Playback Mode: Reciprocate
swCommands_Animation_Play_Slow	1970; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Slow Play
swCommands_Animation_Record	1966; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Save Animation
swCommands_Animation_Rename	2143; Motion Study tab RMB menu > Rename
swCommands_Animation_Rewind	1960; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Rewind
swCommands_Animation_SolverStatus	2930; Motion Study tab RMB menu > Show Solver Status
swCommands_Animation_Stop	1965; valid only when exploding a view or collapsing an exploded view; Configurations tab > exploded_view_name RMB menu > Animate Explode/Collapse ; in Animation Controller Pop-Up Toolbar; Stop
swCommands_Animation_Wizard	659; valid only in the context of Motion Studies; opens the Select an Animation Type dialog; in a Motion Study gantt chart; RMB menu > Animation Wizard ; also available on the MotionManager toolbar
swCommands_AnimEditTime_Dlg_Cancel	2920; valid only in the context of Motion Studies; in the Motion Study gantt chart RMB menu > Move Time Bar > Edit Time dialog > Cancel
swCommands_AnimEditTime_Dlg_Increment	2923; valid only in the context of Motion Studies; in the Motion Study gantt chart RMB menu > Move Time Bar > Edit Time dialog > Spin Increment
swCommands_AnimEditTime_Dlg_Ok	2919; valid only in the context of Motion Studies; in the Motion Study gantt chart RMB menu > Move Time Bar > Edit Time dialog > OK
swCommands_AnimEditTime_Dlg_SetOffset	2922; valid only in the context of Motion Studies; in the Motion Study gantt chart RMB menu > Move Time Bar > Edit Time dialog > Offset
swCommands_AnimEditTime_Dlg_SetTime	2921; valid only in the context of Motion Studies; in the Motion Study gantt chart RMB menu > Move Time Bar > Edit Time dialog > Exact Time
swCommands_Animkey_Clear	2137; valid only in the context of Motion Studies for a selected gantt chart time bar key; in the Motion Study gantt chart; orientation_and_camera_views_time_bar_key RMB > Delete
swCommands_Animkey_Copy	2135; valid only in the context of Motion Studies for a selected gantt chart time bar key; in Motion Study gantt chart; time_bar_key RMB menu > Copy
swCommands_Animkey_Cut	2134; valid only in the context of Motion Studies for a selected gantt chart time bar key; in the Motion Study gantt chart; time_bar_key RMB menu > Cut
swCommands_Animkey_EditTime	2917; valid only in the context of Motion Studies for a selected gantt chart time bar key; opens the Edit Time dialog; in the Motion Study gantt chart; time_bar_key RMB menu > Edit Key Point Time
swCommands_Animkey_Interp_Easein_Sin	2161; valid only in the context of Motion Studies for a selected gantt chart time bar key at position B; in the Motion Study gantt chart; time_bar_key_pos_B RMB menu > Interpolation mode > Ease in
swCommands_Animkey_Interp_Easeinout_Sin	2163; valid only in the context of Motion Studies for a selected gantt chart time bar key at position B; in the Motion Study gantt chart; time_bar_key_pos_B RMB menu > Interpolation mode > Ease in/Ease out
swCommands_Animkey_Interp_Easeout_Sin	2162; valid only in the context of Motion Studies for a selected gantt chart time bar key at position B; in the Motion Study gantt chart; time_bar_key_pos_B RMB menu > Interpolation mode > Ease out
swCommands_Animkey_Interp_Linear	2157; valid only in the context of Motion Studies for a selected gantt chart time bar key at position B; in the Motion Study gantt chart; time_bar_key_pos_B RMB menu > Interpolation mode > Linear
swCommands_Animkey_Interp_Step_End	2156; valid only in the context of Motion Studies for a selected gantt chart time bar key at position B; in the Motion Study gantt chart; time_bar_key_pos_B RMB menu > Interpolation mode > Snap
swCommands_Animkey_Paste	2136; valid only in the context of Motion Studies for a copied gantt chart time bar key; in the Motion Study gantt chart; time_bar_key RMB menu > Paste
swCommands_Animkey_Place	2140; valid only in the context of Motion Studies; in the Motion Study gantt chart; RMB menu > Place Key
swCommands_Animkey_Replace	2141; valid only in the context of Motion Studies for a selected gantt chart time bar key; in the Motion Study gantt chart; time_bar_key RMB menu > Replace Key
swCommands_Animkey_Reverse_Path	2150; valid only in the context of Motion Studies for a selected assembly gantt chart time bar key; in the Motion Study gantt chart; time_bar_key RMB menu > Reverse Path
swCommands_Animkey_Select_All	2138; valid only in the context of Motion Studies; in the Motion Study gantt chart; RMB menu > Select All
swCommands_Animkey_Suppress	2155; valid only in the context of Motion Studies for a selected gantt chart time bar key; in the Motion Study gantt chart; time_bar_key RMB > Suppress Key
swCommands_AnimMateUnsuppress	2932; valid only in the context of Motion Studies for a selected mate; in the Motion Study gantt chart; mate_line_gantt_time_bar RMB menu > Suppress
swCommands_AnimMateUnsuppress	2933; valid only in the context of Motion Studies for a selected mate; in the Motion Study gantt chart; mate_line_gantt_time_bar RMB menu > Unsuppress
swCommands_Ann_Feat_Dim	1550; in the FeatureManager design tree; Annotations folder RMB menu > Show Feature Dimensions
swCommands_Ann_Ref_Dim	1551; in the FeatureManager design tree; Annotations folder RMB menu > Show Reference Dimensions
swCommands_Ann_Show	1549; in the FeatureManager design tree; Annotations folder RMB menu > Display Annotations
swCommands_Annotation_View_Create	2210; in the FeatureManager design tree; Annotations folder RMB menu > Insert Annotation View
swCommands_Annotation_View_Hide	2233; in the FeatureManager design tree; Annotations > annotation_view RMB menu > Hide
swCommands_Annotation_View_Show	2232; in the FeatureManager design tree; Annotations > annotation_view RMB menu > Show
swCommands_AnnotationAlignLeft	307; valid for multi-selected annotations; Align toolbar > Align Left
swCommands_AnnotationAlignRight	308; valid for multi-selected annotations; Align toolbar > Align Right
swCommands_Annotations	475; alternative to swCommands_Toolbar_Annotation; View menu > Toolbars > Annotation
swCommands_Api_Help_Contents	833; ? menu > API Help
swCommands_App_Exit	2825; File menu > Exit
swCommands_App_Servicepacks	1233; ? menu > Check for Updates
swCommands_Apply	696; dialog resource Apply
swCommands_AreaHatchFill	384; valid only for a selected face or closed sketch profile in a drawing; Annotations toolbar > Area Hatch/Fill
swCommands_Asm_Cir_Feat_Pattern	1376; valid for a selected assembly hole or cut and a selected axis about which to create the circular pattern; opens the Circular Pattern PropertyManager page; Insert menu > Assembly Feature > Circular Pattern
swCommands_Asm_Feat_Chamfer	2957; valid for a selected assembly feature; opens the Chamfer PropertyManager page; Insert menu > Assembly Feature > Chamfer
swCommands_Asm_Feat_Cut_Extr	1001; valid for a selected location on an assembly; opens the Extrude PropertyManager page; Insert menu > Assembly Feature > Cut > Extrude
swCommands_Asm_Feat_Cut_Revolve	1002; valid for a selected location on an assembly; opens the Revolve PropertyManager page; Insert menu > Assembly Feature > Cut > Revolve
swCommands_Asm_Feat_Cut_Sweep	2958; valid for assemblies; opens the Cut-Sweep PropertyManager page; Insert menu > Assembly Feature > Cut > Sweep
swCommands_Asm_Feat_Fillet	2956; valid for a selected assembly feature; opens the Fillet PropertyManager page; Insert menu > Assembly Feature > Fillet
swCommands_Asm_Feature_Hole	1003; valid for a selected location on an assembly; Insert menu > Assembly Feature > Hole > Simple
swCommands_Asm_Lin_Feat_Pattern	1375; valid for a selected assembly hole or cut and a selected axis for the pattern direction; opens the Linear Pattern PropertyManager page; Insert menu > Assembly Feature > Linear Pattern
swCommands_Asm_Sketch_Feat_Pattern	1382; valid for a selected assembly hole or cut; opens the Sketch Driven Pattern PropertyManager page; Insert menu > Assembly Feature > Sketch Driven Pattern
swCommands_Asm_Table_Feat_Pattern	1380; valid for a selected assembly hole or cut; opens the Table Driven Pattern dialog; Insert menu > Assembly Feature > Table Driven Pattern
swCommands_Assemblies	476; alternative to swCommands_Toolbar_Assembly; View menu > Toolbars > Assembly
swCommands_Assembly_Stats	1215; valid for assemblies; Assembly toolbar > Performance Evaluation
swCommands_AssemblyTransparency	3; valid only for assemblies that have one or more components in edit mode; in the graphics area; click RMB menu > Assembly Transparency
swCommands_Asset_Publish	3215; opens the Asset Publisher PropertyManager page; Tools menu or toolbar > Asset Publisher
swCommands_Assign_Smart_Fastener	2452; valid only for Toolbox add-ins and assemblies and only when editing a Smart Fastener grouping; opens the Smart Fastener dialog; in the Smart Fasteners PropertyManager page; Results > Group1 > Series1 RMB menu > Change fastener type
swCommands_Attach_Dimensions	986; valid only for drawings; Tools menu > Dimensions > Attach Dimensions
swCommands_Auto_Ann_View_Generate	2223; in the FeatureManager design tree; Annotations folder RMB menu > Automatically Place into Annotation Views
swCommands_Auto_Dimension_Toggle	3026; valid for an open sketch with an active sketch tool; Sketch toolbar > Add Dimension
swCommands_Auto_Jog	639; valid for a selected ordinate dimension; in the graphics area; ord_dim RMB menu > Display Options > Re-Jog Ordinate
swCommands_Auto_Size	1702; valid for a reference plane that is re-sized; in the graphics area ref_plane RMB menu > Autosize
swCommands_AutoArrangeDimension	2976; valid for multi-selected annotations or dimensions; Align toolbar > Auto Arrange Dimensions
swCommands_AutoBalloon	447; valid for drawings; Annotations toolbar > Auto Balloon
swCommands_AutoExplodeLine	3296; valid for assemblies; opens Smart Explode Lines PropertyManager to insert or edit smart explode lines for a selected explode view; Assembly toolbar > Insert/Edit Smart Explode Lines
swCommands_AutoGenerateDrawing	3536; valid for parts and assemblies; auto-generates a new drawing from the model; File menu > Auto-Generate Drawing
swCommands_AutoInfer_Toggle	1301; valid for drawings; Tools menu > Sketch Settings > Enable Snapping
swCommands_Automatic_Cutlist	2601; valid for a selected body folder or cut list folder; in the FeatureManager design tree; folder RMB menu > Create Cut Lists Automatically
swCommands_AutomaticRelations	52; Dimensions/Relations toolbar > Automatic Relations
swCommands_AutomaticUpdateCutlists	3122; valid for a cut list folder that has enabled Create Cut Lists Automatically; in the FeatureManager design tree; folder RMB menu > Update Automatically
swCommands_AutoRepair_Mates	3510; Auto repairs mates in a model that is in resolved or lightweight mode; right-click on the Mates root folder and click Auto Repair.
swCommands_AutoRepair_Pattern	3520; Auto repairs a missing Direction 1 or Direction 2 selection in a linear pattern; Right-click the pattern feature in the FeatureManager design tree and click Auto Repair in the pattern context menu
swCommands_Autosolve_Toggle	997; valid for drawings; Tools menu > Sketch Settings > Automatic Solve
swCommands_AutoUpdateDrawing	3551; valid for parts and assemblies; File menu > Update Drawings
swCommands_Auxiliary	391; valid for part documents with a single 2D sketch in edit mode; 2D to 3D toolbar > Auxiliary Sketch
swCommands_AuxiliaryView	33; valid for drawings; Drawing toolbar > Auxiliary View
swCommands_Axis	22; valid for parts; Reference Geometry toolbar > Axis or Features toolbar > Reference Geometry > Axis
swCommands_Back	162; View toolbar > View Orientation > Back
swCommands_Backward	1616; palette toolbar > Back
swCommands_Balloon	37; Annotations toolbar > Balloon
swCommands_BaseFlangeTab	320; valid for sheet metal parts; Sheet Metal toolbar > Base Flange/Tab
swCommands_BaselineDimension	81; valid only for drawings; Dimensions/Relations toolbar > Baseline Dimension
swCommands_BendTable	3010; valid only for selected flat-pattern views in drawings; Table toolbar > Bend Table or Insert > Tables > Bend Table
swCommands_BillOfMaterials	88; valid for drawings; Table toolbar > Bill of Materials
swCommands_Blank_Atom_Body	1026; in the FeatureManager design tree; click body ; folder RMB context toolbar > Hide
swCommands_Blank_Atom_Body2	2730; valid for a part with a solid or surface body; in the FeatureManager design tree; body_folder > body RMB context toolbar > Hide

swCommands_Blank_Grid_Comp	3000; valid for a part or assembly with the GridSystem PropertyManager page open and the grid feature component visible; in the graphics area, RMB menu > Hide
swCommands_Blank_Origin_Sketch	2468; valid for a visible profile sketch; in the graphics area, <i>prof_sketch</i> RMB menu > Hide
swCommands_Blank_Part_Body	901; valid for a selected face of an atom feature in an assembly; in the graphics area, <i>sel_face</i> RMB menu > Hide Solid Body
swCommands_Blank_Pic_Feat	2485; valid for a selected visible picture feature object; in the graphics area, <i>pic_feat</i> RMB menu > Hide
swCommands_Blank_Refgeom	895; valid for a selected reference geometry; in the FeatureManager design tree, <i>ref_geom</i> RMB menu > Hide
swCommands_Blank_Sketch	954; valid for a selected drawing sketch; in the graphics area, <i>sketch</i> RMB menu > Hide
swCommands_Blocks	557; alternative to swCommands_Toolbar_Sketch_Group; View menu > Toolbars > Blocks
swCommands_Body_Color	648; in the FeatureManager design tree, <i>body_folder</i> RMB menu > Appearance > Sketch/Curve Color
swCommands_Body_Properties	2519; in the FeatureManager design tree, <i>body_name</i> RMB menu > Body Properties
swCommands_Body_RV_Appearance	2896; in the FeatureManager design tree, <i>body_folder</i> RMB menu > Appearance
swCommands_Body_Texture	650; valid for a selected component in an assembly, opens the Texture PropertyManager page
swCommands_BodyComparison	3411; valid for selected bodies, displays color comparison; View toolbar > Body Compare
swCommands_Bold	147; valid for selected text; Formatting toolbar > Bold
swCommands_Bold_Menu_Title	2359; adds the bold font style to a selected item in RMB menus
swCommands_Bom_Open_Comp_File	2557; valid for a selected row in a drawing BOM table; <i>BOM_table_row</i> RMB menu > Open comp_file
swCommands_Bom_Open_Draw_File	3502; valid for a selected row in a drawing BOM table; <i>BOM_table_row</i> RMB menu > Open Drawing
swCommands_Bom_Viewtable	1302; valid for a drawing view Excel-based BOM; <i>Excel_based_bom</i> RMB menu > Edit
swCommands_Bottom	166; View toolbar > View Orientation > Bottom
swCommands_Bottom_Left	933; valid for a selected Excel-based BOM in a drawing view; <i>Excel_BOM</i> RMB menu > Anchor > Bottom Left
swCommands_Bottom_Right	930; valid for a selected Excel-based BOM in a drawing view; <i>Excel_BOM</i> RMB menu > Anchor > Bottom Right
swCommands_Break_Alignment	1510; valid only for aligned drawing view items; <i>view_item</i> RMB menu > Alignment > Break Alignment
swCommands_Break_Dim_Align	1562; valid for a selected drawing dimension to which Align Collinear/Radial has been applied; in the graphics area, <i>aligned_dim</i> RMB menu > Break Alignment
swCommands_Break_View	1519; valid for a drawing view that was previously made a Break View; in the FeatureManager design tree, <i>break_view</i> RMB menu > Break View
swCommands_BreakCornerCornerTrim	364; valid for sheet metal parts; Sheet Metal toolbar > Corners > Break-Corner/Corner-Trim
swCommands_BrokenOutSection	328; valid for drawings; Drawing toolbar > Broken-out Section
swCommands_Browse	795; dialog resource Browse
swCommands_Build_Doctor	1743; valid when a selected feature, component, or mate group has errors; Tools menu > Evaluate > MateXpert
swCommands_Bullet	533; valid for selected text; Formatting toolbar > Bullet
swCommands_CameraView	127; valid for models with cameras; View toolbar > Camera View
swCommands_Cancel	767; dialog resource button "Cancel"
swCommands_Cancel_Command	3043; Standard toolbar > Cancel
swCommands_Cancel_Edit_Cntr	849; virtual key Esc
swCommands_Cancel_Edit_Svr	850; virtual key Esc
swCommands_Capture_3dView	3141; SOLIDWORKS MBD toolbar > Capture 3D View
swCommands_Capture_RenderSystem_ProfilingData	3359; only valid on the DebugDotMenu in SOLIDWORKS debug builds; DotMenu > Display > Capture RenderSystem Profiling data
swCommands_Caterpillar	516; valid for drawings; Annotations toolbar > Caterpillar
swCommands_Cavity	93; for assemblies with a mold base and design parts; Mold Tools toolbar > Cavity
swCommands_Cd_Delete	689; dialog resource Delete
swCommands_Cd_Deleteall	691; dialog resource Delete All
swCommands_Cd_Edit	716; Relations dialog Edit
swCommands_Cd_Undo	706; dialog resource Undo
swCommands_Center	390; valid for selected text; Formatting toolbar > Center
swCommands_Centerline	49; valid for parts with a selected sketch; Sketch toolbar > Centerline
swCommands_CenterMark	95; valid only for drawings; Annotation toolbar > Center Mark
swCommands_CenterpointArc	44; valid for parts and drawings; Layout Tools toolbar > Arcs > Centerpoint Arc or Sketch toolbar > Arcs > Centerpoint Arc
swCommands_CenterPointSnap	530; valid for sketches; Quick Snaps toolbar > Center Point Snap
swCommands_CentreRectangle	2794; valid for parts with a selected sketch; Layout Tools toolbar > Rectangles > Center Rectangle or Sketch toolbar > Rectangles > Center Rectangle
swCommands_CentreRectangleAtAngle	2795; valid for parts with a selected sketch; Layout Tools toolbar > Rectangles > 3 Point Center Rectangle or Sketch toolbar > Rectangles > 3 Point Center Rectangle
swCommands_Chamfer	11; valid for parts; Features toolbar > Chamfer
swCommands_ChamferDimension	366; valid only for drawings; Dimensions/Relations toolbar > Chamfer Dimension
swCommands_Change_OrView_Reference	3094; valid only for drawings; Drawing toolbar > Replace Model
swCommands_Change_Route_Dia	2288; valid for the SOLIDWORKS Routing add-in and an open piping or flexible tubing assembly; Routing Tools toolbar > Change Route Diameter
swCommands_Change_Write_Access	2120; valid for models in a multi-user environment (select Tools > Options > System Options > Collaboration > Add shortcut menu items for multi-user environment ; File menu > Get Write Access)
swCommands_Change_Write_Access_Comp	2119; valid for shared assemblies in a multi-user environment (select Tools > Options > System Options > Collaboration > Collaboration > Add shortcut menu items for multi-user environment ; in the FeatureManager design tree, <i>comp</i> RMB menu > Make Read-Only or Get Write Access)
swCommands_ChangeDisplayStyle	2926; valid for parts and assemblies; View > Change Display States
swCommands_ChangeLayer	3056; valid for drawings; Line Format toolbar > Change Layer
swCommands_ChangeSuppressionState	150; valid for assemblies with a selected component; Assembly toolbar > Change Suppression State
swCommands_ChangeTransparency	120; valid for assemblies with a selected component; Assembly toolbar > Change Transparency
swCommands_Check	133; Tools toolbar > Check
swCommands_Check_Sketch_For_Feature	1138; valid for a part and an open sketch, opens the Check Sketch For Feature Usage dialog; Tools menu > Sketch Tools > Check Sketch for Feature
swCommands_CheckReadOnlyFiles	541; valid only if Tools menu > Options > System Options > Collaboration > Enable Multi-user environment and Check if files opened read-only have been modified by other users are both checked; Standard > Check Read-Only Files
swCommands_Circle	46; for drawings, Layout Tools toolbar > Circle ; for parts with a selected sketch or assemblies with a selected planar face, Sketch toolbar > Circle
swCommands_CircuitWorks	2893; SOLIDWORKS Add-ins toolbar > CircuitWorks
swCommands_CircularPattern	73; valid for parts; Features toolbar > Circular Pattern
swCommands_CircularSketchPattern	173; valid for parts with a sketch in edit mode; Sketch toolbar > Circular Sketch Pattern
swCommands_Clear_List_Box	1734; valid in list boxes in dialogs and PropertyManager pages; <i>list_box</i> RMB menu > Clear Selections
swCommands_ClearAllFilters	274; Selection Filter toolbar > Clear All Filters
swCommands_ClearanceVerification	2848; valid for assemblies; Assembly toolbar > Clearance Verification
swCommands_ClickHereToSeeThePreview	5; alternative to swCommands_Toolbar_Inference; View menu > Toolbars > Quick Snaps
swCommands_ClosedCorner	360; valid for sheet metal parts; Sheet Metal toolbar > Corners > Closed Corner
swCommands_Cmark_Merge	1893; valid for a drawing with two multi-selected center marks that are mergeable in the center mark set; in the graphics area, <i>center_mark</i> RMB menu > Merge Center Mark
swCommands_Cmark_Select	1898; valid for a drawing with a selected center mark in a center mark set; in the graphics area, <i>center_mark</i> RMB menu > Select Center Mark Set
swCommands_Cmark_Setbase	1873; valid for a drawing with a selected center mark in a center mark set; in the graphics area, <i>center_mark</i> RMB menu > Set as Base Center
swCommands_CmdPrediction_Search_Cmd	3541; searches for a command predictor selection
swCommands_Collapse_Tree	1977; accelerator key ctrl-C
swCommands_Collapseallitems_Tree	2555; accelerator key shift-C
swCommands_Color	531; valid for selected text; Formatting toolbar > Color
swCommands_ColorDisplayMode	299; Line Format toolbar > Color Display Mode
swCommands_Combine	407; valid for parts with two or more solid bodies; Features > Combine
swCommands_Command_Option_Toggle	1635; valid during insertion of a line in an open sketch; in the graphics area, <i>sketch_line</i> RMB menu > Switch to arc (A)
swCommands_Comp_Config_Prop	941; valid for assemblies; in the FeatureManager design tree, <i>selected_component</i> RMB menu toolbar > Component Properties
swCommands_Comp_Display_Hiddengreyed	2563; valid for assemblies; in the FeatureManager design tree, <i>selected_component</i> RMB menu > Component Display > Hidden Lines Visible
swCommands_Comp_Display_Hiddengreyed_All	2706; valid for a selected top-level-assembly; Edit menu > Component Display > Hidden Lines Visible > All Display States
swCommands_Comp_Display_Hiddengreyed_Specify	2712; valid for a selected top-level-assembly, opens the Apply to Display States dialog; Edit menu > Component Display > Hidden Lines Visible > Specified Display States
swCommands_Comp_Display_Hiddenremoved	2564; valid for assemblies; in the FeatureManager design tree, <i>selected_component</i> RMB menu > Component Display > Hidden Lines Removed
swCommands_Comp_Display_Hiddenremoved_All	2707; valid for a selected top-level-assembly; Edit menu > Component Display > Hidden Lines Removed > All Display States
swCommands_Comp_Display_Hiddenremoved_Specify	2713; valid for a selected top-level-assembly; Edit menu > Component Display > Hidden Lines Removed > Specified Display States
swCommands_Comp_Display_Shaded	2566; valid for assemblies; in FeatureManager design tree, <i>selected_component</i> RMB menu > Component Display > Shaded
swCommands_Comp_Display_Shaded_All	2709; valid for a selected top-level-assembly; Edit menu > Component Display > Shaded > All Display States
swCommands_Comp_Display_Shaded_Specify	2715; valid for a selected top-level-assembly; Edit menu > Component Display > Shaded > Specified Display States
swCommands_Comp_Display_Shaded_With_Edges	2565; valid for assemblies; in FeatureManager design tree, <i>selected_component</i> RMB menu > Component Display > Shaded With Edges
swCommands_Comp_Display_Shaded_With_Edges_All	2708; valid for a selected top-level-assembly; Edit menu > Component Display > Shaded With Edges > All Display States
swCommands_Comp_Display_Shaded_With_Edges_Specify	2714; valid for a selected top-level-assembly; Edit menu > Component Display > Shaded With Edges > Specified Display States
swCommands_Comp_Display_View_Default	2567; valid for assemblies; in FeatureManager design tree, <i>selected_component</i> RMB menu > Component Display > Default Display
swCommands_Comp_Display_View_Default_All	2710; valid for a selected top-level-assembly; Edit menu > Component Display > Default Display > All Display States
swCommands_Comp_Display_View_Default_Specify	2716; valid for a selected top-level-assembly; Edit menu > Component Display > Default Display > Specified Display States
swCommands_Comp_Display_Wireframe	2562; valid for assemblies; in FeatureManager design tree, <i>selected_component</i> RMB menu > Component Display > Wireframe
swCommands_Comp_Display_Wireframe_All	2705; valid for a selected top-level-assembly; Edit menu > Component Display > Wireframe > All Display States
swCommands_Comp_Display_Wireframe_Specify	2711; valid for a selected top-level-assembly; Edit menu > Component Display > Wireframe > Specified Display States
swCommands_Comp_Isolate	2726; valid for assemblies; in the FeatureManager design tree, <i>selected_component</i> RMB menu > Isolate
swCommands_Comp_Isolate_Exit	2732; Isolate dialog Exit
swCommands_Comp_Parent_Child_Rel	2627; valid for assemblies and drawings; in the FeatureManager design tree, <i>selected_component</i> RMB menu > Parent/Child
swCommands_Component_Color	653; alternative to swCommands_EditColor, valid for a selected component in an assembly, opens the Sketch/Curve Color PropertyManager page; Edit menu > Appearance > Sketch/Curve Color
swCommands_Component_Display	2561; in the FeatureManager design tree, <i>component_name</i> RMB menu > Component Display submenu
swCommands_Component_Pattern	1016; Insert menu > Component Pattern submenu
swCommands_Component_Pattern_Chain	3126; valid for assemblies; Assembly toolbar > Chain Component Pattern
swCommands_Component_Pattern_Circular	1942; valid for assemblies; Assembly toolbar > Circular Component Pattern

swCommands.Component.Pattern.Curve	3109; valid for assemblies; Assembly toolbar > Curve Driven Component Pattern
swCommands.Component.Pattern.Feature	1943; valid for assemblies; Assembly toolbar > Pattern Driven Component Pattern
swCommands.Component.Pattern.Linear	1941; valid for assemblies; Assembly toolbar > Linear Component Pattern
swCommands.Component.Pattern.Sketch	3108; valid for assemblies; Assembly toolbar > Sketch Driven Component Pattern
swCommands.Component.Properties	864; valid for drawings, opens the Component Line Font dialog; in the FeatureManager design tree or drawing view, selected_component RMB menu > Component Line Font
swCommands.Component.Reload	1527; valid for assemblies; in the FeatureManager design tree, selected_component RMB menu > Reload
swCommands.Component.RV.Appearance	2898; in the FeatureManager design tree, component_name RMB context toolbar > Appearances > component_name
swCommands.Component.Texture	654; valid for a selected component in an assembly, opens the Texture PropertyManager page
swCommands.CompositeCurve	158; valid for parts; Features toolbar > Curves > Composite Curve or Curves toolbar > Composite Curve
swCommands.Conc.Dim.Show.Extn.Lines	1995; valid for drawings; concentric_dimension_extension_line RMB menu > Show extension lines
swCommands.Configurations.Toolbar	3117; View menu > Toolbars > Configurations
swCommands.Conic	3049; valid for parts with a selected sketch; Sketch toolbar > Conic
swCommands.ConstructionGeometry	102; valid for parts with an open sketch and selected sketch entity; Sketch toolbar > Construction Geometry
swCommands.Convert.To.Bom98	1585; valid for a selected OLE item in a drawing view; in the graphics area, dr_view_OLE_item RMB menu > Convert to SOLIDWORKS 98 and later Format
swCommands.ConvertEntities	57; valid for parts with an open sketch; Sketch toolbar > Convert Entities
swCommands.ConvertMeshSolid2Classic	3531; converts recognized mesh brep faces to standard BREP faces; Insert > Features > Convert Mesh to Standard...
swCommands.ConvertMeshSolidSurface	3245; converts a selected solid or surface body to a Parasolid mesh body; Feature toolbar > ConvertMesh Bodies...
swCommands.ConvertTo.Base.Dimension	3408; valid for a selected dimension in a chain dimension set, replaces all dimensions in the set with baseline dimensions; RMB menu > Convert To Base
swCommands.ConvertTo.Chain.Dimension	3407; valid for a selected dimension in a baseline dimension set, replaces all dimensions in the set with chain dimensions; RMB menu > Convert To Chain
swCommands.ConvertToGeneric	3364; converts the selected interpolating spline into a generic spline; Tools > Spline Tools > Convert to Generic Spline...
swCommands.ConvertToModif	3124; valid for open sketches of a selected style spline; Spline Tools toolbar > Convert to Spline
swCommands.ConvertToStyle	3123; valid for open sketches of a selected interpolating spline; Spline Tools toolbar > Convert to Style Spline
swCommands.CoordinateSystem	154; valid for parts with a selected sketch; Features toolbar > Reference Geometry > Coordinate System
swCommands.Copy	583; valid for a selection; Standard > Copy
swCommands.Copy.Appearance	3053; valid for a model with an appearance; Render Tools or View toolbar > Copy Appearance
swCommands.Copy.Bookmark.Link	3526; valid only in SOLIDWORKS Design connected to the 3DEXPERIENCE platform, copies the link of the bookmarked file location in bookmarks to the clipboard; Lifecycle and Collaboration toolbar > Bookmarks > Copy Bookmark Link
swCommands.Copy.Drw.To.Dwgeditor	2202; valid for drawings; Edit menu > Copy to DWG format
swCommands.Copy.Swift.Schema	2017; valid for parts with multiple configurations and a selected configuration to which to copy an existing tolerance scheme; DimXpert toolbar > Copy Scheme
swCommands.CopyEntities	559; valid for parts with a sketch in edit mode; Sketch toolbar > Copy Entities
swCommands.Core	514; valid for parts with a selected plane or planar face; Mold Tools toolbar > Core
swCommands.Corner.Relief	3112; valid for sheet metal parts and multiple selected faces that define corners; Sheet Metal toolbar > Corner Relief
swCommands.CosmeticThread	115; valid for parts with a selected circular edge; Annotation > Cosmetic Thread
swCommands.CosmeticWeld	2991; valid for parts or assemblies with a selected assembly feature, opens the Weld Bead PropertyManager page; Weldments toolbar or Insert menu > Assembly Features > Weld Bead
swCommands.COSMOSFloXpress	2834; Tools toolbar > FloXpress Analysis Wizard
swCommands.CosmosMotion	621; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Motion
swCommands.CosmosworksDesigner	565; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Simulation
swCommands.CosmosxpressAnalysisWizard	439; Tools toolbar > SimulationXpress Analysis Wizard
swCommands.Create.Cut.List.Folder	2512; valid for weldment parts; in the FeatureManager design tree, solid_body RMB menu > Create Cut List Item
swCommands.Create.Empty.Folder	1906; in the FeatureManager design tree, item_name RMB menu > Create New Folder
swCommands.Create.New.Configuration	2022; in the FeatureManager design tree, component_name RMB menu > Add Configuration
swCommands.Create.Sub.Body.folder	2570; in the FeatureManager design tree, solid_body_name RMB menu > Add to New Folder
swCommands.Create.Sub.LiveSectionFolder	2884; valid for parts with a Live Section Plane; in the FeatureManager Design Tree, Live Section Planes folder RMB menu > Add to New Folder
swCommands.Create.Sub.Weldment	2367; valid for weldment parts; in the FeatureManager design tree, Cutlist folder > item_name RMB menu > Create Sub-Weldment
swCommands.Create.Userdefined.Rt.By.Drag.Drop	3163; valid for the SOLIDWORKS Routing add-in and a routing assembly; User Defined Route toolbar > Start by Drag/Drop
swCommands.Create.Userdefined.Rt.On.Fly	3166; valid for the SOLIDWORKS Routing add-in and a routing assembly, opens the Connection Point PropertyManager page; User Defined Route toolbar > Start at Point
swCommands.CreateNewTask	3548; opens a Create a Task dialog for SOLIDWORKS Design running in 3DEXPERIENCE; Lifecycle and Collaboration > Create New Task
swCommands.CreateSketchFromSelections	381; valid for parts, creates a new sketch from selected sketch entities; 2D To 3D toolbar > Create Sketch from Selections
swCommands.CropView	311; valid for drawings with a closed sketch profile on a selected view; Drawing toolbar > Crop View
swCommands.Cull.Dynamic.Update	1799; valid for assemblies; View menu > Display > Optimize Zoom/Pan/Rotate
swCommands.Curvature	132; View toolbar > Curvature
swCommands.CurvatureHedgehog	3130; View toolbar > Surface Curvature Combs
swCommands.CurveDrivenPattern	362; valid for parts with a selected sketch; Features toolbar > Curve Driven Pattern
swCommands.Curves	477; alternative to swCommands.Toolbar.Curve; View menu > Toolbars > Curves
swCommands.CurveThroughReferencePoints	123; valid for parts with a selected sketch; Features toolbar > Curves > Curve Through Reference Points
swCommands.CurveThroughXYZPoints	128; valid for parts with a selected sketch; Features toolbar > Curves > Curve Through XYZ Points
swCommands.Custom.Msg.Display.Camera.By.Name	2238; alternative to swCommands.Arim.Custom.Msg.Display.Camera.By.Name; valid only in context of Motion Study ganitt chart pop-up menus; In Motion Study ganitt chart, orientation_and_camera_views_time_bar_key RMB menu > View Orientation > camera_view_name
swCommands.Custom.Msg.Display.Vw.By.Name	2238; menu item valid only in context of view orientations
swCommands.Customization.And.More	1938; File menu > Customize Menu and many RMB menu > Customize menu
swCommands.Cut	584; Standard toolbar > Cut
swCommands.CutListSortingOptions	3431; valid for a model with cut list items, opens the Cut List Sorting Options PropertyManager for the selected cut list folder; FeatureManager design tree cut list folder RMB menu > Cut List Sorting Options
swCommands.CutWithSurface	101; Features toolbar > Cut With Surface
swCommands.CV.Spline	3099; Sketch toolbar > Style Spline
swCommands.DatumFeature	114; Annotation toolbar > Datum Feature
swCommands.DatumTarget	122; Annotation toolbar > Datum Feature
swCommands.DecimateMesh	3429; simplifies facet counts for graphics and mesh BRP bodies; Features toolbar > Decimate Mesh Body
swCommands.DecreaseIndent	543; valid for selected text; Formatting toolbar > Decrease indent
swCommands.Defeature	3050; valid for parts or assemblies with a selected Defeature item; RMB menu > Update Defeature
swCommands.Defer	708; dialog resource Show preview
swCommands.DefineStructConnection	3415; Structure System toolbar > Define Connection Element
swCommands.Deform	454; valid for parts; Features toolbar > Deform
swCommands.Deform.Rmb.Add.Connector	754; valid when the Deform or Loft PropertyManager page is open, the Deform Type is Curve to curve, and an entity is selected; in the graphics area, entity RMB menu > Add Connector
swCommands.Deform.Rmb.Delete.All.Connector	2610; valid when the Loft PropertyManager page is open; in the graphics area, RMB menu > Delete all connectors
swCommands.Deform.Rmb.Delete.Connector	2609; valid when the Deform or Loft PropertyManager page is open, and a connector is selected; in the graphics area, connector RMB menu > Delete Connector
swCommands.Deform.Rmb.Disp.Connectionlines	756; valid when the Deform PropertyManager page is open, and Deform Type is Curve to curve; in the graphics area, RMB menu > Show Connection Lines
swCommands.Deform.Rmb.Set.Transparent	751; valid when the Deform PropertyManager page is open; in the graphics area, RMB menu > Transparent Preview
swCommands.Deform.Rmb.Set.Zebra	752; valid when the Deform PropertyManager page is open; in the graphics area, RMB menu > Zebra Stripes Preview
swCommands.Deform.Rmb.Show.Connector	2608; valid when the Deform or Loft PropertyManager page is open, and a connector has been hidden; in the graphics area, connector RMB menu > Show Connector
swCommands.Deform.Rmb.Update.Display	755; valid when the Deform PropertyManager page is open; in the graphics area, RMB menu > Show Preview
swCommands.Del.Equation	1580; valid in the Equations, Global Variables, and Dimensions dialog; row RMB menu > Delete Equation
swCommands.Delete	16; deletes a selected item; Standard toolbar > Delete
swCommands.Delete.All.Constraints	1763; valid only in specific dialogs involving sketch constraints, such as the Display/Delete Relations PropertyManager page; relations_list_box RMB menu > Delete All
swCommands.Delete.Annotation.View	2215; valid for drawing annotation views; annotation_view RMB menu > Delete
swCommands.Delete.Comment	2070; in the FeatureManager design tree, comment_name RMB menu > Delete Comment
swCommands.Delete.Constraints	709; Move Confirmation or Copy Confirmation dialog resource Delete
swCommands.Delete.Cut.List	2640; in the FeatureManager design tree, cut_list_folder RMB menu > Delete
swCommands.Delete.List.Box.Item	1735; valid in dialog list boxes; RMB > Delete
swCommands.Delete.Pgm.Sketch.Offset	2434; valid for an open sketch with one or more offset entities; sketch_offset_line RMB menu > Delete Offset
swCommands.Delete.Relation	679; Equations dialog resource Delete
swCommands.Delete.Selected.Constraint	1809; valid in specific dialogs involving sketch constraints, such as Display/Delete Relations PropertyManager page; relations_list_box RMB menu > Delete
swCommands.Delete.Smart.Fastener	2457; valid only for Toolbox add-ins and assemblies and only when editing a Smart Fastener grouping; in the Smart Fasteners PropertyManager page, Results > Group1 > Series1 RMB menu > Delete
swCommands.Delete.Weldment	2361; valid only for weldments; in the FeatureManager design tree, weldment_name RMB menu > Delete
swCommands.DeleteFace	393; Surfaces toolbar > Delete Face
swCommands.DeleteHoleSurface	3360; deletes inner cavity on surfaces; Surfaces toolbar > Delete Hole
swCommands.DeleteSolidSurface	424; Feaures toolbar > Delete/Keep Body
swCommands.Derive.Sketch	1009; valid for a multi-selected sketch and a face or a plane; Insert menu > Derived Sketch
swCommands.Design.Study	2953; Tools toolbar > Design Study
swCommands.DesignChecker	460; SOLIDWORKS Add-ins toolbar > Design Checker
swCommands.DesignStudy.Add.Parameters	2955; valid for parts, opens the Parameters dialog; Insert menu > Design Study > Parameters
swCommands.DesignTable	413; Tools toolbar > Design Table
swCommands.DetailView	35; valid for drawings; Drawing toolbar > Detail View
swCommands.DeviationAnalysis	411; valid for parts; Tools toolbar > Deviation Analysis
swCommands.DFMXpress	2833; valid for parts; Tools toolbar > DFMXpress Analysis Wizard
swCommands.Dim.AddBreak	3540; valid for a selected dimension; in the graphics area, dimension_with_break_lines RMB menu > Add Dimension Break
swCommands.Dim.Center.Text	1574; centers a selected dimension between extension lines; in the graphics area, dimension RMB menu > Display Options > Center Dimension
swCommands.Dim.Foreshort	2645; valid for a selected dimension; in the graphics area, dimension RMB menu > Display Options > Foreshorten
swCommands.Dim.Inspection	1342; valid for a selected dimension; in the graphics area, dimension RMB menu > Display Options > Show as Inspection

swCommands_Dim_Jog	2839; valid for a selected dimension; in the graphics area, <i>dimension_extension_line</i> RMB menu > Display Options > Jog
swCommands_Dim_RadialDiametric_Toggle	3470; Toggles display dimension from single distance to doubled distance and vice versa
swCommands_Dim_Restore_Original_Value	3522; valid for a selected overridden dimension; in the graphics area, <i>overridden_dimension</i> RMB menu > Dimension > Restore Original Value
swCommands_Dim_Showpara	1572; valid for a selected dimension; in the graphics area, <i>dimension</i> RMB menu > Display Options > Show Parentheses
swCommands_Dim_Snap_Horizontal	787; valid for a selected vertical dimension; in the graphics area, <i>vertical_dimension</i> RMB menu > Set Horizontal
swCommands_Dim_Snap_To_Edge	789; valid for a selected horizontal dimension; in the graphics area, <i>horizontal_dimension</i> RMB menu > Align to edge
swCommands_Dim_Snap_Vertical	788; valid for a selected horizontal dimension; in the graphics area, <i>horizontal_dimension</i> RMB menu > Set Vertical
swCommands_Dim_Stop_Break	2785; valid for a selected dimension; in the graphics area, <i>dimension_with_break_lines</i> RMB menu > Remove Dimension Breaks
swCommands_Dim_UpdateBreak	3539; valid for a selected dimension; in the graphics area, <i>dimension_with_break_lines</i> RMB menu > Update Dimension Break
swCommands_Dimension_Driven_Toggle	3025; valid for an open sketch with an active sketch tool; Sketch toolbar > Sketch Dimension Driven
swCommands_DimensionAlignCollinear	2974; valid for multi-selected dimensions; Align toolbar > Align Collinear
swCommands_DimensionPattern	3101; valid for parts with a selected sketch; Features toolbar > Dimension Pattern
swCommands_DimensionRelations	490; alternative to swCommands_Toolbar_Sketch_Rels; View menu > Toolbars > Dimensions/Relations
swCommands_DimensionSpaceEvenly	2973; valid for multi-selected dimensions; Align toolbar > Dimension Space Evenly/Radial
swCommands_DimensionStagger	2975; valid for multi-selected dimensions; Align toolbar > Align Stagger
swCommands_DimensionTextAlignBottom	2978; valid for multi-selected dimensions; Align toolbar > Bottom Justify Dimension Text
swCommands_DimensionTextAlignLeft	2979; valid for multi-selected dimensions; Align toolbar > Left Justify Dimension Text
swCommands_DimensionTextAlignRight	2980; valid for multi-selected dimensions; Align toolbar > Right Justify Dimension Text
swCommands_DimensionTextAlignTop	2977; valid for multi-selected dimensions; Align toolbar > Top Justify Dimension Text
swCommands_Dimetric	468; View toolbar > View Orientation > Dimetric
swCommands_Dispatch_Dim_As_Diameter	3486; Left or right click circular entity, display dimension context toolbar > diameter button
swCommands_Dispatch_Dim_As_Linear	3487; Left or right click circular entity, display dimension context toolbar > linear diameter button
swCommands_Dispatch_Dim_As_Radius	3485; Left or right click circular entity, display dimension context toolbar > radius button
swCommands_Display_States_Target	3195; opens the Display State Target dialog; Render Tools toolbar > Display States Target
swCommands_DisplayControlPolygon	572; valid for a selected sketch spline; Spline Tools toolbar > Display Control Polygon
swCommands_DisplayDeleteRelations	60; valid for drawings; Layout toolbar > Display/Delete Relations
swCommands_Dissolve_Lib_Feature	1576; valid for parts with a library feature; in the FeatureManager design tree, <i>library_feature</i> RMB menu > Dissolve Library Feature
swCommands_Dissolve_Sktext	2470; valid for an open sketch with sketch text; in the graphics area, <i>sketch_text</i> RMB menu > Dissolve Sketch Text
swCommands_Dissolve_Subassembly	1260; valid for assemblies with subassemblies; in the FeatureManager design tree, <i>subassembly_name</i> RMB menu > Dissolve Subassembly
swCommands_DissolveEntities	3306; dissolves selected autoexplode lines so they can be edited as regular entities; Sketch toolbar > Dissolve Entities
swCommands_DocumentFont	387; valid for annotations with text; Formatting toolbar > Document Font
swCommands_Dome	137; valid for parts with a selected face; Features toolbar > Dome
swCommands_DowelPinSymbol	369; valid for drawings with circular edges or arcs; Annotation toolbar > Dowel Pin Symbol
swCommands_DraftQualityHirHlv	298; View toolbar > Draft Quality HLRIHLV
swCommands_Draw_Bl_Isozag	1582; valid for a drawing when the Broken View PropertyManager page is open; in the graphics area, <i>break_line</i> RMB menu > Small Zig Zag Cut
swCommands_Draw_Bl_Spline	1522; valid for a drawing when the Broken View PropertyManager page is open; in the graphics area, <i>break_line</i> RMB menu > Curve Cut
swCommands_Draw_Bl_Straight	1521; valid for a drawing when the Broken View PropertyManager page is open; in the graphics area, <i>break_line</i> RMB menu > Straight Cut
swCommands_Draw_Bl_Zigzag	1523; valid for a drawing when the Broken View PropertyManager page is open; in the graphics area, <i>break_line</i> RMB menu > Zig Zag Cut
swCommands_Drawing_Feat_Edit	2693; valid for drawing views; in the FeatureManager design tree, <i>sheet > drawing_view</i> RMB menu > Edit Feature
swCommands_Drawing_Feat_Edit_Def	2497; in the FeatureManager design tree, <i>macro_feature</i> RMB menu > Edit Definition
swCommands_Drawing_Stats	2172; valid for drawings; Tools menu > Evaluate > Performance Evaluation
swCommands_Drawings	478; alternative to swCommands_Toolbar_Drawing; View menu > Toolbars > Drawing
swCommands_Driven_Dim	1908; valid for a selected drawing dimension; in the graphics area, <i>dim</i> RMB menu > Driven
swCommands_DriveWorkXpress	2832; Tools toolbar > DriveWorksXpress Wizard
swCommands_Drview_Load_Model	649; valid for detached drawings; <i>drawing_view</i> RMB menu > Load Model
swCommands_Drw_Rebuild_All	1796; valid for drawings with a modified part when Automatic view update is not set in the FeatureManager design tree, <i>top-level_drawing</i> RMB menu > Update All Views
swCommands_Dt_Save_Table	2508; valid for models with design tables; in the ConfigurationManager, Tables folder > Design Table RMB menu > Save Table
swCommands_Dv_Suppress	1503; valid for a selected drawing view that is unsuppressed; in the graphics area, <i>dr_view</i> RMB menu > Hide
swCommands_Dv_Unsuppress	1504; valid for a selected drawing view that is suppressed; in the graphics area, <i>dr_view</i> RMB menu > Show
swCommands_Dve_Blind	1447; valid when the Surface-Revolve PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Blind
swCommands_Dve_Mid_Plane	1446; valid when the Surface-Revolve PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Mid Plane
swCommands_Dve_Offsetfromsurface	1450; valid when the Surface-Revolve PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Offset From Surface
swCommands_Dve_Rmb_Back	2164; valid for some open PropertyManager pages; in the graphics area, RMB menu > Back
swCommands_Dve_Rmb_Cancel	1465; valid when a PropertyManager page is open; in the graphics area, RMB menu > Cancel
swCommands_Dve_Rmb_Close_Spline_Curve	1653; valid when the Curve Through Reference Point PropertyManager page is open; in the graphics area, RMB menu > Closed Curve
swCommands_Dve_Rmb_Exit_Preview	2439; valid when the Detailed Preview PropertyManager page is open; in the graphics area, RMB menu > Exit Preview
swCommands_Dve_Rmb_Lpat_Flip_Direction1	1657; valid when the LPattern1 PropertyManager page is open; in the graphics area, RMB menu > Reverse Direction 1
swCommands_Dve_Rmb_Lpat_Flip_Direction2	1658; valid when the LPattern1 PropertyManager page is open; in the graphics area, RMB menu > Reverse Direction 2
swCommands_Dve_Rmb_Lpat_Geometry_Pattern	1656; valid when the LPattern1 PropertyManager page is open; in the graphics area, RMB menu > Geometry Pattern
swCommands_Dve_Rmb_Lpat_Varysketch	1655; valid when the LPattern1 PropertyManager page is open for a model with a driving dimension selected for Pattern Direction 1; in the graphics area, RMB menu > Vary sketch
swCommands_Dve_Rmb_Mc_Select_Entities	743; valid when the Move or Copy PropertyManager page is open; in the graphics area, RMB menu > Select Entities
swCommands_Dve_Rmb_Next	2165; valid for some open PropertyManager pages; in the graphics area, RMB menu > Next
swCommands_Dve_Rmb_Ok	1463; valid when a PropertyManager page is open; in the graphics area, RMB menu > OK
swCommands_Dve_Rmb_Pushpin	740; valid when the Planar Surface PropertyManager page is open; in the graphics area, RMB menu > Pin Dialog
swCommands_Dve_Rmb_Redo	1947; valid when a PropertyManager page is open, and Redo is enabled; in the graphics area, RMB menu > Redo
swCommands_Dve_Rmb_Select_Feature	2459; valid when a PropertyManager page is open, and feature selection is enabled; in the graphics area, RMB menu > Select Feature
swCommands_Dve_Rmb_Undo	1945; valid when a PropertyManager page is open, and Undo is enabled; in the graphics area, RMB menu > Undo
swCommands_Dve_Throughall	1451; valid when the Cut-Extrude PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Through All
swCommands_Dve_ThroughAll_Both	3092; valid when the Cut-Extrude PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Through All - Both Directions
swCommands_Dve_Throughnext	1452; valid when the Cut-Extrude PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Up To Next
swCommands_Dve_Uptobody	2509; valid when the Surface-Extrude PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Up To Body
swCommands_Dve_Uptosurface	1449; valid when the Surface-Revolve PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Up To Surface
swCommands_Dve_Uptovortex	1448; valid when the Surface-Revolve PropertyManager page is open; in the graphics area, RMB menu > Direction 1 > Up To Vortex
swCommands_Dytparam_Dlg_Cancel	1037; valid on a change parameter dialog pop-up toolbar
swCommands_Dytparam_Dlg_Desiginintnt	1041; valid on a change parameter dialog pop-up toolbar
swCommands_Dytparam_Dlg_Increment	1040; valid on a change parameter dialog pop-up toolbar
swCommands_Dytparam_Dlg_Ok	1036; valid on a change parameter dialog pop-up toolbar
swCommands_Dytparam_Dlg_Regen	1039; valid on a change parameter dialog pop-up toolbar
swCommands_Dytparam_Dlg_Reverse	1038; valid on a change parameter dialog pop-up toolbar
swCommands_Dynamic_Annotation_Views	3145; View (Heads-Up) toolbar > Dynamic Annotation Views
swCommands_DynamicMirrorEntities	529; valid for parts with an open sketch and selected sketch segment about which to mirror; Sketch toolbar > Dynamic Mirror Entities
swCommands_EdgeFlange	359; valid for sheet metal parts; Sheet Metal toolbar > Edge Flange
swCommands_Edit_Ang_Ordinate	3082; valid for drawings of circles or arcs with angular running dimensions; in the graphics area, <i>angular_running_dimension</i> RMB menu > Add to Running Dimension
swCommands_Edit_Annotation_View	2234; in the FeatureManager design tree, Annotations folder > annotation_view RMB menu > Edit Annotation View
swCommands_Edit_Assembly	967; valid for assemblies with subassemblies; in the FeatureManager design tree, <i>subassembly_name</i> RMB minibar > Edit Assembly or Assembly toolbar > Edit Component
swCommands_Edit_Broken_Out_Section	1678; valid for a selected Broken-Out Section; in the FeatureManager design tree, <i>broken_out_section</i> RMB menu > Edit Definition
swCommands_Edit_Cavity_Part	1741; valid for a selected body feature used in mold creation; <i>sel_body</i> RMB menu > Edit Cavity Part
swCommands_Edit_Comment	2071; in the FeatureManager design tree, <i>comment_name</i> RMB menu > Edit Comment
swCommands_Edit_Csk_Pattern	1392; valid for circular sketch patterns; in the graphics area, <i>circular_sketch_entity</i> RMB menu > Edit Circular Pattern
swCommands_Edit_Cut_List_Folder_Props	2513; valid for weldments with a cut list folder; in the FeatureManager design tree, <i>cut_list_item</i> RMB menu > Properties
swCommands_Edit_Decal	2207; Render Tools toolbar > Edit Decal
swCommands_Edit_Def_Assy	655; valid for Smart Components open in edit mode; in the FeatureManager design tree, Smart Feature folder > RMB menu > Edit in Defining Assembly
swCommands_Edit_Delete_Replay	1907; valid for a selected animation feature; RMB menu > Delete Replay
swCommands_Edit_Dissolve_Assembly	1324; valid for a selected subassembly; Edit menu > Dissolve Assembly
swCommands_Edit_Dragitem	831; valid for assemblies with MateReferences folders; in the FeatureManager design tree, <i>MateReferences folder > mate_reference</i> RMB menu > Edit Definition
swCommands_Edit_Drawingview_Sketch	1530; valid for drawing detail views or broken-out sections; FeatureManager design tree > detail_view folder > detail_circle RMB menu > Edit Sketch
swCommands_Edit_Equation	1578; valid for a selected dimension with equations; <i>sel_dim</i> RMB menu > Edit Equation
swCommands_Edit_Exit_No_Save	1787; Edit menu > Exit Sketch without Saving Changes
swCommands_Edit_Familytable	866; valid for models with design tables; Edit menu > Design Table > Edit Table or in ConfigurationManager, Tables folder > Design Table RMB menu > Edit Table
swCommands_Edit_Familytable_Open	867; valid for models with design tables; Edit menu > Design Table > Edit Table in New Window or in ConfigurationManager, Tables folder > Design Table RMB menu > Edit Table in New Window
swCommands_Edit_Findinfm	1588; opens the Find In FeatureManager Design Tree dialog; in the FeatureManager design tree, <i>fm_item</i> RMB menu > Go To
swCommands_Edit_Flex_Tube_Rt	2260; valid for the SOLIDWORKS Routing add-in and an open flexible tube routing assembly; Flexible Tubing toolbar > Edit Route
swCommands_Edit_Folder_Feat	2390; valid for assemblies with a Mate group; Mates folder RMB menu > Edit Features
swCommands_Edit_Importfolder	1583; valid for a selected import folder; <i>sel_folder</i> RMB menu > Edit import folder
swCommands_Edit_Incontext	868; edits the selected model in the context of the assembly where it was created; in the FeatureManager design tree, <i>model_name</i> RMB menu > Edit in Context
swCommands_Edit_Layout	2818; valid for assemblies; Layout Tools toolbar > Layout
swCommands_Edit_Lsk_Pattern	1391; valid for open sketches with linear sketch patterns; in the graphics area, <i>lin_sketch_pattern_entity</i> RMB menu > Edit Linear Pattern
swCommands_Edit_Ordinate	1507; valid for drawings with an ordinate dimension; in the graphics area, <i>ordinate_dim</i> RMB Menu > Add to Ordinate

swCommands.Edit.Paragraph	2068; valid for selected text; Formatting toolbar > Paragraph Properties
swCommands.Edit.Part	965; valid for assemblies; in the FeatureManager design tree, <i>part_name</i> RMB context toolbar > Edit Part ; alternative to Assembly toolbar > Edit Component
swCommands.Edit.Pipe.Rt	2256; valid for the SOLIDWORKS Routing add-in and an open piping assembly; Piping toolbar > Edit Route
swCommands.Edit.Polygon	1398; valid for an open sketch of a polygon; in the graphics area, <i>polygon_entity</i> RMB menu > Edit polygon
swCommands.Edit.Redolist	1456; valid for models with an undo list; Standard toolbar > Redo
swCommands.Edit.Rollback	815; valid for a model rebuilt with a feature; in the FeatureManager design tree, <i>added_feature</i> RMB context toolbar > Rollback or Edit menu > Rollback
swCommands.Edit.Rolloend	2503; valid for rolled back models; in the FeatureManager design tree, <i>rolled_back_feat_name</i> RMB menu > Roll to End or Edit menu > Roll to End
swCommands.Edit.Rolloforward	2506; valid for a selected rolled back feature; in the FeatureManager design tree, <i>rolled_back_feat_name</i> RMB menu > Roll Forward
swCommands.Edit.Roltoprevious	2502; valid for rolled back models; in the FeatureManager design tree, <i>rolled_back_feat_name</i> RMB menu > Roll to Previous or Edit menu > Roll to Previous
swCommands.Edit.Rtl.Mode	2166; Text editor popup menu > Right to left reading order
swCommands.Edit.RV.Appearance	2821; Render Tools or View toolbar > Edit Appearance
swCommands.Edit.Scene	2967; Render Tools toolbar > Edit Scene
swCommands.Edit.Seed.Feature	1242; valid for parts with a pattern feature; in the graphics area, <i>pattern_entity</i> RMB menu > Edit Seed Feature
swCommands.Edit.Select.All	3027; Standard toolbar > Select All
swCommands.Edit.Sheet	1502; finishes editing a drawing sheet in edit sheet format mode; in the FeatureManager design tree or the graphics area, <i>sheet</i> RMB menu > Edit Sheet
swCommands.Edit.Sk.Pattern	1816; valid for a selected non-polygonal pattern relation; constraint RMB menu > Edit Pattern
swCommands.Edit.Sketch	859; valid for sketches; Edit menu > Sketch or in the FeatureManager design tree, <i>sketch_name</i> RMB context toolbar > Edit Sketch
swCommands.Edit.Sketch.Belt	2750; valid for sketch belts; in the FeatureManager design tree, <i>belt_name</i> RMB menu > Edit Belt
swCommands.Edit.Sketchplane	863; valid for sketches; in the FeatureManager design tree or the graphics area, <i>sketch</i> RMB context toolbar > Edit Sketch Plane
swCommands.Edit.Smart.Comp.Inst	2221; valid for assemblies with Smart Features; in the FeatureManager design tree, <i>smart_feature</i> RMB menu > Edit Feature
swCommands.Edit.Smart.Fastener	2463; valid only for Toolbox add-ins and assemblies and existing Smart Fasteners; in the FeatureManager design tree, <i>smart_fastener_feature</i> RMB menu > Edit Smart Fastener
swCommands.Edit.Smart.Insert	1856; valid for a selected Smart Insert feature; in the graphics area, <i>feat</i> RMB menu > Edit Smart Insert
swCommands.Edit.Suppress.All.Configs	1417; valid for a selected feature that has multiple configurations; Edit menu > Suppress > All Configurations
swCommands.Edit.Suppress.Feature	2498; valid for suppressible macro features; <i>macro_feature</i> RMB menu > Suppress
swCommands.Edit.Suppress.Select.Configs	1419; valid for a selected feature that has multiple configurations; Edit menu > Suppress > Specified Configurations
swCommands.Edit.Swift.Schema	2018; valid for a selected scheme in DimXpertManager, opens the Tolerance Scheme Properties PropertyManager page; in the DimXpertManager, <i>sel_scheme</i> RMB menu > Properties
swCommands.Edit.Template	1501; valid for drawings; Sheet Format toolbar > Edit Sheet Format
swCommands.Edit.Text	1811; valid for a selected note annotation; RMB menu > Edit Text
swCommands.Edit.Undolist	813; Standard toolbar > Undo
swCommands.Edit.Unsuppress.All.Configs	1421; valid for a suppressed selected feature that has multiple configurations; Edit menu > Unsuppress > All Configurations
swCommands.Edit.Unsuppress.Dependent.All.Configs	1424; valid for a suppressed selected feature that has multiple configurations; Edit menu > Unsuppress with Dependents > All Configurations
swCommands.Edit.Unsuppress.Dependent.Select.Configs	1425; valid for a suppressed selected feature that has multiple configurations; Edit menu > Unsuppress with Dependents > Specified Configurations
swCommands.Edit.Unsuppress.Feature	2499; valid for suppressed macro features; <i>macro_feature</i> RMB menu > Unsuppress
swCommands.Edit.Unsuppress.Select.Configs	1422; valid for a suppressed selected feature that has multiple configurations; Edit menu > Unsuppress > Specified Configurations
swCommands.Edit.Userdefined.Start.At.Point	3167; valid for the SOLIDWORKS Routing add-in and an open routing assembly; User Defined Route toolbar > Edit Route
swCommands.Edit.Vsection	1129; valid for a Section view; View menu > Modify > Section View
swCommands.Edit.Weldment.Props	2360; valid for weldments; in the FeatureManager design tree, Weldment RMB menu > Properties
swCommands.EditBlock	471; valid for models with blocks; Blocks toolbar > Edit Block
swCommands.EditColor	170; valid for a selected curve or sketch; View toolbar > Edit Sketch or Curve Color
swCommands.EditComponent	119; valid for a selected assembly component; Assembly toolbar > Edit Component
swCommands.EditFeature	623; valid for parts with features; Edit Menu > Definition ; valid in many context toolbars, e.g., in the FeatureManager design tree, <i>feat_name</i> RMB context toolbar > Edit Feature ; valid for models with design tables; in the ConfigurationManager, Tables folder > Design Table RMB menu > Edit Feature
swCommands.EditFlexiblePartComp	3421; valid for the selected flexible assembly component; RMB menu > Edit Flexible Part References
swCommands.EditMacro	84; Macro toolbar > Edit Macro
swCommands.EditMaterial	501; valid for a selected part in an assembly; Standard toolbar > Edit Material
swCommands.Elec.Elec.Route	2251; valid for the SOLIDWORKS Routing add-in and an open routing assembly; Electrical toolbar > Edit Route
swCommands.Elec.Rt.Properties	2253; valid for the SOLIDWORKS Routing add-in and an open routing assembly; Electrical toolbar > Route Properties
swCommands.Electrical.Autoroute	2079; valid for the SOLIDWORKS Routing add-in and an open routing assembly; Routing Tools toolbar > Auto Route
swCommands.Electrical.EditConnector	3143; valid for the SOLIDWORKS Routing add-in and an open route; Electrical toolbar > Edit Connectors
swCommands.Electrical.Load.From.To.Data	2078; valid for the SOLIDWORKS Routing add-in and an open route; Electrical toolbar > Edit Wires
swCommands.Electrical.Route	2271; valid for the SOLIDWORKS Routing add-in; Routing toolbar > Electrical
swCommands.Ellipse	87; valid in an open sketch; Sketch toolbar > Ellipse
swCommands.EmptyView	351; valid for drawings; Drawing toolbar > Empty View
swCommands.Enable.Ann.View.Mode	2443; valid for parts and assemblies; in the FeatureManager design tree, Annotations folder RMB menu > Enable Annotation View Visibility
swCommands.End.Contour.Single.Select	661; valid for parts or assemblies in contour single select mode, ends contour single select mode
swCommands.End.Select.Contour	2496; valid when a PropertyManager page is open, and RMB menu > Start Contour Selection was selected; in the graphics area, RMB menu > End Select Contours
swCommands.End.Smart.Selection	2629; valid during Smart selection; RMB menu > End Smart Selection
swCommands.EndCap	570; valid for weldments; Weldments toolbar > End Cap
swCommands.EndTreatment	517; valid for drawings with a selected edge; Annotation toolbar > End Treatment
swCommands.EnterTheOffsetOfTheSupportArea	6; alternative to swCommands.Toolbar.Table; View menu > Toolbars > Table
swCommands.Entity.Properties	807; <i>entity</i> RMB menu > <i>entity</i> Properties
swCommands.Envelope.Publisher	3416; Tools toolbar > Envelope Publisher
swCommands.Equations	51; Tools toolbar > Equations
swCommands.Escape.Key.Down	961; virtual key ESC
swCommands.ExcelBasedBillOfMaterials	512; valid for a selected view in a drawing of an assembly; Table toolbar > Excel based Bill of Materials
swCommands.Exit.Measure	2961; Measure dialog > Exit measure
swCommands.Exit.Sketch	862; valid for an open sketch; RMB menu > Exit Sketch
swCommands.Exit.Structural.Member	3404; valid when creating a structure system, exits from Advanced Structure System mode; Structure System toolbar > Exit Structure System
swCommands.Explode.Add.To.Group	2544; valid when the Explode PropertyManager page is open, an explode step exists, and a component is selected; in the Explode PropertyManager page, Explode Steps > Explode Step > comp > RMB menu > Group
swCommands.Explode.Delete	2540; valid when the Explode PropertyManager page is open, and a group of chained explode steps exists; in the Explode PropertyManager page, Explode Steps > Chain > Group > comp > RMB menu > Delete
swCommands.Explode.Delete.Last.Step	2545; valid when the Explode PropertyManager page is open, and a subassembly is selected; in the graphics area, RMB menu > Delete from last step
swCommands.Explode.Done.With.Step	3385; valid when the Explode PropertyManager page is open, and a subassembly is selected; in the graphics area, RMB menu > Done with step
swCommands.Explode.Move.After.Group.T	2550; valid when the Explode PropertyManager page is open, and a group of chained explode steps exists; in the Explode PropertyManager page, Explode Steps > Chain > Group > comp > RMB menu > Ungroup and move down
swCommands.Explode.Move.Before.Group.T	2546; valid when the Explode PropertyManager page is open, and a group of chained explode steps exists; in the Explode PropertyManager page, Explode Steps > Chain > Group > comp > RMB menu > Ungroup and move up
swCommands.Explode.Reuse.Sub	2547; valid when the Explode PropertyManager page is open, and a subassembly is selected; in the graphics area, RMB menu > Reuse subassembly explode
swCommands.Explode.Reuse.Tree.Sub	2549; valid when the Explode PropertyManager page is open, and a subassembly is selected; in the Explode PropertyManager page, Explode Steps > subassembly RMB menu > Reuse subassembly explode
swCommands.Explode.Roll.Back	3339; valid in an assembly's Exploded ViewN PropertyManager, Explode Steps > explode_stepN RMB menu > Roll back
swCommands.Explode.Roll.Forward	3340; valid in an assembly's Exploded ViewN PropertyManager, Explode Steps > explode_stepN RMB menu > Roll forward
swCommands.Explode.Roll.To.End	3342; valid in an assembly's Exploded ViewN PropertyManager, Explode Steps > explode_stepN RMB menu > Roll to end
swCommands.Explode.Roll.To.Previous	3341; valid in an assembly's Exploded ViewN PropertyManager, Explode Steps > explode_stepN RMB menu > Roll to previous
swCommands.Explode.Suppress	3348; valid in an assembly's Exploded ViewN PropertyManager, Explode Steps > explode_stepN RMB menu > Suppress
swCommands.Explode.Tree.Edit	2553; valid when the Explode PropertyManager page is open, and a drag manipulator is selected; in the graphics area, <i>drag_manip</i> RMB menu > Edit step
swCommands.Explode.Unsuppress	3349; valid in an assembly's Exploded ViewN PropertyManager, Explode Steps > explode_stepN RMB menu > Unsuppress
swCommands.Explode.Update.Sub	2548; valid when the Explode PropertyManager page is open, and a subassembly's explode has been reused ; in the Explode PropertyManager, Explode Steps > steps_of_subassembly RMB menu > Update subassembly's steps
swCommands.ExplodeBlock	472; valid for blocks created in assembly layouts or drawings; Layout Tools toolbar > Explode Block
swCommands.ExplodedView	135; valid for assemblies; Assembly toolbar > Exploded View
swCommands.ExplodeLineSketch	395; valid for assemblies with exploded views; Assembly toolbar > Explode Line Sketch
swCommands.ExplodeSketch	485; alternative to swCommands.Toolbar.Exploderoute; View menu > Toolbars > Explode Sketch
swCommands.ExtendEntities	63; valid for open sketches; Sketch toolbar > Extend Entities
swCommands.ExtendSurface	301; valid for selected edge or face of a surface sketch; Surfaces toolbar > Extend Surface
swCommands.Extrude	392; valid only for parts; 2D to 3D toolbar > Convert to Extrusion
swCommands.ExtrudedBossBase	8; valid for parts with a selected sketch; Features toolbar > Extruded Boss/Base
swCommands.ExtrudedCut	10; valid for parts; Sheet Metal toolbar > Extruded Cut or Features toolbar > Extruded Cut
swCommands.ExtrudedSurface	106; valid for a selected part sketch; Surfaces toolbar > Extruded Surface
swCommands.Face.Curvature	1141; valid for parts or assemblies; alternative to swCommands.Curvature; View toolbar > Curvature
swCommands.FaceCurves	321; valid for parts with a selected face; Sketch toolbar > Face Curves
swCommands.Far.Stack.Smart.Fastener	2455; valid for a Smart Hole Fastener in an assembly; <i>smart_hole_fastener_tree_item</i> RMB > Bottom stack
swCommands.Feat.Edit	865; valid for some selected surfaces and body features; in the graphics area, RMB menu > Edit
swCommands.Feature.Color	651; in the FeatureManager design tree, <i>sketch_name</i> RMB menu > Sketch Color
swCommands.Feature.Pop.Make.Weld.Bead	2391; valid for weldments with a selected feature; in the FeatureManager design tree, <i>feature_name</i> RMB menu > Make Weld Bead
swCommands.Feature.Pop.Remove.Weld.Bead	2393; valid for weldments with a selected feature having weld beads; in the FeatureManager design tree, <i>feature_name</i> RMB menu > Make Non Weld Bead
swCommands.Feature.Pop.Suppress.Weld.Beads	2392; valid for a selected weldment; in the FeatureManager design tree, Weldment RMB menu > Suppress Weld Beads
swCommands.Feature.Pop.Unsuppress.Weld.Beads	2394; valid for a selected weldment; in the FeatureManager design tree, Weldment RMB menu > Unsuppress Weld Beads
swCommands.Feature.RV.Appearance	2897; valid for parts or assemblies with a selected feature; in the FeatureManager design tree, <i>feature_name</i> RMB context toolbar > Appearances > feature_name
swCommands.Feature.Texture	652; valid for a selected feature, opens the Texture PropertyManager page

swCommands_FeatureImportDiagnostics	70; valid for imported geometry only; Tools toolbar > Import Diagnostics
swCommands_Features	479; alternative to swCommands_Toolbar_Features; View menu > Toolbars > Features
swCommands_Featureworks	438; SOLIDWORKS Add-ins toolbar > FeatureWorks
swCommands_File_Copy_Design	2295; File menu > Pack and Go
swCommands_File_Derive_Comp	992; valid for assemblies; File menu > Derive Component Part
swCommands_File_Find	977; File menu > Find References
swCommands_File_SummaryInfo	963; Standard toolbar > File Properties
swCommands_FileClose	2789; File menu > Close or Standard toolbar > Close
swCommands_FileReload	113; File menu > Reload or Standard toolbar > Reload
swCommands_Fillet	9; valid for parts; Features toolbar > Fillet
swCommands_FilletBead	505; valid for weldments with two preselected face sets and one preselected intersecting edge set; Weldment toolbar > Fillet Bead
swCommands_FillPattern	558; valid for parts with a selected sketch; Features toolbar > Fill Pattern
swCommands_Filter_Toolbar	1609; alternative to swCommands_Toolbar_Sel_Filter; View menu > Toolbars > Selection Filter
swCommands_FilterAxes	279; Selection Filter toolbar > Filter Axes
swCommands_FilterBlocks	361; Selection Filter toolbar > Filter Blocks
swCommands_FilterCenterlines	441; Selection Filter toolbar > Filter Centerlines
swCommands_FilterCenterMarks	284; Selection Filter toolbar > Filter Center Marks
swCommands_FilterConnectionPoints	458; Selection Filter toolbar > Filter Connection Points
swCommands_FilterCosmeticThreads	292; Selection Filter toolbar > Filter Cosmetic Threads
swCommands_FilterDatumFeatures	289; Selection Filter toolbar > Filter Datum Features
swCommands_FilterDatumTargets	291; Selection Filter toolbar > Filter Datum Targets
swCommands_FilterDimensionsHoleCallouts	285; Selection Filter toolbar > Filter Dimensions/Hole Callouts
swCommands_FilterDowelPinSymbols	382; Selection Filter toolbar > Filter Dowel Pin Symbols
swCommands_FilterEdges	277; Selection Filter toolbar > Filter Edges
swCommands_FilterFaces	278; Selection Filter toolbar > Filter Faces
swCommands_FilterGeometricTolerances	287; Selection Filter toolbar > Filter Geometric Tolerances
swCommands_FilterMeshFacet	3230; allows selection of mesh facets only; Selection Filter toolbar > Filter Mesh Facets
swCommands_FilterMeshFin	3231; allows selection of mesh facet edges only; Selection Filter toolbar > Filter Mesh Facet Edges
swCommands_FilterMeshVertex	3232; allows selection of mesh facet vertices only; Selection Filter toolbar > Filter Mesh Facet Vertices
swCommands_FilterMidpoints	283; Selection Filter toolbar > Filter Midpoints
swCommands_FilterNotesBalloons	288; Selection Filter toolbar > Filter Notes/Balloons
swCommands_FilterPlanes	280; Selection Filter toolbar > Filter Planes
swCommands_FilterRoutingPoints	459; Selection Filter toolbar > Filter Routing Points
swCommands_FilterSketches	2857; Selection Filter toolbar > Filter Sketches
swCommands_FilterSketchPoints	281; Selection Filter toolbar > Filter Sketch Points
swCommands_FilterSketchSegments	282; Selection Filter toolbar > Filter Sketch Segments
swCommands_FilterSolidBodies	419; Selection Filter toolbar > Filter Solid Bodies
swCommands_FilterSurfaceBodies	303; Selection Filter toolbar > Filter Surface Bodies
swCommands_FilterSurfaceFinishSymbols	286; Selection Filter toolbar > Filter Surface Finish Symbols
swCommands_FilterVertices	276; Selection Filter toolbar > Filter Vertices
swCommands_FilterWeldBeads	577; Selection Filter toolbar > Filter Weld Beads
swCommands_FilterWeldSymbols	290; Selection Filter toolbar > Filter Weld Symbols
swCommands_Final_Render	2969; Render Tools toolbar > Final Render
swCommands_Find_Next	764; dialog resource Find Next
swCommands_Finish_Active_Contour	665; valid for an active sketch in contour manipulation mode; in the graphics area, RMB menu > Finish Contour
swCommands_FitSpline	426; valid for a sketch in edit mode; Spline Tools toolbar > Fit Spline
swCommands_FitText	628; valid for selected text; Formatting toolbar > Fit Text
swCommands_Fix_Component	957; valid for a selected floating component; in the FeatureManager design tree, comp RMB menu > Fix
swCommands_Fixed_Length_Covering	3382; valid for SOLIDWORKS Routing add-in and an open assembly with a route and selected route segments; Routing Tools toolbar > Fixed Length Covering
swCommands_Fixed_Length_Route	3149; valid for SOLIDWORKS Routing add-in and an open assembly with a route and selected route segments; Routing Tools toolbar > Fixed Length
swCommands_FlatPatternBendNotch	3529; Insert > Sheet Metal > Bend Notch...
swCommands_Flatten	138; valid for sheet metal parts; Sheet Metal toolbar > Flatten
swCommands_Flex	409; valid for parts; Features toolbar > Flex
swCommands_Flex_Tube_Rt_Properties	2261; valid for the SOLIDWORKS Routing add-in and an open flexible tubing assembly; Flexible Tubing toolbar > Route Properties
swCommands_Flexible_Part_Remove_Ref	3430; valid for a selected reference entity in the Flexible References group box of the Activate Flexible Component PropertyManager; selected PM reference entity RMB menu > Delete
swCommands_Flexible_Tube_Route	2272; valid for the SOLIDWORKS Routing add-in; Routing toolbar > Flexible Tube
swCommands_Flip_Direction	2560; valid in sketch constraint list boxes; list_box RMB menu > Flip Relation
swCommands_Flip_Dowel_Sym	1806; valid for a selected dowel symbol; dowel_sym RMB menu > Flip Symbol
swCommands_Flip_Endpoint_Tangency	3535; Sketch toolbar > Flip Endpoint Tangent
swCommands_Flip_Ref_Dim	1548; selected_reference_dimension RMB menu > Change Plane
swCommands_Flip_Smart_Fastener	2453; valid only for Toolbox add-ins and assemblies and only when editing a Smart Fastener grouping; in the Smart Fasteners PropertyManager page, Results > Group1 > Series1 RMB menu > Flip
swCommands_FlowSimulation	3504; SOLIDWORKS Flow Simulation
swCommands_FlowSimulation_ElCooling	3506; SOLIDWORKS Flow Simulation + Electronics
swCommands_FlowSimulation_HVAC	3505; SOLIDWORKS Flow Simulation + HVAC
swCommands_FlowSimulation_HVAC_ElCooling	3507; SOLIDWORKS Flow Simulation + HVAC + Electronics
swCommands_Fmt_Painter	2841; valid for a selected annotation or dimension from which to copy visual properties; Tools toolbar > Format Painter
swCommands_Fmt_Painting_Apply_All	2856; valid after calling swCommands_Fmt_Painter (Format Painter) and selecting the annotation or dimension to copy from; in the graphics area, selected_anno_or_dim RMB menu > Apply to all
swCommands_Fold	325; valid for sheet metal parts; Sheet Metal toolbar > Fold
swCommands_Font_Continue_Number	2099; Text editor popup menu > Continue Numbering
swCommands_Font_Face	1148; valid for selected text; Formatting toolbar > Document Font (dropdown)
swCommands_Font_Points	1150; valid for selected text; Formatting toolbar > Font Points (dropdown)
swCommands_Font_Restart_Number	2098; Text editor popup menu > Restart Numbering
swCommands_Font_Units	1149; valid for selected text; Formatting toolbar > Font Units
swCommands_Fonts	480; alternative to swCommands_Toolbar_Font; View menu > Toolbars > Formatting
swCommands_Force_Regen_Bucket	3501; Regenerates drawing views; CTRL-Shift-Q
swCommands_ForceMateMisalignment	3326; valid for a pre-selected concentric mate, forces misalignment; in the FeatureManager design tree, concentric mate RMB menu > Force misalignment
swCommands_Form_Newassembly	1259; valid for assemblies with one or more selected components or feature folders; in the FeatureManager design tree, sel_comp RMB menu > Form New Subassembly
swCommands_FormingTool	560; valid for sheet metal parts; Sheet Metal toolbar > Forming Tool
swCommands_Forward	1615; palette toolbar > Forward
swCommands_FourView	552; View toolbar > Four View
swCommands_Freeze_All	3015; valid for a selected freeze bar in the FeatureManager design tree; freeze_bar RMB menu > Roll to End (Freeze All)
swCommands_Front	161; View toolbar > View Orientation > Front
swCommands_FullScreenMode	619; F11 or View menu > Full Screen or Standard toolbar > Full Screen View
swCommands_FullyDefineSketch	600; valid for an open sketch; Dimensions/Relations toolbar > Fully Define Sketch
swCommands_Gantt_Zoomin	2146; Motion Study Animator toolbar > Zoom In
swCommands_Gantt_Zoomout	2147; Motion Study Animator toolbar > Zoom Out
swCommands_Gantt_Zoomtofit	2916; Motion Study Animator toolbar > Zoom to Fit
swCommands_GeneralTable	412; valid for drawings; Table toolbar > General Table
swCommands_GeneralToleranceTable	3233; valid for drawings; Table toolbar > General Tolerance Table
swCommands_Generate_Region	2510; valid during contour selection if region selection is enabled, RMB menu > Generate Regions
swCommands_Geometric_Callout	1838; valid for a selected hole wizard callout dimension; RMB menu > Define by Geometry
swCommands_GeometricTolerance	58; valid for drawings; Annotation toolbar > Geometric Tolerance
swCommands_GetSupport	3446; Help > Get Support
swCommands_Glassbox_Done	2196; valid after running swCommands_3DDrawingView for a selected drawing view; OK in popup toolbar dialog
swCommands_Glassbox_Exit	2986; valid after running swCommands_3DDrawingView for a selected drawing view; Exit in popup toolbar dialog
swCommands_Glassbox_Pan	2201; valid after running swCommands_3DDrawingView for a selected drawing view; Pan in popup toolbar dialog
swCommands_Glassbox_Rotate	2200; valid after running swCommands_3DDrawingView for a selected drawing view; Rotate in popup toolbar dialog
swCommands_Glassbox_Save	2987; valid after running swCommands_3DDrawingView for a selected drawing view; Save the view in popup toolbar dialog
swCommands_Glassbox_ViewOrient	2988; valid after running swCommands_3DDrawingView for a selected drawing view; View Orientation in popup toolbar dialog
swCommands_Glassbox_Zoom	2199; valid after running swCommands_3DDrawingView for a selected drawing view; Zoom in/out in popup toolbar dialog
swCommands_Glassbox_Zoomto	2198; valid after running swCommands_3DDrawingView for a selected drawing view; Zoom to Area in popup toolbar dialog
swCommands_Glassbox_Zoomtofit	2197; valid after running swCommands_3DDrawingView for a selected drawing view; Zoom to Fit in popup toolbar dialog
swCommands_Go_To_Mate_Component_1	2528; valid for assemblies with mate components; in the FeatureManager design tree, first_part_mate_relation RMB menu > second_part_mate > Go to
swCommands_Go_To_Mate_Component_2	2533; valid for assemblies with mate components; in the FeatureManager design tree, second_part_mate_relation RMB menu > first_part_mate > Go to
swCommands_Goto_Auxiliary_View	1404; valid for drawings with an auxiliary view, in the drawing, selected_auxiliary_view_arrow RMB menu > Jump to Auxiliary View
swCommands_Goto_Component	1587; valid for assembly views under special circumstances; in the graphics view, comp RMB menu > Go to Component (in Tree)
swCommands_Goto_Detail_View	1402; valid for drawings with a detail view, in the drawing, detail_circle RMB menu > Jump to Detail View
swCommands_Goto_Feature	1586; in the graphics area, selected_entity RMB menu > Go to Feature (in Tree)

swCommands_Goto_Parent_View	1403; valid for drawings with a section or detail view; detail_view RMB menu > Jump to Parent View
swCommands_Goto_Projected_View	1405; valid for drawings with a projected view; projected_view_arrow RMB menu > Jump to Projected View
swCommands_Goto_Section_View	1401; valid for drawings with a section view; section_view_arrow RMB menu > Jump to Section View
swCommands_Gravity	420; valid in the context of Basic Motion Studies; in the MotionManager toolbar, Gravity adds gravity to a motion study
swCommands_Grid_Align	673; resource string or dialog resource Align Grid
swCommands_Grid_View	2999; valid for a part or assembly with a GridSystem feature; in the FeatureManager design tree, grid_system RMB menu > View Grid Components
swCommands_GridFeature	2982; valid for parts or assemblies; Features toolbar > Grid System or Insert > Reference Geometry > Grid System
swCommands_GridSnap	41; valid for sketches; Quick Snaps toolbar > Grid Snap
swCommands_GrooveWeld	3530; valid for parts, adds a groove weld bead feature between two selected disjoint bodies; Insert > Weldments > Groove Bead
swCommands_Ground_Plane	3217; valid for assemblies only, opens the Ground Plane PropertyManager page; Insert menu > Reference Geometry > Ground Plane
swCommands_Group	318; valid for multi-selected annotations or dimensions in a drawing; Align toolbar > Group
swCommands_Group_Remove_Item	1455; valid for a drawing with a group of three or more annotations or dimensions; grouped_anno RMB menu > Group > Remove from Group
swCommands_Gusset	453; valid for weldments with two selected adjoining faces; Weldments toolbar > Gusset
swCommands_HandSketch	2850; valid only for a sketch opened in SOLIDWORKS running on supporting pen/stylus hardware; Sketch Ink toolbar > Insert HandSketch
swCommands_HandsketchColor	3238; valid only on supporting pen/stylus hardware, sets pen stroke color; Sketch Ink toolbar > Color
swCommands_HandsketchConvertEntity	3241; valid only on supporting pen/stylus hardware, automatically converts a pen stroke to sketch entities; Sketch Ink toolbar > Auto Convert to Entities
swCommands_HandsketchConvertShape	3240; valid only on supporting pen/stylus hardware, automatically converts a pen stroke to recognized shapes; Sketch Ink toolbar > Auto Convert to Shape
swCommands_HandsketchDraw	3455; valid only on supporting pen/stylus hardware, draws ink strokes; Sketch Ink toolbar > Pen
swCommands_HandsketchEditModify	3413; valid only on supporting pen/stylus hardware, edit power modify sketch entities; Sketch Ink toolbar > Edit Power Modify
swCommands_HandsketchEraser	3236; valid only on supporting pen/stylus hardware, erases pen strokes; Sketch Ink toolbar > Eraser
swCommands_HandsketchModify	3409; valid only on supporting pen/stylus hardware, modifies the sketch; Sketch Ink toolbar > Power Modify
swCommands_HandsketchPen	3235; valid only on supporting pen/stylus hardware, uses pen for sketch ink; Tools menu > Sketch Tools > Pen Tools > Pen
swCommands_HandsketchPenProps	3295; valid only on supporting pen/stylus hardware, gets pen properties; Sketch Ink toolbar > Pen or Tools > Sketch Settings > Pen Settings > Pen Properties
swCommands_HandsketchProtractor	3381; valid only on supporting pen/stylus hardware, toggles the pen sketch protractor; Sketch Ink toolbar > Protractor
swCommands_HandsketchReplaceChamfer	3426; valid only on supporting pen/stylus hardware, converts power modify to sketch chamfer; Sketch Ink toolbar > Convert to Sketch Chamfer
swCommands_HandsketchReplaceComposite	3345; valid only on supporting pen/stylus hardware, converts recognized shape with Composite; Sketch Ink toolbar > Convert to Composite
swCommands_HandsketchReplaceEllipse	3347; valid only on supporting pen/stylus hardware, converts recognized shape with Ellipse; Sketch Ink toolbar > Convert to Ellipse
swCommands_HandsketchReplaceExtend	3428; valid only on supporting pen/stylus hardware, converts power modify to sketch extend; Sketch Ink toolbar > Convert to Sketch Extend
swCommands_HandsketchReplaceFillet	3427; valid only on supporting pen/stylus hardware, converts power modify to sketch fillet; Sketch Ink toolbar > Convert to Sketch Fillet
swCommands_HandsketchReplaceSlot	3346; valid only on supporting pen/stylus hardware, converts recognized shape with Slot; Sketch Ink toolbar > Convert to Slot
swCommands_HandsketchReplaceSpline	3344; valid only on supporting pen/stylus hardware, converts recognized shape with Spline; Sketch Ink toolbar > Convert to Spline
swCommands_HandsketchRuler	3291; valid only on supporting pen/stylus hardware, toggles the pen sketch ruler; Sketch Ink toolbar > Ruler
swCommands_HandsketchSelect	3237; valid only on supporting pen/stylus hardware, uses the pen to select; Sketch Ink toolbar > Select
swCommands_HandsketchSplineMode	3387; valid only on supporting pen/stylus hardware, automatically converts complex stroke to spline; Sketch Ink toolbar > Auto Spline
swCommands_HandsketchTouch	3290; valid only on supporting pen/stylus hardware, toggles Touch input to Pen Sketch; Sketch Ink toolbar > Touch
swCommands_HandsketchUpdateToEntity	3241; valid only on supporting pen/stylus hardware, updates the selected pen stroke to sketch entities; Sketch Ink toolbar > Update to Entities
swCommands_HandsketchUpdateToShape	3240; valid only on supporting pen/stylus hardware, updates the selected pen stroke to a recognized shape; Sketch Ink toolbar > Update to Shape
swCommands_Hatch_Properties	674; valid for hatched section views in drawings or part sketches; selected_hatched_sketch RMB menu > Crosshatch Properties
swCommands_HealEdges	518; valid for parts for selected faces; Features toolbar > Heal Edges
swCommands_Helix_Ccw	2389; valid when the Helix/Spiral PropertyManager page is open, and the helix is going clockwise; in the graphics area, RMB menu > Counterclockwise
swCommands_Helix_Cw	2387; valid when the Helix/Spiral PropertyManager page is open, and the helix is going counterclockwise; in the graphics area, RMB menu > Clockwise
swCommands_Helix_Taperhelix	2388; valid when the Helix/Spiral PropertyManager page is open; in the graphics area, RMB menu > Taper Helix
swCommands_HelixAndSpiral	94; valid for parts with a selected sketch of a single circle; Features toolbar > Curves > Helix and Spiral
swCommands_Helixdve_Revdir	2386; valid when the Helix/Spiral PropertyManager page is open, and the helix is going counterclockwise; in the graphics area, RMB menu > Reverse Direction
swCommands_Help	340; Standard toolbar > Help
swCommands_Help_Autocad_Users	1882; Help menu > Moving from 2D to 3D
swCommands_Help_Onlinetutorial	1423; Help menu > SOLIDWORKS Tutorials
swCommands_Hem	363; valid for sheet metal parts; Sheet Metal toolbar > Hem
swCommands_HiddenLinesRemoved	335; View toolbar > Display Style > Hidden Lines Removed
swCommands_HiddenLinesVisible	336; View toolbar > Display Style > Hidden Lines Visible
swCommands_Hide_3d_Sketch_Triad	3528; valid for an open 3D sketch displaying the sketcher triad; in the graphics area, RMB menu > Hide Sketcher Triad
swCommands_Hide_Bom	1239; valid for a drawing view excel-based BOM; excel_based_bom RMB menu > Hide
swCommands_Hide_Components	925; valid for selected components in assemblies; in the FeatureManager design tree, selected_comp RMB context toolbar > Hide Components
swCommands_Hide_Components_All_Configs	1649; valid for a selected top-level assembly; Edit menu > Hide > All Display States
swCommands_Hide_Components_Select_Configs	1650; valid for a selected top-level assembly, opens the Apply To Display States dialog; Edit menu > Hide > Specified Display States
swCommands_Hide_Cthread	1528; valid for a model with a selected cosmetic thread; in the graphics area, cosmetic_thread RMB context toolbar > Hide Cosmetic Thread
swCommands_Hide_Dim	1539; valid in drawings with annotations or dimension; in the graphics area, selected_anno RMB menu > Hide
swCommands_Hide_Dim_Leader	2538; valid for a drawing with a dimension with a leader line; leader_line RMB menu > Hide Dimension Line
swCommands_Hide_Dim_Witness	2526; valid for a drawing with a dimension with a witness line; witness_line RMB menu > Hide Extension Line
swCommands_Hide_Feature_Detail	931; valid for a selected top-level assembly showing feature detail; in the graphics area, RMB menu > Show Hierarchy Only
swCommands_Hide_Incontext_Feature_Holders	687; valid for a selected top-level assembly with visible update holders; selected_assembly RMB menu > Hide Update Holders
swCommands_Hide_Mate_Component_1	2529; valid for assemblies with visible mate components; in the FeatureManager design tree, first_part_mate_constraint RMB menu > second_part_mate > Hide component
swCommands_Hide_Mate_Component_2	2534; valid for assemblies with visible mate components; in the FeatureManager design tree, second_part_mate_constraint RMB menu > first_part_mate > Hide component
swCommands_Hide_Mesh_Feat	3211; valid for a selected mesh feature that is visible; RMB menu > Hide
swCommands_Hide_Sketch_Dim_In_Drawing	2478; valid for a selected visible dimension in a drawing sketch; RMB menu > Hide Dimensions
swCommands_Hide_Table	2623; valid for models with tables; in the FeatureManager design tree, table_name RMB menu > Hide Table
swCommands_Hide_Zone	1561; valid for assemblies with envelope components; in the FeatureManager design tree, envelope_feature RMB menu > Envelope > Select Using Envelope
swCommands_HideEdge	353; valid for a selected edge in a drawing, hides the selected edge
swCommands_Hideshow_Browser_Tree	2556; F9 or View menu > User Interface > FeatureManager Tree Area
swCommands_HideShowAnnotations	67; Annotation toolbar > Hide/Show Annotations
swCommands_HideShowComponents	85; valid for selected components in an assembly; Assembly toolbar > Hide/Show Components
swCommands_HideShowEdges	2938; valid for drawings; Line Format toolbar > Hide/Show Edges
swCommands_Highlight	3550; valid for selected text; Formatting toolbar > Highlight
swCommands_Hilink_History	684; Web toolbar > web_history dropdown
swCommands_Hole_Table_Expand_Same_Size	2368; valid for drawings with hole tables where same-size holes are combined; in the FeatureManager design tree, hole_table RMB menu > Expand Same Sizes
swCommands_Hole_Table_Goto_Tag	2364; valid for drawings with hole tables; in the drawing, hole_table_cell RMB menu > Jump to Tag
swCommands_Hole_Table_Hide_Centers	2370; valid for drawings with hole tables whose hole centers are visible; in the drawing, hole_table RMB menu > Hide Hole Centers
swCommands_Hole_Table_Hide_Origin	2362; valid for drawings with hole tables whose hole origins are visible; in the drawing, hole_table RMB menu > Hide Origin Indicator
swCommands_Hole_Table_Hide_Tags	2438; valid for drawings with hole tables whose hole tags are visible; in the drawing, hole_table RMB menu > Hide Hole Tags
swCommands_Hole_Table_Show_Centers	2369; valid for drawings with hole tables whose hole centers are hidden; in the drawing, hole_table RMB menu > Show Hole Centers
swCommands_Hole_Table_Show_Origin	2363; valid for drawings with hole tables whose hole origins are hidden; in the drawing, hole_table RMB menu > Show Origin Indicator
swCommands_Hole_Table_Show_Tags	2437; valid for drawings with hole tables whose hole tags are hidden; in the drawing, hole_table RMB menu > Show Hole Tags
swCommands_HoleAlignment	2822 valid for assemblies; Assembly toolbar > Hole Alignment
swCommands_HoleCallout	121; valid for drawings with holes or circular cut features; Annotation toolbar > Hole Callout
swCommands_HoleSeries	556; valid for assemblies with multi-selected part locations for a series of holes; Features toolbar or Insert menu > Assembly Feature > Hole > Hole Series
swCommands_HoleTable	446; valid for drawings; Table toolbar > Hole Table
swCommands_HoleWizard	39; valid for parts with a selected sketch, opens the Hole Specification PropertyManager page; Features toolbar > Hole Wizard ; also valid for assemblies; Insert menu > Assembly Feature > Hole > Wizard
swCommands_Holewizard_Callout	1839; valid for drawings with radial annotations; in the drawing, radial_dimension RMB menu > Display Options > Define by Hole Wizard
swCommands_Home	1617; palette toolbar > Home
swCommands_HorizontalDimension	66; valid for open sketches; Dimensions/Relations toolbar > Horizontal Dimension
swCommands_HorizontalOrinateDimension	347; valid for open sketches; Dimensions/Relations toolbar > Horizontal Ordinate Dimension
swCommands_HVPointSnap	522; valid for sketches; Quick Snaps toolbar > HV Point Snap
swCommands_HVSnap	525; valid during sketch creation only with parts that contain curves such as circles, arcs, fillets, parabolas, ellipses, partial ellipses, or splines; Quick Snaps toolbar > HV Snap
swCommands_Ignore_Construction_Geom	3332; valid when the Trim PropertyManager is active, graphics area RMB menu > Ignore trimming of construction geometry
swCommands_Import_To_Drawing	1772; valid for a part with a location, basic location, or basic size dimension; location_dimension RMB menu > Mark for Drawing
swCommands_ImportedGeometry	96; valid for parts; Features toolbar > Imported Geometry
swCommands_IncreaseIndent	544; valid for selected text; Formatting toolbar > Increase indent
swCommands_Indent	571; valid for multi-body parts with selected target and tool bodies; Features toolbar > Indent
swCommands_InkMarkupEraser	3441; valid only in Markup Views, erases ink strokes; Markup toolbar > Erase
swCommands_InkMarkupMouse	3440; valid only in Markup Views, draws with the mouse; Markup toolbar > Draw
swCommands_InkMarkupPen	3439; valid only on supporting pen/stylus hardware and only in Markup Views, uses pen for Markup Ink input; Markup toolbar > Pen
swCommands_InkMarkupPenProps	3438; valid only on supporting pen/stylus hardware and only in Markup Views, sets ink color and thickness; Markup toolbar > Color
swCommands_InkMarkupSelect	3442; valid only on supporting pen/stylus hardware and only in Markup Views, selects ink strokes or notes; Markup toolbar > Select
swCommands_InkMarkupText	3444; valid only on supporting pen/stylus hardware and only in Markup Views, adds a note to the current Markup View; Markup toolbar > Note
swCommands_InkMarkupView	3398; inserts a Markup View; Markup toolbar > Markup View
swCommands_Insert_Baseline_Dimension	3048; valid for a selected baseline dimension in a drawing; baseline_dim RMB menu > Add to BaseLine
swCommands_Insert_Bendtable_New	1443; valid for a sheet metal part; Insert menu > Bend Table > New
swCommands_Insert_Bendtable_Open	1442; valid for a sheet metal part; Insert menu > Bend Table > From File

swCommands.Insert_Camera	2191; valid for parts; in DisplayManager, Scene, Lights, and Cameras > Camera RMB menu > Add Camera
swCommands.Insert_Chain_Dimension	3405; starts the Chain Dimension tool; Tools menu > Dimensions > Chain
swCommands.Insert_Connection_Point	1223; valid for the SOLIDWORKS Routing add-in and an open routing assembly; Routing toolbar > Connection Point
swCommands.Insert_Connector	2862; valid for the SOLIDWORKS Routing add-in and an open electrical routing assembly; Electrical toolbar > Insert Connectors
swCommands.Insert_Create_Assy_Feat	1974; valid for parts with solid bodies; in the FeatureManager design tree, Cut list or Solid bodies folder RMB menu > Save Bodies ; opens the Save Bodies PropertyManager
swCommands.Insert_Chread_Callout	845; valid for drawing views with a selected cosmetic thread that was created without a standard and with non-empty Thread Callout text; in the drawing, callout_thread RMB menu > Insert Callout
swCommands.Insert_Custom_Symbol_Save	1208; custom_symbol RMB menu > Save to File
swCommands.Insert_Cut_Net	2175; valid for parts with a selected sketch; Features toolbar > Boundary Cut
swCommands.Insert_Drw_Dxfdwg	1849; Insert menu > DXF/DWG
swCommands.Insert_Feature_Lock	29599; valid for models where feature freeze is enabled, and the feature to freeze is selected; in the FeatureManager design tree, feature RMB menu > Freeze
swCommands.Insert_FI_View_3rd	1244; valid when adding a 1st or 3rd angle view to a drawing; RMB menu > Insert From File
swCommands.Insert_Folder	1829; valid for a selected item in the FeatureManager design tree; feature_name RMB menu > Add to New Folder
swCommands.Insert_Form_Assembly	1325; valid for assemblies with selected components, opens Assembly Structure Editing dialog; Insert menu > Component > Assembly from [Selected] Components
swCommands.Insert_From_PartSupply	3498; Opens 3DEXPERIENCE PartSupply in the SOLIDWORKS Task Pane. Browse PartSupply's comprehensive and intelligent catalog of qualified sourceable 3D components to add to your assembly; only valid if 3DEXPERIENCE Marketplace Add-in is loaded and logged into; SOLIDWORKS menu > Insert > Component > Insert from PartSupply
swCommands.Insert_Geometry_Import	1878; alternative to swCommands.ImportedGeometry; Features toolbar > Imported Geometry
swCommands.Insert_Light_Distantlight	1295; in DisplayManager, Scene, Lights, and Cameras > SOLIDWORKS Lights RMB menu > Add Directional Light
swCommands.Insert_Light_Pointlight	1293; in DisplayManager, Scene, Lights, and Cameras > SOLIDWORKS Lights RMB menu > Add Point Light
swCommands.Insert_Light_Spotlight	1294; in DisplayManager, Scene, Lights, and Cameras > SOLIDWORKS Lights RMB menu > Add Spot Light
swCommands.Insert_Light_Sunlight	3093; in DisplayManager, Scene, Lights, and Cameras > SOLIDWORKS Lights RMB menu > Add Sunlight
swCommands.Insert_Mirror_Subassembly	1638; valid for assemblies; Assembly toolbar > Mirror Components
swCommands.Insert_Mirrored_Part	988; valid for parts with a selected plane about which to mirror the part; Insert menu > Mirror Part
swCommands.Insert_Object	818; opens an Insert Object dialog; Insert menu > Object
swCommands.Insert_Picture	1131; valid for assemblies, opens an Open dialog with a Tiff Images (*.tif) selection filter; Insert > Picture
swCommands.Insert_Ref_Line	1212; opens a Reference Line dialog
swCommands.Insert_Refdim	909; valid for drawings, activates the dimensioning cursor; after calling this command, select one or two edges/vertices and then a location where to place the reference dimension text
swCommands.Insert_Route_Point	1222; valid for the SOLIDWORKS Routing add-in, opens a Route Point PropertyManager page; Routing Tools toolbar > Route Point
swCommands.Insert_Schematic	1632; valid for drawings, opens the Position Schematic PropertyManager page; Insert menu > Schematic
swCommands.Insert_Sculpt	3051; valid for parts with two or more selected solid bodies; Features toolbar > Intersect
swCommands.Insert_Sectionline	924; valid for a selected drawing sheet or view, opens a Make Section Line PropertyManager page; Insert menu > Make Section Line
swCommands.Insert_Sheet	857; valid for drawings; Insert menu > Sheet
swCommands.Insert_Sketch_Dxfdwg	1833; valid for parts with a selected plane where to insert the drawing, opens an Open dialog with a Dxf Files (*.dxf) filter; Insert menu > DXF/DWG
swCommands.Insert_Sketch_Import	1408; valid for an open (minimized) drawing and an active window with an open sketch in a part; Insert menu > Sketch from Drawing (see the SOLIDWORKS Help)
swCommands.Insert_Smart_Features	2220; valid for an assembly with a saved, selected Smart Component, opens the Smart Feature Insert PropertyManager page; Insert menu > Smart Features ; in the FeatureManager design tree, Smart_Component RMB menu > Insert Smart Feature
swCommands.Insert_Smartfeature	2235; valid for assemblies with saved Smart Components, opens the Smart Feature Insert PropertyManager page; in the FeatureManager design tree, History > Smart_Component_name > Smart Feature RMB menu > Insert
swCommands.Insert_Stock_Net	2176; valid for parts with a selected sketch; Features toolbar > Boundary Boss/Base
swCommands.Insert_Target_Point	1044; valid for a selected drawing view, activates the point cursor; after calling this command, select the location where to insert a datum target point
swCommands.Insert_Walkthrough	2960; View toolbar > Add Walk-through or View menu > Lights and Cameras > Add Walk-through or Large Design Review tab > Add Walk-through
swCommands.Insert_Weld	1024; valid for assemblies, opens the Weld Bead Type dialog
swCommands.Insert_Zone	1139; valid for assemblies, opens an Open dialog with which to select the component to insert as an envelope feature
swCommands.InsertAbbView	3466; Opens the Model Break View PropertyManager; Insert > Model Break View...
swCommands.InsertAutoDim	3244; valid for a selected sketch, applies the correct dimension based on selected entities; Dimension/Relations toolbar > Auto Insert Dimension
swCommands.InsertBelt	616; valid for assemblies, opens the Belt/Chain PropertyManager page; Assembly or Blocks toolbar > Belt/Chain
swCommands.InsertBends	118; valid for sheet metal parts; Sheet Metal toolbar > Insert Bends
swCommands.InsertBlock	470; valid for a selected plane or planar face, opens the Insert Block PropertyManager page; Layout Tools or Blocks toolbar > Insert Block
swCommands.InsertBoundarySurface	618; valid for parts, opens a Boundary-Surface PropertyManager page; Surfaces toolbar > Boundary Surface or Insert menu > Surface > Boundary Surface
swCommands.InsertCenterOfMass	3057; valid for parts with a selected sketch; Features toolbar > Reference Geometry > Center of Mass or Reference Geometry toolbar > Center of Mass
swCommands.InsertCenterOfMassRefPoint	3069; valid for parts with a Center of Mass; in the graphics area, center_of_mass context toolbar > Center of Mass Reference Point
swCommands.InsertComponents	13; valid for assemblies, opens the Insert Component PropertyManager page; Assembly toolbar > Insert Component
swCommands.InsertCV	3100; valid for open style splines; Spline Tools toolbar > Insert Control Vertex
swCommands.InsertDetailCenterLine	425; valid for drawings, opens the Centerline PropertyManager page; Annotation toolbar > Centerline
swCommands.InsertDrawingViewSection	34; valid for a selected drawing view; Drawing toolbar > SectionView
swCommands.InsertFaceDraft	40; valid for parts with a selected sketch; Features toolbar > Draft
swCommands.InsertFamilyTable	410; Insert menu > Tables > Family Table or Tables toolbar > Family Table
swCommands.InsertFamilyTable_Drw	3537; Insert menu > Tables > Family Table or Tables toolbar > Family Table
swCommands.InsertFeatureBlend	322; for assemblies with a mold base and design parts; Mold Tools toolbar > Filled Surface
swCommands.InsertFeatureMoveFace	538; valid for parts, opens the Move Face PropertyManager page; Features toolbar > Move Face
swCommands.InsertFeatureNudge	2928; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Move Face
swCommands.InsertHandSketch	3243; valid for systems supporting stylus/pen hardware, inserts a pen sketch; Sketch toolbar > Pen Sketch
swCommands.InsertHyperlink	134; opens an Insert Hyperlink dialog; Web toolbar > Insert Hyperlink
swCommands.InsertLiveSection	2843; valid for parts and a selected face; Features toolbar > Live Section Plane
swCommands.InsertMoldFolders	546; valid for parts; Mold Tools toolbar > Insert Mold Folders
swCommands.InsertNewFamilyMember	3452; 3DEXPERIENCE SOLIDWORKS only, for a selected family member in ConfigurationManager, launches an Add Family Member PropertyManager to add a new part/assembly family member; ConfigurationManager > family_member RMB menu > New Family Member
swCommands.InsertNewPrivateFamilyMember	3454; 3DEXPERIENCE SOLIDWORKS only, for a selected family member in ConfigurationManager, launches an Add Family Member PropertyManager to add a new private part/assembly family member that cannot be saved in the platform as a physical product; ConfigurationManager > family_member RMB menu > New Family Member
swCommands.InsertNewRepresentation	3453; 3DEXPERIENCE SOLIDWORKS only, for a selected family member in ConfigurationManager, launches an Add Representation PropertyManager to add a new part/assembly representation of the configuration which is not managed on the platform as a physical product but has the same part number as the family member to which it is associated; ConfigurationManager > family_member RMB menu > New Family Member
swCommands.InsertOffsetRefSurface	105; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Offset Surface
swCommands.InsertPart	26; valid for parts, opens the Open dialog; Features toolbar > Insert Part
swCommands.InsertPartingLine	111; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Split Line or Feature toolbar > Curves > Split Line
swCommands.InsertPartingPlane	449; valid for parts; Mold Tools toolbar > Parting Surfaces
swCommands.InsertPlanarSurface	168; valid for parts, opens the Planar Surface PropertyManager page; Surfaces or Mold Tools toolbar > Planar Surface
swCommands.InsertPlane	23; valid for parts with a selected sketch; Features toolbar > Reference Geometry > Plane
swCommands.InsertRefpoint	455; valid for parts with a selected sketch; Features toolbar > Reference Geometry > Point or Reference Geometry toolbar > Point
swCommands.InsertRefSurfaceRadiate	155; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Radiate Surface
swCommands.InsertRefSurfaceSew	156; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Knit Surface
swCommands.InsertRuledSurfaceFromEdge	448; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Ruled Surface
swCommands.InsertScale	350; valid for assemblies with a mold base and design parts; Mold Tools toolbar > Scale
swCommands.InsertSketchBelt	611; valid for sketches with circles or arcs; Blocks toolbar > Belt/Chain
swCommands.InsertSketchEQCurve	2881; valid for open sketches; Sketch toolbar > Equation Driven Curve
swCommands.InsertSplinePoint	140; valid for an open sketch of a spline; Spline Tools toolbar > Insert Spline Point
swCommands.InsertSplitFeat	397; valid for a selected solid body in a part; Features toolbar > Split
swCommands.InsertStructConnection	3445; Structure System toolbar > Insert structural connection element
swCommands.InsertStudWiz	3489; Insert menu > Features > Stud Wizard... ; Inserts a stud using a pre-defined cross-section
swCommands.InsertSubdExtrude	3328; Insert menu > Freeshape > Extrude
swCommands.InsertSubdRevolve	3329; Insert menu > Freeshape > Revolve
swCommands.InsertSubdSweep	3330; Insert menu > Freeshape > Sweep
swCommands.InsertSymmDiaDim	3490; Tools menu > Dimensions > Symmetric ; Creates a reference diameter dimension between selected entities
swCommands.InsertThreadWiz	3181; valid for parts with a selected sketch; Features toolbar > Thread
swCommands.Int_Tree_Ignore	2613; valid in an open Interference Detection DVE after calculation; Interference Detection PropertyManager page > Results > interference_tree RMB menu > Ignore
swCommands.Int_Tree_Open	2614; valid in an open Interference Detection DVE after calculation; Interference Detection PropertyManager page > Results > interference_tree RMB menu > Open
swCommands.Int_Tree_Unignore	2615; valid in an open Interference Detection DVE after calculation and only if Interference Detection > Options > Show ignored interferences is selected; Interference Detection PropertyManager page > Results > interference_tree RMB menu > Unignore
swCommands.Int_Tree_Zoom	2616; valid in an open Interference Detection DVE after calculation; Interference Detection PropertyManager page > Results > interference_tree RMB menu > Zoom to selection
swCommands.InterferenceDetection	344; valid for assemblies; Assembly toolbar > Interference Detection
swCommands.Internal_Dimension	2594; valid for a selected dimension, toggles the Internal Dimension state and rebuilds the browser tree
swCommands.IntersectionCurve	306; valid for sketches; Sketch toolbar > Intersection Curve
swCommands.IntersectionSnap	524; valid for sketches; Quick Snaps toolbar > Intersection Snap
swCommands.InvertSelection	564; Selection Filter toolbar > Invert Selection
swCommands.Invoke_SWVisualize_Render_PM	3543; Launches SOLIDWORKS Visualize Render PropertyManager
swCommands.Iso_Draw_Electrical_Rt	3353; Tools menu > Routing > Electrical > Create Drawing
swCommands.Iso_draw_pipe_rt	2948; valid for the SOLIDWORKS Routing add-in and an open piping assembly; Piping toolbar > Pipe Drawing
swCommands.Isolate_Changed_Dims	3023; valid for drawings saved in 2012 or later; Dimensions/Relations toolbar > Isolate Changed Dimensions
swCommands.Isometric	167; View toolbar > View Orientation > Isometric
swCommands.Italic	148; valid for selected text; Formatting toolbar > Italic
swCommands.Jog	372; valid for sheet metal parts; Sheet Metal toolbar > Jog
swCommands.Jog_Ordinate	1518; valid for a drawing of a circle or arc with a selected angular running dimension; in the graphics area, angular_running_dimension RMB menu > Display Options > Jog

swCommands_JogLine	398; valid for a part with an open sketch and a selected segment; also valid for SOLIDWORKS Routing Add-in and an open route; Explode Sketch toolbar > Jog Line
swCommands_Join	116; valid for an assembly to which a new join part is being added; Features toolbar > Join (see the SOLIDWORKS help)
swCommands_Join_Contours	2516; valid for contour or loft DVEs; selection_list_box RMB menu > Join Contours
swCommands_Keep_Constraints	2798; Move Confirm dialog resource Keep or Dangle
swCommands_Large_Icon	1622; valid for content or palette list controls or component list views; RMB menu > Large Icons
swCommands_Large_List_Icon	2065; valid for content or palette list controls or component list views; RMB menu > Large List Icons
swCommands_LargeAssemblyMode	405; valid for assemblies; Assembly toolbar > Large Assembly Mode
swCommands_LaunchFilePrep_Asst	3513; launches the File Preparation Assistant; Tools menu > File Preparation Assistant...
swCommands_Layer_Select	1151; valid for drawings; Layer toolbar > drop-down menu
swCommands_Layer_Toolbar	1955; alternative to swCommands_Toolbar_Layer; View menu > Toolbars > Layer
swCommands_LayerProperties	296; valid for drawings; Line Format toolbar > Layer Properties
swCommands_Layout	2817; alternative to swCommands_Toolbar_Layout; View menu > Toolbars > Layout Tools
swCommands_LayoutDefault	2888; View menu > Workspace > Default
swCommands_LayoutDualMonitor	2890; View menu > Workspace > Dual Monitor
swCommands_LayoutWidescreen	2889; View menu > Workspace > Widescreen
swCommands_LDR_Update_Model_Graphics	3090; valid for a selected assembly opened in Large Design Review mode; in the FeatureManager design tree, top_level_assembly RMB menu > Update Model Graphics
swCommands_Leader_Add_Bent	1780; valid for a drawing view with a selected leader; in the graphics area, leader RMB menu > Add Jog Point
swCommands_Leader_Add_Branch	1778; valid for a drawing view with a selected leader; in the graphics area, leader RMB menu > Insert New Branch
swCommands_Leader_Delete_All	1781; valid for a drawing with a selected multi-jog leader; in the graphics area, multi_jog_leader RMB menu > Delete Leader
swCommands_Leader_Delete_Bent	1779; valid for a drawing view with a selected leader that has a jog; in the graphics area, leader RMB menu > Delete Jog Point
swCommands_Leader_Delete_Branch	722; valid for a drawing view with a selected leader that has a branch; in the graphics area, leader RMB menu > Delete Branch
swCommands_Left	164; View menu > View Orientation > Left
swCommands_LengthSnap	540; valid during sketch creation only with parts that contain curves such as circles, arcs, fillets, parabolas, ellipses, partial ellipses, or splines; Quick Snaps toolbar > Length Snap
swCommands_Light_Properties	1296; valid for a selected SOLIDWORKS Light in the FeatureManager design tree; Scene, Lights, and Cameras > SOLIDWORKS Lights RMB menu > Show Lights is selected; in the graphics area, light RMB menu > Properties ; valid for a selected camera in DisplayManager; Camera > Camera1 RMB menu > Edit Camera
swCommands_Lightweight_All	1235; valid for a selected assembly with resolved components; in the FeatureManager design tree, top_level_assy RMB menu > Set Resolved to Lightweight
swCommands_Line	43; valid for an open sketch; Layout Tools or Sketch toolbar > Line
swCommands_Line_Center	1312; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Style > Center
swCommands_Line_Chain	1311; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Style > Chain
swCommands_Line_Dashed	1309; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Style > Dashed
swCommands_Line_Normal	1317; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > 0.25mm
swCommands_Line_Phantom	1310; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Style > Phantom
swCommands_Line_Solid	1308; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Style > Solid
swCommands_Line_Stitch	1313; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Style > Stitch
swCommands_Line_Stylebylayer	1307; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Style > Default
swCommands_Line_Thick	1318; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > 0.35mm
swCommands_Line_Thick2	1319; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > 0.5mm
swCommands_Line_Thick3	1320; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > 0.7mm
swCommands_Line_Thick4	1321; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > 1mm
swCommands_Line_Thick5	1322; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > 1.4mm
swCommands_Line_Thick6	1323; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > 2mm
swCommands_Line_Thickthin	1314; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Style > Thin/Thick Chain
swCommands_Line_Thin	1316; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > 0.18mm
swCommands_Line_Weightbylayer	1315; valid for drawings with a selected line; in the graphics area, selected_edge RMB context toolbar > Line Thickness > Default
swCommands_LinearMotor	422; valid for MotionManager, opens the Motor PropertyManager page; MotionManager toolbar > Motor
swCommands_LinearPattern	18; valid for parts with a selected sketch; Features toolbar > Linear Pattern
swCommands_LinearSketchPattern	172; valid for an open sketch; Sketch toolbar > Linear Sketch Pattern
swCommands_LinearSpring	444; valid for MotionManager, opens the Motor PropertyManager page; MotionManager toolbar > Spring
swCommands_LineColor	141; valid for drawings and selected sketches; Line Format toolbar > Line Color
swCommands_LineFormats	481; alternative to swCommands_Toolbar_Lineformat; View menu > Toolbars > Line Format
swCommands_LineStyle	143; valid for drawings and selected sketches; Line Format toolbar > Line Style
swCommands_LineThickness	142; valid for drawings and selected sketches; Line Format toolbar > Line Thickness
swCommands_Link_Dims	1543; valid for sketches with dimensions, opens the Shared Values dialog; in the graphics area, dimension RMB menu > Link Values
swCommands_LinkViews	553; valid for two or more viewport views; Standard Views toolbar > Link Views or Window menu > Viewport > Link Views
swCommands_List_Body_References	2803; valid for a selected body in a part, opens the References for body dialog
swCommands_List_Comp_References	2802; valid for a selected component in an assembly, opens the References for comp dialog
swCommands_List_Edge_References	2806; valid for a selected edge in a part, opens the References for Edge dialog
swCommands_List_Exportents	1080; valid for parts with named entities, opens the Named Entities dialog; in the FeatureManager design tree, top_level_part RMB menu > List Named Entities
swCommands_List_Extrefs	1055; valid for parts and assemblies with external references, opens the External References For dialog; FeatureManager design tree > Assembly RMB menu > List External Refs
swCommands_List_Face_References	2805; valid for a selected face in a part, opens the References for Face dialog
swCommands_List_Feat_References	2804; valid for a selected feature in a part, opens the References for feat dialog
swCommands_List_Vert_References	2807; valid for a selected vertex in a part, opens the References for Vertex dialog
swCommands_LiveSectionFitToPart	2844; valid for models with a live section plane; in the graphics area, live_section_plane RMB menu > Fit To Part
swCommands_LiveSectionReset	2845; valid for models with a live section plane; in the graphics area, live_section_plane RMB menu > Reset
swCommands_LiveSectionTriadHide	2847; valid for models with a live section plane; in the graphics area, live_section_plane RMB context toolbar > Show Triad
swCommands_LiveSectionTriadShow	2846; valid for models with a live section plane; in the graphics area, live_section_plane RMB context toolbar > Hide Triad
swCommands_Lock_Bom	918; valid for a drawing view with an Excel-based Bill of Materials; in the graphics area, BOM_table RMB menu > Anchor > Lock to Anchor
swCommands_Lock_Configuration	1847; valid in a PDM-enabled environment with an unlocked configuration; in ConfigurationManager, unlocked_config RMB menu > Lock Configuration
swCommands_Lock_Unlock_Focus	2617; valid for drawings; in the graphics area or the FeatureManager design tree, drawing_view RMB menu > Lock View Focus or Unlock View Focus
swCommands_Lock_Unlock_Focus_Double_Click	2618; valid for drawings; in the graphics area or the FeatureManager design tree, drawing_view RMB menu > double click
swCommands_LockViewPlane	3436; valid for assemblies displaying a section view; graphics area RMB > Lock View
swCommands_LoftedBend	406; valid for sheet metal parts; Sheet Metal toolbar > Lofted-Bend
swCommands_LoftedBossBase	25; valid for parts with a selected sketch; Features toolbar > Lofted Boss/Base
swCommands_LoftedCut	82; valid for parts with a selected sketch; Features toolbar > Lofted Cut
swCommands_LoftedSurface	107; valid for parts; Surfaces toolbar > Lofted Surface
swCommands_LoopDve	3098; valid for a selected plane, planar face, or edge on a part, opens the Path PropertyManager page
swCommands_Machined_Parts_Costing	3028; SOLIDWORKS Costing task pane > Machining Costing
swCommands_Macros	482; alternative to swCommands_Toolbar_Macro; View menu > Toolbars > Macro
swCommands_MagnetLine	3007; valid for drawings with a selected start point for a magnetic line with which to align balloons; Annotation toolbar > Magnetic Line
swCommands_Make_Edit_Sketch	3419; converts the selected reference sketch to an edit sketch; RMB menu > Make Edit Sketch
swCommands_Make_Lightweight	1202; valid for assemblies with a resolved component; in the FeatureManager design tree, resolved_component RMB menu > Set to Lightweight
swCommands_Make_Reference_Sketch	3420; converts the selected edit sketch to a reference sketch; RMB menu > Make Reference Sketch
swCommands_Make_Resolved	1203; valid for assemblies with a lightweight component; in the FeatureManager design tree, lightweight_component RMB menu > Set to Resolved
swCommands_Make_Suppressed	1204; valid for one or more selected components in an assembly
swCommands_Make_Trim_As_Construction	3331; valid when the Trim PropertyManager is active, graphics area RMB menu > Keep trimmed entities as construction geometry
swCommands_MakeAssemblyFromPartAssembly	462; opens the Begin Assembly PropertyManager page; Standard toolbar > Make Assembly From Part/Assembly
swCommands_MakeBlock	469; Blocks toolbar > Make Block
swCommands_MakeDrawingFromPartAssembly	461; opens the Sheet Format/Size dialog to create a drawing; Standard toolbar > Make Drawing from Part/Assembly
swCommands_MakeSmartComponent	563; valid for assemblies, opens the Smart Component PropertyManager page; Assembly toolbar > Make Smart Component
swCommands_MakeVirtualComplndependent	3494; Makes the selected virtual assembly component independent; in the FeatureManager design tree, right-click a virtual assembly component and select Make Independent
swCommands_Manage_Equations	3040; opens the Equations, Global Variables, and Dimensions dialog; in the FeatureManager design tree, Equations RMB menu > Manage Equations
swCommands_Manual_ViewLabel	2073; valid for drawings with a selected view location label; in the graphics area, location_label RMB menu > Manual View Label Text
swCommands_Mark_LDR_Config	3204; valid for an assembly opened in Resolved or Lightweight mode, allows the user to mark the configurations to display when the assembly is opened in Large Design Review mode; in the ConfigurationManager, top_level_assembly RMB menu > Large Design Review Mark menu
swCommands_Mark_LDR_ConfigActive	3206; valid for an assembly opened in Resolved or Lightweight mode, allows the user to mark the active configuration for display when the assembly is opened in Large Design Review mode; in the ConfigurationManager, top_level_assembly RMB menu > Large Design Review Mark > Add Large Design Review Mark for This Configuration
swCommands_Mark_LDR_ConfigAll	3207; valid for an assembly opened in Resolved or Lightweight mode, allows the user to mark all of the configurations for display when the assembly is opened in Large Design Review mode; in the ConfigurationManager, top_level_assembly RMB menu > Large Design Review Mark > Add Large Design Review Mark for All Configurations
swCommands_Mark_LDR_ConfigOff	3205; valid for an assembly opened in Resolved or Lightweight mode, allows the user to unmark a configuration to prevent its display when the assembly is opened in Large Design Review mode; in the ConfigurationManager, top_level_assembly RMB menu > Large Design Review Mark > Remove Large Design Review Mark
swCommands_Mark_LDR_ConfigSpecific	3208; valid for an assembly opened in Resolved or Lightweight mode, allows the user to mark a specific configuration to display when the assembly is opened in Large Design Review mode; in the ConfigurationManager, top_level_assembly RMB menu > Large Design Review Mark > Add Large Design Review Mark for Specified Configurations
swCommands_Mark_Smart_Fastener_Update	2464; valid only for Toolbox add-ins and an assembly with a selected Smart Fastener; in FeatureManager design tree, smart_fastener.feature RMB menu > Mark up to date
swCommands_Mark_Smart_Insert_Update	1857; valid only for Toolbox add-ins and an assembly with a Smart Insert that needs to be updated; in the graphics area, RMB menu > Update Smart Insert
swCommands_MassProperties	343; Tools toolbar > Mass Properties
swCommands_Mate	90; valid for assemblies with two or more selected components to mate; Assembly toolbar > Mate
swCommands_Mate_Cancel	698; Add Mate dialog resource Undo
swCommands_Mate_Delete	2517; valid in the assembly Mate PropertyManager page for a selected mate; Mates tab > Mate Selections > mate RMB menu > Delete
swCommands_Mate_Preview	702; Add Mate dialog resource Preview
swCommands_MateReference	160; valid for parts with a selected sketch; Features toolbar > Reference Geometry > Mate Reference or Reference Geometry toolbar > Mate Reference

swCommands_Mating_Component	3305; applies dimensions and tolerances on target based on source component; DimXpert toolbar > Auto Pair Tolerance
swCommands_MBD	3140; View menu > Toolbars > SOLIDWORKS MBD
swCommands_MBD_Load_Unload	3185; SOLIDWORKS Add-ins toolbar > SOLIDWORKS MBD SNL
swCommands_MBD_Template_Editor	3142; SOLIDWORKS MBD toolbar > 3D PDF Template Editor
swCommands_Measure	92; opens the Measure dialog; Tools toolbar > Measure
swCommands_Measure_Csys	2104; Measure dialog > XYZ Relative To
swCommands_Measure_History	3066; Measure dialog > Measurement History
swCommands_Measure_Minmax	2101; valid for the Measure dialog if Point-to-Point is not selected; Measure dialog > Arc/Circle Measurements
swCommands_Measure_Proj	2100; Measure dialog > Projected On
swCommands_Measure_Proj_None	2108; valid for the Measure dialog; Projected On > None
swCommands_Measure_Proj_Plane	2110; valid for the Measure dialog; Projected On > Select Face/Plane
swCommands_Measure_Proj_Recent	2111; valid for the Measure dialog; Projected On > no selection
swCommands_Measure_Proj_Screen	2109; valid for the Measure dialog; Projected On > Screen
swCommands_Measure_PtoP	3065; Measure dialog > Point-to-Point
swCommands_Measure_Showcallouts	2398; valid if Measure dialog > Show XYZ Measurements is selected and an entity is selected; in the graphics area, <i>measurement calout</i> RMB menu > Show XYZ dimensions and associated geometry
swCommands_Measure_Units	2102; opens the Measure Units/Precision dialog; Measure dialog > Units/Precision
swCommands_Measure_Xyz	2103; Measure dialog > Show XYZ Measurements
swCommands_Midpointline	3118; Sketch toolbar > Midpoint Line
swCommands_MidpointSnap	523; valid for sketches; Quick Snaps toolbar > Midpoint Snap
swCommands_MidSurface	117; valid for parts with offset face pairs, opens the MidSurface1 PropertyManager page; Surfaces toolbar > Mid-Surface
swCommands_Mirrcmd_Browse	1687; valid if the Mirror Components PropertyManager page is open, opens the Choose File dialog; Mirror Components > Step 3: Opposite Hand > Opposite Hand Versions > Create new files > browse_button
swCommands_Mirrcmd_Copy_All_Instances	1686; valid for a selected subassembly and an open Mirror Components PropertyManager page; Mirror Components > Step 2: Set Orientation > Orient Components > top_level_comp RMB menu > Copy All Instances
swCommands_Mirrcmd_Mirror_All_Children	1683; valid for a selected subassembly and an open Mirror Components PropertyManager page; Mirror Components > Step 2: Set Orientation > Orient Components > top_level_comp RMB menu > Mirror All Children
swCommands_Mirrcmd_Mirror_All_Instances	1684; valid for a selected subassembly and an open Mirror Components PropertyManager page; Mirror Components > Step 2: Set Orientation > Orient Components > top_level_comp RMB menu > Mirror All Instances
swCommands_Mirror	83; valid for parts with a selected sketch; Features toolbar > Mirror or for assemblies with a selected assembly feature, opens the Mirror PropertyManager page; Insert > Assembly Feature > Mirror
swCommands_MirrorEntities	61; valid for an open sketch, opens the Mirror PropertyManager page; Sketch or Layout Tools toolbar > Mirror Entities
swCommands_MiterFlange	324; valid for sheet metal parts; Sheet Metal toolbar > Miter Flange
swCommands_MixModel_LightWeight	3322; Assembly toolbar > Set Component to Lightweight
swCommands_MixModel_Resolve	3321; Assembly toolbar > Set Component to Resolved
swCommands_ModelItems	513; valid for drawings; Annotation toolbar > Model Items
swCommands_ModelView	77; valid for drawings, opens the Model View PropertyManager page; Drawing toolbar > Model View
swCommands_Modify_Curv_Scale	646; valid for a selected curve with curvature combs, opens the Curvature Scale PropertyManager page; in the graphics area, <i>curve</i> RMB menu > Modify Curvature Scale
swCommands_ModifySketch	100; valid for selected sketches, opens the Modify Sketch dialog; Sketch toolbar > Modify Sketch
swCommands_MoldflowXpressAnalysisWizard	414; runs the MoldflowXpress Analysis Wizard, if the product is available
swCommands_Molds	483; alternative to swCommands_Toolbar_Mold; View menu > Toolbars > Mold Tools
swCommands_MostRecentlyUsed_File1	3365; opens file 1 in File > Open Recent
swCommands_MostRecentlyUsed_File10	3374; opens file 10 in File > Open Recent
swCommands_MostRecentlyUsed_File11	3375; opens file 11 in File > Open Recent
swCommands_MostRecentlyUsed_File12	3376; opens file 12 in File > Open Recent
swCommands_MostRecentlyUsed_File13	3377; opens file 13 in File > Open Recent
swCommands_MostRecentlyUsed_File14	3378; opens file 14 in File > Open Recent
swCommands_MostRecentlyUsed_File15	3379; opens file 15 in File > Open Recent
swCommands_MostRecentlyUsed_File16	3380; opens file 16 in File > Open Recent
swCommands_MostRecentlyUsed_File2	3366; opens file 2 in File > Open Recent
swCommands_MostRecentlyUsed_File3	3367; opens file 3 in File > Open Recent
swCommands_MostRecentlyUsed_File4	3368; opens file 4 in File > Open Recent
swCommands_MostRecentlyUsed_File5	3369; opens file 5 in File > Open Recent
swCommands_MostRecentlyUsed_File6	3370; opens file 6 in File > Open Recent
swCommands_MostRecentlyUsed_File7	3371; opens file 7 in File > Open Recent
swCommands_MostRecentlyUsed_File8	3372; opens file 8 in File > Open Recent
swCommands_MostRecentlyUsed_File9	3373; opens file 9 in File > Open Recent
swCommands_Move_Down_Using_Arrow_Key	2001; VK_DOWN; shift-control-down arrow key
swCommands_Move_Dve_Resume_Drag	1464; valid for collision detection and dynamic clearance list boxes in the Move Component PropertyManager page; RMB menu > Resume Drag
swCommands_Move_Left_Using_Arrow_Key	2002; VK_LEFT; shift-control-left arrow key
swCommands_Move_Right_Using_Arrow_Key	2003; VK_RIGHT; shift-control-left arrow key
swCommands_Move_Show_Delta_Xyz	1135; valid after <i>component</i> RMB menu > Move with Triad command in an assembly; in the graphics area, <i>triad_center_ball</i> RMB menu > Show Translate Delta XYZ Box
swCommands_Move_Show_Xyz	1142; valid after <i>component</i> RMB menu > Move with Triad command in an assembly; in the graphics area, <i>triad_center_ball</i> RMB menu > Show Translate XYZ Box
swCommands_Move_Up_Using_Arrow_Key	2000; VK_UP; shift-control-up arrow key
swCommands_MoveComponent	20; valid for assemblies, opens the Move Component PropertyManager page; in the graphics area, RMB menu > Move Component
swCommands_MoveCopyBodies	408; valid for multibody parts; Features toolbar > Move/Copy Bodies
swCommands_MoveEntities	502; valid for an open sketch, opens the Move PropertyManager page; Sketch toolbar > Move Entities
swCommands_MoveSizeFeatures	386; valid for parts; Features toolbar > Instant3D
swCommands_MultiJogLeader	367; valid for drawings; Annotation toolbar > Multi-jog Leader
swCommands_Near_Stack_Smart_Fastener	2454; valid for a Smart Hole Fastener in an assembly; <i>smart_hole_fastener_tree_item</i> RMB > Top stack
swCommands_NearestSnap	520; valid for sketches; Quick Snaps toolbar > Nearest Snap
swCommands_New	1; File menu > New; Standard toolbar > New
swCommands_New_Display_State	2129; Visual Overlay dialog toolbar > New Display State
swCommands_New_Subassembly	1258; valid for assemblies; in the FeatureManager design tree, <i>top_level_assembly</i> RMB menu > Insert New Subassembly
swCommands_New_Toolbar_Sel_Filter	1177; alternative to swCommands_SelectionFilters; View menu > Toolbars > Selection Filter
swCommands_New_View	1231; opens a Named View dialog; View toolbar > View Orientation > New View
swCommands_NewAssembly	295; valid for assemblies; Assembly toolbar > New Assembly
swCommands_NewMacro	573; opens the Save As dialog; Macro toolbar > New Macro
swCommands_NewMacroButton	272; creates custom macros, swCommands_UserMacro01 - swCommands_UserMacro98; Macro toolbar > New Macro Button
swCommands_NewPart	91; valid for assemblies with a selected face or plane; Assembly toolbar > New Part
swCommands_NewWindow	580; Window menu > New Window; Standard toolbar > New Window
swCommands_NextCmdMgrTab	3046; navigates to the next CommandManager tab
swCommands_NoBends	139; valid for sheet metal parts; Sheet Metal toolbar > No Bends
swCommands_NoCommand	-3; no command is running
swCommands_NoExternalReferences	578; valid for assemblies; Assembly toolbar > No External References
swCommands_NormalTo	169; View toolbar > View Orientation > Normal To
swCommands_NoSolveMove	171; valid for parts; Sketch toolbar > No Solve Move
swCommands_Note	36; opens the Note PropertyManager page; Annotation toolbar > Note
swCommands_NoteCPat	2994; opens the Circular Note Pattern PropertyManager page; Annotation toolbar > Circular Note Pattern
swCommands_NoteLPat	2993; opens the LinearNote Pattern PropertyManager page; Annotation toolbar > Linear Note Pattern
swCommands_Number	539; valid for selected text; Formatting toolbar > Number
swCommands_Numeric_Input_Toggle	3029; Sketch toolbar > Sketch Numeric Input
swCommands_Nx_Rmb_Auto_Ok	2744; valid if SelectionManager is open; in the graphics area, RMB menu > Auto-OK Selections
swCommands_Nx_Rmb_Cancel	2736; valid if SelectionManager is open; in the graphics area, RMB menu > Cancel
swCommands_Nx_Rmb_Clear_All	2737; valid if SelectionManager is open with multiple selections; in the graphics area, RMB menu > Clear All
swCommands_Nx_Rmb_Ok	2735; valid if SelectionManager is open and with multiple selections; in the graphics area, RMB menu > OK
swCommands_Nx_Rmb_Push_Pin	2743; valid if SelectionManager is open; in the graphics area, RMB menu > Pin Dialog
swCommands_Nx_Rmb_Sel_Closed_Loop	2741; valid if SelectionManager is open; in the graphics area, RMB menu > Select Closed Loop
swCommands_Nx_Rmb_Sel_Group	2739; valid if SelectionManager is open; in the graphics area, RMB menu > Select Group
swCommands_Nx_Rmb_Sel_Open_Loop	2740; valid if SelectionManager is open; in the graphics area, RMB menu > Select Open Loop
swCommands_Nx_Rmb_Sel_Region	2742; valid if SelectionManager is open; in the graphics area, RMB menu > Select Region
swCommands_Nx_Rmb_Sel_Regular	2738; valid if SelectionManager is open; in the graphics area, RMB menu > Select
swCommands_Nx_Sel_Clear_All	2722; SelectionManager dialog > Clear
swCommands_Nx_Sel_Group	2721; SelectionManager dialog > Select Group
swCommands_Nx_Sel_Loop	2720; SelectionManager dialog > Select Closed Loop
swCommands_Nx_Sel_Open_Loop	2723; SelectionManager dialog > Select Open Loop
swCommands_Nx_Sel_Region	2724; SelectionManager dialog > Select Region
swCommands_Nx_Sel_Regular	2725; SelectionManager dialog > Standard Selection
swCommands_Nx_Select_Manager	2718; opens the SelectionManager dialog which is valid only during creation of loft, sweep, and boundary surface features and path mates; in the graphics area, RMB menu > SelectionManager
swCommands_Nx_Select_Manager_End	2719; valid if SelectionManager is open during creation of loft, sweep, and boundary surface features and path mates; in the active PropertyManager page list box, RMB menu > End SelectionManager
swCommands_Object_Displayasicon	799; valid for an embedded OLE object; Edit menu > Object > Display as Icon

swCommands.Object.Displaycontent	798; valid for an embedded OLE object; Edit menu > Object > Display Content
swCommands.Object.Popup.Menu	672; embedded OLE object popup menu
swCommands.Object.Resetsize	800; valid for an embedded OLE object; Edit menu > Object > Reset Size
swCommands.OfficeAddin3dExperienceMarketPlace	3328; loads or unloads the 3DEXPERIENCE Marketplace add-in; Standard toolbar > 3DEXPERIENCE Marketplace
swCommands.OfficeButtonFlowSimulation	3146; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Flow Simulation
swCommands.OfficeButtonInspection	3148; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Inspection
swCommands.OfficeButtonPlastics	3147; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Plastics
swCommands.OfficeButtonTolAnalyst	2894; SOLIDWORKS Add-ins toolbar > TolAnalyst
swCommands.Offset.Dim.Text	1607; valid for drawings with a selected dimension text, in the graphics area, dimension_text RMB menu > Display Options > Offset Text
swCommands.OffsetEntities	76; valid for a selected face, edge, curve, or sketch entity in a part or assembly; Layout Tools or Sketch toolbar > Offset Entities
swCommands.OffsetOnSurface	3190; opens the Offset On Surface PropertyManager page; Sketch toolbar > Offset On Surface
swCommands.Ok	766; OK in dialogs
swCommands.Ok.Command	3042; Standard toolbar > OK
swCommands.Ole.Edit	1675; valid for a selected embedded OLE object; RMB menu > Edit with tool_name
swCommands.Ole.Property_Sheet	1500; valid for a selected embedded OLE object, opens the OLE Object Property dialog; RMB menu > Properties
swCommands.On.Demand.Manufacturing	3499; Opens 3DEXPERIENCE Make in the SOLIDWORKS Task Pane. Make provides instant quotes for your parts and connects you with manufacturing service providers; only valid if 3DEXPERIENCE Marketplace Add-in is loaded and logged into; Tools toolbar > On Demand Manufacturing
swCommands.On.Hide.Cosmetic.Welds	2998; valid for a weldment part with a visible weld bead feature and a selected Weld Folder, in the FeatureManager design tree, Weld Folder RMB menu > Hide Cosmetic Welds
swCommands.On.Hold.Cosmetic.Welds.Rebuild	3127; valid for a weldment part with a weld bead feature and a selected Weld Folder, in the FeatureManager design tree, Weld Folder RMB menu > Suspend Automatic Rebuild
swCommands.On.Rebuild.Cosmetic.Welds	3128; valid for a weldment part with a weld bead feature and a selected Weld Folder, in the FeatureManager design tree, Weld Folder RMB menu > Rebuild Welds
swCommands.On.Screen.Dim.Dialog	3488; For a selected drawing dimension, opens an on-screen dimension dialog that mirrors the Dimension Text section of the Dimension PropertyManager
swCommands.On.Show.Cosmetic.Welds	2997; valid for a weldment part with a hidden weld bead feature and a selected Weld Folder, in the FeatureManager design tree, Weld Folder RMB menu > Show Cosmetic Welds
swCommands.Online.Familytable.Closed	3417
swCommands.OnViewCenterOfMassSymbol	3059; View toolbar > Hide/Show Items > View Center of Mass
swCommands.Open	0; File menu > Open ; Standard toolbar > Open
swCommands.Open.Assembly	3009; valid for a drawing view with a selected assembly; in the FeatureManager design tree, drw_view_assem RMB menu > Open Assembly
swCommands.Open.Associated.Drw	2458; valid for a selected model, opens the Open dialog; in the FeatureManager design tree, model RMB context toolbar > Open Drawing
swCommands.Open.Bookmark.Editor	3515; valid only in SOLDWORKS Connected, accesses the Bookmark Editor; Lifecycle and Collaboration toolbar > Add to Bookmark > Open Bookmark Editor
swCommands.Open.Comp.Assem.File	1377; valid for a selected component in a drawing, opens the component file
swCommands.Open.Comp.File	970; valid for a selected component in an assembly, in the FeatureManager design tree, selected_comp RMB context toolbar > Open Part
swCommands.Open.Detailing.Drw	3497; opens drawing in detailing mode; Standard toolbar > Open Drawing in Detailing Mode
swCommands.Open.LightWeight	3039; valid for assemblies opened in Large Design Review mode; Assembly toolbar > Open in Lightweight
swCommands.Open.Part	3008; valid for a drawing view with a selected component; in the FeatureManager design tree, drw_view_comp RMB toolbar > Open Part
swCommands.Open.Partdrawg.For.Drawing	3503; Opens the drawing for the selected part or assembly in the drawing; In a drawing view, RMB on a part or assembly > Open Drawing
swCommands.Open.Sub.Assembly	3011; valid for a drawing of an assembly with subassemblies; in the graphics area, face_or_edge RMB context toolbar > Open Subassembly
swCommands.OpenCollaborativeTask	3534; valid only in SOLIDWORKS Design connected to the 3DEXPERIENCE platform, opens the Collaborative Tasks app in the SOWIDWORKS Task Pane; Lifecycle and Collaboration toolbar > (split button) Create New Task/Open Collaborative Task
swCommands.OpenFromPC	3495; Opens a dialog to select a document on this PC to open in SOLIDWORKS Power-By; File > Open from This PC...
swCommands.OpenIn.SWVisualize	3544; Opens a model in SOLIDWORKS Visualize
swCommands.OpenInternetAddress	130; opens the Open Internet Address dialog; Web toolbar > Open Internet Address
swCommands.Option.Relations.Snaps	2169; opens the Relations/Snaps page of the System Options dialog for a selected sheet or drawing view in a drawing; in the FeatureManager design tree, sheet RMB menu > Relations/Snaps Options
swCommands.Options	342; opens the System Options dialog; Standard toolbar > Options
swCommands.OrdinateDimension	346; valid for an open sketch; Dimensions/Relations toolbar > Ordinate Dimension
swCommands.Orient.Annotation.By.Selection	2216; valid for a selected linear radial dimension; in the graphics area, lin_radial_dim RMB menu > Display Options > Orientation > By Selection
swCommands.Orient.Annotation.View	2442; valid for parts and assemblies with a selected active annotation view, in the FeatureManager design tree, active_anno_view RMB menu > Orient
swCommands.Page.Setup	975; File menu > Page Setup
swCommands.Pan	330; View toolbar > Pan
swCommands.Parabola	151; Sketch toolbar > Parabola
swCommands.Parallelogram	294; opens the Rectangle PropertyManager page; Sketch tools > Parallelogram
swCommands.ParallelSnap	526; valid during sketch creation only with parts that contain curves such as circles, arcs, fillets, parabolas, ellipses, partial ellipses, or splines; Quick Snaps toolbar > Parallel Snap
swCommands.Parent.Child.Rel	806; valid for a selected item in the FeatureManager design tree, opens the Parent/Child Relationships dialog; in the FeatureManager design tree, tree_item RMB menu > Parent/Child
swCommands.PartialEllipse	86; valid for a selected plane, planar face, or edge on which to create a partial elliptical sketch; Sketch toolbar > Partial Ellipse
swCommands.PartingLines	445; valid for parts; Mold Tools toolbar > Parting Lines
swCommands.PartReviewer	3058; valid for parts; Tools toolbar > Part Reviewer
swCommands.Paste	585; valid for a non-empty clipboard; Standard toolbar > Paste
swCommands.Paste.Appearance	3054; valid for a selection after an appearance has been copied; Render Tools or View toolbar > Paste Appearance
swCommands.PathLengthDimension	3096; valid for an open sketch with selected entities that are end-to-end coincident and form a single chain, opens the Path Length PropertyManager page; Dimensions/Relations toolbar > Path Length Dimension
swCommands.PatternStructConnection	3509; Opens the Pattern Connection Element to Corners PropertyManager; SOLIDWORKS Menu > Insert > Structure System > Pattern Connection Element to Corner
swCommands.Pe.Newsgroup	1948; valid on the SOLIDWORKS Personal Edition Help menu
swCommands.PerimeterCircle	545; valid for a selected plane, planar face, or edge, opens the Circle PropertyManager page; Sketch or Layout Tools toolbar > Perimeter Circle
swCommands.PerpendicularSnap	527; valid during sketch creation only with parts that contain curves such as circles, arcs, fillets, parabolas, ellipses, partial ellipses, or splines; Quick Snaps toolbar > Perpendicular Snap
swCommands.Perspective	349; valid for parts and assemblies; View toolbar > View Settings > Perspective
swCommands.Pick.Identicalcomponents	3186; valid for assemblies with a selected component; Tools menu > Component Selection > Select Identical Components
swCommands.PickMode	345; places the model in pick mode; Sketch or Standard toolbar > Select
swCommands.Pin.Orientation.Dialog	2838; valid after View toolbar > View Orientation > More Options > Orientation dialog; Pin/Unpin the dialog
swCommands.Pipe.Route	2270; valid for the SOLIDWORKS Routing add-in, displays the Piping toolbar; Routing Tools toolbar > Piping
swCommands.Pipe.Rt.Properties	2257; valid for the SOLIDWORKS Routing add-in and an open piping assembly; Piping toolbar > Route Properties
swCommands.Piping.Custom.Pipe.Config	1353; valid for a selected reducer route component in a piping drawing or the Input folder of a piping assembly; in the FeatureManager design tree, reducer_route_comp RMB menu > Create Custom Pipe Configuration
swCommands.Piping.Make.Flange.Driven	1356; valid for a selected fitting in a piping drawing or the Input folder of a piping assembly; in the FeatureManager design tree, comp RMB menu > Constrain Fitting to Sketch
swCommands.Piping.Make.Flange.Driving	1355; valid for a selected fitting in a piping drawing or the Input folder of a piping assembly; in the FeatureManager design tree, comp RMB menu > Constrain Sketch to Fitting
swCommands.Piping.Standard.Pipe.Config	1354; valid for a selected reducer route component in a custom pipe configuration in a piping drawing or the Input folder of a piping assembly; in the FeatureManager design tree, reducer_route_comp RMB menu > Use Standard PipeTube Configuration
swCommands.Plane	554; valid for a selected reference in a part, opens the Sketch Plane PropertyManager page; Sketch toolbar > Plane
swCommands.PlasticsPremium	3493; SOLIDWORKS Plastics Premium
swCommands.PlasticsPro	3492; SOLIDWORKS Plastics Professional
swCommands.PlasticsStd	3491; SOLIDWORKS Plastics Standard
swCommands.PLM.Gen.Derived.Output.Number	3483; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Allows you to generate derived output for a selected object; MySession widget > Action Bar > Tools > Generate Derived Output or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Generate Derived Output
swCommands.PLM.Maturity	3476; for SOLIDWORKS Design connected to the 3DEXPERIENCE platform only, changes the maturity state of a selected object; MySession widget > Action Bar > Lifecycle > Maturity or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Maturity
swCommands.PLM.Move.to	3478; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Allows you to move a selected object to another collaborative space and/or organization and change its owner; MySession widget > Action Bar > Lifecycle > Move To or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Move To
swCommands.PLM.New.Revision	3477; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Allows you to create a new revision of a selected object and refresh local information to reflect the new revision; MySession widget > Action Bar > Lifecycle > New Revision or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > New Revision
swCommands.PLM.Properties	3479; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Displays the 3DEXPERIENCE properties of the selected object; MySession widget > Action Bar > View > Properties or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > PLM Properties
swCommands.PLM.Relations	3480; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Displays the ecosystem of the related objects by navigating on relationships and paths; MySession widget > Action Bar > Tools > Relations or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Relations
swCommands.PLM.Reload.fromServer	3474; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Updates the selected revision in a session with the latest version that exists in 3DEXPERIENCE; MySession widget > Action Bar > Lifecycle > Reload from Server or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Reload from Server
swCommands.PLM.Replace.By.Revision	3475; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Opens the Replace by Revision dialog box to replace the revision that is open in the session; MySession widget > Action Bar > Lifecycle > Replace by Revision or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Replace by Revision
swCommands.PLM.Replace.Content	3481; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Opens the File Selection Box in which you can select an object to replace a pre-selected object; MySession widget > Action Bar > Tools > Replace Content or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Replace Content
swCommands.PLM.Reserve	3472; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Reserves the selected object; MySession widget > Action Bar > Lifecycle > Reserve or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Reserve
swCommands.PLM.Set.Ent.Item.Number	3482; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Opens the Set Enterprise Item Number dialog box where you can enter the enterprise item number for parts and assemblies; MySession widget > Action Bar > Tools > Set Enterprise Item Number or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Set Enterprise Item Number
swCommands.PLM.Unreserve	3473; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Removes the reservation of the selected object; MySession widget > Action Bar > Lifecycle > Unreserve or SOLIDWORKS menu bar > Tools > Lifecycle and Collaboration > Unreserve
swCommands.PmCancel	-1; valid on PropertyManager pages; Cancel
swCommands.PmOK	-2; valid on PropertyManager pages; OK
swCommands.Point	72; valid for a selected plane, planar face, or edge; Sketch toolbar > Point
swCommands.PointSnap	521; valid for sketches; Quick Snaps toolbar > Point Snap
swCommands.Polygon	305; valid for a selected plane, planar face, or edge, opens the Polygon PropertyManager page; Sketch tools > Polygon
swCommands.Popup.Hide.Component	812; valid for a selected, visible component; RMB menu > Hide Component
swCommands.Popup.Hide.Hidden	810; valid for a selected feature with visible edges; RMB menu > Hide Hidden Edges
swCommands.Popup.Show.Component	811; valid for a selected, hidden component; RMB menu > Show Component
swCommands.Popup.Show.Hidden	808; valid for a selected feature with hidden edges; RMB menu > Show Hidden Edges
swCommands.Predefined.Add.Model	2507; valid for a predefined drawing view; predefined_drawing_view RMB menu > Insert Model
swCommands.PredefinedView	428; valid for drawings; Drawing toolbar > Predefined View
swCommands.PrevCmdMgrTab	3047; VK_PRIOR; navigates to the previous CommandManager tab; resource string "Previous CommandManager Tab"

swCommands_Preview_Sketch_Dimension_Toggle	3518; Toggles preview of selected sketch dimension; Sketch toolbar > Preview Sketch Dimension
swCommands_PreviousVersionCheck	3523; launches previous release check dialog to check the model for incompatible features; Tools > Evaluate > Previous Release Check
swCommands_PreviousView	159; valid for models with changed views; View toolbar > View Orientation dialog > Previous View
swCommands_PrimaryAdvStructMember	3336; creates a primary structural member feature by sweeping pre-defined profiles along user-defined paths; Structures toolbar > Primary Structural Member...
swCommands_Print	589; valid for an open document, opens the Print dialog; Standard toolbar > Print
swCommands_PrintPreview	590; Standard toolbar > Print Preview
swCommands_ProfileProperties	3386; creates a predefined pierce point in the weldment profile; Insert > Structure System > Profile Properties
swCommands_ProjectCurve	74; valid for parts with a selected sketch; Features toolbar > Curves > Project Curve
swCommands_ProjectView	28; valid for a selected drawing view; Drawing toolbar > Projected View
swCommands_Propagate_Slots	3517; Opens Slot Propagation PropertyManager; Propagates slots to a selected instance or all instances of an assembly component containing a tab feature; RMB menu for selected component with tab feature > Propagate Slots...
swCommands_Properties	75; opens a Properties dialog for the current selection; Standard toolbar > Properties
swCommands_Properties_Smart_Fastener	2456; valid for a selected Smart Fastener; smart_fastener RMB menu > Properties
swCommands_Publish_3DSwym_3D	3503; valid only for 3DEXPERIENCE platform/SOLIDWORKS Design connected to the 3DEXPERIENCE platform; Tools menu > Lifecycle and Collaboration > Publish to 3DSwym > Share as 3D ; exports the current model as a 3DXML file and publishes it in a 3DSwym community or conversation
swCommands_Publish_3DSwym_Picture	3502; valid only for 3DEXPERIENCE platform/SOLIDWORKS Design connected to the 3DEXPERIENCE platform; Tools menu > Lifecycle and Collaboration > Publish to 3DSwym > Share as Picture ; publishes a picture of the current model in a 3DSwym community or conversation
swCommands_Publish_DI_Content	2758; valid for the Motion Study gantt chart and a selected, suppressed simulation element row, in the MotionManager design tree, rotary_motor_bar RMB menu > Add to Library
swCommands_Publish_HomeByMe	3496; publishes the current document to HomeByMe; Tools toolbar > Publish to HomeByMe...
swCommands_Publish_To_Edrawing	2931; Standard toolbar > Publish eDrawings File
swCommands_Publish3DPDF	3451; SOLIDWORKS MBD toolbar > Publish to 3D PDF
swCommands_PublishSTEP242File	3198; SOLIDWORKS MBD toolbar > Publish STEP 242 File
swCommands_PunchTable	3036; valid for drawings, opens the Punch Table PropertyManager page; Table toolbar > Punch Table
swCommands_PushPull	609; valid for parts, opens the Freeform PropertyManager page; Features toolbar > Freeform
swCommands_QuadrantSnap	537; valid for sketches; Quick Snaps toolbar > Quadrant Snap
swCommands_Query_Advanced	1140; valid for assemblies, opens the Advanced Component Selection dialog; Tools menu > Component Selection > Advanced Select
swCommands_Quick_Create_Plane	1736; valid for a part, opens the Plane PropertyManager page
swCommands_Rad_Dim_Diametric	1570; valid for a part with a selected radial dimension; rad_dim RMB menu > Display Options > Display as Diameter
swCommands_Rad_Dim_Lindiamtric	1571; valid for a part with a selected diameter dimension; diam_dim RMB menu > Display Options > Display as Linear
swCommands_Rad_Dim_Radial	1568; valid for a part with a selected diameter dimension; diam_dim RMB menu > Display Options > Display as Radius
swCommands_RapidPrototype	624; valid for Windows 8.1 or later, opens the Print3D PropertyManager page; Standard toolbar > Print3D
swCommands_RapidSketch	2835; Sketch toolbar > Rapid Sketch
swCommands_Re_Jog	3083; valid for a drawing of a circle or arc with a selected angular running dimension; in the graphics area, angular_running_dimension RMB menu > Display Options > Re-Jog Running Dimension
swCommands_Read_Only_Pref	1905; valid in an open file dialog with preview, RMB menu > Open as Read-only
swCommands_RealviewGraphics	499; valid for parts and assemblies; View toolbar > View Settings > RealView Graphics
swCommands_RealViewPlusGraphics	500; valid if enabled in the registry (graphics, RealViewPlus_Enable = 1); View menu > Display > RealView Plus Graphics
swCommands_Reattach_Dim	3521; Re-attaches the selected dangling dimension; RMB click a dimension > Reattach
swCommands_Reattach_to_CMarkSet	3137; valid for a selected dangling center mark in a drawing; in the graphics area, dangling_center_mark RMB menu > Reattach
swCommands_Rebuild	17; Standard toolbar > Rebuild
swCommands_RebuildAll	3200; Standard toolbar > Rebuild All configuration
swCommands_RebuildAndSaveConfig	3060; valid for parts and assemblies with multiple configurations; in the ConfigurationManager, configuration RMB menu > Add Rebuild/Save Mark
swCommands_RebuildAndSaveConfigActive	3; valid for parts and assemblies with multiple configurations; in the ConfigurationManager, top_assembly RMB menu > Rebuild/Save Mark > Add Mark for This Configuration
swCommands_RebuildAndSaveConfigAll	3063; valid for parts and assemblies with multiple configurations; in the ConfigurationManager, top_assembly RMB menu > Rebuild/Save Mark > Add Mark for All Configurations
swCommands_RebuildAndSaveConfigOff	3061; valid for parts and assemblies with multiple configurations; in the ConfigurationManager, configuration RMB menu > Remove Rebuild/Save Mark
swCommands_RebuildAndSaveConfigSpecific	3064; valid for parts and assemblies with multiple configurations, opens the Rebuild and Save Settings dialog; in the ConfigurationManager, top_assembly RMB menu > Rebuild/Save Mark > Add Mark for Specified Configurations
swCommands_Recall_Last_Render	2971; opens the Use perspective Views in Renderings dialog; Render Tools toolbar > Recall Last Render
swCommands_RecordPauseMacro	29; Macro toolbar > Record/Pause Macro
swCommands_Rectangle	79; valid for a part with a selected plane, planar face, or edge, opens the Rectangle PropertyManager page; Sketch or Layout Tools toolbar > Corner Rectangle
swCommands_RectangleAtAngle	2793; valid for a part with a selected plane, planar face, or edge, opens the Rectangle PropertyManager page; Sketch or Layout Tools toolbar > 3 Point Corner Rectangle
swCommands_Redo	587; valid for a model for which an Undo action occurred; Standard toolbar > Redo
swCommands_Redraw	355; View toolbar > Redraw
swCommands_Ref_Help	771; Edit Referenced File Locations dialog > Help
swCommands_Reference_arrow	3138; valid for a selected component in an assembly; comp RMB menu context toolbar > Dynamic Reference Visualization (Parent)
swCommands_ReferenceGeometry	484; alternative to swCommands_Toolbar_RelGeom; View menu > Toolbars > Reference Geometry
swCommands_RefPlane_Flip_Normal	3113; valid for a selected reference plane in a part; in the graphics area, ref_plane RMB context toolbar > Flip Normal
swCommands_Reimport_From_To_Lst	2861; valid for a SOLIDWORKS Routing add-in and an assembly to which from-to list was imported; Electrical toolbar > Re-Import From/To
swCommands_RelativeView	27; valid for a drawing with a selected planar face, opens the Relative View PropertyManager page; Drawing toolbar > Relative View
swCommands_Reload	1618; Palette toolbar > Reload
swCommands_Remove_Body_Appearance	2935; valid in a body appearance callout; body_appearance_callout RMB menu context toolbar > This Instance
swCommands_Remove_Component_Appearance	2936; valid in a component appearance callout; comp_appearance_callout RMB menu context toolbar > This Instance
swCommands_Remove_Feature_Appearance	2934; valid in a feature appearance callout; feature_appearance_callout RMB menu context toolbar > This Instance
swCommands_Remove_Feature_Dims	1553; valid for a selected, dimensioned feature; in the FeatureManager design tree, feature RMB menu > HideAll Dimensions
swCommands_Remove_From_ChainDim	3412; valid for a selected dimension in a chain dimension set, makes the selected dimension independent from the chain dimension set; RMB menu > Convert To Chain
swCommands_Remove_From_Library	1525; valid for a selected library feature; in the FeatureManager design tree, lib_feat RMB menu > Remove From Library
swCommands_Remove_Mark_LDR_AndPurgeDataForAllConfig	3209; valid for an assembly opened in Resolved or Lightweight mode, allows the user to unmark the configurations to display for the assembly opened in Large Design Review mode; in the ConfigurationManager, top_level_assembly RMB menu > Large Design Review Mark > Remove Mark and Purge Data for All Configurations
swCommands_Remove_Part_Appearance	2937; valid in a part appearance callout; part_appearance_callout RMB menu context toolbar > This Instance
swCommands_Remove_Smc_Reference	2677; valid in Missing Reference list boxes of PropertyManager pages; list_box_item RMB menu > Delete
swCommands_Remove_Snap	1554; valid for a drawing with a selected dimension extension line endpoint configured with a snap option; dim_ext_line_endpt_with_snap RMB menu > Display Options > Default Extension Snap
swCommands_RemoveAllDisplayStates	3037; valid for a part that is not in edit mode; in the ConfigurationManager, white_space RMB menu > Remove all display states
swCommands_RemovedSection	3352; adds a removed section view; Drawing toolbar > Removed Section
swCommands_RemoveMarkAndPurgeDataForAllConfig	3091; valid for parts and assemblies with multiple configurations; in the ConfigurationManager, top_assembly RMB menu > Rebuild/Save Mark > Remove Mark and Purge Data for All Configurations
swCommands_RemoveMateMisalignment	3327; valid for pre-selected concentric misaligned mate, removes its mate misalignment property; in the FeatureManager design tree, concentric mate RMB menu > Remove misalignment
swCommands_Rename_Annotation_View	3136; valid for a selected annotation view in the Select Annotation View dialog; anno_view RMB menu > Rename
swCommands_Render_Options	2968; Render Tools toolbar > Options
swCommands_Render_Region	3115; Render Tools toolbar > Render Region
swCommands_RenderToolbar	2962; alternative to swCommands_Toolbar_Render; View menu > Toolbars > Render Tools
swCommands_Renumber_Hole_Table	2964; valid for drawings with hole tables; in the FeatureManager design tree, hole_table RMB menu > Renumber all Tags
swCommands_Renumber_Series_Table	2965; valid for a selected row in the TAG column of a drawing hole table; in the graphics area, hole_table_row_tag_column RMB menu > Renumber Series
swCommands_Repair_Route	2289; valid for the SOLIDWORKS Routing add-in and an open routing assembly; Routing Tools toolbar > Repair Route
swCommands_RepairSketch	380; valid only for sketches in edit mode; Sketch toolbar > Repair Sketch
swCommands_Repeat_Command	2114; Edit menu > Repeat Last Command
swCommands_Repeat_Mate	2819; valid for selected components in an assembly, opens the Copy with Mates PropertyManager page; Assembly toolbar > Copy with Mates
swCommands_ReplaceComponents	575; valid for assemblies, opens the Replace PropertyManager page; Assembly toolbar > Replace Components
swCommands_ReplaceEntity	3104; valid for a selected sketch entity in an open sketch, opens the Replace Entity PropertyManager page; Sketch toolbar > Replace Entity
swCommands_ReplaceFace	371; valid for a solid or surface body, opens the Replace Face1 PropertyManager page; Surface toolbar > Replace Face
swCommands_ReplaceFormTool	3024; valid for parts with a Forming Tool, opens the Open dialog; in the FeatureManager design tree, forming_tool RMB menu > Replace Form Tool
swCommands_ReplaceMateEntities	574; valid for a selected Mate Group entity in assemblies; in the FeatureManager design tree, Assembly toolbar > Replace Mate Entities
swCommands_Reset	635; dialog > Reset
swCommands_Reset_Dim_Extension_Centerline	3107; valid for a drawing with a centered dimension extension line; in the graphics area, dim_ext_line RMB menu > Reset Extension Line Style
swCommands_Reset_Line_Font	1575; valid for a selected drawing edge whose line format was changed from the default; in the graphics area, sel_edge RMB menu > Reset line font
swCommands_Reset_Std_View	700; valid after View toolbar > View Orientation > More Options is selected; Orientation dialog > Reset Standard Views
swCommands_Resolve_All	1234; valid for selected assembly with lightweight components; in the FeatureManager design tree, top_level_assy RMB menu > Set Lightweight to Resolved
swCommands_Resolve_Conflict	2192; valid for an open, over-defined sketch, opens the SketchXpert PropertyManager page; Tools menu > Sketch Tools > SketchXpert
swCommands_Resolve_Drawing	3447; valid only for drawings in Detailing mode; FeatureManager design tree root node RMB menu > Resolve drawing or first button in every CommandManager toolbar
swCommands_Resolve_Mate_Component_1	2532; valid for an assembly with two lightweight mate components, one of which is suppressed; in the FeatureManager design tree, unsuppressed_lightweight_mate_component > Mates in assy_name > constraint_of_suppressed_lightweight_mate_component_1 RMB menu > suppp_lwt_mate_comp_1 > Resolve component
swCommands_Resolve_Mate_Component_2	2537; valid for an assembly with a mate containing three lightweight mate components, two of which are suppressed; in the FeatureManager design tree, unsuppressed_lightweight_mate_component > Mates in assy_name > constraint_of_suppressed_lightweight_mate_component_2 RMB menu > suppp_lwt_mate_comp_2 > Resolve component
swCommands_Resolve_Out_Of_Date_Lwcomps	1407; valid for a selected assembly with out-of-date lightweight components; top_assy RMB menu > Set out-of-date Lightweight to Resolved
swCommands_Resolve_Top	3034; valid for a selected assembly opened in Large Design Review mode; in the FeatureManager design tree, top_assy RMB menu > Set All to Resolved
swCommands_Resolve_Top_LightWeight	3035; valid for a selected assembly opened in Large Design Review mode; in the FeatureManager design tree, top_assy RMB menu > Set All to Lightweight
swCommands_Restore_Align	1513; valid only for a selected drawing view that has been aligned; in the FeatureManager design tree, sel_align_view RMB menu > Alignment > Default Alignment
swCommands_Restore_Rotation	637; valid for a selected drawing view that has been rotated; in the FeatureManager design tree, sel_rot_view RMB menu > Alignment > Default Rotation
swCommands_Restore_Settings	3114; Tools menu > Save/Restore Settings
swCommands_Resume_Stacking_Balloons	676; valid for a selected balloon in a drawing view, opens the Stacked Balloon PropertyManager page; sel_balloon RMB menu > Add to Stack
swCommands_Reverse_Endpoint_Tangency	3304; Sketch toolbar > Reverse Endpoint Tangent
swCommands_Review_Pending_Updates	2989; valid for a selected frozen feature that has updates pending due to the lock, opens a What's Wrong dialog with the pending updates; in the FeatureManager design tree, frozen_feature RMB menu > Review Pending Updates ; resource string "Show all pending updates due to Freeze. Review Pending Updates"
swCommands_RevisionCloud	3052; valid for drawings, opens the Revision Cloud PropertyManager page; Annotation toolbar > Revision Cloud

swCommands_RevisionSymbol	457; valid for a drawing with a revision table with one or more revision rows; Annotation toolbar > Revision Symbol
swCommands_RevisionTable	456; valid for drawings, opens the Revision Table PropertyManager page; Table toolbar > Revision Table
swCommands_RevolvedBossBase	24; valid for parts with a selected sketch; Features toolbar > Revolved Boss/Base
swCommands_RevolvedCut	48; valid for parts with a selected sketch; Features toolbar > Revolved Cut
swCommands_RevolvedSurface	104; valid for a selected profile and the centerline about which to revolve the surface, opens the Surface-Revolve PropertyManager page; Surfaces toolbar > Revolve Surface
swCommands_Rib	125; valid for parts with a selected sketch, opens the Rib1 PropertyManager page; Features toolbar > Rib
swCommands_Right	165; View toolbar > View Orientation > Right
swCommands_Rip	297; valid for sheet metal parts; Sheet Metal toolbar > Rip
swCommands_Rip_Both_Directions	1707; valid when inserting a sheet metal rip; in the graphics area, <i>rip_manipulator</i> RMB menu > Both Directions
swCommands_Rip_Single_Direction	1708; valid when inserting a sheet metal rip; in the graphics area, <i>rip_manipulator</i> RMB menu > Single Direction
swCommands_Rmb_Ann_Use_Jog_Leader	1808; valid for a new drawing annotation; in the graphics area, <i>new_anno</i> RMB menu > Use Multi-jog Leader
swCommands_Rmb_Appear_Callout_Delete_Body_Color	2696; valid for a selected body row in an appearance callout; RMB menu > Remove Color
swCommands_Rmb_Appear_Callout_Delete_Body_Texture	2697; valid for a selected body row in an appearance callout; RMB menu > Remove Texture
swCommands_Rmb_Appear_Callout_Delete_Comp_Color	2698; valid for a selected component row in an appearance callout; RMB menu > Remove Color
swCommands_Rmb_Appear_Callout_Delete_Comp_Texture	2699; valid for a selected component row in an appearance callout; RMB menu > Remove Texture
swCommands_Rmb_Appear_Callout_Delete_Face_Color	2685; valid for a selected face row in an appearance callout; RMB menu > Remove Color
swCommands_Rmb_Appear_Callout_Delete_Face_Texture	2686; valid for a selected face row in an appearance callout; RMB menu > Remove Texture
swCommands_Rmb_Appear_Callout_Delete_Feat_Color	2694; valid for a selected feature row in an appearance callout; RMB menu > Remove Color
swCommands_Rmb_Appear_Callout_Delete_Feat_Texture	2695; valid for a selected feature row in an appearance callout; RMB menu > Remove Texture
swCommands_Rmb_Appear_Callout_Delete_Part_Color	2700; valid for a selected part row in an appearance callout; RMB menu > Remove Color
swCommands_Rmb_Appear_Callout_Delete_Part_Texture	2701; valid for a selected part row in an appearance callout; RMB menu > Remove Texture
swCommands_Rmb_Appear_Callout_Edit_Body_Color	2688; valid for a selected body row in an appearance callout; RMB menu > Edit Color
swCommands_Rmb_Appear_Callout_Edit_Body_Texture	2691; valid for a selected body row in an appearance callout; RMB menu > Edit Texture
swCommands_Rmb_Appear_Callout_Edit_Color	2649; valid for a selected face row in an appearance callout; RMB menu > Edit Color
swCommands_Rmb_Appear_Callout_Edit_Comp_Color	2702; valid for a selected component row in an appearance callout; RMB menu > Edit Color
swCommands_Rmb_Appear_Callout_Edit_Comp_Texture	2703; valid for a selected component row in an appearance callout; RMB menu > Edit Texture
swCommands_Rmb_Appear_Callout_Edit_Feat_Color	2687; valid for a selected feature row in an appearance callout; RMB menu > Edit Color
swCommands_Rmb_Appear_Callout_Edit_Feat_Texture	2690; valid for a selected feature row in an appearance callout; RMB menu > Edit Texture
swCommands_Rmb_Appear_Callout_Edit_Part_Color	2689; valid for a selected part row in an appearance callout; RMB menu > Edit Color
swCommands_Rmb_Appear_Callout_Edit_Part_Texture	2692; valid for a selected part row in an appearance callout; RMB menu > Edit Texture
swCommands_Rmb_Appear_Callout_Edit_Texture	2650; valid for a selected face row in an appearance callout; RMB menu > Edit Texture
swCommands_Rmb_Appearance_Co	2646; valid for a selected face, displays an appearance callout in the graphics area
swCommands_Rmb_BiDir	3383; valid when the Projected Curve PropertyManager is active, graphics area RMB menu > Bi-Directional Projection
swCommands_RMB_Blind_Direction_2	3072; valid when the Surface-Revolve PropertyManager page is open, and Direction 1 is not set to Mid Plane; in the graphics area, <i>revolve_sketch</i> RMB menu > Direction 2 > Blind
swCommands_Rmb_BodyAppearance_Co	2679; valid for a selected solid body, displays an appearance callout in the graphics area
swCommands_Rmb_Collect_All_Bends	730; valid for sheet metal parts when the Fold PropertyManager page is open; in the graphics area, RMB menu > Collect All Bends
swCommands_Rmb_CompAppearance_Co	2680; valid for a selected component, displays an appearance callout in the graphics area
swCommands_Rmb_Cpat_Equal_Space	1660; valid when a Circular Pattern PropertyManager page is open for a non-dimension circular pattern; in the graphics area, RMB menu > Equal Spacing ; valid only if swCommands_Rmb_Cpat_Symmetric is called
swCommands_Rmb_Cpat_Equal_Spacing1	3213; valid when a Circular Pattern PropertyManager page is open for a non-dimension circular pattern; in the graphics area, RMB menu > Equal Spacing Direction 1 ; not valid if swCommands_Rmb_Cpat_Symmetric is called; see swCommands_Rmb_Cpat_Equal_Space
swCommands_Rmb_Cpat_Equal_Spacing2	3214; valid when a Circular Pattern PropertyManager page is open for a non-dimension circular pattern; in the graphics area, RMB menu > Equal Spacing Direction 2 ; not valid if swCommands_Rmb_Cpat_Symmetric is called; see swCommands_Rmb_Cpat_Equal_Space
swCommands_Rmb_Cpat_Flip_Direction	1667; valid when a Circular Pattern PropertyManager page is open; in the graphics area, RMB menu > Reverse Direction
swCommands_Rmb_Cpat_Geometry_Pattern	1661; valid when a Circular Pattern PropertyManager page is open for a non-dimension, non-body circular pattern in an assembly that is not in edit mode; in the graphics area, RMB menu > Geometry Pattern
swCommands_Rmb_Cpat_Symmetric	3192; valid when a Circular Pattern PropertyManager page is open; in the graphics area, RMB menu > Symmetric
swCommands_Rmb_Create_Hole_Series	2660; valid for a selected assembly Wizard Hole; in the FeatureManager design tree, <i>wizard_hole_feature</i> RMB menu > Create Hole Series
swCommands_Rmb_Delete_Manipulator	2500; valid for a selected manipulator for some dialogs (mold shut-off surface and fillet); RMB menu > Delete
swCommands_RMB_Direction_2_OnOff	3079; valid when the Surface-Revolve PropertyManager page is open, and Direction 1 is not set to Mid Plane; in the graphics area, <i>revolve_sketch</i> RMB menu > Direction 2 > Direction 2 Off
swCommands_Rmb_Display_Camera_FOV_Box	2840; valid for a model with a selected camera in DisplayManager; in the display area, RMB menu > Display Field of View Box
swCommands_Rmb_Edit_Camera	1059; valid for a model with a selected camera in DisplayManager; Camera > Camera1 RMB menu > Edit Camera
swCommands_Rmb_Edit_Section	753; valid for a section view; in the graphics area of a section view, RMB menu > Section View Properties
swCommands_Rmb_Edit_SimResults	3202; opens the View Simulation Results PropertyManager page; valid only if the SOLIDWORKS Simulation add-in is loaded, Simulation study results are available for the current model, View toolbar > View Simulation Results was previously clicked, and the View Simulation Results PropertyManager page was configured to display simulation results with the model; in the graphics area, RMB menu > Simulation Results Properties
swCommands_Rmb_Enable_Appear_Callouts	2704; Appearance Callout dialog > Enable Appearance Callouts
swCommands_Rmb_Extend_Distance	1664; valid when the Surface-Extend1 PropertyManager page is open; in the graphics area, <i>surface_extend_sketch</i> RMB menu > Distance
swCommands_Rmb_Extend_Upto_Point	1665; valid when the Surface-Extend1 PropertyManager page is open; in the graphics area, <i>surface_extend_sketch</i> RMB menu > Up to Point
swCommands_Rmb_Extend_Upto_Surface	1666; valid when the Surface-Extend1 PropertyManager page is open; in the graphics area, <i>surface_extend_sketch</i> RMB menu > Up to Surface
swCommands_Rmb_Face_Zebra_Stripes	1807; valid for a selected face, opens the Zebra Stripes PropertyManager page; <i>sel_face</i> RMB menu > Zebra Stripes
swCommands_Rmb_FeatAppearance_Co	2678; valid for a selected feature, displays an appearance callout in the graphics area
swCommands_Rmb_Find_Intersection	3110; use to define virtual sharps; valid for an open sketch while in the dimension tool; in the graphics area, <i>sketch_entity</i> RMB menu > Find Intersection
swCommands_Rmb_Iso_Ad_Mesh	731; valid when the Face Curves PropertyManager page is open, and Position is selected; in the graphics area, RMB menu > Mesh
swCommands_Rmb_Iso_Constrain_Model	733; valid when the Face Curves PropertyManager page is open; in the graphics area, RMB menu > Constrain to Model
swCommands_Rmb_Iso_Ignore_Holes	734; valid when the Face Curves PropertyManager page is open; in the graphics area, RMB menu > Ignore Holes
swCommands_Rmb_Iso_Position	732; valid when the Face Curves PropertyManager page is open, and Mesh is selected; in the graphics area, RMB menu > Position
swCommands_Rmb_Leader_Done	2475; valid for drawings while adding an annotation leader; <i>anno_leader</i> RMB menu > End Leader (double click)
swCommands_Rmb_Lock_Camera	1062; valid when a model is in Camera View mode; in the graphics area, RMB menu > Lock Camera
swCommands_Rmb_Loft_Close	726; valid when the Surface-Loft PropertyManager page is open; in the graphics area, <i>loft_sketch</i> RMB menu > Close Loft
swCommands_Rmb_Loft_Mesh_Allfaces1	2630; valid when the Boundary-Surface PropertyManager page is open, and two directions are selected; in the graphics area, RMB menu > Mesh Preview > Mesh All Faces
swCommands_Rmb_Loft_Mesh_Clear_Allfaces1	2632; valid when the Boundary-Surface PropertyManager page is open, two directions are selected, and all faces are meshed; in the graphics area, RMB menu > Mesh Preview > Clear All Meshed Faces
swCommands_Rmb_Loft_Mesh_Clear_Oneface1	2633; valid when the Boundary-Surface PropertyManager page is open, and a face is meshed; in the graphics area, RMB menu > Mesh Preview > Clear Meshed Faces
swCommands_Rmb_Loft_Mesh_Oneface1	2631; valid when the Boundary-Surface PropertyManager page is open; in the graphics area, RMB menu > Mesh Preview > Mesh Face
swCommands_Rmb_Loft_Show_All	2525; valid when the Loft PropertyManager page is open, and connectors have been hidden; in the graphics area, RMB menu > Show All Connectors
swCommands_Rmb_Loft_Synch_Hide	2522; valid when the Loft PropertyManager page is open, and a connector is selected; in the graphics area, <i>connector</i> RMB menu > Hide Connector
swCommands_Rmb_Loft_Synch_Hide_All	2524; valid when the Loft PropertyManager page is open; in the graphics area, RMB menu > Hide All Connectors
swCommands_Rmb_Loft_Synch_Undo	2523; valid when the Surface-Loft PropertyManager page is open; in the graphics area, RMB menu > Reset Connectors
swCommands_Rmb_Loft_Synch_Undo_Last_Oper	2611; valid when the Loft PropertyManager page is open, and a connector has been deleted; in the graphics area, RMB menu > Undo connector edit
swCommands_Rmb_Loft_Tangency	724; valid when the Surface-Loft PropertyManager page is open; in the graphics area, <i>loft_sketch</i> RMB menu > Merge tangent faces
swCommands_Rmb_Mvsrf_Copy	746; valid when the Move Face PropertyManager page is open; in the graphics area, RMB menu > Copy
swCommands_RMB_OffsetFromSurface_Direction_2	3075; valid when the Surface-Revolve PropertyManager page is open, and Direction 1 is not set to Mid Plane; in the graphics area, <i>revolve_sketch</i> RMB menu > Direction 2 > Offset From Surface
swCommands_Rmb_onto_Face	2473; valid when the Projected Curve PropertyManager page is open, and Projection type is Sketch on sketch; in the graphics area, RMB menu > Sketch onto Face(s)
swCommands_Rmb_onto_Sketch	2472; valid when the Projected Curve PropertyManager page is open, and Projection type is Sketch on faces; in the graphics area, RMB menu > Sketch onto Sketch
swCommands_Rmb_Reverse	2474; valid when the Projected Curve PropertyManager page is open; in the graphics area, RMB menu > Reverse Projection
swCommands_RMB_Reverse_Direction	3080; valid when the Surface-Revolve PropertyManager page is open; in the graphics area, <i>revolve_sketch</i> RMB menu > Direction 1 > Reverse Direction
swCommands_Rmb_Rib_Both_Sides	1791; valid when the Rib1 PropertyManager page is open; in the graphics area, RMB menu > Both Sides
swCommands_Rmb_Rib_First_Side	1789; valid when the Rib1 PropertyManager page is open; in the graphics area, RMB menu > First Side
swCommands_Rmb_Rib_Normal_To_Sketch	1792; valid when the Rib1 PropertyManager page is open, and Extrusion direction is Parallel to Sketch; in the graphics area, RMB menu > Normal to Sketch
swCommands_Rmb_Rib_Parallel_To_Sketch	1793; valid when the Rib1 PropertyManager page is open, and Extrusion direction is Normal to Sketch; in the graphics area, RMB menu > Parallel to Sketch
swCommands_Rmb_Rib_Second_Side	1790; valid when the Rib1 PropertyManager page is open, and Extrusion direction is Parallel to Sketch; in the graphics area, RMB menu > Second Side
swCommands_Rmb_Skcham_Angle	736; valid when the Sketch Chamfer PropertyManager page is open, and Distance-distance is selected; in the graphics area, RMB menu > Angle-Distance
swCommands_Rmb_Skcham_Dist	735; valid when the Sketch Chamfer PropertyManager page is open, and Angle-distance is selected; in the graphics area, RMB menu > Distance-Distance
swCommands_Rmb_Skcham_Equal	737; valid when the Sketch Chamfer PropertyManager page is open, and Distance-distance is selected; in the graphics area, RMB menu > Equal Distance
swCommands_Rmb_Sm_Bend_Revdir	739; valid when the Sketched Bend PropertyManager page is open; in the graphics area, RMB menu > Reverse Direction
swCommands_Rmb_Sm_Reverse_Dir	738; valid when the Revolve PropertyManager page is open, and Thin Feature is selected; in the graphics area, RMB menu > Reverse Direction (second version)
swCommands_Rmb_Spat_Centroid	1662; valid when a Sketch Driven Pattern PropertyManager page is open, and Reference point is Selected point; in the graphics area, RMB menu > Bounding box center
swCommands_Rmb_Spat_Geometry_Pattern	1663; valid when a Sketch Driven Pattern PropertyManager page is open; in the graphics area, RMB menu > Geometry Pattern
swCommands_Rmb_Spat_Setpoint	1773; valid when a Sketch Driven Pattern PropertyManager page is open, and Reference point is Centroid; in the graphics area, RMB menu > Selected point
swCommands_Rmb_Sweep_Align	729; valid when the Cut-Sweep PropertyManager page is open; in the graphics area, RMB menu > Align with end faces
swCommands_Rmb_Sweep_Tangency	727; valid when the Surface-Sweep PropertyManager page is open; in the graphics area, <i>sweep_sketch</i> RMB menu > Merge tangent faces
swCommands_RMB_ThroughAll_Direction_2	3076; valid when the Cut-Extrude PropertyManager page is open; in the graphics area, RMB menu > Direction 2 > Through All
swCommands_RMB_ThroughNext_Direction_2	3077; valid when the Cut-Extrude PropertyManager page is open; in the graphics area, RMB menu > Direction 2 > Up To Next
swCommands_RMB_UptoBody_Direction_2	3078; valid when the Surface-Extrude PropertyManager page is open; in the graphics area, <i>extrude_sketch</i> RMB menu > Direction 2 > Up To Body
swCommands_RMB_UptoSurface_Direction_2	3074; valid when the Surface-Revolve PropertyManager page is open, and Direction 1 is not set to Mid Plane; in the graphics area, <i>revolve_sketch</i> RMB menu > Direction 2 > Up To Surface
swCommands_RMB_UptoVertex_Direction_2	3073; valid when the Surface-Revolve PropertyManager page is open, and Direction 1 is not set to Mid Plane; in the graphics area, <i>revolve_sketch</i> RMB menu > Direction 2 > Up To Vertex
swCommands_Rmb_Zebra_Properties	1761; valid for a model with zebra stripes, opens the Zebra Stripes PropertyManager page; in the graphics area, RMB menu > Zebra Stripe Properties
swCommands_RMBFreeShapeCancel	3320; cancels FreeShape; FreeShape RMB menu > Cancel
swCommands_RMBFreeShapeOK	3319; FreeShape RMB menu > OK
swCommands_Roll	605; View toolbar > Roll

swCommands.RotaryMotor	423; MotionManager toolbar > Motor
swCommands.Rotate_180_Degrees	2278; valid when the move triad is visible; in the graphics area, triad_ring RMB menu > rotate 180°
swCommands.Rotate_45_Degrees	2880; valid for a selected ZX triad ring of a live section plane; in the graphics area, ZX_triad_ring RMB menu > rotate 45°
swCommands.Rotate_90_Degrees	2277; valid when the move triad is visible; in the graphics area, triad_ring RMB menu > rotate 90°
swCommands.Rotate_Routing_Clip	1637; valid for the SOLIDWORKS Routing add-in with a selected routing clip in an open routing assembly; Routing Tools toolbar > Rotate Clip
swCommands.Rotate_Show_Delta_Xyz	1136; valid after component RMB menu > Move with Triad command in an assembly; in the graphics area, triad_center_ball RMB menu > Show Rotate Delta XYZ Box
swCommands.Rotate_Xaxis_By90	3132; valid when the Insert Component PropertyManager page is open, and a part or assembly to insert is selected; in the graphics area, RMB menu > Rotate X 90 Deg
swCommands.Rotate_Yaxis_By90	3133; valid when the Insert Component PropertyManager page is open, and a part or assembly to insert is selected; in the graphics area, RMB menu > Rotate Y 90 Deg
swCommands.Rotate_Zaxis_By90	3134; valid when the Insert Component PropertyManager page is open, and a part or assembly to insert is selected; in the graphics area, RMB menu > Rotate Z 90 Deg
swCommands.RotateComponent	21; valid for assemblies; Tools menu > Component > Rotate or Assembly toolbar > Rotate Component
swCommands.RotateEntities	503; valid for a sketch with a selected entity or annotation; Sketch toolbar > Rotate Entities
swCommands.RotateView	329; View toolbar > Rotate View
swCommands.Route_Add_To_Fab	1328; valid for the SOLIDWORKS Routing add-in, an open routing assembly, and a selected connection point or component; in the graphics area, cpoint_or_comp RMB menu > Add to Route
swCommands.Route_Get_Property	721; valid for the SOLIDWORKS Routing add-in with a selected routing segment in an open routing assembly; in the graphics area, route_segment RMB menu > Route Segment Properties
swCommands.Route_Jo_Output	2397; valid for the SOLIDWORKS Routing add-in and an open pipe or tube routing assembly; in the graphics area, route_pipe_or_tube RMB menu > Export Pipe/Tube Data
swCommands.Route_Properties	693; valid for the SOLIDWORKS Routing add-in and an open piping route, opens the Route Properties PropertyManager page; Piping toolbar > Route Properties
swCommands.Route_Realign_Fitting	1326; valid for the SOLIDWORKS Routing add-in with an open routing assembly and a selected piping fitting; in the graphics area, sel_piping_fitting RMB menu > Change Fitting Alignment
swCommands.Route_Remove_Pipe	723; valid for the SOLIDWORKS Routing add-in with an open routing assembly and a selected pipe; in the graphics area, sel_pipe RMB menu > Remove Pipe
swCommands.Route_Rotate_Clip	2266; valid for SOLIDWORKS Routing add-in and an open routing assembly; Routing Tools toolbar > Rotate Clip
swCommands.Route_Start_Con_Point	1238; valid for the SOLIDWORKS Routing add-in with a selected component in a route that is not in edit mode; in the graphics area, comp RMB menu > Start Route
swCommands.Route_Through	2267; valid for the SOLIDWORKS Routing add-in and an open route; Routing Tools toolbar > Route Through Clip
swCommands.Route_Unhook_From	2268; valid for SOLIDWORKS Routing add-in and an open route; Routing Tools toolbar > Unhook from Clip
swCommands.RouteLine	396; valid for the SOLIDWORKS Routing add-in and an open route; Explode Sketch toolbar > Route Line
swCommands.Router_Change_Mode	2558; valid for the SOLIDWORKS Routing add-in, when the Auto Route PropertyManager page is open, and Auto Route Orthogonal route is selected; in the graphics area, RMB menu > Edit Mode
swCommands.Routing_Reuse_Route	3190; valid for the SOLIDWORKS Routing add-in and an open electrical routing assembly; Electrical toolbar > Reuse Route
swCommands.Routing_Tools	2448; valid for the SOLIDWORKS Routing add-in; Route toolbar > Routing Tools
swCommands.RunMacro	30; Macro toolbar > Run Macro
swCommands.SageExpress	2952; valid for parts, opens the Enable SustainabilityXpress dialog; Tools toolbar > SustainabilityXpress
swCommands.Save	2; for modified parts, opens the Save Modified Documents dialog; Standard toolbar > Save or Older version file
swCommands.Save_Comp	2118; valid for shared assemblies in a multi-user environment (select Tools > Options > System Options > Collaboration > Add shortcut menu items for multi-user environment ; in the FeatureManager design tree, comp RMB menu > Save
swCommands.Save_Config_Preview	1853; valid for a document that is already saved, saves a configuration preview
swCommands.Save_Journal_As_Word	2060; valid for a selected journal, saves it in Word format
swCommands.Save_Template	921; valid for drawings, opens the Save Sheet Format dialog; File menu > Save Sheet Format
swCommands.Save_To_Webfolder	1680; saves an assembly to a web folder
swCommands.Save_Virtual_Comp	3464; performs an external save of a virtual component in an assembly; in the FeatureManager design tree, right click a virtual component and select RMB menu > Save Part(In External file)
swCommands.SaveAll	19; Standard toolbar > Save All
swCommands.SaveAs	620; Standard toolbar > Save As
swCommands.SaveBlock	473; valid for blocks created in assembly layouts; Blocks toolbar > Save Sketch as Block
swCommands.SaveLocally	3457; 3DEXPERIENCE SOLIDWORKS only, saves the active document to your cache; File menu > Save Locally
swCommands.Savenotification	2357; valid during autosave, sends the current window the save notification specifics
swCommands.Saveto_Separate_File	2375; valid for weldment cut-list items, opens the Insert Into New Part PropertyManager page; in the FeatureManager design tree, Cut list folder > item RMB menu > Insert into New Part
swCommands.SaveWithOptions	3456; 3DEXPERIENCE SOLIDWORKS only, opens a dialog of options with which to save the active document; File menu > Save with Options...
swCommands.ScaleEntities	504; valid for an open sketch, opens the Scale PropertyManager page; Sketch toolbar > Scale Entities
swCommands.ScanEqual	78; valid for drawings; Dimensions/Relations toolbar > Scan Equal
swCommands.ScanTo3D	622; SOLIDWORKS Add-ins toolbar > ScanTo3D
swCommands.Scene	2799; View toolbar > Apply Scene
swCommands.Schedule_Render	2970; opens the Schedule Render dialog; Render Tools toolbar > Schedule Render
swCommands.ScreenCapture	604; Screen Capture toolbar > Image Capture
swCommands.ScreenCaptureAvi_Begin	2814; opens the Record Screen Capture to File dialog; Screen Capture toolbar > Record Video
swCommands.ScreenCaptureAvi_End	2815; valid if a screen is being videoed; Screen Capture toolbar > Stop Video Record
swCommands.ScreenCaptureToolbar	2813; alternative to swCommands_Toolbar_ScreenCapture; View menu > Toolbars > Screen Capture
swCommands.Search_Detail_Items	1998; accelerator F key to Find/Replace text in detail items
swCommands.SearchCommands	3019; Help menu > Search > Commands
swCommands.SearchFilesAndModels	3020; Help menu > Search > Files and Models
swCommands.SearchHelp	3016; Help menu > Search > SOLIDWORKS Help
swCommands.SearchManufacturers	3180; Help menu > Search > Manufacturers
swCommands.SearchMySolidworks	3174; Help menu > Search > MySolidWorks
swCommands.SecondaryAdvStrucMember	3337; creates a secondary structural member feature by sweeping pre-defined profiles along user-defined planes; Structures toolbar > Secondary Structural Member...
swCommands.SectionProperties	383; opens the Section Properties dialog; Tools toolbar > Section Properties
swCommands.SectionView	124; opens the Section View PropertyManager page; View toolbar > Section View
swCommands.Segment	3129; valid for an open sketch, opens the Segment PropertyManager page; Sketch toolbar > Segment
swCommands.SegmentImportedMeshBody	3357; segments imported solid and surface mesh bodies; Features toolbar > Segment Imported Mesh Body
swCommands.Select_All	634; dialog resource Select All
swCommands.Select_Annotation_View	3135; valid for 3D annotations, opens the Select annotation view dialog; in the graphics area, dim RMB menu > Select Annotation View
swCommands.Select_Chain	2471; valid for an open sketch, in the graphics area, selected_line RMB menu > Select Chain
swCommands.Select_Display_State	2808; Display States toolbar > dropdown
swCommands.Select_Loop	1420; in the graphics area, selected_edge RMB menu > Select Loop
swCommands.Select_Midpoint	802; valid for specific dialogs, such as the Deform PropertyManager page; in the graphics area, RMB menu > Select Midpoint ; also valid for selected_edge RMB menu > Select Midpoint
swCommands.Select_Open_Edge_Loop	1697; valid when the Untrim Surface PropertyManager page is open, and a surface edge is selected; in the graphics area, surface_edge RMB menu > Select Open Loop
swCommands.Select_Open_Half_Loop	2435; valid when the Surface-Untrim1 PropertyManager page is open, and a surface edge is selected; in the graphics area, surface_edge RMB menu > Select Partial Loop
swCommands.Select_Seed_Feature	1802; valid for a selected pattern feature; in the graphics area, sel_pattern RMB menu > Select Seed of Pattern
swCommands.Select_Snapshot	3031; valid for assemblies, opens the Name Snapshot dialog; View toolbar > Take Snapshot
swCommands.Select_SubAssembly_In_GraphicsView	2824; valid for a selected component of a subassembly; in the graphics area, subasm_comp RMB menu > Select Subassembly
swCommands.Select_Tangency	1428; valid when the Surface-Untrim1 PropertyManager page is open, and a surface edge is selected; in the graphics area, surface_edge RMB menu > Select Tangency
swCommands.Select_Tangency_Laminar	1696; valid when the Surface-Untrim1 PropertyManager page is open, and a surface edge is selected; in the graphics area, surface_edge RMB menu > Select Open Tangency
swCommands.SelectAllFilters	275; Selection Filter toolbar > Select All Filters
swCommands.SelectConfigurations	3116; Configurations toolbar > dropdown
swCommands.SelectionFilters	486; alternative to swCommands_New_Toolbar_Sel_Filter; View menu > Toolbars > Selection Filter
swCommands.Selective_Open	3033; valid for a selected assembly opened in Large Design Review mode, opens the Selective Open dialog; in the FeatureManager design tree, top_assy RMB menu > Selective Open
swCommands.Selective_Open_LightWeight	3038; valid for a selected assembly opened in Large Design Review mode, opens the Selective Open in Lightweight dialog; in the FeatureManager design tree, top_assy RMB menu > Selective Open in Lightweight
swCommands.SelectOverGeometry	3310; VIRTKEY "T"; enables/disables box and lasso selection to start on faces; Standard toolbar > Select over Geometry
swCommands.SendTo	3045; File menu > Send To
swCommands.Set_As_Anchor	1624; valid for a selected point in a drawing sheet whose format is in edit mode; sketch_pt RMB menu > Set as Anchor > table_type
swCommands.Set_Current_View_As_Back	3085; valid for assemblies and parts; View menu > Modify > Set Current View As > Back
swCommands.Set_Current_View_As_Bottom	3087; valid for assemblies and parts; View menu > Modify > Set Current View As > Bottom
swCommands.Set_Current_View_As_Front	3084; valid for assemblies and parts; View menu > Modify > Set Current View As > Front
swCommands.Set_Current_View_As_Left	3089; valid for assemblies and parts; View menu > Modify > Set Current View As > Left
swCommands.Set_Current_View_As_Right	3088; valid for assemblies and parts; View menu > Modify > Set Current View As > Right
swCommands.Set_Current_View_As_Top	3086; valid for assemblies and parts; View menu > Modify > Set Current View As > Top
swCommands.Set_Dim_Extension_Centerline	3106; valid for a drawing with a dimension extension line; in the graphics area, dim_ext_line RMB menu > Set Extension Line as Centerline
swCommands.Set_QuickView_Transparency	3032; valid for assemblies opened in Large Design Review mode with one or more modified components; View toolbar > Filter Modified Components
swCommands.Shaded	337; View toolbar > Display Style > Shaded
swCommands.ShadedSketchContours	3189; Sketch toolbar > Shaded Sketch Contours
swCommands.ShadedWithEdges	506; View toolbar > Display Style > Shaded With Edges
swCommands.ShadowsInShadedMode	399; valid for parts and assemblies; View toolbar > View Settings > Shadows in Shaded Mode
swCommands.Share	3524; opens a Share dialog to share a copy of the current model with members outside or inside your organization; File > Share
swCommands.Share_A_File	3516; opens Share file_name_with_extension dialog; Tools > Lifecycle and Collaboration > Share a file
swCommands.Sheet_Tab_Popup_Activate	950; valid for drawings with a selected sheet tab; sheet_tab RMB menu > Activate
swCommands.Sheet_Tab_Popup_Add	948; valid for drawings with a selected sheet tab; sheet_tab RMB menu > Add Sheet
swCommands.Sheet_Tab_Popup_Delete	949; valid for drawings with a selected sheet tab; sheet_tab RMB menu > Delete
swCommands.Sheet_Tab_Popup_Properties	947; valid for drawings with a selected sheet tab; sheet_tab RMB menu > Properties
swCommands.Sheet_Tab_Popup_Rename	2717; valid for drawings with a selected sheet tab; sheet_tab RMB menu > Rename
swCommands.SheetMetal	487; alternative to swCommands_Toolbar_Sht_Mtl; View menu > Toolbars > Sheet Metal
swCommands.SheetmetalCosting	3006; Tools toolbar > Costing
swCommands.Shell	32; valid for parts with a selected sketch; Features toolbar > Shell
swCommands.Show_3d_Sketch_Triad	2440; valid for an open 3D sketch; in the graphics area, RMB menu > Show Sketcher Triad
swCommands.Show_Ann_Based_Swift_Tree	2086; valid for a selected scheme in DimXpertManager; in the DimXpertManager, sel_scheme RMB menu > Tree Display > Show annotation based tree

swCommands.Show_Bom	1240; valid for a drawing view with an Excel-based BOM, <i>excel_based_bom</i> RMB menu > Show
swCommands.Show_CADFamily_Name	3461; 3DEXPERIENCE SOLIDWORKS assemblies only, displays the CAD family in which the part reference belongs in the FeatureManager design tree; FeatureManager design tree > Top Assembly RMB menu > Tree Display > Show CAD Family Name
swCommands.Show_Comp_Des	2490; valid for a selected top-level assembly; in the FeatureManager design tree, <i>top_asm</i> RMB menu > Tree Display > Show Component Descriptions
swCommands.Show_Comp_Filename	2489; valid for a selected top-level assembly; in the FeatureManager design tree, <i>top_asm</i> RMB menu > Tree Display > Show Component Names
swCommands.Show_ComponentInstance_Name	3458; 3DEXPERIENCE SOLIDWORKS assemblies only, displays the full name derived from the component's properties in the FeatureManager design tree; FeatureManager design tree > Top Assembly RMB menu > Tree Display > Show Component Instance Name
swCommands.Show_ComponentReference_Name	3459; 3DEXPERIENCE SOLIDWORKS assemblies only, displays the Family Name (physical product) of the part being referenced in the FeatureManager design tree; FeatureManager design tree > Top Assembly RMB menu > Tree Display > Show Component ReferenceName
swCommands.Show_Components	926; valid for selected components in assemblies; in the FeatureManager design tree, <i>selected_comp</i> RMB context toolbar > Show Components
swCommands.Show_Components_All_Configs	1651; valid for a selected top-level assembly; Edit menu > Show > All Display States
swCommands.Show_Components_Select_Configs	1652; valid for a selected top-level assembly, opens the Apply To Display States dialog; Edit menu > Show > Specified Display States
swCommands.Show_Config_Description	2511; valid for a selected top-level assembly; in the FeatureManager design tree, <i>top_asm</i> RMB menu > Tree Display > Show Component Configuration Descriptions
swCommands.Show_Config_Name	2491; valid for a selected top-level assembly; in the FeatureManager design tree, <i>top_asm</i> RMB menu > Tree Display > Show Component Configuration Names
swCommands.Show_Config_Or_DisplayState_Name	3199; valid for a selected top-level assembly; in the FeatureManager design tree, <i>top_asm</i> RMB menu > Tree Display > Show Configuration/Display State Names if at least one exists
swCommands.Show_Config_Previews	2494; valid for a selected configuration; in the ConfigurationManager, <i>config</i> RMB menu > Show Preview
swCommands.Show_Configs_In_Configtree	2493; valid for assemblies; in ConfigurationManager, <i>top_level_config</i> RMB menu > Tree Display > Show Configuration Descriptions
swCommands.Show_Configname_In_Configtree	2492; valid for assemblies; in ConfigurationManager, <i>top_level_config</i> RMB menu > Tree Display > Show Configuration Names
swCommands.Show_Configuration	1535; valid for a selected inactive configuration, in ConfigurationManager, <i>inactive_config</i> RMB menu > Show Configuration
swCommands.Show_Configuration_Adv	1558; valid for assemblies, opens the Advanced Show/Hide Components dialog
swCommands.Show_Chread	1529; valid for a model with a hidden, selected cosmetic thread; in the FeatureManager design tree, <i>cosmetic_thread</i> RMB context toolbar > Show Cosmetic Thread
swCommands.Show_Dependents	1046; valid for a selected top-level assembly; Edit Menu > Show with Dependents > Current Display State
swCommands.Show_Dependents_All_Configs	1647; valid for a selected top-level assembly; Edit Menu > Show with Dependents > All Display States
swCommands.Show_Dependents_Select_Configs	1648; valid for a selected top-level assembly; Edit Menu > Show with Dependents > Specified Display States
swCommands.Show_Dim	1540; use swCommands.HideShowAnnotations to display hidden annotations
swCommands.Show_Dim_Align	1564; valid for a selected drawing dimension to which Align Collinear/Radial has been applied; in the graphics area, <i>aligned_dim</i> RMB menu > Show Alignment
swCommands.Show_Dim_Leader	2539; valid for a drawing with a selected dimension with a hidden leader line; <i>leader_line</i> RMB menu > Show Dimension Lines
swCommands.Show_Dim_Witness	2527; valid for a drawing with a selected dimension with a hidden witness line; <i>witness_line</i> RMB menu > Show Extension Lines
swCommands.Show_Explode_Steps	1556; valid for a selected component in an assembly with an Exploded View; in the FeatureManager design tree, <i>component</i> RMB menu > Show Explode Steps
swCommands.Show_Feat_Based_Swift_Tree	2085; valid for a selected scheme in DimXpertManager; in the DimXpertManager, <i>sel_scheme</i> RMB menu > Tree Display > Show feat based tree
swCommands.Show_Feature_Des	2488; valid for a selected top-level assembly; in the FeatureManager design tree, <i>top_asm</i> RMB menu > Tree Display > Show Feature Descriptions
swCommands.Show_Feature_Detail	927; valid for a selected top-level assembly showing hierarchy only; in the graphics area, RMB menu > Show Feature Detail
swCommands.Show_Feature_History	2599; valid for a part with a selected solid or surface body folder; <i>sel_folder</i> RMB menu > Show Feature History
swCommands.Show_Feature_Name	2487; valid for a selected top-level assembly; in the FeatureManager design tree, <i>top_asm</i> RMB menu > Tree Display > Show Feature Names
swCommands.Show_Flat_Swift_Tree	2087; valid for a selected scheme in DimXpertManager; in the DimXpertManager, <i>sel_scheme</i> RMB menu > Tree Display > Show flat tree
swCommands.Show_Hidden_comps	2810; valid for assemblies, opens the Show Hidden dialog; Assembly toolbar > Show Hidden Components
swCommands.Show_Hidden_comps_Exit	3022; dialog resource Cancel
swCommands.Show_Hidden_comps_Undo	3021; dialog resource Undo
swCommands.Show_Hide_Fixed_Length_Route_Manipulators	3150; valid for the SOLIDWORKS Routing add-in and an open assembly with a route and selected route segments; Routing Tools toolbar > Show Fixed Length Dimensions
swCommands.Show_Incontext_Feature_Holders	686; valid for a selected top-level assembly with hidden update holders; <i>selected_assembly</i> RMB menu > Show Update Holders
swCommands.Show_LDR_Configuration	3203; valid for assemblies opened in Large Design Review mode for a selected configuration in ConfigurationManager; in the ConfigurationManager, <i>hidden_config</i> RMB menu > Show Configuration
swCommands.Show_Mate_Component_1	2530; valid for assemblies with hidden mate components; in the FeatureManager design tree, <i>first_part_mate_constraint</i> RMB menu > second_part_mate > Show component
swCommands.Show_Mate_Component_2	2535; valid for assemblies with hidden mate components; in the FeatureManager design tree, <i>second_part_mate_constraint</i> RMB menu > first_part_mate > Show component
swCommands.Show_Mesh_Feat	3210; valid for a selected mesh feature that is hidden; RMB menu > Show
swCommands.Show_Representation_Name	3460; 3DEXPERIENCE SOLIDWORKS assemblies only, displays the representation name of the part in the FeatureManager design tree; FeatureManager design tree > Top Assembly RMB menu > Tree Display > Show Component Reference Representation Name
swCommands.Show_Revision_And_Maturity	3462; 3DEXPERIENCE SOLIDWORKS assemblies only, displays a component's revisions and maturity in the FeatureManager design tree; FeatureManager design tree > Top Assembly RMB menu > Tree Display > Show Revision and Maturity
swCommands.Show_Sketch_Dim_In_Drawing	2479; valid for a selected hidden dimension in a drawing sketch; RMB menu > Show Dimensions
swCommands.Show_Table	2622; valid for models with hidden tables; in the FeatureManager design tree, <i>table_name</i> RMB menu > Show Table
swCommands.Show_Triad_Manipulator	769; valid for a selected component in an assembly, displays the triad manipulator
swCommands.Show_View_Palette	2243; valid for drawings; accelerator key P to display view palette
swCommands.Show_Zone	1560; valid for assemblies with envelope components; in the FeatureManager design tree, <i>envelope_feature</i> RMB menu > Envelope > Show/Hide Using Envelope
swCommands.ShowCurvatureCombs	4; valid for a selected spline, opens the Curvature Scale PropertyManager page; Spline Tools toolbar > Show Curvature Combs
swCommands.ShowEdge	352; valid for drawings, opens the Show Edge PropertyManager page
swCommands.ShowGuidelines	2983; valid for the SOLIDWORKS Routing add-in for an open assembly route; Routing Tools toolbar > Show Guidelines
swCommands.ShowInflectionPoints	417; valid for an open sketch of a selected spline, opens the Spline PropertyManager page; Spline Tools toolbar > Show Inflection Points
swCommands.ShowMinimumRadius	418; valid for an open sketch of a selected spline, opens the Spline PropertyManager page; Spline Tools toolbar > Show Minimum Radius
swCommands.ShowSplineHandles	443; valid for an open sketch of a selected spline; Spline Tools toolbar > Show Spline Handles
swCommands.ShutOffSurfaces	452; valid for parts; Mold Tools toolbar > Shut-off Surfaces
swCommands.SimElementOff	2829; valid only in the context of a Motion Study gantt chart for a selected simulation element row; in the gantt chart, <i>rotary_motor_bar</i> RMB menu > Off
swCommands.SimElementOn	2828; valid only in the context of a Motion Study gantt chart for a selected simulation element row; in the gantt chart, <i>rotary_motor_bar</i> RMB menu > On
swCommands.SimElementSuppress	2830; valid only in the context of a Motion Study gantt chart for a selected simulation element row; in the MotionManager design tree, <i>rotary_motor_bar</i> RMB menu > Suppress
swCommands.SimElementUnsuppress	2831; valid only in the context of a Motion Study gantt chart for a selected, suppressed simulation element row; in the MotionManager design tree, <i>rotary_motor_bar</i> RMB menu > Unsuppress
swCommands.SimpleHole	12; valid for sheet metal parts; Sheet Metal toolbar > Simple Hole
swCommands.SimplifySpline	144; valid for a selected spline in an open sketch; Spline Tools toolbar > Simplify Spline
swCommands.SimulationDesigner	3527; SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Simulation Designer
swCommands.SimulationPremium	3435; valid only if entitled; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Simulation Premium
swCommands.SimulationPro	3434; valid only if entitled; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Simulation Professional
swCommands.SimulationStd	3433; valid only if entitled; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Simulation Standard
swCommands.SingleView	549; View toolbar > View Orientation > Single View
swCommands.Sk_Close_Contour	1048; valid for a selected open profile in an open sketch; Tools menu > Sketch Tools > Close Sketch to Model
swCommands.Sk_Endchain	1674; valid during insertion of an arc or line in an open sketch; in the graphics area, <i>sketch_line</i> RMB menu > End chain (double-click)
swCommands.Sk_Endcos	2126; valid for an open sketch during spline on surface creation, stops the drawing of the spline and opens the Spline PropertyManager page
swCommands.Sk_Endspline	1804; valid for an open sketch during spline creation, stops the drawing of the spline and opens the Spline PropertyManager page
swCommands.Sketch	45; valid for a selected plane or sketch; Sketch toolbar > Sketch
swCommands.Sketch_Align_Grid_Origin	2727; valid for an open sketch, opens the Align Grid/Origin PropertyManager page; Tools > Sketch Tools > Align > Align Grid/Origin
swCommands.Sketch_Detach	1547; valid for an open sketch; Sketch toolbar > Detach Segment On Drag
swCommands.Sketch_Jog_Flip	1817; valid for a sketch jog line in an assembly view; RMB menu > Flip Direction
swCommands.Sketch_Suppress_Constraints	1936; valid for a selected sketch relations manipulator; in the graphics area, <i>manip</i> RMB menu > Toggle Suppression
swCommands.SketchChamfer	358; valid for an open sketch, opens the Sketch Chamfer PropertyManager page; Sketch toolbar > Sketch Chamfer
swCommands.SketchCreateChain	617; valid when inserting a Grid System, opens the Path PropertyManager page; in the graphics area, RMB menu > Make Path
swCommands.SketchDrivenPattern	304; valid for parts with a selected sketch; Features toolbar > Sketch Driven Pattern
swCommands.SketchedBend	323; valid for sheet metal parts; Sheet Metal toolbar > Sketched Bend
swCommands.SketchFillet	62; valid for an open sketch, opens the Sketch Fillet PropertyManager page; Sketch toolbar > Sketch Fillet
swCommands.SketchGroupRebuild	555; valid for an open sketch block; Blocks toolbar > Rebuild
swCommands.SketchPicture	368; opens the Open dialog; Sketch toolbar > Sketch Picture
swCommands.Sketchplane.Delete	2681; valid for a selected sketch plane in the 3D sketch environment; RMB menu > Delete
swCommands.Sketchplane.Deleteall	2682; valid for a selected sketch plane in the 3D sketch environment; RMB menu > Delete all
swCommands.Sketchplane.Rename	2683; valid for a selected sketch plane in the 3D sketch environment; RMB menu > Rename
swCommands.SketchSlicing	3399; opens the Slicing PropertyManager; Insert menu > Slicing or Sketch toolbar > Slicing
swCommands.SketchSlot_Arc_Center	2867; valid for a selected plane, planar face, or edge, opens the Slot PropertyManager page; Sketch toolbar > Centerpoint Arc Slot
swCommands.SketchSlot_Arc3P	2866; valid for a selected plane, planar face, or edge, opens the Slot PropertyManager page; Sketch toolbar > 3 Point Arc Slot
swCommands.SketchSlot_Line	2864; valid for a selected plane, planar face, or edge, opens the Slot PropertyManager page; Sketch toolbar > Straight Slot
swCommands.SketchSlot_Line_Center	2865; valid for a selected plane, planar face, or edge, opens the Slot PropertyManager page; Sketch toolbar > Centerpoint Straight Slot
swCommands.SketchToolbar	489; alternative to swCommands.Toolbar_Sketch; View menu > Toolbars > Sketch
swCommands.Skey_SearchBox	3471; Opens a command search box; in the graphics area, click "s" or select Help menu > Search > Commands
swCommands.Skg_Cancel	2027; valid during block creation, cancels
swCommands.Skg_Ok	2026; valid during a block edit; RMB menu > Exit Block Edit
swCommands.Skg_Remove	2023; removes a selected sketch block
swCommands.SkSilhouetteEnts	3414; converts silhouette outlines of bodies and components into sketch segments; Sketch toolbar > Silhouette Entities
swCommands.Sktools_Autoconstr	987; valid for an open, unconstrained sketch; Tools menu > Relations> Constrain All Relations
swCommands.Sm_Clear_Problem_Areas	2945; valid for a sheet metal flat pattern feature with problem areas; in the graphics area, RMB menu > Clear problem areas
swCommands.Sm_Convert_To_Sheetmetal	2245; converts a part to a sheet metal part
swCommands.Sm_Measure_Bend_Deviation	1830; valid for a selected sheet metal bend feature; in the FeatureManager design tree, <i>bend</i> RMB menu > Bend Deviation
swCommands.Sm_Reorder_Bends	1096; valid for a selected sheet metal bend feature; in the FeatureManager design tree, <i>bend</i> RMB menu > Reorder Bends
swCommands.Sm_Show_Problem_Areas	2944; valid for a selected sheet metal flat pattern feature with cleared problem areas; in the graphics area, RMB menu > Show problem areas
swCommands.Sm_Toggle_Flat_Display	2924; valid for a selected flat pattern feature of a sheet metal part; in the graphics area, RMB menu > Toggle flat display
swCommands.Small_Icon	1621; valid in the Appearances, Scenes, and Decals task pane palette; <i>palette</i> RMB menu > Small Icons

swCommands_Small_List_Icon	2064; valid in content list popups; RMB menu > List, Small Icons
swCommands_Smart_Feature_Preview	2218; valid for assemblies with a selected smart feature component; in the FeatureManager design tree, History folder > smart_component > Smart Feature folder > Components > comp RMB menu > Preview
swCommands_Smart_Mate	1343; valid for assemblies, opens the SmartMates PropertyManager page; Assembly toolbar > SmartMates
swCommands_SmartDimension	38; opens the Dimension PropertyManager page; Layout Tools or Dimensions/Relations toolbar > Smart Dimension
swCommands_SmartFasteners	7; valid for assemblies, opens the Smart Fasteners PropertyManager page; Assembly toolbar > Smart Fasteners
swCommands_Smc_Help	2219; valid for a Smart Component as it is being edited in its defining assembly, opens the Editing Definition of a Smart Component topic in the SOLIDWORKS help; SMC popup toolbar > Help
swCommands_SMGusset	3111; valid for sheet metal parts, opens the Sheet Metal Gusset PropertyManager page; Sheet Metal toolbar > Sheet Metal Gusset
swCommands_SMNormalCut	3196; opens the Normal Cut PropertyManager page; Sheet Metal toolbar > Normal Cut
swCommands_SmoothMesh	3469; Opens the Smooth Graphics Mesh PropertyManager for a selected graphics body or facet group; Insert menu > Mesh > Mesh Smoothing
swCommands_SMStamp	3518; Inserts a sheet metal stamp; Insert menu > Sheet Metal > Stamp
swCommands_Snap_To_Selection	2275; valid after component RMB menu > Move with Triad command in assembly; in the graphics area, triad_center_ball RMB menu > Move to selection
swCommands_Snap_While_Dragging	2276; valid for a selected Move with Triad ring in an assembly; triad_ring RMB menu > Snap while dragging
swCommands_Solid_Data_Manager	1393; valid if SOLIDWORKS Explorer is installed; Tools menu > SOLIDWORKS Applications > SOLIDWORKS Explorer
swCommands_SolidToSheetMetal	2882; valid for sheet metal parts; Sheet Metal toolbar > Convert to Sheet Metal
swCommands_SolidWorks_backoffice	3356; Tools menu > SOLIDWORKS Applications > SOLIDWORKS Task Scheduler...
swCommands_SolidworksAnimator	433; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Animator
swCommands_SolidworksOffice	491; alternative to swCommands_Toolbar_Office; View menu > Toolbars > SOLIDWORKS Add-ins
swCommands_SolidworksRouting	566; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Routing
swCommands_SolidworksToolbox	437; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Toolbox
swCommands_SolidworksUtilities	436; SOLIDWORKS Add-ins toolbar > SOLIDWORKS Utilities
swCommands_SolveAsFlexibleOrRigid	3095; valid for a selected subassembly; Assembly toolbar > Make Subassembly Flexible
swCommands_Sort_Stacked_Balloons	3161; valid for a selected annotation with stacked balloons; in the graphics area, stacked_balloon_anno RMB menu > Sort Stacked Balloons
swCommands_SpaceEvenlyAcross	312; valid for multi-selected annotations or dimensions; Align toolbar > Space Evenly Across
swCommands_SpaceEvenlyDown	313; valid for multi-selected annotations or dimensions; Align toolbar > Space Evenly Down
swCommands_SpaceTightlyAcross	316; valid for multi-selected annotations or dimensions; Align toolbar > Space Tightly Across
swCommands_SpaceTightlyDown	317; valid for multi-selected annotations or dimensions; Align toolbar > Space Tightly Down
swCommands_SpellChecker	535; opens the Spelling Check PropertyManager page; Tools toolbar > Spell Checker
swCommands_Spline	47; valid for a selected plane or planar face; Sketch toolbar > Spline
swCommands_SplineOnSurface	542; valid for a selected face or surface; Sketch toolbar > Spline on Surface
swCommands_Splines	492; alternative to swCommands_Toolbar_Spline_Tools; View menu > Toolbars > Spline Tools
swCommands_Split_Open_Route	2342; valid for the SOLIDWORKS Routing add-in; splits an open route for selected splittable segments
swCommands_Split_Open_Segm_Ar	1858; valid for the SOLIDWORKS Routing Add-in and when the Auto Route PropertyManager page is open; in the graphics area, RMB menu > Split Entry
swCommands_Split_Route	2269; valid for the SOLIDWORKS Routing add-in and an open routing assembly; Routing Tools toolbar > Split Route
swCommands_SplitEntities	293; valid for an open sketch and a selected sketch entity; Sketch toolbar > Split Entities
swCommands_Spool_Command	3013; valid for the SOLIDWORKS Routing add-in and an open piping route, opens the Spools PropertyManager page; Piping toolbar > Define Spools
swCommands_Spool_Tube_Command	3044; valid for SOLIDWORKS Routing add-in and an open flexible tube assembly; in the graphics area, sel_route_or_tube_comp RMB menu > Define Spools
swCommands_Stack	534; valid for selected text; Formatting toolbar > Stack
swCommands_Stack_Dir_Down	678; valid for a selected stacked balloon stacked left, right, or up; in the graphics area, stacked_balloon RMB menu > Down
swCommands_Stack_Dir_Left	680; valid for a selected stacked balloon stacked down, right, or up; in the graphics area, stacked_balloon RMB menu > Left
swCommands_Stack_Dir_Right	681; valid for a selected stacked balloon stacked left, down, or up; in the graphics area, stacked_balloon RMB menu > Right
swCommands_Stack_Dir_Up	677; valid for a selected stacked balloon stacked left, right, or down; in the graphics area, stacked_balloon RMB menu > Up
swCommands_StackedBalloons	319; opens the Stacked Balloon PropertyManager page; Annotation toolbar > Stacked Balloons
swCommands_StackFasteners	3410; valid for assemblies, adds a fastener stack to the assembly using the SOLIDWORKS Toolbox library of standard hardware; Assembly toolbar > Fastener Stack
swCommands_Standard	493; alternative to swCommands_Toolbar_Standard; View menu > Toolbars > Standard
swCommands_Standard3View	42; Drawing toolbar > Standard 3 View
swCommands_StandardViews	494; alternative to swCommands_Toolbar_Stdview; View menu > Toolbars > Standard Views
swCommands_Start_Contour_Single_Select	660; valid for parts or assemblies, starts contour single select mode
swCommands_Start_Screen	3229; opens the Welcome dialog; CTRL-F2; Standard toolbar > Welcome to SOLIDWORKS
swCommands_Start_Select_Contour	2495; valid for a selected sketch contour; sketch_contour RMB menu > Contour Select Tool
swCommands_Start_Select_Contour_2	2514; valid when the Planar Surface PropertyManager page is open, and the planar surface sketch is selected; in the graphics area, planar_surface_sketch RMB menu > Start Contour Selection
swCommands_Start_Smart_Selection	2628; valid when a PropertyManager page supporting multi-edge selection is open; in the graphics area, sel_edge RMB menu > Start/Edit Smart Selection
swCommands_Statistics	427; valid for parts and drawings; Tools toolbar > Performance Evaluation
swCommands_StopCurrentJump	129; Web toolbar > Stop Current Jump
swCommands_StopMacro	31; valid for a running macro, opens the Save As dialog; Macro toolbar > Stop Macro
swCommands_StretchEntities	2851; valid for an open sketch, opens the Stretch PropertyManager page; Sketch toolbar > Stretch Entities
swCommands_Strikeout	532; valid for selected text; Formatting toolbar > StrikeOut
swCommands_StructuralMember	465; valid for weldments, opens the Structural Member PropertyManager page; Weldments toolbar > Structural Member
swCommands_Submit	794; dialog resource Submit
swCommands_Suppress	14; valid for one or more selected features; Edit menu > Suppress > This Configuration
swCommands_Suppress_Mate_Component_1	2531; valid for assemblies with visible, resolved mate components; in the FeatureManager design tree, first_part_mate_constraint RMB menu > second_part_mate > Suppress component
swCommands_Suppress_Mate_Component_2	2536; valid for assemblies with visible, resolved mate components; in the FeatureManager design tree, second_part_mate_constraint RMB menu > first_part_mate > Suppress Component
swCommands_Surface_Flatten	3139; opens the Flatten PropertyManager page; Surfaces toolbar > Surface Flatten
swCommands_SurfaceFinish	112; opens the Surface Finish PropertyManager page; Annotation toolbar > Surface Finish
swCommands_Surfaces	495; alternative to swCommands_Toolbar_Surface; View menu > Toolbars > Surfaces
swCommands_SurfFromMesh	3218; creates surfaces from mesh; Mold or Surface toolbar > Surface From Mesh
swCommands_Sw_Animatorpane	2811; valid for assemblies; View menu > Toolbars > MotionManager
swCommands_Sw_Beta_Report	1412; opens the SOLIDWORKS Beta problem report from www.solidworks.com , if available
swCommands_Sw_Educator_Resources	3465; Opens www.solidworks.com/eduwhatsnew
swCommands_Sw_Release_Notes	1411; opens the Administration Guides from www.solidworks.com ; Help menu > Release Notes
swCommands_Sw_Taskpane	2127; View menu > User Interface > Task Pane
swCommands_SwConnected_Release_Notes	3500; displays the release notes for the installed version of SOLIDWORKS Design connected to the 3DEXPERIENCE platform; SOLIDWORKS menu > Help > Release Notes > SOLIDWORKS Design connected to the 3DEXPERIENCE platform yyyyx
swCommands_SweptBossBase	64; valid for parts with a selected sketch; Features toolbar > Swept Boss/Base
swCommands_SweptCut	65; valid for parts with a selected sketch; Features toolbar > Swept Cut
swCommands_SweptFlange	3041; valid for sheet metal parts, opens the Swept Flange PropertyManager page; Sheet Metal toolbar > Swept Flange
swCommands_SweptSurface	103; opens the Surface-Sweep PropertyManager page; Surfaces toolbar > Swept Surface
swCommands_Swift_Create_Basic_Dim	2780; valid for DimXpertManager and a selected Position tolerance; in the DimXpertManager, position_tol RMB menu > Recreate basic dim
swCommands_Swift_Fpo_Boss	2755; DimXpert feature selector > Boss
swCommands_Swift_Fpo_Chamfer	2754; DimXpert feature selector > Chamfer
swCommands_Swift_Fpo_Compound	2665; DimXpert feature selector > Compound Hole
swCommands_Swift_Fpo_Cone	2669; DimXpert feature selector > Cone
swCommands_Swift_Fpo_Constr_Circle	2283; DimXpert feature selector > Intersect Circle
swCommands_Swift_Fpo_Constr_Line	2282; DimXpert feature selector > Intersect Line
swCommands_Swift_Fpo_Constr_Plane	2284; DimXpert feature selector > Intersect Plane
swCommands_Swift_Fpo_Constr_Point	2281; DimXpert feature selector > Intersect Point
swCommands_Swift_Fpo_Cotersink	2667; DimXpert feature selector > Countersink
swCommands_Swift_Fpo_Counterbore	2666; DimXpert feature selector > Counterbore
swCommands_Swift_Fpo_Cylinder	2670; DimXpert feature selector > Cylinder
swCommands_Swift_Fpo_DimType_Angular	2940; DimXpert feature selector > Angular Dimension
swCommands_Swift_Fpo_DimType_Linear	2939; DimXpert feature selector > Linear Dimension
swCommands_Swift_Fpo_Fillet	2753; DimXpert feature selector > Fillet
swCommands_Swift_Fpo_Hole	2664; DimXpert feature selector > Hole
swCommands_Swift_Fpo_Notch	2752; DimXpert feature selector > Notch
swCommands_Swift_Fpo_Ok	2676; DimXpert feature selector > OK
swCommands_Swift_Fpo_Pattern	2675; DimXpert feature selector > Pattern
swCommands_Swift_Fpo_Plane	2663; DimXpert feature selector > Plane
swCommands_Swift_Fpo_Pocket	2674; DimXpert feature selector > Pocket
swCommands_Swift_Fpo_Slot	2672; DimXpert feature selector > Slot
swCommands_Swift_Fpo_Sphere	2671; DimXpert feature selector > Sphere
swCommands_Swift_Fpo_Surf	2662; DimXpert feature selector > Surface
swCommands_Swift_Fpo_Width	2673; DimXpert feature selector > Width
swCommands_SwiftAddTaStudy	2801; valid for SOLIDWORKS Premium assemblies whose parts have been assigned dimensions and tolerances; DimXpert toolbar > TolAnalystStudy
swCommands_SwiftDeleteAll	596; valid for parts with assigned tolerances; DimXpert toolbar > Delete All Tolerances
swCommands_SwiftInserAngleDimension	3467; Adds a DimXpert angle dimension from the DimXpertManager tab; Tools menu > MBD Dimension > Angle Dimension...
swCommands_SwiftInserBasicDimension	3182; valid for parts; DimXpert toolbar > Basic Dimension
swCommands_SwiftInserBasicSizeDimension	3197; valid for parts; DimXpert toolbar > Basic Size Dimension
swCommands_SwiftInserDatum	593; valid for parts; DimXpert toolbar > Datum
swCommands_SwiftInserDatumTarget	3450; Inserts a DimXpert datum target; Tools menu > MBD Dimension > Datum Target

swCommands_SwiftInsertDimension	592; valid for parts; DimXpert toolbar > Location Dimension
swCommands_SwiftInsertGeneralProfileTolerance	3325; adds a Profile of Surface geometric tolerance to an open part; DimXpert toolbar > General Profile Tolerance
swCommands_SwiftInsertGtol	594; valid for parts, opens the GeometricTolerance Properties dialog; DimXpert toolbar > Geometric Tolerance
swCommands_SwiftInsertOrdinateDimension	3549; adds ordinate dimensions to DimXpert features; DimXpert toolbar > Ordinate Dimension
swCommands_SwiftInsertPatternFeature	627; valid for parts, opens the DimXpert Pattern/Collection.PropertyManager page; DimXpert toolbar > Pattern Feature
swCommands_SwiftInsertSizeDimension	625; valid for parts; DimXpert toolbar > Size Dimension
swCommands_SwiftRecognizeFeatures	591; valid for parts; DimXpert toolbar > Auto Dimension Scheme
swCommands_SwiftShowConstraintStatus	595; valid for parts; DimXpert toolbar > Show Tolerance Status
swCommands_SWPremium	3432; SOLIDWORKS Premium
swCommands_SWUltimate	3532; SOLIDWORKS Ultimate
swCommands_SWVisualize	3542; Loads or Unloads the SOLIDWORKS Visualize add-in
swCommands_SWVisualize_GroupByAppearance	3545; Group by appearance; SOLIDWORKS Visualize add-in
swCommands_SWVisualize_GroupByPart	3546; Group by part; SOLIDWORKS Visualize add-in
swCommands_SWVisualize_ImportWithOptions	3547; Import with options; SOLIDWORKS Visualize add-in
swCommands_TabAndSlot	3234; adds a tab and slot feature; Sheet Metal toolbar > Tab and Slot
swCommands_Table_Cell_Sub_Total	1975; inserts "Sub-total" into a selected table cell
swCommands_Table_Cell_Total	1976; inserts "Total" into a selected table cell
swCommands_TableDrivenPattern	300; valid for parts with a selected sketch; Features toolbar > Table Driven Pattern
swCommands_TangentArc	69; Layout Tools or Sketch toolbar > Tangent Arc
swCommands_TangentSnap	528; valid during sketch creation only with parts that contain curves such as circles, arcs, fillets, parabolas, ellipses, partial ellipses, or splines; Quick Snaps toolbar > Tangent Snap
swCommands_Text	109; Sketch toolbar > Text
swCommands_Thicken	97; valid for a part with two or more knit surfaces, opens the Thicken PropertyManager page; Features toolbar > Thicken
swCommands_ThickenedCut	98; valid for a part with two or more knit surfaces, opens the Cut-Thicken PropertyManager page; Features toolbar > Thickened Cut
swCommands_TileHorizontally	581; Standard toolbar > Tile Horizontally
swCommands_TileVertically	582; Standard toolbar > Tile Vertically
swCommands_TitleBlockDefine	2852; valid for a drawing with its sheet format open, opens the Title Block Table PropertyManager page; Sheet Format toolbar > Title Block Fields
swCommands_TitleBlockEdit	2853; valid for a drawing sheet format with a title block defined, opens the Title Block Table; in the FeatureManager design tree, <i>sheet_folder > sheet_format_folder > title_block_table</i> RMB menu > Title Block Fields
swCommands_TitleBlockEnterData	2854; valid for a drawing sheet format with a title block defined, opens the Title Block Data PropertyManager page; in the FeatureManager design tree, <i>sheet_folder > sheet_format_folder > title_block_table</i> RMB menu > Enter Title Block Data
swCommands_TitleBlockTable	2949; valid for parts and assemblies, opens the Title Block Table PropertyManager page; Table toolbar > Title Block Table
swCommands_Toggle_Context_Switch	1990; CommandManager RMB menu > Use Large Buttons With Text
swCommands_Toggle_Grid	1509; valid when inserting a Grid System; in the graphics area, RMB menu > Display Grid
swCommands_Toggle_MagMate	3216; valid for assemblies only, toggles magnetic mates; alt-M or Tools menu or toolbar > Magnetic Mate ON/OFF
swCommands_Toggle_Magnified_Selection	3135; Standard toolbar > Magnified Selection
swCommands_Toggle_Notes_UpperCase	3105; toggles Note case to upper case; press F3
swCommands_Toggle_Ole_Owner	1555; valid for a drawing with a selected object; in the graphics area, <i>ole_object</i> RMB menu > Show on this sheet only
swCommands_Toggle_Pic_Texture	1900; valid for a selected picture with a texture; in the graphics area, <i>pic_with_texture</i> RMB menu > Hide/Show Texture
swCommands_Toggle_Power_Dim_Mode	2445; valid when Power Assist PropertyManager page is open; in the graphics area, RMB menu > DimXpert dimension toggle
swCommands_Toggle_Smart_Dim_Mode	2444; valid when Power Assist PropertyManager page is open; in the graphics area, RMB menu > Smart dimension toggle
swCommands_Toggle_Viewing_Dir	1593; valid for a selected drawing view arrow; in the graphics area, <i>sel_view_arrow</i> RMB menu > Toggle View Direction
swCommands_ToggleGraphicsDisplay	3246; Tools toolbar > Display Graphics Components
swCommands_ToggleInstant2D	3188; Sketch toolbar > Instant2D
swCommands_ToggleSelectionFilters	273; Selection Filters toolbar > Toggle Selection Filters
swCommands_ToggleSelectionFilterToolbar	356; Standard toolbar > Toggle Selection Filter Toolbar
swCommands_TolXpert	612; alternative to swCommands_Toolbar_DimXpert; View menu > Toolbars > DimXpert
swCommands_Toggle_Bwrtree	2446; valid in Full Screen mode; Full Screen toolbar > Hide/Show FeatureManager
swCommands_Toolbar_2dto3d	1182; alternative to swCommands_2dto3d_Toolbar; View menu > Toolbars > 2D to 3D
swCommands_Toolbar_Adv_Struct_System	3334; View menu > Toolbars > Structure System
swCommands_Toolbar_Align	1180; alternative to swCommands_Align; View menu > Toolbars > Align
swCommands_Toolbar_Annotation	1167; alternative to swCommands_Annotations; View menu > Toolbars > Annotation
swCommands_Toolbar_Assembly	1155; alternative to swCommands_Assemblies; View menu > Toolbars > Assembly
swCommands_Toolbar_Context	1205; View menu > Toolbars > CommandManager
swCommands_Toolbar_Curve	1175; alternative to swCommands_Curves; View menu > Toolbars > Curves
swCommands_Toolbar_DimXpert	1192; alternative to swCommands_TolXpert; View menu > Toolbars > DimXpert
swCommands_Toolbar_Display_States	2809; View menu > Toolbars > Display States
swCommands_Toolbar_Drawing	1156; alternative to swCommands_Drawings; View menu > Toolbars > Drawing
swCommands_Toolbar_Exploderoute	1183; alternative to swCommands_ExplodeSketch; View menu > Toolbars > Explode Sketch
swCommands_Toolbar_Features	1157; alternative to swCommands_Features; View menu > Toolbars > Features
swCommands_Toolbar_Font	1166; alternative to swCommands_Fonts; View menu > Toolbars > Formatting
swCommands_Toolbar_Handsketch	3242; valid only for a sketch opened in SOLIDWORKS running on supporting pen/stylus hardware; alternative to swCommands_Handsketch_Toolbar
swCommands_Toolbar_Inference	1190; alternative to swCommands_ClickHereToSeeThePreview; View menu > Toolbars > Quick Snaps
swCommands_Toolbar_Inkmarkup	3437; View menu > Toolbars > Markup
swCommands_Toolbar_Layer	1180; alternative to swCommands_Layer_Toolbar; View menu > Toolbars > Layer
swCommands_Toolbar_Layout_Tools	2816; alternative to swCommands_Layout; View menu > Toolbars > Layout Tools
swCommands_Toolbar_Lifecycle_And_Collaboration	3484; For SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; Activates the Lifecycle and Collaboration toolbar; View menu > Toolbars > Lifecycle and Collaboration
swCommands_Toolbar_Lineformat	1165; alternative to swCommands_LineFormats; View menu > Toolbars > Line Format
swCommands_Toolbar_Macro	1159; alternative to swCommands_Macros; View menu > Toolbars > Macro
swCommands_Toolbar_Mold	1172; alternative to swCommands_Molds; View menu > Toolbars > Mold Tools
swCommands_Toolbar_Office	1187; alternative to swCommands_SolidworksOffice; View menu > Toolbars > SOLIDWORKS Add-Ins
swCommands_Toolbar_OneClick	3289; Tools menu > 3DEXPERIENCE Simulation Connector
swCommands_Toolbar_Refgeom	1178; alternative to swCommands_ReferenceGeometry; View menu > Toolbars > Reference Geometry
swCommands_Toolbar_Render	2963; alternative to swCommands_RenderToolbar; View menu > Toolbars > Render Tools
swCommands_Toolbar_ScreenCapture	2812; alternative to swCommands_ScreenCaptureToolbar; View menu > Toolbars > Screen Capture
swCommands_Toolbar_Sel_Filter	1160; alternative to swCommands_Filter_Toolbar; View menu > Toolbars > Selection Filter
swCommands_Toolbar_Sht_Mtl	1173; alternative to swCommands_SheetMetal; View menu > Toolbars > Sheet Metal
swCommands_Toolbar_Sketch	1161; alternative to swCommands_SketchToolbar; View menu > Toolbars > Sketch
swCommands_Toolbar_Sketch_Group	2028; alternative to swCommands_Blocks; View menu > Toolbars > Blocks
swCommands_Toolbar_Sketch_Rels	1162; alternative to swCommands_DimensionRelations; View menu > Toolbars > Dimensions/Relations
swCommands_Toolbar_Spline_Tools	1185; alternative to swCommands_Splines; View menu > Toolbars > Spline Tools
swCommands_Toolbar_Standard	1153; alternative to swCommands_Standard; View menu > Toolbars > Standard
swCommands_Toolbar_Stdview	1169; alternative to swCommands_StandardViews; View menu > Toolbars > Standard Views
swCommands_Toolbar_Surface	1174; alternative to swCommands_Surfaces; View menu > Toolbars > Surfaces
swCommands_Toolbar_Table	1191; alternative to swCommands_EnterTheOffsetOfTheSupportArea; View menu > Toolbars > Table
swCommands_Toolbar_Tools	1179; alternative to swCommands_Tools; View menu > Toolbars > Tools
swCommands_Toolbar_View	1154; alternative to swCommands_View; View menu > Toolbars > View
swCommands_Toolbar_Web	1164; alternative to swCommands_Web; View menu > Toolbars > Web
swCommands_Toolbar_Weldment	1189; alternative to swCommands_Weldments; View menu > Toolbars > Weldments
swCommands_ToolingSplit	464; valid for parts containing 3 surface bodies (core, cavity, and parting) and a selected face or plane perpendicular to the direction of pull; Mold Tools toolbar > Tooling Split
swCommands_Tools	496 alternative to swCommands_Toolbar_Tools; View menu > Toolbars > Tools
swCommands_Tools_Addins	1073; opens the Add-Ins dialog; Tools menu > Add-Ins
swCommands_Tools_Addview_Ff	1245; valid for drawings with the Relative View PropertyManager page open, opens the Open dialog; in the graphics area, RMB menu > Insert From File
swCommands_Tools_Align_Horz	889; valid for a selected drawing view; Tools > Align Drawing View > Horizontal Edge
swCommands_Tools_Align_Vert	890; valid for a selected drawing view; Tools > Align Drawing View > Vertical Edge
swCommands_Tools_Arrange_Components	1254; valid for assemblies, opens the Assembly Structure Editing dialog; Tools menu > Reorganize Components
swCommands_Tools_Configuration	973; valid for parts and assemblies, opens the SOLIDWORKS ConfigurationManager dialog
swCommands_Tools_Crop_Delete	1389; valid for a selected Crop View in a drawing; <i>crop_view</i> RMB menu > Crop View > Remove Crop
swCommands_Tools_Crop_Edit	1388; valid for a selected Crop View in a drawing; <i>crop_view</i> RMB menu > Crop View > Edit Crop
swCommands_Tools_Customize	1137; opens the Customize dialog; Tools menu > Customize
swCommands_Tools_Dim_Pref	945; valid for an open model, opens the Document Properties dialog; in the FeatureManager design tree, <i>top_level_document</i> RMB menu > Document Properties
swCommands_Tools_Drv_Autoregen	1573; valid for a selected drawing; in the FeatureManager design tree, <i>drawing</i> RMB menu > Automatic view update
swCommands_Tools_Drv_Dimtext_Link	636; valid for a selected drawing; in the FeatureManager design tree, <i>drawing</i> RMB menu > Link external dim text
swCommands_Tools_Font_Tan	1078; valid for parts; View menu > Display > Tangent Edges as Phantom
swCommands_Tools_Font_Tangent_Edges	1546; valid for drawings for a selected view; View menu > Display > Tangent Edges With Font
swCommands_Tools_Hide_Dv	979; valid for drawings; View menu > Hide / Show > Hidden Views
swCommands_Tools_Macro_Mru_1	2376; opens the first macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > first_macro
swCommands_Tools_Macro_Mru_2	2377; opens the second macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > second_macro
swCommands_Tools_Macro_Mru_3	2378; opens the third macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > third_macro
swCommands_Tools_Macro_Mru_4	2379; opens the fourth macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > fourth_macro

swCommands_Tools_Macro_Mru_5	2380; opens the fifth macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > fifth_macro
swCommands_Tools_Macro_Mru_6	2381; opens the sixth macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > sixth_macro
swCommands_Tools_Macro_Mru_7	2382; opens the seventh macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > seventh_macro
swCommands_Tools_Macro_Mru_8	2383; opens the eighth macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > eighth_macro
swCommands_Tools_Macro_Mru_9	2384; opens the ninth macro in the recent macros list in Microsoft Visual Basic for Applications; Tools menu > Macro > ninth_macro
swCommands_Tools_Remove_Tan	1079; valid for parts; View menu > Display > Tangent Edges Removed
swCommands_Tools_Remove_Tangent_Edges	1515; valid for drawings for a selected view; View menu > Display > Tangent Edges Removed
swCommands_Tools_Show_Tan	1077; valid for parts; View menu > Display > Tangent Edges Visible
swCommands_Tools_Show_Tangent_Edges	1545; valid for drawings for a selected view; View menu > Display > Tangent Edges Visible
swCommands_ToolsGrid	2791; opens the Document Properties - Grid/Snap dialog; Sketch toolbar > Grid/Snap
swCommands_ToolsSensor	2892; opens the Sensor PropertyManager page; Tools toolbar > Sensor
swCommands_Top	163; View toolbar > View Orientation > Top
swCommands_Top_Left	923; valid for a selected Excel-based BOM in a drawing view; Excel_BOM RMB menu > Anchor > Top Left
swCommands_Top_Right	920; valid for a selected Excel-based BOM in a drawing view; Excel_BOM RMB menu > Anchor > Top Right
swCommands_Translate_Drawing	638; valid for a drawing, opens the Move Drawing dialog; in the FeatureManager design tree, drawing RMB menu > Move
swCommands_Triad_Blob_Align_To	2449; valid after component RMB menu > Move with Triad command in assembly; in the graphics area, triad_center_ball RMB menu > Align to
swCommands_TrimAsGroupWithPreAdvStructMember	3362; trims with previous advanced structure member
swCommands_TrimAsIndAdvStructMember	3363; trims as an individual advanced structure member
swCommands_TrimCornerCorner	2792; valid for a flattened sheet metal part with a selected corner, opens the Corner-Trim PropertyManager page; Sheet Metal toolbar > Corner-Trim
swCommands_TrimEntities	59; valid for an open sketch, opens the Trim PropertyManager page; Sketch or Layout Tools toolbar > Trim Entities
swCommands_Trimetric	467; Standard Views toolbar > Trimetric
swCommands_TrimExtend	466; valid for weldments, opens the Trim/Extend PropertyManager page; Weldment toolbar > Trim/Extend
swCommands_TrimSurface	302; valid for a part with one or more selected surfaces, opens the Trim Surface PropertyManager page; Surfaces toolbar > Trim Surface
swCommands_Tube_Properties	3012; valid for the SOLIDWORKS Routing add-in and a selected tube in an open flexible tube route; flex_tube RMB menu > Tube Properties
swCommands_Turn	606; valid for a model with a camera; View menu > Modify > Turn Camera
swCommands_TwoViewHorizontal	550; View toolbar > View Orientation > Two View - Horizontal
swCommands_TwoViewVertical	551; View toolbar > View Orientation > Two View - Vertical
swCommands_Unblank_Atom_Body	1028; in the FeatureManager design tree, click body_folder RMB context toolbar > Show
swCommands_Unblank_Atom_Body2	2731; valid for a part with a solid or surface body; in the FeatureManager design tree, body_folder > body RMB context toolbar > Show
swCommands_Unblank_Grid_Comp	3001; valid for a part or assembly with the GridSystem PropertyManager page open and the grid feature component hidden; in the graphics area, RMB menu > Show
swCommands_Unblank_Origin_Sketch	2469; valid for a hidden profile sketch; in the graphics area, prof_sketch RMB menu > Show
swCommands_Unblank_Part_Body	1413; valid for a selected face of an atom feature in an assembly; in the graphics area, sel_face RMB menu > Show Solid Body
swCommands_Unblank_Pic_Feat	2486; valid for a selected hidden picture feature object; in the graphics area, pic_feat RMB menu > Show
swCommands_Unblank_Refgeom	896; valid for a selected reference geometry; in the FeatureManager design tree, ref_geom RMB menu > Show
swCommands_Unblank_Sketch	955; valid for a selected drawing sketch; in the graphics area, sketch RMB menu > Show
swCommands_Unbreak_View	1520; valid for a drawing break view; in the FeatureManager design tree, break_view RMB menu > Un-Break View
swCommands_Underive_Sketch	1010; valid for a selected derived sketch; in the FeatureManager design tree, sketch_derived RMB menu > Underive
swCommands_Underline	149; valid for selected text; Formatting toolbar > Underline
swCommands_Undo	586; Standard toolbar > Undo
swCommands_Undo_Eq	633; dialog resource Undo
swCommands_Unfix_Component	959; valid for a selected fixed assembly component; in the FeatureManager design tree, comp RMB menu > Float
swCommands_Unfold	326; valid for sheet metal parts; Sheet Metal toolbar > Unfold
swCommands_Unfreeze_All	3014; valid for models where feature freeze is enabled, and the selected feature is frozen; in the FeatureManager design tree, feature RMB menu > Unfreeze All Features
swCommands_Ungroup	327; valid for multi-selected annotations or dimensions; Align toolbar > Ungroup
swCommands_Unlink_Dim	1544; valid for sketches with dimensions with shared parameters, opens the Shared Values dialog; in the graphics area, shared_dimension RMB menu > Unlink Value
swCommands_Unload_Hidden_Comps	2868; valid for a selected assembly; in the FeatureManager design tree, top_level_assy RMB menu > Unload Hidden Components
swCommands_Unlock_Bom	914; valid for a drawing view with an Excel-based Bill of Materials; in the graphics area, BOM_table RMB menu > Anchor > Unlock from Anchor
swCommands_Unlock_Configuration	1846; valid in a PDM-enabled environment with a locked configuration; in ConfigurationManager, locked_config RMB menu > Unlock Configuration
swCommands_Unslant_Dim	1533; valid for a selected dimension with a witness line that is slanted; in the graphics area, dim_with_slanted_witness RMB menu > Display Options > Remove Slant
swCommands_Unsuppress	15; valid for one or more selected suppressed features; Edit menu > Unsuppress > This Configuration
swCommands_UnsuppressWithDependents	50; valid for one or more selected suppressed features; Edit menu > Unsuppress with Dependents > This Configuration
swCommands_UntrimSurface	400; valid for a part with a selected face or edge to patch, opens the Untrim Surface PropertyManager page; Surfaces toolbar > Untrim Surface
swCommands_Update_Cutlist	2602; valid for a part with a selected Cut list folder; in the FeatureManager design tree, cut_list_folder RMB menu > Update
swCommands_Update_Msg	2786; dialog resource Update
swCommands_Update_Std_View	885; View toolbar > View Orientation > More options > Orientation dialog > Update Standard Views
swCommands_UpdateAllSpeedpakConfig	3070; valid for assemblies; Assembly toolbar > Update Speedpak
swCommands_UpdateImportedModel	3343; updates an imported model
swCommands_UpdateView	385; valid for drawings with a selected view; Drawing toolbar > Update View
swCommands_User_Communities	3463; Help menu > User Communities
swCommands_User_Defined_Route	3189; valid for the SOLIDWORKS Routing or the SOLIDWORKS Electrical add-in, opens the Projects Manager dialog; Routing or SOLIDWORKS Electrical: Application toolbar > User Defined Route
swCommands_User_Job_Cancel	699; dialog resource Cancel
swCommands_User_Toolbar_Max	1628; maximum allowed number of toolbar commands
swCommands_User_Toolbar_Min	1627; minimum allowed number of toolbar commands
swCommands_Userdefined_Add_Fitting	3165; valid for SOLIDWORKS Routing add-in with an open route; User Defined toolbar > Add Fitting
swCommands_Userdefined_Rt_On_Fly	3166; valid for SOLIDWORKS Routing add-in with an open route; User Defined toolbar > Start at Point
swCommands_Userdefined_Rt_Properties	3168; valid for SOLIDWORKS Routing add-in with an open route; User Defined toolbar > Route Properties
swCommands_UserMacro01	174; runs the first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro02	175; runs the second macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro03	176; runs the third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro04	177; runs the fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro05	178; runs the fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro06	179; runs the sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro07	180; runs the seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro08	181; runs the eighth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro09	182; runs the ninth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro10	183; runs the tenth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro11	184; runs the eleventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro12	185; runs the twelfth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro13	186; runs the thirteenth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro14	187; runs the fourteenth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro15	188; runs the fifteenth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro16	189; runs the sixteenth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro17	190; runs the seventeenth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro18	191; runs the eighteenth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro19	192; runs the nineteenth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro20	193; runs the twentieth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro21	194; runs the twenty-first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro22	195; runs the twenty-second macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro23	196; runs the twenty-third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro24	197; runs the twenty-fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro25	198; runs the twenty-fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro26	199; runs the twenty-sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro27	200; runs the twenty-seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro28	201; runs the twenty-eighth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro29	202; runs the twenty-ninth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro30	203; runs the thirtieth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro31	204; runs the thirty-first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro32	205; runs the thirty-second macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro33	206; runs the thirty-third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro34	207; runs the thirty-fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro35	208; runs the thirty-fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro36	209; runs the thirty-sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro37	210; runs the thirty-seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro38	211; runs the thirty-eighth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro39	212; runs the thirty-ninth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro40	213; runs the fortieth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro41	214; runs the forty-first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro42	215; runs the forty-second macro defined by Macro toolbar > New Macro Button

swCommands_UserMacro43	216; runs the forty-third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro44	217; runs the forty-fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro45	218; runs the forty-fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro46	219; runs the forty-sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro47	220; runs the forty-seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro48	221; runs the forty-eighth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro49	222; runs the forty-ninth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro50	223; runs the fiftieth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro51	224; runs the fifty-first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro52	225; runs the fifty-second macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro53	226; runs the fifty-third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro54	227; runs the fifty-fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro55	228; runs the fifty-fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro56	229; runs the fifty-sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro57	230; runs the fifty-seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro58	231; runs the fifty-eighth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro59	232; runs the fifty-ninth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro60	233; runs the sixtieth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro61	234; runs the sixty-first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro62	235; runs the sixty-second macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro63	236; runs the sixty-third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro64	237; runs the sixty-fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro65	238; runs the sixty-fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro66	239; runs the sixty-sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro67	240; runs the sixty-seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro68	241; runs the sixty-eighth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro69	242; runs the sixty-ninth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro70	243; runs the seventieth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro71	244; runs the seventy-first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro72	245; runs the seventy-second macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro73	246; runs the seventy-third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro74	247; runs the seventy-fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro75	248; runs the seventy-fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro76	249; runs the seventy-sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro77	250; runs the seventy-seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro78	251; runs the seventy-eighth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro79	252; runs the seventy-ninth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro80	253; runs the eightieth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro81	254; runs the eighty-first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro82	255; runs the eighty-second macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro83	256; runs the eighty-third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro84	257; runs the eighty-fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro85	258; runs the eighty-fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro86	259; runs the eighty-sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro87	260; runs the eighty-seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro88	261; runs the eighty-eighth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro89	262; runs the eighty-ninth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro90	263; runs the ninetieth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro91	264; runs the ninety-first macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro92	265; runs the ninety-second macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro93	266; runs the ninety-third macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro94	267; runs the ninety-fourth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro95	268; runs the ninety-fifth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro96	269; runs the ninety-sixth macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro97	270; runs the ninety-seventh macro defined by Macro toolbar > New Macro Button
swCommands_UserMacro98	271; runs the ninety-eighth macro defined by Macro toolbar > New Macro Button
swCommands_VerticalBreak	110; valid for a drawing and a selected view; Drawing toolbar > Break
swCommands_VerticalDimension	68; Dimensions/Relations toolbar > Vertical Dimension
swCommands_VerticalOrdinateDimension	348; Dimensions/Relations toolbar > Vertical Ordinate Dimension
swCommands_View	498; alternative to swCommands_Toolbar_View; View menu > Toolbars > View
swCommands_View_Animate_Collapse_Assembly	1983; valid for an assembly with a selected exploded view, opens the Animation Controller dialog; in the ConfigurationManager, ExpView RMB menu > Animate collapse
swCommands_View_Animate_Explode_Assembly	1982; valid for an assembly with a selected exploded view that was collapsed, opens the Animation Controller dialog; in the ConfigurationManager, ExpView RMB menu > Animate explode
swCommands_View_Assy_Full	748; valid for an assembly with a component being edited in context; in the graphics area, RMB menu > Assembly Transparency > Force Transparency
swCommands_View_Assy_Maintain	749; valid for an assembly with a component being edited in context; in the graphics area, RMB menu > Assembly Transparency > Maintain Transparency
swCommands_View_Assy_Opaque	747; valid for an assembly with a component being edited in context; in the graphics area, RMB menu > Assembly Transparency > Opaque
swCommands_View_Clear_Select	1541; valid in many contexts; pop-up menu item "Clear Selections"
swCommands_View_Collapse_Assembly	995; valid for an assembly with a selected explode view; in the ConfigurationManager, exploded_view RMB menu > Collapse
swCommands_View_Displ_Hideall	1810; View menu > Hide / Show > Hide All Types
swCommands_View_Edit_Perspective	1043; valid for a perspective view, opens the Perspective View PropertyManager page; View menu > Modify > Perspective
swCommands_View_Explode_Assembly	993; valid for an assembly with a selected explode view that is collapsed; in the ConfigurationManager, exploded_view RMB menu > Explode
swCommands_View_Fm_By_Dep	1031; View menu > User Interface > FeatureManager Tree > By Dependencies
swCommands_View_Fm_By_Feat	1030; View menu > User Interface > FeatureManager Tree > By Features
swCommands_View_Hide_Behind_Plane	875; valid for a drawing document, opens the Hide Behind Plane dialog; in the FeatureManager design tree, ref_plane RMB menu > Hide Behind Plane
swCommands_View_Hideshow	1390; valid for part or assembly with bodies, opens the Hide / Show Bodies PropertyManager page; View menu > Hide / Show > Bodies
swCommands_View_Lock_Camera	1061; valid for a model with a selected camera in DisplayManager; in DisplayManager, Camera > Camera1 > RMB menu > Lock Camera
swCommands_View_Move_Manipulator	1993; valid for assemblies; in the graphics area, comp RMB menu > Move with Triad
swCommands_View_Normal_To	1640; valid for annotation, BOM, and title block tables; in the graphics area, table RMB menu > Normal To
swCommands_View_Orientation_Rmb	916; valid in many contexts; in the graphics area, RMB menu > View Orientation
swCommands_View_Orientation_ViewBox	3081; View toolbar > View Orientation > View Selector
swCommands_View_Query_Select	891; valid in many contexts; in the graphics area, RMB menu > Select Other
swCommands_View_Rotate_About_Vertical	3071; View menu > Modify > Rotate About Scene Floor
swCommands_View_Rotateminusx	1472; Press DOWN ARROW
swCommands_View_Rotateminusy	1469; Press LEFT ARROW
swCommands_View_Rotateminusz	1471; Press Alt-LEFT ARROW
swCommands_View_Rotateplusx	1473; Press UP ARROW
swCommands_View_Rotateplusy	1468; Press RIGHT ARROW
swCommands_View_Rotateplusz	1470; Press Alt-RIGHT ARROW
swCommands_View_Rotx_Minusninety	1474; Press Shift-DOWN ARROW
swCommands_View_Rotx_Plusninety	1475; Press Shift-UP ARROW
swCommands_View_Roty_Minusninety	1476; Press Shift-LEFT ARROW
swCommands_View_Roty_Plusninety	1477; Press Shift-RIGHT ARROW
swCommands_View_Ruler	1303; valid for drawings; View menu > User Interface > Rulers
swCommands_View_Sheet_Next	898; valid for drawings; View menu > Next Sheet
swCommands_View_Sheet_Previous	897; valid for drawings; View menu > Previous Sheet
swCommands_View_ShowAnnotationTextExpression	3538; View menu > Hide / Show > Annotation Text Expression
swCommands_View_Showantrn_Linkerrors	1895; View menu > Hide / Show > Annotation Link Errors
swCommands_View_Showantrn_Linkvar	2145; View menu > Hide / Show > Annotation Link Variables
swCommands_View_Showwide_Tb	2756; View menu > User Interface > Toolbars
swCommands_View_This_Camera	1060; valid for a selected camera; in the DisplayManager, camera RMB menu > Camera View
swCommands_View_Transminusx	1479; Press Ctrl-LEFT ARROW
swCommands_View_Transminusy	1481; Press Ctrl-UP ARROW
swCommands_View_Transplusx	1478; Press Ctrl-RIGHT ARROW
swCommands_View_Transplusy	1480; Press Ctrl-DOWN ARROW
swCommands_View_Undo_Last	1584; valid for parts; View menu > Modify > Previous View
swCommands_View_Zoom_About_Center	1803; View menu > Modify > Zoom About Screen Center
swCommands_View_Zoomin	1482; Press Shift-Z
swCommands_View_Zoomout	1483; Press Z
swCommands_View3DSketchDimensions	562; View toolbar > View Sketch Dimensions

swCommands_View3DSketchPlane	561; View toolbar > View 3D Sketch Plane
swCommands_ViewAllAnnotations	404; View toolbar > View All Annotations
swCommands_ViewAssemAnnotations	3120; View toolbar > View Top Level Annotations
swCommands_ViewAssemEnvelopes	3423; View toolbar > View Top Level Envelopes
swCommands_ViewAxes	339; View toolbar > View Axes
swCommands_ViewBendLines	3468; Controls the visibility of bend lines; View menu > Hide / Show > Bend Lines or View toolbar > View Bend Lines
swCommands_ViewCameras	608; View toolbar > View Cameras
swCommands_ViewCompAnnotations	3119; View toolbar > View Component Annotations
swCommands_ViewCompEnvelopes	3422; View toolbar > View Component Envelopes
swCommands_ViewCoordinateSystems	153; View toolbar > View Coordinate Systems
swCommands_ViewCosmeticWeldSymbol	3004; View toolbar > View Weld Beads
swCommands_ViewCurves	402; View toolbar > View Curves
swCommands_ViewDatumReferenceFrame	3184; View toolbar > View Datum Reference Frame
swCommands_ViewDecals	2925; View toolbar > View Decals
swCommands_ViewDimNames	2954; View toolbar > View Dimension Names
swCommands_ViewGlobalBBox	3323; controls the visibility of the bounding box; View menu > View Bounding Box
swCommands_ViewLights	607; View toolbar > View Lights
swCommands_ViewLiveSections	2875; View toolbar > View Live Section Planes
swCommands_ViewOrientation	341; Press SPACEBAR
swCommands_ViewOrigins	126; View toolbar > View Origins
swCommands_ViewPartingLines	547; View toolbar > View Parting Lines
swCommands_ViewPlanes	338; View toolbar > View Planes
swCommands_ViewPoints	511; View toolbar > View Points
swCommands_Viewport_Unsplit_Camera	2185; valid when the Camera1 PropertyManager page is open; in the Camera1 PropertyManager page, click X.
swCommands_ViewRoutingPoints	510; View toolbar > View Routing Points
swCommands_ViewSimResults	3201; opens the View Simulation Results PropertyManager page; valid only if the SOLIDWORKS Simulation add-in is loaded, and Simulation study results are available for the current model; View toolbar > View Simulation Results
swCommands_ViewSimulationSymbol	2992; View toolbar > View Simulation Symbols
swCommands_ViewSketches	403; View toolbar > View Sketches
swCommands_ViewSketchRelations	440; View toolbar > View Sketch Relations
swCommands_ViewTemporaryAxes	99; View toolbar > View Temporary Axes
swCommands_Visual_State_Clear_Override	785; valid for assemblies with display settings; in the Display Pane, RMB menu > Clear Override
swCommands_Visual_State_Clear_Override_All	786; valid for assemblies with display settings; in the Display Pane, RMB menu > Clear All Top Level Overrides
swCommands_VisualizationTool	2883; valid for assemblies; Assembly toolbar > Assembly Visualization
swCommands_Watch_Exit	715; dialog resource Exit
swCommands_Watch_Start	713; dialog resource Start
swCommands_Watch_Stop	714; dialog resource Stop
swCommands_Web	497; alternative to swCommands_Toolbar_Web; View menu > Toolbars > Web
swCommands_WebToolbar	136; Standard toolbar > Web Toolbar
swCommands_Weld_Gap	2981; valid for SOLIDWORKS Routing add-in with an open piping route; Piping toolbar > Weld Gap
swCommands_WeldBead	2796; valid for sheet metal parts; Sheet Metal toolbar > Corners > Welded Corner
swCommands_Weldment	450; valid for parts; Weldments toolbar > Weldment
swCommands_WeldmentCutList	463; Table toolbar > Weldment Cut List
swCommands_Weldments	508; alternative to swCommands_Toolbar_Weldment; View menu > Toolbars > Weldments
swCommands_WeldSymbol	131; opens the Weld Symbol PropertyManager page and the ISO Weld Symbol Properties dialog; Annotation toolbar > Weld Symbol
swCommands_WeldTable	3002; Table toolbar > Weld Table
swCommands_Whats_New_HTML	2951; opens the What's New in SOLIDWORKS year HTML page; Help menu > What's New > HTML
swCommands_Whats_New_Interactive	1987; Help menu > What's New > Interactive
swCommands_Whats_New_Pdf	2950; Help menu > What's New > PDF
swCommands_Whats_Wrong	809; valid in many contexts; RMB menu > What's Wrong?
swCommands_Window_Closeall	1033; Window menu > Close All
swCommands_Window_Redraw	1494; View menu > Redraw
swCommands_Wireframe	334; View toolbar > Wireframe
swCommands_Work_Offline	3508; Standard toolbar > Work Offline ; Work for a limited time while disconnected from the 3DEXPERIENCE platform
swCommands_XRayToggleAssem	3317; toggles transparency of the top-level assembly; Assembly toolbar > Top Level Transparency
swCommands_XRayTogglePart	3318; toggles transparency of the part; Assembly toolbar > Top Level Transparency
swCommands_YUpViewOrientation	3448
swCommands_Zebra_Properties	1805; valid for assemblies with Zebra Stripes, opens the Zebra Stripes PropertyManager page; View menu > Modify > Zebra Stripe Properties
swCommands_Zebra_Stripe_Preview	2356; valid in several contexts, including when the Surface-Sweep PropertyManager page is open; in the graphics area, <i>sweep_sketch</i> RMB menu > Zebra Stripes Preview
swCommands_ZebraStripes	365; valid for assemblies with Zebra Stripes; View menu > Display > Zebra Stripes
swCommands_Zone_Editor	3144; valid for drawings open in a SOLIDWORKS debug build, and the ENABLE_ZONE_TAG_EDITOR debug variable is set, opens the Zone Tag Editor PropertyManager page; in the FeatureManager design tree, <i>sheet > Sheet Format1</i> RMB menu > Zone Tag Editor
swCommands_ZoomInOut	331; View toolbar > Zoom In/Out
swCommands_ZoomToArea	333; View toolbar > Zoom to Area
swCommands_ZoomToFit	332; View toolbar > Zoom to Fit
swCommands_ZoomToFitKey	601; Press F
swCommands_ZoomToSelection	354; View toolbar > Zoom to Selection
swCommands_ZoomtoSheet	3121; valid for drawings; View toolbar > Zoom to Sheet
swCommands_ZUpViewOrientation	3449

 **See Also**

[SolidWorks.Interop.swcommands Namespace](#)

swMouse_e (Type)

SOLIDWORKS API Commands Enumeration

[Send comments on this topic.](#)

swMouse_e Enumeration

[See Also](#)



[SolidWorks.Interop.swcommands Namespace](#) : swMouse_e Enumeration

Mouse commands.

Syntax

Visual Basic (Declaration)

```
Public Enum swMouse_e
    Inherits System.Enum
```

C#

```
public enum swMouse_e : System.Enum
```

C++/CLI

```
public enum class swMouse_e : public System.Enum
```

Members

Member	Description
swMouse_Absolute	256 or 0x100
swMouse_Click	512 or 0x200
swMouse_DoubleClick	1024 or 0x400
swMouse_LeftDown	2 or 0x2
swMouse_LeftUp	4 or 0x4
swMouse_MiddleDoubleClick	8192 or 0x2000; Zoom to fit
swMouse_MiddleDown	32 or 0x20
swMouse_MiddleUp	64 or 0x40
swMouse_MouseMove	1 or 0x1
swMouse_RightClick	2048 or 0x800
swMouse_RightDoubleClick	4096 or 0x1000
swMouse_RightDown	8 or 0x8
swMouse_RightUp	16 or 0x10
swMouse_SelectANNOTATIONTABLES	0x620000; filters mouse selections to annotation tables
swMouse_SelectANNOTATIONVIEW	0x8b0000; filters mouse selections to annotation views
swMouse_SelectARROWS	0x310000; filters mouse selections to arrows
swMouse_SelectATTRIBUTES	0x80000; filters mouse selections to attributes
swMouse_SelectBLOCKDEF	0x630000; filters mouse selections to block definitions
swMouse_SelectBLOCKINST	0x5d0000; filters mouse selections to block instances
swMouse_SelectBODYFEATURES	0x160000; filters mouse selections to body features
swMouse_SelectBODYFOLDER	0x760000; filters mouse selections to body folders
swMouse_SelectBOMFEATURES	0x610000; filters mouse selections to BOM features
swMouse_SelectBOMS	0x360000; filters mouse selections to BOMs
swMouse_SelectBOMTEMPS	0x400000; filters mouse selections to BOM templates
swMouse_SelectBorder	0xfe0000; filters mouse selections to borders
swMouse_SelectBREAKLINES	0x1f0000; filters mouse selections to breaklines
swMouse_SelectBROWSERITEM	0x450000; filters mouse selections to browser items
swMouse_SelectCAMERAS	0x880000; filters mouse selections to cameras
swMouse_SelectCENTERLINES	0x670000; filters mouse selections to centerlines
swMouse_SelectCENTERMARKS	0x1c0000; filters mouse selections to centermarks
swMouse_SelectCENTERMARKSYMS	0x640000; filters mouse selections to centermark symbols only
swMouse_SelectCOMMENT	0x7f0000; filters mouse selections to comments
swMouse_SelectCOMMENTSFOLDER	0x7e0000; filters mouse selections to comment folders
swMouse_SelectCOMPONENTS	0x140000; filters mouse selections to components
swMouse_SelectCOMPPATTERN	0x250000; filters mouse selections to component patterns
swMouse_SelectCOMPSDONTOVERRIDE	0x480000; filters mouse selections to specified selection types (e.g., edges, vertices, or faces) over the competing component selection type in an assembly
swMouse_SelectCONFIGURATIONS	0x2f0000; filters mouse selections to configurations
swMouse_SelectCONNECTIONPOINTS	0x420000; filters mouse selections to connection points
swMouse_SelectCOORDSYS	0x3d0000; filters mouse selections to coordinate systems
swMouse_SelectCOSMETICWELDS	0xdc0000; filters mouse selections to cosmetic welds
swMouse_SelectCTHREADS	0x270000; filters mouse selections to cosmetic threads
swMouse_SelectCUSTOMSYMBOLS	0x3c0000; filters mouse selections to custom symbols
swMouse_SelectDATUMAXES	0x50000; filters mouse selections to datum axes
swMouse_SelectDATUMLINES	0x3e0000; filters mouse selections to datum lines
swMouse_SelectDATUMPLANES	0x40000; filters mouse selections to datum planes
swMouse_SelectDATUMPOINTS	0x60000; filters mouse selections to datum points
swMouse_SelectDATUMTAGS	0x240000; filters mouse selections to datum tags
swMouse_SelectDCABINETS	0x2a0000; filters mouse selections to D cabinets
swMouse_SelectDETAILCIRCLES	0x110000; filters mouse selections to detail circles
swMouse_SelectDIMENSIONS	0xe0000; filters mouse selections to dimensions
swMouse_SelectDISPLAYSTATE	0x940000; filters mouse selections to display states
swMouse_SelectDOCFSOLDER	0x7d0000; filters mouse selections to document folders
swMouse_SelectDOWELSYMS	0x560000; filters mouse selections to dowel symbols
swMouse.SelectDRAWINGVIEWS	0xc0000; filters mouse selections to drawing views
swMouse.SelectDTMTARGS	0x280000; filters mouse selections to datum targets
swMouse.SelectEDGES	65536 or 0x10000; filters mouse selections to edges
swMouse.SelectEMBEDLINKDOC	0x7b0000; filters mouse selections to embedded document links
swMouse.SelectEMPTYSPACE	0x480000; filters mouse selections to empty spaces
swMouse.SelectEQNFOLDER	0x370000; filters mouse selections to equations folders
swMouse.SelectEXCLUDEMANIPULATORS	0x6f0000; filters mouse selections to exclude manipulators
swMouse.SelectEXPLLINES	0x2d0000; filters mouse selections to explode lines
swMouse.SelectEXPLSTEPS	0x2c0000; filters mouse selections to explode steps
swMouse.SelectEXPLVIEWS	0x2b0000; filters mouse selections to explode views
swMouse.SelectEXTSKETCHPOINTS	0x190000; filters mouse selections to sketch points
swMouse.SelectEXTSKETCHSEGS	0x180000; filters mouse selections to sketch segments
swMouse.SelectEXTSKETCHTEXT	0x580000; filters mouse selections to sketch text
swMouse.SelectFABRICATEDROUTE	0x460000; filters mouse selections to a fabricated routes
swMouse.SelectFACES	131072 or 0x20000; filters mouse selections to faces
swMouse.SelectFRAMEPOINT	0x4d0000; filters mouse selections to frame points

swMouse_SelectIFTRFOLDER	0x5e0000; filters mouse selections to feature folders
swMouse_SelectIGENERALTABLEFEAT	0x8e0000; filters mouse selections to general table features
swMouse_SelectIGTOLS	0xd0000; filters mouse selections to Gtols
swMouse_SelectIHELIX	0x1a0000; filters mouse selections to helices
swMouse_SelectIHOLESERIES	0x530000; filters mouse selections to hole series
swMouse_SelectIHOLETABLEAXES	0x690000; filters mouse selections to hole table axes
swMouse_SelectIHOLETABLEFEATS	0x680000; filters mouse selections to hole table features
swMouse_SelectIIMPORTFOLDER	0x390000; filters mouse selections to import folders
swMouse_SelectINCONTEXTFEAT	0x1d0000; filters mouse selections to in-context features
swMouse_SelectINCONTEXTFEATS	0x200000; filters mouse selections to in-context features
swMouse_SelectIJOURNAL	0x7c0000; filters mouse selections to journals
swMouse_SelectILEADERS	0x540000; filters mouse selections to leaders
swMouse_SelectILIGHTS	0x490000; filters mouse selections to lights
swMouse_SelectIMAGNETICLINES	0xe10000; filters mouse selections to magnetic lines
swMouse_SelectIMANIPULATORS	0x4f0000; filters mouse selections to manipulators
swMouse_SelectIMATEGROUP	0x1e0000; filters mouse selections to mate groups
swMouse_SelectIMATEGROUPS	0x210000; filters mouse selections to multiple mate groups
swMouse_SelectIMATES	0x150000; filters mouse selections to mates
swMouse_SelectIMATESUPPLEMENT	0x8a0000; filters mouse selections to mate supplemental faces
swMouse_SelectIMIDPOINTS	0x3b0000; filters mouse selections to midpoints
swMouse_SelectINOTES	0xd0000; filters mouse selections to notes
swMouse_SelectIOBJGROUP	0xc10000; filters mouse selections to object groups
swMouse_SelectIOBJHANDLES	0x300000; filters mouse selections to object handles
swMouse_SelectIOLEITEMS	0x70000; filters mouse selections to OLE items
swMouse_SelectIPICTUREBODIES	0x500000; filters mouse selections to picture bodies
swMouse_SelectIPLANESECTIONS	0xdb0000; filters mouse selections to plane sections
swMouse_SelectIPOINTREFS	0x290000; filters mouse selections to point references
swMouse_SelectIPOSGROUP	0x440000; filters mouse selections to mate reference folders
swMouse_SelectIPUNCHTABLEFEATS	0xea0000; filters mouse selections to punch table features
swMouse_SelectIREFCURVES	0x170000; filters mouse selections to reference curves
swMouse_SelectIREFEDGES	0x330000; filters mouse selections to reference edges
swMouse_SelectIREFERENCESCURVES	0x1a0000; filters mouse selections to reference curves
swMouse_SelectIREFFACES	0x340000; filters mouse selections to reference faces
swMouse_SelectREFSILHOUETTE	0x350000; filters mouse selections to reference silhouettes
swMouse_SelectREFSURFACES	0x1b0000; filters mouse selections to reference surfaces
swMouse_SelectREVISIONCLOUDS	0xf00000; filters mouse selections to revision clouds
swMouse_SelectREVISIONTABLE	0x710000; filters mouse selections to revision tables
swMouse_SelectREVISIONTABLEFEAT	0x770000; filters mouse selections to revision table features
swMouse_SelectROUTECURVES	0x3f0000; filters mouse selections to route curves
swMouse_SelectROUTEPOINTS	0x410000; filters mouse selections to route points
swMouse_SelectROUTESWEEPS	0x430000; filters mouse selections to route sweeps
swMouse_SelectSECTIONLINES	0x100000; filters mouse selections to section lines
swMouse_SelectSECTIONTEXT	0x120000; filters mouse selections to section text
swMouse_SelectSELECTIONSETFOLDER	0x1020000; filters mouse selections to selection set folders
swMouse_SelectSELECTIONSETNODE	0x1030000; filters mouse selections to selection set nodes
swMouse_SelectSFSYMBOLS	0x230000; filters mouse selections to SF symbols
swMouse_SelectSHEETS	0x130000; filters mouse selections to sheets
swMouse_SelectSILHOUETTES	0x2e0000; filters mouse selections to silhouettes
swMouse_SelectSIMELEMENT	0x660000; filters mouse selections to simulation elements
swMouse_SelectSIMULATION	0x650000; filters mouse selections to simulation studies
swMouse_SelectSKETCHBITMAP	0x550000; filters mouse selections to sketch bitmaps
swMouse_SelectSKETCHCONTOUR	0x600000; filters mouse selections to sketch contours
swMouse_SelectSKETCHES	0x90000; filters mouse selections to sketches
swMouse_SelectSKETCHHATCH	0x380000; filters mouse selections to sketch hatches
swMouse_SelectSKETCHPOINTFEAT	0x470000; filters mouse selections to sketch point features
swMouse_SelectSKETCHPOINTS	0xb0000; filters mouse selections to sketch points
swMouse_SelectSKETCHREGION	0x5f0000; filters mouse selections to sketch regions
swMouse_SelectSKETCHSEGMENTS	0xa0000; filters mouse selections to sketch segments
swMouse_SelectSKETCHTEXT	0x220000; filters mouse selections to sketch text
swMouse_SelectSOLIDBODIES	0x4c0000; filters mouse selections to solid bodies
swMouse_SelectSOLIDBODIESFIRST	0x510000; filters mouse selections to solid bodies over competing selection types (e.g., face, component)
swMouse_SelectSUBATOMFOLDER	0x790000; filters mouse selections to body folders
swMouse_SelectSUBSKETCHDEF	0x9a0000; filters mouse selections to sketch block definitions
swMouse_SelectSUBSKETCHINST	0x720000; filters mouse selections to sketch block instances
swMouse_SelectSUBWELDFOLDER	0x6b0000; filters mouse selections to sub-weldment folders
swMouse_SelectSURFACEBODIES	0x4b0000; filters mouse selections to surface bodies
swMouse_SelectSURFBODIESFIRST	0x4e0000; filters mouse selections to surface bodies over competing selection types (e.g., face, component)
swMouse_SelectSWIFTANNOTATIONS	0x820000; filters mouse selections to Swift annotations
swMouse_SelectSWIFTFEATURES	0x840000; filters mouse selections to Swift features
swMouse_SelectSWIFTSHEMA	0x9f0000; filters mouse selections to Swift schemas
swMouse_SelectTITLEBLOCK	0xc00000; filters mouse selections to title blocks
swMouse_SelectTITLEBLOCKTABLEFEAT	0xc00000; filters mouse selections to title block table features
swMouse_SelectVERTICES	196608 or 0x30000; filters mouse selections to vertices
swMouse_SelectVIEWERHYPERLINK	0x3a0000; filters mouse selections to viewer hyperlinks
swMouse_SelectWELDBEADS	0x7a0000; filters mouse selections to weld beads
swMouse_SelectWELDMENT	0x6a0000; filters mouse selections to weldments
swMouse_SelectWELDMENTTABLEFEATS	0x740000; filters mouse selections to weldment table features
swMouse_SelectWELDS	0x260000; filters mouse selections to welds
swMouse_SelectWIREBODIES	0x4a0000; filters mouse selections to wire bodies
swMouse_SelectZONES	0x320000; filters mouse selections to zones
swMouse_Wheel	128 or 0x80

 See Also

[SolidWorks.Interop.swcommands Namespace](#)