

SOLIDWORKS Enumerations (swconst) — Reference (1/17): namespace hierarchy- swApplicationType_e

SOLIDWORKS API Documentation (converted from CHM)

_namespace_hierarchy (Type)

SOLIDWORKS API Enumerations

[Send comments on this topic.](#)

SolidWorks.Interop.swconst Namespace Inheritance Hierarchy

[See Also](#)



Inheritance Hierarchy

System.Object



See Also

[SolidWorks.Interop.swconst Assembly.](#)

SolidWorks.Interop.swconst (Namespace Overview)

SOLIDWORKS API Enumerations

SolidWorks.Interop.swconst Namespace

See Also [Inheritance Hierarchy](#)

[Send comments on this topic.](#)



SOLIDWORKS API enumerations

Enumerations

Enumeration	Description
sw3DExperienceCtnType_e	Types of configurations viewed in SOLIDWORKS Design connected to the 3DEXPERIENCE platform.
sw3DExperienceModelType_e	Types of 3DEXPERIENCE component icons.
sw3DExperienceState_e	SOLIDWORKS Design connected to the 3DEXPERIENCE platform states. Bitmask .
sw3DInterconnectImportErrors_e	3D Interconnect import errors.
sw3DPDFAccuracy_e	Levels of SOLIDWORKS MBD 3D PDF accuracies
sw3DPMISaveOptions_e	3D PMI (Product and Manufacturing Information) save options when comparing two different versions of the same model. Bitmask .
swAcisOutputGeometryPreference_e	ACIS output geometry types.
swAcisOutputVersion_e	ACIS output versions.
swActivateDocError_e	Document activation errors. Bitmask .
swAddComponentConfigOptions_e	Options for adding components to an assembly.
swAddControlOptions_e	Options for PropertyManager page, group box, and tab controls. Bitmask .
swAddGroupBoxOptions_e	PropertyManager page group box and tab controls. Bitmask .
swAddInBrokerBBoxOption_e	Bounding box options. Bitmask .
swAdditionalSymbol_e	Additional symbols in Gtol frame boxes.
swAddMateError_e	Status after adding or editing a mate.
swAddOrdinateDims_e	Types of ordinate dimensions.
swAddSpecificDimension_e	Status after adding a specific dimension.
swAddToRecentDocumentList_e	Recent Documents list actions for a document opened using ISkdWorks.OpenDoc7 and IDocumentSpecification.AddToRecentDocumentList .
swAdvancedHoleResults_e	Result codes for Advanced Hole.
swAdvSelectType_e	Conditions of criteria for advanced component selection list. Bitmask .
swAdvWzdGeneralHoleTypes_e	Advanced Hole element types.
swAlignDimensionType_e	Align dimension types.
swAlignDrawingViewTypes_e	Types of auxiliary drawing view alignment.
swAlignViewTypes_e	View alignments.
swAngleUnit_e	Angle unit types.
swAngularEquationUnits_e	Angular units used in equations.
swAnimationOutputType_e	Animation output type.
swAnimationPlayMode_e	Modes to play animations.
swAnimationPlaySpeed_e	Speeds to play animations.
swAnimatorAxisOfRotation_e	Animation axis of rotation.
swAnimatorDirectionOfRotation_e	Animation direction of rotation
swAnnotationOwner_e	Types of owners of annotations.
swAnnotationType_e	Annotation types.
swAnnotationVisibilityState_e	Annotation visibility states.
swApiHoleWizardItemExportStatus_e	Return codes for Advanced Hole Wizard item export.
swApiHoleWizardItemImportStatus_e	Return codes for Advanced Hole Wizard item import.
swApiToolboxItemExportStatus_e	Return codes for toolbox item export.
swApiToolboxItemImportStatus_e	Return codes for toolbox item import.
swAppCallBackCmd_e	Types of application callback functions.
swAppearanceSurfaceFinishShaderTypes_e	Types of surface finish shaders.
swAppearanceTargetType_e	Types of targets to which to apply a copied appearance.
swApplicationType_e	Types of SOLIDWORKS application.
swAppNotify_e	Application notifications.
swArcEndCondition_e	Arc endpoint conditions for linear dimensions.
swArcLengthLeaderType_e	Arc length dimension leader styles.
swAreaHatchFillStyle_e	Area hatch fill styles.
swAreaHatchingScope_e	Areas for hatching.
swArrowDirection_e	DXF/DWG output arrow directions.
swArrowPlacement_e	Smart arrow placement.
swArrowPosition_e	Arrow positions for bubble ToolTips.
swArrowStyle_e	Arrow styles.
swASMSLDPRTCompPref_e	Options for a specified component when saving an assembly as a part.
swAssemblyDeleteOptions_e	Assembly delete options.
swAssemblyExplodeStepType_e	Assembly explode step types.
swAssemblyLevelToUpdate_e	Levels of assemblies to update options.
swAssemblyLoadComponents_e	Tools > System Options > Performance > Assembly loading.
swAssemblyMode_e	Assembly states.
swAssemblyNotify_e	Assembly notifications.
swAssemblyUpdateToolboxComponentStatus_e	Status of updating SOLIDWORKS Toolbox components in assemblies using the current information in Toolbox Settings.
swAssociatedEntityStates_e	Associated entity states for attributes.
swAttachAnnotationOption_e	Annotation attachment options.
swAutodimEntities_e	Entities to dimension ISketch.AutoDimension2 and IDrawingDoc.AutoDimension .
swAutodimHorizontalPlacement_e	Placements for the horizontal dimensions created by ISketch.AutoDimension2 and IDrawingDoc.AutoDimension .
swAutodimMark_e	Selection mark values. Bitmask .
swAutodimScheme_e	Dimensioning schemes for ISketch.AutoDimension2 and IDrawingDoc.AutoDimension .
swAutodimStatus_e	Statuses returned by ISketch.AutoDimension2 and IDrawingDoc.AutoDimension .
swAutodimVerticalPlacement_e	Placements of the vertical dimensions created by ISketch.AutoDimension2 and IDrawingDoc.AutoDimension .
swAutoHideShowResponse_e	Visibility of FeatureManager design tree folders and tools.
swAutoInsertCenterMarkTypes_e	Types for which to insert center marks. Bitmask .
swAutoMateRepairErrors_e	Automatic mate repair errors.
swAutoSaveIntervalMode_e	Modes for autosaving documents.
swBackgroundProcessOption_e	Background processing options.
swBalloonFit_e	Types of balloon and label location fits.
swBalloonItemNumbersOrder_e	Balloon item ordering options. Bitmask .
swBalloonLayoutType_e	Arrangements for automatic BOM balloons in relation to the drawing views with which they are associated.
swBalloonQuantityPlacement_e	Balloon quantity placement options.
swBalloonStyle_e	Balloon styles.
swBalloonTextContent_e	Style of the text contents of balloon notes.
swBasicDimType_e	Basic dimension types for DimXpert geometric tolerances.
swBBoxDescriptionApplyMethod_e	Weldment bounding box apply to options.
swBendAllowanceTypes_e	Bend allowance types.
swBendDirection_e	Bend directions.
swBendLineControlOption_e	Bend line options.
swBendLineDirection_e	Bend line directions.
swBendNoteAttribute_e	Bend note attributes.
swBendNoteStyle_e	Bend note styles.
swBendTableTagStyle_e	Bend table tag styles.
swBendType_e	Bend types.
swBitmapControlStandardTypes_e	Bitmap control standard types.
swBitMaps_e	Types of bitmaps for error and trouble-shooting tips bubbles.

swBlockDefinitionExtFileStatus_e	Block definition external file status.
swBlockingStates_e	Blocking states.
swBlockInstanceTextDisplay_e	Block instance text display.
swBodyFolderFeatureType_e	Body folder feature types.
swBodyInfo_e	Type of body.
swBodyMaterialApplicationError_e	Body material application errors.
swBodyOperationError_e	Body operation errors.
swBodyOperationType_e	Body operation types.
swBodyType_e	Valid body types.
swBOMConfigurationAnchorType_e	BOM table configuration anchor types.
swBOMConfigurationCreationErrors_e	BOM table configuration creation errors.
swBOMConfigurationWhatToShow_e	What to show in BOM tables.
swBOMControlMissingRowDisplay_e	How to handle empty rows in BOM tables.
swBOMControlSplitDirection_e	Direction where to split new sections in BOM tables.
swBOMPartNumberSource_e	Sources from numbers in BOM tables. Bitmask .
swBOMTableObjectType_e	Types of BOM table items to expand and collapse.
swBomTableSortItemGroup_e	Categories for sorting bill of material table rows.
swBomTableSortMethod_e	Bill of Materials table sorting methods.
swBomType_e	Types of BOM tables.
swBoundaryBossAlignment_e	Boundary feature alignments.
swBoundaryBossCurveInfluenceType_e	Boundary feature curve influence types. Bitmask .
swBoundaryBossDirection_e	Boundary feature directions.
swBoundaryBossTangencyType_e	Tangency types for curves in boundary features.
swBoundingBoxOptions_e	Bounding box options. Bitmask .
swBoundType_e	Boundary behaviors at the start and end of UV parameter ranges.
swBreakCornerTypes_e	Types of break corners.
swBreakLineOrientation_e	Break lines orientation.
swBreakLineStyle_e	Break line styles.
swButtonSize_e	Toolbar button sizes.
swCADFamilyCfgOptions_e	SOLIDWORKS Design connected to the 3DEXPERIENCE platform family configuration options. Bitmask .
swCalloutTargetStyle_e	Callout target styles.
swCalloutVariable_e	Types of specific hole callout variables.
swCalloutVariableType_e	Types of general hole callout variables.
swCameraPositionType_e	Camera position styles.
swCameraType_e	Camera types.
swCamMateEntityType_e	Cam-follower mate entity types.
swCavityScaleType_e	Cavity scale types.
swCellEquationStatus_e	Cell equation error codes.
swCenterLineMarkOrient_e	Centerline mark orientation.
swCenterMarkConnectionLine_e	Visibility options for connection lines of center marks. Bitmask .
swCenterMarkHandle_e	Direction of center mark handle.
swCenterMarkStyle_e	Center mark styles.
swChainPatternAlignment_e	Chain pattern alignments.
swChainPatternOptions_e	Chain pattern options.
swChainPatternPitchMethod_e	Chain pattern pitch methods.
swChamferType_e	Chamfer types.
swCheckClearanceBetween_e	Between options for clearance verification.
swCheckInterferenceOption_e	Check interference options. Bitmask .
swCheckOutOfDate_e	Check for out-of-date lightweight components options.
swCheckSpellingOptions_e	Spell check options. Bitmask .
swChildComponentInBOMOption_e	Child component display options in Bills of Materials (BOM) for assemblies and for parts that have weldment/sheet metal cut lists.
swClearanceType_e	Clearance verification types.
swClearanceVerificationSetEntityErrors_e	Error codes when setting entities for clearance verification.
swClosedCornerTypes_e	Closed corner types.
swCloseReopenError_e	Close and reopen errors.
swCloseReopenOption_e	File close and reopen options. Bitmask .
swCollabCheckReadOnlyModifiedInterval_e	Intervals when to check files for modifications that were opened read-only in a multi-user environment.
swCollinearChainDimArrowHeadStyle_e	Collinear chain dimension arrow head styles.
swCollisionDetectionResults_e	Collision detection results.
swCollisionGroupApplyTransformErrors_e	Errors when applying transforms to collision groups.
swCollisionGroupSetComponentsErrors_e	Errors when setting components in collision groups.
swCollisionManagerSetAssemblyErrors_e	Return codes when setting the assembly for the collision detection manager.
swColorsBackgroundAppearance_e	Backgrounds for graphics area.
swColumnTypeStatus_e	Table column error codes.
swCombineBodiesOperationType_e	Combine bodies operation types.
swCommand_e	Dialog or file to display.
swCommandFlyoutStyle_e	Types of FlyoutGroup.
swCommandItemType_e	Types of command items. Bitmask .
swCommandTabButtonFlyoutStyle_e	CommandManager tab button flyout styles. Bitmask .
swCommandTabButtonTextDisplay_e	CommandManager tab button text display. Bitmask .
swCompatibilityDialogOptions_e	Options for displaying the previous file format version compatibility check results dialog.
swComponentIdentifier_e	Component display options for the FeatureManager design tree. Bitmask .
swComponentLoadStatus_e	Load status of component.
swComponentReloadError_e	Codes returned when reloading components in assemblies.
swComponentReloadOption_e	Options for reloading components in assemblies.
swComponentResolveStatus_e	States for resolving components.
swComponentSolvingOption_e	Options for resolving components.
swComponentSuppressionState_e	States for component suppression.
swComponentVisibilityState_e	States for component visibility.
swConcentricAlignmentType_e	Concentric mate alignment types.
swConcentricPositionType_e	Misaligned concentric mate positions.
swConfigTreeSortType_e	Order in which configurations are listed in the ConfigurationManager.
swConfigurationChangeTypes_e	Types of configuration changes.
swConfigurationOptions_e	Option bits used when setting configuration options. Bitmask .
swConfigurationOptions2_e	Option bits used when setting configuration options. Bitmask .
swConfigurationType_e	Types of configurations.
swConnectedSegmentsOption_e	Types of structural weldment segment connections.
swConnectedSyncSettingsErrors_e	Return codes for ISldWorks:UploadToMySolidWorksSettings and ISldWorks:DownloadFromMySolidWorksSettings .
swConnectionPointType_e	Connection point types.
swConstrainedCornerAction_e	Actions to take if the corner to be filleted is constrained or has a dimension.
swConstrainedStatus_e	Status of sketch constraints.
swConstraintType_e	Sketch constraints.
swContactType_e	Curve control contact types.
swControlBitmapLabelType_e	SOLIDWORKS bitmap types.
swCoordSysElementType_e	Coordinate system element types.
swCoreFeatureDirection_e	Directions for core features.
swCornerReliefBendType_e	Sheet metal corner relief bend types.
swCornerReliefError_e	Sheet metal corner relief errors.
swCornerReliefSuitCaseType_e	Sheet metal corner relief suitcase types.
swCornerReliefType_e	Corner reliefs.
swCornerTreatmentPlanarTrimOptions_e	Structure system corner treatment planar trim options.
swCornerTreatmentPlanarTrimToolType_e	Structure system corner treatment planar trim tool types.
swCornerTreatmentTrimType_e	Structure system corner treatment trim types.
swCornerType_e	Structure system corner types.
swCosmeticConfigOptions_e	Cosmetic thread configuration options.
swCosmeticEndConditions_e	Cosmetic thread end conditions.
swCosmeticStandardType_e	Cosmetic thread standard types.
swCosmeticThreadDiameterType_e	Cosmetic thread diameter types.

swCosmeticThreadType_e	Cosmetic thread types.
swCosmeticWeldBeadMode_e	Cosmetic weld bead modes
swCosmeticWeldBeadSide_e	Cosmetic weld bead options.
swCosmosWorksMat	SOLIDWORKS Simulation (formerly called COSMOSWorks) materials.
swCreateAngRunDimError_e	Statuses when inserting an angular running dimension.
swCreateCommandGroupErrors	Error codes for creating CommandGroups.
swCreateExplodeStepError_e	Return codes when creating an explode step.
swCreateFacesBodyAction_e	Options for creating missing faces on an open body.
swCreateFeatureBodyOpts_e	Options for creating bodies. Bitmask .
swCreateFeatureError_e	Error codes that may occur when creating a feature.
swCreateOrdDimError_e	Errors when inserting an ordinate dimension.
swCreatePartExplodeStepError_e	Result codes when creating explode steps for multibody parts.
swCreateSectionViewAtOptions_e	Options that affect the section view that is created. Bitmask .
swCreateSeedCutType_e	Pattern seed cut types.
swCreateWireBodyOptions_e	Options for creating wire bodies. Bitmask .
swCropViewErrors_e	Errors when cropping views.
swCrossHatchFilter_e	Cross hatch filters.
swCurveDrivenPatternAlignment_e	Curve-driven pattern alignments.
swCurveDrivenPatternCurveMethod_e	Curve methods.
swCurveTypes_e	Curve types.
swCustomInfoAddResult_e	Result codes when adding custom properties.
swCustomInfoDeleteResult_e	Result codes when deleting custom properties.
swCustomInfoGetResult_e	Result codes when getting custom properties.
swCustomInfoSetResult_e	Result codes when setting custom properties.
swCustomInfoType_e	Custom property types.
swCustomLinkSetResult_e	Error codes when linking and unlinking custom properties.
swCustomPropertyAddOption_e	Options when adding custom properties.
swCutListExclusionStatus_e	Status of excluding the selected faces and features in the cut list sort exclusion list.
swCutListTransferOptions_e	Options for transferring the cut list when saving a weldment member, surface body, or solid body to another part.
swCutListType_e	Cut list types.
swCutSweepOption_e	Sweep cut options.
swDatumDisplayType_e	Datum feature display styles.
swDatumGblLeaderStyle_e	Orientations of the leader for a round datum feature symbol.
swDatumTagTextParts_e	Text parts of datum tags.
swDatumTargetAreaShape_e	Target area shapes for datum target symbols.
swDefaultBOMPartNumberSource_e	Sources of bill of materials part numbers for new configurations.
swDeleteSelectionOptions_e	Options for deleting features. Bitmask .
swDesignTableErrors_e	Design table errors.
swDesignTableSourceTypes_e	Types of source files for design tables.
swDesignTableUpdateOptions_e	Options for updating design tables.
swDestroyNotIVType_e	Options for when destroying model views.
swDetailingBalloonAutoBalloons_e	Types of autoballoons.
swDetailingChamferDimLeaderStyle_e	Detailing chamfer dimension leader style.
swDetailingChamferDimLeaderTextStyle_e	Detailing chamfer dimension leader text style.
swDetailingChamferDimXStyle_e	Detailing chamfer DimXpert style.
swDetailingDimFractionScaleIndex_e	Sizes of stacked dimensions in fractional dimensions.
swDetailingDimFractionStyle_e	Detailing dimension fraction styles.
swDetailingDimTrailingZero_e	Detailing dimension trailing zero styles.
swDetailingDimXpertChamferInstanceStyle_e	DimXpert chamfer options.
swDetailingDimXpertChamferStyle_e	DimXpert chamfer options.
swDetailingDimXpertFilletInstanceStyle_e	DimXpert fillet options.
swDetailingDimXpertSlotStyle_e	DimXpert slot options.
swDetailingDualDimPosition_e	Detailing dual dimension positions.
swDetailingForeshortenedDiameterStyle_e	Detailing foreshortened diameter styles.
swDetailingGtolMaterialConditionSymbolPlacement_e	Tools > System Options > Document properties > Annotations > Geometric Tolerances > Material Condition Symbol Placement.
swDetailingHalfSectionArrow_e	Half section arrow displays.
swDetailingLeadingZero_e	Detailing leading zero options.
swDetailingLinearForeshortened_e	Linear dimensions foreshortened types.
swDetailingNoteTextContent_e	BOM balloon note text styles.
swDetailingSectionViewLineStyle_e	Display section view line styles.
swDetailingSFSymbolStandard_e	Detailing surface finish symbol standards.
swDetailingStandard_e	Detailing standards.
swDetailingToleranceTextSizing_e	Detailing tolerance text sizes.
swDetailingViewLabelsDelimiter_e	Formats for the auxiliary view scale labels.
swDetailingViewLabelsLabel_e	Formats of the auxiliary view labels.
swDetailingViewLabelsName_e	Format of the titles to use in front of the auxiliary view labels.
swDetailingViewLabelsScale_e	Format of the titles to use in front of the auxiliary view scales.
swDetailingViewRotation_e	View rotation options.
swDetailingVirtualSharp_e	Display options for virtual sharps.
swDetCircleShowType_e	Types of circles or profiles to use for detail views.
swDetViewStyle_e	Detail view styles.
swDimensionArrowsSide_e	Dimension arrow directions.
swDimensionDrivenState_e	Driven or driving state of dimensions.
swDimensionParamType_e	Dimension types.
swDimensionPrecisionSettings_e	Precision settings for dimensions.
swDimensionPrefix_e	Prefixes for PMI dimension annotations.
swDimensionSymbol_e	Symbols for PMI dimension annotations.
swDimensionTextParts_e	Options for getting and setting display dimension text.
swDimensionToleranceWarning_e	Dimension tolerance warnings.
swDimensionType_e	Types of dimensions.
swDimXpertBlockPrecision_e	DimXpert block tolerance precisions.
swDimXpertDisplayDatumGtolLinearDimAttachmentType_e	Attachment types for DimXpert datum geometric tolerance linear dimensions.
swDimXpertDisplayDatumGtolSurfaceAttachmentType_e	Attachment types for DimXpert datum geometric tolerance surfaces.
swDimXpertDisplayGtolLinearDimAttachmentType_e	Attachment types for DimXpert geometric tolerance linear dimensions.
swDimXpertDisplayHoleDimensionType_e	Dimension types for DimXpert holes.
swDimXpertDisplaySlotDimensionType_e	Dimension types for DimXpert slots.
swDimXpertGeneralTolClass_e	DimXpert tolerance classes.
swDimXpertTolType_e	DimXpert tolerance types.
swDimXpertTreeDisplay_e	Types of tree display on the DimXpert tab.
swDisplayCircularReferencesInEquations_e	Display options for circular references in equations.
swDisplayDimensionLeaderText_e	Display dimension leaders and text placement.
swDisplayMode_e	Display modes of drawing views.
swDisplayPanelIndex_e	Active display panes.
swDisplayPotentialCircularReferencesInEquations_e	Display options for potential circular references in equations.
swDisplayStateCreationChoices_e	Display-state preserve options.
swDisplayStateOpts_e	Display state options.
swDisplayTangentEdges_e	Tangent edge display modes.
swDistanceMateArcConditions_e	Arc conditions for cylindrical distance mates.
swDocTemplateTypes_e	Document template types. Bitmask .
swDocumentTypes_e	Document types.
swDofStatus_e	Dof status.
swDraftAnalysisFaceType_e	Draft analysis face types.
swDraftAnalysisOptions_e	Draft analysis options. Bitmask .
swDraftAnalysisShow_e	Show draft analysis options. Bitmask .
swDraftFacePropagationType_e	Draft face propagation types.
swDraftStepType_e	Draft step types.
swDraftType_e	Draft types.
swDragArrowManipulatorOptions_e	Draft arrow manipulator options.

swDrawingComponentLineFontOption_e	Types of edges of components in assembly drawings whose line font styles you can change.
swDrawingMode_e	Drawing modes.
swDrawingNotify_e	Drawing notifications.
swDrawingProjectionType_e	Drawing projection types.
swDrawingSheetsZonesEnterLayout_e	Options for letter layouts in drawing sheet zones.
swDrawingSheetsZonesOrigin_e	Options for the origins of drawing sheet zones.
swDrawingViewTypes_e	Drawing view types.
swDwgImportEntitiesPositioning_e	Drawing import entities positionings.
swDwgPaperSizes_e	Drawing paper sizes.
swDwgTemplates_e	Drawing templates.
swDxfFormat_e	DXF/DWG output formats.
swDxfMultisheet_e	DXF/DWG multisheets.
swDynamicMode_e	Dynamic modes.
swEdgeFlangeError_e	Edge flange error codes.
swEdgesHiddenEdgeDisplay_e	Hidden edge display types.
swEdgesInContextEditTransparencyType_e	In-context edit transparency edge types.
swEdgesShadedModeDisplay_e	Shaded edges display modes.
swEdgesTangentEdgeDisplay_e	Tangent edge display modes.
swEdgeUntrimType_e	Untrimmed edge types.
swEditBalloonOption_e	Edit balloon options.
swEditPartCommandStatus_e	Return values during the activation of a part.
swEdrawingsAttachmentOption_e	Configuration options for creating and attaching STEP files when publishing a part or assembly to eDrawings.
swEdrawingsAttachmentType_e	Types of STEP file to create and attach when publishing configurations to eDrawings.
swEdrawingSaveAsOption_e	eDrawings Save As options.
swElectricalConnectionPointType_e	Electrical connection point types.
swElectricalSubType_e	Electrical route sub types for connection points.
swEllipsePts_e	Values for interpreting ellipse data.
swEndCapThicknessDirection_e	End cap thickness directions.
swEndConditions_e	End conditions for creation of a variety of features.
swEndShape_e	End shapes for straight hole and straight tap elements of the Advanced Hole.
swExcludeFromBOMError_e	Result codes when setting whether to exclude a component from a bill of materials.
swExplodeDirectionIndex_e	Explode direction manipulator options when creating or editing an explode step.
swExportDataFileType_e	Export data file types.
swExportDataSheetsToExport_e	Export data sheets to export options.
swExportFlatPatternViewOptions_e	Flat-pattern view options.
swExportGeomOptions_e	DXF/DWG geometry export options.
swExportSVPJFileFormatGroupType_e	SVPJ file format group types.
swExportToDWG_e	Options for the Action parameter of IPartDoc.ExportToDWG2 .
swExternalFileReferencesConfig_e	External file references configurations options.
swExternalFileReferencesUpdate_e	External file references update options.
swExternalReferenceStatus_e	External reference status.
swExternalReferencesUpdateOutOfDateLinkedDesignTable_e	Out-of-date external references linked design table options.
swExtrudeFrom_e	Extrude from options.
swFaceCoincidentResult_e	Face coincidence results.
swFaceDeleteOption_e	DeleteFace feature options.
swFaceUntrimType_e	Untrimmed faces types.
swFamilyTableDimColumnType_e	Family table dimension column types.
swFamilyTableGetConfigurationCriteria_e	Criteria for getting family table configurations.
swFastenerTableTypes_e	Fastener table types.
swFaultEntityErrorCode_e	Fault entity error codes.
swFeatMgrPane_e	Available panes and states.
swFeatureChamferOption_e	Chamfer feature options. Bitmask .
swFeatureDimensionParameter_e	Pattern display dimension options.
swFeatureEditStatus_e	Editing status of feature. Bitmask .
swFeatureError_e	Feature error codes.
swFeatureFilletOptions_e	Fillet/chamfer options. Bitmask .
swFeatureFilletProfileType_e	Fillet cross-sectional profile shapes.
swFeatureFilletType_e	Feature fillet types.
swFeatureFillSurfaceOptions_e	Feature fill surface options. Bitmask .
swFeatureManagerDisplayWarnings_e	FeatureManager design tree display warnings.
swFeatureManagerTreeViewCADFamily_e	SOLIDWORKS Design connected to the 3DEXPERIENCE platform only. Tools > System Options > FeatureManager > Select a configuration view for the FeatureManager Tree Area.
swFeatureModifier_e	Material conditions for PMI Gtol frames.
swFeatureNameID_e	Feature name IDs.
swFeatureScope_e	Feature scope options.
swFeaturesToPatternType_e	Seed instance types for patterns.
swFeatureSuppressionAction_e	Feature suppression actions.
swFeatureTreeFolderType_e	Ways to insert feature folders for selected features or components in the FeatureManager design tree.
swFeatureTreeState_e	Flyout FeatureManager design tree states.
swFileCloseNotifyReason_e	Reasons for the FileCloseNotify event.
swFileFormatType_e	STEP file formats/editions.
swFileLoadError_e	File load errors. Bitmask .
swFileLoadWarning_e	File load warnings for ISldWorks.OpenDoc6 . Bitmask .
swFileSaveError_e	File save errors. Bitmask .
swFileSaveTo3DExperienceError_e	Errors when saving files in SOLIDWORKS Design connected to the 3DEXPERIENCE platform.
swFileSaveTypes_e	File save types.
swFileSaveWarning_e	Values for File.Save warnings that can be returned from the IModelDoc2 Save methods. These warnings do not cause the File.Save operation to fail. Bitmask .
swFilletOverFlowType_e	Fillet overflow types.
swFitToDisplay_e	Fit tolerance display styles.
swFitType_e	Fit types.
swFlangeDimTypes_e	Origins for dimensioning Blind or Up To Edge And Merge flange length end conditions in edge flanges.
swFlangeOffsetTypes_e	End conditions for both flange length and flange position offset for sheet metal edge and base flanges.
swFlangePositionTypes_e	Position types for sheet metal edge flanges.
swFMViewNotify_e	FeatureManager design tree notifications.
swFractionDisplay_e	Fraction display types.
swGeneralImportFreePointCurveEntityOptions_e	Import free curve entity options.
swGeneralImportSurfaceSolidEntityOptions_e	Import surface solid entity options.
swGeneralImportUnitsOptions_e	Import unit options.
swGeometricCharacteristic_e	Geometric characteristics for Gtol frames.
swGeometryToSave_e	Geometry to save options for IAdvancedSaveAsOptions.GeometryToSave .
swGeomType_e	Geometry types.
swGetOpenFileNameOptions_e	Options for opening a file returned by ISkrtWorks.GetOpenFileName2 . Bitmask .
swGlobalBBoxLWTAIDirectionType_e	Length, width, and thickness directions for a rectangular bounding box and axis directions for a cylindrical bounding box.
swGlobalBoundingBoxFitOptions_e	Global bounding box fit types.
swGlobalBoundingBoxResult_e	Global bounding box insertion results.
swGtolDecimalSeparatorType_e	Gtol decimal separator types.
swGtolFormatConversionError_e	Gtol format conversion errors.
swGtolFormatSchemaVersion_e	Gtol format schema versions.
swGtolFormatType_e	Gtol format types.
swGtolGeomCharSymbol_e	Gtol geometric character symbols.
swGtolIndicatorBorderType_e	Gtol indicator border types.
swGtolMatCondition_e	Gtol material condition types.
swGtolTextParts_e	Text parts of GTols.
swGtolToType_e	Tolerance zone types in Gtol frame boxes.
swGuideCurveInfluence_e	Guide curve influence types.
swGussetProfileLocationType_e	Gusset profile location types.
swGussetProfileType_e	Gusset profile types.
swGussetThicknessType_e	Gusset thickness types.

swHandleActiveXCreationFailure_e	Actions on failure to create an ActiveX control on a PropertyManager page.
swHandleWindowFromHandleCreationFailure_e	Actions on failure to create a .NET control on a PropertyManager page.
swHealActionType_e	Healing actions.
swHelixDefinedBy_e	Helix definitions.
swHemPositionTypes_e	Hem position types.
swHemTypes_e	Hem types.
swHingeMateEntityType_e	Hinge mate entity types.
swHlrQuality_e	HLR types.
swHoleElementOrientation_e	Advanced Hole orientations.
swHoleSeriesWhichParts_e	Which parts the hole series passes through.
swHoleTableTagOrder_e	Method by which to assign tag numbers to holes of the same size.
swHoleTableTagPrefixApply_e	Options for applying prefixes to manual table tags of holes.
swHoleTableTagStyle_e	Hole table tag styles.
swHorizontalAutoSplitApply_e	Options for when to automatically split a table horizontally.
swHorizontalAutoSplitPlacementOfSplitTable_e	Options for placement of the split table portion after a horizontal table split.
swIFCExportSaveType_e	IFC export options.
swIFCOmniUniClassPreference_e	IFC output as types.
swIGESCurveRepresentation_e	IGES curve representations.
swIGESPreferredSystem_e	IGES systems.
swIGESRepresentation_e	IGES representation types.
swImageQualityShaded_e	Quality of tessellation of cylindrical surfaces for shaded rendering output.
swImageQualityWireframe_e	Quality of wireframe display output.
swImageSizeToUse_e	Default image sizes for the current DPI setting of the display device for images that are not based on the SOLIDWORKS icon size setting.
swImportDxfDwg_ImportMethod_e	DXF/DWG import methods.
swImportDxfDwg_LayerVisibility_e	DXF/DWG layer visibility states.
swImportModelItemsSource_e	Sources from which to import model items.
swImportNeutralAssemblyStructureMapping_e	Neutral import assembly structure mappings.
swImportNeutralCurvesAndPointsOptions_e	Neutral import curves and points options.
swImportNeutralKnitOption_e	Neutral import knit options.
swImportNeutralUnits_e	Neutral import units.
swImportPartCustomPropertiesToOptions_e	Derived part custom properties import options.
swImportSheetMetalInformation_e	Derived part sheet metal information import options.
swImportStivrmModelType_e	STL/VRML import model types.
swImprintingFacesOpts_e	Imprinting faces options. Bitmask .
swInConfigurationOpts_e	Configuration options.
swInContextEditTransparencyType_e	In-context edit transparency types.
swIndentSelectionState_e	Indent selection states.
swInsertAnnotation_e	Annotation types. Bitmask .
swInsertAssyOptions_e	Insert assembly into part options. Bitmask .
swInsertEdgeFlangeOptions_e	Sheet metal edge flange options. Bitmask .
swInsertNewAssemblyErrorCode_e	Error codes when assembly inserted.
swInsertNewPartErrorCode_e	Error codes when part inserted.
swInsertOptions_e	Options for pasting a sheet into a drawing document.
swInsertPartOptions_e	Part insertion options. Bitmask .
swInsertSlicingError_e	Error codes for slicing insertion. Bitmask .
swInsertTableColumnWidthStyle_e	Inserted table column width options.
swInstanceToVaryModificationType_e	Types of pattern instance modification when varying instances.
swInterfaceBrightnessColor_e	Background colors.
swInterfaceBrightnessTheme_e	Background themes.
swInterpolationType_e	Types of interpolation.
swIntersectionType_e	Curve intersections types.
swIsolateVisibility_e	Isolate component options.
swJogDimensionPositionType_e	Jog dimension position types.
swJogOffsetTypes_e	Jog offset types.
swJogPositionType_e	Jog position types.
swKeepReplacedCompOption_e	Options for replacing components in BOM features.
swKernelErrorCode_e	Kernel error codes.
swLargeDesignReviewState_e	Large Design Review states.
swLayerItemsOption_e	Layer item types.
swLayerOverride_e	Layer override types. Bitmask .
swLeaderLineVisibility_e	Visibility of leader lines.
swLeaderSide_e	Leader side types.
swLeaderStyle_e	Leader styles.
swLengthUnit_e	Length unit types.
swLibFeatDimensionType_e	Library feature dimension types.
swLibFeatureData_e	Library feature entity options.
swLicenseType_e	SOLIDWORKS license types.
swLineEndCaps_e	Line end caps types.
swLineStyles_e	Line styles used in drawings.
swLineTypes_e	Line styles in drawings.
swLineWeights_e	Line weights used in layers.
swLinkBomToDisplayStateError_e	Errors when linking a BOM to a Display State.
swLinkDimensionError_e	Link dimension errors.
swLinkString	Types of links for errors and trouble-shooting bubbles.
swLoadAddinError_e	Add-in load errors.
swLoadDetachedModelRules_e	Detached model load options.
swLoadExternalReferences_e	External references load options.
swLocalCurvePatternAlignment_e	Alignments for local curve-driven patterns.
swLocalCurvePatternCurveMethod_e	Curve methods for local curve-driven patterns.
swLocalCurvePatternReferencePoint_e	Reference points for local curve-driven patterns.
swLocalSketchPatternReferencePoint_e	Reference points for local sketch-driven patterns.
swLocationLabelText_e	Types of text for the upper and lower sections of location labels.
swLoftedBendFacetOptions_e	Faceting options for lofted bend facet features.
swLoopProcessOption_e	Loop processing options.
swMacroFeatureEntityType_e	Macro feature entity ID types.
swMacroFeatureOptions_e	Placement of the macro feature in the FeatureManager design tree options. Bitmask .
swMacroFeatureParamType_e	Macro feature parameter types.
swMacroFeatureSecurityOptions_e	Macro feature security options. Bitmask .
swMacroMethods_e	Types of macro methods.
swManipulatorCursor_e	Triad manipulator cursor types.
swManipulatorOptions_e	Manipulator options. Bitmask .
swManipulatorRepresentation_e	Triad manipulator representations.
swManipulatorType_e	Manipulator types.
swMassPropertiesStatus_e	Mass property result codes.
swMassPropertyAccuracyLevel_e	Mass property accuracy level options.
swMassPropertyMoment_e	Moment of inertia coordinate systems.
swMateAlign_e	Mate alignment types.
swMateEntity2ReferenceType_e	Mate entity reference types.
swMateEntityType_e	Mate entity type IDs.
swMateReferenceAlignment_e	Mate reference alignments.
swMateReferenceIndex_e	Mate reference indexes.
swMateReferenceType_e	Mate reference types.
swMaterialModifier_e	Material modifiers in Gtol frames.
swMatesDefaultMisalignment_e	Concentric mate misalignment options.
swMateType_e	Assembly mate types.
swMateWidthOptions_e	Assembly mate width options.
swMBDSTEP242PublishEdition_e	Step 242 publish editions.
swMeasureArcCircleOption_e	Distance to display when arcs or circles are selected using the Measure tool.

swMeasureProjectOnOption_e	Distance between selected entities projection when using the Measure tool.
swMenuIdentifiers_e	Menu item types.
swMenuItemType_e	Menu item types.
swMessageBoxBtn_e	Message box control buttons.
swMessageBoxIcon_e	Message box icons.
swMessageBoxResult_e	Message box results.
swMirrorComponentMirrorType_e	Mirror positions for mirroring components.
swMirrorComponentNameModifier_e	Prefix or suffix for newly mirrored components.
swMirrorComponentOrientation_e	Orientation options for instanced mirror components.
swMirrorComponentOrientation2_e	Orientations for mirroring components.
swMirrorPartOptions_e	Options for creating a mirror part. Bitmask .
swMirrorPlaneType_e	Types of mirror plane.
swMirrorProfileOrAlignmentAxis_e	Axis options for mirroring the profile of or aligning a sweep cut feature.
swMirrorViewPositions_e	Mirror view orientations.
swModelRebuildStatus_e	Rebuild status of model. Bitmask .
swModelRouteType_e	Route types for connection points.
swModifyTableNotifyReason_e	Notification reason codes for modifying tables.
swMomentsOfInertiaReferenceFrame_e	Reference frames for moments of inertia mass properties.
swMotionContactFrictionType_e	Motion Study contact friction types.
swMotionMat_e	Motion Study materials.
swMotionPlotAxisComponent_e	Types of motion study components.
swMotionPlotAxisType_e	Types of motion study plot axes.
swMouseDownMode_e	Current command states.
swMouseNotify_e	Mouse notifications.
swMoveableDatumDirection_e	Directions for moveable datum target symbols.
swMoveableDatumStyle_e	Moveable datum target symbol styles.
swMoveCopyBodyFeatureTransformType_e	Move/copy body transform types.
swMoveCopyError_e	Move/copy errors.
swMoveCopyOptions_e	Move/copy options. Bitmask .
swMoveFaceType_e	Face move types.
swMoveFreezeBarTo_e	Move options for freeze bar.
swMoveLocation_e	Options for moving features in parts and assemblies.
swMoveRollbackBarTo_e	Position to move rollback bar.
swNameType_e	Names of types of entities. Bitmask .
swNonInterferingComponentDisplay_e	Modes to display non-interfering components.
swNormalCutErrors_e	Error codes when creating a sheet metal Normal Cut cut-extrude face group.
swNormalCutParameters_e	Sheet metal normal cut parameters.
swNotifyEntityType_e	Notification entity types.
swNumberboxUnitType_e	Number box units.
swNumberedListStartType_e	Numbered list start types.
swNumberedListType_e	Numbered list types.
swNumberingFormat_e	Format of numbered list items.
swNumberingType_e	Types of numbering for indented BOM tables.
swObjectEquality	Object equality states.
swOffsetPlanarWireBodyOptions_e	How to fill the gap between edges.
swOLEObjectOptions_e	OLE object options.
swOnSurfacePlaneProjectType_e	Types of planes on surfaces.
swOpenDocOptions_e	How to open documents using ISlidWorks::OpenDoc6 . Bitmask .
swOrdDimEndSymbol_e	Ordinate dimension end symbols.
swOutOfDateStatus_e	Rebuild state of the components.
swPackAndGoDocumentStatus_e	Types of documents for Pack and Go.
swPackAndGoFolderOptions_e	Types of folder structure options for Pack and Go.
swPackAndGoSaveStatus_e	Status of each document intended for Pack and Go.
swPageSetupDrawingColor_e	Colors of drawings set-up values.
swPageSetupPinUse_e	Page set-up values.
swPageSetupOrientation_e	Page orientation set-up values.
swParabolaPts_e	Parabola points.
swParagraphType_e	Paragraph list types.
swParameterizationPropertyType_e	Properties of U and V parameters.
swParamType_e	Parameter data types.
swParasolidOutputVersion_e	Parasolid output versions.
swPartConfigurationGroupingOption_e	Part configuration groupings for BOM table display.
swPartDimXpertToleranceMethod_e	DimXpert tolerance methods.
swPartingLineFeatureStatus_e	Statuses of parting line features.
swPartingSurfaceMoldParmType_e	Types of mold parting surfaces.
swPartingSurfaceSmoothingType_e	Smooth mold parting surfaces.
swPartnerEntitlementStatus_e	Partner entitlement status.
swPartNotify_e	Part notifications.
swPatternElementSelection_e	Pattern element selection options.
swPatternEndCondition_e	Pattern spacing options.
swPatternFeatureImportExportError_e	Variable pattern feature errors when importing or exporting Microsoft Excel data.
swPatternLayoutSpacingType_e	Pattern layout spacing types.
swPatternLayoutType_e	Pattern layout types.
swPatternReferenceTypes_e	Local linear pattern axis types.
swPerformanceFeedback_e	Performance feedback options.
swPersistReferencedObjectStates_e	Object codes for objects' persistent reference IDs. Bitmask .
swPipingPenetrationStatus_e	Piping penetration status.
swPLYQuality_e	Polygon file format resolutions.
swPMCContainer_e	Docking states of PropertyManager page.
swPMIDatumAnchorStyle_e	PMI datum anchor styles.
swPMIDatumShape_e	PMI datum shapes.
swPMIDatumTargetAreaStyle_e	PMI datum target area styles.
swPMIDatumTargetMovableStyle_e	PMI datum target movable styles.
swPMIDatumTargetSymbolStyle_e	PMI datum target symbol styles.
swPMIDatumType_e	Datum types for PMI annotations.
swPMILeaderLocation_e	PMI leader locations.
swPMILeaderModifier_e	PMI leader modifiers.
swPMILeaderStyle_e	PMI leader styles.
swPMILeaderType_e	PMI leader types.
swPMITolPerUnitAreaType_e	PMI tolerance per unit area types.
swPMIType_e	Types of PMI annotations.
swPMIUnit_e	Units of measure for Product and Manufacturing Information purposes.
swPointInferenceBrokerOption_e	Inference points options from add-ins. Bitmask .
swPointStyle_e	Point styles.
swPresentationOpts_e	SOLIDWORKS Presentation options. Bitmask .
swPrimaryMemberPointLengthEndCondition_e	Structure system primary member point length end conditions.
swPrintProperties_e	Print properties.
swPrintSelectionScaleFactor_e	Drawing print selection scale options.
swPromptForFilenameCause_e	Reasons for opening or saving missing dependent documents.
swPromptAlwaysNever_e	Responses to being prompted by SOLIDWORKS.
swPropertyManagerButtonTypes_e	PropertyManager button types. Bitmask .
swPropertyManagerCheckBoxState_e	PropertyManager page check box states.
swPropertyManagerColorScheme_e	Color schemes for PropertyManager pages.
swPropertyManagerPageBitmapButtons_e	PropertyManager page bitmap buttons.
swPropertyManagerPageButtons_e	PropertyManager page buttons.
swPropertyManagerPageCloseReasons_e	Reasons why a PropertyManager page closes.
swPropertyManagerPageControlLeftAlign_e	Left alignments for controls on PropertyManager pages.
swPropertyManagerPageControlType_e	Controls for PropertyManager pages.

swPropertyManagerPageCursors_e	PropertyManager page's cursor after a user makes a selection in the SOLIDWORKS graphics area.
swPropertyManagerPageMessageExpanded	Expand, compress, or leave the state of the PropertyManager page's message as is.
swPropertyManagerPageMessageVisibility	Visibility states for messages for PropertyManager pages.
swPropertyManagerPageOptions_e	Options for PropertyManager pages. Bitmask .
swPropertyManagerPageShowOptions_e	Options for showing PropertyManager pages. Bitmask .
swPropertyManagerPageStatus_e	PropertyManager page statuses.
swPropertyManagerStatus_e	Return values for various PropertyManager APIs.
swPropertySheetNotify_e	Property sheet notifications.
swPropMgrPageComboBoxStyle_e	PropertyManager page combobox styles.
swPropMgrPageControlOnResizeOptions_e	PropertyManager page control resize options. Bitmask .
swPropMgrPageLabelStyle_e	PropertyManager page control label styles. Bitmask .
swPropMgrPageLabelUnderlineStyle_e	Underline style of PropertyManager page label.
swPropMgrPageListBoxStyle_e	PropertyManager page list box styles. Bitmask .
swPropMgrPageNumberBoxStyle_e	PropertyManager page number box styles. Bitmask .
swPropMgrPageOptionStyle_e	PropertyManager page group option styles. Bitmask .
swPropMgrPageSelectionBoxStyle_e	PropertyManager page selection box styles. Bitmask .
swPropMgrPageSliderStyle_e	PropertyManager page slider styles. Bitmask .
swPropMgrPageTextBoxStyle_e	PropertyManager page textbox styles. Bitmask .
swPropSheetType_e	Property sheet types.
swPublishStepOpts_e	Options for publishing to Step 242.
swPublishTo3DPDFError_e	Status codes for publishing SOLIDWORKS MBD 3D PDF files.
swPunchTableTagStyle_e	Punch table datum tag styles
swQuadrant_e	Angular dimension types
swRackPinionMateDistanceOptions_e	Rack and pinion mate distance options.
swRackPinionMateEntityType_e	Rack and pinion mate entity types.
swRayPtsOpts_e	Ray points options. Bitmask .
swRayPtsResults_e	Types of intersections and whether the rays are entering or exiting the body when they hit. Bitmask .
swRayTraceRenderImageFormat_e	Image formats.
swRayTraceRenderingType_e	Ray trace rendering types.
swRayTraceRenderQuality_e	Ray-trace render quality.
swRayTraceRenderType_e	Ray trace rendering methods.
swRebuildOnActivation_e	Rebuild options during document activation.
swRebuildOptions_e	Rebuild options. Bitmask .
swRetAxisType_e	Reference axis types.
swReferencedFileStatus_e	Reference file open error codes.
swRefGeometryError_e	Errors when setting geometry of moveable rotational datum target symbols.
swRefPlaneReferenceConstraints_e	Reference plane constraints. Bitmask .
swRefPlaneReferenceIndex_e	Reference plane entities.
swRefPlaneType_e	Reference plane types.
swRefPointAlongCurveType_e	Reference point along curve types.
swRefPointType_e	Reference point type.
swRegionType_e	Drawing zone region types.
swRelativeViewCreationDirection_e	Relative view creation directions.
swReliefTearTypes_e	Sheet metal tear-drop relief types.
swReloadTemplateResult_e	Reload template results.
swRemainingDofs_e	Remaining Dofs types.
swRemoveCommandGroupErrors	Error codes for removing CommandGroups.
swRenamedDocumentFinalAction_e	Final actions for renaming document references.
swRenameDocumentError_e	Rename components errors.
swRenameOptions_e	Options for renaming a pasted drawing sheet.
swRendererType_e	Renderer type.
swRenderMaterialBumpMap_e	Render material (appearance) surface finish.
swRenderMaterialColorForms_e	Number of render material (appearance) colors.
swRenderMaterialIlluminationTypes_e	Render material (appearance) illumination types.
swReorderComponentsWhere_e	Where to move the components.
swRepaintTypes_e	Repaint notification types.
swRepairSketchOption_e	Options for repairing sketches. Bitmask .
swReplaceComponentError_e	Replace component errors.
swReplaceComponentsConfiguration_e	Replace components configuration options.
swReverseEndPointTangentResult_e	Result codes for ISketchManager::ReverseEndPointTangent .
swRevisionCloudShape_e	Revision cloud shapes.
swRevisionTableMultipleSheetStyle_e	Revision table multiple sheet styles.
swRevisionTableSymbolShape_e	Revision table symbol shapes.
swRevisionTableTagStyle_e	Revision table symbol shapes.
swRevolveOptions_e	Revolve feature options. Bitmask .
swRevolveType_e	Revolve feature types.
swRibExtrusionDirection_e	Rib extrusion directions.
swRibType_e	Rib types.
swRotationAxisIndex_e	Rotation ring manipulator options when creating or editing an explode step.
swRoutingComponentGroupingOption_e	Routing components grouping options. Bitmask .
swRoutingFlattenConnectorOptions_e	Flattened route connector display options.
swRoutingFlattenSegmentOrientation_e	Flattened route segment orientation.
swRoutingFlattenTypes_e	Route flattening types.
swRoutingSearchType_e	Routing search types.
swRuledSurfaceType_e	Ruled surface types.
swRunMacroError_e	VBA macro error codes.
swRunMacroOption_e	VBA macro options.
swSafeArrayType_e	SafeArray types.
swSameAs_Status_e	Comparison status.
swSaveAsmAsPartOptions_e	Save assembly as parts options.
swSaveAsOptions_e	Save As options. Bitmask .
swSaveAsVersion_e	Version of a particular format to save the document.
swSaveItemsPathError_e	Error return codes for IAdvancedSaveAsOptions::ModifyItemsNameAndPath .
swSaveReminderIntervalMode_e	Intervals in which to remind user to save document.
swSaveRestoreSettingsResults_e	Return values for saving and restoring SOLIDWORKS settings.
swSaveToVersion_e	Previous version file formats available for save compatibility checks.
swSaveWithReferencesOptions_e	Options for saving references while getting the IAdvancedSaveAsOptions object; used by the Options parameter of IModelDocExtension::GetAdvancedSaveAsOptions . Bitmask .
swScaleType_e	Scale types.
swSceneBackgroundType_e	Scene background options.
swSceneFloorAlign_e	Scene floor alignment options.
swScrewMateDistanceOptions_e	Screw mate revolution options.
swSearchFolderTypes_e	Search folder types.
swSearchIndexingPerformance_e	Options when to perform search indexing.
swSecondaryMemberBetweenPointsDistanceFromEndType_e	Distance types of structure system secondary members created between end points of primary members.
swSecondaryMemberUpToMembersDistanceFromEndType_e	Distance from end types for structure system secondary up-to members.
swSecondaryMemberUpToMembersMemberPointParameters_e	Point parameters for structure system secondary up-to members.
swSeedAlignmentReferencePoint_e	Types of reference points for aligning rotated pattern instances to the seed instance in linear component patterns.
swSelectionMarkAction_e	Selection mark actions.
swSelectionReferenceTypes_e	Selection reference types.
swSelectOption_e	Selection options. Bitmask .
swSelectType_e	Values for types of returned IDs.
swSensorAlertType_e	Types of sensor alert.
swSensorType_e	Types of sensor.
swSetComponentIdentifierResult_e	Set component identifier status. Bitmask .
swSetComponentsAndTransformsStatus_e	Results for setting interfering components and their transforms.
swSetHelixRegionParameterStatus_e	Statuses for setting helix regions.
swSetRouteFixedLengthError_e	Routing fixed-length errors.
swSetSectionLabelStatus_e	Section label statuses.

swSetValueInConfiguration_e	Values for indicating in which configurations the value should be set.
swSetValueReturnStatus_e	Return values for attempting to set the value of a parameter.
swSFLaySym_e	Values for direction of lay types.
swSFProfileDirection_e	Surface finish profile directions.
swSFSymType_e	Values for surface finish symbol types and options.
swSheetMetalAutoReliefTypes_e	Sheet metal auto relief types.
swSheetMetalBendNotesBorderSize_e	Sheet metal bend notes border sizes.
swSheetMetalGussetProfileDimType_e	Sheet metal gusset profile dimensioning schemes.
swSheetMetalGussetProfileType_e	Sheet metal gusset profile types.
swSheetMetalMBDBendNotesStyle_e	Sheet metal MBD bend note styles.
swSheetMetalModifierError_e	Sheet metal feature data errors.
swSheetMetalOverlapTypes_e	Sheet metal overlap types.
swSheetMetalOverrideDefaultParameters_e	Types of default parameters to override in a sheet metal feature in a multibody sheet metal part.
swSheetMetalReliefTypes_e	Sheet metal relief types.
swSheetMetalRibGussetType_e	Sheet metal gusset rib types.
swSheetPrintQuadrant_e	Quadrant options to print in TIFF format a high quality (zoomed) image of a drawing sheet. Used for machine learning and pixel compare tests.
swSheetSewingError_e	Sheet sewing errors.
swSheetSewingOption_e	Sheet sewing options.
swShowMessageBarResult_e	Message bar display result codes.
swShowNotificationResult_e	User notification display return values.
swShutOffSurfaceFeatureStatus_e	Shut-off surface features statuses.
swShutOffSurfacePatchType_e	Shut-off surface patch types.
swSimpleFilletPartialEdgeCondition_e	Partial fillet edge condition options.
swSimpleFilletType_e	Simple fillet types.
swSimpleFilletWhichFaces_e	Faces for simple-fillet features.
swSimulationDamperType_e	Simulation damper types.
swSimulationForceActionType_e	Simulation force action types.
swSimulationForceFunctionType_e	Simulation force function types.
swSimulationForceType_e	Simulation force types.
swSimulationGravityAxisName_e	Simulation gravity axis names.
swSimulationMotorDriveType_e	Simulation motor drive types.
swSimulationMotorMotionType_e	Simulation motor motion types.
swSimulationMotorType_e	Simulation motor types.
swSimulationSpringType_e	Simulation spring types.
swSketchChamferType_e	Chamfer types.
swSketchCheckFeatureProfileUsage_e	Types of features to check to see if this sketch is valid for use in creating the specified feature.
swSketchCheckFeatureStatus_e	Statuses after checking to see if this sketch is valid for use in creating the specified feature
swSketchEntityType_e	Sketch entity types.
swSketchFullyDefineRelationType_e	Fully defined sketch relations. Bitmask .
swSketchPictureTransparencyStyle_e	Transparency styles for sketch pictures.
swSketchPointType_e	Sketch point types.
swSketchRelationEntityType_e	Sketch relation entity types.
swSketchRelationFilterType_e	Sketch relation filter types.
swSketchSegments_e	Types of iSketchSegment objects.
swSketchSegmentType_e	iSketchSegment EqualSegment divide types.
swSketchSlotCreationType_e	Sketch slot creation types.
swSketchSlotLengthType_e	Sketch slot length types.
swSketchTrimChoice_e	Sketch trim options.
swSkInternalPntOpts_e	Values to control the display of internal sketch points.
swSkOffsetCapEndType_e	Offset sketch cap end types.
swSkOffsetMakeConstructionType_e	Convert original and offset sketch entities to construction sketch entities.
swSlicingTypes_e	Types of slicing. Bitmask .
swSlotMateConstraintOptions_e	Slot mate constraint options.
swSmartComponentSelectionTypes_e	Smart component selection types.
swSmartDimensionDirection_e	Smart dimension extension line directions or rapid dimensioning selector quadrants.
swSMBendState_e	Bend state values for a sheet metal part.
swSMCommandStatus_e	Return conditions for various sheet metal APIs that attempt to do set operations.
swSMGExportProfiles_e	SMG export profiles.
swSMGRefinementType_e	SMG export refinement types.
swSMGRefineRelativeType_e	SMG export relative refinement types.
swSMNormalCutError_e	Status codes when creating a Normal Cut feature.
swSolidBodiesDescriptionPropertyIndex_e	Arguments in the text expression of the Description bounding box property.
swSolidworksWeldmentEndCondOptions_e	Weldment end condition options.
swSpeedpakUpdate_e	Options for updating out-of-date Speedpak configurations when saving files.
swSplitBodyType_e	Split body types.
swSplitFaceOnParam_e	Split face on parameters.
swSplitFacesOption_e	Split faces options.
swSplitLineFeatureType_e	Split line feature types.
swSplitLineSplitSurfaceType_e	Split line surface types.
swSplitMemberDimensionType_e	Structure system split member dimension types.
swSpringDefineType_e	Spring definition types.
swSpringExtensionEndType_e	Spring extension types.
swSpringProfileType_e	Spring profile types.
swSpringTorsionEndType_e	Spring torsion end types.
swSpringType_e	Spring types.
swStackedBalloonDirection_e	Balloon stacking directions.
swStandardHeaderFooterPageSetupTexts_e	Standard header and footer page setup options.
swStandardViews_e	Standard view types.
swStartConditions_e	Start conditions.
swStep242Error_e	Status codes for exporting SOLIDWORKS MBD 3D PDF files to STEP 242.
swSTLQuality_e	STL quality types.
swStopContinuePrompt_e	Continue responses.
swStraightHoleClassificationType_e	Classification types for straight hole elements of the Advanced Hole.
swStraightHoleFilter_e	Filters for straight hole elements that use the PEM standard in Advanced Holes.
swStraightHoleFitType_e	Fit types for straight hole elements of the Advanced Hole.
swStraightTapHoleCustomSizing_e	Custom sizing options for straight tap elements of the Advanced Hole.
swStraightTapHoleEquation_e	Straight tap hole equation options for blind depth and offset distance.
swStraightTapHoleThreadClass_e	Thread classes for straight tap hole elements of the Advanced Hole.
swStructureProfileAlignmentType_e	Structure system profile alignment types.
swStructureProfileMirrorType_e	Structure system profile mirror types.
swStructureProfilePiercePointType_e	Structure profile pierce points.
swStructureSplitMemberType_e	Structure system split member types.
swStructureSystemMemberCreationType_e	Structure system member creation types.
swStructureSystemMemberType_e	Structure system member types.
swStyleSplineCurveType_e	Curve types and degrees for style splines.
swSumInfoField_e	Summary information fields. Read-only.
swSunIllumInfoType_e	Sunlight information.
swSuppressDialog_e	Task dialog suppression options. For internal use only.
swSuppressionError_e	Suppression errors.
swSurfaceCutFeatureError_e	Types of surface-cut errors.
swSurfaceExtendEndCond_e	Surface extend end conditions.
swSurfaceFinishSymbolOrientation_e	Surface finish symbol orientations.
swSurfaceFinishSymbolText_e	Types of surface finish symbol texts.
swSurfaceTrimType_e	Surface trim types.
swSurfaceTypes_e	Surface types.
swSweepDirection_e	Sweep directions.
swSweptFlangeError_e	Swept flange creation errors. Bitmask .
swSweptFlangePositionTypes_e	Types of swept flange position.

swSystemColorsCurrentColorScheme_e	Current color schemes.
swSystemColorsEnvelopes_e	System envelope colors.
swSystemColorsIconColor_e	System icon colors.
swSystemOptionDisplayAntiAliasing_e	System anti-aliasing display options.
swTabEdgesType_e	Types of tab edge treatments for Tab and Slot groups.
swTableAnnotationType_e	Table annotation types.
swTableCellOrientation_e	Orientations of text in table cells.
swTableCellRangeIdentifier_e	Table cell-range identifiers.
swTableColumnType_e	Table column types.
swTableHeaderPosition_e	Table header positions.
swTableItemInsertPosition_e	Table item insert positions.
swTableMergeLocations_e	Table merge locations.
swTableRowColSizeChangeBehavior_e	Values indicate how the size of the rest of the table should behave when a height of a row or width of a column changes.
swTableSplitDirection_e	Table split directions.
swTableSplitLocations_e	Table split locations.
swTableTagStyle_e	Table tag styles
swTabSlotFeatureHeightType_e	Types of tab height calculations in Tab and Slot groups.
swTabSlotFeatureSpacingType_e	Types of spacing between tabs/slots in Tab and Slot groups.
swTangencyType_e	Tangency options for lofts and profile twist options for sweeps.
swTangentArcTypes_e	Tangent arc types.
swTangentMagnitudeDirection_e	Tangent magnitude directions.
swTaperedTapCustomSizing_e	Custom sizing options for tapered tap elements of the Advanced Hole.
swTaperedTapThreadClass_e	Thread classes for tapered tap hole elements of the Advanced Hole.
swTaskPaneBitmapOptions_e	SOLIDWORKS standard Task Pane toolbar bitmap buttons .
swTaskPaneNotify_e	Task Pane notifications.
swTaskPaneTab_e	Task Pane tabs.
swTaskpaneViewStatus_e	Task Pane view statuses.
swTempBodySelectOptions_e	Temporary body selection options.
swTessellationMatchType_e	Tessellation match types.
swTextAlignmentVertical_e	Vertical text alignment options.
swTextInBoxStyle_e	Text in box styles.
swTextJustification_e	Text justifications options.
swTextPosition_e	Values for text reference point position types.
swTextSize_e	Toolbar text sizes.
swTextureRenderModes_e	Texture render modes.
swThickenDirection_e	Direction in which to thicken sheet bodies.
swThickenThicknessType_e	Thicken thickness directions.
swThinWallType_e	Thin wall types.
swThreadEndCondition_e	Thread end conditions.
swThreadMethod_e	Thread feature types.
swThreadMirrorType_e	Thread mirror profiles.
swTiffCompressionScheme_e	TIFF compression schemes.
swTiffImageType_e	TIFF image types.
swTolerances_e	Tolerance types.
swToleranceZoneModifier_e	Tolerance zone modifiers.
swTolType_e	Dimension tolerance types.
swToolbar_e	Toolbar identifiers.
swToolbarDockStatePosition_e	Toolbar docking positions.
swToolbarLayoutOption_e	Toolbar layout options for saving SOLIDWORKS settings.
swToolbarStates_e	Toolbar states.
swToolBoxPartType_e	Toolbox part types. Bitmask
swToolBoxPropertyName_e	Toolbox properties.
swTopoEntity_e	Types of topological entities.
swTopoBody_e	Types of bodies.
swTopoBodyTypes_e	Types of topology.
swTrackingIDError_e	Tracking ID errors.
swTranslationNotifyOptions_e	Translation notification options. Bitmask
swTransparencyState_e	Transparency states.
swTreeControlItemTypes_e	Tree control item types.
swTriadManipulatorControlPoints_e	Triad manipulator control points.
swTriadManipulatorDoNotShow_e	Triad manipulator visibility options. Bitmask
swTrimToolMemberObjectType_e	Structure system complex corner treatment trim tools.
swTwistControlType_e	Sweep twist control options.
swUIStates_e	User-interface state types.
swUnitsDecimalRounding_e	Rounding options for decimal units.
swUnitsEnergyUnit_e	Energy unit types.
swUnitsForce_e	Force units.
swUnitsMassPropMass_e	Mass property units.
swUnitsMassPropVolume_e	Mass property per unit volumes.
swUnitsPowerUnit_e	Types of power units.
swUnitsTimeUnit_e	Types of time units.
swUnitSystem_e	System units.
swUpdateProgressError_e	User progress errors.
swUserMessageBarResponseType_e	Types of user response controls for message bars.
swUserMessageBarSeverity_e	Types of severities for message bars.
swUserNotificationPosition_e	User notification display positions.
swUserNotificationResponseType_e	User response controls for user notifications.
swUserNotificationSeverity_e	User notification severities.
swUserPreferenceDoubleValue_e	User-preference enumerators for system options and document properties.
swUserPreferenceIntegerValue_e	User-preference enumerators for system options and document properties.
swUserPreferenceOption_e	User-preference enumerators for customizing document-level annotation, dimension, table, and view-label drafting standards.
swUserPreferenceLanguages_e	Supported FeatureManager design tree language translations.
swUserPreferenceStringListValue_e	User-preference enumerators for system options and document properties.
swUserPreferenceStringValue_e	User-preference enumerators for system options and document properties.
swUserPreferenceTextFormat_e	User-preference enumerators for system options and document properties.
swUserPreferenceToggle_e	User-preference enumerators for system options and document properties.
swUserUnitsType_e	User unit types.
swVariablePitchHelixRegionParameter_e	Parameters to modify in a variable-pitch helix.
swVariableRadiusFilletOptions_e	Variable radius fillet transition options.
swVersionCompatibilityResult_e	Results for file version compatibility checks.
swVerticalJustification_e	Dimension text vertical justifications.
swViewAlignment_e	Values for alignment of views.
swViewDisplayMode_e	View display modes.
swViewDisplayType_e	View display states.
swViewEntityType_e	View entity types.
swViewIndication_e	View indicators.
swViewNotify_e	Model view notifications.
swViewOrientationUpAxisFlyout_e	View orientation up axis flyout options.
swViewportDisplay_e	Viewport arrangements.
swVisibilityState_e	Visibility states.
swVrmOutputVersion_e	VRML output versions.
swWeldBeadSide_e	Weld bead sides.
swWeldBeadType_e	Weld bead types.
swWeldmentTrimExtendOptionType_e	Options for weldment trim extensions. Bitmask
swWeldSymbolContourTypes_e	Weld symbol contour types.
swWeldSymbolField_e	Field weld characteristics of weld symbols.
swWeldSymbolSymmetric_e	Symmetric characteristics of weld symbols.
swWeldSymbolTextTypes_e	Types of weld symbol text.

swWindowState_e	Window states.
swWitnessLineVisibility_e	Values for the visibility of extension lines.
swWrapMethods_e	Wrap feature methods.
swWrapSketchType_e	Wrap sketch types.
swWzdGeneralHoleTypes_e	General Hole Wizard types.
swWzdHoleCosmeticThreadTypes_e	Hole Wizard cosmetic thread types.
swWzdHoleCounterSinkHeadClearanceTypes_e	Hole Wizard countersink hole clearance types.
swWzdHoleHcoilTapTypes_e	Hole Wizard helicoil tap types.
swWzdHoleScrewClearanceTypes_e	Hole Wizard screw clearance types.
swWzdHoleStandardFastenerTypes_e	Hole Wizard standard fastener types.
swWzdHoleStandards_e	Hole Wizard standards.
swWzdHoleThreadEndCondition_e	Hole Wizard thread end conditions.
swWzdHoleTypes_e	Hole Wizard types.
swZeroQuantityDisplay_e	Characters or values to display when values are zero (0).
swZonalSectionViewZones_e	Intersection zones for section views. Bitmask
swZoneMargin_e	Zone margins.
swZoneSizeDistribution_e	Zone size distribution types.
swZoomLevelOnOpenType_e	Display zoom-to level when opening drawings.

 See Also

[SolidWorks.Interop.swconst Assembly](#)

sw3DExperienceCfgType_e (Type)

SOLIDWORKS API Enumerations

sw3DExperienceCfgType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : sw3DExperienceCfgType_e Enumeration

Types of configurations viewed in SOLIDWORKS Design connected to the 3DEXPERIENCE platform.

Syntax

Visual Basic (Declaration)

Public Enum sw3DExperienceCfgType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [sw3DExperienceCfgType_e](#)

C#

public enum sw3DExperienceCfgType_e : System.Enum

C++/CLI

public enum class sw3DExperienceCfgType_e : public System.Enum

Members

Member	Description
swNot3DExperienceType	0 = Default SOLIDWORKS configuration
swPhysicalProduct	1 = Family member
swRepresentation	2 = Break views, section view, or other representation of the Physical Product

See Also

[SolidWorks.Interop.swconst Namespace](#)

sw3DExperienceModelType_e (Type)

SOLIDWORKS API Enumerations

sw3DExperienceModelType_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : sw3DExperienceModelType_e Enumeration

Types of 3DEXPERIENCE component icons.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum sw3DExperienceModelType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [sw3DExperienceModelType_e](#)

C#

public enum sw3DExperienceModelType_e : System.Enum

C++/CLI

public enum class sw3DExperienceModelType_e : public System.Enum

Members

Member	Description
sw3DExperienceModelType_3DExperience	2
sw3DExperienceModelType_PartSupply	1
sw3DExperienceModelType_Standard	0 = SOLIDWORKS Desktop component icon
sw3DExperienceModelType_xCad	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

sw3DExperienceState_e (Type)

SOLIDWORKS API Enumerations

sw3DExperienceState_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : sw3DExperienceState_e Enumeration

SOLIDWORKS Design connected to the 3DEXPERIENCE platform states. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum sw3DExperienceState_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As sw3DExperienceState\_e
```

C#

```
public enum sw3DExperienceState_e : System.Enum
```

C++/CLI

```
public enum class sw3DExperienceState_e : public System.Enum
```

Members

Member	Description
sw3DExperienceState_None	0
sw3DExperienceState_Offline	2
sw3DExperienceState_Online	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

sw3DInterconnectImportErrors_e (Type)

SOLIDWORKS API Enumerations

sw3DInterconnectImportErrors_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : sw3DInterconnectImportErrors_e Enumeration

3D Interconnect import errors.

 Syntax

Visual Basic (Declaration)

Public Enum sw3DInterconnectImportErrors_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [sw3DInterconnectImportErrors_e](#)

C#

public enum sw3DInterconnectImportErrors_e : System.Enum

C++/CLI

public enum class sw3DInterconnectImportErrors_e : public System.Enum

 Members

Member	Description
sw3DInterconnectImportErrors_AssemblyNotSaved	3
sw3DInterconnectImportErrors_BreakLinkUnavailable	4 = Break link is not available for the selected 3D Interconnect feature; break link is only available for top-level assemblies
sw3DInterconnectImportErrors_Disabled	1 = 3D Interconnect is not enabled; to enable set Tools > Options > System Options > Import > Enable 3D Interconnect or call ISldWorks.SetUserPreferenceToggle(swUserPreferenceToggle_e.swMultiCAD_Enable3DInterconnect, True)
sw3DInterconnectImportErrors_IncompatibleType	2 = Specified file type is not correct
sw3DInterconnectImportErrors_None	0
sw3DInterconnectImportErrors_ParametersUnavailable	5 = Only top-level 3D Interconnect features can be edited
sw3DInterconnectImportErrors_TransferOptionNeeded	6 = One or more import options need to be specified for this import

 See Also

[SolidWorks.Interop.swconst Namespace](#)

sw3DPDFAccuracy_e (Type)

SOLIDWORKS API Enumerations

sw3DPDFAccuracy_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : sw3DPDFAccuracy_e Enumeration

Levels of SOLIDWORKS MBD 3D PDF accuracies

 Syntax

Visual Basic (Declaration)

Public Enum sw3DPDFAccuracy_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [sw3DPDFAccuracy_e](#)

 [Copy Code](#)

C#

public enum sw3DPDFAccuracy_e : System.Enum

C++/CLI

public enum class sw3DPDFAccuracy_e : public System.Enum

 Members

Member	Description
swHigh	2
swLow	0
swMaximum	3
swMedium	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

sw3DPMISaveOptions_e (Type)

SOLIDWORKS API Enumerations

sw3DPMISaveOptions_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : sw3DPMISaveOptions_e Enumeration

3D PMI (Product and Manufacturing Information) save options when comparing two different versions of the same model. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

Public Enum sw3DPMISaveOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [sw3DPMISaveOptions_e](#)



C#

public enum sw3DPMISaveOptions_e : System.Enum

C++/CLI

public enum class sw3DPMISaveOptions_e : public System.Enum

 Members

Member	Description
swAddReportToDesignBinder	1 or 0x1
swDimXpertData	4 or 0x4
swReferenceData	8 or 0x8
swViewReportOnSave	2 or 0x2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAcisOutputGeometryPreference_e (Type)

SOLIDWORKS API Enumerations

swAcisOutputGeometryPreference_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swAcisOutputGeometryPreference_e Enumeration

ACIS output geometry types.

Syntax

Visual Basic (Declaration)

```
Public Enum swAcisOutputGeometryPreference_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAcisOutputGeometryPreference\_e
```

C#

```
public enum swAcisOutputGeometryPreference_e : System.Enum
```

C++/CLI

```
public enum class swAcisOutputGeometryPreference_e : public System.Enum
```

Members

Member	Description
swAcisOutputAs3DCurves	1 = 3D curves without export sketch entities
swAcisOutputAs3DCurves_IncludeSketchEnts	2 = 3D curves with export sketch entities
swAcisOutputAsSolidAndSurface	0 = Solid/surface geometry

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAcisOutputVersion_e (Type)

SOLIDWORKS API Enumerations

swAcisOutputVersion_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swAcisOutputVersion_e Enumeration

ACIS output versions.

Syntax

Visual Basic (Declaration)

```
Public Enum swAcisOutputVersion_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAcisOutputVersion\_e
```

C#

```
public enum swAcisOutputVersion_e : System.Enum
```

C++/CLI

```
public enum class swAcisOutputVersion_e : public System.Enum
```

Members

Member	Description
swAcisOutputVersion_100	10
swAcisOutputVersion_110	11
swAcisOutputVersion_120	12
swAcisOutputVersion_130	13
swAcisOutputVersion_140	14
swAcisOutputVersion_150	15
swAcisOutputVersion_16	0
swAcisOutputVersion_160	16
swAcisOutputVersion_17	1
swAcisOutputVersion_170	17
swAcisOutputVersion_180	18
swAcisOutputVersion_190	19
swAcisOutputVersion_20	2
swAcisOutputVersion_200	20
swAcisOutputVersion_21	3
swAcisOutputVersion_210	21
swAcisOutputVersion_220	22
swAcisOutputVersion_270	23
swAcisOutputVersion_30	4
swAcisOutputVersion_330	24
swAcisOutputVersion_40	5
swAcisOutputVersion_50	6
swAcisOutputVersion_60	7
swAcisOutputVersion_70	8
swAcisOutputVersion_80	9

See Also

[SolidWorks.Interop.swconst Namespace](#)

swActivateDocError_e (Type)

SOLIDWORKS API Enumerations

swActivateDocError_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swActivateDocError_e Enumeration

Document activation errors. Bitmask.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swActivateDocError_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swActivateDocError_e](#)

C#

public enum swActivateDocError_e : System.Enum

C++/CLI

public enum class swActivateDocError_e : public System.Enum

Members

Member	Description
swDocNeedsRebuildWarning	2 or 0x2: The document that was activated needs to be rebuilt (your application can use EditRebuild on the PartDoc, AssemblyDoc, or DrawingDoc to perform the rebuild).
swGenericActivateError	1 or 0x1: An unspecified error was encountered, and the document was not activated.

Remarks

Bitmask

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAddComponentConfigOptions_e (Type)

SOLIDWORKS API Enumerations

swAddComponentConfigOptions_e Enumeration

See Also Example

 ▼

[SolidWorks.Interop.swconst Namespace](#) : swAddComponentConfigOptions_e Enumeration

Options for adding components to an assembly.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAddComponentConfigOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAddComponentConfigOptions\_e
```

C#

```
public enum swAddComponentConfigOptions_e : System.Enum
```

C++/CLI

```
public enum class swAddComponentConfigOptions_e : public System.Enum
```

Members

Member	Description
swAddComponentConfigOptions_CurrentSelectedConfig	0 = Add a part or assembly in its last saved configuration. (See AssemblyDoc::AddComponent5)
swAddComponentConfigOptions_NewConfigWithAllReferenceModels	1 = Add an assembly with all of its components resolved. (See AssemblyDoc::AddComponent5)
swAddComponentConfigOptions_NewConfigWithAsmStructure	2 = Add an assembly with all of its components suppressed. (See AssemblyDoc::AddComponent5)

Example

[Add Component and Mate \(VBA\)](#)
[Add Component and Mate \(VB.NET\)](#)
[Add Component and Mate \(C#\)](#)

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAddControlOptions_e (Type)

SOLIDWORKS API Enumerations

swAddControlOptions_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAddControlOptions_e Enumeration

Options for PropertyManager page, group box, and tab controls. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

Public Enum swAddControlOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAddControlOptions_e](#)



C#

public enum swAddControlOptions_e : System.Enum

C++/CLI

public enum class swAddControlOptions_e : public System.Enum

 Members

Member	Description
swControlOptions_Enabled	2 or 0x2
swControlOptions_SmallGapAbove	4 or 0x4
swControlOptions_Visible	1 or 0x1

 Remarks

Bitmask

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAddGroupBoxOptions_e (Type)

SOLIDWORKS API Enumerations

swAddGroupBoxOptions_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAddGroupBoxOptions_e Enumeration

PropertyManager page group box and tab controls. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

```
Public Enum swAddGroupBoxOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swAddGroupBoxOptions\_e
```

C#

```
public enum swAddGroupBoxOptions_e : System.Enum
```

C++/CLI

```
public enum class swAddGroupBoxOptions_e : public System.Enum
```

 Members

Member	Description
swGroupBoxOptions_Checkbox	1 or 0x1
swGroupBoxOptions_Checked	2 or 0x2
swGroupBoxOptions_Expanded	8 or 0x8
swGroupBoxOptions_Visible	4 or 0x4

 Remarks

Bitmask

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAddinBrokerBBoxOption_e (Type)

SOLIDWORKS API Enumerations

swAddinBrokerBBoxOption_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAddinBrokerBBoxOption_e Enumeration

Bounding box options. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swAddinBrokerBBoxOption_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swAddinBrokerBBoxOption\_e
```

C#

```
public enum swAddinBrokerBBoxOption_e : System.Enum
```

C++/CLI

```
public enum class swAddinBrokerBBoxOption_e : public System.Enum
```

 Members

Member	Description
swAddinBrokerBBoxOption_Default	0 or 0x0; Placeholder for future use

 Remarks

Bitmask

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAdditionalSymbol_e (Type)

SOLIDWORKS API Enumerations

swAdditionalSymbol_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAdditionalSymbol_e Enumeration

Additional symbols in Gtol frame boxes.

 Syntax

Visual Basic (Declaration)

```
Public Enum swAdditionalSymbol_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAdditionalSymbol\_e
```

C#

```
public enum swAdditionalSymbol_e : System.Enum
```

C++/CLI

```
public enum class swAdditionalSymbol_e : public System.Enum
```

 Members

Member	Description
swAdditionalSymbol_FreeState	3
swAdditionalSymbol_MaximumUpperTolerance	5
swAdditionalSymbol_MinimumLowerTolerance	6
swAdditionalSymbol_None	0
swAdditionalSymbol_Statistical	4
swAdditionalSymbol_TangentPlane	2
swAdditionalSymbol_Unknown	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAddMateError_e (Type)

SOLIDWORKS API Enumerations

swAddMateError_e Enumeration

See Also

Send comments on this topic.

 SolidWorks.Interop.swconst Namespace : swAddMateError_e Enumeration

Status after adding or editing a mate.

 Syntax

Visual Basic (Declaration)

Public Enum swAddMateError_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAddMateError_e](#)

C#

public enum swAddMateError_e : System.Enum

C++/CLI

public enum class swAddMateError_e : public System.Enum

 Members

Member	Description
swAddMateError_ErrorUnknown	0 = Unknown error occurred
swAddMateError_IncorrectAlignment	3 = Unknown mate alignment or mate alignment is not present in swMateAlign_e
swAddMateError_IncorrectGearRatios	6 = Mate gear ratios are invalid
swAddMateError_IncorrectMateType	2 = Unknown mate type or mate type not present in swMateType_e
swAddMateError_IncorrectSelections	4 = Incorrect selections for mate
swAddMateError_NoError	1 = Success, no error
swAddMateError_OverDefinedAssembly	5 = Mate is over-defining the assembly

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAddOrdinateDims_e (Type)

SOLIDWORKS API Enumerations

swAddOrdinateDims_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swAddOrdinateDims_e Enumeration

Types of ordinate dimensions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swAddOrdinateDims_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAddOrdinateDims_e](#)

C#

public enum swAddOrdinateDims_e : System.Enum

C++/CLI

public enum class swAddOrdinateDims_e : public System.Enum

Members

Member	Description
swAngularOrdinate	4 = Angular ordinate dimension
swHorizontalOrdinate	3 = Horizontal ordinate dimension
swOrdinate	1 = Type of ordinate dimension (horizontal or vertical) is defined by the orientation of the selected points
swVerticalOrdinate	2 = Vertical ordinate dimension

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAddSpecificDimension_e (Type)

SOLIDWORKS API Enumerations

swAddSpecificDimension_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAddSpecificDimension_e Enumeration

Status after adding a specific dimension.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAddSpecificDimension_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAddSpecificDimension\_e
```

C#

```
public enum swAddSpecificDimension_e : System.Enum
```

C++/CLI

```
public enum class swAddSpecificDimension_e : public System.Enum
```

Members

Member	Description
swAddSpecificDimension_DimTypeMismatch	1
swAddSpecificDimension_Success	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAddToRecentDocumentList_e (Type)

SOLIDWORKS API Enumerations

swAddToRecentDocumentList_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAddToRecentDocumentList_e Enumeration

Recent Documents list actions for a document opened using [ISldWorks::OpenDoc7](#) and [IDocumentSpecification::AddToRecentDocumentList](#).

 Syntax

Visual Basic (Declaration)

Public Enum swAddToRecentDocumentList_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swAddToRecentDocumentList_e](#)

C#

public enum swAddToRecentDocumentList_e : System.Enum

C++/CLI

public enum class swAddToRecentDocumentList_e : public System.Enum

 Members

Member	Description
swAddToRecentDocumentList_Add	1
swAddToRecentDocumentList_Default	0 = Default OpenDoc7 action: if a configuration is specified, the document is not added to the Recent Documents list; if a configuration is not specified, the document is added
swAddToRecentDocumentList_DontAdd	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAdvancedHoleResults_e (Type)

SOLIDWORKS API Enumerations

swAdvancedHoleResults_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swAdvancedHoleResults_e Enumeration

Result codes for Advanced Hole.

 Syntax

Visual Basic (Declaration)

```
Public Enum swAdvancedHoleResults_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swAdvancedHoleResults\_e
```

C#

```
public enum swAdvancedHoleResults_e : System.Enum
```

C++/CLI

```
public enum class swAdvancedHoleResults_e : public System.Enum
```

 Members

Member	Description
swAdvancedHoleResults_FailedIncorrectHoleElementParameters	1
swAdvancedHoleResults_Success	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAdvSelectType_e (Type)

SOLIDWORKS API Enumerations

swAdvSelectType_e Enumeration

See Also

  : swAdvSelectType_e Enumeration

Conditions of criteria for advanced component selection list. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAdvSelectType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAdvSelectType\_e
```

C#

```
public enum swAdvSelectType_e : System.Enum
```

C++/CLI

```
public enum class swAdvSelectType_e : public System.Enum
```

Members

Member	Description
swAdvSelectType_And	1 or 0x1
swAdvSelectType_Contains	16 or 0x10
swAdvSelectType_Does_Not_Interferes_With	128 or 0x80
swAdvSelectType_Equals	4096 or 0x1000
swAdvSelectType_Greater_Than	256 or 0x100
swAdvSelectType_Greater_Than_OR_Equal	1024 or 0x400
swAdvSelectType_Interferes_With	64 or 0x40
swAdvSelectType_Is_Contained_By	32 or 0x20
swAdvSelectType_Is_Exactly	4 or 0x4
swAdvSelectType_Is_No	32768 or 0x8000
swAdvSelectType_Is_Not	8 or 0x8
swAdvSelectType_Is_Not_Equal	8192 or 0x2000
swAdvSelectType_Is_Yes	16384 or 0x4000
swAdvSelectType_Less_Than	512 or 0x200
swAdvSelectType_Less_Than_OR_Equal	2048 or 0x800
swAdvSelectType_Or	2 or 0x2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAdvWzdGeneralHoleTypes_e (Type)

SOLIDWORKS API Enumerations

swAdvWzdGeneralHoleTypes_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swAdvWzdGeneralHoleTypes_e Enumeration

Advanced Hole element types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swAdvWzdGeneralHoleTypes_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAdvWzdGeneralHoleTypes_e](#)

 [Copy Code](#)

C#

public enum swAdvWzdGeneralHoleTypes_e : System.Enum

C++/CLI

public enum class swAdvWzdGeneralHoleTypes_e : public System.Enum

 Members

Member	Description
swAdvWzdCounterBore	0
swAdvWzdCounterSink	1
swAdvWzdStraight	2
swAdvWzdStraightTap	3
swAdvWzdTaperTap	4

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAlignDimensionType_e (Type)

SOLIDWORKS API Enumerations

swAlignDimensionType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAlignDimensionType_e Enumeration

Align dimension types.

Syntax

Visual Basic (Declaration)

```
Public Enum swAlignDimensionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAlignDimensionType\_e
```

C#

```
public enum swAlignDimensionType_e : System.Enum
```

C++/CLI

```
public enum class swAlignDimensionType_e : public System.Enum
```

Members

Member	Description
swAlignDimensionType_AutoArrange	0
swAlignDimensionType_BottomAlignText	5
swAlignDimensionType_Colinear	2
swAlignDimensionType_LeftAlignText	6
swAlignDimensionType_RightAlignText	7
swAlignDimensionType_SpaceEvenly	1
swAlignDimensionType_Stagger	3
swAlignDimensionType_TopAlignText	4

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAlignDrawingViewTypes_e (Type)

SOLIDWORKS API Enumerations

swAlignDrawingViewTypes_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swAlignDrawingViewTypes_e Enumeration

Types of auxiliary drawing view alignment.

Syntax

Visual Basic (Declaration)

```
Public Enum swAlignDrawingViewTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAlignDrawingViewTypes\_e
```

C#

```
public enum swAlignDrawingViewTypes_e : System.Enum
```

C++/CLI

```
public enum class swAlignDrawingViewTypes_e : public System.Enum
```

Members

Member	Description
swDefaultAlignment	2
swHorizontalToSheetClockwise	0
swHorizontalToSheetCounterclockwise	1
swProjectedAngle	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAlignViewTypes_e (Type)

SOLIDWORKS API Enumerations

swAlignViewTypes_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swAlignViewTypes_e Enumeration

View alignments.

 Syntax

Visual Basic (Declaration)

```
Public Enum swAlignViewTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swAlignViewTypes\_e
```

C#

```
public enum swAlignViewTypes_e : System.Enum
```

C++/CLI

```
public enum class swAlignViewTypes_e : public System.Enum
```

 Members

Member	Description
swAlignViewHorizontalCenter	2 = Align this view horizontally with the center of BaseView
swAlignViewHorizontalOrigin	4 = Align this view horizontally with the origin of BaseView
swAlignViewVerticalCenter	3 = Align this view vertically with BaseView
swAlignViewVerticalOrigin	5 = Align this view vertically with the origin of BaseView
swDefaultViewAlignment	1 = Set the alignment of this view to its default
swNoViewAlignment	0 = Remove the alignment restriction on this view

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAngleUnit_e (Type)

SOLIDWORKS API Enumerations

swAngleUnit_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swAngleUnit_e Enumeration

Angle unit types.

 Syntax

Visual Basic (Declaration)

Public Enum swAngleUnit_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swAngleUnit_e](#)

C#

public enum swAngleUnit_e : System.Enum

C++/CLI

public enum class swAngleUnit_e : public System.Enum

 Members

Member	Description
swDEG_MIN	1
swDEG_MIN_SEC	2
swDEGREES	0
swRADIANS	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAngularEquationUnits_e (Type)

SOLIDWORKS API Enumerations

swAngularEquationUnits_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAngularEquationUnits_e Enumeration

Angular units used in equations.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swAngularEquationUnits_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAngularEquationUnits_e](#)



C#

public enum swAngularEquationUnits_e : System.Enum

C++/CLI

public enum class swAngularEquationUnits_e : public System.Enum

 Members

Member	Description
swAngularEquationUnitsDegrees	1
swAngularEquationUnitsRadians	2
swAngularEquationUnitsUnrecognized	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAnimationOutputType_e (Type)

SOLIDWORKS API Enumerations

swAnimationOutputType_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swAnimationOutputType_e Enumeration

Animation output type.

 Syntax

Visual Basic (Declaration)

```
Public Enum swAnimationOutputType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swAnimationOutputType\_e
```

C#

```
public enum swAnimationOutputType_e : System.Enum
```

C++/CLI

```
public enum class swAnimationOutputType_e : public System.Enum
```

 Members

Member	Description
swAnimationOutput_AVI	1 = Microsoft AVI file (.avi)
swAnimationOutput_Series_of_BMP	2 = Series of Windows Bitmaps (.bmp)
swAnimationOutput_Series_of_FLV	9 = Flash video file
swAnimationOutput_Series_of_JPG	5
swAnimationOutput_Series_of_LXO	10 = Luxology scene file
swAnimationOutput_Series_of_MKV	8 = Matroska video file
swAnimationOutput_Series_of_MP4	7
swAnimationOutput_Series_of_PNG	4
swAnimationOutput_Series_of_TGA	3 = Series of Truevision Targas (.tga)
swAnimationOutput_Series_of_TIF	6

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAnimationPlayMode_e (Type)

SOLIDWORKS API Enumerations

swAnimationPlayMode_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swAnimationPlayMode_e Enumeration

Modes to play animations.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swAnimationPlayMode_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAnimationPlayMode_e](#)

C#

public enum swAnimationPlayMode_e : System.Enum

C++/CLI

public enum class swAnimationPlayMode_e : public System.Enum

Members

Member	Description
swAnimationPlayModeLoop	2 = Play from beginning to end, from beginning to end, etc.
swAnimationPlayModeNormal	1 = Play from beginning to end once.
swAnimationPlayModeReciprocate	3 = Play from beginning to end, from end to beginning, beginning to end, etc.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAnimationPlaySpeed_e (Type)

SOLIDWORKS API Enumerations

swAnimationPlaySpeed_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAnimationPlaySpeed_e Enumeration

Speeds to play animations.

 Syntax

Visual Basic (Declaration)

Public Enum swAnimationPlaySpeed_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swAnimationPlaySpeed_e](#)

C#

public enum swAnimationPlaySpeed_e : System.Enum

C++/CLI

public enum class swAnimationPlaySpeed_e : public System.Enum

 Members

Member	Description
swAnimationPlaySpeedFast	3
swAnimationPlaySpeedNormal	1
swAnimationPlaySpeedSlow	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAnimatorAxisOfRotation_e (Type)

SOLIDWORKS API Enumerations

swAnimatorAxisOfRotation_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAnimatorAxisOfRotation_e Enumeration

Animation axis of rotation.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAnimatorAxisOfRotation_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAnimatorAxisOfRotation\_e
```

C#

```
public enum swAnimatorAxisOfRotation_e : System.Enum
```

C++/CLI

```
public enum class swAnimatorAxisOfRotation_e : public System.Enum
```

Members

Member	Description
swRotationAboutXAxis	0 = About x axis
swRotationAboutYAxis	1 = About y axis
swRotationAboutZAxis	2 = About z axis

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAnimatorDirectionOfRotation_e (Type)

SOLIDWORKS API Enumerations

swAnimatorDirectionOfRotation_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swAnimatorDirectionOfRotation_e Enumeration

Animation direction of rotation

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAnimatorDirectionOfRotation_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swAnimatorDirectionOfRotation\_e
```

C#

```
public enum swAnimatorDirectionOfRotation_e : System.Enum
```

C++/CLI

```
public enum class swAnimatorDirectionOfRotation_e : public System.Enum
```

Members

Member	Description
swRotationClockwise	0 = Clockwise
swRotationCounterClockwise	1 = Counter-clockwise

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAnnotationOwner_e (Type)

SOLIDWORKS API Enumerations

swAnnotationOwner_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAnnotationOwner_e Enumeration

Types of owners of annotations.

Syntax

Visual Basic (Declaration)

```
Public Enum swAnnotationOwner_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAnnotationOwner\_e
```

C#

```
public enum swAnnotationOwner_e : System.Enum
```

C++/CLI

```
public enum class swAnnotationOwner_e : public System.Enum
```

Members

Member	Description
swAnnotationOwner_Assembly	4
swAnnotationOwner_DrawingSheet	1
swAnnotationOwner_DrawingTemplate	2
swAnnotationOwner_DrawingView	0
swAnnotationOwner_Part	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAnnotationType_e (Type)

SOLIDWORKS API Enumerations

swAnnotationType_e Enumeration

See Also

[Send comments on this topic.](#)

[SolidWorks.Interop.swconst Namespace](#) : swAnnotationType_e Enumeration

Annotation types.

Syntax

Visual Basic (Declaration)

```
Public Enum swAnnotationType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAnnotationType\_e
```

C#

```
public enum swAnnotationType_e : System.Enum
```

C++/CLI

```
public enum class swAnnotationType_e : public System.Enum
```

Members

Member	Description
swBlock	12
swCenterLine	15
swCenterMarkSym	13
swCThread	1
swCustomSymbol	9
swDatumOrigin	16
swDatumTag	2
swDatumTargetSym	3
swDisplayDimension	4
swDowelSym	10
swGTol	5
swLeader	11
swNote	6
swPMIOnly	19
swRevisionCloud	18
swSFSymbol	7
swTableAnnotation	14
swWeldBeadSymbol	17
swWeldSymbol	8

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAnnotationVisibilityState_e (Type)

SOLIDWORKS API Enumerations

swAnnotationVisibilityState_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swAnnotationVisibilityState_e Enumeration

Annotation visibility states.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swAnnotationVisibilityState_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAnnotationVisibilityState_e](#)

C#

public enum swAnnotationVisibilityState_e : System.Enum

C++/CLI

public enum class swAnnotationVisibilityState_e : public System.Enum

 Members

Member	Description
swAnnotationHalfHidden	2 = Annotation is half-hidden (grayed out) or hidden depending on the interactive user's actions. For example, if the annotation's visibility is set to swAnnotationHalfHidden by Annotation.Visible , then that annotation is in a half-hidden state, which is not a permanent state. During a Hide/Show Annotations operation in a drawing, a half-hidden annotation is displayed in gray if the interactive user selects to show all annotations. Any annotation set to swAnnotationHalfHidden is hidden when the interactive user finishes using Hide/Show Annotations .
swAnnotationHidden	3 = Annotation is hidden
swAnnotationVisibilityUnknown	0 = Annotation visibility is not known
swAnnotationVisible	1 = Annotation is visible

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swApiHoleWizardItemExportStatus_e (Type)

SOLIDWORKS API Enumerations

swApiHoleWizardItemExportStatus_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swApiHoleWizardItemExportStatus_e Enumeration

Return codes for Advanced Hole Wizard item export.

Syntax

Visual Basic (Declaration)

```
Public Enum swApiHoleWizardItemExportStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swApiHoleWizardItemExportStatus\_e
```

C#

```
public enum swApiHoleWizardItemExportStatus_e : System.Enum
```

C++/CLI

```
public enum class swApiHoleWizardItemExportStatus_e : public System.Enum
```

Members

Member	Description
swApiHoleWizardItemExportStatus_InvalidArgument	1
swApiHoleWizardItemExportStatus_MicrosoftExcelNotInstalled	2
swApiHoleWizardItemExportStatus_Success	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swApiHoleWizardItemImportStatus_e (Type)

SOLIDWORKS API Enumerations

swApiHoleWizardItemImportStatus_e Enumeration

[Send comments on this topic.](#)

[See Also](#)



[SolidWorks.Interop.swconst Namespace](#) : swApiHoleWizardItemImportStatus_e Enumeration

Return codes for Advanced Hole Wizard item import.

Syntax

Visual Basic (Declaration)

```
Public Enum swApiHoleWizardItemImportStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swApiHoleWizardItemImportStatus\_e
```

C#

```
public enum swApiHoleWizardItemImportStatus_e : System.Enum
```

C++/CLI

```
public enum class swApiHoleWizardItemImportStatus_e : public System.Enum
```

Members

Member	Description
swApiHoleWizardItemImportStatus_DataError	7
swApiHoleWizardItemImportStatus_ExcelCouldNotOpenFile	4
swApiHoleWizardItemImportStatus_ExcelSheetNameError	5
swApiHoleWizardItemImportStatus_FailedToSaveFile	3
swApiHoleWizardItemImportStatus_FailedToSaveReportFile	6
swApiHoleWizardItemImportStatus_InvalidArgument	1
swApiHoleWizardItemImportStatus_MicrosoftExcelNotInstalled	2
swApiHoleWizardItemImportStatus_Success	0
swApiHoleWizardItemImportStatus_UnspecifiedError	8

See Also

[SolidWorks.Interop.swconst Namespace](#)

swApiToolboxItemExportStatus_e (Type)

SOLIDWORKS API Enumerations

swApiToolboxItemExportStatus_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swApiToolboxItemExportStatus_e Enumeration

Return codes for toolbox item export.

Syntax

Visual Basic (Declaration)

```
Public Enum swApiToolboxItemExportStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swApiToolboxItemExportStatus\_e
```

C#

```
public enum swApiToolboxItemExportStatus_e : System.Enum
```

C++/CLI

```
public enum class swApiToolboxItemExportStatus_e : public System.Enum
```

Members

Member	Description
swApiToolboxItemExportStatus_FailedToSaveFile	3
swApiToolboxItemExportStatus_InvalidArgument	1
swApiToolboxItemExportStatus_InvalidPartNumber	4
swApiToolboxItemExportStatus_MicrosoftExcelNotInstalled	2
swApiToolboxItemExportStatus_Success	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swApiToolboxItemImportStatus_e (Type)

SOLIDWORKS API Enumerations

swApiToolboxItemImportStatus_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swApiToolboxItemImportStatus_e Enumeration

Return codes for toolbox item import.

Syntax

Visual Basic (Declaration)

```
Public Enum swApiToolboxItemImportStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swApiToolboxItemImportStatus\_e
```

C#

```
public enum swApiToolboxItemImportStatus_e : System.Enum
```

C++/CLI

```
public enum class swApiToolboxItemImportStatus_e : public System.Enum
```

Members

Member	Description
swApiToolboxItemImportStatus_ExcelCouldNotOpenFile	6
swApiToolboxItemImportStatus_ExcelImportDidNotFindColumn	4
swApiToolboxItemImportStatus_ExcelImportWrongFile	5
swApiToolboxItemImportStatus_FailedToSaveFile	3
swApiToolboxItemImportStatus_FailedUnspecifiedError	8
swApiToolboxItemImportStatus_InvalidArgument	1
swApiToolboxItemImportStatus_InvalidPartNumber	7
swApiToolboxItemImportStatus_MicrosoftExcelNotInstalled	2
swApiToolboxItemImportStatus_Success	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAppCallbackCmd_e (Type)

SOLIDWORKS API Enumerations

swAppCallbackCmd_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swAppCallbackCmd_e Enumeration

Types of application callback functions.

 Syntax

Visual Basic (Declaration)

Public Enum swAppCallbackCmd_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swAppCallbackCmd_e](#)

C#

public enum swAppCallbackCmd_e : System.Enum

C++/CLI

public enum class swAppCallbackCmd_e : public System.Enum

 Members

Member	Description
swAppHelpContext	3 = Not used
swAppIsCmdEnabled	4 = CommandGroup item is enabled
swAppIsNewCmd	1 = True if data is new, false if not
swAppPostNotifyEvent	5 = Your application is posting a callback to the SOLIDWORKS message queue that will be invoked when the callback is processed in the SOLIDWORKS message queue
swAppWhatsNewDescription	2 = Interactive What's New

 Remarks

Use with [ISldWorks::AddCallback](#).

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAppearanceSurfaceFinishShaderTypes_e (Type)

SOLIDWORKS API Enumerations

swAppearanceSurfaceFinishShaderTypes_e Enumeration

See Also

[Send comments on this topic.](#)

SolidWorks.Interop.swconst Namespace : swAppearanceSurfaceFinishShaderTypes_e Enumeration

Types of surface finish shaders.

Syntax

Visual Basic (Declaration)

```
Public Enum swAppearanceSurfaceFinishShaderTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAppearanceSurfaceFinishShaderTypes\_e
```

C#

```
public enum swAppearanceSurfaceFinishShaderTypes_e : System.Enum
```

C++/CLI

```
public enum class swAppearanceSurfaceFinishShaderTypes_e : public System.Enum
```

Members

Member	Description
swAppearanceSurfaceFinishShaderType_Brushed	3
swAppearanceSurfaceFinishShaderType_Burnished	4
swAppearanceSurfaceFinishShaderType_Cast	5
swAppearanceSurfaceFinishShaderType_ChainLink	11
swAppearanceSurfaceFinishShaderType_CircularHoleMesh	18
swAppearanceSurfaceFinishShaderType_CustomHoleMesh	19
swAppearanceSurfaceFinishShaderType_DefaultColor	0
swAppearanceSurfaceFinishShaderType_DiamondHoleMesh	17
swAppearanceSurfaceFinishShaderType_DiamondTreadplate	15
swAppearanceSurfaceFinishShaderType_Dimpled	10
swAppearanceSurfaceFinishShaderType_FromFile	2
swAppearanceSurfaceFinishShaderType_Knurled	8
swAppearanceSurfaceFinishShaderType_Machined	7
swAppearanceSurfaceFinishShaderType_None	1
swAppearanceSurfaceFinishShaderType_Rough1	13
swAppearanceSurfaceFinishShaderType_Rough2	14
swAppearanceSurfaceFinishShaderType_Sandblasted	12
swAppearanceSurfaceFinishShaderType_Treadplate1	9
swAppearanceSurfaceFinishShaderType_Treadplate2	16
swAppearanceSurfaceFinishShaderType_Undefined	20
swAppearanceSurfaceFinishShaderType_Wrought	6

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAppearanceTargetType_e (Type)

SOLIDWORKS API Enumerations

swAppearanceTargetType_e Enumeration

See Also

Send comments on this topic.

▼

[SolidWorks.Interop.swconst Namespace](#) : swAppearanceTargetType_e Enumeration

Types of targets to which to apply a copied appearance.

Syntax

Visual Basic (Declaration)

```
Public Enum swAppearanceTargetType_e
    Inherits System.Enum
```

Visual Basic (Usage) Copy Code

```
Dim instance As swAppearanceTargetType\_e
```

C#

```
public enum swAppearanceTargetType_e : System.Enum
```

C++/CLI

```
public enum class swAppearanceTargetType_e : public System.Enum
```

Members

Member	Description
swAppearanceTargetAppearanceFilter	5 = All appearances in the model that match the appearance of the selected face are applied the copied appearance
swAppearanceTargetBody	2 = The body of the selected face is applied the copied appearance
swAppearanceTargetComponent	4 = The component of the selected face is applied the copied appearance
swAppearanceTargetFace	0 = The selected face is applied the copied appearance
swAppearanceTargetFeature	1 = The feature of the selected face is applied the copied appearance
swAppearanceTargetPart	3 = The part of the selected face is applied the copied appearance

See Also

[SolidWorks.Interop.swconst Namespace](#)

swApplicationType_e (Type)

SOLIDWORKS API Enumerations

swApplicationType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swApplicationType_e Enumeration

Types of SOLIDWORKS application.

 Syntax

Visual Basic (Declaration)

Public Enum swApplicationType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swApplicationType_e](#)



C#

public enum swApplicationType_e : System.Enum

C++/CLI

public enum class swApplicationType_e : public System.Enum

 Members

Member	Description
swApplicationType_3DEXPERIENCE	1
swApplicationType_Desktop	0 = SOLIDWORKS Design
swApplicationType_WithConnector	2 = SOLIDWORKS Design connected to the 3DEXPERIENCE platform

 See Also

[SolidWorks.Interop.swconst Namespace](#)