

SOLIDWORKS Enumerations (swconst) — Reference (2/17): swAppNotify_e- swBOMConfigurationWhatToShow_e

SOLIDWORKS API Documentation (converted from CHM)

swAppNotify_e (Type)

SOLIDWORKS API Enumerations

swAppNotify_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swAppNotify_e Enumeration

Application notifications.

Send comments on this topic.

Syntax

Visual Basic (Declaration)

```
Public Enum swAppNotify_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAppNotify_e
```

C#

```
public enum swAppNotify_e : System.Enum
```

C++/CLI

```
public enum class swAppNotify_e : public System.Enum
```

Members

Member	Description
swAppActiveDocChangeNotify	4 = ActiveDocChangeNotify
swAppActiveModelDocChangeNotify	5 = ActiveModelDocChangeNotify
swAppBackgroundProcessingEndNotify	34 = BackgroundProcessingEndNotify
swAppBackgroundProcessingStartNotify	33 = BackgroundProcessingStartNotify
swAppBegin3DInterconnectTranslationNotify	37 = Begin3DInterconnectTranslationNotify
swAppBeginRecordNotify	24 = Not used.
swAppBeginTranslationNotify	16 = BeginTranslationNotify
swAppCommandCloseNotify	29 = CommandCloseNotify
swAppCommandOpenPreNotify	31 = CommandOpenPreNotify
swAppDestroyNotify	3 = DestroyNotify
swAppDisplayPaneActivationNotify	45 = DisplayPaneActivationNotify
swAppDocumentConversionNotify	9 = DocumentConversionNotify
swAppDocumentLoadNotify	27 = Obsolete
swAppDocumentLoadNotify2	28 = DocumentLoadNotify2
swAppEnd3DInterconnectTranslationNotify	38 = End3DInterconnectTranslationNotify
swAppEndRecordNotify	25 = Not used.
swAppEndTranslationNotify	16 = EndTranslationNotify
swAppFileCloseNotify	32 = FileCloseNotify
swAppFileNewNotify	2 = Obsolete
swAppFileNewNotify2	12 = FileNewNotify2
NOTE: Because it is possible to have a NULL active document when an add-in is notified using swAppFileOpenNotify2, use ISldWorks::IGetOpenDocumentByName2 instead of ISldWorks::IActiveDoc2 .	
swAppFileNewPreNotify	26 = FileNewPreNotify
swAppFileOpenNotify	1 = Obsolete
swAppFileOpenNotify2	13 = FileOpenNotify2
swAppFileOpenPostNotify	22 = FileOpenPostNotify
swAppFileOpenPreNotify	21 = FileOpenPreNotify
swAppInterfaceBrightnessThemeChangeNotify	35 = InterfaceBrightnessThemeChangeNotify
swAppJournalWriteNotify	27 = Not used.
swAppLightPMCreateNotify	Not used.
swAppLightSheetCreateNotify	18 = LightSheetCreateNotify
swAppLightweightComponentOpenNotify	10 = Not used.
swAppNonNativeFileOpenNotify	7 = NonNativeFileOpenNotify
swAppOn3DExperienceStateChangeNotify	46 = On3DExperienceStateChangeNotify
swAppOnIdleNotify	20 = OnIdleNotify
swAppPromptForFilenameNotify	15 = PromptForFilenameNotify
swAppPromptForMultipleFileNamesNotify	30 = PromptForMultipleFileNamesNotify
swAppPropertySheetCreateNotify	6 = PropertySheetCreateNotify
swAppReferencedFilePreNotify	23 = ReferencedFilePreNotify
swAppReferencedFilePreNotify2	36 = ReferencedFilePreNotify2
swAppReferenceNotFoundNotify	14 = ReferenceNotFoundNotify
swAppStandardsDatabaseChangeNotify	19 = Not used.
swAppTaskPaneCollapseNotify	44 = TaskPaneCollapseNotify
swAppTaskPaneExpandNotify	43 = TaskPaneExpandNotify
swAppTaskPaneHideNotify	41 = TaskPaneHideNotify
swAppTaskPanePinnedNotify	39 = TaskPanePinnedNotify
swAppTaskPaneShowNotify	42 = TaskPaneShowNotify
swAppTaskPaneUnpinnedNotify	40 = TaskPaneUnpinnedNotify

Remarks

To receive notifications, a DLL application must register for the notifications by object type. This registration must be done for each instance of a particular object.

For example, in the file in the Visual C++ 6.0 wizard-generated add-in that supports SOLIDWORKS events (<ATL_object_name>.h), include:

```
BEGIN_SINK_MAP(C<ATL_object_name>)  
    SINK_ENTRY_EX(ID_SLDWORKS_EVENTS, DIID_DSldWorksEvents, swAppDocumentLoadNotify,  
        DocumentLoadNotify)  
    SINK_ENTRY_EX(ID_SLDWORKS_EVENTS, DIID_DSldWorksEvents, swAppFileNewNotify2, FileNewNotify2)  
    SINK_ENTRY_EX(ID_SLDWORKS_EVENTS, DIID_DSldWorksEvents, swAppActiveDocChangeNotify,  
        ActiveDocChangeNotify)  
    SINK_ENTRY_EX(ID_SLDWORKS_EVENTS, DIID_DSldWorksEvents, swAppActiveModelDocChangeNotify,  
        ActiveModelDocChangeNotify)  
END_SINK_MAP()
```

If developing a C++ application, use the enumerators to [register for notifications](#) for the [ISldWorks](#) events.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swArcEndCondition_e (Type)

SOLIDWORKS API Enumerations

swArcEndCondition_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swArcEndCondition_e Enumeration

Arc endpoint conditions for linear dimensions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swArcEndCondition_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swArcEndCondition\_e
```

C#

```
public enum swArcEndCondition_e : System.Enum
```

C++/CLI

```
public enum class swArcEndCondition_e : public System.Enum
```

Members

Member	Description
swArcEndConditionCenter	1 = End point is the center of the arc
swArcEndConditionMax	3 = End point is the furthest point on the arc
swArcEndConditionMin	2 = End point is the nearest point on the arc
swArcEndConditionNone	0 = End point is not related to an arc

See Also

[SolidWorks.Interop.swconst Namespace](#)

swArcLengthLeaderType_e (Type)

SOLIDWORKS API Enumerations

swArcLengthLeaderType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

[SolidWorks.Interop.swconst Namespace](#) : swArcLengthLeaderType_e Enumeration

Arc length dimension leader styles.

Syntax

Visual Basic (Declaration)

Public Enum swArcLengthLeaderType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swArcLengthLeaderType_e](#)

C#

public enum swArcLengthLeaderType_e : System.Enum

C++/CLI

public enum class swArcLengthLeaderType_e : public System.Enum

Members

Member	Description
swArcLengthLeaderParallel	1 = Leaders are parallel to each other
swArcLengthLeaderRadial	2 = Leaders are radial from the arc center point

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAreaHatchFillStyle_e (Type)

SOLIDWORKS API Enumerations

swAreaHatchFillStyle_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAreaHatchFillStyle_e Enumeration

Area hatch fill styles.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAreaHatchFillStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAreaHatchFillStyle\_e
```

C#

```
public enum swAreaHatchFillStyle_e : System.Enum
```

C++/CLI

```
public enum class swAreaHatchFillStyle_e : public System.Enum
```

Members

Member	Description
swAreaHatchFillStyle_None	1
swAreaHatchFillStyle_Pattern	2
swAreaHatchFillStyle_Solid	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAreaHatchingScope_e (Type)

SOLIDWORKS API Enumerations

swAreaHatchingScope_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swAreaHatchingScope_e Enumeration

Areas for hatching.

 Syntax

Visual Basic (Declaration)

Public Enum swAreaHatchingScope_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swAreaHatchingScope_e](#)

C#

public enum swAreaHatchingScope_e : System.Enum

C++/CLI

public enum class swAreaHatchingScope_e : public System.Enum

 Members

Member	Description
swAreaHatchingScope_Body	3
swAreaHatchingScope_Component	1
swAreaHatchingScope_Region	0
swAreaHatchingScope_View	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swArrowDirection_e (Type)

SOLIDWORKS API Enumerations

swArrowDirection_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swArrowDirection_e Enumeration

DXF/DWG output arrow directions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swArrowDirection_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swArrowDirection_e](#)

C#

public enum swArrowDirection_e : System.Enum

C++/CLI

public enum class swArrowDirection_e : public System.Enum

Members

Member	Description
swINSIDE	0
swOUTSIDE	1
swSMART	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swArrowPlacement_e (Type)

SOLIDWORKS API Enumerations

swArrowPlacement_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swArrowPlacement_e Enumeration

Smart arrow placement.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swArrowPlacement_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swArrowPlacement\_e
```

C#

```
public enum swArrowPlacement_e : System.Enum
```

C++/CLI

```
public enum class swArrowPlacement_e : public System.Enum
```

Members

Member	Description
swArrowPlacementLegacy	0 = Vary Smart arrow placement as in SOLIDWORKS 2012 and earlier (see Remarks)
swArrowPlacementSmartArrowFollowText	1
swArrowPlacementSmartArrowRemainAttachedToArc	2

Remarks

In SOLIDWORKS 2012 and earlier, Smart arrows sometimes:

- Remained on the far side of an arc when moved to its other side.
- Were attached to an extension line.
- Pointed out to space.
- Were placed on the part.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swArrowPosition (Type)

SOLIDWORKS API Enumerations

swArrowPosition Enumeration

[See Also](#)

[Send comments on this topic.](#)



SolidWorks.Interop.swconst Namespace : swArrowPosition Enumeration

Arrow positions for bubble ToolTips.

Syntax

Visual Basic (Declaration)

```
Public Enum swArrowPosition
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swArrowPosition
```

C#

```
public enum swArrowPosition : System.Enum
```

C++/CLI

```
public enum class swArrowPosition : public System.Enum
```

Members

Member	Description
swArrowDownBottomLeft	6 = Down and on the bottom-left edge of bubble
swArrowDownBottomRight	7 = Down and on the bottom-right edge of bubble
swArrowLeftBottom	1 = Left and at bottom corner of bubble
swArrowLeftOrRight	10 = Left or right; code decides if arrow on top or bottom corner
swArrowLeftOrRightBottom	9 = Left or right and in one of the bottom corners of bubble
swArrowLeftOrRightTop	8 = Left or right and in one of the top corners of bubble
swArrowLeftTop	0 = Left and at top corner of bubble
swArrowNone	14 = No arrow used; instead, a floating
swArrowRightBottom	3 = Right and at bottom corner of bubble
swArrowRightTop	2 = Right and at top corner of bubble
swArrowUnknown	15 = Do not know where to put the arrow; instead, ActiveX control decides where to put arrow or its default position is used
swArrowUpOrDown	13 = Upward or downward; code decides if arrow left or right of the bubble
swArrowUpOrDownLeft	11 = Upward or downward and on left side of bubble
swArrowUpOrDownRight	12 = Upward or downward and on right side of bubble
swArrowUpTopLeft	4 = Upward and on the top-left edge of bubble
swArrowUpTopRight	5 = Upward and on the top-right edge of bubble

See Also

[SolidWorks.Interop.swconst Namespace](#)

swArrowStyle_e (Type)

SOLIDWORKS API Enumerations

swArrowStyle_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swArrowStyle_e Enumeration

Arrow styles.

 Syntax

Visual Basic (Declaration)

```
Public Enum swArrowStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swArrowStyle\_e
```

C#

```
public enum swArrowStyle_e : System.Enum
```

C++/CLI

```
public enum class swArrowStyle_e : public System.Enum
```

 Members

Member	Description
swCLOSEBOT_ARROWHEAD	9 = Filled bottom only
swCLOSED_ARROWHEAD	1 = Filled
swCLOSETOP_ARROWHEAD	8 = Filled top only
swDOT_ARROWHEAD	3 = Filled circle
swISOWIDE_ARROWHEAD	6 = ISO wide
swNO_ARROWHEAD	10 = None
swOPEN_ARROWHEAD	0 = No fill
swORIGIN_ARROWHEAD	4 = No fill circle
swRUS_ARROWHEAD	7 = GOST standard
swSHOULDER_ARROWHEAD	11 = No arrowhead; filled triangle at leader attachment point
swSLASH_ARROWHEAD	2 = Slash
swSMART_ARROWHEAD	12 = Filled arrowhead with lightning bolt
swWIDE_ARROWHEAD	5 = Wide

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swASMSLDPRTCompPref_e (Type)

SOLIDWORKS API Enumerations

swASMSLDPRTCompPref_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swASMSLDPRTCompPref_e Enumeration

Options for a specified component when saving an assembly as a part.

 Syntax

Visual Basic (Declaration)

Public Enum swASMSLDPRTCompPref_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swASMSLDPRTCompPref_e](#)



C#

public enum swASMSLDPRTCompPref_e : System.Enum

C++/CLI

public enum class swASMSLDPRTCompPref_e : public System.Enum

 Members

Member	Description
swAlwaysExclude	2
swAlwaysInclude	1
swUseSystemSettings	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAssemblyDeleteOptions_e (Type)

SOLIDWORKS API Enumerations

swAssemblyDeleteOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swAssemblyDeleteOptions_e Enumeration

Assembly delete options.

Syntax

Visual Basic (Declaration)

```
Public Enum swAssemblyDeleteOptions_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAssemblyDeleteOptions\_e
```

C#

```
public enum swAssemblyDeleteOptions_e : System.Enum
```

C++/CLI

```
public enum class swAssemblyDeleteOptions_e : public System.Enum
```

Members

Member	Description
swDelete_SelectedComponents	0
swDelete_SubAssembly	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAssemblyExplodeStepType (Type)

SOLIDWORKS API Enumerations

swAssemblyExplodeStepType Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swAssemblyExplodeStepType Enumeration

Assembly explode step types.

 Syntax

Visual Basic (Declaration)

Public Enum swAssemblyExplodeStepType
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAssemblyExplodeStepType](#)

C#

public enum swAssemblyExplodeStepType : System.Enum

C++/CLI

public enum class swAssemblyExplodeStepType : public System.Enum

 Members

Member	Description
swAssemblyExplodeStepType_Radial	1
swAssemblyExplodeStepType_SubAssembly	2
swAssemblyExplodeStepType_Translate	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAssemblyLevelToUpdate_e (Type)

SOLIDWORKS API Enumerations

swAssemblyLevelToUpdate_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAssemblyLevelToUpdate_e Enumeration

Levels of assemblies to update options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAssemblyLevelToUpdate_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAssemblyLevelToUpdate\_e
```

C#

```
public enum swAssemblyLevelToUpdate_e : System.Enum
```

C++/CLI

```
public enum class swAssemblyLevelToUpdate_e : public System.Enum
```

Members

Member	Description
swAssemblyLevelToUpdate_AllLevels	2
swAssemblyLevelToUpdate_SubLevelAssemblyOnly	1
swAssemblyLevelToUpdate_TopLevelAssemblyOnly	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAssemblyLoadComponents_e (Type)

SOLIDWORKS API Enumerations

swAssemblyLoadComponents_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swAssemblyLoadComponents_e Enumeration

Tools > System Options > Performance > Assembly loading.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swAssemblyLoadComponents_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAssemblyLoadComponents_e](#)

C#

public enum swAssemblyLoadComponents_e : System.Enum

C++/CLI

public enum class swAssemblyLoadComponents_e : public System.Enum

Members

Member	Description
swAssemblyLoadComponents_AutoLoad	0
swAssemblyLoadComponents_ManualLoad	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAssemblyMode_e (Type)

SOLIDWORKS API Enumerations

swAssemblyMode_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAssemblyMode_e Enumeration

Assembly states.

 Syntax

Visual Basic (Declaration)

Public Enum swAssemblyMode_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swAssemblyMode_e](#)

C#

public enum swAssemblyMode_e : System.Enum

C++/CLI

public enum class swAssemblyMode_e : public System.Enum

 Members

Member	Description
swAssemblyMode_LDR	3
swAssemblyMode_LDR_EditAssembly	4
swAssemblyMode_LightWeight	2
swAssemblyMode_None	0
swAssemblyMode_Resolved	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAssemblyNotify_e (Type)

SOLIDWORKS API Enumerations

swAssemblyNotify_e Enumeration

See Also

[Send comments on this topic.](#)



[SolidWorks.Interop.swconst Namespace](#) : swAssemblyNotify_e Enumeration
Assembly notifications.

Syntax

Visual Basic (Declaration)

```
Public Enum swAssemblyNotify_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAssemblyNotify\_e
```

C#

```
public enum swAssemblyNotify_e : System.Enum
```

C++/CLI

```
public enum class swAssemblyNotify_e : public System.Enum
```

Members

Member	Description
swAssemblyActiveAnnotationViewChangeNotify	98 = ActiveAnnotationViewChangeNotify
swAssemblyActiveDisplayStateChangePostNotify	71 = ActiveDisplayStateChangePostNotify
swAssemblyActiveDisplayStateChangePreNotify	70 = ActiveDisplayStateChangePreNotify
swAssemblyActiveViewChangeNotify	66 = ActiveViewChangeNotify
swAssemblyAddCustomPropertyNotify	26 = AddCustomPropertyNotify
swAssemblyAddDependencyNotify	103 = AddDependencyNotify
swAssemblyAddDvePagePreNotify	60 = Not used.
swAssemblyAddItemNotify	18 = AddItemNotify
swAssemblyAddMatePostNotify	72 = Obsolete
swAssemblyAddMatePostNotify2	95 = AddMatePostNotify
swAssemblyAutoSaveNotify	12 = AutoSaveNotify
swAssemblyAutoSaveToStorageNotify	13 = AutoSaveToStorageNotify
swAssemblyAutoSaveToStorageStoreNotify	82 = AutoSaveToStorageStoreNotify
swAssemblyBeginInContextEditNotify	14 = BeginInContextEditNotify
swAssemblyBodyVisibleChangeNotify	37 = BodyVisibleChangeNotify
swAssemblyChangeCustomPropertyNotify	27 = ChangeCustomPropertyNotify
swAssemblyClearSelectionsNotify	53 = ClearSelectionsNotify
swAssemblyCloseDesignTableNotify	58 = CloseDesignTableNotify
swAssemblyCommandManagerTabActivatedPreNotify	89 = CommandManagerTabActivatedPreNotify
swAssemblyComponentConfigurationChangeNotify	73 = ComponentConfigurationChangeNotify
swAssemblyComponentDisplayModeChangePostNotify	88 = ComponentDisplayModeChangePostNotify
swAssemblyComponentDisplayModeChangePreNotify	87 = ComponentDisplayModeChangePreNotify
swAssemblyComponentDisplayStateChangeNotify	47 = ComponentDisplayStateChangeNotify
swAssemblyComponentMoveNotify	35 = Obsolete
swAssemblyComponentMoveNotify2	44 = ComponentMoveNotify2
swAssemblyComponentReferredDisplayStateChangeNotify	79 = ComponentReferredDisplayStateChangeNotify
swAssemblyComponentReorganizeNotify	64 = ComponentReorganizeNotify
swAssemblyComponentStateChangeNotify	22 = Obsolete
swAssemblyComponentStateChangeNotify2	25 = Obsolete
swAssemblyComponentStateChangeNotify3	96 = ComponentStateChangeNotify3
swAssemblyComponentVisibleChangeNotify	36 = ComponentVisibleChangeNotify
swAssemblyComponentVisualPropertiesChangeNotify	46 = ComponentVisualPropertiesChangeNotify
swAssemblyConfigChangeNotify	10 = ActiveConfigChangeNotify
swAssemblyConfigChangePostNotify	11 = ActiveConfigChangePostNotify
swAssemblyConfigurationChangeNotify	63 = ConfigurationChangeNotify
swAssemblyDeleteCustomPropertyNotify	28 = DeleteCustomPropertyNotify
swAssemblyDeleteDependencyNotify	104 = DeleteDependencyNotify
swAssemblyDeleteItemNotify	20 = DeleteItemNotify
swAssemblyDeleteItemPreNotify	52 = DeleteItemPreNotify
swAssemblyDeleteSelectionPreNotify	33 = DeleteSelectionPreNotify
swAssemblyDestroyNotify	2 = Obsolete
swAssemblyDestroyNotify2	62 = DestroyNotify2
swAssemblyDimensionChangeNotify	48 = DimensionChangeNotify
swAssemblyDisplayPaneCollapseNotify	100 = DisplayPaneCollapseNotify
swAssemblyDisplayPaneExpandNotify	99 = DisplayPaneExpandNotify
swAssemblyDragStateChangeNotify	83 = DragStateChangeNotify
swAssemblyDynamicHighlightNotify	45 = DynamicHighlightNotify
swAssemblyElectricalDataUpdateNotify	43 = AssemblyElectricalDataUpdateNotify
swAssemblyEndInContextEditNotify	15 = EndInContextEditNotify
swAssemblyEquationEditorPostNotify	56 = EquationEditorPostNotify
swAssemblyEquationEditorPreNotify	55 = EquationEditorPreNotify
swAssemblyFeatureEditPreNotify	29 = FeatureEditPreNotify
swAssemblyFeatureManagerFilterStringChangeNotify	67 = FeatureManagerFilterStringChangeNotify
swAssemblyFeatureManagerTabActivatedNotify	93 = FeatureManagerTabActivatedNotify
swAssemblyFeatureManagerTabActivatedPreNotify	92 = FeatureManagerTabActivatedPreNotify
swAssemblyFeatureManagerTreeRebuildNotify	42 = FeatureManagerTreeRebuildNotify
swAssemblyFeatureSketchEditPreNotify	30 = FeatureSketchEditPreNotify

swAssemblyFileDropNotify	23 = FileDropNotify
swAssemblyFileDropPostNotify	54 = FileDropPostNotify
swAssemblyFileDropPreNotify	38 = FileDropPreNotify
swAssemblyFileReloadCancelNotify	49 = FileReloadCancelNotify
swAssemblyFileReloadNotify	24 = FileReloadNotify
swAssemblyFileReloadPreNotify	34 = FileReloadPreNotify
swAssemblyFileSaveAsNotify	7 = Obsolete
swAssemblyFileSaveAsNotify2	31 = FileSaveAsNotify2
swAssemblyFileSaveNotify	6 = Obsolete
swAssemblyFileSavePostCancelNotify	50 = FileSavePostCancelNotify
swAssemblyFileSavePostNotify	39 = FileSavePostNotify
swAssemblyFlipLoopNotify	68 = FlipLoopNotify
swAssemblyInsertTableNotify	84 = InsertTableNotify
swAssemblyInterferenceNotify	32 = InterferenceNotify
swAssemblyLargeDesignReviewStateChangeNotify	101 = LargeDesignReviewStateChangeNotify
swAssemblyLightingDialogCreateNotify	17 = LightingDialogCreateNotify
swAssemblyLoadFromStorageNotify	8 = LoadFromStorageNotify
swAssemblyLoadFromStorageStoreNotify	40 = LoadFromStorageStoreNotify
swAssemblyModifyNotify	21 = ModifyNotify
swAssemblyModifyTableNotify	85 = ModifyTableNotify
swAssemblyNewSelectionNotify	5 = NewSelectionNotify
swAssemblyOpenDesignTableNotify	57 = OpenDesignTableNotify
swAssemblyPreRenameItemNotify	90 = PreRenameItemNotify
swAssemblyPromptBodiesToKeepNotify	59 = PromptBodiesToKeepNotify
swAssemblyPublishTo3DPDFNotify	96 = PublishTo3DPDFNotify
swAssemblyRedoPostNotify	76 = RedoPostNotify
swAssemblyRedoPreNotify	77 = RedoPreNotify
swAssemblyRegenNotify	1 = RegenNotify
swAssemblyRegenPostNotify	3 = RegenPostNotify
swAssemblyRegenPostNotify2	81 = RegenPostNotify2
swAssemblyRenamedDocumentNotify	91 = RenamedDocumentNotify
swAssemblyRenameDisplayTitleNotify	97 = RenameDisplayTitleNotify
swAssemblyRenameItemNotify	19 = RenameItemNotify
swAssemblySaveToStorageNotify	9 = SaveToStorageNotify
swAssemblySaveToStorageStoreNotify	41 = SaveToStorageStore
swAssemblySelectiveOpenPostNotify	80 = SelectiveOpenPostNotify
swAssemblySensorAlertPreNotify	69 = SensorAlertPreNotify
swAssemblySketchSolveNotify	51 = SketchSolveNotify
swAssemblySolidBodyFolderReorderNotify	102 = SolidBodyFolderReorderNotify
swAssemblySuppressionStateChangeNotify	65 = SuppressionStateChangeNotify
swAssemblyUndoPostNotify	74 = UndoPostNotify
swAssemblyUndoPreNotify	78 = UndoPreNotify
swAssemblyUnitsChangeNotify	61 = UnitsChangeNotify
swAssemblyUserSelectionPostNotify	86 = UserSelectionPostNotify
swAssemblyUserSelectionPreNotify	75 = UserSelectionPreNotify
swAssemblyViewNewNotify	4 = Obsolete
swAssemblyViewNewNotify2	16 = ViewNewNotify2

Remarks

To receive notifications, a DLL application must register for the notifications by object type. This registration must be done for each instance of a particular object.

For example, in the file in the Visual C++ 6.0 wizard-generated add-in that supports assembly events (e.g., Assembly.h), include:

```
BEGIN_SINK_MAP(CSAssembly)

    SINK_ENTRY_EX(ID_ASSEMBLYDOC_EVENTS, DIID_DAssemblyDocEvents, swAssemblyDestroyNotify,
        DestroyNotify)

    SINK_ENTRY_EX(ID_ASSEMBLYDOC_EVENTS, DIID_DAssemblyDocEvents, swAssemblyNewSelectionNotify,
        NewSelectionNotify)

END_SINK_MAP( )
```

If developing a C++ application, use the enumerators to [register for notifications](#) for the [IAssemblyDoc](#) events (see the **Members** list in this topic).

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAssemblyUpdateToolboxComponentStatus_e (Type)

SOLIDWORKS API Enumerations

swAssemblyUpdateToolboxComponentStatus_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAssemblyUpdateToolboxComponentStatus_e Enumeration

Status of updating SOLIDWORKS Toolbox components in assemblies using the current information in Toolbox Settings.

Syntax

Visual Basic (Declaration)

```
Public Enum swAssemblyUpdateToolboxComponentStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAssemblyUpdateToolboxComponentStatus\_e
```

C#

```
public enum swAssemblyUpdateToolboxComponentStatus_e : System.Enum
```

C++/CLI

```
public enum class swAssemblyUpdateToolboxComponentStatus_e : public System.Enum
```

Members

Member	Description
swAssemblyUpdateToolboxComponentStatus_Failed	1
swAssemblyUpdateToolboxComponentStatus_Success	0
swAssemblyUpdateToolboxComponentStatus_ToolboxNotRegistered	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAssociatedEntityStates_e (Type)

SOLIDWORKS API Enumerations

swAssociatedEntityStates_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swAssociatedEntityStates_e Enumeration

Associated entity states for attributes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAssociatedEntityStates_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAssociatedEntityStates\_e
```

C#

```
public enum swAssociatedEntityStates_e : System.Enum
```

C++/CLI

```
public enum class swAssociatedEntityStates_e : public System.Enum
```

Members

Member	Description
swlsEntityAmbiguous	2
swlsEntityDeleted	3
swlsEntityInvalid	0
swlsEntitySuppressed	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAttachAnnotationOption_e (Type)

SOLIDWORKS API Enumerations

swAttachAnnotationOption_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAttachAnnotationOption_e Enumeration

Annotation attachment options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAttachAnnotationOption_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAttachAnnotationOption\_e
```

C#

```
public enum swAttachAnnotationOption_e : System.Enum
```

C++/CLI

```
public enum class swAttachAnnotationOption_e : public System.Enum
```

Members

Member	Description
swAttachAnnotationOption_Sheet	1
swAttachAnnotationOption_View	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutodimEntities_e (Type)

SOLIDWORKS API Enumerations

swAutodimEntities_e Enumeration

See Also

Send comments on this topic.

▼

[SolidWorks.Interop.swconst Namespace](#) : swAutodimEntities_e Enumeration

Entities to dimension [ISketch::AutoDimension2](#) and [IDrawingDoc::AutoDimension](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swAutodimEntities_e
    Inherits System.Enum
```

Visual Basic (Usage) Copy Code

```
Dim instance As swAutodimEntities\_e
```

C#

```
public enum swAutodimEntities_e : System.Enum
```

C++/CLI

```
public enum class swAutodimEntities_e : public System.Enum
```

Members

Member	Description
swAutodimEntitiesAll	1 = Autodimensions all of the supported entities in the sketch
swAutodimEntitiesBasedOnPreselect	0 = SOLIDWORKS to figure out what to do based on the selected supported entities marked with swAutodimMarkEntities . If any exist, then autodimension them, just like swAutodimEntitiesSelected. If none exist, then autodimension all supported entities, just like swAutodimEntitiesAll
swAutodimEntitiesSelected	2 = Autodimensions selected supported entities marked with swAutodimMarkEntities . If none exist, then autodimensions all supported entities, just like swAutodimEntitiesAll

Remarks

Supported entities are lines, points, vertices, faces, sketch entities, center lines, and center marks.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutodimHorizontalPlacement_e (Type)

SOLIDWORKS API Enumerations

swAutodimHorizontalPlacement_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swAutodimHorizontalPlacement_e Enumeration

Placements for the horizontal dimensions created by [ISketch::AutoDimension2](#) and [IDrawingDoc::AutoDimension](#).

 Syntax

Visual Basic (Declaration)

```
Public Enum swAutodimHorizontalPlacement_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swAutodimHorizontalPlacement\_e
```

C#

```
public enum swAutodimHorizontalPlacement_e : System.Enum
```

C++/CLI

```
public enum class swAutodimHorizontalPlacement_e : public System.Enum
```

 Members

Member	Description
swAutodimHorizontalPlacementAbove	1 = Place the horizontal dimensions above the sketch.
swAutodimHorizontalPlacementBelow	-1 = Place the horizontal dimensions below the sketch.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutodimMark_e (Type)

SOLIDWORKS API Enumerations

swAutodimMark_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swAutodimMark_e Enumeration

Selection mark values. [Bitmask](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swAutodimMark_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAutodimMark\_e
```

C#

```
public enum swAutodimMark_e : System.Enum
```

C++/CLI

```
public enum class swAutodimMark_e : public System.Enum
```

Members

Member	Description
swAutodimMarkEntities	1 or 0x1; Sketch entities to autodimension when swAutodimEntitiesSelected is passed as the entitiesToDimension argument to ISketch::AutoDimension2
swAutodimMarkHorizontalDatum	2 or 0x2; Sketch entities to autodimension when swAutodimEntitiesSelected is passed as the entitiesToDimension argument to ISketch::AutoDimension2
swAutodimMarkOriginDatum	8 or 0x8; Unique datum for the origin dimension scheme. Datum must be either a sketch point or a vertical sketch line.
swAutodimMarkVerticalDatum	4 or 0x4; Unique datum for the horizontal dimension scheme; datum must be either a sketch point or a vertical sketch line

Remarks

These values are passed by [IModelDocExtension::SelectByID2](#).

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutodimScheme_e (Type)

SOLIDWORKS API Enumerations

swAutodimScheme_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swAutodimScheme_e Enumeration

Dimensioning schemes for [ISketch::AutoDimension2](#) and [IDrawingDoc::AutoDimension](#).

 Syntax

Visual Basic (Declaration)

Public Enum swAutodimScheme_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swAutodimScheme_e](#)

C#

public enum swAutodimScheme_e : System.Enum

C++/CLI

public enum class swAutodimScheme_e : public System.Enum

 Members

Member	Description
swAutodimSchemeBaseline	1 = Use a baseline dimensioning scheme
swAutodimSchemeCenterline	4 = Not supported in sketches or drawings; do not use
swAutodimSchemeChain	3 = Use a chain dimensioning scheme
swAutodimSchemeOrdinate	2 = Use an ordinate dimensioning scheme

 Remarks

The horizontal and vertical dimension placements are specified independently using the HorizontalPlacement and VerticalPlacement parameters in the methods.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutodimStatus_e (Type)

SOLIDWORKS API Enumerations

[Send comments on this topic.](#)

swAutodimStatus_e Enumeration

[See Also](#)



[SolidWorks.Interop.swconst Namespace](#) : swAutodimStatus_e Enumeration

Statuses returned by [ISketch::AutoDimension2](#) and [IDrawingDoc::AutoDimension](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swAutodimStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAutodimStatus\_e
```

C#

```
public enum swAutodimStatus_e : System.Enum
```

C++/CLI

```
public enum class swAutodimStatus_e : public System.Enum
```

Members

Member	Description
swAutodimStatus3DSketchNotSupported	5 = Cannot autodimension a 3D sketch
swAutodimStatusAlgorithmFailed	17 = Unspecified algorithm failure
swAutodimStatusBadOptionValue	1 = An option value for an argument is out of range
swAutodimStatusCenterlineNotAllowed	10 = The centerline scheme is not valid for sketches that cannot be revolved to create valid features
swAutodimStatusDatumLineNotCenterline	14 = The datum must be a centerline for the centerline scheme
swAutodimStatusDatumLineNotHorizontal	16 = If the sketch line is a datum, it must be horizontal for horizontal dimensions
swAutodimStatusDatumLineNotVertical	15 = If the sketch line is a datum, it must be vertical for vertical dimension
swAutodimStatusDatumNotSupplied	11 = No datum was selected for either the horizontal or vertical dimensioning schemes
swAutodimStatusDatumNotUnique	12 = More than one datum was selected for either the horizontal or vertical dimensioning schemes
swAutodimStatusDatumNotValidType	13 = One of the selected datums is not valid. Valid types are sketch points and sketch lines
swAutodimStatusDocTypeNotSupported	3 = Only part and assemblies documents are supported
swAutodimStatusEntitiesNotValid	9 = The entitiesToDimension argument has the value of swAutodimEntitiesSelected , but the marked entities are not valid
swAutodimStatusNoActiveDoc	2 = No active document
swAutodimStatusNoActiveSketch	4 = Can only autodimension an active sketch
swAutodimStatusNoEntities	8 = The entitiesToDimension argument has the value of swAutodimEntitiesSelected , but no entities were selected and marked with the value swAutodimMarkEntities
swAutodimStatusSketchIsEmpty	6 = Cannot autodimension an empty sketch
swAutodimStatusSketchIsOverDefined	7 = Cannot autodimension an over defined sketch
swAutodimStatusSketchNoSolutionFound	18 = Cannot autodimension a sketch for which there is no solution
swAutodimStatusSuccess	0 = Sketch successfully dimensioned

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutodimVerticalPlacement_e (Type)

SOLIDWORKS API Enumerations

swAutodimVerticalPlacement_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swAutodimVerticalPlacement_e Enumeration

Placements of the vertical dimensions created by [ISketch::AutoDimension2](#) and [IDrawingDoc::AutoDimension](#).

 Syntax

Visual Basic (Declaration)

Public Enum swAutodimVerticalPlacement_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swAutodimVerticalPlacement_e](#)

C#

public enum swAutodimVerticalPlacement_e : System.Enum

C++/CLI

public enum class swAutodimVerticalPlacement_e : public System.Enum

 Members

Member	Description
swAutodimVerticalPlacementLeft	-1 = Place the vertical dimensions left of the sketch
swAutodimVerticalPlacementRight	1 = Place the vertical dimensions right of the sketch

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutoHideShowResponse_e (Type)

SOLIDWORKS API Enumerations

swAutoHideShowResponse_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swAutoHideShowResponse_e Enumeration

Visibility of FeatureManager design tree folders and tools.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAutoHideShowResponse_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAutoHideShowResponse\_e
```

C#

```
public enum swAutoHideShowResponse_e : System.Enum
```

C++/CLI

```
public enum class swAutoHideShowResponse_e : public System.Enum
```

Members

Member	Description
swAutoHideShowResponse_Automatic	1
swAutoHideShowResponse_Hide	2
swAutoHideShowResponse_Show	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutoInsertCenterMarkTypes_e (Type)

SOLIDWORKS API Enumerations

swAutoInsertCenterMarkTypes_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAutoInsertCenterMarkTypes_e Enumeration

Types for which to insert center marks. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAutoInsertCenterMarkTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAutoInsertCenterMarkTypes\_e
```

C#

```
public enum swAutoInsertCenterMarkTypes_e : System.Enum
```

C++/CLI

```
public enum class swAutoInsertCenterMarkTypes_e : public System.Enum
```

Members

Member	Description
swAutoInsertCenterMarkType_Fillets	0x2 or 2
swAutoInsertCenterMarkType_Hole	0x1 or 1
swAutoInsertCenterMarkType_Slots	0x4 or 4

See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutoMateRepairErrors_e (Type)

SOLIDWORKS API Enumerations

swAutoMateRepairErrors_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAutoMateRepairErrors_e Enumeration

Automatic mate repair errors.

 Syntax

Visual Basic (Declaration)

```
Public Enum swAutoMateRepairErrors_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swAutoMateRepairErrors\_e
```

C#

```
public enum swAutoMateRepairErrors_e : System.Enum
```

C++/CLI

```
public enum class swAutoMateRepairErrors_e : public System.Enum
```

 Members

Member	Description
swAutoMateRepairErrors_Failed	4
swAutoMateRepairErrors_InvalidSelection	3
swAutoMateRepairErrors_NoSelection	2
swAutoMateRepairErrors_PartialSuccess	1
swAutoMateRepairErrors_Success	0
swAutoMateRepairErrors_Unknown	-1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swAutoSaveIntervalMode_e (Type)

SOLIDWORKS API Enumerations

swAutoSaveIntervalMode_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swAutoSaveIntervalMode_e Enumeration

Modes for autosaving documents.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swAutoSaveIntervalMode_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swAutoSaveIntervalMode\_e
```

C#

```
public enum swAutoSaveIntervalMode_e : System.Enum
```

C++/CLI

```
public enum class swAutoSaveIntervalMode_e : public System.Enum
```

Members

Member	Description
swAutoSaveIntervalMode_Changes	1
swAutoSaveIntervalMode_Minutes	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBackgroundProcessOption_e (Type)

SOLIDWORKS API Enumerations

swBackgroundProcessOption_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swBackgroundProcessOption_e Enumeration

Background processing options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swBackgroundProcessOption_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBackgroundProcessOption\_e
```

C#

```
public enum swBackgroundProcessOption_e : System.Enum
```

C++/CLI

```
public enum class swBackgroundProcessOption_e : public System.Enum
```

Members

Member	Description
swBackgroundProcessing_DeferToApplication	2 = Defer to ISldWorks.EnableBackgroundProcessing setting
swBackgroundProcessing_Disabled	0
swBackgroundProcessing_Enabled	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBalloonFit_e (Type)

SOLIDWORKS API Enumerations

swBalloonFit_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swBalloonFit_e Enumeration

Types of balloon and label location fits.

Syntax

Visual Basic (Declaration)

Public Enum swBalloonFit_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swBalloonFit_e](#)

C#

public enum swBalloonFit_e : System.Enum

C++/CLI

public enum class swBalloonFit_e : public System.Enum

Members

Member	Description
swBF_1Char	1
swBF_2Chars	2
swBF_3Chars	3
swBF_4Chars	4
swBF_5Chars	5
swBF_Tightest	0; Not available for a label location
swBF_UserDef	6; Can use for label location selection Custom Size

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBalloonItemNumbersOrder_e (Type)

SOLIDWORKS API Enumerations

swBalloonItemNumbersOrder_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBalloonItemNumbersOrder_e Enumeration

Balloon item ordering options. [Bitmask](#).

Syntax

Visual Basic (Declaration)

Public Enum swBalloonItemNumbersOrder_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swBalloonItemNumbersOrder_e](#)

C#

public enum swBalloonItemNumbersOrder_e : System.Enum

C++/CLI

public enum class swBalloonItemNumbersOrder_e : public System.Enum

Members

Member	Description
swBalloonItemNumbers.DoNotChangeItemNumbers	0x1 or 1
swBalloonItemNumbers.FollowAssemblyOrder	0x2 or 2
swBalloonItemNumbers.NotApplicable	-1
swBalloonItemNumbers.OrderSequentially	0x4 or 4

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBalloonLayoutType_e (Type)

SOLIDWORKS API Enumerations

swBalloonLayoutType_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swBalloonLayoutType_e Enumeration

Arrangements for automatic BOM balloons in relation to the drawing views with which they are associated.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swBalloonLayoutType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBalloonLayoutType\_e
```

C#

```
public enum swBalloonLayoutType_e : System.Enum
```

C++/CLI

```
public enum class swBalloonLayoutType_e : public System.Enum
```

Members

Member	Description
swDetailingBalloonLayout_Bottom	4 = Along the bottom edge of the drawing view
swDetailingBalloonLayout_Circle	2 = In a circle around the drawing view
swDetailingBalloonLayout_Left	6 = Along the left edge of the drawing view
swDetailingBalloonLayout_Right	5 = Along the right edge of the drawing view
swDetailingBalloonLayout_Square	1 = In a box around the drawing view
swDetailingBalloonLayout_Top	3 = Along the top edge of the drawing view

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBalloonQuantityPlacement_e (Type)

SOLIDWORKS API Enumerations

swBalloonQuantityPlacement_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swBalloonQuantityPlacement_e Enumeration

Balloon quantity placement options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swBalloonQuantityPlacement_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swBalloonQuantityPlacement_e](#)

C#

public enum swBalloonQuantityPlacement_e : System.Enum

C++/CLI

public enum class swBalloonQuantityPlacement_e : public System.Enum

Members

Member	Description
swBalloonQuantityPlacement_Bottom	3
swBalloonQuantityPlacement_Left	0
swBalloonQuantityPlacement_NotApplicable	-1
swBalloonQuantityPlacement_Right	1
swBalloonQuantityPlacement_Top	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBalloonStyle_e (Type)

SOLIDWORKS API Enumerations

swBalloonStyle_e Enumeration

See Also

[Send comments on this topic.](#)

[SolidWorks.Interop.swconst Namespace](#) : swBalloonStyle_e Enumeration

Balloon styles.

Syntax

Visual Basic (Declaration)

```
Public Enum swBalloonStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBalloonStyle\_e
```

C#

```
public enum swBalloonStyle_e : System.Enum
```

C++/CLI

```
public enum class swBalloonStyle_e : public System.Enum
```

Members

Member	Description
swBS_ArcBracket	14
swBS_ArcLenSym	16
swBS_Box	4
swBS_Circular	1
swBS_Diamond	5
swBS_DoubleArrow	18
swBS_FixedSym	17
swBS_FlagPentagon	8
swBS_FlagTriangle	9
swBS_Hexagon	3
swBS_Inspection	13
swBS_None	0
swBS_Pentagon	6; Can be used for label location selection Circular Spit Line
swBS_RectBracket	15
swBS_SCircle	12
swBS_SplitCirc	7; Not valid for notes; only valid for balloons
swBS_SplitSquare	19; Can be used for label location selection Square Spit Line
swBS_Square	11
swBS_Triangle	2
swBS_Underline	10
swBS_Verbose	20

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBalloonTextContent_e (Type)

SOLIDWORKS API Enumerations

swBalloonTextContent_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swBalloonTextContent_e Enumeration

Style of the text contents of balloon notes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swBalloonTextContent_e
    Inherits System.Enum
```

Visual Basic (Usage)

Copy Code

```
Dim instance As swBalloonTextContent\_e
```

C#

```
public enum swBalloonTextContent_e : System.Enum
```

C++/CLI

```
public enum class swBalloonTextContent_e : public System.Enum
```

Members

Member	Description
swBalloonTextComponentReference	4
swBalloonTextCustom	0
swBalloonTextCustomProperties	3
swBalloonTextCutlistProperties	8
swBalloonTextFileName	7
swBalloonTextItemNumber	1
swBalloonTextPartNumberBOM	6
swBalloonTextQuantity	2
swBalloonTextSpoolReference	5
swBalloonTextViewSheet	9
swBalloonTextViewSheetWithLabel	10
swBalloonTextViewViewLetter	12
swBalloonTextViewZone	11

Remarks

Although these values are similar to those in [swDetailingNoteTextContent_e](#), they are not the same.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBasicDimType_e (Type)

SOLIDWORKS API Enumerations

swBasicDimType_e Enumeration

See Also

[Send comments on this topic.](#)

                                                                      

[SolidWorks.Interop.swconst Namespace](#) : swBasicDimType_e Enumeration

Basic dimension types for DimXpert geometric tolerances.

 Syntax

Visual Basic (Declaration)

Public Enum swBasicDimType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swBasicDimType_e](#)

C#

public enum swBasicDimType_e : System.Enum

C++/CLI

public enum class swBasicDimType_e : public System.Enum

 Members

Member	Description
swBasicDimType_Baseline	1
swBasicDimType_Chain	0
swBasicDimType_Polar	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBBoxDescriptionApplyMethod_e (Type)

SOLIDWORKS API Enumerations

swBBoxDescriptionApplyMethod_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swBBoxDescriptionApplyMethod_e Enumeration

Weldment bounding box apply to options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swBBoxDescriptionApplyMethod_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBBoxDescriptionApplyMethod\_e
```

C#

```
public enum swBBoxDescriptionApplyMethod_e : System.Enum
```

C++/CLI

```
public enum class swBBoxDescriptionApplyMethod_e : public System.Enum
```

Members

Member	Description
swBBoxDescriptionApplyMethod_ExistingAndNew	1
swBBoxDescriptionApplyMethod_New	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBendAllowanceTypes_e (Type)

SOLIDWORKS API Enumerations

swBendAllowanceTypes_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBendAllowanceTypes_e Enumeration

Bend allowance types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swBendAllowanceTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swBendAllowanceTypes\_e
```

C#

```
public enum swBendAllowanceTypes_e : System.Enum
```

C++/CLI

```
public enum class swBendAllowanceTypes_e : public System.Enum
```

 Members

Member	Description
swBendAllowanceBendCalculationTable	5
swBendAllowanceBendTable	1
swBendAllowanceDeduction	4
swBendAllowanceDirect	3
swBendAllowanceGaugeTable	6
swBendAllowanceKFactor	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBendDirection_e (Type)

SOLIDWORKS API Enumerations

swBendDirection_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swBendDirection_e Enumeration

Bend directions.

 Syntax

Visual Basic (Declaration)

Public Enum swBendDirection_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swBendDirection_e](#)

C#

public enum swBendDirection_e : System.Enum

C++/CLI

public enum class swBendDirection_e : public System.Enum

 Members

Member	Description
swBendDirection_DOWN	2
swBendDirection_ERROR	0
swBendDirection_UP	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBendLineControlOption_e (Type)

SOLIDWORKS API Enumerations

swBendLineControlOption_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBendLineControlOption_e Enumeration

Bend line options.

 Syntax

Visual Basic (Declaration)

```
Public Enum swBendLineControlOption_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swBendLineControlOption\_e
```

C#

```
public enum swBendLineControlOption_e : System.Enum
```

C++/CLI

```
public enum class swBendLineControlOption_e : public System.Enum
```

 Members

Member	Description
swBendLineControl_MaximumDeviation	1
swBendLineControl_NumberOfBendLine	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBendLineDirection_e (Type)

SOLIDWORKS API Enumerations

swBendLineDirection_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBendLineDirection_e Enumeration

Bend line directions.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swBendLineDirection_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swBendLineDirection_e](#)

 [Copy Code](#)

C#

public enum swBendLineDirection_e : System.Enum

C++/CLI

public enum class swBendLineDirection_e : public System.Enum

 Members

Member	Description
swDownDirection	2
swNotBendLine	0
swUpDirection	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBendNoteAttribute_e (Type)

SOLIDWORKS API Enumerations

swBendNoteAttribute_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBendNoteAttribute_e Enumeration

Bend note attributes.

 Syntax

Visual Basic (Declaration)

```
Public Enum swBendNoteAttribute_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swBendNoteAttribute\_e
```

C#

```
public enum swBendNoteAttribute_e : System.Enum
```

C++/CLI

```
public enum class swBendNoteAttribute_e : public System.Enum
```

 Members

Member	Description
swBendNoteAttribute_BendAllowance	6
swBendNoteAttribute_BendDirection	1
swBendNoteAttribute_BendOrder	5
swBendNoteAttribute_BendRadius	4
swBendNoteAttribute_ComplementaryAngle	3
swBendNoteAttribute_SupplementaryAngle	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBendNoteStyle_e (Type)

SOLIDWORKS API Enumerations

swBendNoteStyle_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBendNoteStyle_e Enumeration

Bend note styles.

 Syntax

Visual Basic (Declaration)

```
Public Enum swBendNoteStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swBendNoteStyle\_e
```

C#

```
public enum swBendNoteStyle_e : System.Enum
```

C++/CLI

```
public enum class swBendNoteStyle_e : public System.Enum
```

 Members

Member	Description
swAboveBendLine	0
swBelowBendLine	1
swWithLeader	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBendTableTagStyle_e (Type)

SOLIDWORKS API Enumerations

swBendTableTagStyle_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBendTableTagStyle_e Enumeration

Bend table tag styles.

 Syntax

Visual Basic (Declaration)

Public Enum swBendTableTagStyle_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swBendTableTagStyle_e](#)

C#

public enum swBendTableTagStyle_e : System.Enum

C++/CLI

public enum class swBendTableTagStyle_e : public System.Enum

 Members

Member	Description
swBendTable_AlphaNumericTags	1
swBendTable_NumericTags	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBendType_e (Type)

 

[SolidWorks.Interop.swconst Namespace](#) : swBendType_e Enumeration

Bend types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swBendType_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swBendType\_e
```

C#

```
public enum swBendType_e : System.Enum
```

C++/CLI

```
public enum class swBendType_e : public System.Enum
```

 Members

Member	Description
swBaseBend	4
swEdgeFlangeBend	8
swFlat3dBend	6
swFlatBend	2
swFreeFormBend	10 = Obsolete
swHemBend	9
swLoftedBend	12
swMirrorBend	7
swMiterBend	5
swNoneBend	3
swRoundBend	1
swRuledBend	11 = Obsolete
swSharpBend	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBitmapControlStandardTypes_e (Type)

SOLIDWORKS API Enumerations

swBitmapControlStandardTypes_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swBitmapControlStandardTypes_e Enumeration

Bitmap control standard types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swBitmapControlStandardTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swBitmapControlStandardTypes\_e
```

C#

```
public enum swBitmapControlStandardTypes_e : System.Enum
```

C++/CLI

```
public enum class swBitmapControlStandardTypes_e : public System.Enum
```

 Members

Member	Description
swBitmapControl_Volume	1 = Gradient bitmap

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBitMaps (Type)

SOLIDWORKS API Enumerations

swBitMaps Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swBitMaps Enumeration

Types of bitmaps for error and trouble-shooting tips bubbles.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swBitMaps
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swBitMaps](#)

 [Copy Code](#)

C#

public enum swBitMaps : System.Enum

C++/CLI

public enum class swBitMaps : public System.Enum

 Members

Member	Description
swBitMapNone	0 = None
swBitMapTreeError	2 = FeatureManager design tree error bitmap
swBitMapUserDefined	1 = User-defined bitmap

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBlockDefinitionExtFileStatus_e (Type)

SOLIDWORKS API Enumerations

swBlockDefinitionExtFileStatus_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swBlockDefinitionExtFileStatus_e Enumeration

Block definition external file status.

Syntax

Visual Basic (Declaration)

```
Public Enum swBlockDefinitionExtFileStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBlockDefinitionExtFileStatus\_e
```

C#

```
public enum swBlockDefinitionExtFileStatus_e : System.Enum
```

C++/CLI

```
public enum class swBlockDefinitionExtFileStatus_e : public System.Enum
```

Members

Member	Description
swBlockDefinitionExtFile_Failed	-1
swBlockDefinitionExtFile_MissingReference	2
swBlockDefinitionExtFile_NotLinked	1
swBlockDefinitionExtFile_OutOfDateReference	3
swBlockDefinitionExtFile_Success	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBlockingStates_e (Type)

SOLIDWORKS API Enumerations

swBlockingStates_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swBlockingStates_e Enumeration

Blocking states.

 Syntax

Visual Basic (Declaration)

```
Public Enum swBlockingStates_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swBlockingStates\_e
```

C#

```
public enum swBlockingStates_e : System.Enum
```

C++/CLI

```
public enum class swBlockingStates_e : public System.Enum
```

 Members

Member	Description
swEditorBlock	4 = A valid return value for IModelDoc2::GetBlockingState , but it is not a valid input for IModelDoc2::SetBlockingState ; editing or inserting blocks are blocked
swEditSketchAllowExitBlock	8 = Block model changes but allow sketching and exiting sketch edit mode
swEditSketchBlock	5 = A block is being edited in the drawing
swFullBlock	1 = Most actions are blocked; you cannot edit features, add features, change views (rotate, pan, and so on), exit the SOLIDWORKS software, or change a document; however, you can open a document
swModifyBlock	2 = Similar to swFullBlock except that view-related (rotate, pan, and so on) operations are not blocked
swNoBlock	0 = No actions are blocked
swPartialModifyBlock	3 = Similar to swModifyBlock except that you can change documents
swSystemBlock	6 = Similar to swFullBlock except that you cannot open a document
swViewOnlyBlock	7 = A valid return value for IModelDoc2::GetBlockingState when a document is open in View only/Selective open mode; not a valid input for IModelDoc2::SetBlockingState

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBlockInstanceTextDisplay_e (Type)

SOLIDWORKS API Enumerations

swBlockInstanceTextDisplay_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBlockInstanceTextDisplay_e Enumeration

Block instance text display.

 Syntax

Visual Basic (Declaration)

```
Public Enum swBlockInstanceTextDisplay_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swBlockInstanceTextDisplay\_e
```

C#

```
public enum swBlockInstanceTextDisplay_e : System.Enum
```

C++/CLI

```
public enum class swBlockInstanceTextDisplay_e : public System.Enum
```

 Members

Member	Description
swBlockInstanceTextDisplayAll	2
swBlockInstanceTextDisplayNone	1
swBlockInstanceTextDisplayNormal	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBodyFolderFeatureType_e (Type)

SOLIDWORKS API Enumerations

swBodyFolderFeatureType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBodyFolderFeatureType_e Enumeration

Body folder feature types.

 Syntax

Visual Basic (Declaration)

Public Enum swBodyFolderFeatureType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swBodyFolderFeatureType_e](#)

C#

public enum swBodyFolderFeatureType_e : System.Enum

C++/CLI

public enum class swBodyFolderFeatureType_e : public System.Enum

 Members

Member	Description
swBodySubFolder	3
swSolidBodyFolder	1
swSurfaceBodyFolder	2
swWeldmentCuttListFolder	5
swWeldmentSubFolder	4

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBodyInfo_e (Type)

SOLIDWORKS API Enumerations

swBodyInfo_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBodyInfo_e Enumeration

Type of body.

Syntax

Visual Basic (Declaration)

```
Public Enum swBodyInfo_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBodyInfo\_e
```

C#

```
public enum swBodyInfo_e : System.Enum
```

C++/CLI

```
public enum class swBodyInfo_e : public System.Enum
```

Members

Member	Description
swNormalBody_e	1 = Normal body
swUserBody_e	0 = User body

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBodyMaterialApplicationError_e (Type)

SOLIDWORKS API Enumerations

swBodyMaterialApplicationError_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBodyMaterialApplicationError_e Enumeration

Body material application errors.

Syntax

Visual Basic (Declaration)

```
Public Enum swBodyMaterialApplicationError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBodyMaterialApplicationError\_e
```

C#

```
public enum swBodyMaterialApplicationError_e : System.Enum
```

C++/CLI

```
public enum class swBodyMaterialApplicationError_e : public System.Enum
```

Members

Member	Description
swBodyMaterialApplicationError_ExternalReference	3
swBodyMaterialApplicationError_InvalidConfigName	5
swBodyMaterialApplicationError_InvalidMaterialNameOrDbName	6
swBodyMaterialApplicationError_NoError	1
swBodyMaterialApplicationError_ReadOnly	2
swBodyMaterialApplicationError_RolledBackState	4
swBodyMaterialApplicationError_UnknownError	-1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBodyOperationError_e (Type)

SOLIDWORKS API Enumerations

swBodyOperationError_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swBodyOperationError_e Enumeration

Body operation errors.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swBodyOperationError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBodyOperationError\_e
```

C#

```
public enum swBodyOperationError_e : System.Enum
```

C++/CLI

```
public enum class swBodyOperationError_e : public System.Enum
```

Members

Member	Description
swBodyOperationBooleanFail	1058 = Boolean fail error
swBodyOperationDisjointBodies	5 = Disjoint bodies error
swBodyOperationEmptyBody	6 = Empty body error
swBodyOperationEmptyInputBody	7 = Empty input body error
swBodyOperationFailGeomCondition	3 = Failed geometry condition
swBodyOperationFailToCutBody	4 = Failed to cut body error
swBodyOperationIntersectSolidWithSheets	972 = Intersect solid with sheets error
swBodyOperationInvalidInputBody	8 = Invalid input body
swBodyOperationMissingGeom	96 = Missing geometry error
swBodyOperationNoError	0 = No error
swBodyOperationNoIntersect	1067 = No intersect error
swBodyOperationNonApiBody	1 = Non API body error
swBodyOperationNonManifold	547 = Nonmanifold error
swBodyOperationOpposedSheets	951 = Boolean fail error, invalid orientation for operation
swBodyOperationPartialCoincidence	1040 = Partial coincidence error
swBodyOperationSameToolAndTarget	545 = Same tool and target error
swBodyOperationUniteSolidSheet	543 = Unite solid sheet error
swBodyOperationUnknownError	-1 = Unknown error
swBodyOperationWrongType	2 = Wrong type error

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBodyOperationType_e (Type)

SOLIDWORKS API Enumerations

swBodyOperationType_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBodyOperationType_e Enumeration

Body operation types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swBodyOperationType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBodyOperationType\_e
```

C#

```
public enum swBodyOperationType_e : System.Enum
```

C++/CLI

```
public enum class swBodyOperationType_e : public System.Enum
```

Members

Member	Description
SWBODYADD	15903
SWBODYCUT	15902
SWBODYINTERSECT	15901

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBodyType_e (Type)

SOLIDWORKS API Enumerations

swBodyType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBodyType_e Enumeration

Valid body types.

 Syntax

Visual Basic (Declaration)

Public Enum swBodyType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swBodyType_e](#)

C#

public enum swBodyType_e : System.Enum

C++/CLI

public enum class swBodyType_e : public System.Enum

 Members

Member	Description
swAllBodies	-1 = All solid and sheet bodies
swEmptyBody	5 = NULL body
swGeneralBody	4 = General, nonmanifold body
swGraphicsBody	7 = Graphics body
swMeshBody	6 = Mesh body
swMinimumBody	3 = Point body
swSheetBody	1 = Sheet body
swSolidBody	0 = Solid body
swWireBody	2 = Wire body

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swBOMConfigurationAnchorType_e (Type)

SOLIDWORKS API Enumerations

swBOMConfigurationAnchorType_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBOMConfigurationAnchorType_e Enumeration

BOM table configuration anchor types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swBOMConfigurationAnchorType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBOMConfigurationAnchorType\_e
```

C#

```
public enum swBOMConfigurationAnchorType_e : System.Enum
```

C++/CLI

```
public enum class swBOMConfigurationAnchorType_e : public System.Enum
```

Members

Member	Description
swBOMConfigurationAnchor_BottomLeft	3 = Lower-left corner
swBOMConfigurationAnchor_BottomRight	4 = Lower-right corner
swBOMConfigurationAnchor_TopLeft	1 = Upper-left corner
swBOMConfigurationAnchor_TopRight	2 = Upper-right corner

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBOMConfigurationCreationErrors_e (Type)

SOLIDWORKS API Enumerations

swBOMConfigurationCreationErrors_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swBOMConfigurationCreationErrors_e Enumeration

BOM table configuration creation errors.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swBOMConfigurationCreationErrors_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swBOMConfigurationCreationErrors\_e
```

C#

```
public enum swBOMConfigurationCreationErrors_e : System.Enum
```

C++/CLI

```
public enum class swBOMConfigurationCreationErrors_e : public System.Enum
```

Members

Member	Description
swBOMTableCreation_AlreadyExists	-3 = BOM table already exists for this drawing view
swBOMTableCreation_ExcelDisabled	-4 = BOM table cannot be created because Microsoft Excel is disabled on this system
swBOMTableCreation_Failed	-5 = BOM table creation failed because the specified template is not valid
swBOMTableCreation_MustBeDrawingView	-2 = BOM tables can only be added to a drawing view
swBOMTableCreation_NoModelForView	-6 = No model available for drawing view
swBOMTableCreation_Okay	0 = Table was successfully created
swBOMTableCreation_UnspecifiedError	-1 = Table could not be created for unknown reasons

See Also

[SolidWorks.Interop.swconst Namespace](#)

swBOMConfigurationWhatToShow_e (Type)

SOLIDWORKS API Enumerations

swBOMConfigurationWhatToShow_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swBOMConfigurationWhatToShow_e Enumeration

What to show in BOM tables.

Syntax

Visual Basic (Declaration)

Public Enum swBOMConfigurationWhatToShow_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swBOMConfigurationWhatToShow_e](#)

C#

public enum swBOMConfigurationWhatToShow_e : System.Enum

C++/CLI

public enum class swBOMConfigurationWhatToShow_e : public System.Enum

Members

Member	Description
swBOMConfiguration_ShowAllIndentedList	3 = Show all parts and subassemblies in an indented list
swBOMConfiguration_ShowPartsAndTopLevelAsm	2 = Show only parts and top-level subassemblies
swBOMConfiguration_ShowPartsOnly	1 = Show only parts

See Also

[SolidWorks.Interop.swconst Namespace](#)