

SOLIDWORKS Enumerations (swconst) — Reference (4/17): swComponentSuppressionState_e- swDatumGbLeaderStyle_e

SOLIDWORKS API Documentation (converted from CHM)

swComponentSuppressionState_e (Type)

SOLIDWORKS API Enumerations

swComponentSuppressionState_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swComponentSuppressionState_e Enumeration

States for component suppression.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swComponentSuppressionState_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swComponentSuppressionState_e](#)

C#

public enum swComponentSuppressionState_e : System.Enum

C++/CLI

public enum class swComponentSuppressionState_e : public System.Enum

Members

Member	Description
swComponentFullyLightweight	4 = Fully lightweight - recursively makes the component and any child components lightweight
swComponentFullyResolved	2 = Fully resolved - recursively resolves the component and any child components
swComponentInvalidIdMismatch	5
swComponentLightweight	1 = Lightweight - makes only the component lightweight
swComponentResolved	3 = Resolved - resolves only the component
swComponentSuppressed	0 = Fully suppressed - recursively suppresses the component and any child components

See Also

[SolidWorks.Interop.swconst Namespace](#)

swComponentVisibilityState_e (Type)

SOLIDWORKS API Enumerations

swComponentVisibilityState_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swComponentVisibilityState_e Enumeration

States for component visibility.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swComponentVisibilityState_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swComponentVisibilityState_e](#)

C#

public enum swComponentVisibilityState_e : System.Enum

C++/CLI

public enum class swComponentVisibilityState_e : public System.Enum

Members

Member	Description
swComponentHidden	0 = Component is hidden in the assembly
swComponentUnknown	-1 = Component is unknown
swComponentVisible	1 = Component is visible in the assembly

See Also

[SolidWorks.Interop.swconst Namespace](#)

swConcentricAlignmentType_e (Type)

SOLIDWORKS API Enumerations

swConcentricAlignmentType_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swConcentricAlignmentType_e Enumeration

Concentric mate alignment types.

 Syntax

Visual Basic (Declaration)

Public Enum swConcentricAlignmentType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swConcentricAlignmentType_e](#)



C#

public enum swConcentricAlignmentType_e : System.Enum

C++/CLI

public enum class swConcentricAlignmentType_e : public System.Enum

 Members

Member	Description
swConcentricAlignConcentric	0; Align both mates to be exactly concentric; neither mate is misaligned
swConcentricAlignLinkedMate	2; Align the linked mate to be exactly concentric, causing the currently edited mate to be misaligned
swConcentricAlignSymmetric	3; Misalign both concentric mates, splitting the misalignment deviation evenly between mates
swConcentricAlignThisMate	1; Align the mate currently being edited to be exactly concentric, causing the linked mate to be misaligned

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swConcentricPositionType (Type)

SOLIDWORKS API Enumerations

swConcentricPositionType Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swConcentricPositionType Enumeration

Misaligned concentric mate positions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swConcentricPositionType
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swConcentricPositionType
```

C#

```
public enum swConcentricPositionType : System.Enum
```

C++/CLI

```
public enum class swConcentricPositionType : public System.Enum
```

Members

Member	Description
swConcentricPositionType_Aligned	0
swConcentricPositionType_Default	-1
swConcentricPositionType_Symmetric	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swConfigTreeSortType_e (Type)

[SolidWorks.Interop.swconst Namespace](#) : swConfigTreeSortType_e Enumeration
Order in which configurations are listed in the ConfigurationManager.

Syntax

Visual Basic (Declaration)

```
Public Enum swConfigTreeSortType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swConfigTreeSortType\_e
```

C#

```
public enum swConfigTreeSortType_e : System.Enum
```

C++/CLI

```
public enum class swConfigTreeSortType_e : public System.Enum
```

Members

Member	Description
swSortType_DesignTable	3 = Order of the configurations in the ConfigurationManager is dictated by the order of the configurations in the design table
swSortType_History	0 = Order of the configurations in the ConfigurationManager is dictated by the date the configuration was created, from earliest created at the top of the list to most recently created at the bottom of the list
swSortType_Literal	2 = Order of the configurations in the ConfigurationManager is alphabetical
swSortType_Numeric	1 = Order of the configurations in the ConfigurationManager is by ascending alpha or numeric value

See Also

[SolidWorks.Interop.swconst Namespace](#)

swConfigurationChangeTypes_e (Type)

SOLIDWORKS API Enumerations

swConfigurationChangeTypes_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swConfigurationChangeTypes_e Enumeration

Types of configuration changes.

Syntax

Visual Basic (Declaration)

```
Public Enum swConfigurationChangeTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swConfigurationChangeTypes\_e
```

C#

```
public enum swConfigurationChangeTypes_e : System.Enum
```

C++/CLI

```
public enum class swConfigurationChangeTypes_e : public System.Enum
```

Members

Member	Description
swConfigurationChangeTypes_AddChildConfiguration	2
swConfigurationChangeTypes_AddDisplayState	6
swConfigurationChangeTypes_ChangeRepresentationParent	14
swConfigurationChangeTypes_ComponentVisibilityState	4
swConfigurationChangeTypes_ConvertToPhysicalProduct	13 = Change to Physical Product for SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; used in DAssemblyDocEvents_ConfigurationChangeNotifyEventHandler
swConfigurationChangeTypes_ConvertToRepresentation	12 = Change to Representation for SOLIDWORKS Design connected to the 3DEXPERIENCE platform only; used in DAssemblyDocEvents_ConfigurationChangeNotifyEventHandler
swConfigurationChangeTypes_CustomProperty	5
swConfigurationChangeTypes_DimensionValue	0
swConfigurationChangeTypes_Feature	9
swConfigurationChangeTypes_RemoveChildConfiguration	3
swConfigurationChangeTypes_RemoveDisplayState	7
swConfigurationChangeTypes_RenameDisplayState	8
swConfigurationChangeTypes_SuppressionState	1
swConfigurationChangeTypes_Undefined	-1
swConfigurationChangeTypes_Unused1	10 = Not used
swConfigurationChangeTypes_Unused2	11 = Not used

See Also

[SolidWorks.Interop.swconst Namespace](#)

swConfigurationOptions2_e (Type)

SOLIDWORKS API Enumerations

swConfigurationOptions2_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swConfigurationOptions2_e Enumeration

Option bits used when setting configuration options. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swConfigurationOptions2_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swConfigurationOptions2\_e
```

C#

```
public enum swConfigurationOptions2_e : System.Enum
```

C++/CLI

```
public enum class swConfigurationOptions2_e : public System.Enum
```

Members

Member	Description
swConfigOption_DoDissolveInBOM	256 or 0x100; True to dissolve the configuration in the BOM and promote all of its child components up one level, false to not
swConfigOption_DontActivate	128 or 0x80; True to not activate the configuration, false to activate the configuration
swConfigOption_DontShowPartsInBOM	2 or 0x2; True to show sub-assemblies in the Bill of Materials, false to list child components in the Bill of Materials
swConfigOption_HideByDefault	8 or 0x8; True to hide newly added components, false to not
swConfigOption_InheritProperties	Obsolete
swConfigOption_LinkToParent	64 or 0x40; True to link component to parent configuration, false to not
swConfigOption_MinFeatureManager	16 or 0x10; True to suppress new components, false to not
swConfigOption_SuppressByDefault	4 or 0x4; True to suppress newly added features and mates in this configuration, false to not
swConfigOption_UseAlternateName	1 or 0x1; True to use an alternate configuration name, false to not
swConfigOption_UseDescriptionInBOM	512 or 0x200; True to use the description in the BOM, false to not

See Also

[SolidWorks.Interop.swconst Namespace](#)

swConfigurationOptions_e (Type)

SOLIDWORKS API Enumerations

swConfigurationOptions_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swConfigurationOptions_e Enumeration

Option bits used when setting configuration options. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

```
Public Enum swConfigurationOptions_e
    Inherits System.Enum
```

Visual Basic (Usage) 

```
Dim instance As swConfigurationOptions\_e
```

C#

```
public enum swConfigurationOptions_e : System.Enum
```

C++/CLI

```
public enum class swConfigurationOptions_e : public System.Enum
```

 Members

Member	Description
swDontShowPartsInBOM	2 or 0x2
swUseAlternateName	1 or 0x1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swConfigurationType_e (Type)

SOLIDWORKS API Enumerations

swConfigurationType_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swConfigurationType_e Enumeration

Types of configurations.

 Syntax

Visual Basic (Declaration)

```
Public Enum swConfigurationType_e
    Inherits System.Enum
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As swConfigurationType\_e
```

C#

```
public enum swConfigurationType_e : System.Enum
```

C++/CLI

```
public enum class swConfigurationType_e : public System.Enum
```

 Members

Member	Description
swConfiguration_AsMachined	1
swConfiguration_AsWelded	2
swConfiguration_Defeature	5
swConfiguration_SheetMetal	3
swConfiguration_SpeedPak	4
swConfiguration_Standard	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swConnectedSegmentsOption_e (Type)

SOLIDWORKS API Enumerations

swConnectedSegmentsOption_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swConnectedSegmentsOption_e Enumeration

Types of structural weldment segment connections.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swConnectedSegmentsOption_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swConnectedSegmentsOption\_e
```

C#

```
public enum swConnectedSegmentsOption_e : System.Enum
```

C++/CLI

```
public enum class swConnectedSegmentsOption_e : public System.Enum
```

Members

Member	Description
swConnectedSegments_CopedCut	2
swConnectedSegments_SimpleCut	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swConnectedSyncSettingsErrors_e (Type)

SOLIDWORKS API Enumerations

swConnectedSyncSettingsErrors_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swConnectedSyncSettingsErrors_e Enumeration

Return codes for [ISldWorks::UploadToMySolidWorksSettings](#) and [ISldWorks::DownloadFromMySolidWorksSettings](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swConnectedSyncSettingsErrors_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swConnectedSyncSettingsErrors\_e
```

C#

```
public enum swConnectedSyncSettingsErrors_e : System.Enum
```

C++/CLI

```
public enum class swConnectedSyncSettingsErrors_e : public System.Enum
```

Members

Member	Description
swConnectedSyncSettings_ConnectedDisabled	1
swConnectedSyncSettings_ConnectedNotLoggedIn	2
swConnectedSyncSettings_Success	0
swConnectedSyncSettings_UploadDownloadError	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swConnectionPointType_e (Type)

SOLIDWORKS API Enumerations

swConnectionPointType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swConnectionPointType_e Enumeration

Connection point types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swConnectionPointType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swConnectionPointType\_e
```

C#

```
public enum swConnectionPointType_e : System.Enum
```

C++/CLI

```
public enum class swConnectionPointType_e : public System.Enum
```

 Members

Member	Description
swConnectionPoint_Electrical	3
swConnectionPoint_FabricatedPipe	2
swConnectionPoint_Tube	1
swConnectionPoint_UserDefined	4

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swConstrainedCornerAction_e (Type)

SOLIDWORKS API Enumerations

swConstrainedCornerAction_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swConstrainedCornerAction_e Enumeration

Actions to take if the corner to be filleted is constrained or has a dimension.

 Syntax

Visual Basic (Declaration)

Public Enum swConstrainedCornerAction_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swConstrainedCornerAction_e](#)



C#

public enum swConstrainedCornerAction_e : System.Enum

C++/CLI

public enum class swConstrainedCornerAction_e : public System.Enum

 Members

Member	Description
swConstrainedCornerDeleteGeometry	2 = Delete the constraint or dimension and add the fillet
swConstrainedCornerInteract	0 = Ask the user whether to delete the geometry or stop processing
swConstrainedCornerKeepGeometry	1 = Keep the constraint or dimension by creating a virtual intersection point before adding the fillet
swConstrainedCornerStopProcessing	3 = Do not delete the constraint or dimension and do not create the fillet

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swConstrainedStatus_e (Type)

SOLIDWORKS API Enumerations

swConstrainedStatus_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swConstrainedStatus_e Enumeration

Status of sketch constraints.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swConstrainedStatus_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swConstrainedStatus_e](#)

C#

public enum swConstrainedStatus_e : System.Enum

C++/CLI

public enum class swConstrainedStatus_e : public System.Enum

 Members

Member	Description
swAutosolveOff	7
swFullyConstrained	3
swInvalidSolution	6
swNoSolution	5
swOverConstrained	4
swUnderConstrained	2
swUnknownConstraint	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swConstraintType_e (Type)

SOLIDWORKS API Enumerations

swConstraintType_e Enumeration

See Also

[Send comments on this topic.](#)



[SolidWorks.Interop.swconst Namespace](#) : swConstraintType_e Enumeration
Sketch constraints.

Syntax

Visual Basic (Declaration)

```
Public Enum swConstraintType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swConstraintType\_e
```

C#

```
public enum swConstraintType_e : System.Enum
```

C++/CLI

```
public enum class swConstraintType_e : public System.Enum
```

Members

Member	Description
swConstraintType_ALONGX	48
swConstraintType_ALONGX3D	64
swConstraintType_ALONGXPOINTS	51
swConstraintType_ALONGXPOINTS3D	66
swConstraintType_ALONGY	49
swConstraintType_ALONGY3D	65
swConstraintType_ALONGYPOINTS	52
swConstraintType_ALONGYPOINTS3D	67
swConstraintType_ALONGZ	50
swConstraintType_ALONGZPOINTS	53
swConstraintType_ANGLE	2
swConstraintType_ANGLE3P	43
swConstraintType_ARCANG180	19
swConstraintType_ARCANG270	20
swConstraintType_ARCANG90	18
swConstraintType_ARCANGBOTTOM	22
swConstraintType_ARCANGLEFT	23
swConstraintType_ARCANGRIGHT	24
swConstraintType_ARCANGTOP	21
swConstraintType_ARCLENGTH	44
swConstraintType_ATINTERSECT	13
swConstraintType_ATMIDDLE	12
swConstraintType_ATPIERCE	40
swConstraintType_BELTTRACTION	69
swConstraintType_BLOCKFIXEDLOCK	70 = Lock two blocks together
swConstraintType_BLOCKNORMALLOCK	71 = Lock blocks to be normal to one another (3D sketch)
swConstraintType_BLOCKROTATELOCK	72 = Lock blocks to rotate around each other (3D sketch)
swConstraintType_C3TOUCH	83
swConstraintType_CIRCULARPATCNT	77
swConstraintType_COINCIDENT	9
swConstraintType_COLINEAR	27
swConstraintType_CONCENTRIC	10
swConstraintType_CONICRHO	82
swConstraintType_CORADIAL	28
swConstraintType_DIAMETER	15
swConstraintType_DISTANCE	1
swConstraintType_DOUBLEANGLE	84 = Double angle display
swConstraintType_DOUBLEDISTANCE	41
swConstraintType_ELLIPSEANG180	34
swConstraintType_ELLIPSEANG270	35
swConstraintType_ELLIPSEANG90	33
swConstraintType_ELLIPSEANGBOTTOM	37
swConstraintType_ELLIPSEANGLEFT	38
swConstraintType_ELLIPSEANGRIGHT	39
swConstraintType_ELLIPSEANGTOP	36
swConstraintType_EQUALCURV3DALIGN	80 = Aligned equal curvature between 3D splines
swConstraintType_EQUALCURVATURE	61
swConstraintType_EQUALTANGENT	62
swConstraintType_FAKESLOTCONSTRAINT	73 = Not actually a constraint; for display purposes only
swConstraintType_FITSPLINE	60
swConstraintType_FIXED	17
swConstraintType_FIXEDSLOT	74 = Fix a slot
swConstraintType_FLANGEFACEDIST	81 = Distance from virtual point to the relevant flange face
swConstraintType_HORIZONTAL	4
swConstraintType_HORIZPOINTS	25
swConstraintType_INTERSECTION	56
swConstraintType_INVALIDCTYPE	0

swConstraintType_ISOBYPOINT	58 = ISO curve when its constraint parameter is determined by an external point
swConstraintType_LINEARPATTCNT	76
swConstraintType_MERGEPOINTS	42
swConstraintType_NORMAL	45
swConstraintType_NORMALPOINTS	46
swConstraintType_OFFSETEdge	16
swConstraintType_PARALLEL	7
swConstraintType_PARALLELYZ	54
swConstraintType_PARALLELZX	55
swConstraintType_PATTERNE	57
swConstraintType_PERPENDICULAR	8
swConstraintType_PLANAROFFSET	79 = For routing pipe offsets
swConstraintType_RADIALOFFSET	78 = For routing pipe offsets
swConstraintType_RADIUS	3
swConstraintType_SAMECURVELENGTH	85 = Equal arc/spline length
swConstraintType_SAMEISOPARAM	59 = Common relation for all pieces (for the face) of the surface's iso curve
swConstraintType_SAMELENGTH	14
swConstraintType_SAMESLOTS	75 = Same slot width and length
swConstraintType_SKETCHOFFSET	47 = Between entities of the same sketch
swConstraintType_SNAPANGLE	31
swConstraintType_SNAPGRID	29
swConstraintType_SNAPLENGTH	30
swConstraintType_SYMMETRIC	11
swConstraintType_TANGENT	6
swConstraintType_TANGENTFACE	63
swConstraintType_TRACTION	68
swConstraintType_USEEDGE	32
swConstraintType_VERTICAL	5 = Applies only to sketch lines
swConstraintType_VERTPOINTS	26 = Applies only to sketch points

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swContactType_e (Type)

SOLIDWORKS API Enumerations

swContactType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swContactType_e Enumeration

Curve control contact types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swContactType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swContactType_e](#)

C#

public enum swContactType_e : System.Enum

C++/CLI

public enum class swContactType_e : public System.Enum

Members

Member	Description
swContact	0
swCurvature	2
swTangent	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swControlBitmapLabelType_e (Type)

SOLIDWORKS API Enumerations

swControlBitmapLabelType_e Enumeration

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swControlBitmapLabelType_e Enumeration

SOLIDWORKS bitmap types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swControlBitmapLabelType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swControlBitmapLabelType_e](#)

C#

public enum swControlBitmapLabelType_e : System.Enum

C++/CLI

public enum class swControlBitmapLabelType_e : public System.Enum

Members

Member	Description
swBitmapLabel_AngularDistance	2
swBitmapLabel_BendAllowance	21
swBitmapLabel_BendDeduction	22
swBitmapLabel_CircularPattern	17
swBitmapLabel_Depth	19
swBitmapLabel_Diameter	10
swBitmapLabel_KFactor	20
swBitmapLabel_LinearDistance	1
swBitmapLabel_LinearDistance1	12
swBitmapLabel_LinearDistance2	13
swBitmapLabel_LinearPattern	16
swBitmapLabel_Radius	11
swBitmapLabel_RipGap	23
swBitmapLabel_SelectBoundary	25
swBitmapLabel_SelectComponent	9
swBitmapLabel_SelectEdge	7
swBitmapLabel_SelectEdgeFaceVertex	3
swBitmapLabel_SelectFace	6
swBitmapLabel_SelectFaceEdge	8
swBitmapLabel_SelectFaceSurface	4
swBitmapLabel_SelectProfile	24
swBitmapLabel_SelectVertex	5
swBitmapLabel_Thickness1	14
swBitmapLabel_Thickness2	15
swBitmapLabel_Width	18

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCoordSysElementType_e (Type)

SOLIDWORKS API Enumerations

swCoordSysElementType_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swCoordSysElementType_e Enumeration

Coordinate system element types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCoordSysElementType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCoordSysElementType\_e
```

C#

```
public enum swCoordSysElementType_e : System.Enum
```

C++/CLI

```
public enum class swCoordSysElementType_e : public System.Enum
```

 Members

Member	Description
swCoordSysElement_Point	6
swCoordSysElement_XAxis	3
swCoordSysElement_XYPlane	0
swCoordSysElement_XZPlane	1
swCoordSysElement_YAxis	4
swCoordSysElement_YZPlane	2
swCoordSysElement_ZAxis	5

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCoreFeatureDirection_e (Type)

SOLIDWORKS API Enumerations

swCoreFeatureDirection_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCoreFeatureDirection_e Enumeration

Directions for core features.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCoreFeatureDirection_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCoreFeatureDirection\_e
```

C#

```
public enum swCoreFeatureDirection_e : System.Enum
```

C++/CLI

```
public enum class swCoreFeatureDirection_e : public System.Enum
```

 Members

Member	Description
swCoreAlongExtractionDirection	0
swCoreAwayFromExtractionDirection	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCornerReliefBendType_e (Type)

SOLIDWORKS API Enumerations

swCornerReliefBendType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCornerReliefBendType_e Enumeration

Sheet metal corner relief bend types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swCornerReliefBendType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCornerReliefBendType_e](#)

C#

public enum swCornerReliefBendType_e : System.Enum

C++/CLI

public enum class swCornerReliefBendType_e : public System.Enum

Members

Member	Description
swCornerReliefBendType_ThreeBend	1
swCornerReliefBendType_TwoBend	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCornerReliefError_e (Type)

SOLIDWORKS API Enumerations

swCornerReliefError_e Enumeration

See Also

 SolidWorks.Interop.swconst Namespace : swCornerReliefError_e Enumeration

Sheet metal corner relief errors.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swCornerReliefError_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCornerReliefError_e](#)

C#

public enum swCornerReliefError_e : System.Enum

C++/CLI

public enum class swCornerReliefError_e : public System.Enum

Members

Member	Description
swCornerReliefError_GenericFailure	6
swCornerReliefError_IndexNotAvailable	5
swCornerReliefError_InvalidBody	2
swCornerReliefError_InvalidCornerType	3
swCornerReliefError_InvalidFaces	1
swCornerReliefError_InvalidReliefType	4
swCornerReliefError_None	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCornerReliefSuitCaseType_e (Type)

SOLIDWORKS API Enumerations

swCornerReliefSuitCaseType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCornerReliefSuitCaseType_e Enumeration

Sheet metal corner relief suitcase types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCornerReliefSuitCaseType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCornerReliefSuitCaseType\_e
```

C#

```
public enum swCornerReliefSuitCaseType_e : System.Enum
```

C++/CLI

```
public enum class swCornerReliefSuitCaseType_e : public System.Enum
```

 Members

Member	Description
swCornerReliefSuitCase_Default	0 = Leaves the gap unchanged
swCornerReliefSuitCase_ExtendGapInBendArea	1 = Cut the corner relief with the gap
swCornerReliefSuitCase_FillInSomeGap	2 = Extends the corner relief material into the gap

 Remarks

A suitcase is a closed spherical corner without any cutouts.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCornerReliefType_e (Type)

SOLIDWORKS API Enumerations

swCornerReliefType_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swCornerReliefType_e Enumeration

Corner reliefs.

 Syntax

Visual Basic (Declaration)

Public Enum swCornerReliefType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swCornerReliefType_e](#)

C#

public enum swCornerReliefType_e : System.Enum

C++/CLI

public enum class swCornerReliefType_e : public System.Enum

 Members

Member	Description
swCornerBendWaistRelief	Obsolete.
swCornerCircularRelief	0
swCornerConstantWidthRelief	4
swCornerFullRoundRelief	7
swCornerMixed	Obsolete.
swCornerObroundRelief	5
swCornerRectangularRelief	9
swCornerSquareRelief	Obsolete.
swCornerSutCaseRelief	8
swCornerTearRelief	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCornerTreatmentPlanarTrimOptions_e (Type)

SOLIDWORKS API Enumerations

swCornerTreatmentPlanarTrimOptions_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCornerTreatmentPlanarTrimOptions_e Enumeration

Structure system corner treatment planar trim options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCornerTreatmentPlanarTrimOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCornerTreatmentPlanarTrimOptions\_e
```

C#

```
public enum swCornerTreatmentPlanarTrimOptions_e : System.Enum
```

C++/CLI

```
public enum class swCornerTreatmentPlanarTrimOptions_e : public System.Enum
```

Members

Member	Description
swCornerTreatmentPlanarTrim_FirstContact	0 = Trims the member when it first comes into contact with adjacent faces
swCornerTreatmentPlanarTrim_FullContact	1 = Trims the member flush with adjacent faces

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCornerTreatmentPlanarTrimToolType_e (Type)

SOLIDWORKS API Enumerations

swCornerTreatmentPlanarTrimToolType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCornerTreatmentPlanarTrimToolType_e Enumeration

Structure system corner treatment planar trim tool types.

 Syntax

Visual Basic (Declaration)

Public Enum swCornerTreatmentPlanarTrimToolType_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swCornerTreatmentPlanarTrimToolType_e](#)

C#

public enum swCornerTreatmentPlanarTrimToolType_e : System.Enum

C++/CLI

public enum class swCornerTreatmentPlanarTrimToolType_e : public System.Enum

 Members

Member	Description
swCornerTreatmentPlanarTrimTool_Automatic	0 = Planar trim options are enabled
swCornerTreatmentPlanarTrimTool_UserDefined	1 = User defined trim faces are used

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCornerTreatmentTrimType_e (Type)

SOLIDWORKS API Enumerations

swCornerTreatmentTrimType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCornerTreatmentTrimType_e Enumeration

Structure system corner treatment trim types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swCornerTreatmentTrimType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCornerTreatmentTrimType_e](#)

C#

public enum swCornerTreatmentTrimType_e : System.Enum

C++/CLI

public enum class swCornerTreatmentTrimType_e : public System.Enum

Members

Member	Description
swCornerTreatmentTrim_BodyTrim	1 = Conforms the intersecting member to the shape of adjacent faces by adding or removing material according to trim order
swCornerTreatmentTrim_MiterTrim	2 = Trims the members at a 45 degree angle; valid only for two member corner treatments
swCornerTreatmentTrim_PlanarTrim	0 = Cuts the intersecting member with a plane using first contact or full contact trim

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCornerType_e (Type)

SOLIDWORKS API Enumerations

swCornerType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swCornerType_e Enumeration

Structure system corner types.

Syntax

Visual Basic (Declaration)

```
Public Enum swCornerType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCornerType\_e
```

C#

```
public enum swCornerType_e : System.Enum
```

C++/CLI

```
public enum class swCornerType_e : public System.Enum
```

Members

Member	Description
swCorner_Complex	2 = Three or more members intersect with several trim options
swCorner_Simple	0 = Two members intersect with two trim options
swCorner_TwoMember	1 = Two members intersect with three trim options

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCosmeticConfigOptions_e (Type)

SOLIDWORKS API Enumerations

swCosmeticConfigOptions_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swCosmeticConfigOptions_e Enumeration

Cosmetic thread configuration options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCosmeticConfigOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCosmeticConfigOptions\_e
```

C#

```
public enum swCosmeticConfigOptions_e : System.Enum
```

C++/CLI

```
public enum class swCosmeticConfigOptions_e : public System.Enum
```

Members

Member	Description
swConfigOptions_AllConfiguration	2
swConfigOptions_SpecifyConfiguration	3
swConfigOptions_ThisConfiguration	1

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCosmeticEndConditions_e (Type)

SOLIDWORKS API Enumerations

swCosmeticEndConditions_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swCosmeticEndConditions_e Enumeration

Cosmetic thread end conditions.

Syntax

Visual Basic (Declaration)

```
Public Enum swCosmeticEndConditions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCosmeticEndConditions\_e
```

C#

```
public enum swCosmeticEndConditions_e : System.Enum
```

C++/CLI

```
public enum class swCosmeticEndConditions_e : public System.Enum
```

Members

Member	Description
swEndConditionBlind	0
swEndConditionBlind2Dia	3
swEndConditionBlindUptoNext	1
swEndConditionThrough	2

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCosmeticStandardType_e (Type)

SOLIDWORKS API Enumerations

swCosmeticStandardType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swCosmeticStandardType_e Enumeration

Cosmetic thread standard types.

Syntax

Visual Basic (Declaration)

```
Public Enum swCosmeticStandardType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCosmeticStandardType\_e
```

C#

```
public enum swCosmeticStandardType_e : System.Enum
```

C++/CLI

```
public enum class swCosmeticStandardType_e : public System.Enum
```

Members

Member	Description
swStandardType_StandardAnsiInch	0
swStandardType_StandardAnsiMetric	1
swStandardType_StandardAS	16
swStandardType_StandardBSI	2
swStandardType_StandardDIN	4
swStandardType_StandardDME	3
swStandardType_StandardGB	13
swStandardType_StandardHascoMetric	5
swStandardType_StandardHelicoilInch	6
swStandardType_StandardHelicoilMetric	7
swStandardType_StandardIS	15
swStandardType_StandardISO	8
swStandardType_StandardJIS	9
swStandardType_StandardKS	14
swStandardType_StandardNone	-2
swStandardType_StandardPCS	10
swStandardType_StandardProgressive	11
swStandardType_StandardSuperior	12

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCosmeticThreadDiameterType_e (Type)

SOLIDWORKS API Enumerations

swCosmeticThreadDiameterType_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCosmeticThreadDiameterType_e Enumeration

Cosmetic thread diameter types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swCosmeticThreadDiameterType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCosmeticThreadDiameterType_e](#)

C#

public enum swCosmeticThreadDiameterType_e : System.Enum

C++/CLI

public enum class swCosmeticThreadDiameterType_e : public System.Enum

Members

Member	Description
swCosmeticThread_ConicalOffset	1 = Conical hole
swCosmeticThread_MajorDiameter	2 = Cut or hole
swCosmeticThread_MinorDiameter	3 = Boss

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCosmeticThreadType_e (Type)

SOLIDWORKS API Enumerations

swCosmeticThreadType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCosmeticThreadType_e Enumeration

Cosmetic thread types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCosmeticThreadType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCosmeticThreadType\_e
```

C#

```
public enum swCosmeticThreadType_e : System.Enum
```

C++/CLI

```
public enum class swCosmeticThreadType_e : public System.Enum
```

 Members

Member	Description
swApplyCosmeticThread_Blind	0 = Runs the thread for a specified distance
swApplyCosmeticThread_ThroughFeature	2 = Runs the thread through the object
swApplyCosmeticThread_UpToNext	1 = Runs the thread to the next face

 Remarks

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCosmeticWeldBeadMode_e (Type)

SOLIDWORKS API Enumerations

swCosmeticWeldBeadMode_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCosmeticWeldBeadMode_e Enumeration

Cosmetic weld bead modes

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swCosmeticWeldBeadMode_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCosmeticWeldBeadMode_e](#)

C#

public enum swCosmeticWeldBeadMode_e : System.Enum

C++/CLI

public enum class swCosmeticWeldBeadMode_e : public System.Enum

Members

Member	Description
swCosmeticWeldBeadMode_WeldGeometry	0
swCosmeticWeldBeadMode_WeldPath	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCosmeticWeldBeadSide_e (Type)

SOLIDWORKS API Enumerations

swCosmeticWeldBeadSide_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCosmeticWeldBeadSide_e Enumeration

Cosmetic weld bead options.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swCosmeticWeldBeadSide_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCosmeticWeldBeadSide_e](#)



C#

public enum swCosmeticWeldBeadSide_e : System.Enum

C++/CLI

public enum class swCosmeticWeldBeadSide_e : public System.Enum

 Members

Member	Description
swCosmeticWeldBeadSide_allAround	3 = Apply the weld bead to the selected face or edge and to all adjacent faces or edges
swCosmeticWeldBeadSide_bothSides	2 = Apply the weld bead to the selected face or edge and to the opposite face or edge
swCosmeticWeldBeadSide_selection	1 = Apply the weld bead to the selected face or edge

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCosmosWorksMat (Type)

SOLIDWORKS API Enumerations

swCosmosWorksMat Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swCosmosWorksMat Enumeration

SOLIDWORKS Simulation (formerly called COSMOSWorks) materials.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swCosmosWorksMat
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCosmosWorksMat](#)

C#

public enum swCosmosWorksMat : System.Enum

C++/CLI

public enum class swCosmosWorksMat : public System.Enum

Members

Member	Description
swCosmosWorksMatAcrylic	1
swCosmosWorksMatAluminum	2
swCosmosWorksMatNone	0
swCosmosWorksMatNylon	3
swCosmosWorksMatRubber	4
swCosmosWorksMatSteel	5

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateAngRunDimError_e (Type)

SOLIDWORKS API Enumerations

swCreateAngRunDimError_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCreateAngRunDimError_e Enumeration

Statuses when inserting an angular running dimension.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCreateAngRunDimError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCreateAngRunDimError\_e
```

C#

```
public enum swCreateAngRunDimError_e : System.Enum
```

C++/CLI

```
public enum class swCreateAngRunDimError_e : public System.Enum
```

Members

Member	Description
swCreateAngRunDimError_GenFailure	0 = Cannot create this angular running dimension
swCreateAngRunDimError_IdenticalDimension	2 = Identical dimensions cannot be created in the same angular running dimension
swCreateAngRunDimError_SelectAnotherEntity	3 = Cannot use the selected entity to create this angular running dimension; select another entity
swCreateAngRunDimError_Success	1
swCreateAngRunDimError_Undefined	-1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateCommandGroupErrors (Type)

SOLIDWORKS API Enumerations

swCreateCommandGroupErrors Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swCreateCommandGroupErrors Enumeration

Error codes for creating CommandGroups.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCreateCommandGroupErrors
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCreateCommandGroupErrors
```

C#

```
public enum swCreateCommandGroupErrors : System.Enum
```

C++/CLI

```
public enum class swCreateCommandGroupErrors : public System.Enum
```

 Members

Member	Description
swCreateCommandGroup_Exceeds_ToolBarIds	2
swCreateCommandGroup_Failed	0
swCreateCommandGroup_Success	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateExplodeStepError_e (Type)

SOLIDWORKS API Enumerations

swCreateExplodeStepError_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCreateExplodeStepError_e Enumeration

Return codes when creating an explode step.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCreateExplodeStepError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCreateExplodeStepError\_e
```

C#

```
public enum swCreateExplodeStepError_e : System.Enum
```

C++/CLI

```
public enum class swCreateExplodeStepError_e : public System.Enum
```

Members

Member	Description
swCreateExplodeStepError_EditingComponentInContext	6 = A component being edited in context is blocking explode step creation.
swCreateExplodeStepError_Generic	1 = Explode step creation failed.
swCreateExplodeStepError_InvalidRadialAxis	4 = A radial explode step is not allowed using the selected components.
swCreateExplodeStepError_NoComponents	3 = Components to move must be selected.
swCreateExplodeStepError_NoExplodeView	2 = An explode view must be active in the current configuration to create an explode step.
swCreateExplodeStepError_OpenExplodePMP	5 = The open Explode PropertyManager is blocking step creation.
swCreateExplodeStepError_Successful	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateFacesBodyAction_e (Type)

SOLIDWORKS API Enumerations

swCreateFacesBodyAction_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swCreateFacesBodyAction_e Enumeration

Options for creating missing faces on an open body.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swCreateFacesBodyAction_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCreateFacesBodyAction_e](#)

C#

public enum swCreateFacesBodyAction_e : System.Enum

C++/CLI

public enum class swCreateFacesBodyAction_e : public System.Enum

Members

Member	Description
swCreateFacesBodyActionCap	1 = Cap the missing face
swCreateFacesBodyActionGrow	2 = Grow the missing face
swCreateFacesBodyActionGrowFromParent	3 = Grow the missing face from the parent
swCreateFacesBodyActionLeaveRubber	4 = Create a virtual face topological entity without any associated geometry

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateFeatureBodyOpts_e (Type)

SOLIDWORKS API Enumerations

swCreateFeatureBodyOpts_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCreateFeatureBodyOpts_e Enumeration

Options for creating bodies. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCreateFeatureBodyOpts_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCreateFeatureBody0pts\_e
```

C#

```
public enum swCreateFeatureBody0pts_e : System.Enum
```

C++/CLI

```
public enum class swCreateFeatureBody0pts_e : public System.Enum
```

Members

Member	Description
swCreateFeatureBodyCheck	1 or 0x1; Check body
swCreateFeatureBodySimplify	2 or 0x2; Simplify body

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateFeatureError_e (Type)

SOLIDWORKS API Enumerations

swCreateFeatureError_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCreateFeatureError_e Enumeration

Error codes that may occur when creating a feature.

Syntax

Visual Basic (Declaration)

```
Public Enum swCreateFeatureError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCreateFeatureError\_e
```

C#

```
public enum swCreateFeatureError_e : System.Enum
```

C++/CLI

```
public enum class swCreateFeatureError_e : public System.Enum
```

Members

Member	Description
swCreateFeatureError_GenricError_GeometricError	0 = Inputs provided resulted in a geometric error
swCreateFeatureError_GenricError_UnknownError	1 = Failure reason unknown
swCreateFeatureError_MateController_DimensionValueOutOfLimit	5 = Value for dimension provided is out of range
swCreateFeatureError_MateController_FailedToSolveMates	4 = Inputs provided failed to solve mates
swCreateFeatureError_MateController_MateNotSet	2 = Mate not set when creating mate controller
swCreateFeatureError_MateController_MateSelectionsPositionDataMismatch	6 = Number of mate selections do not match number of values in position data array
swCreateFeatureError_MateController_MateTypeNotSupported	3 = Supported mate types are Distance and Limit Distance, Angle and Limit Angle, Width, and Slot
swCreateFeatureError_SolidToSheetMetal_FixedFaceOrEdgesMissing	8
swCreateFeatureError_SolidToSheetMetal_Success	7

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateOrdDimError_e (Type)

SOLIDWORKS API Enumerations

swCreateOrdDimError_e Enumeration

See Also

 SolidWorks.Interop.swconst Namespace : swCreateOrdDimError_e Enumeration

Errors when inserting an ordinate dimension.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCreateOrdDimError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCreateOrdDimError\_e
```

C#

```
public enum swCreateOrdDimError_e : System.Enum
```

C++/CLI

```
public enum class swCreateOrdDimError_e : public System.Enum
```

Members

Member	Description
swCreateOrdDimErr_GenBadSel	3
swCreateOrdDimErr_GenExtraSelection	6
swCreateOrdDimErr_GenFailure	7
swCreateOrdDimErr_GenNeedModelLoaded	4
swCreateOrdDimErr_GenNoInternalDims	2
swCreateOrdDimErr_GenSamePartOnly	5
swCreateOrdDimErr_OrdBadDir	9
swCreateOrdDimErr_OrdDupInGroup	8
swCreateOrdDimErr_OrdFailure	1
swCreateOrdDimErr_Success	0
swCreateOrdDimErr_Undefined	-1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreatePartExplodeStepError_e (Type)

SOLIDWORKS API Enumerations

swCreatePartExplodeStepError_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCreatePartExplodeStepError_e Enumeration

Result codes when creating explode steps for multibody parts.

Syntax

Visual Basic (Declaration)

```
Public Enum swCreatePartExplodeStepError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCreatePartExplodeStepError\_e
```

C#

```
public enum swCreatePartExplodeStepError_e : System.Enum
```

C++/CLI

```
public enum class swCreatePartExplodeStepError_e : public System.Enum
```

Members

Member	Description
swCreatePartExplodeStepError_Generic	1
swCreatePartExplodeStepError_InactiveConfiguration	4
swCreatePartExplodeStepError_NoBodies	2
swCreatePartExplodeStepError_OpenExplodePMP	3
swCreatePartExplodeStepError_Successful	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateSectionViewAtOptions_e (Type)

SOLIDWORKS API Enumerations

swCreateSectionViewAtOptions_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swCreateSectionViewAtOptions_e Enumeration

Options that affect the section view that is created. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swCreateSectionViewAtOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCreateSectionViewAtOptions_e](#)

C#

public enum swCreateSectionViewAtOptions_e : System.Enum

C++/CLI

public enum class swCreateSectionViewAtOptions_e : public System.Enum

Members

Member	Description
swCreateSectionView_ChangeDirection	4 or 0x4; If set, then the direction of this section view is switched; if not set, then the direction of this section view is not switched
swCreateSectionView_CutSurfaceBodies	128 or 0x80; If set, then shows only the intersecting line of a surface in a section view
swCreateSectionView_DisplaySurfaceCut	32 or 0x20; If set, then only the surfaces cut by the section line appear in the section view; if not set, then all model surfaces appear in the section view
swCreateSectionView_ExcludeFasteners	64 or 0x40; If set, then fasteners are not included in the section view; if not set, then fasteners are included in the section view
swCreateSectionView_NotAligned	1 or 0x1; If set, then the section does not snap into alignment with the parent view; if not set, then the section snaps into alignment with the parent view
swCreateSectionView_OffsetSection	2 or 0x2; If set, then an aligned section view is created (two lines at an angle); if not set, a normal projection section view is created
swCreateSectionView_Partial	16 or 0x10; If set, then a partial section view is created; if not set, then a complete section view is created
swCreateSectionView_ScaleWithModel	8 or 0x8; If set, then the section view is scaled with the model; if not set, then the section view is not scaled with the model

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateSeedCutType_e (Type)

SOLIDWORKS API Enumerations

swCreateSeedCutType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swCreateSeedCutType_e Enumeration

Pattern seed cut types.

Syntax

Visual Basic (Declaration)

```
Public Enum swCreateSeedCutType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCreateSeedCutType\_e
```

C#

```
public enum swCreateSeedCutType_e : System.Enum
```

C++/CLI

```
public enum class swCreateSeedCutType_e : public System.Enum
```

Members

Member	Description
swCreateSeedCutCircle	1
swCreateSeedCutDiamond	3
swCreateSeedCutNone	0
swCreateSeedCutPolygon	4
swCreateSeedCutSquare	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCreateWireBodyOptions_e (Type)

SOLIDWORKS API Enumerations

swCreateWireBodyOptions_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swCreateWireBodyOptions_e Enumeration

Options for creating wire bodies. [Bitmask](#).

Syntax

Visual Basic (Declaration)

Public Enum swCreateWireBodyOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCreateWireBodyOptions_e](#)

C#

public enum swCreateWireBodyOptions_e : System.Enum

C++/CLI

public enum class swCreateWireBodyOptions_e : public System.Enum

Members

Member	Description
swCreateWireBodyByDefault	0 or 0x0
swCreateWireBodyMergeCurves	1 or 0x1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCropViewErrors_e (Type)

SOLIDWORKS API Enumerations

swCropViewErrors_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swCropViewErrors_e Enumeration

Errors when cropping views.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCropViewErrors_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCropViewErrors\_e
```

C#

```
public enum swCropViewErrors_e : System.Enum
```

C++/CLI

```
public enum class swCropViewErrors_e : public System.Enum
```

 Members

Member	Description
swCropViewErrors_CannotCropDetailOrBrokenView	2 = Cannot crop detail or broken view
swCropViewErrors_CannotUnfoldView	3 = Cannot unfold view
swCropViewErrors_IncorrectProfile	4 = Bad spline
swCropViewErrors_NoError	1
swCropViewErrors_Unknown	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCrossHatchFilter_e (Type)

SOLIDWORKS API Enumerations

swCrossHatchFilter_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swCrossHatchFilter_e Enumeration

Cross hatch filters.

 Syntax

Visual Basic (Declaration)

Public Enum swCrossHatchFilter_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swCrossHatchFilter_e](#)

C#

public enum swCrossHatchFilter_e : System.Enum

C++/CLI

public enum class swCrossHatchFilter_e : public System.Enum

 Members

Member	Description
swCrossHatchAndExplodeOnly	3
swCrossHatchExclude	1
swCrossHatchInclude	0
swCrossHatchOnly	2
swSolidHatchOnly	4

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCurveDrivenPatternAlignment_e (Type)

SOLIDWORKS API Enumerations

swCurveDrivenPatternAlignment_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swCurveDrivenPatternAlignment_e Enumeration

Curve-driven pattern alignments.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCurveDrivenPatternAlignment_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCurveDrivenPatternAlignment\_e
```

C#

```
public enum swCurveDrivenPatternAlignment_e : System.Enum
```

C++/CLI

```
public enum class swCurveDrivenPatternAlignment_e : public System.Enum
```

Members

Member	Description
swCurvePatternAlignToSeed	1
swCurvePatternTangentToCurve	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCurveDrivenPatternCurveMethod_e (Type)

SOLIDWORKS API Enumerations

swCurveDrivenPatternCurveMethod_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCurveDrivenPatternCurveMethod_e Enumeration

Curve methods.

 Syntax

Visual Basic (Declaration)

Public Enum swCurveDrivenPatternCurveMethod_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swCurveDrivenPatternCurveMethod_e](#)

C#

public enum swCurveDrivenPatternCurveMethod_e : System.Enum

C++/CLI

public enum class swCurveDrivenPatternCurveMethod_e : public System.Enum

 Members

Member	Description
swCurvePatternOffsetCurve	1
swCurvePatternTransformCurve	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCurveTypes_e (Type)

SOLIDWORKS API Enumerations

swCurveTypes_e Enumeration

See Also

[Send comments on this topic.](#)

 SolidWorks.Interop.swconst Namespace : swCurveTypes_e Enumeration

Curve types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCurveTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCurveTypes\_e
```

C#

```
public enum swCurveTypes_e : System.Enum
```

C++/CLI

```
public enum class swCurveTypes_e : public System.Enum
```

 Members

Member	Description
BCURVE_TYPE	3005
CIRCLE_TYPE	3002
CONSTPARAM_TYPE	3008
ELLIPSE_TYPE	3003
INTERSECTION_TYPE	3004
LINE_TYPE	3001
SPCURVE_TYPE	3006
TRIMMED_TYPE	3009

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCustomInfoAddResult_e (Type)

SOLIDWORKS API Enumerations

swCustomInfoAddResult_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swCustomInfoAddResult_e Enumeration

Result codes when adding custom properties.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCustomInfoAddResult_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCustomInfoAddResult\_e
```

C#

```
public enum swCustomInfoAddResult_e : System.Enum
```

C++/CLI

```
public enum class swCustomInfoAddResult_e : public System.Enum
```

Members

Member	Description
swCustomInfoAddResult_AddedOrChanged	0 = Success
swCustomInfoAddResult_GenericFail	1 = Failed to add the custom property
swCustomInfoAddResult_MismatchAgainstExistingType	2 = Existing custom property with the same name has a different type
swCustomInfoAddResult_MismatchAgainstLegacyTypes	4 = Cannot add the specified custom property to legacy architecture
swCustomInfoAddResult_MismatchAgainstSpecifiedType	3 = Specified value of the custom property does not match the specified type

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCustomInfoDeleteResult_e (Type)

SOLIDWORKS API Enumerations

swCustomInfoDeleteResult_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCustomInfoDeleteResult_e Enumeration

Result codes when deleting custom properties.

Syntax

Visual Basic (Declaration)

```
Public Enum swCustomInfoDeleteResult_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCustomInfoDeleteResult\_e
```

C#

```
public enum swCustomInfoDeleteResult_e : System.Enum
```

C++/CLI

```
public enum class swCustomInfoDeleteResult_e : public System.Enum
```

Members

Member	Description
swCustomInfoDeleteResult_LinkedProp	2
swCustomInfoDeleteResult_NotPresent	1 = Custom property does not exist
swCustomInfoDeleteResult_OK	0 = Success

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCustomInfoGetResult_e (Type)

SOLIDWORKS API Enumerations

swCustomInfoGetResult_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCustomInfoGetResult_e Enumeration

Result codes when getting custom properties.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCustomInfoGetResult_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCustomInfoGetResult\_e
```

C#

```
public enum swCustomInfoGetResult_e : System.Enum
```

C++/CLI

```
public enum class swCustomInfoGetResult_e : public System.Enum
```

Members

Member	Description
swCustomInfoGetResult_CachedValue	0 = Cached value was returned
swCustomInfoGetResult_NotPresent	1 = Custom property does not exist
swCustomInfoGetResult_ResolvedValue	2 = Resolved value was returned

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCustomInfoSetResult_e (Type)

SOLIDWORKS API Enumerations

swCustomInfoSetResult_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCustomInfoSetResult_e Enumeration

Result codes when setting custom properties.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCustomInfoSetResult_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCustomInfoSetResult\_e
```

C#

```
public enum swCustomInfoSetResult_e : System.Enum
```

C++/CLI

```
public enum class swCustomInfoSetResult_e : public System.Enum
```

 Members

Member	Description
swCustomInfoSetResult_LinkedProp	3
swCustomInfoSetResult_NotPresent	1 = Custom property does not exist
swCustomInfoSetResult_OK	0 = Success
swCustomInfoSetResult_TypeMismatch	2 = Specified value has an incorrect type

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCustomInfoType_e (Type)

SOLIDWORKS API Enumerations

swCustomInfoType_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCustomInfoType_e Enumeration

Custom property types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCustomInfoType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCustomInfoType\_e
```

C#

```
public enum swCustomInfoType_e : System.Enum
```

C++/CLI

```
public enum class swCustomInfoType_e : public System.Enum
```

Members

Member	Description
swCustomInfoDate	64 = Datetime value
swCustomInfoDouble	5 = Double value
swCustomInfoEquation	105 = Equation value
swCustomInfoNumber	3 = Integer value
swCustomInfoText	30 = Text value
swCustomInfoUnknown	0
swCustomInfoYesOrNo	11 = Yes or No value

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCustomLinkSetResult_e (Type)

SOLIDWORKS API Enumerations

swCustomLinkSetResult_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCustomLinkSetResult_e Enumeration

Error codes when linking and unlinking custom properties.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCustomLinkSetResult_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCustomLinkSetResult\_e
```

C#

```
public enum swCustomLinkSetResult_e : System.Enum
```

C++/CLI

```
public enum class swCustomLinkSetResult_e : public System.Enum
```

 Members

Member	Description
swCustomLinkSetResult_Legacy	2 = Legacy custom properties cannot be linked or unlinked
swCustomLinkSetResult_NotPresent	1 = Custom property does not exist
swCustomLinkSetResult_OK	0 = Success
swCustomLinkSetResult_UserProp	3 = User-defined custom properties cannot be linked or unlinked

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCustomPropertyAddOption_e (Type)

SOLIDWORKS API Enumerations

swCustomPropertyAddOption_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCustomPropertyAddOption_e Enumeration

Options when adding custom properties.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swCustomPropertyAddOption_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCustomPropertyAddOption\_e
```

C#

```
public enum swCustomPropertyAddOption_e : System.Enum
```

C++/CLI

```
public enum class swCustomPropertyAddOption_e : public System.Enum
```

 Members

Member	Description
swCustomPropertyDeleteAndAdd	1 = Delete an existing custom property having the same name and add the new custom property
swCustomPropertyOnlyIfNew	0 = Add the custom property only if it is new
swCustomPropertyReplaceValue	2 = Replace the value of an existing custom property having the same name

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCutListExclusionStatus_e (Type)

SOLIDWORKS API Enumerations

swCutListExclusionStatus_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swCutListExclusionStatus_e Enumeration

Status of excluding the selected faces and features in the cut list sort exclusion list.

Syntax

Visual Basic (Declaration)

Public Enum swCutListExclusionStatus_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swCutListExclusionStatus_e](#)

C#

public enum swCutListExclusionStatus_e : System.Enum

C++/CLI

public enum class swCutListExclusionStatus_e : public System.Enum

Members

Member	Description
swCutListExclusionStatus_InvalidEntities	1 = Selected faces and features are invalid because they are not of selection type BODYFEATURE or FACE. Other examples of face and features that are invalid for exclusion: • Chamfers that remove an entire face. • Suppressed features. • Features that create new bodies from sketches, such as boss-extrude, revolve, and sweep. • Certain sheet metal features.
swCutListExclusionStatus_Success	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swCutListTransferOptions_e (Type)

SOLIDWORKS API Enumerations

swCutListTransferOptions_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCutListTransferOptions_e Enumeration

Options for transferring the cut list when saving a weldment member, surface body, or solid body to another part.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCutListTransferOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swCutListTransferOptions\_e
```

C#

```
public enum swCutListTransferOptions_e : System.Enum
```

C++/CLI

```
public enum class swCutListTransferOptions_e : public System.Enum
```

 Members

Member	Description
swCutListTransferOptions_CutListProperties	2 = Transfer to a cut list in the new part
swCutListTransferOptions_FileProperties	1 = Transfer to file properties of the new part
swCutListTransferOptions_None	0 = No transfer

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCutListType_e (Type)

SOLIDWORKS API Enumerations

swCutListType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swCutListType_e Enumeration

Cut list types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swCutListType_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swCutListType\_e
```

C#

```
public enum swCutListType_e : System.Enum
```

C++/CLI

```
public enum class swCutListType_e : public System.Enum
```

 Members

Member	Description
swSheetmetalCutlist	2
swSolidBodyCutList	1
swWeldmentCutlist	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swCutSweepOption_e (Type)

SOLIDWORKS API Enumerations

swCutSweepOption_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swCutSweepOption_e Enumeration

Sweep cut options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swCutSweepOption_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swCutSweepOption\_e
```

C#

```
public enum swCutSweepOption_e : System.Enum
```

C++/CLI

```
public enum class swCutSweepOption_e : public System.Enum
```

Members

Member	Description
swProfileSweep	1
swSolidSweep	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDatumDisplayType_e (Type)

SOLIDWORKS API Enumerations

swDatumDisplayType_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDatumDisplayType_e Enumeration

Datum feature display styles.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swDatumDisplayType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDatumDisplayType\_e
```

C#

```
public enum swDatumDisplayType_e : System.Enum
```

C++/CLI

```
public enum class swDatumDisplayType_e : public System.Enum
```

Members

Member	Description
swDatumDisplayType_Default	0
swDatumDisplayType_Roundgb	2
swDatumDisplayType_Square	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swDatumGbLeaderStyle_e (Type)

SOLIDWORKS API Enumerations

swDatumGbLeaderStyle_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swDatumGbLeaderStyle_e Enumeration

Orientations of the leader for a round datum feature symbol.

Syntax

Visual Basic (Declaration)

```
Public Enum swDatumGbLeaderStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDatumGbLeaderStyle\_e
```

C#

```
public enum swDatumGbLeaderStyle_e : System.Enum
```

C++/CLI

```
public enum class swDatumGbLeaderStyle_e : public System.Enum
```

Members

Member	Description
swDatumLeaderStyle_Horizontal	1
swDatumLeaderStyle_Perpendicular	3
swDatumLeaderStyle_Vertical	2

See Also

[SolidWorks.Interop.swconst Namespace](#)