

# SOLIDWORKS Enumerations (swconst) — Reference (6/17): swDocTemplateTypes\_e- swFeatureEditStatus\_e

SOLIDWORKS API Documentation (converted from CHM)

# swDocTemplateTypes\_e (Type)

SOLIDWORKS API Enumerations

swDocTemplateTypes\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDocTemplateTypes\_e Enumeration

Document template types. [Bitmask](#).

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDocTemplateTypes_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDocTemplateTypes\_e
```

### C#

```
public enum swDocTemplateTypes_e : System.Enum
```

### C++/CLI

```
public enum class swDocTemplateTypes_e : public System.Enum
```

## Members

| Member                     | Description |
|----------------------------|-------------|
| swDocTemplateTypeASSEMBLY  | 4 or 0x4    |
| swDocTemplateTypeDRAWING   | 8 or 0x8    |
| swDocTemplateTypeInContext | 16 or 0x10  |
| swDocTemplateTypeNONE      | 1 or 0x1    |
| swDocTemplateTypePART      | 2 or 0x2    |

## Remarks

These values can be OR'd together to indicate on which toolbar the document types should reside.

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDocumentTypes\_e (Type)

SOLIDWORKS API Enumerations

swDocumentTypes\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDocumentTypes\_e Enumeration

Document types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDocumentTypes_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDocumentTypes\_e
```

C#

```
public enum swDocumentTypes_e : System.Enum
```

C++/CLI

```
public enum class swDocumentTypes_e : public System.Enum
```

 Members

| Member                 | Description  |
|------------------------|--------------|
| swDocASSEMBLY          | 2            |
| swDocDRAWING           | 3            |
| swDocIMPORTED_ASSEMBLY | 7; Multi-CAD |
| swDocIMPORTED_PART     | 6; Multi-CAD |
| swDocLAYOUT            | 5            |
| swDocNONE              | 0            |
| swDocPART              | 1            |
| swDocSDM               | 4            |

 Remarks

When opening library feature parts, use swDocPART.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDofStatus\_e (Type)

SOLIDWORKS API Enumerations

swDofStatus\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDofStatus\_e Enumeration

Dof status.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDofStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swDofStatus\_e
```

C#

```
public enum swDofStatus_e : System.Enum
```

C++/CLI

```
public enum class swDofStatus_e : public System.Enum
```

 Members

| Member                          | Description |
|---------------------------------|-------------|
| swDofStatus_Free                | 3           |
| swDofStatus_FreeNormal          | 4           |
| swDofStatus_Instantaneous       | 5           |
| swDofStatus_InstantaneousNormal | 6           |
| swDofStatus_Static              | 1           |
| swDofStatus_StaticNormal        | 2           |
| swDofStatus_Unused              | 0           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDraftAnalysisFaceType\_e (Type)

[SolidWorks.Interop.swconst Namespace](#) : swDraftAnalysisFaceType\_e Enumeration

Draft analysis face types.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDraftAnalysisFaceType_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDraftAnalysisFaceType\_e
```

### C#

```
public enum swDraftAnalysisFaceType_e : System.Enum
```

### C++/CLI

```
public enum class swDraftAnalysisFaceType_e : public System.Enum
```

## Members

| Member                          | Description |
|---------------------------------|-------------|
| swDraftAnalysisFaceTypeNegative | 1           |
| swDraftAnalysisFaceTypeNoDraft  | 2           |
| swDraftAnalysisFaceTypePositive | 0           |
| swDraftAnalysisFaceTypeStraddle | 3           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDraftAnalysisOptions\_e (Type)

SOLIDWORKS API Enumerations

swDraftAnalysisOptions\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDraftAnalysisOptions\_e Enumeration

Draft analysis options. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

```
Public Enum swDraftAnalysisOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swDraftAnalysisOptions\_e
```

C#

```
public enum swDraftAnalysisOptions_e : System.Enum
```

C++/CLI

```
public enum class swDraftAnalysisOptions_e : public System.Enum
```

 Members

| Member                   | Description |
|--------------------------|-------------|
| swDraftAnalysisFindSteep | 2 or 0x2    |
| swDraftAnalysisFlipDir   | 1 or 0x1    |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDraftAnalysisShow\_e (Type)

SOLIDWORKS API Enumerations

swDraftAnalysisShow\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDraftAnalysisShow\_e Enumeration

Show draft analysis options. [Bitmask](#).

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDraftAnalysisShow_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDraftAnalysisShow\_e
```

### C#

```
public enum swDraftAnalysisShow_e : System.Enum
```

### C++/CLI

```
public enum class swDraftAnalysisShow_e : public System.Enum
```

## Members

| Member                           | Description |
|----------------------------------|-------------|
| swDraftAnalysisShowDraftRequired | 4 or 0x4    |
| swDraftAnalysisShowNegative      | 2 or 0x2    |
| swDraftAnalysisShowNegativeSteep | 32 or 0x20  |
| swDraftAnalysisShowPositive      | 1 or 0x1    |
| swDraftAnalysisShowPositiveSteep | 16 or 0x10  |
| swDraftAnalysisShowStraddle      | 8 or 0x8    |
| swDraftAnalysisShowSurface       | 64 or 0x40  |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDraftFacePropagationType\_e (Type)

SOLIDWORKS API Enumerations

swDraftFacePropagationType\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDraftFacePropagationType\_e Enumeration

Draft face propagaton types.

 Syntax

Visual Basic (Declaration)

Public Enum swDraftFacePropagationType\_e  
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDraftFacePropagationType\\_e](#)

C#

public enum swDraftFacePropagationType\_e : System.Enum

C++/CLI

public enum class swDraftFacePropagationType\_e : public System.Enum

 Members

| Member               | Description |
|----------------------|-------------|
| swFacePropAllLoops   | 2           |
| swFacePropInnerLoops | 3           |
| swFacePropNone       | 0           |
| swFacePropOuterLoops | 4           |
| swFacePropTangent    | 1           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)



# swDraftStepType\_e (Type)

SOLIDWORKS API Enumerations

swDraftStepType\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDraftStepType\_e Enumeration

Draft step types.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDraftStepType_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDraftStepType\_e
```

### C#

```
public enum swDraftStepType_e : System.Enum
```

### C++/CLI

```
public enum class swDraftStepType_e : public System.Enum
```

## Members

| Member               | Description |
|----------------------|-------------|
| swDraftPerpendicular | 6           |
| swDraftTaperedStep   | 3           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDraftType\_e (Type)

 

[SolidWorks.Interop.swconst Namespace](#) : swDraftType\_e Enumeration

Draft types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDraftType_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swDraftType\_e
```

C#

```
public enum swDraftType_e : System.Enum
```

C++/CLI

```
public enum class swDraftType_e : public System.Enum
```

 Members

| Member              | Description |
|---------------------|-------------|
| swNeutralPlaneDraft | 0           |
| swPartingLineDraft  | 1           |
| swStepDraft         | 3           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDragArrowManipulatorOptions\_e (Type)

SOLIDWORKS API Enumerations

swDragArrowManipulatorOptions\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDragArrowManipulatorOptions\_e Enumeration

Draft arrow manipulator options.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDragArrowManipulatorOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swDragArrowManipulatorOptions\_e
```

C#

```
public enum swDragArrowManipulatorOptions_e : System.Enum
```

C++/CLI

```
public enum class swDragArrowManipulatorOptions_e : public System.Enum
```

 Members

| Member                           | Description |
|----------------------------------|-------------|
| swDragArrowManipulatorDirection1 | 0           |
| swDragArrowManipulatorDirection2 | 1           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDrawingComponentLineFontOption\_e (Type)

SOLIDWORKS API Enumerations

swDrawingComponentLineFontOption\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDrawingComponentLineFontOption\_e Enumeration

Types of edges of components in assembly drawings whose line font styles you can change.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDrawingComponentLineFontOption_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDrawingComponentLineFontOption\_e
```

### C#

```
public enum swDrawingComponentLineFontOption_e : System.Enum
```

### C++/CLI

```
public enum class swDrawingComponentLineFontOption_e : public System.Enum
```

## Members

| Member                             | Description                              |
|------------------------------------|------------------------------------------|
| swDrawingComponentLineFontHatch    | 4 = Crosshatch edges                     |
| swDrawingComponentLineFontHidden   | 2 = Hidden edges                         |
| swDrawingComponentLineFontSpeedpak | 5 = Visible edges of SpeedPak components |
| swDrawingComponentLineFontTangent  | 3 = Tangent edges                        |
| swDrawingComponentLineFontVisible  | 1 = Visible edges                        |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDrawingMode\_e (Type)

SOLIDWORKS API Enumerations

swDrawingMode\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDrawingMode\_e Enumeration

Drawing modes.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDrawingMode_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDrawingMode\_e
```

### C#

```
public enum swDrawingMode_e : System.Enum
```

### C++/CLI

```
public enum class swDrawingMode_e : public System.Enum
```

## Members

| Member                  | Description |
|-------------------------|-------------|
| swDrawingMode_Detailing | 2           |
| swDrawingMode_None      | 0           |
| swDrawingMode_Resolved  | 1           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

swDrawingNotify\_e (Type)

SOLIDWORKS API Enumerations

swDrawingNotify\_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swDrawingNotify\_e Enumeration

Drawing notifications.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swDrawingNotify\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDrawingNotify\\_e](#)

C#

public enum swDrawingNotify\_e : System.Enum

C++/CLI

public enum class swDrawingNotify\_e : public System.Enum

Members

| Member                                       | Description                                              |
|----------------------------------------------|----------------------------------------------------------|
| swDrawingActivateSheetPostNotify             | 53 = <a href="#">ActivateSheetPostNotify</a>             |
| swDrawingActivateSheetPreNotify              | 52 = <a href="#">ActivateSheetPreNotify</a>              |
| swDrawingAddCustomPropertyNotify             | 20 = <a href="#">AddCustomPropertyNotify</a>             |
| swDrawingAddDependencyNotify                 | 62 = <a href="#">AddDependencyNotify</a>                 |
| swDrawingAddDvePagePreNotify                 | 40 = Not used.                                           |
| swDrawingAddItemNotify                       | 15 = <a href="#">AddItemNotify</a>                       |
| swDrawingAutoSaveNotify                      | 10 = <a href="#">AutoSaveNotify</a>                      |
| swDrawingAutoSaveToStorageNotify             | 11 = <a href="#">AutoSaveToStorageNotify</a>             |
| swDrawingAutoSaveToStorageStoreNotify        | 48 = <a href="#">AutoSaveToStorageStoreNotify</a>        |
| swDrawingChangeCustomPropertyNotify          | 21 = <a href="#">ChangeCustomPropertyNotify</a>          |
| swDrawingClearSelectionsNotify               | 37 = <a href="#">ClearSelectionsNotify</a>               |
| swDrawingCommandManagerTabActivatedPreNotify | 54 = <a href="#">CommandManagerTabActivatedPreNotify</a> |
| swDrawingConfigChangeNotify                  | 12 = <a href="#">ActiveConfigChangeNotify</a>            |
| swDrawingConfigChangePostNotify              | 13 = <a href="#">ActiveConfigChangePostNotify</a>        |
| swDrawingDeleteCustomPropertyNotify          | 22 = <a href="#">DeleteCustomPropertyNotify</a>          |
| swDrawingDeleteDependencyNotify              | 63 = <a href="#">DeleteDependencyNotify</a>              |
| swDrawingDeleteItemNotify                    | 17 = <a href="#">DeleteItemNotify</a>                    |
| swDrawingDeleteItemPreNotify                 | 36 = <a href="#">DeleteItemPreNotify</a>                 |
| swDrawingDeleteSelectionPreNotify            | 24 = <a href="#">DeleteSelectionPreNotify</a>            |
| swDrawingDestroyNotify                       | 2 = <a href="#">Obsolete</a>                             |
| swDrawingDestroyNotify2                      | 42 = <a href="#">DestroyNotify2</a>                      |
| swDrawingDimensionChangeNotify               | 32 = <a href="#">DimensionChangeNotify</a>               |
| swDrawingDisplayPaneCollapseNotify           | 59 = <a href="#">DisplayPaneCollapseNotify</a>           |
| swDrawingDisplayPaneExpandNotify             | 58 = <a href="#">DisplayPaneExpandNotify</a>             |
| swDrawingDynamicHighlightNotify              | 31 = <a href="#">DynamicHighlightNotify</a>              |
| swDrawingEquationEditorPostNotify            | 39 = <a href="#">EquationEditorPostNotify</a>            |
| swDrawingEquationEditorPreNotify             | 38 = <a href="#">EquationEditorPreNotify</a>             |
| swDrawingFeatureManagerTabActivatedNotify    | 56 = <a href="#">FeatureManagerTabActivatedNotify</a>    |
| swDrawingFeatureManagerTabActivatedPreNotify | 55 = <a href="#">FeatureManagerTabActivatedPreNotify</a> |
| swDrawingFeatureManagerTreeRebuildNotify     | 29 = <a href="#">FeatureManagerTreeRebuildNotify</a>     |
| swDrawingFileReloadCancelNotify              | 33 = Not used.                                           |
| swDrawingFileReloadNotify                    | 19 = Not used.                                           |
| swDrawingFileReloadPreNotify                 | 25 = Not used.                                           |
| swDrawingFileSaveAsNotify                    | 7 = <a href="#">Obsolete</a>                             |
| swDrawingFileSaveAsNotify2                   | 23 = <a href="#">FileSaveAsNotify2</a>                   |
| swDrawingFileSaveNotify                      | 6 = <a href="#">FileSaveNotify</a>                       |
| swDrawingFileSavePostCancelNotify            | 34 = <a href="#">FileSavePostCancelNotify</a>            |
| swDrawingFileSavePostNotify                  | 26 = <a href="#">FileSavePostNotify</a>                  |
| swDrawingInsertTableNotify                   | 49 = <a href="#">InsertTableNotify</a>                   |
| swDrawingLoadFromStorageNotify               | 8 = <a href="#">LoadFromStorageNotify</a>                |
| swDrawingLoadFromStorageStoreNotify          | 27 = <a href="#">LoadFromStorageStoreNotify</a>          |
| swDrawingModifyNotify                        | 18 = <a href="#">ModifyNotify</a>                        |
| swDrawingModifyTableNotify                   | 50 = <a href="#">ModifyTableNotify</a>                   |
| swDrawingNewSelectionNotify                  | 5 = <a href="#">NewSelectionNotify</a>                   |
| swDrawingRedoPostNotify                      | 45 = <a href="#">RedoPostNotify</a>                      |
| swDrawingRedoPreNotify                       | 46 = <a href="#">RedoPreNotify</a>                       |
| swDrawingRegenNotify                         | 1 = <a href="#">RegenNotify</a>                          |
| swDrawingRegenPostNotify                     | 3 = <a href="#">RegenPostNotify</a>                      |
| swDrawingRenameDisplayTitleNotify            | 57 = <a href="#">RenameDisplayTitleNotify</a>            |
| swDrawingRenameItemNotify                    | 16 = <a href="#">RenameItemNotify</a>                    |
| swDrawingSaveToStorageNotify                 | 9 = <a href="#">SaveToStorageNotify</a>                  |
| swDrawingSaveToStorageStoreNotify            | 28 = <a href="#">SaveToStorageStoreNotify</a>            |
| swDrawingSketchSolveNotify                   | 35 = <a href="#">SketchSolveNotify</a>                   |
| swDrawingStateChangeNotify                   | 60 = <a href="#">DrawingStateChangeNotify</a>            |
| swDrawingUndoPostNotify                      | 43 = <a href="#">UndoPostNotify</a>                      |
| swDrawingUndoPreNotify                       | 47 = <a href="#">UndoPreNotify</a>                       |
| swDrawingUnitsChangeNotify                   | 41 = <a href="#">UnitsChangeNotify</a>                   |

|                                  |                                               |
|----------------------------------|-----------------------------------------------|
| swDrawingUserSelectionPostNotify | 51 = <a href="#">UserSelectionPostNotify</a>  |
| swDrawingUserSelectionPreNotify  | 44 = <a href="#">UserSelectionPreNotify</a>   |
| swDrawingViewCreatePreNotify     | 30 = <a href="#">ViewCreatePreNotify</a>      |
| swDrawingViewNewNotify           | 4 = <a href="#">Obsolete</a>                  |
| swDrawingViewNewNotify2          | 14 = <a href="#">ViewNewNotify2</a>           |
| swViewPositionChangeNotify       | 61 = <a href="#">ViewPositionChangeNotify</a> |

#### Remarks

To receive notifications, a DLL application must register for the notifications by object type. This registration must be done for each instance of a particular object.

For example, in the file in the Visual C++ 6.0 wizard-generated add-in that supports drawing events (e.g., Drawing.h), include:

```
BEGIN_SINK_MAP(CSwDrawing)

    SINK_ENTRY_EX(ID_DRAWINGDOC_EVENTS, DIID_DDrawingDocEvents, swDrawingDestroyNotify, DestroyNotify)

    SINK_ENTRY_EX(ID_DRAWINGDOC_EVENTS, DIID_DDrawingDocEvents, swDrawingNewSelectionNotify,
        NewSelectionNotify)

END_SINK_MAP( )
```

If developing a C++ application, use the enumerators to [register for notifications](#) for [IDrawingDoc](#) events.

#### See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDrawingProjectionType\_e (Type)

SOLIDWORKS API Enumerations

swDrawingProjectionType\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDrawingProjectionType\_e Enumeration

[Send comments on this topic.](#)

Drawing projection types.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDrawingProjectionType_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDrawingProjectionType\_e
```

### C#

```
public enum swDrawingProjectionType_e : System.Enum
```

### C++/CLI

```
public enum class swDrawingProjectionType_e : public System.Enum
```

## Members

| Member                      | Description |
|-----------------------------|-------------|
| swDrawing1stAngleProjection | 1           |
| swDrawing3rdAngleProjection | 2           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)



# swDrawingSheetsZonesLetterLayout\_e (Type)

SOLIDWORKS API Enumerations

swDrawingSheetsZonesLetterLayout\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDrawingSheetsZonesLetterLayout\_e Enumeration

Options for letter layouts in drawing sheet zones.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDrawingSheetsZonesLetterLayout_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDrawingSheetsZonesLetterLayout\_e
```

### C#

```
public enum swDrawingSheetsZonesLetterLayout_e : System.Enum
```

### C++/CLI

```
public enum class swDrawingSheetsZonesLetterLayout_e : public System.Enum
```

## Members

| Member                                  | Description                                                              |
|-----------------------------------------|--------------------------------------------------------------------------|
| swDrawingSheetsZonesLetterLayout_Column | 1 = Letters appear in columns from the origin and numbers appear in rows |
| swDrawingSheetsZonesLetterLayout_Row    | 0 = Letters appear in rows from the origin and numbers appear in columns |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDrawingSheetsZonesOrigin\_e (Type)

SOLIDWORKS API Enumerations

swDrawingSheetsZonesOrigin\_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDrawingSheetsZonesOrigin\_e Enumeration

Options for the origins of drawing sheet zones.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDrawingSheetsZonesOrigin_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDrawingSheetsZonesOrigin\_e
```

### C#

```
public enum swDrawingSheetsZonesOrigin_e : System.Enum
```

### C++/CLI

```
public enum class swDrawingSheetsZonesOrigin_e : public System.Enum
```

## Members

| Member                          | Description                                                                           |
|---------------------------------|---------------------------------------------------------------------------------------|
| swDrawingSheetsZones_LowerLeft  | 2 = Lowest letters and numbers start from the lower-left corner of the drawing sheet  |
| swDrawingSheetsZones_LowerRight | 3 = Lowest letters and numbers start from the lower-right corner of the drawing sheet |
| swDrawingSheetsZones_UpperLeft  | 0 = Lowest letters and numbers start from the upper-left corner of the drawing sheet  |
| swDrawingSheetsZones_UpperRight | 1 = Lowest letters and numbers start from the upper-right corner of the drawing sheet |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDrawingViewTypes\_e (Type)

SOLIDWORKS API Enumerations

swDrawingViewTypes\_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swDrawingViewTypes\_e Enumeration

Drawing view types.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDrawingViewTypes_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDrawingViewTypes\_e
```

### C#

```
public enum swDrawingViewTypes_e : System.Enum
```

### C++/CLI

```
public enum class swDrawingViewTypes_e : public System.Enum
```

## Members

| Member                         | Description                    |
|--------------------------------|--------------------------------|
| swDrawingAlternatePositionView | 10 = Alternate position view   |
| swDrawingAuxiliaryView         | 5 = Auxiliary view             |
| swDrawingDetachedView          | 9 = Detached view              |
| swDrawingDetailView            | 3 = Detail view                |
| swDrawingNamedView             | 7 = Named view                 |
| swDrawingProjectedView         | 4 = Projected (unfolded) view  |
| swDrawingRelativeView          | 8 = Relative view to the model |
| swDrawingSectionView           | 2 = Section view               |
| swDrawingSheet                 | 1 = Drawing sheet              |
| swDrawingStandardView          | 6 = Standard view              |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDwgImportEntitiesPositioning\_e (Type)

SOLIDWORKS API Enumerations

swDwgImportEntitiesPositioning\_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swDwgImportEntitiesPositioning\_e Enumeration

Drawing import entities positionings.

 Syntax

Visual Basic (Declaration)

Public Enum swDwgImportEntitiesPositioning\_e  
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swDwgImportEntitiesPositioning\\_e](#)

C#

public enum swDwgImportEntitiesPositioning\_e : System.Enum

C++/CLI

public enum class swDwgImportEntitiesPositioning\_e : public System.Enum

 Members

| Member                       | Description |
|------------------------------|-------------|
| swDwgEntitiesCentered        | 1           |
| swDwgEntitiesSpecifyPosition | 2           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDwgPaperSizes\_e (Type)

SOLIDWORKS API Enumerations

swDwgPaperSizes\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDwgPaperSizes\_e Enumeration

Drawing paper sizes.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDwgPaperSizes_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDwgPaperSizes\_e
```

C#

```
public enum swDwgPaperSizes_e : System.Enum
```

C++/CLI

```
public enum class swDwgPaperSizes_e : public System.Enum
```

 Members

| Member                   | Description |
|--------------------------|-------------|
| swDwgPaperA0size         | 11          |
| swDwgPaperA1size         | 10          |
| swDwgPaperA2size         | 9           |
| swDwgPaperA3size         | 8           |
| swDwgPaperA4size         | 6           |
| swDwgPaperA4sizeVertical | 7           |
| swDwgPaperAsize          | 0           |
| swDwgPaperAsizeVertical  | 1           |
| swDwgPaperBsize          | 2           |
| swDwgPaperCsize          | 3           |
| swDwgPaperDsize          | 4           |
| swDwgPaperEsize          | 5           |
| swDwgPapersUserDefined   | 12          |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDwgTemplates\_e (Type)

SOLIDWORKS API Enumerations

swDwgTemplates\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDwgTemplates\_e Enumeration

Drawing templates.

 Syntax

Visual Basic (Declaration)

Public Enum swDwgTemplates\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDwgTemplates\\_e](#)

C#

public enum swDwgTemplates\_e : System.Enum

C++/CLI

public enum class swDwgTemplates\_e : public System.Enum

 Members

| Member                      | Description |
|-----------------------------|-------------|
| swDwgTemplateA0size         | 11          |
| swDwgTemplateA1size         | 10          |
| swDwgTemplateA2size         | 9           |
| swDwgTemplateA3size         | 8           |
| swDwgTemplateA4size         | 6           |
| swDwgTemplateA4sizeVertical | 7           |
| swDwgTemplateAsize          | 0           |
| swDwgTemplateAsizeVertical  | 1           |
| swDwgTemplateBsize          | 2           |
| swDwgTemplateCsize          | 3           |
| swDwgTemplateCustom         | 12          |
| swDwgTemplateDsize          | 4           |
| swDwgTemplateEsize          | 5           |
| swDwgTemplateNone           | 13          |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDxfFormat\_e (Type)

SOLIDWORKS API Enumerations

swDxfFormat\_e Enumeration

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swDxfFormat\_e Enumeration

DXF/DWG output formats.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swDxfFormat_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swDxfFormat\_e
```

### C#

```
public enum swDxfFormat_e : System.Enum
```

### C++/CLI

```
public enum class swDxfFormat_e : public System.Enum
```

## Members

| Member            | Description |
|-------------------|-------------|
| swDxfFormat_R12   | 0           |
| swDxfFormat_R13   | 1           |
| swDxfFormat_R14   | 2           |
| swDxfFormat_R2000 | 3           |
| swDxfFormat_R2004 | 4           |
| swDxfFormat_R2007 | 5           |
| swDxfFormat_R2010 | 6           |
| swDxfFormat_R2013 | 7           |
| swDxfFormat_R2018 | 8           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swDxfMultisheet\_e (Type)

SOLIDWORKS API Enumerations

swDxfMultisheet\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swDxfMultisheet\_e Enumeration  
DXF/DWG multisheets.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swDxfMultisheet\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swDxfMultisheet\\_e](#)

C#

public enum swDxfMultisheet\_e : System.Enum

C++/CLI

public enum class swDxfMultisheet\_e : public System.Enum

Members

| Member               | Description |
|----------------------|-------------|
| swDxfActiveSheetOnly | 0           |
| swDxfMultiSheet      | 2           |
| swDxfSeparateSheets  | 1           |

See Also

[SolidWorks.Interop.swconst Namespace](#)



# swDynamicMode\_e (Type)

SOLIDWORKS API Enumerations

swDynamicMode\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swDynamicMode\_e Enumeration

Dynamic modes.

 Syntax

Visual Basic (Declaration)

```
Public Enum swDynamicMode_e
    Inherits System.Enum
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As swDynamicMode\_e
```

C#

```
public enum swDynamicMode_e : System.Enum
```

C++/CLI

```
public enum class swDynamicMode_e : public System.Enum
```

 Members

| Member            | Description |
|-------------------|-------------|
| swAnimDynamics    | 5           |
| swDragDynamics    | 6           |
| swNoDynamics      | 0           |
| swPanDynamics     | 2           |
| swSpinDynamics    | 1           |
| swUnknownDynamics | 4           |
| swZoomDynamics    | 3           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdgeFlangeError\_e (Type)

SOLIDWORKS API Enumerations

swEdgeFlangeError\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swEdgeFlangeError\_e Enumeration

Edge flange error codes.

 Syntax

Visual Basic (Declaration)

Public Enum swEdgeFlangeError\_e  
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swEdgeFlangeError\\_e](#)

C#

public enum swEdgeFlangeError\_e : System.Enum

C++/CLI

public enum class swEdgeFlangeError\_e : public System.Enum

 Members

| Member                                             | Description                                           |
|----------------------------------------------------|-------------------------------------------------------|
| swEdgeFlangeError_EdgeAlreadyExists                | 4 = Specified edge already exists                     |
| swEdgeFlangeError_EdgeNotSpecified                 | 1 = Input array of edges is empty                     |
| swEdgeFlangeError_GenericError                     | 7 = Unknown error                                     |
| swEdgeFlangeError_InvalidEdge                      | 5 = Specified edge is invalid                         |
| swEdgeFlangeError_MustSpecifyAtLeastOneEdge        | 6 = You must specify at least one edge                |
| swEdgeFlangeError_NoError                          | 0 = No error                                          |
| swEdgeFlangeError_NumberOfEdgesAndSketchesNotEqual | 3 = Number of edges must equal the number of sketches |
| swEdgeFlangeError_SketchNotSpecified               | 2 = Input array of sketches is empty                  |

 Remarks

These error codes are returned by [IEdgeFlangeFeatureData::AddEdges](#) and [IEdgeFlangeFeatureData::RemoveEdges](#).

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdgesHiddenEdgeDisplay\_e (Type)

SOLIDWORKS API Enumerations

swEdgesHiddenEdgeDisplay\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swEdgesHiddenEdgeDisplay\_e Enumeration

Hidden edge display types.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swEdgesHiddenEdgeDisplay_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swEdgesHiddenEdgeDisplay\_e
```

### C#

```
public enum swEdgesHiddenEdgeDisplay_e : System.Enum
```

### C++/CLI

```
public enum class swEdgesHiddenEdgeDisplay_e : public System.Enum
```

## Members

| Member                         | Description |
|--------------------------------|-------------|
| swEdgesHiddenEdgeDisplayDashed | 2           |
| swEdgesHiddenEdgeDisplaySolid  | 1           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdgesInContextEditTransparencyType\_e (Type)

SOLIDWORKS API Enumerations

swEdgesInContextEditTransparencyType\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swEdgesInContextEditTransparencyType\_e Enumeration

In-context edit transparency edge types.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swEdgesInContextEditTransparencyType_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swEdgesInContextEditTransparencyType\_e
```

### C#

```
public enum swEdgesInContextEditTransparencyType_e : System.Enum
```

### C++/CLI

```
public enum class swEdgesInContextEditTransparencyType_e : public System.Enum
```

## Members

| Member                                            | Description |
|---------------------------------------------------|-------------|
| swEdgesInContextEditTransparency_ForceAssembly    | 3           |
| swEdgesInContextEditTransparency_MaintainAssembly | 2           |
| swEdgesInContextEditTransparency_OpaqueAssembly   | 1           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdgesShadedModeDisplay\_e (Type)

SOLIDWORKS API Enumerations

swEdgesShadedModeDisplay\_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swEdgesShadedModeDisplay\_e Enumeration

Shaded edges display modes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swEdgesShadedModeDisplay\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swEdgesShadedModeDisplay\\_e](#)

C#

public enum swEdgesShadedModeDisplay\_e : System.Enum

C++/CLI

public enum class swEdgesShadedModeDisplay\_e : public System.Enum

Members

| Member                            | Description |
|-----------------------------------|-------------|
| swEdgesShadedModeDisplayHLR       | 2           |
| swEdgesShadedModeDisplayNone      | 1           |
| swEdgesShadedModeDisplayWireframe | 3           |

See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdgesTangentEdgeDisplay\_e (Type)

SOLIDWORKS API Enumerations

swEdgesTangentEdgeDisplay\_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swEdgesTangentEdgeDisplay\_e Enumeration

Tangent edge display modes.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swEdgesTangentEdgeDisplay_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swEdgesTangentEdgeDisplay\_e
```

### C#

```
public enum swEdgesTangentEdgeDisplay_e : System.Enum
```

### C++/CLI

```
public enum class swEdgesTangentEdgeDisplay_e : public System.Enum
```

## Members

| Member                           | Description |
|----------------------------------|-------------|
| swEdgesTangentEdgeDisplayPhantom | 2           |
| swEdgesTangentEdgeDisplayRemoved | 3           |
| swEdgesTangentEdgeDisplayVisible | 1           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdgeUntrimType\_e (Type)

SOLIDWORKS API Enumerations

swEdgeUntrimType\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swEdgeUntrimType\_e Enumeration

Untrimmed edge types.

 Syntax

Visual Basic (Declaration)

Public Enum swEdgeUntrimType\_e  
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swEdgeUntrimType\\_e](#)

C#

public enum swEdgeUntrimType\_e : System.Enum

C++/CLI

public enum class swEdgeUntrimType\_e : public System.Enum

 Members

| Member                           | Description |
|----------------------------------|-------------|
| swEdgeUntrimTypeConnectEndPoints | 1           |
| swEdgeUntrimTypeExtendEdges      | 2           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEditBalloonOption\_e (Type)

SOLIDWORKS API Enumerations

swEditBalloonOption\_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swEditBalloonOption\_e Enumeration

Edit balloon options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swEditBalloonOption\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swEditBalloonOption\\_e](#)

C#

public enum swEditBalloonOption\_e : System.Enum

C++/CLI

public enum class swEditBalloonOption\_e : public System.Enum

Members

| Member                         | Description                       |
|--------------------------------|-----------------------------------|
| swEditBalloonOption_Replace    | 0 = Replaces existing balloons    |
| swEditBalloonOption_Resequence | 1 = Resequences existing balloons |

See Also

[SolidWorks.Interop.swconst Namespace](#)



# swEditPartCommandStatus\_e (Type)

SOLIDWORKS API Enumerations

swEditPartCommandStatus\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swEditPartCommandStatus\_e Enumeration

Return values during the activation of a part.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swEditPartCommandStatus_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swEditPartCommandStatus\_e
```

### C#

```
public enum swEditPartCommandStatus_e : System.Enum
```

### C++/CLI

```
public enum class swEditPartCommandStatus_e : public System.Enum
```

## Members

| Member                            | Description |
|-----------------------------------|-------------|
| swEditPartAsmMustBeSaved          | -2          |
| swEditPartCompMustBeResolved      | -4          |
| swEditPartCompMustBeSelected      | -3          |
| swEditPartCompMustHaveWriteAccess | -5          |
| swEditPartCompNotPositioned       | 1 or 0x1    |
| swEditPartFailure                 | -1          |
| swEditPartSuccessful              | 0           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdrawingsAttachmentOption\_e (Type)

SOLIDWORKS API Enumerations

swEdrawingsAttachmentOption\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

[SolidWorks.Interop.swconst Namespace](#) : swEdrawingsAttachmentOption\_e Enumeration

Configuration options for creating and attaching STEP files when publishing a part or assembly to eDrawings.

Syntax

Visual Basic (Declaration)

Public Enum swEdrawingsAttachmentOption\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swEdrawingsAttachmentOption\\_e](#)

C#

public enum swEdrawingsAttachmentOption\_e : System.Enum

C++/CLI

public enum class swEdrawingsAttachmentOption\_e : public System.Enum

Members

| Member                    | Description                                                       |
|---------------------------|-------------------------------------------------------------------|
| swEdrawingsAttachActive   | 1 = Create and attach STEP files to the active configuration only |
| swEdrawingsAttachAll      | 2 = Create and attach STEP files to all configurations            |
| swEdrawingsAttachNone     | 0 = Do not create and attach any STEP files                       |
| swEdrawingsAttachSelected | 3 = Create and attach STEP files to specified configurations only |

See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdrawingsAttachmentType\_e (Type)

SOLIDWORKS API Enumerations

swEdrawingsAttachmentType\_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swEdrawingsAttachmentType\_e Enumeration

Types of STEP file to create and attach when publishing configurations to eDrawings.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swEdrawingsAttachmentType\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swEdrawingsAttachmentType\\_e](#)

C#

public enum swEdrawingsAttachmentType\_e : System.Enum

C++/CLI

public enum class swEdrawingsAttachmentType\_e : public System.Enum

Members

| Member       | Description                                                                     |
|--------------|---------------------------------------------------------------------------------|
| SWAP_203     | 1                                                                               |
| SWAP_214     | 2                                                                               |
| SWAP_242     | 3 = SOLIDWORKS MBD license only; supports Product and Manufacturing Information |
| SWAP_Unknown | 0                                                                               |

See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEdrawingSaveAsOption\_e (Type)

SOLIDWORKS API Enumerations

swEdrawingSaveAsOption\_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swEdrawingSaveAsOption\_e Enumeration

eDrawings Save As options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swEdrawingSaveAsOption\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swEdrawingSaveAsOption\\_e](#)

C#

public enum swEdrawingSaveAsOption\_e : System.Enum

C++/CLI

public enum class swEdrawingSaveAsOption\_e : public System.Enum

Members

| Member                 | Description                                                                                                               |
|------------------------|---------------------------------------------------------------------------------------------------------------------------|
| swEdrawingSaveActive   | 1 or 0x1; Publish the active configuration or sheet when saving as an eDrawings                                           |
| swEdrawingSaveAll      | 2 or 0x2; Publish all configurations or sheets when saving as an eDrawings                                                |
| swEdrawingSaveSelected | 3 or 0x3; Publish sheets or configurations specified by <a href="#">swEmodelSelectionList</a> when saving as an eDrawings |

See Also

[SolidWorks.Interop.swconst Namespace](#)

# swElectricalConnectionPointType\_e (Type)

SOLIDWORKS API Enumerations

swElectricalConnectionPointType\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swElectricalConnectionPointType\_e Enumeration

Electrical connection point types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swElectricalConnectionPointType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swElectricalConnectionPointType\_e
```

C#

```
public enum swElectricalConnectionPointType_e : System.Enum
```

C++/CLI

```
public enum class swElectricalConnectionPointType_e : public System.Enum
```

 Members

| Member                                  | Description |
|-----------------------------------------|-------------|
| swElectricalConnectionPoint_CableOrWire | 2           |
| swElectricalConnectionPoint_CableTray   | 5           |
| swElectricalConnectionPoint_Conduit     | 3           |
| swElectricalConnectionPoint_Harness     | 1           |
| swElectricalConnectionPoint_RibbonCable | 4           |
| swElectricalConnectionPoint_Trunking    | 6           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swElectricalSubType\_e (Type)

SOLIDWORKS API Enumerations

swElectricalSubType\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swElectricalSubType\_e Enumeration

Electrical route sub types for connection points.

 Syntax

Visual Basic (Declaration)

```
Public Enum swElectricalSubType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swElectricalSubType\_e
```

C#

```
public enum swElectricalSubType_e : System.Enum
```

C++/CLI

```
public enum class swElectricalSubType_e : public System.Enum
```

 Members

| Member                                      | Description         |
|---------------------------------------------|---------------------|
| swElectricalSubType_ElectricalCableWire     | 1 = Cable wire      |
| swElectricalSubType_ElectricalConduit       | 2 = Conduit         |
| swElectricalSubType_ElectricalHarness       | 0 = Harness         |
| swElectricalSubType_ElectricalRibbonCable   | 30 = Ribbon cable   |
| swElectricalSubType_ElectricalStandardCable | 3 = Standard cable  |
| swElectricalSubType_NotElectrical           | 20 = Not electrical |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEllipsePts\_e (Type)

SOLIDWORKS API Enumerations

swEllipsePts\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swEllipsePts\_e Enumeration

Values for interpreting ellipse data.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swEllipsePts_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swEllipsePts\_e
```

### C#

```
public enum swEllipsePts_e : System.Enum
```

### C++/CLI

```
public enum class swEllipsePts_e : public System.Enum
```

## Members

| Member            | Description |
|-------------------|-------------|
| swEllipseCenterPt | 2           |
| swEllipseEndPt    | 1           |
| swEllipseMajorPt  | 3           |
| swEllipseMinorPt  | 4           |
| swEllipseStartPt  | 0           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEndCapThicknessDirection\_e (Type)

SOLIDWORKS API Enumerations

swEndCapThicknessDirection\_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swEndCapThicknessDirection\_e Enumeration

End cap thickness directions.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swEndCapThicknessDirection\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swEndCapThicknessDirection\\_e](#)

C#

public enum swEndCapThicknessDirection\_e : System.Enum

C++/CLI

public enum class swEndCapThicknessDirection\_e : public System.Enum

Members

| Member          | Description |
|-----------------|-------------|
| swExtendInward  | 1           |
| swExtendOutward | 0           |
| swSpecifyInset  | 2           |

See Also

[SolidWorks.Interop.swconst Namespace](#)



# swEndConditions\_e (Type)

SOLIDWORKS API Enumerations

swEndConditions\_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swEndConditions\_e Enumeration

End conditions for creation of a variety of features.

 Syntax

Visual Basic (Declaration)

Public Enum swEndConditions\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swEndConditions\\_e](#)

C#

public enum swEndConditions\_e : System.Enum

C++/CLI

public enum class swEndConditions\_e : public System.Enum

 Members

| Member                     | Description                                          |
|----------------------------|------------------------------------------------------|
| swEndCondBlind             | 0                                                    |
| swEndCondMidPlane          | 6                                                    |
| swEndCondOffsetFromSurface | 5                                                    |
| swEndCondThroughAll        | 1                                                    |
| swEndCondThroughAllBoth    | 9                                                    |
| swEndCondThroughNext       | 2                                                    |
| swEndCondUpToBody          | 7                                                    |
| swEndCondUpToNext          | 11                                                   |
| swEndCondUpToSelection     | 10                                                   |
| swEndCondUpToSurface       | 4 = Do not use; superseded by swEndCondUpToSelection |
| swEndCondUpToVertex        | 3 = Do not use; superseded by swEndCondUpToSelection |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swEndShape\_e (Type)

SOLIDWORKS API Enumerations

swEndShape\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swEndShape\_e Enumeration

End shapes for straight hole and straight tap elements of the Advanced Hole.

 Syntax

Visual Basic (Declaration)

```
Public Enum swEndShape_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swEndShape\_e
```

C#

```
public enum swEndShape_e : System.Enum
```

C++/CLI

```
public enum class swEndShape_e : public System.Enum
```

 Members

| Member                | Description |
|-----------------------|-------------|
| swEndShape_DrillPoint | 0           |
| swEndShape_FlatBottom | 1           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExcludeFromBOMError\_e (Type)

SOLIDWORKS API Enumerations

swExcludeFromBOMError\_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swExcludeFromBOMError\_e Enumeration

Result codes when setting whether to exclude a component from a bill of materials.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swExcludeFromBOMError_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swExcludeFromBOMError\_e
```

### C#

```
public enum swExcludeFromBOMError_e : System.Enum
```

### C++/CLI

```
public enum class swExcludeFromBOMError_e : public System.Enum
```

## Members

| Member                               | Description |
|--------------------------------------|-------------|
| swExcludeFromBOM_ EnvelopedComponent | 2           |
| swExcludeFromBOM_ Fail               | 0           |
| swExcludeFromBOM_ Success            | 1           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExplodeDirectionIndex\_e (Type)

SOLIDWORKS API Enumerations

swExplodeDirectionIndex\_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swExplodeDirectionIndex\_e Enumeration

Explode direction manipulator options when creating or editing an explode step.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swExplodeDirectionIndex_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swExplodeDirectionIndex\_e
```

### C#

```
public enum swExplodeDirectionIndex_e : System.Enum
```

### C++/CLI

```
public enum class swExplodeDirectionIndex_e : public System.Enum
```

## Members

| Member                          | Description                                                                                                  |
|---------------------------------|--------------------------------------------------------------------------------------------------------------|
| swExplodeDirectionIndex_Unknown | -1 = Use in <a href="#">IExplodeStep::SetExplodeDirection</a> to continue using the current enumerator value |
| swExplodeDirectionIndex_XAxis   | 0                                                                                                            |
| swExplodeDirectionIndex_YAxis   | 1                                                                                                            |
| swExplodeDirectionIndex_ZAxis   | 2                                                                                                            |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExportDataFileType\_e (Type)

SOLIDWORKS API Enumerations

swExportDataFileType\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swExportDataFileType\_e Enumeration

Export data file types.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swExportDataFileType_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swExportDataFileType\_e
```

### C#

```
public enum swExportDataFileType_e : System.Enum
```

### C++/CLI

```
public enum class swExportDataFileType_e : public System.Enum
```

## Members

| Member          | Description |
|-----------------|-------------|
| swExportPdfData | 1           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExportDataSheetsToExport\_e (Type)

SOLIDWORKS API Enumerations

swExportDataSheetsToExport\_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swExportDataSheetsToExport\_e Enumeration

Export data sheets to export options.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swExportDataSheetsToExport_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swExportDataSheetsToExport\_e
```

### C#

```
public enum swExportDataSheetsToExport_e : System.Enum
```

### C++/CLI

```
public enum class swExportDataSheetsToExport_e : public System.Enum
```

## Members

| Member                             | Description |
|------------------------------------|-------------|
| swExportData_ExportAllSheets       | 1           |
| swExportData_ExportCurrentSheet    | 2           |
| swExportData_ExportSpecifiedSheets | 3           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExportFlatPatternViewOptions\_e (Type)

SOLIDWORKS API Enumerations

swExportFlatPatternViewOptions\_e Enumeration

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swExportFlatPatternViewOptions\_e Enumeration

Flat-pattern view options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swExportFlatPatternViewOptions\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swExportFlatPatternViewOptions\\_e](#)

C#

public enum swExportFlatPatternViewOptions\_e : System.Enum

C++/CLI

public enum class swExportFlatPatternViewOptions\_e : public System.Enum

Members

| Member                                | Description |
|---------------------------------------|-------------|
| swExportFlatPatternOption_None        | 0           |
| swExportFlatPatternOption_RemoveBends | 1           |

See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExportGeomOptions\_e (Type)

SOLIDWORKS API Enumerations

swExportGeomOptions\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swExportGeomOptions\_e Enumeration

DXF/DWG geometry export options.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swExportGeomOptions_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swExportGeomOptions\_e
```

### C#

```
public enum swExportGeomOptions_e : System.Enum
```

### C++/CLI

```
public enum class swExportGeomOptions_e : public System.Enum
```

## Members

| Member                      | Description                                                                       |
|-----------------------------|-----------------------------------------------------------------------------------|
| swExportGeomAsPoly          | -1 = Export geometry as polylines                                                 |
| swExportNone                | -2 = None (default)                                                               |
| swExportTopLevelCompAsBlock | 1 = Export top-level components as blocks                                         |
| swExportViewAsBlock         | 0 = Export views as blocks (default for System Options for DXF/DWG View Geometry) |

## See Also

[SolidWorks.Interop.swconst Namespace](#)



# swExportSVPJFileFormatGroupType\_e (Type)

SOLIDWORKS API Enumerations

swExportSVPJFileFormatGroupType\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swExportSVPJFileFormatGroupType\_e Enumeration

SVPJ file format group types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swExportSVPJFileFormatGroupType\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swExportSVPJFileFormatGroupType\\_e](#)

 [Copy Code](#)

C#

public enum swExportSVPJFileFormatGroupType\_e : System.Enum

C++/CLI

public enum class swExportSVPJFileFormatGroupType\_e : public System.Enum

 Members

| Member                             | Description |
|------------------------------------|-------------|
| swExportSVPJGroupType_ByAppearance | 0           |
| swExportSVPJGroupType_ByPart       | 1           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExportToDWG\_e (Type)

SOLIDWORKS API Enumerations

swExportToDWG\_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swExportToDWG\_e Enumeration

Options for the Action parameter of [IPartDoc::ExportToDWG2](#).

 Syntax

Visual Basic (Declaration)

Public Enum swExportToDWG\_e  
Inherits System.Enum

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [swExportToDWG\\_e](#)

C#

public enum swExportToDWG\_e : System.Enum

C++/CLI

public enum class swExportToDWG\_e : public System.Enum

 Members

| Member                                   | Description                                               |
|------------------------------------------|-----------------------------------------------------------|
| swExportToDWG_ExportAnnotationViews      | 3                                                         |
| swExportToDWG_ExportSelectedFacesOrLoops | 2                                                         |
| swExportToDWG_ExportSheetMetal           | 1; Valid only if the active document contains sheet metal |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExternalFileReferencesConfig\_e (Type)

SOLIDWORKS API Enumerations

swExternalFileReferencesConfig\_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swExternalFileReferencesConfig\_e Enumeration

External file references configurations options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swExternalFileReferencesConfig\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swExternalFileReferencesConfig\\_e](#)

C#

public enum swExternalFileReferencesConfig\_e : System.Enum

C++/CLI

public enum class swExternalFileReferencesConfig\_e : public System.Enum

Members

| Member                                | Description |
|---------------------------------------|-------------|
| swExternalFileReferencesConfigNone    | 0           |
| swExternalFileReferencesCurrentConfig | 1           |
| swExternalFileReferencesNamedConfig   | 2           |

See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExternalFileReferencesUpdate\_e (Type)

SOLIDWORKS API Enumerations

swExternalFileReferencesUpdate\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swExternalFileReferencesUpdate\_e Enumeration

External file references update options.

 Syntax

Visual Basic (Declaration)

```
Public Enum swExternalFileReferencesUpdate_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swExternalFileReferencesUpdate\_e
```

C#

```
public enum swExternalFileReferencesUpdate_e : System.Enum
```

C++/CLI

```
public enum class swExternalFileReferencesUpdate_e : public System.Enum
```

 Members

| Member                             | Description |
|------------------------------------|-------------|
| swExternalFileReferencesBreakAll   | 1           |
| swExternalFileReferencesLockAll    | 2           |
| swExternalFileReferencesunlockAll  | 3           |
| swExternalFileReferencesUpdateNone | 0           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExternalReferenceStatus\_e (Type)

SOLIDWORKS API Enumerations

swExternalReferenceStatus\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swExternalReferenceStatus\_e Enumeration

External reference status.

 Syntax

Visual Basic (Declaration)

```
Public Enum swExternalReferenceStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swExternalReferenceStatus\_e
```

C#

```
public enum swExternalReferenceStatus_e : System.Enum
```

C++/CLI

```
public enum class swExternalReferenceStatus_e : public System.Enum
```

 Members

| Member                          | Description |
|---------------------------------|-------------|
| swExternalReferenceBroken       | 0           |
| swExternalReferenceDangling     | 5           |
| swExternalReferenceInContext    | 3           |
| swExternalReferenceLocked       | 1           |
| swExternalReferenceOutOfContext | 4           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExternalReferencesUpdateOutOfDateLinkedDesignTable\_e (Type)

SOLIDWORKS API Enumerations

swExternalReferencesUpdateOutOfDateLinkedDesignTable\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swExternalReferencesUpdateOutOfDateLinkedDesignTable\_e Enumeration

Out-of-date external references linked design table options.

 Syntax

Visual Basic (Declaration)

Public Enum swExternalReferencesUpdateOutOfDateLinkedDesignTable\_e  
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swExternalReferencesUpdateOutOfDateLinkedDesignTable\\_e](#)

C#

public enum swExternalReferencesUpdateOutOfDateLinkedDesignTable\_e : System.Enum

C++/CLI

public enum class swExternalReferencesUpdateOutOfDateLinkedDesignTable\_e : public System.Enum

 Members

| Member                              | Description |
|-------------------------------------|-------------|
| swUpdateDesignTable_Model           | 1           |
| swUpdateDesignTable_Prompt          | 0           |
| swUpdateLinkedDesignTable_ExcelFile | 2           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swExtrudeFrom\_e (Type)

SOLIDWORKS API Enumerations

swExtrudeFrom\_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swExtrudeFrom\_e Enumeration

Extrude from options.

 Syntax

Visual Basic (Declaration)

```
Public Enum swExtrudeFrom_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swExtrudeFrom\_e
```

C#

```
public enum swExtrudeFrom_e : System.Enum
```

C++/CLI

```
public enum class swExtrudeFrom_e : public System.Enum
```

 Members

| Member                         | Description |
|--------------------------------|-------------|
| swExtrudeFrom_Offset           | 3           |
| swExtrudeFrom_SketchPlane      | 0           |
| swExtrudeFrom_SurfaceFacePlane | 1           |
| swExtrudeFrom_Vertex           | 2           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFaceCoincidentResult\_e (Type)

SOLIDWORKS API Enumerations

swFaceCoincidentResult\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swFaceCoincidentResult\_e Enumeration

Face coincidence results.

 Syntax

Visual Basic (Declaration)

```
Public Enum swFaceCoincidentResult_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swFaceCoincidentResult\_e
```

C#

```
public enum swFaceCoincidentResult_e : System.Enum
```

C++/CLI

```
public enum class swFaceCoincidentResult_e : public System.Enum
```

 Members

| Member                          | Description                                                                                                                       |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| swFaceCoincident_FalseBoundary1 | 3 = The two faces are not coincident. At least one point on the boundary of face 1 is not coincident with the boundary of face 2. |
| swFaceCoincident_FalseBoundary2 | 4 = The two faces are not coincident. At least one point on the boundary of face 2 is not coincident with the boundary of face 1. |
| swFaceCoincident_FalseFace1     | 5 = The two faces are not coincident. At least one point on face 1 is not coincident with face 2.                                 |
| swFaceCoincident_FalseFace2     | 6 = The two faces are not coincident. At least one point on face 2 is not coincident with face 1.                                 |
| swFaceCoincident_FalseSurface   | 7 = At least one of the faces does not have a surface attached.                                                                   |
| swFaceCoincident_FalseTopology  | 2 = The two faces are not coincident. The number of holes are different.                                                          |
| swFaceCoincident_True           | 0 = The faces are coincident to the specified tolerance.                                                                          |
| swFaceCoincident_TrueReversed   | 1 = The two faces are coincident to the specified tolerance, but their normals are reversed.                                      |
| swFaceCoincidentUnknownResult   | -1 = Unknown                                                                                                                      |

 See Also

[SolidWorks.Interop.swconst Namespace](#)



# swFaceDeleteOption\_e (Type)

SOLIDWORKS API Enumerations

swFaceDeleteOption\_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swFaceDeleteOption\_e Enumeration

DeleteFace feature options.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swFaceDeleteOption_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swFaceDeleteOption\_e
```

### C#

```
public enum swFaceDeleteOption_e : System.Enum
```

### C++/CLI

```
public enum class swFaceDeleteOption_e : public System.Enum
```

## Members

| Member                       | Description |
|------------------------------|-------------|
| swFaceDelete_Default         | 0           |
| swFaceDelete_Fill            | 2           |
| swFaceDelete_FillWithTangent | 3           |
| swFaceDelete_Patch           | 1           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFaceUntrimType\_e (Type)

SOLIDWORKS API Enumerations

swFaceUntrimType\_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swFaceUntrimType\_e Enumeration

Untrimmed faces types.

 Syntax

Visual Basic (Declaration)

Public Enum swFaceUntrimType\_e  
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swFaceUntrimType\\_e](#)

C#

public enum swFaceUntrimType\_e : System.Enum

C++/CLI

public enum class swFaceUntrimType\_e : public System.Enum

 Members

| Member                        | Description |
|-------------------------------|-------------|
| swFaceUntrimTypeAllEdges      | 0           |
| swFaceUntrimTypeExternalEdges | 2           |
| swFaceUntrimTypeInternalEdges | 1           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFamilyTableDimColumnType\_e (Type)

SOLIDWORKS API Enumerations

swFamilyTableDimColumnType\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swFamilyTableDimColumnType\_e Enumeration

Family table dimension column types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swFamilyTableDimColumnType\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swFamilyTableDimColumnType\\_e](#)

C#

public enum swFamilyTableDimColumnType\_e : System.Enum

C++/CLI

public enum class swFamilyTableDimColumnType\_e : public System.Enum

Members

| Member                            | Description |
|-----------------------------------|-------------|
| swFamilyTable_MarkedForDrawing    | 0x2         |
| swFamilyTable_NotMarkedForDrawing | 0x4         |
| swFamilyTable_TableControlled     | 0x1         |

See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFamilyTableGetConfigurationCriteria\_e (Type)

SOLIDWORKS API Enumerations

swFamilyTableGetConfigurationCriteria\_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swFamilyTableGetConfigurationCriteria\_e Enumeration

Criteria for getting family table configurations.

 Syntax

Visual Basic (Declaration)

Public Enum swFamilyTableGetConfigurationCriteria\_e  
Inherits System.Enum

Visual Basic (Usage)

 Copy Code

Dim instance As [swFamilyTableGetConfigurationCriteria\\_e](#)

C#

public enum swFamilyTableGetConfigurationCriteria\_e : System.Enum

C++/CLI

public enum class swFamilyTableGetConfigurationCriteria\_e : public System.Enum

 Members

| Member                             | Description |
|------------------------------------|-------------|
| GetAllConfigurationsAvailableNames | 0           |
| GetJustEnabledConfigurationNames   | 1           |
| GetJustVisibleConfigurationNames   | 2           |

 See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFastenerTableTypes\_e (Type)

SOLIDWORKS API Enumerations

swFastenerTableTypes\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swFastenerTableTypes\_e Enumeration

Fastener table types.

[Send comments on this topic.](#)

## Syntax

### Visual Basic (Declaration)

```
Public Enum swFastenerTableTypes_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swFastenerTableTypes\_e
```

### C#

```
public enum swFastenerTableTypes_e : System.Enum
```

### C++/CLI

```
public enum class swFastenerTableTypes_e : public System.Enum
```

## Members

| Member                 | Description |
|------------------------|-------------|
| swScrewClearancesTable | 2           |
| swSizeTable            | 0           |
| swThreadDataTable      | 1           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFaultEntityErrorCode\_e (Type)

SOLIDWORKS API Enumerations

swFaultEntityErrorCode\_e Enumeration

See Also

[Send comments on this topic.](#)



[SolidWorks.Interop.swconst Namespace](#) : swFaultEntityErrorCode\_e Enumeration

Fault entity error codes.

## Syntax

Visual Basic (Declaration)

```
Public Enum swFaultEntityErrorCode_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swFaultEntityErrorCode\_e
```

C#

```
public enum swFaultEntityErrorCode_e : System.Enum
```

C++/CLI

```
public enum class swFaultEntityErrorCode_e : public System.Enum
```

## Members

| Member                       | Description                                                                                                                 |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| swBodyCorrupt                | 1 = Data structure is corrupt                                                                                               |
| swBodyInsideOut              | 3 = Body is inside out                                                                                                      |
| swBodyInvalidIdentifiers     | 2 = Body has invalid or duplicate identifiers                                                                               |
| swBodyRegionsInconsistent    | 4 = Regions of body are inconsistent                                                                                        |
| swEdgeBadFaceOrder           | 14 = On a non-manifold edge, the face order around the edge does not match the order of the faces' surfaces around the edge |
| swEdgeBadWire                | 15 = Two wireframe edges intersect at a position other than a vertex                                                        |
| swEdgeNonPeriodicCurve       | 5 = Open or non-periodic curve on ring edge                                                                                 |
| swEdgeNonPeriodicNomGeom     | 6 = Open or non-periodic nominal geometry on ring edge                                                                      |
| swEdgeSpcurveOutOfTol        | 11 = Spcurve not within edge's tolerance                                                                                    |
| swEdgeSpcurveOutOfTolNomGeom | 12 = Spcurve not within edge's tolerance of nominal geometry                                                                |
| swEdgeTouchEdge              | 36 = Edges touch                                                                                                            |
| swEdgeVertexNotLie           | 7 = Vertex does not lie on edge's curve                                                                                     |
| swEdgeVertexNotLieNomGeom    | 8 = Vertex does not lie on nominal geometry                                                                                 |
| swEdgeVerticesTouch          | 13 = Vertices of edge touch                                                                                                 |
| swEdgeWrongDir               | 9 = Curve in wrong direction for edge                                                                                       |
| swEdgeWrongDirNomGeom        | 10 = Nominal geometry in wrong direction                                                                                    |
| swEntityStateInvalid         | 34 = State of entity is invalid                                                                                             |
| swFaceBadEdge                | 17 = Edge does not lie on face's surface                                                                                    |
| swFaceBadEdgeOrder           | 18 = Edge order around the face does not match the order of the edges' curves around the face                               |
| swFaceBadLoops               | 20 = Loops inconsistent                                                                                                     |
| swFaceBadVertex              | 16 = Vertex does not lie on face's surface                                                                                  |
| swFaceBadWireframe           | 22 = A wireframe edge intersects a face at a position other than a vertex                                                   |
| swFaceCheckerFailure         | 23 = Checker failure during face/face check                                                                                 |
| swFaceFaceInconsistency      | 24 = Inconsistent faces                                                                                                     |
| swFaceNoAccomVertex          | 19 = A surface singularity has no accompanying vertex                                                                       |
| swFaceSelfIntersecting       | 21 = Face is self intersecting                                                                                              |
| swGeomDegenerate             | 26 = Geometry degenerated                                                                                                   |
| swGeomStateSelfIntersect     | 25 = Geometry is self intersecting                                                                                          |
| swRegionBadShells            | 27 = Inconsistent shells                                                                                                    |
| swShellBadTopologyGeometry   | 28 = A topological entity belonging to a shell is not geometrically within the shell                                        |
| swShellIntersect             | 29 = Shell shell inconsistency                                                                                              |
| swTopoMissingGeometry        | 35 = Missing geometry                                                                                                       |
| swTopoNotG1Continuous        | 30 = Topology's geometry is not G1 continuous                                                                               |
| swTopoSizeBoxViolation       | 31 = Some or all of entity is outside size box                                                                              |
| swTopoStateCheckFail         | 32 = Checker failure                                                                                                        |
| swTopoStateNoGeometry        | 33 = Missing geometry                                                                                                       |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFeatMgrPane\_e (Type)

SOLIDWORKS API Enumerations

swFeatMgrPane\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swFeatMgrPane\_e Enumeration

[Send comments on this topic.](#)

Available panes and states.

## Syntax

### Visual Basic (Declaration)

```
Public Enum swFeatMgrPane_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swFeatMgrPane\_e
```

### C#

```
public enum swFeatMgrPane_e : System.Enum
```

### C++/CLI

```
public enum class swFeatMgrPane_e : public System.Enum
```

## Members

| Member                    | Description |
|---------------------------|-------------|
| swFeatMgrPaneBottom       | 1           |
| swFeatMgrPaneBottomHidden | 3           |
| swFeatMgrPaneFlyout       | 4           |
| swFeatMgrPaneTop          | 0           |
| swFeatMgrPaneTopHidden    | 2           |

## See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFeatureChamferOption\_e (Type)

SOLIDWORKS API Enumerations

swFeatureChamferOption\_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swFeatureChamferOption\_e Enumeration

Chamfer feature options. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swFeatureChamferOption\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swFeatureChamferOption\\_e](#)

 [Copy Code](#)

C#

public enum swFeatureChamferOption\_e : System.Enum

C++/CLI

public enum class swFeatureChamferOption\_e : public System.Enum

 Members

| Member                               | Description |
|--------------------------------------|-------------|
| swFeatureChamferFlipDirection        | 1 or 0x1    |
| swFeatureChamferKeepFeature          | 2 or 0x2    |
| swFeatureChamferPropagateFeatToParts | 8 or 0x8    |
| swFeatureChamferTangentPropagation   | 4 or 0x4    |

 See Also

[SolidWorks.Interop.swconst Namespace](#)



# swFeatureDimensionParameter\_e (Type)

SOLIDWORKS API Enumerations

swFeatureDimensionParameter\_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swFeatureDimensionParameter\_e Enumeration

Pattern display dimension options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swFeatureDimensionParameter\_e  
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swFeatureDimensionParameter\\_e](#)

C#

public enum swFeatureDimensionParameter\_e : System.Enum

C++/CLI

public enum class swFeatureDimensionParameter\_e : public System.Enum

Members

| Member                  | Description                                              |
|-------------------------|----------------------------------------------------------|
| swPatternInstanceCount1 | 2 = Number of instances of pattern in Direction 1        |
| swPatternInstanceCount2 | 4 = Number of instances of pattern in Direction 2        |
| swPatternSpacing1       | 1 = Distance between instances of pattern in Direction 1 |
| swPatternSpacing2       | 3 = Distance between instances of pattern in Direction 2 |

See Also

[SolidWorks.Interop.swconst Namespace](#)

# swFeatureEditStatus\_e (Type)

SOLIDWORKS API Enumerations

swFeatureEditStatus\_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swFeatureEditStatus\_e Enumeration

Editing status of feature. [Bitmask](#).

## Syntax

### Visual Basic (Declaration)

```
Public Enum swFeatureEditStatus_e
    Inherits System.Enum
```

### Visual Basic (Usage)



```
Dim instance As swFeatureEditStatus\_e
```

### C#

```
public enum swFeatureEditStatus_e : System.Enum
```

### C++/CLI

```
public enum class swFeatureEditStatus_e : public System.Enum
```

## Members

| Member                 | Description                                                                   |
|------------------------|-------------------------------------------------------------------------------|
| swFeature_Editable     | 0 or 0x0; Feature can be edited                                               |
| swFeature_NonEditable  | 1 or 0x1; Feature cannot be edited                                            |
| swFeature_UnderEditing | 2 or 0x2; If the feature is a sketch, then the sketch is already being edited |

## Remarks

Although swFeatureEditStatus\_e is a bitmask, you currently cannot combine its mutually exclusive enumerators.

## See Also

[SolidWorks.Interop.swconst Namespace](#)