

SOLIDWORKS Enumerations (swconst) — Reference (8/17): swHoleElementOrientation_e- swLinkDimensionError_e

SOLIDWORKS API Documentation (converted from CHM)

swHoleElementOrientation_e (Type)

SOLIDWORKS API Enumerations

swHoleElementOrientation_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swHoleElementOrientation_e Enumeration

Advanced Hole orientations.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swHoleElementOrientation_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swHoleElementOrientation\_e
```

C#

```
public enum swHoleElementOrientation_e : System.Enum
```

C++/CLI

```
public enum class swHoleElementOrientation_e : public System.Enum
```

Members

Member	Description
swHoleElementOrientation_Farside	1
swHoleElementOrientation_Nearside	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swHoleSeriesWhichParts_e (Type)

SOLIDWORKS API Enumerations

swHoleSeriesWhichParts_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swHoleSeriesWhichParts_e Enumeration

Which parts the hole series passes through.

 Syntax

Visual Basic (Declaration)

```
Public Enum swHoleSeriesWhichParts_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swHoleSeriesWhichParts\_e
```

C#

```
public enum swHoleSeriesWhichParts_e : System.Enum
```

C++/CLI

```
public enum class swHoleSeriesWhichParts_e : public System.Enum
```

 Members

Member	Description
swHoleSeriesFirstPart	0
swHoleSeriesLastPart	2
swHoleSeriesMiddleParts	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swHoleTableTagOrder_e (Type)

SOLIDWORKS API Enumerations

swHoleTableTagOrder_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swHoleTableTagOrder_e Enumeration

Method by which to assign tag numbers to holes of the same size.

 Syntax

Visual Basic (Declaration)

```
Public Enum swHoleTableTagOrder_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swHoleTableTagOrder\_e
```

C#

```
public enum swHoleTableTagOrder_e : System.Enum
```

C++/CLI

```
public enum class swHoleTableTagOrder_e : public System.Enum
```

 Members

Member	Description
swHoleTableTagOrder_Radial	3 = Number holes in order of increasing radial angle from the table view origin, starting at -180 degrees in a counterclockwise direction
swHoleTableTagOrder_ReduceToolPath	2 = Number holes in next nearest order, starting at the table view origin
swHoleTableTagOrder_XY	1 = Number holes in order of their XLoc and YLoc

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swHoleTableTagPrefixApply_e (Type)

SOLIDWORKS API Enumerations

swHoleTableTagPrefixApply_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swHoleTableTagPrefixApply_e Enumeration

Options for applying prefixes to manual table tags of holes.

 Syntax

Visual Basic (Declaration)

```
Public Enum swHoleTableTagPrefixApply_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swHoleTableTagPrefixApply\_e
```

C#

```
public enum swHoleTableTagPrefixApply_e : System.Enum
```

C++/CLI

```
public enum class swHoleTableTagPrefixApply_e : public System.Enum
```

 Members

Member	Description
swHoleTableTagPrefixApply_AllHolesOfSameSize	1
swHoleTableTagPrefixOption_OnlySpecifiedHole	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swHoleTableTagStyle_e (Type)

SOLIDWORKS API Enumerations

swHoleTableTagStyle_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swHoleTableTagStyle_e Enumeration

Hole table tag styles.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swHoleTableTagStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swHoleTableTagStyle\_e
```

C#

```
public enum swHoleTableTagStyle_e : System.Enum
```

C++/CLI

```
public enum class swHoleTableTagStyle_e : public System.Enum
```

Members

Member	Description
swHoleTable_AlphaNumericTags	1
swHoleTable_ManualTags	3
swHoleTable_NumericTags	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swHorizontalAutoSplitApply_e (Type)

SOLIDWORKS API Enumerations

swHorizontalAutoSplitApply_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swHorizontalAutoSplitApply_e Enumeration

Options for when to automatically split a table horizontally.

 Syntax

Visual Basic (Declaration)

```
Public Enum swHorizontalAutoSplitApply_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swHorizontalAutoSplitApply\_e
```

C#

```
public enum swHorizontalAutoSplitApply_e : System.Enum
```

C++/CLI

```
public enum class swHorizontalAutoSplitApply_e : public System.Enum
```

 Members

Member	Description
swHorizontalAutoSplitApply_Continuously	1
swHorizontalAutoSplitApply_ThisTimeOnly	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swHorizontalAutoSplitPlacementOfSplitTable_e (Type)

SOLIDWORKS API Enumerations

swHorizontalAutoSplitPlacementOfSplitTable_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swHorizontalAutoSplitPlacementOfSplitTable_e Enumeration

Options for placement of the split table portion after a horizontal table split.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swHorizontalAutoSplitPlacementOfSplitTable_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swHorizontalAutoSplitPlacementOfSplitTable_e](#)

  Copy Code

C#

public enum swHorizontalAutoSplitPlacementOfSplitTable_e : System.Enum

C++/CLI

public enum class swHorizontalAutoSplitPlacementOfSplitTable_e : public System.Enum

 Members

Member	Description
swHorizontalAutoSplitPlacementOfSplitTable_BelowLastSplit	1 = Place the bottom split portion below the top split portion
swHorizontalAutoSplitPlacementOfSplitTable_NextToLastSplit	0 = Place the bottom split portion to the right of the top split portion

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swIFCExportSaveType_e (Type)

SOLIDWORKS API Enumerations

swIFCExportSaveType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swIFCExportSaveType_e Enumeration

IFC export options.

Syntax

Visual Basic (Declaration)

Public Enum swIFCExportSaveType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swIFCExportSaveType_e](#)

C#

public enum swIFCExportSaveType_e : System.Enum

C++/CLI

public enum class swIFCExportSaveType_e : public System.Enum

Members

Member	Description
swIFCExportSaveType_BREP	0
swIFCExportSaveType_BREPAndTessellation	1
swIFCExportSaveType_Tessellation	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swIFCOmniUniClassPreference_e (Type)

SOLIDWORKS API Enumerations

swIFCOmniUniClassPreference_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swIFCOmniUniClassPreference_e Enumeration

IFC output as types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swIFCOmniUniClassPreference_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swIFCOmniUniClassPreference\_e
```

C#

```
public enum swIFCOmniUniClassPreference_e : System.Enum
```

C++/CLI

```
public enum class swIFCOmniUniClassPreference_e : public System.Enum
```

 Members

Member	Description
swIFCSaveAsOmniClass	0
swIFCSaveAsUniClass2	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swIGESCurveRepresentation_e (Type)

SOLIDWORKS API Enumerations

swIGESCurveRepresentation_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swIGESCurveRepresentation_e Enumeration

IGES curve representations.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swIGESCurveRepresentation_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swIGESCurveRepresentation\_e
```

C#

```
public enum swIGESCurveRepresentation_e : System.Enum
```

C++/CLI

```
public enum class swIGESCurveRepresentation_e : public System.Enum
```

Members

Member	Description
swIGES_CURVES_BSPLINE	0
swIGES_CURVES_PSPLINE	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swIGESPreferredSystem_e (Type)

SOLIDWORKS API Enumerations

swIGESPreferredSystem_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swIGESPreferredSystem_e Enumeration

IGES systems.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swIGESPreferredSystem_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swIGESPreferredSystem\_e
```

C#

```
public enum swIGESPreferredSystem_e : System.Enum
```

C++/CLI

```
public enum class swIGESPreferredSystem_e : public System.Enum
```

Members

Member	Description
swIGES_ALIAS	10 = Apply transform directly to the geometry of each compone
swIGES_ALPHACAM	8
swIGES_ANSYS	2
swIGES_COSMOS	3
swIGES_MASCAM	4
swIGES_MULTICAM	9
swIGES_NURBS	1
swIGES_SMARTCAM	6
swIGES_STANDARD	0
swIGES_SURFCAM	5
swIGES_TEKSOFT	7

See Also

[SolidWorks.Interop.swconst Namespace](#)

swIGESRepresentation_e (Type)

SOLIDWORKS API Enumerations

swIGESRepresentation_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swIGESRepresentation_e Enumeration

IGES representation types.

Syntax

Visual Basic (Declaration)

```
Public Enum swIGESRepresentation_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swIGESRepresentation\_e
```

C#

```
public enum swIGESRepresentation_e : System.Enum
```

C++/CLI

```
public enum class swIGESRepresentation_e : public System.Enum
```

Members

Member	Description
swIGES_BOUNDEDSE	4 = Bounded surface
swIGES_BREP	3 = BREP
swIGES_CURVES	Obsolete
swIGES_TRIMS	0 = Trimmed surface
swIGES_TRIMSANDCURVES	Obsolete

See Also

[SolidWorks.Interop.swconst Namespace](#)

swImageQualityShaded_e (Type)

SOLIDWORKS API Enumerations

swImageQualityShaded_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImageQualityShaded_e Enumeration

Quality of tessellation of cylindrical surfaces for shaded rendering output.

 Syntax

Visual Basic (Declaration)

```
Public Enum swImageQualityShaded_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swImageQualityShaded\_e
```

C#

```
public enum swImageQualityShaded_e : System.Enum
```

C++/CLI

```
public enum class swImageQualityShaded_e : public System.Enum
```

 Members

Member	Description
swShadedImageQualityCoarse	1
swShadedImageQualityCustom	3 = Use swUserPreferenceDoubleValue_e.swImageQualityShadedDeviation to set a value for the custom shaded image quality.
swShadedImageQualityFine	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swImageQualityWireframe_e (Type)

SOLIDWORKS API Enumerations

swImageQualityWireframe_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swImageQualityWireframe_e Enumeration

Quality of wireframe display output.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swImageQualityWireframe_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swImageQualityWireframe\_e
```

C#

```
public enum swImageQualityWireframe_e : System.Enum
```

C++/CLI

```
public enum class swImageQualityWireframe_e : public System.Enum
```

Members

Member	Description
swWireframeImageQualityCustom	2
swWireframeImageQualityOptimal	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swImageSizeToUse_e (Type)

SOLIDWORKS API Enumerations

swImageSizeToUse_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swImageSizeToUse_e Enumeration

Default image sizes for the current DPI setting of the display device for images that are not based on the SOLIDWORKS icon size setting.

 Syntax

Visual Basic (Declaration)

```
Public Enum swImageSizeToUse_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swImageSizeToUse\_e
```

C#

```
public enum swImageSizeToUse_e : System.Enum
```

C++/CLI

```
public enum class swImageSizeToUse_e : public System.Enum
```

 Members

Member	Description
swImageSizeToUse_128x128	128
swImageSizeToUse_20x20	20
swImageSizeToUse_32x32	32
swImageSizeToUse_40x40	40
swImageSizeToUse_64x64	64
swImageSizeToUse_96x96	96

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportDxfDwg_ImportMethod_e (Type)

SOLIDWORKS API Enumerations

swImportDxfDwg_ImportMethod_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swImportDxfDwg_ImportMethod_e Enumeration
DXF/DWG import methods.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swImportDxfDwg_ImportMethod_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swImportDxfDwg\_ImportMethod\_e
```

C#

```
public enum swImportDxfDwg_ImportMethod_e : System.Enum
```

C++/CLI

```
public enum class swImportDxfDwg_ImportMethod_e : public System.Enum
```

Members

Member	Description
swImportDxfDwg_DoNotImportSheet	0 = Do not import this sheet (layout)
swImportDxfDwg_ImportToDrawing	1 = Import this sheet (layout) to a sheet in a new drawing
swImportDxfDwg_ImportToExistingDrawing	3 = Import this sheet (layout) into an existing drawing
swImportDxfDwg_ImportToExistingPart	4 = Import this sheet (layout) into an existing part
swImportDxfDwg_ImportToPartSketch	2 = Import this sheet (layout) into a sketch in a new part

See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportDxfDwg_LayerVisibility_e (Type)

SOLIDWORKS API Enumerations

swImportDxfDwg_LayerVisibility_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImportDxfDwg_LayerVisibility_e Enumeration

DXF/DWG layer visibility states.

 Syntax

Visual Basic (Declaration)

Public Enum swImportDxfDwg_LayerVisibility_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swImportDxfDwg_LayerVisibility_e](#)

C#

public enum swImportDxfDwg_LayerVisibility_e : System.Enum

C++/CLI

public enum class swImportDxfDwg_LayerVisibility_e : public System.Enum

 Members

Member	Description
swImportDxfDwg_LayerHidden	2
swImportDxfDwg_LayerMaintain	0
swImportDxfDwg_LayerVisible	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportModelItemsSource_e (Type)

SOLIDWORKS API Enumerations

swImportModelItemsSource_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swImportModelItemsSource_e Enumeration

Sources from which to import model items.

 Syntax

Visual Basic (Declaration)

Public Enum swImportModelItemsSource_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swImportModelItemsSource_e](#)



C#

public enum swImportModelItemsSource_e : System.Enum

C++/CLI

public enum class swImportModelItemsSource_e : public System.Enum

 Members

Member	Description
swImportModelItemsFromAssemblyOnly	3
swImportModelItemsFromEntireModel	0
swImportModelItemsFromSelectedComponent	2
swImportModelItemsFromSelectedFeature	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportNeutralAssemblyStructureMapping_e (Type)

SOLIDWORKS API Enumerations

swImportNeutralAssemblyStructureMapping_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImportNeutralAssemblyStructureMapping_e Enumeration

Neutral import assembly structure mappings.

Syntax

Visual Basic (Declaration)

```
Public Enum swImportNeutralAssemblyStructureMapping_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swImportNeutralAssemblyStructureMapping\_e
```

C#

```
public enum swImportNeutralAssemblyStructureMapping_e : System.Enum
```

C++/CLI

```
public enum class swImportNeutralAssemblyStructureMapping_e : public System.Enum
```

Members

Member	Description
swImportNeutralAssemblyStructureMapping_Default	0
swImportNeutralAssemblyStructureMapping_MultibodyPart	2
swImportNeutralAssemblyStructureMapping_MultipleParts	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportNeutralCurvesAndPointsOptions_e (Type)

SOLIDWORKS API Enumerations

swImportNeutralCurvesAndPointsOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImportNeutralCurvesAndPointsOptions_e Enumeration

Neutral import curves and points options.

 Syntax

Visual Basic (Declaration)

Public Enum swImportNeutralCurvesAndPointsOptions_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swImportNeutralCurvesAndPointsOptions_e](#)

C#

public enum swImportNeutralCurvesAndPointsOptions_e : System.Enum

C++/CLI

public enum class swImportNeutralCurvesAndPointsOptions_e : public System.Enum

 Members

Member	Description
swImportNeutralCurvesAndPointsOptions_As3DCurves	1
swImportNeutralCurvesAndPointsOptions_AsSketches	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportNeutralKnitOption_e (Type)

SOLIDWORKS API Enumerations

swImportNeutralKnitOption_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImportNeutralKnitOption_e Enumeration

Neutral import knit options.

 Syntax

Visual Basic (Declaration)

```
Public Enum swImportNeutralKnitOption_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swImportNeutralKnitOption\_e
```

C#

```
public enum swImportNeutralKnitOption_e : System.Enum
```

C++/CLI

```
public enum class swImportNeutralKnitOption_e : public System.Enum
```

 Members

Member	Description
swImportNeutralKnitOption_DoNotKnit	1
swImportNeutralKnitOption_FormSolids	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportNeutralUnits_e (Type)

SOLIDWORKS API Enumerations

swImportNeutralUnits_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImportNeutralUnits_e Enumeration

Neutral import units.

 Syntax

Visual Basic (Declaration)

```
Public Enum swImportNeutralUnits_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swImportNeutralUnits\_e
```

C#

```
public enum swImportNeutralUnits_e : System.Enum
```

C++/CLI

```
public enum class swImportNeutralUnits_e : public System.Enum
```

 Members

Member	Description
swImportNeutralUnits_ImportFileUnits	0
swImportNeutralUnits_TemplateUnits	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportPartCustomPropertiesToOptions_e (Type)

SOLIDWORKS API Enumerations

swImportPartCustomPropertiesToOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImportPartCustomPropertiesToOptions_e Enumeration

Derived part custom properties import options.

Syntax

Visual Basic (Declaration)

```
Public Enum swImportPartCustomPropertiesToOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swImportPartCustomPropertiesToOptions\_e
```

C#

```
public enum swImportPartCustomPropertiesToOptions_e : System.Enum
```

C++/CLI

```
public enum class swImportPartCustomPropertiesToOptions_e : public System.Enum
```

Members

Member	Description
swImportPartCustomPropertiesNone	3
swImportPropertiesToCutlistProperties	2
swImportPropertiesToFileProperties	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportSheetMetalInformation_e (Type)

SOLIDWORKS API Enumerations

swImportSheetMetalInformation_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImportSheetMetalInformation_e Enumeration

Derived part sheet metal information import options.

 Syntax

Visual Basic (Declaration)

```
Public Enum swImportSheetMetalInformation_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swImportSheetMetalInformation\_e
```

C#

```
public enum swImportSheetMetalInformation_e : System.Enum
```

C++/CLI

```
public enum class swImportSheetMetalInformation_e : public System.Enum
```

 Members

Member	Description
swImportUnlockedPropertiesNone	3
swImportWithoutUnlockedProperties	2
swImportWithUnlockedProperties	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swImportStlVrmlModelType_e (Type)

SOLIDWORKS API Enumerations

swImportStlVrmlModelType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swImportStlVrmlModelType_e Enumeration

STL/VRML import model types.

Syntax

Visual Basic (Declaration)

Public Enum swImportStlVrmlModelType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swImportStlVrmlModelType_e](#)

C#

public enum swImportStlVrmlModelType_e : System.Enum

C++/CLI

public enum class swImportStlVrmlModelType_e : public System.Enum

Members

Member	Description
swImportStlVrmlModelType_Graphics	0
swImportStlVrmlModelType_Solid	2
swImportStlVrmlModelType_Surface	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swImprintingFacesOpts_e (Type)

SOLIDWORKS API Enumerations

swImprintingFacesOpts_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swImprintingFacesOpts_e Enumeration

Imprinting faces options. [Bitmask](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swImprintingFacesOpts_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swImprintingFacesOpts\_e
```

C#

```
public enum swImprintingFacesOpts_e : System.Enum
```

C++/CLI

```
public enum class swImprintingFacesOpts_e : public System.Enum
```

Members

Member	Description
swImprintingFacesOnExtendFace	4 or 0x4
swImprintingFacesOnOverlapping	2 or 0x2
swImprintingFacesOnTool	1 or 0x1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInConfigurationOpts_e (Type)

SOLIDWORKS API Enumerations

swInConfigurationOpts_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swInConfigurationOpts_e Enumeration

Configuration options.

Syntax

Visual Basic (Declaration)

```
Public Enum swInConfigurationOpts_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInConfigurationOpts\_e
```

C#

```
public enum swInConfigurationOpts_e : System.Enum
```

C++/CLI

```
public enum class swInConfigurationOpts_e : public System.Enum
```

Members

Member	Description
swAllConfiguration	2
swConfigPropertySuppressFeatures	0
swLinkedToParent	4 = Valid only for derived configurations; if specified for non-derived configurations, then the active configuration is used
swSpecifyConfiguration	3
swSpeedpakConfiguration	5
swThisConfiguration	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInContextEditTransparencyType_e (Type)

SOLIDWORKS API Enumerations

swInContextEditTransparencyType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swInContextEditTransparencyType_e Enumeration

In-context edit transparency types.

Syntax

Visual Basic (Declaration)

```
Public Enum swInContextEditTransparencyType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInContextEditTransparencyType\_e
```

C#

```
public enum swInContextEditTransparencyType_e : System.Enum
```

C++/CLI

```
public enum class swInContextEditTransparencyType_e : public System.Enum
```

Members

Member	Description
swInContextEditTransparencyForce	1
swInContextEditTransparencyMaintain	2
swInContextEditTransparencyOpaque	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swIndentSelectionState_e (Type)

SOLIDWORKS API Enumerations

swIndentSelectionState_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swIndentSelectionState_e Enumeration

Indent selection states.

 Syntax

Visual Basic (Declaration)

```
Public Enum swIndentSelectionState_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swIndentSelectionState\_e
```

C#

```
public enum swIndentSelectionState_e : System.Enum
```

C++/CLI

```
public enum class swIndentSelectionState_e : public System.Enum
```

 Members

Member	Description
swIndentSelectionStateKeepSelection	0
swIndentSelectionStateRemoveSelection	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertAnnotation_e (Type)

SOLIDWORKS API Enumerations

swInsertAnnotation_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swInsertAnnotation_e Enumeration

Annotation types. Bitmask.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swInsertAnnotation_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInsertAnnotation\_e
```

C#

```
public enum swInsertAnnotation_e : System.Enum
```

C++/CLI

```
public enum class swInsertAnnotation_e : public System.Enum
```

 Members

Member	Description
swInsertAxes	512 or 0x200
swInsertCenterOfMass	33554432 or 0x2000000
swInsertCThreads	1 or 0x1; insert annotation cosmetic threads
swInsertCurves	1024 or 0x400
swInsertDatums	2 or 0x2
swInsertDatumTargets	4 or 0x4
swInsertDimensions	8 or 0x8
swInsertDimensionsMarkedForDrawing	32768 or 0x8000
swInsertDimensionsNotMarkedForDrawing	524288 or 0x80000
swInsertGTols	32 or 0x20; insert annotation geometric tolerances
swInsertHoleCallout	1048576 or 0x100000
swInsertHoleWizardLocationDimensions	131072 or 0x20000
swInsertHoleWizardProfileDimensions	65536 or 0x10000
swInsertInstanceCounts	16 or 0x10; insert dimension instance/revolution counts
swInsertNotes	64 or 0x40
swInsertOrigins	16384 or 0x4000
swInsertPlanes	2048 or 0x800
swInsertPoints	8192 or 0x2000; insert routing points
swInsertRefPoints	262144 or 0x40000; insert reference geometry points
swInsertSFSymbols	128 or 0x80; insert annotation surface finishes
swInsertSketches	4194304 or 0x400000
swInsertSurfaces	4096 or 0x1000
swInsertTolerancedDims	16777216 or 0x1000000
swInsertWeldBeads	2097152 or 0x200000; insert annotation weld bead caterpillars
swInsertWeldBeads_ET	8388608 or 0x800000; insert annotation weld bead end treatments
swInsertWelds	256 or 0x100; insert annotation weld symbols

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertAssyOptions_e (Type)

SOLIDWORKS API Enumerations

swInsertAssyOptions_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swInsertAssyOptions_e Enumeration

Insert assembly into part options. [Bitmask](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swInsertAssyOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInsertAssyOptions\_e
```

C#

```
public enum swInsertAssyOptions_e : System.Enum
```

C++/CLI

```
public enum class swInsertAssyOptions_e : public System.Enum
```

Members

Member	Description
swInsertAssyCoordinateSystems	10 or 0x10
swInsertAssyCosmeticThreads	20 or 0x20
swInsertAssyCustomProperties	100 or 0x100
swInsertAssyGraphicsBodies	400 or 0x400
swInsertAssyHoleWizardData	200 or 0x200
swInsertAssyMaterials	2 or 0x2
swInsertAssyPartCutListProps	800 or 0x800
swInsertAssyRefAxes	8 or 0x8
swInsertAssyRefPlanes	4 or 0x4
swInsertAssySketches	80 or 0x80
swInsertAssySurfaceBodies	1 or 0x1
swInsertAssyVisualProperties	40 or 0x40

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertEdgeFlangeOptions_e (Type)

SOLIDWORKS API Enumerations

swInsertEdgeFlangeOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swInsertEdgeFlangeOptions_e Enumeration

Sheet metal edge flange options. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

Public Enum swInsertEdgeFlangeOptions_e
Inherits System.Enum

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [swInsertEdgeFlangeOptions_e](#)

C#

public enum swInsertEdgeFlangeOptions_e : System.Enum

C++/CLI

public enum class swInsertEdgeFlangeOptions_e : public System.Enum

 Members

Member	Description
swInsertEdgeFlangeDoOffset	4 or 0x4
swInsertEdgeFlangeFlipDir	2 or 0x2
swInsertEdgeFlangeReverseOffsetDir	8 or 0x8
swInsertEdgeFlangeTearClip	16 or 0x10
swInsertEdgeFlangeTrimSideBend	32 or 0x20
swInsertEdgeFlangeUseDefaultRadius	1 or 0x1
swInsertEdgeFlangeUseDefaultRelief	128 or 0x80
swInsertEdgeFlangeUseReliefRatio	64 or 0x40

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertNewAssemblyErrorCode_e (Type)

SOLIDWORKS API Enumerations

swInsertNewAssemblyErrorCode_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swInsertNewAssemblyErrorCode_e Enumeration

Error codes when assembly inserted.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swInsertNewAssemblyErrorCode_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInsertNewAssemblyErrorCode\_e
```

C#

```
public enum swInsertNewAssemblyErrorCode_e : System.Enum
```

C++/CLI

```
public enum class swInsertNewAssemblyErrorCode_e : public System.Enum
```

Members

Member	Description
swInsertNewAssemblyError_ErrorUnknown	0
swInsertNewAssemblyError_ExtensionNotSidAsm	5
swInsertNewAssemblyError_FileAlreadyExists	3
swInsertNewAssemblyError_FilePathEmpty	2
swInsertNewAssemblyError_FolderDoesNotExist	4
swInsertNewAssemblyError_NoError	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertNewPartErrorCode_e (Type)

SOLIDWORKS API Enumerations

swInsertNewPartErrorCode_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swInsertNewPartErrorCode_e Enumeration

Error codes when part inserted.

Syntax

Visual Basic (Declaration)

```
Public Enum swInsertNewPartErrorCode_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInsertNewPartErrorCode\_e
```

C#

```
public enum swInsertNewPartErrorCode_e : System.Enum
```

C++/CLI

```
public enum class swInsertNewPartErrorCode_e : public System.Enum
```

Members

Member	Description
swInsertNewPartError_CannotSelectFaceOrPlane	7
swInsertNewPartError_ErrorUnknown	0
swInsertNewPartError_ExtensionNotStdPrt	5
swInsertNewPartError_FileAlreadyExists	3
swInsertNewPartError_FilePathEmpty	2
swInsertNewPartError_FolderDoesNotExist	4
swInsertNewPartError_NoError	1
swInsertNewPartError_NotAFaceOrPlane	6

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertOptions_e (Type)

SOLIDWORKS API Enumerations

swInsertOptions_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swInsertOptions_e Enumeration

Options for pasting a sheet into a drawing document.

 Syntax

Visual Basic (Declaration)

Public Enum swInsertOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swInsertOptions_e](#)

C#

public enum swInsertOptions_e : System.Enum

C++/CLI

public enum class swInsertOptions_e : public System.Enum

 Members

Member	Description
swInsertOption_AfterSelectedSheet	1
swInsertOption_BeforeSelectedSheet	0
swInsertOption_MoveToEnd	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertPartOptions_e (Type)

SOLIDWORKS API Enumerations

swInsertPartOptions_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swInsertPartOptions_e Enumeration

Part insertion options. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swInsertPartOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInsertPartOptions\_e
```

C#

```
public enum swInsertPartOptions_e : System.Enum
```

C++/CLI

```
public enum class swInsertPartOptions_e : public System.Enum
```

Members

Member	Description
swInsertPartBreakLink	512 or 0x200
swInsertPartDontZoomAll	262144 or 0x40000
swInsertPartImportAbsorbedSketchs	32 or 0x20
swInsertPartImportAxes	4 or 0x4
swInsertPartImportCoordinateSystem	256 or 0x100
swInsertPartImportCosmeticThreads	16 or 0x10
swInsertPartImportCustomProperties	128 or 0x80
swInsertPartImportCustomToCutlistProperties	65536 or 0x10000
swInsertPartImportCustomToFileProperties	32768 or 0x8000
swInsertPartImportCutListProperties	2048 or 0x800
swInsertPartImportDimXpertAnnotations	131072 or 0x20000
swInsertPartImportGraphicBodies	8388608 or 0x800000
swInsertPartImportHoleWzdData	4096 or 0x1000
swInsertPartImportIndProps	16384 or 0x4000
swInsertPartImportMaterial	524288 or 0x80000; Transfer - Body Material
swInsertPartImportModelDimensions	1024 or 0x400
swInsertPartImportPartMaterial	4194304 or 0x400000; Transfer - Part Material
swInsertPartImportPlanes	8 or 0x8
swInsertPartImportPoints	2097152 or 0x200000
swInsertPartImportPropagateVisualPropertiesFromOriginalPart	1048576 or 0x100000; Visual Properties - Propagate from original part
swInsertPartImportSMInfo	8192 or 0x2000
swInsertPartImportSolids	1 or 0x1
swInsertPartImportSurfaces	2 or 0x2
swInsertPartImportUnabsorbedSketchs	64 or 0x40

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertSlicingError_e (Type)

SOLIDWORKS API Enumerations

swInsertSlicingError_e Enumeration

See Also

SolidWorks.Interop.swconst Namespace : swInsertSlicingError_e Enumeration

Error codes for slicing insertion. [Bitmask](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swInsertSlicingError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInsertSlicingError\_e
```

C#

```
public enum swInsertSlicingError_e : System.Enum
```

C++/CLI

```
public enum class swInsertSlicingError_e : public System.Enum
```

Members

Member	Description
swInsertSlicingError_EntitiesCannotFormPlane	0x10 = Point and provided line overlap
swInsertSlicingError_GenericError	0x1 = Slicing inserted successfully
swInsertSlicingError_InvalidNumberOfPlanes	0x80 = Number of planes must be <= 100
swInsertSlicingError_InvalidSlicesToGenerateOption	0x4 = Slicing method specified in SlicingData.SlicesToGenerate is not valid
swInsertSlicingError_InvalidSlicingData	0x40 = Null or invalid slicing data
swInsertSlicingError_InvalidSlicingPlaneEntities	0x8 = None or invalid type of entities specified
swInsertSlicingError_InvalidTotalAngle	0x2 = (SlicingData.NumberOfPlanes * SlicingData.Offset) is invalid
swInsertSlicingError_NoBodiesInsideBox	0x20 = No bodies are inside the bounding box
swInsertSlicingError_NoError	0x0 = Slicing inserted successfully

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInsertTableColumnWidthStyle_e (Type)

SOLIDWORKS API Enumerations

swInsertTableColumnWidthStyle_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swInsertTableColumnWidthStyle_e Enumeration

Inserted table column width options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swInsertTableColumnWidthStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInsertTableColumnWidthStyle\_e
```

C#

```
public enum swInsertTableColumnWidthStyle_e : System.Enum
```

C++/CLI

```
public enum class swInsertTableColumnWidthStyle_e : public System.Enum
```

Members

Member	Description
swInsertColumn_DefaultWidth	0
swInsertColumn_MultilineTight	2
swInsertColumn_SingleLineTight	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInstanceToVaryModificationType_e (Type)

SOLIDWORKS API Enumerations

swInstanceToVaryModificationType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swInstanceToVaryModificationType_e Enumeration

Types of pattern instance modification when varying instances.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swInstanceToVaryModificationType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInstanceToVaryModificationType\_e
```

C#

```
public enum swInstanceToVaryModificationType_e : System.Enum
```

C++/CLI

```
public enum class swInstanceToVaryModificationType_e : public System.Enum
```

Members

Member	Description
swInstanceToVaryModificationType_D1Spacing	1 = Instance spacing change in Direction 1
swInstanceToVaryModificationType_D2Spacing	2 = Instance spacing change in Direction 2
swInstanceToVaryModificationType_Dimensions	3 = Instance dimension change

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInterfaceBrightnessColor_e (Type)

SOLIDWORKS API Enumerations

swInterfaceBrightnessColor_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swInterfaceBrightnessColor_e Enumeration

Background colors.

 Syntax

Visual Basic (Declaration)

```
Public Enum swInterfaceBrightnessColor_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swInterfaceBrightnessColor\_e
```

C#

```
public enum swInterfaceBrightnessColor_e : System.Enum
```

C++/CLI

```
public enum class swInterfaceBrightnessColor_e : public System.Enum
```

 Members

Member	Description
swIColor_ActiveTabColor	3 = Color of a tab's fill area when the tab is active
swIColor_ButtonFillCheckedAndHotColor	8 = Color of the CommandManager flat-style button's fill area
swIColor_ButtonFillCheckedColor	6 = Color of the CommandManager flat-style button's fill area
swIColor_ButtonFillHotColor	5 = Color of the CommandManager flat-style button's fill area
swIColor_ButtonFillPressedColor	7 = Color of the CommandManager flat-style button's fill area when pressing and holding down the left button of the mouse
swIColor_DisabledTextColor	2 = Color of text when text is disabled
swIColor_EnabledTextColor	1 = Color of text when text is enabled
swIColor_FeatureMgrBkgnd	0 = Background color is the same as the FeatureManager design tree's background color
swIColor_InactiveTabColor	4 = Color of a tab's fill area when the tab is inactive

 Remarks

If you want your add-in to use the same colors for your buttons as used by the SOLIDWORKS CommandManager buttons, then you can query and use these values.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swInterfaceBrightnessTheme_e (Type)

SOLIDWORKS API Enumerations

swInterfaceBrightnessTheme_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swInterfaceBrightnessTheme_e Enumeration

Background themes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swInterfaceBrightnessTheme_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swInterfaceBrightnessTheme\_e
```

C#

```
public enum swInterfaceBrightnessTheme_e : System.Enum
```

C++/CLI

```
public enum class swInterfaceBrightnessTheme_e : public System.Enum
```

Members

Member	Description
swInterfaceBrightnessTheme_3DExperience	4
swInterfaceBrightnessTheme_Dark	2
swInterfaceBrightnessTheme_Light	0
swInterfaceBrightnessTheme_Medium	1
swInterfaceBrightnessTheme_MediumLight	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swInterpolationType_e (Type)

SOLIDWORKS API Enumerations

swInterpolationType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swInterpolationType_e Enumeration

Types of interpolation.

 Syntax

Visual Basic (Declaration)

Public Enum swInterpolationType_e
Inherits System.Enum

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [swInterpolationType_e](#)

C#

public enum swInterpolationType_e : System.Enum

C++/CLI

public enum class swInterpolationType_e : public System.Enum

 Members

Member	Description
swAkimaInterpolation	2
swCubicInterpolation	1
swInvalidInterpolation	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swIntersectionType_e (Type)

SOLIDWORKS API Enumerations

swIntersectionType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swIntersectionType_e Enumeration

Curve intersections types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swIntersectionType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swIntersectionType_e](#)

C#

public enum swIntersectionType_e : System.Enum

C++/CLI

public enum class swIntersectionType_e : public System.Enum

Members

Member	Description
swIntersectionCOINCIDENCE_END	4 = An intersection at the end of a region of coincidence
swIntersectionCOINCIDENCE_START	3 = An intersection at the start of a region of coincidence
swIntersectionSIMPLE	1 = An intersection not adjoining a region of coincidence
swIntersectionTANGENT	2 = A tangent intersection

See Also

[SolidWorks.Interop.swconst Namespace](#)

swIsolateVisibility_e (Type)

SOLIDWORKS API Enumerations

swIsolateVisibility_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swIsolateVisibility_e Enumeration

Isolate component options.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swIsolateVisibility_e
    Inherits System.Enum
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As swIsolateVisibility\_e
```

C#

```
public enum swIsolateVisibility_e : System.Enum
```

C++/CLI

```
public enum class swIsolateVisibility_e : public System.Enum
```

 Members

Member	Description
swIsolateVisibility_HIDDEN	2
swIsolateVisibility_TRANSPARENT	1
swIsolateVisibility_WIREFRAME	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swJogDimensionPositionType_e (Type)

SOLIDWORKS API Enumerations

swJogDimensionPositionType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swJogDimensionPositionType_e Enumeration

Jog dimension position types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swJogDimensionPositionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swJogDimensionPositionType\_e
```

C#

```
public enum swJogDimensionPositionType_e : System.Enum
```

C++/CLI

```
public enum class swJogDimensionPositionType_e : public System.Enum
```

Members

Member	Description
swJogDimensionPositionInsideOffset	1
swJogDimensionPositionOutsideOffset	2
swJogDimensionPositionOverallPosition	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swJogOffsetTypes_e (Type)

 

[SolidWorks.Interop.swconst Namespace](#) : swJogOffsetTypes_e Enumeration

Jog offset types.

Syntax

Visual Basic (Declaration)

Public Enum swJogOffsetTypes_e
Inherits System.Enum

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [swJogOffsetTypes_e](#)

C#

public enum swJogOffsetTypes_e : System.Enum

C++/CLI

public enum class swJogOffsetTypes_e : public System.Enum

Members

Member	Description
swJogOffsetBlind	1
swJogOffsetFromSurface	4
swJogOffsetMidPlane	5
swJogOffsetUpToSurface	3
swJogOffsetUpToVertex	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swJogPositionType_e (Type)

SOLIDWORKS API Enumerations

swJogPositionType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swJogPositionType_e Enumeration

Jog position types.

 Syntax

Visual Basic (Declaration)

Public Enum swJogPositionType_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swJogPositionType_e](#)

C#

public enum swJogPositionType_e : System.Enum

C++/CLI

public enum class swJogPositionType_e : public System.Enum

 Members

Member	Description
swJogPositionBendCenterline	1
swJogPositionBendOutside	4
swJogPositionMaterialInside	2
swJogPositionMaterialOutside	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swKeepReplacedCompOption_e (Type)

SOLIDWORKS API Enumerations

swKeepReplacedCompOption_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swKeepReplacedCompOption_e Enumeration

Options for replacing components in BOM features.

 Syntax

Visual Basic (Declaration)

```
Public Enum swKeepReplacedCompOption_e
    Inherits System.Enum
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As swKeepReplacedCompOption\_e
```

C#

```
public enum swKeepReplacedCompOption_e : System.Enum
```

C++/CLI

```
public enum class swKeepReplacedCompOption_e : public System.Enum
```

 Members

Member	Description
swKeepBothNewItemNumber	0 = Keep both with new item number
swKeepBothSameItemNumber	1 = Keep both with same item number
swKeepItemNumber	2 = Keep item number and do not keep replaced component
swKeepNewItemNumberRemoveReplacedComp	3 = Assign new item number and do not keep replaced component

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swKernelErrorCode_e (Type)

SOLIDWORKS API Enumerations

swKernelErrorCode_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swKernelErrorCode_e Enumeration

Kernel error codes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swKernelErrorCode_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swKernelErrorCode\_e
```

C#

```
public enum swKernelErrorCode_e : System.Enum
```

C++/CLI

```
public enum class swKernelErrorCode_e : public System.Enum
```

Members

Member	Description
swErrorBodyDontKnit	-101041
swErrorCheckFailed	-105061
swErrorCheckFailed2	-113812
swErrorCurveDiscontinuous	-100131
swErrorCurveShort	-101057
swErrorEdgeIncorrectOrder	-116406
swErrorEdgeIssectInvalid	-116404
swErrorError	0
swErrorFacecheckFailed	-113829
swErrorFaceFacelInconsistent	-113816
swErrorFaceRedundant	-116402
swErrorFailed	-101063
swErrorGeometryDegenerate	-113806
swErrorGeometryDiscontinuous	-113827
swErrorGeometryMissing	-113803
swErrorGeometrySelfx	-113805
swErrorHasInvalidity	-101004
swErrorInconsistentDirs	-116403
swErrorInvalidEntity	-100914
swErrorInvalidGeometry	-100999
swErrorInvalidGeometry2	-113808
swErrorInvalidKnots	-100978
swErrorInvalidLoop	-116405
swErrorInvalidParameter	-100120
swErrorInvalidPattern	-101042
swErrorInvalidSharing	-100921
swErrorLoopsInconsistent	-113826
swErrorNotEntity	-100022
swErrorSuccess	1
swErrorSurfaceDiscontinuous	-100129
swErrorTopologySelfx	-113804
swErrorUnknown	-1
swErrorVertexNotOnCurve	-113818
swErrorVerticesTouch	-113821

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLargeDesignReviewState_e (Type)

SOLIDWORKS API Enumerations

swLargeDesignReviewState_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLargeDesignReviewState_e Enumeration

Large Design Review states.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swLargeDesignReviewState_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLargeDesignReviewState\_e
```

C#

```
public enum swLargeDesignReviewState_e : System.Enum
```

C++/CLI

```
public enum class swLargeDesignReviewState_e : public System.Enum
```

Members

Member	Description
swLargeDesignReviewState_LDR	1 = View only
swLargeDesignReviewState_LDR_EditAssembly	2 = LDR edit
swLargeDesignReviewState_None	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLayerItemsOption_e (Type)

SOLIDWORKS API Enumerations

swLayerItemsOption_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLayerItemsOption_e Enumeration

Layer item types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swLayerItemsOption_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swLayerItemsOption\_e
```

C#

```
public enum swLayerItemsOption_e : System.Enum
```

C++/CLI

```
public enum class swLayerItemsOption_e : public System.Enum
```

 Members

Member	Description
swLayerItemsOption_Annotations	1 or 0x1
swLayerItemsOption_SketchBlockInstance	4 or 0x4
swLayerItemsOption_SketchHatch	10 or 0x10
swLayerItemsOption_SketchPoint	8 or 0x8
swLayerItemsOption_SketchSegments	2 or 0x2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLayerOverride_e (Type)

SOLIDWORKS API Enumerations

swLayerOverride_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swLayerOverride_e Enumeration

Layer override types. [Bitmask](#).

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swLayerOverride_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swLayerOverride_e](#)

C#

public enum swLayerOverride_e : System.Enum

C++/CLI

public enum class swLayerOverride_e : public System.Enum

 Members

Member	Description
swLayerOverrideColor	1 or 0x1
swLayerOverrideNone	0 or 0x0
swLayerOverrideStyle	2 or 0x2
swLayerOverrideWidth	4 or 0x4

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLeaderLineVisibility_e (Type)

SOLIDWORKS API Enumerations

swLeaderLineVisibility_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swLeaderLineVisibility_e Enumeration

Visibility of leader lines.

 Syntax

Visual Basic (Declaration)

```
Public Enum swLeaderLineVisibility_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swLeaderLineVisibility\_e
```

C#

```
public enum swLeaderLineVisibility_e : System.Enum
```

C++/CLI

```
public enum class swLeaderLineVisibility_e : public System.Enum
```

 Members

Member	Description
swLeaderLineBoth	0 = Both leader lines are visible
swLeaderLineFirst	1 = Only the first leader line is visible
swLeaderLineNone	3 = Neither leader line is visible
swLeaderLineSecond	2 = Only the second leader line is visible

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLeaderSide_e (Type)

SOLIDWORKS API Enumerations

swLeaderSide_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLeaderSide_e Enumeration

Leader side types.

 Syntax

Visual Basic (Declaration)

Public Enum swLeaderSide_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swLeaderSide_e](#)

C#

public enum swLeaderSide_e : System.Enum

C++/CLI

public enum class swLeaderSide_e : public System.Enum

 Members

Member	Description
swLS_LEFT	1
swLS_RIGHT	2
swLS_SMART	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLeaderStyle_e (Type)

SolidWorks.Interop.swconst Namespace : swLeaderStyle_e Enumeration

Leader styles.

Syntax

Visual Basic (Declaration)

```
Public Enum swLeaderStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLeaderStyle\_e
```

C#

```
public enum swLeaderStyle_e : System.Enum
```

C++/CLI

```
public enum class swLeaderStyle_e : public System.Enum
```

Members

Member	Description
swAlwaysAttachToBalloon	0x1004 or 4100 = Bitmask; applies only to balloon annotations; specifies that the balloon's Always Attach to Balloon leader option is enabled and the leader is always attached to the balloon when quantity is specified, and the balloon's Break Around leader option is disabled; if not specified, then the balloon's Always Attach to Balloon leader option is disabled, and the balloon's Break Around leader option is enabled and the balloon's leader is set to break around quantity; AND with one of the following options: - swBENT - swSTRAIGHT - swUNDERLINED (parts only) - swSPLINE (drawings only) - swVDA
swAttachLeaderBottom	0x400 or 1024 = Bitmask; in part's multiline note, attaches leader to bottom of note; AND with one of the following options: - swBENT - swSTRAIGHT - swUNDERLINED
swAttachLeaderCenter	0x200 or 512 = Bitmask; in a part's multiline note, attaches leader to center of note; AND with one of the following options: - swBENT - swSTRAIGHT - swUNDERLINED
swAttachLeaderNearest	0x800 or 2048 = Bitmask; in a part's multiline note, left leader attaches to the top of note and right leader attaches to the bottom of note; AND with one of the following options: - swBENT - swSTRAIGHT - swUNDERLINED
swAttachLeaderTop	0x100 or 256 = Bitmask; in a part's multiline note, attaches leader to top of note; AND with one of the following options: - swBENT - swSTRAIGHT - swUNDERLINED
swBENT	2 = Creates a bent leader
swNO_LEADER	0 = No leader
swSPLINE	4 = Creates a spline leader from a note; for drawings only
swSTRAIGHT	1 = Creates a straight leader
swUNDERLINED	3 = Creates an underlined leader; for parts only
swVDA	8 = Creates an inspection leader

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLengthUnit_e (Type)

SOLIDWORKS API Enumerations

swLengthUnit_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swLengthUnit_e Enumeration

Length unit types.

Syntax

Visual Basic (Declaration)

```
Public Enum swLengthUnit_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLengthUnit\_e
```

C#

```
public enum swLengthUnit_e : System.Enum
```

C++/CLI

```
public enum class swLengthUnit_e : public System.Enum
```

Members

Member	Description
swANGSTROM	6
swCM	1
swFEET	4
swFEETINCHES	5
swINCHES	3
swMETER	2
swMICRON	8
swMIL	9
swMM	0
swNANOMETER	7
swUIN	10

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLibFeatDimensionType_e (Type)

SOLIDWORKS API Enumerations

swLibFeatDimensionType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swLibFeatDimensionType_e Enumeration

Library feature dimension types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swLibFeatDimensionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLibFeatDimensionType\_e
```

C#

```
public enum swLibFeatDimensionType_e : System.Enum
```

C++/CLI

```
public enum class swLibFeatDimensionType_e : public System.Enum
```

Members

Member	Description
swLibFeatLocatingDimension	0
swLibFeatSizeDimension	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLibFeatureData_e (Type)

SOLIDWORKS API Enumerations

swLibFeatureData_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLibFeatureData_e Enumeration

Library feature entity options.

 Syntax

Visual Basic (Declaration)

Public Enum swLibFeatureData_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swLibFeatureData_e](#)

C#

public enum swLibFeatureData_e : System.Enum

C++/CLI

public enum class swLibFeatureData_e : public System.Enum

 Members

Member	Description
swLibFeatureData_FeatureRespect	0 = Library feature
swLibFeatureData_PartRespect	1 = Part

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLicenseType_e (Type)

SOLIDWORKS API Enumerations

swLicenseType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLicenseType_e Enumeration

SOLIDWORKS license types.

 Syntax

Visual Basic (Declaration)

Public Enum swLicenseType_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swLicenseType_e](#)

C#

public enum swLicenseType_e : System.Enum

C++/CLI

public enum class swLicenseType_e : public System.Enum

 Members

Member	Description
swLicenseType_Educational	1
swLicenseType_Full	0
swLicenseType_Full_Office	5
swLicenseType_Full_Premium	7
swLicenseType_Full_Professional	6
swLicenseType_Full_Ultimate	9
swLicenseType_Maker	8
swLicenseType_PersonalEdition	4
swLicenseType_Student	2
swLicenseType_StudentDesignKit	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLineEndCaps_e (Type)

SOLIDWORKS API Enumerations

swLineEndCaps_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLineEndCaps_e Enumeration

Line end caps types.

 Syntax

Visual Basic (Declaration)

Public Enum swLineEndCaps_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swLineEndCaps_e](#)

C#

public enum swLineEndCaps_e : System.Enum

C++/CLI

public enum class swLineEndCaps_e : public System.Enum

 Members

Member	Description
swLineEndCapFlat	1
swLineEndCapRound	2
swLineEndCapSquare	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLineStyles_e (Type)

SOLIDWORKS API Enumerations

swLineStyles_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swLineStyles_e Enumeration

Line styles used in drawings.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swLineStyles_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLineStyles\_e
```

C#

```
public enum swLineStyles_e : System.Enum
```

C++/CLI

```
public enum class swLineStyles_e : public System.Enum
```

Members

Member	Description
swLineCENTER	4
swLineCHAIN	3
swLineCHAINTHICK	6 = Thin/Thick Chain
swLineCONTINUOUS	0 = Solid
swLineDEFAULT	7
swLineHIDDEN	1 = Dashed
swLinePHANTOM	2
swLineSTITCH	5

Remarks

Open a drawing and view line style appearances in **Tools > Options > Document Properties > Line Style**.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLineTypes_e (Type)

SOLIDWORKS API Enumerations

swLineTypes_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swLineTypes_e Enumeration

Line styles in drawings.

Syntax

Visual Basic (Declaration)

Public Enum swLineTypes_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swLineTypes_e](#)

C#

public enum swLineTypes_e : System.Enum

C++/CLI

public enum class swLineTypes_e : public System.Enum

Members

Member	Description
swLF_CENTER	6
swLF_DETAIL	3
swLF_DIMENSION	5
swLF_HATCH	7
swLF_HIDDEN	1
swLF_SECTION	4
swLF_SKETCH	2
swLF_TANGENT	8
swLF_VISIBLE	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLineWeights_e (Type)

SOLIDWORKS API Enumerations

swLineWeights_e Enumeration

See Also

[Send comments on this topic.](#)

 SolidWorks.Interop.swconst Namespace : swLineWeights_e Enumeration

Line weights used in layers.

 Syntax

Visual Basic (Declaration)

Public Enum swLineWeights_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swLineWeights_e](#)



C#

public enum swLineWeights_e : System.Enum

C++/CLI

public enum class swLineWeights_e : public System.Enum

 Members

Member	Description
swLW_CUSTOM	10
swLW_LAYER	9
swLW_NONE	-1
swLW_NORMAL	1
swLW_NUMBER	8
swLW_THICK	2
swLW_THICK2	3
swLW_THICK3	4
swLW_THICK4	5
swLW_THICK5	6
swLW_THICK6	7
swLW_THIN	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLinkBomToDisplayStateError_e (Type)

SOLIDWORKS API Enumerations

swLinkBomToDisplayStateError_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLinkBomToDisplayStateError_e Enumeration

Errors when linking a BOM to a Display State.

 Syntax

Visual Basic (Declaration)

```
Public Enum swLinkBomToDisplayStateError_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swLinkBomToDisplayStateError\_e
```

C#

```
public enum swLinkBomToDisplayStateError_e : System.Enum
```

C++/CLI

```
public enum class swLinkBomToDisplayStateError_e : public System.Enum
```

 Members

Member	Description
swLinkBomToDisplayState_InvalidDisplayState	1
swLinkBomToDisplayState_MultipleConfigurations	2
swLinkBomToDisplayState_Success	0

 Remarks

This enumeration is used in IBomFeature::GetLinkToDisplayState and IBomFeature::SetLinkToDisplayState.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLinkDimensionError_e (Type)

SOLIDWORKS API Enumerations

swLinkDimensionError_e Enumeration

See Also

Send comments on this topic.

 SolidWorks.Interop.swconst Namespace : swLinkDimensionError_e Enumeration

Link dimension errors.

 Syntax

Visual Basic (Declaration)

```
Public Enum swLinkDimensionError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLinkDimensionError\_e
```

C#

```
public enum swLinkDimensionError_e : System.Enum
```

C++/CLI

```
public enum class swLinkDimensionError_e : public System.Enum
```

 Members

Member	Description
swLinkDimensionError_AlreadyLinked	4 = Dimension already linked elsewhere
swLinkDimensionError_CannotLink	8 = The selected dimensions cannot be linked; combination of failures swLinkDimensionError_LinkAcrossDocs to swLinkDimensionError_DrivenByEquation
swLinkDimensionError_DrivenByEquation	7 = Dimension's driven by an equation
swLinkDimensionError_EmptyString	11 = Empty string passed as link text
swLinkDimensionError_ErrorUnknown	0 = Unknown error occurred
swLinkDimensionError_IncompatibleDimTypes	3 = Cannot link incompatible dimension types
swLinkDimensionError_IncompatibleValues	6 = Incompatible range of values make these dimensions not linkable
swLinkDimensionError_InvalidString	12 = Invalid string passed as link text; cannot contain the at sign (@) character
swLinkDimensionError_LinkAcrossDocs	2 = Values to be linked must belong to the same model
swLinkDimensionError_NoError	1 = No error; success
swLinkDimensionError_ReadOnlyOrDriven	5 = Dimension is a read-only, driven, or a reference dimension that cannot be linked
swLinkDimensionError_UnableToCreateSharedParam	9 = Shared parameter could not be created
swLinkDimensionError_UnlinkFailure	10 = Dimension was not already linked

 See Also

[SolidWorks.Interop.swconst Namespace](#)