

SOLIDWORKS Enumerations (swconst) — Reference (9/17): swLinkString- swMoveCopyOptions_e

SOLIDWORKS API Documentation (converted from CHM)

swLinkString (Type)

 

[SolidWorks.Interop.swconst Namespace](#) : swLinkString Enumeration

Types of links for errors and trouble-shooting bubbles.

 Syntax

Visual Basic (Declaration)

Public Enum swLinkString
Inherits System.Enum

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [swLinkString](#)

C#

public enum swLinkString : System.Enum

C++/CLI

public enum class swLinkString : public System.Enum

 Members

Member	Description
swLinkStringNone	0 = None
swLinkStringTroubleShootTip	2 = Trouble-shooting tip
swLinkStringUserDefined	1 = User-defined

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLoadAddinError_e (Type)

SOLIDWORKS API Enumerations

swLoadAddinError_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLoadAddinError_e Enumeration

Add-in load errors.

 Syntax

Visual Basic (Declaration)

```
Public Enum swLoadAddinError_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swLoadAddinError\_e
```

C#

```
public enum swLoadAddinError_e : System.Enum
```

C++/CLI

```
public enum class swLoadAddinError_e : public System.Enum
```

 Members

Member	Description
swAddinAlreadyLoaded	2
swAddinNotLoaded	1
swAddinsDisabled	4
swFileNotFound	3
swLicenseError	7
swLoadConflict	5
swRegistrationError	6
swSuccess	0
swUnknownError	-1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLoadDetachedModelRules_e (Type)

SOLIDWORKS API Enumerations

swLoadDetachedModelRules_e Enumeration

[See Also](#)

[SolidWorks.Interop.swconst Namespace](#) : swLoadDetachedModelRules_e Enumeration

Detached model load options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swLoadDetachedModelRules_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLoadDetachedModelRules\_e
```

C#

```
public enum swLoadDetachedModelRules_e : System.Enum
```

C++/CLI

```
public enum class swLoadDetachedModelRules_e : public System.Enum
```

Members

Member	Description
swDoNotLoadDetachedModel	2
swLoadDetachedModelAuto	1
swLoadDetachedModelPrompt	0
swLoadDetailedModel	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLoadExternalReferences_e (Type)

SOLIDWORKS API Enumerations

swLoadExternalReferences_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLoadExternalReferences_e Enumeration

External references load options.

 Syntax

Visual Basic (Declaration)

```
Public Enum swLoadExternalReferences_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swLoadExternalReferences\_e
```

C#

```
public enum swLoadExternalReferences_e : System.Enum
```

C++/CLI

```
public enum class swLoadExternalReferences_e : public System.Enum
```

 Members

Member	Description
swLoadExternalReferences_All	1
swLoadExternalReferences_ChangedOnly	3
swLoadExternalReferences_None	2
swLoadExternalReferences_Prompt	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLocalCurvePatternAlignment_e (Type)

SOLIDWORKS API Enumerations

swLocalCurvePatternAlignment_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLocalCurvePatternAlignment_e Enumeration

Alignments for local curve-driven patterns.

 Syntax

Visual Basic (Declaration)

```
Public Enum swLocalCurvePatternAlignment_e
    Inherits System.Enum
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As swLocalCurvePatternAlignment\_e
```

C#

```
public enum swLocalCurvePatternAlignment_e : System.Enum
```

C++/CLI

```
public enum class swLocalCurvePatternAlignment_e : public System.Enum
```

 Members

Member	Description
swLocalCurvePatternAlignToSeed	1
swLocalCurvePatternTangentToCurve	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLocalCurvePatternCurveMethod_e (Type)

SOLIDWORKS API Enumerations

swLocalCurvePatternCurveMethod_e Enumeration

See Also

▼

SolidWorks.Interop.swconst Namespace : swLocalCurvePatternCurveMethod_e Enumeration

Curve methods for local curve-driven patterns.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swLocalCurvePatternCurveMethod_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLocalCurvePatternCurveMethod\_e
```

C#

```
public enum swLocalCurvePatternCurveMethod_e : System.Enum
```

C++/CLI

```
public enum class swLocalCurvePatternCurveMethod_e : public System.Enum
```

Members

Member	Description
swLocalCurvePatternOffsetCurve	1
swLocalCurvePatternTransformCurve	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLocalCurvePatternReferencePoint_e (Type)

SOLIDWORKS API Enumerations

swLocalCurvePatternReferencePoint_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLocalCurvePatternReferencePoint_e Enumeration

Reference points for local curve-driven patterns.

Syntax

Visual Basic (Declaration)

Public Enum swLocalCurvePatternReferencePoint_e
Inherits System.Enum

Visual Basic (Usage)

 [Copy Code](#)

Dim instance As [swLocalCurvePatternReferencePoint_e](#)

C#

public enum swLocalCurvePatternReferencePoint_e : System.Enum

C++/CLI

public enum class swLocalCurvePatternReferencePoint_e : public System.Enum

Members

Member	Description
swLocalCurvePatternBoundingBoxCenter	1
swLocalCurvePatternComponentOrigin	2
swLocalCurvePatternSelectedPoint	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLocalSketchPatternReferencePoint_e (Type)

SOLIDWORKS API Enumerations

swLocalSketchPatternReferencePoint_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLocalSketchPatternReferencePoint_e Enumeration

Reference points for local sketch-driven patterns.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swLocalSketchPatternReferencePoint_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLocalSketchPatternReferencePoint\_e
```

C#

```
public enum swLocalSketchPatternReferencePoint_e : System.Enum
```

C++/CLI

```
public enum class swLocalSketchPatternReferencePoint_e : public System.Enum
```

Members

Member	Description
swLocalSketchPatternBoundingBoxCenter	1
swLocalSketchPatternComponentOrigin	2
swLocalSketchPatternSelectedPoint	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swLocationLabelText_e (Type)

 

[SolidWorks.Interop.swconst Namespace](#) : swLocationLabelText_e Enumeration

Types of text for the upper and lower sections of location labels.

 Syntax

Visual Basic (Declaration)

```
Public Enum swLocationLabelText_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swLocationLabelText\_e
```

C#

```
public enum swLocationLabelText_e : System.Enum
```

C++/CLI

```
public enum class swLocationLabelText_e : public System.Enum
```

 Members

Member	Description
swLocationLabelTextSheet	0
swLocationLabelTextSheetWithLabel	1
swLocationLabelTextText	4
swLocationLabelTextViewLetter	3
swLocationLabelTextZone	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLoftedBendFacetOptions_e (Type)

SOLIDWORKS API Enumerations

swLoftedBendFacetOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLoftedBendFacetOptions_e Enumeration

Faceting options for lofted bend facet features.

 Syntax

Visual Basic (Declaration)

Public Enum swLoftedBendFacetOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swLoftedBendFacetOptions_e](#)



C#

public enum swLoftedBendFacetOptions_e : System.Enum

C++/CLI

public enum class swLoftedBendFacetOptions_e : public System.Enum

 Members

Member	Description
swAngleBetweenSegments	3 = Facet by maximum angle between adjacent linear segments
swBendsPerTransitionSegment	1 = Facet by maximum number of bends per transition segment
swChordTolerance	0 = Facet by maximum distance between the arc and linear segment of a chord on the lofted bend
swMaxSegmentLength	2 = Facet by maximum length of a linear segment

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swLoopProcessOption_e (Type)

SOLIDWORKS API Enumerations

swLoopProcessOption_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swLoopProcessOption_e Enumeration

Loop processing options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swLoopProcessOption_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swLoopProcessOption\_e
```

C#

```
public enum swLoopProcessOption_e : System.Enum
```

C++/CLI

```
public enum class swLoopProcessOption_e : public System.Enum
```

Members

Member	Description
swLoopProcess_Auto	2
swLoopProcess_Independent	1
swLoopProcess_Together	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMacroFeatureEntityType_e (Type)

SOLIDWORKS API Enumerations

swMacroFeatureEntityType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swMacroFeatureEntityType_e Enumeration

Macro feature entity ID types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swMacroFeatureEntityType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swMacroFeatureEntityType_e](#)

C#

public enum swMacroFeatureEntityType_e : System.Enum

C++/CLI

public enum class swMacroFeatureEntityType_e : public System.Enum

Members

Member	Description
swMacroFeatureEntityIdDerived	2
swMacroFeatureEntityIdNotApplied	-1
swMacroFeatureEntityIdUndefined	0
swMacroFeatureEntityIdUnique	1
swMacroFeatureEntityIdUserDefined	3

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMacroFeatureOptions_e (Type)

SOLIDWORKS API Enumerations

swMacroFeatureOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

▼

[SolidWorks.Interop.swconst Namespace](#) : swMacroFeatureOptions_e Enumeration

Placement of the macro feature in the FeatureManager design tree options. [Bitmask](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swMacroFeatureOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMacroFeatureOptions\_e
```

C#

```
public enum swMacroFeatureOptions_e : System.Enum
```

C++/CLI

```
public enum class swMacroFeatureOptions_e : public System.Enum
```

Members

Member	Description
swMacroFeatureAlwaysAtEnd	1 or 0x1
swMacroFeatureByDefault	0 or 0x0
swMacroFeatureEmbedMacroFile	16 or 0x10; not supported by programming languages for the Microsoft .NET Framework; for example, not supported by C#, Visual Basic .NET, or Managed C++
swMacroFeatureIsDragable	4 or 0x4
swMacroFeatureIsPatternable	2 or 0x2
swMacroFeatureNoCachedBody	8 or 0x8; do not serialize cached body in macro feature

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMacroFeatureParamType_e (Type)

SOLIDWORKS API Enumerations

swMacroFeatureParamType_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swMacroFeatureParamType_e Enumeration

Macro feature parameter types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

```
Public Enum swMacroFeatureParamType_e
    Inherits System.Enum
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As swMacroFeatureParamType\_e
```

C#

```
public enum swMacroFeatureParamType_e : System.Enum
```

C++/CLI

```
public enum class swMacroFeatureParamType_e : public System.Enum
```

 Members

Member	Description
swMacroFeatureParamTypeDouble	1
swMacroFeatureParamTypeInteger	2
swMacroFeatureParamTypeString	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMacroFeatureSecurityOptions_e (Type)

SOLIDWORKS API Enumerations

swMacroFeatureSecurityOptions_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMacroFeatureSecurityOptions_e Enumeration

Macro feature security options. [Bitmask](#).

Syntax

Visual Basic (Declaration)

```
Public Enum swMacroFeatureSecurityOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMacroFeatureSecurityOptions\_e
```

C#

```
public enum swMacroFeatureSecurityOptions_e : System.Enum
```

C++/CLI

```
public enum class swMacroFeatureSecurityOptions_e : public System.Enum
```

Members

Member	Description
swMacroFeatureSecurityByDefault	0 or 0x0
swMacroFeatureSecurityCannotBeDeleted	1 or 0x1
swMacroFeatureSecurityCannotBeReplaced	8 or 0x8
swMacroFeatureSecurityCannotBeRolledBack	32 or 0x20
swMacroFeatureSecurityCannotBeSuppressed	4 or 0x4
swMacroFeatureSecurityEnableNote	16 or 0x10
swMacroFeatureSecurityNotEditable	2 or 0x2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMacroMethods_e (Type)

SOLIDWORKS API Enumerations

swMacroMethods_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMacroMethods_e Enumeration

Types of macro methods.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMacroMethods_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMacroMethods\_e
```

C#

```
public enum swMacroMethods_e : System.Enum
```

C++/CLI

```
public enum class swMacroMethods_e : public System.Enum
```

Members

Member	Description
swAllMethods	3
swMethodsWithArguments	2
swMethodsWithoutArguments	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swManipulatorCursor_e (Type)

SOLIDWORKS API Enumerations

swManipulatorCursor_e Enumeration

See Also

[Send comments on this topic.](#)

 [SolidWorks.Interop.swconst Namespace](#) : swManipulatorCursor_e Enumeration

Triad manipulator cursor types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swManipulatorCursor_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swManipulatorCursor\_e
```

C#

```
public enum swManipulatorCursor_e : System.Enum
```

C++/CLI

```
public enum class swManipulatorCursor_e : public System.Enum
```

 Members

Member	Description
swManipulatorMoveCursor	1
swManipulatorMoveRotateCursor	3
swManipulatorRotateCursor	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swManipulatorOptions_e (Type)

SOLIDWORKS API Enumerations

swManipulatorOptions_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swManipulatorOptions_e Enumeration

Manipulator options. [Bitmask](#).

Syntax

Visual Basic (Declaration)

Public Enum swManipulatorOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swManipulatorOptions_e](#)

C#

public enum swManipulatorOptions_e : System.Enum

C++/CLI

public enum class swManipulatorOptions_e : public System.Enum

Members

Member	Description
swManipulatorOpts_Default	0 or 0x0; Manipulators created using the SOLIDWORKS API are deleted when a component is modified or deleted in the context of an assembly NOTE: This is the default behavior.
swManipulatorOpts_KeepAfterComponentModify	1 or 0x1; Manipulators are not deleted when a component is modified or deleted in the context of an assembly

See Also

[SolidWorks.Interop.swconst Namespace](#)

swManipulatorRepresentation_e (Type)

SOLIDWORKS API Enumerations

swManipulatorRepresentation_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swManipulatorRepresentation_e Enumeration

Triad manipulator representations.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swManipulatorRepresentation_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swManipulatorRepresentation\_e
```

C#

```
public enum swManipulatorRepresentation_e : System.Enum
```

C++/CLI

```
public enum class swManipulatorRepresentation_e : public System.Enum
```

Members

Member	Description
swManipulatorRepresentationArrow	5
swManipulatorRepresentationBitmap	13
swManipulatorRepresentationCircle	2
swManipulatorRepresentationDiamond	3
swManipulatorRepresentationEmpty	15
swManipulatorRepresentationMiscTopol	12
swManipulatorRepresentationNone	0
swManipulatorRepresentationPanHandle	8
swManipulatorRepresentationRotationHandle	7
swManipulatorRepresentationScaleHandle	9
swManipulatorRepresentationShadow	14
swManipulatorRepresentationSquare	1
swManipulatorRepresentationSurfTopol	10
swManipulatorRepresentationTextBox	6
swManipulatorRepresentationTriangle	4
swManipulatorRepresentationWireTopol	11

See Also

[SolidWorks.Interop.swconst Namespace](#)

swManipulatorType_e (Type)

SOLIDWORKS API Enumerations

swManipulatorType_e Enumeration

See Also

▼

[SolidWorks.Interop.swconst Namespace](#) : swManipulatorType_e Enumeration

Manipulator types.

[Send comments on this topic.](#)

 Syntax

Visual Basic (Declaration)

Public Enum swManipulatorType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swManipulatorType_e](#)

C#

public enum swManipulatorType_e : System.Enum

C++/CLI

public enum class swManipulatorType_e : public System.Enum

 Members

Member	Description
swDragArrowManipulator	1 = Allows the user to manipulate a dimension handle
swPlaneManipulator	2 = Allows the user to manipulate planes
swTriadManipulator	0 = Allows the user to re-position objects using the triad tool

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMassPropertiesStatus_e (Type)

SOLIDWORKS API Enumerations

swMassPropertiesStatus_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swMassPropertiesStatus_e Enumeration

Mass property result codes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMassPropertiesStatus_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMassPropertiesStatus\_e
```

C#

```
public enum swMassPropertiesStatus_e : System.Enum
```

C++/CLI

```
public enum class swMassPropertiesStatus_e : public System.Enum
```

Members

Member	Description
swMassPropertiesStatus_NoBody	2 = Mass properties calculation failed because there is no body in the model
swMassPropertiesStatus_OK	0 = Mass properties calculation successful
swMassPropertiesStatus_UnknownError	1 = Mass properties calculation failed for an unknown reason

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMassPropertyAccuracyLevel_e (Type)

SOLIDWORKS API Enumerations

swMassPropertyAccuracyLevel_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swMassPropertyAccuracyLevel_e Enumeration

Mass property accuracy level options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMassPropertyAccuracyLevel_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMassPropertyAccuracyLevel\_e
```

C#

```
public enum swMassPropertyAccuracyLevel_e : System.Enum
```

C++/CLI

```
public enum class swMassPropertyAccuracyLevel_e : public System.Enum
```

Members

Member	Description
swMassPropertyAccuracyLevel_Higher	2 = More accurate but slower
swMassPropertyAccuracyLevel_Lower	0 = Least accurate but faster
swMassPropertyAccuracyLevel_Medium	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMassPropertyMoment_e (Type)

SOLIDWORKS API Enumerations

swMassPropertyMoment_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

SolidWorks.Interop.swconst Namespace : swMassPropertyMoment_e Enumeration

Moment of inertia coordinate systems.

Syntax

Visual Basic (Declaration)

Public Enum swMassPropertyMoment_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swMassPropertyMoment_e](#)

C#

public enum swMassPropertyMoment_e : System.Enum

C++/CLI

public enum class swMassPropertyMoment_e : public System.Enum

Members

Member	Description
swMassPropertyMomentAboutCenterOfMass	0
swMassPropertyMomentAboutCoordSys	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMateAlign_e (Type)

SOLIDWORKS API Enumerations

swMateAlign_e Enumeration

See Also

Send comments on this topic.

 

SolidWorks.Interop.swconst Namespace : swMateAlign_e Enumeration

Mate alignment types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swMateAlign_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swMateAlign\_e
```

C#

```
public enum swMateAlign_e : System.Enum
```

C++/CLI

```
public enum class swMateAlign_e : public System.Enum
```

 Members

Member	Description
swAlignAGAINST	Obsolete. Do not use.
swAlignNONE	Obsolete. Do not use.
swAlignSAME	Obsolete. Do not use.
swMateAlignALIGNED	0
swMateAlignANTI_ALIGNED	1
swMateAlignCLOSEST	2

 Remarks

These values have been changed to correct improper mate alignment mapping.

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMateEntity2ReferenceType_e (Type)

SOLIDWORKS API Enumerations

swMateEntity2ReferenceType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swMateEntity2ReferenceType_e Enumeration

Mate entity reference types.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMateEntity2ReferenceType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMateEntity2ReferenceType\_e
```

C#

```
public enum swMateEntity2ReferenceType_e : System.Enum
```

C++/CLI

```
public enum class swMateEntity2ReferenceType_e : public System.Enum
```

Members

Member	Description
swMateEntity2ReferenceType_Circle	2
swMateEntity2ReferenceType_Cone	7
swMateEntity2ReferenceType_Cylinder	4
swMateEntity2ReferenceType_Ellipse	11
swMateEntity2ReferenceType_GeneralCurve	12
swMateEntity2ReferenceType_GenSurface	10
swMateEntity2ReferenceType_Line	1
swMateEntity2ReferenceType_MultipleSurface	9
swMateEntity2ReferenceType_Plane	3
swMateEntity2ReferenceType_Point	0
swMateEntity2ReferenceType_Set	6
swMateEntity2ReferenceType_Sphere	5
swMateEntity2ReferenceType_SweptSurface	8
swMateEntity2ReferenceType_UNKNOWN	13

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMateEntityTypes_e (Type)

SOLIDWORKS API Enumerations

swMateEntityTypes_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMateEntityTypes_e Enumeration

Mate entity type IDs.

 Syntax

Visual Basic (Declaration)

Public Enum swMateEntityTypes_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swMateEntityTypes_e](#)

C#

public enum swMateEntityTypes_e : System.Enum

C++/CLI

public enum class swMateEntityTypes_e : public System.Enum

 Members

Member	Description
swMateCircle	7
swMateCone	5
swMateCylinder	4
swMateLine	2
swMatePlane	3
swMatePoint	1
swMateSphere	6
swMateUnsupported	0

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMateReferenceAlignment_e (Type)

SOLIDWORKS API Enumerations

swMateReferenceAlignment_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMateReferenceAlignment_e Enumeration

Mate reference alignments.

 Syntax

Visual Basic (Declaration)

```
Public Enum swMateReferenceAlignment_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swMateReferenceAlignment\_e
```

C#

```
public enum swMateReferenceAlignment_e : System.Enum
```

C++/CLI

```
public enum class swMateReferenceAlignment_e : public System.Enum
```

 Members

Member	Description
swMateReferenceAlignment_Aligned	1
swMateReferenceAlignment_AntiAligned	2
swMateReferenceAlignment_Any	0
swMateReferenceAlignment_Closest	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMateReferenceIndex_e (Type)

SOLIDWORKS API Enumerations

swMateReferenceIndex_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swMateReferenceIndex_e Enumeration

Mate reference indexes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMateReferenceIndex_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMateReferenceIndex\_e
```

C#

```
public enum swMateReferenceIndex_e : System.Enum
```

C++/CLI

```
public enum class swMateReferenceIndex_e : public System.Enum
```

Members

Member	Description
swMateReference_Primary	0
swMateReference_Secondary	1
swMateReference_Tertiary	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMateReferenceType_e (Type)

SOLIDWORKS API Enumerations

swMateReferenceType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMateReferenceType_e Enumeration

Mate reference types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swMateReferenceType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swMateReferenceType\_e
```

C#

```
public enum swMateReferenceType_e : System.Enum
```

C++/CLI

```
public enum class swMateReferenceType_e : public System.Enum
```

 Members

Member	Description
swMateReferenceType_Coincident	2
swMateReferenceType_Concentric	3
swMateReferenceType_default	0
swMateReferenceType_Parallel	4
swMateReferenceType_Tangent	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMaterialModifier_e (Type)

SOLIDWORKS API Enumerations

swMaterialModifier_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMaterialModifier_e Enumeration

Material modifiers in Gtol frames.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMaterialModifier_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMaterialModifier\_e
```

C#

```
public enum swMaterialModifier_e : System.Enum
```

C++/CLI

```
public enum class swMaterialModifier_e : public System.Enum
```

Members

Member	Description
swMaterialModifier_LeastMaterialCondition	3
swMaterialModifier_MaximumMaterialCondition	2
swMaterialModifier_None	0
swMaterialModifier_RegardlessOfFeatureSize	4
swMaterialModifier_Translation	5
swMaterialModifier_Unknown	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMatesDefaultMisalignment_e (Type)

SOLIDWORKS API Enumerations

swMatesDefaultMisalignment_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swMatesDefaultMisalignment_e Enumeration

Concentric mate misalignment options.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swMatesDefaultMisalignment_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swMatesDefaultMisalignment_e](#)

C#

public enum swMatesDefaultMisalignment_e : System.Enum

C++/CLI

public enum class swMatesDefaultMisalignment_e : public System.Enum

Members

Member	Description
swMatesAlignFirstConcentricMate	0; Align this mate; align the mate currently being edited to be exactly concentric, causing the linked mate to be misaligned
swMatesAlignSecondConcentricMate	1; Align linked mate; aligns the linked mate to be exactly concentric, causing the currently edited mate to be misaligned
swMatesSymmetric	2; Symmetric; misaligns both concentric mates, splitting the deviation evenly between mates

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMateType_e (Type)

SOLIDWORKS API Enumerations

swMateType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 [SolidWorks.Interop.swconst Namespace](#) : swMateType_e Enumeration

Assembly mate types.

Syntax

Visual Basic (Declaration)

```
Public Enum swMateType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMateType\_e
```

C#

```
public enum swMateType_e : System.Enum
```

C++/CLI

```
public enum class swMateType_e : public System.Enum
```

Members

Member	Description
swMateANGLE	6
swMateCAMFOLLOWER	9
swMateCOINCIDENT	0
swMateCONCENTRIC	1
swMateCOORDINATE	20
swMateDISTANCE	5
swMateGEAR	10
swMateHINGE	22
swMateLINEARCOUPLER	18
swMateLOCK	16
swMateLOCKTOSKETCH	12
swMateMAGNETIC	25
swMateMAXMATES	14
swMatePARALLEL	3
swMatePATH	15
swMatePERPENDICULAR	2
swMatePROFILECENTER	24
swMateRACKPINION	13
swMateSCREW	17
swMateSLIDER	23
swMateSLOT	21
swMateSYMMETRIC	8
swMateTANGENT	4
swMateUNIVERSALJOINT	19
swMateUNKNOWN	7
swMateWIDTH	11

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMateWidthOptions_e (Type)

SOLIDWORKS API Enumerations

swMateWidthOptions_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swMateWidthOptions_e Enumeration

Assembly mate width options.

Syntax

Visual Basic (Declaration)

```
Public Enum swMateWidthOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMateWidthOptions\_e
```

C#

```
public enum swMateWidthOptions_e : System.Enum
```

C++/CLI

```
public enum class swMateWidthOptions_e : public System.Enum
```

Members

Member	Description
swMateWidth_Centered	0
swMateWidth_Dimension	2
swMateWidth_Free	1
swMateWidth_Percent	3

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMBDSTEP242PublishEdition_e (Type)

SOLIDWORKS API Enumerations

swMBDSTEP242PublishEdition_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMBDSTEP242PublishEdition_e Enumeration

Step 242 publish editions.

 Syntax

Visual Basic (Declaration)

Public Enum swMBDSTEP242PublishEdition_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swMBDSTEP242PublishEdition_e](#)



C#

public enum swMBDSTEP242PublishEdition_e : System.Enum

C++/CLI

public enum class swMBDSTEP242PublishEdition_e : public System.Enum

 Members

Member	Description
swPublishSTEP242Edition_1_0	1
swPublishSTEP242Edition_2_0	2
swPublishSTEP242Edition_3_0	3

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMeasureArcCircleOption_e (Type)

SOLIDWORKS API Enumerations

swMeasureArcCircleOption_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMeasureArcCircleOption_e Enumeration

Distance to display when arcs or circles are selected using the Measure tool.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMeasureArcCircleOption_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMeasureArcCircleOption\_e
```

C#

```
public enum swMeasureArcCircleOption_e : System.Enum
```

C++/CLI

```
public enum class swMeasureArcCircleOption_e : public System.Enum
```

Members

Member	Description
swMeasureArcCircle_CenterToCenter	0
swMeasureArcCircle_CustomCenterToCenter	3
swMeasureArcCircle_CustomCenterToMaximum	7
swMeasureArcCircle_CustomCenterToMinimum	6
swMeasureArcCircle_CustomMaximumToCenter	9
swMeasureArcCircle_CustomMaximumToMaximum	5
swMeasureArcCircle_CustomMaximumToMinimum	11
swMeasureArcCircle_CustomMinimumToCenter	8
swMeasureArcCircle_CustomMinimumToMaximum	10
swMeasureArcCircle_CustomMinimumToMinimum	4
swMeasureArcCircle_MaximumDistance	2
swMeasureArcCircle_MinimumDistance	1

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMeasureProjectOnOption_e (Type)

SOLIDWORKS API Enumerations

swMeasureProjectOnOption_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMeasureProjectOnOption_e Enumeration

Distance between selected entities projection when using the Measure tool.

 Syntax

Visual Basic (Declaration)

Public Enum swMeasureProjectOnOption_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swMeasureProjectOnOption_e](#)

C#

public enum swMeasureProjectOnOption_e : System.Enum

C++/CLI

public enum class swMeasureProjectOnOption_e : public System.Enum

 Members

Member	Description
swMeasureProjectOn_FaceOrPlane	2
swMeasureProjectOn_None	0
swMeasureProjectOn_Screen	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMenuIdentifiers_e (Type)

SOLIDWORKS API Enumerations

swMenuIdentifiers_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMenuIdentifiers_e Enumeration

Menu item types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swMenuIdentifiers_e
    Inherits System.Enum
```

Visual Basic (Usage)

 [Copy Code](#)

```
Dim instance As swMenuIdentifiers\_e
```

C#

```
public enum swMenuIdentifiers_e : System.Enum
```

C++/CLI

```
public enum class swMenuIdentifiers_e : public System.Enum
```

 Members

Member	Description
swDeveloperToolsMenu	7
swEditMenu	1
swFileMenu	0
swHelpMenu	6
swInsertMenu	3
swToolsMenu	4
swViewMenu	2
swViewToolbarsMenu	8
swWindowMenu	5

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMenuItemType_e (Type)

SOLIDWORKS API Enumerations

swMenuItemType_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swMenuItemType_e Enumeration

Menu item types.

 Syntax

Visual Basic (Declaration)

```
Public Enum swMenuItemType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swMenuItemType\_e
```

C#

```
public enum swMenuItemType_e : System.Enum
```

C++/CLI

```
public enum class swMenuItemType_e : public System.Enum
```

 Members

Member	Description
swMenuItemType_Break	1 = Add titles to sections of third-party pop-up menus
swMenuItemType_Default	0 = Add actionable menu items to third-party pop-up menus
swMenuItemType_Separator	2 = Add separator bars to third-party pop-up menus

 See Also

[SolidWorks.Interop.swconst Namespace](#)
[ISldWorks::AddItemToThirdPartyPopupMenu](#)
[ISldWorks::AddItemToThirdPartyPopupMenu2](#)

swMessageBoxBtn_e (Type)

[SolidWorks.Interop.swconst Namespace](#) : swMessageBoxBtn_e Enumeration

Message box control buttons.

Syntax

Visual Basic (Declaration)

```
Public Enum swMessageBoxBtn_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMessageBoxBtn\_e
```

C#

```
public enum swMessageBoxBtn_e : System.Enum
```

C++/CLI

```
public enum class swMessageBoxBtn_e : public System.Enum
```

Members

Member	Description
swMbAbortRetryIgnore	1 = The message box contains three push buttons: Abort, Retry, and Ignore
swMbOk	2 = The message box contains one button, OK
swMbOkCancel	3 = The message box contains two push buttons: OK and Cancel
swMbRetryCancel	4 = The message box contains two push buttons: Retry and Cancel
swMbYesNo	5 = The message box contains two push buttons: Yes and No
swMbYesNoCancel	6 = The message box contains three push buttons: Yes, No, and Cancel

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMessageBoxIcon_e (Type)

SOLIDWORKS API Enumerations

swMessageBoxIcon_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMessageBoxIcon_e Enumeration

Message box icons.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMessageBoxIcon_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMessageBoxIcon\_e
```

C#

```
public enum swMessageBoxIcon_e : System.Enum
```

C++/CLI

```
public enum class swMessageBoxIcon_e : public System.Enum
```

Members

Member	Description
swMbInformation	2 = An icon containing the letter i in a circle appears in the message box
swMbQuestion	3 = A question-mark (?) icon appears in the message box
swMbStop	4 = A stop-sign icon appears in the message box
swMbWarning	1 = An exclamation-point (!) icon appears in the message box

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMessageBoxResult_e (Type)

▼

[SolidWorks.Interop.swconst Namespace](#) : swMessageBoxResult_e Enumeration

Message box results.

Syntax

Visual Basic (Declaration)

Public Enum swMessageBoxResult_e
Inherits System.Enum

Visual Basic (Usage) Copy Code

Dim instance As [swMessageBoxResult_e](#)

C#

public enum swMessageBoxResult_e : System.Enum

C++/CLI

public enum class swMessageBoxResult_e : public System.Enum

Members

Member	Description
swMbHitAbort	1 = Abort was clicked
swMbHitCancel	7 = Cancel was clicked
swMbHitIgnore	2 = Ignore was clicked
swMbHitNo	3 = No was clicked
swMbHitOk	4 = OK was clicked
swMbHitRetry	5 = Retry was clicked
swMbHitYes	6 = Yes was clicked

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMirrorComponentMirrorType_e (Type)

SOLIDWORKS API Enumerations

swMirrorComponentMirrorType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swMirrorComponentMirrorType_e Enumeration

Mirror positions for mirroring components.

Syntax

Visual Basic (Declaration)

```
Public Enum swMirrorComponentMirrorType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMirrorComponentMirrorType\_e
```

C#

```
public enum swMirrorComponentMirrorType_e : System.Enum
```

C++/CLI

```
public enum class swMirrorComponentMirrorType_e : public System.Enum
```

Members

Member	Description
swMirrorType_CenterOfBoundingBox	0 = Positions the mirror so that the center of a bounding box for the selected components is mirrored about the mirror plane
swMirrorType_CenterOfMass	1 = Positions the mirror so that the center of mass of the selected components is mirrored about the mirror plane
swMirrorType_ComponentOrigin	2 = Positions the mirror so that the component origins are mirrored about the mirror plane

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMirrorComponentNameModifier_e (Type)

SOLIDWORKS API Enumerations

swMirrorComponentNameModifier_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMirrorComponentNameModifier_e Enumeration

Prefix or suffix for newly mirrored components.

Syntax

Visual Basic (Declaration)

```
Public Enum swMirrorComponentNameModifier_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMirrorComponentNameModifier\_e
```

C#

```
public enum swMirrorComponentNameModifier_e : System.Enum
```

C++/CLI

```
public enum class swMirrorComponentNameModifier_e : public System.Enum
```

Members

Member	Description
swMirrorComponentName_Custom	2
swMirrorComponentName_Prefix	0
swMirrorComponentName_Suffix	1

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMirrorComponentOrientation2_e (Type)

SOLIDWORKS API Enumerations

swMirrorComponentOrientation2_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swMirrorComponentOrientation2_e Enumeration

Orientations for mirroring components.

Syntax

Visual Basic (Declaration)

```
Public Enum swMirrorComponentOrientation2_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMirrorComponentOrientation2\_e
```

C#

```
public enum swMirrorComponentOrientation2_e : System.Enum
```

C++/CLI

```
public enum class swMirrorComponentOrientation2_e : public System.Enum
```

Members

Member	Description
swOrientation_MirroredAndFlippedX_MirroredAndFlippedY	3
swOrientation_MirroredAndFlippedX_MirroredY	1
swOrientation_MirroredX_MirroredAndFlippedY	2
swOrientation_MirroredX_MirroredY	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMirrorComponentOrientation_e (Type)

SOLIDWORKS API Enumerations

swMirrorComponentOrientation_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMirrorComponentOrientation_e Enumeration

Orientation options for instanced mirror components.

Syntax

Visual Basic (Declaration)

```
Public Enum swMirrorComponentOrientation_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMirrorComponentOrientation\_e
```

C#

```
public enum swMirrorComponentOrientation_e : System.Enum
```

C++/CLI

```
public enum class swMirrorComponentOrientation_e : public System.Enum
```

Members

Member	Description
swMirrorComponentOrientation_None	1
swMirrorComponentOrientation_RotatePlaneX	3
swMirrorComponentOrientation_RotatePlaneXY	2
swMirrorComponentOrientation_RotatePlaneY	0

Remarks

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMirrorPartOptions_e (Type)

SOLIDWORKS API Enumerations

swMirrorPartOptions_e Enumeration

See Also

Send comments on this topic.

 SolidWorks.Interop.swconst Namespace : swMirrorPartOptions_e Enumeration

Options for creating a mirror part. [Bitmask](#).

 Syntax

Visual Basic (Declaration)

```
Public Enum swMirrorPartOptions_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swMirrorPartOptions\_e
```

C#

```
public enum swMirrorPartOptions_e : System.Enum
```

C++/CLI

```
public enum class swMirrorPartOptions_e : public System.Enum
```

 Members

Member	Description
swMirrorPartOptions.ImportAbsorbedSketchs	32 or 0x20
swMirrorPartOptions.ImportAxes	4 or 0x4
swMirrorPartOptions.ImportBodyMaterial	32768 or 0x8000
swMirrorPartOptions.ImportCoordinateSystem	256 or 0x100
swMirrorPartOptions.ImportCosmeticThreads	16 or 0x10
swMirrorPartOptions.ImportCustomProperties	128 or 0x80
swMirrorPartOptions.ImportCutListProperties	2048 or 0x800
swMirrorPartOptions.ImportDimXpertAnnotations	16384 or 0x4000
swMirrorPartOptions.ImportHoleWizardData	1024 or 0x400
swMirrorPartOptions.ImportIndProps	8192 or 0x2000 = Lets you edit the sheet-metal definition in the mirrored part, which updates the cut-list properties
swMirrorPartOptions.ImportModelDimensions	512 or 0x200
swMirrorPartOptions.ImportPartMaterial	65536 or 0x10000
swMirrorPartOptions.ImportPlanes	8 or 0x8
swMirrorPartOptions.ImportSMInfo	4096 or 0x1000 = Transfers the sheet-metal and flat-pattern information from the original part to the mirrored part; e.g., fixed face, grain direction, bendlines, and bounding box
swMirrorPartOptions.ImportSolids	1 or 0x1
swMirrorPartOptions.ImportSurfaces	2 or 0x2
swMirrorPartOptions.ImportUnabsorbedSketchs	64 or 0x40

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMirrorPlaneType_e (Type)

SOLIDWORKS API Enumerations

swMirrorPlaneType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMirrorPlaneType_e Enumeration

Types of mirror plane.

 Syntax

Visual Basic (Declaration)

```
Public Enum swMirrorPlaneType_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swMirrorPlaneType\_e
```

C#

```
public enum swMirrorPlaneType_e : System.Enum
```

C++/CLI

```
public enum class swMirrorPlaneType_e : public System.Enum
```

 Members

Member	Description
swMirrorPlaneType_Face	0
swMirrorPlaneType_Plane	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMirrorProfileOrAlignmentAxis_e (Type)

SOLIDWORKS API Enumerations

swMirrorProfileOrAlignmentAxis_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMirrorProfileOrAlignmentAxis_e Enumeration

Axis options for mirroring the profile of or aligning a sweep cut feature.

 Syntax

Visual Basic (Declaration)

```
Public Enum swMirrorProfileOrAlignmentAxis_e
    Inherits System.Enum
```

Visual Basic (Usage)  Copy Code

```
Dim instance As swMirrorProfileOrAlignmentAxis\_e
```

C#

```
public enum swMirrorProfileOrAlignmentAxis_e : System.Enum
```

C++/CLI

```
public enum class swMirrorProfileOrAlignmentAxis_e : public System.Enum
```

 Members

Member	Description
swMirrorProfileOrAlignmentAxis_Horizontal	1
swMirrorProfileOrAlignmentAxis_Vertical	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMirrorViewPositions_e (Type)

SOLIDWORKS API Enumerations

swMirrorViewPositions_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swMirrorViewPositions_e Enumeration

Mirror view orientations.

 Syntax

Visual Basic (Declaration)

Public Enum swMirrorViewPositions_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swMirrorViewPositions_e](#)

C#

public enum swMirrorViewPositions_e : System.Enum

C++/CLI

public enum class swMirrorViewPositions_e : public System.Enum

 Members

Member	Description
swMirrorViewPosition_Horizontal	0
swMirrorViewPosition_NotDefined	-1
swMirrorViewPosition_Vertical	1

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swModelRebuildStatus_e (Type)

SOLIDWORKS API Enumerations

swModelRebuildStatus_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swModelRebuildStatus_e Enumeration

Rebuild status of model. [Bitmask](#).

Syntax

Visual Basic (Declaration)

Public Enum swModelRebuildStatus_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swModelRebuildStatus_e](#)

C#

public enum swModelRebuildStatus_e : System.Enum

C++/CLI

public enum class swModelRebuildStatus_e : public System.Enum

Members

Member	Description
swModelRebuildStatus_FrozenFeatureNeedsRebuild	2
swModelRebuildStatus_FullyRebuilt	0 or FALSE
swModelRebuildStatus_NonFrozenFeatureNeedsRebuild	1 or TRUE

See Also

[SolidWorks.Interop.swconst Namespace](#)

swModelRouteType_e (Type)

SOLIDWORKS API Enumerations

swModelRouteType_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swModelRouteType_e Enumeration

Route types for connection points.

 Syntax

Visual Basic (Declaration)

Public Enum swModelRouteType_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swModelRouteType_e](#)

C#

public enum swModelRouteType_e : System.Enum

C++/CLI

public enum class swModelRouteType_e : public System.Enum

 Members

Member	Description
swModelRouteType_AnyRouteType	7 = Any
swModelRouteType_Electrical	6 = Electrical
swModelRouteType_FabricatedPipe	2 = Fabricated pipe
swModelRouteType_FormedPipe	3 = Formed pipe
swModelRouteType_Harness	0 = Harness
swModelRouteType_MixedRouteType	8 = Mixed
swModelRouteType_Trunking	4 = Trunking
swModelRouteType_Tube	1 = Tube
swModelRouteType_UnknownRouteType	5 = Unknown

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swModifyTableNotifyReason_e (Type)

SOLIDWORKS API Enumerations

swModifyTableNotifyReason_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swModifyTableNotifyReason_e Enumeration

Notification reason codes for modifying tables.

Syntax

Visual Basic (Declaration)

```
Public Enum swModifyTableNotifyReason_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swModifyTableNotifyReason\_e
```

C#

```
public enum swModifyTableNotifyReason_e : System.Enum
```

C++/CLI

```
public enum class swModifyTableNotifyReason_e : public System.Enum
```

Members

Member	Description
swModifyTableNotifyReason_CellDataModify	7
swModifyTableNotifyReason_CellMerge	9
swModifyTableNotifyReason_CellUnMerge	10
swModifyTableNotifyReason_ColumnDeletion	6
swModifyTableNotifyReason_ColumnInsertionLeft	0
swModifyTableNotifyReason_ColumnInsertionRight	1
swModifyTableNotifyReason_ColumnPropertyModify	8
swModifyTableNotifyReason_ColumnRelocation	4
swModifyTableNotifyReason_CustomPropertyModify	12
swModifyTableNotifyReason_EditMultiProp	11
swModifyTableNotifyReason_RowInsertionAbove	2
swModifyTableNotifyReason_RowInsertionBelow	3
swModifyTableNotifyReason_RowRelocation	5
swModifyTableNotifyReason_TableMerge	17
swModifyTableNotifyReason_TableSplitHorizontallyAbove	15
swModifyTableNotifyReason_TableSplitHorizontallyBelow	16
swModifyTableNotifyReason_TableSplitVerticallyLeft	13
swModifyTableNotifyReason_TableSplitVerticallyRight	14

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMomentsOfInertiaReferenceFrame_e (Type)

SOLIDWORKS API Enumerations

swMomentsOfInertiaReferenceFrame_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMomentsOfInertiaReferenceFrame_e Enumeration

Reference frames for moments of inertia mass properties.

Syntax

Visual Basic (Declaration)

```
Public Enum swMomentsOfInertiaReferenceFrame_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMomentsOfInertiaReferenceFrame\_e
```

C#

```
public enum swMomentsOfInertiaReferenceFrame_e : System.Enum
```

C++/CLI

```
public enum class swMomentsOfInertiaReferenceFrame_e : public System.Enum
```

Members

Member	Description
swMomentsOfInertiaReferenceFrame_CenterOfMass	0
swMomentsOfInertiaReferenceFrame_DefaultCoordinateSystem	1
swMomentsOfInertiaReferenceFrame_UserCoordinateSystem	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMotionContactFrictionType_e (Type)

SOLIDWORKS API Enumerations

swMotionContactFrictionType_e Enumeration

[See Also](#)

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMotionContactFrictionType_e Enumeration

Motion Study contact friction types.

Syntax

Visual Basic (Declaration)

```
Public Enum swMotionContactFrictionType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMotionContactFrictionType\_e
```

C#

```
public enum swMotionContactFrictionType_e : System.Enum
```

C++/CLI

```
public enum class swMotionContactFrictionType_e : public System.Enum
```

Members

Member	Description
swMotionContactFrictionDynamic	2
swMotionContactFrictionFull	1
swMotionContactFrictionOff	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMotionMat_e (Type)

SOLIDWORKS API Enumerations

swMotionMat_e Enumeration

See Also

[Send comments on this topic.](#)

 

SolidWorks.Interop.swconst Namespace : swMotionMat_e Enumeration

Motion Study materials.

 Syntax

Visual Basic (Declaration)

Public Enum swMotionMat_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swMotionMat_e](#)

C#

public enum swMotionMat_e : System.Enum

C++/CLI

public enum class swMotionMat_e : public System.Enum

 Members

Member	Description
swMotionMatAcrylic	1001
swMotionMatAluminumDry	1002
swMotionMatAluminumGreasy	1003
swMotionMatNone	1000
swMotionMatNylon	1004
swMotionMatRubberDry	1005
swMotionMatRubberGreasy	1006
swMotionMatSteelDry	1007
swMotionMatSteelGreasy	1008

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMotionPlotAxisComponent_e (Type)

SOLIDWORKS API Enumerations

swMotionPlotAxisComponent_e Enumeration

See Also

 

SolidWorks.Interop.swconst Namespace : swMotionPlotAxisComponent_e Enumeration

Types of motion study components.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMotionPlotAxisComponent_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMotionPlotAxisComponent\_e
```

C#

```
public enum swMotionPlotAxisComponent_e : System.Enum
```

C++/CLI

```
public enum class swMotionPlotAxisComponent_e : public System.Enum
```

Members

Member	Description
swMotionPlotAxisComponent_BRYANT_ANGLE1	14
swMotionPlotAxisComponent_BRYANT_ANGLE2	15
swMotionPlotAxisComponent_BRYANT_ANGLE3	16
swMotionPlotAxisComponent_EULER_PHI	7
swMotionPlotAxisComponent_EULER_PSI	5
swMotionPlotAxisComponent_EULER_THETA	6
swMotionPlotAxisComponent_MAGNITUDE	3
swMotionPlotAxisComponent_PITCH	9
swMotionPlotAxisComponent_RADIAL_MAGNITUDE	4
swMotionPlotAxisComponent_RODRIGUEZ_PARAM1	11
swMotionPlotAxisComponent_RODRIGUEZ_PARAM2	12
swMotionPlotAxisComponent_RODRIGUEZ_PARAM3	13
swMotionPlotAxisComponent_ROLL	10
swMotionPlotAxisComponent_X	0
swMotionPlotAxisComponent_Y	1
swMotionPlotAxisComponent_YAW	8
swMotionPlotAxisComponent_Z	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMotionPlotAxisType_e (Type)

SOLIDWORKS API Enumerations

swMotionPlotAxisType_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swMotionPlotAxisType_e Enumeration

Types of motion study plot axes.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMotionPlotAxisType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMotionPlotAxisType\_e
```

C#

```
public enum swMotionPlotAxisType_e : System.Enum
```

C++/CLI

```
public enum class swMotionPlotAxisType_e : public System.Enum
```

Members

Member	Description
swMotionPlotAxisType_ANGULAR_ACCEL	11
swMotionPlotAxisType_ANGULAR_DISP	9
swMotionPlotAxisType_ANGULAR_KINETIC_ENERGY	27
swMotionPlotAxisType_ANGULAR_MOMENTUM	13
swMotionPlotAxisType_ANGULAR_VELOCITY	10
swMotionPlotAxisType_BRYANT_ANGLE	19
swMotionPlotAxisType_CM_ACCELERATION	5
swMotionPlotAxisType_CM_POSITION	2
swMotionPlotAxisType_CM_VELOCITY	4
swMotionPlotAxisType_CONTACT_FORCE	31
swMotionPlotAxisType_EULER_ANGLES	17
swMotionPlotAxisType_FRICTION_FORCE	23
swMotionPlotAxisType_FRICTION_MOMENT	24
swMotionPlotAxisType_KINETIC_ENERGY	25
swMotionPlotAxisType_MOTION_APPLIED_FORCE	21
swMotionPlotAxisType_MOTION_APPLIED_TORQUE	22
swMotionPlotAxisType_PITCH	18
swMotionPlotAxisType_POTENTIAL_ENERGY_DELTA	28
swMotionPlotAxisType_POWER_CONSUMPTION	29
swMotionPlotAxisType_PRESSURE_ANGLE	3
swMotionPlotAxisType_PROJ_ANGLES	16
swMotionPlotAxisType_REACTION_FORCE	14
swMotionPlotAxisType_REACTION_TORQUE	15
swMotionPlotAxisType_REFLECTED_INERTIA	33
swMotionPlotAxisType_REFLECTED_MASS	32
swMotionPlotAxisType_RODRIGUEZ_PARAM	20
swMotionPlotAxisType_TRACE_PATH	30
swMotionPlotAxisType_TRANS_ACCELERATION	8
swMotionPlotAxisType_TRANS_DISP	6
swMotionPlotAxisType_TRANS_KINETIC_ENERGY	26
swMotionPlotAxisType_TRANS_MOMENTUM	12
swMotionPlotAxisType_TRANS_VELOCITY	7
swMotionPlotAxisType_XAXISFRAME	1
swMotionPlotAxisType_XAXISTIME	0

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMouseDownMode_e (Type)

SOLIDWORKS API Enumerations

swMouseDownMode_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swMouseDownMode_e Enumeration

Current command states.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMouseDownMode_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMouseDownMode\_e
```

C#

```
public enum swMouseDownMode_e : System.Enum
```

C++/CLI

```
public enum class swMouseDownMode_e : public System.Enum
```

Members

Member	Description
swAssemblySmartMates	4 = Assembly component smartmate mode
swInsertDimension	9 = Insert dimension mode
swRollView	10 = Roll view mode
swRotateAssemblyComponentAboutAxis	3 = Assembly component rotate about axis mode
swRotateAssemblyComponentAboutCenter	2 = Assembly component rotate mode
swRotateView	5 = View rotate mode
swTranslateAssemblyComponent	1 = Assembly component move mode
swTranslateView	6 = View translate mode
swTurnView	11 = Turn view mode
swZoomToAreaOfView	8 = View zoom-to mode
swZoomView	7 = View zoom mode

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMouseNotify_e (Type)

SolidWorks.Interop.swconst Namespace : swMouseNotify_e Enumeration

Mouse notifications.

Syntax

Visual Basic (Declaration)

```
Public Enum swMouseNotify_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMouseNotify_e
```

C#

```
public enum swMouseNotify_e : System.Enum
```

C++/CLI

```
public enum class swMouseNotify_e : public System.Enum
```

Members

Member	Description
swMouseLBtnDbtClkNotify	9 = MouseLBtnDbtClkNotify
swMouseLBtnDownNotify	3 = MouseLBtnDownNotify
swMouseLBtnUpNotify	4 = MouseLBtnUpNotify
swMouseMBtnDbtClkNotify	11 = MouseMBtnDbtClkNotify
swMouseMBtnDownNotify	7 = MouseMBtnDownNotify
swMouseMBtnUpNotify	8 = MouseMBtnUpNotify
swMouseMoveNotify	2 = MouseMoveNotify
swMouseNotify	1 = MouseNotify
swMouseRBtnDbtClkNotify	10 = MouseRBtnDbtClkNotify
swMouseRBtnDownNotify	5 = MouseRBtnDownNotify
swMouseRBtnUpNotify	6 = MouseRBtnUpNotify
swMouseSelectNotify	12 = MouseSelectNotify

Remarks

To receive notifications, a DLL application must register for the notifications by object type. This registration must be done for each instance of a particular object.

For example, in the file in the Visual C++ 6.0 wizard-generated add-in that supports mouse events (e.g., Mouse.h), include:

```
DECLARE_REGISTRY_RESOURCEID( IDR_MOUSE )

BEGIN_SINK_MAP(CMouse)

    SINK_ENTRY_EX( ID_MOUSE_EVENTS, DIID_DMouseEvents, swMouseMoveNotify, MouseMoveNotify )
    SINK_ENTRY_EX( ID_MOUSE_EVENTS, DIID_DMouseEvents, swMouseSelectNotify, MouseSelectNotify )
    SINK_ENTRY_EX( ID_MOUSE_EVENTS, DIID_DMouseEvents, swMouseLBtnDownNotify, MouseLBtnDownNotify )

END_SINK_MAP( )
```

If developing a C++ application, use these enumerators to [register for notifications](#) for the [IMouse](#) events.

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMoveableDatumDirection_e (Type)

SOLIDWORKS API Enumerations

swMoveableDatumDirection_e Enumeration

See Also

[Send comments on this topic.](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMoveableDatumDirection_e Enumeration

Directions for moveable datum target symbols.

 Syntax

Visual Basic (Declaration)

Public Enum swMoveableDatumDirection_e
Inherits System.Enum

Visual Basic (Usage)  Copy Code

Dim instance As [swMoveableDatumDirection_e](#)

C#

public enum swMoveableDatumDirection_e : System.Enum

C++/CLI

public enum class swMoveableDatumDirection_e : public System.Enum

 Members

Member	Description
swMoveableDatumDirectionBySelection	5
swMoveableDatumDirectionDown	3
swMoveableDatumDirectionFreeDrag	4
swMoveableDatumDirectionLeft	0
swMoveableDatumDirectionRight	1
swMoveableDatumDirectionUp	2

 See Also

[SolidWorks.Interop.swconst Namespace](#)

swMoveableDatumStyle_e (Type)

SOLIDWORKS API Enumerations

swMoveableDatumStyle_e Enumeration

See Also

[SolidWorks.Interop.swconst Namespace](#) : swMoveableDatumStyle_e Enumeration

Moveable datum target symbol styles.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMoveableDatumStyle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMoveableDatumStyle\_e
```

C#

```
public enum swMoveableDatumStyle_e : System.Enum
```

C++/CLI

```
public enum class swMoveableDatumStyle_e : public System.Enum
```

Members

Member	Description
swMoveableDatumStyle_Horizontal	1
swMoveableDatumStyle_NotMoveable	0
swMoveableDatumStyle_Rotational	2

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMoveCopyBodyFeatureTransformType_e (Type)

SOLIDWORKS API Enumerations

swMoveCopyBodyFeatureTransformType_e Enumeration

[Send comments on this topic.](#)

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMoveCopyBodyFeatureTransformType_e Enumeration

Move/copy body transform types.

Syntax

Visual Basic (Declaration)

Public Enum swMoveCopyBodyFeatureTransformType_e
Inherits System.Enum

Visual Basic (Usage)

 Copy Code

Dim instance As [swMoveCopyBodyFeatureTransformType_e](#)

C#

public enum swMoveCopyBodyFeatureTransformType_e : System.Enum

C++/CLI

public enum class swMoveCopyBodyFeatureTransformType_e : public System.Enum

Members

Member	Description
swTransformType_None	0 = No transform applied; all transform arguments ignored
swTransformType_Rotation	2
swTransformType_Translation	1

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMoveCopyError_e (Type)

SOLIDWORKS API Enumerations

swMoveCopyError_e Enumeration

[See Also](#)

 

[SolidWorks.Interop.swconst Namespace](#) : swMoveCopyError_e Enumeration

Move/copy errors.

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

```
Public Enum swMoveCopyError_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swMoveCopyError\_e
```

C#

```
public enum swMoveCopyError_e : System.Enum
```

C++/CLI

```
public enum class swMoveCopyError_e : public System.Enum
```

Members

Member	Description
swMoveCopyErrorFail	2 = Failed to create destination directories or copy operation failed possibly because you do not have proper permissions
swMoveCopyErrorNone	0 = Successful
swMoveCopyErrorSourceDoesNotExist	1 = Source file does not exist

See Also

[SolidWorks.Interop.swconst Namespace](#)

swMoveCopyOptions_e (Type)

SOLIDWORKS API Enumerations

swMoveCopyOptions_e Enumeration

See Also

 

[SolidWorks.Interop.swconst Namespace](#) : swMoveCopyOptions_e Enumeration

Move/copy options. [Bitmask](#).

[Send comments on this topic.](#)

Syntax

Visual Basic (Declaration)

Public Enum swMoveCopyOptions_e
Inherits System.Enum

Visual Basic (Usage)

Dim instance As [swMoveCopyOptions_e](#)

C#

public enum swMoveCopyOptions_e : System.Enum

C++/CLI

public enum class swMoveCopyOptions_e : public System.Enum

Members

Member	Description
swMoveCopyOptionsCreateNewFolder	2 or 0x2
swMoveCopyOptionsOverwriteExistingDocs	1 or 0x1

See Also

[SolidWorks.Interop.swconst Namespace](#)