

SOLIDWORKS DimXpert API (.NET) — Examples

(6/7): Get_DimXpert_Tolerances5_Example_VB- Get_DimXpert_Tolerance6_Example_VB.NET

SOLIDWORKS API Documentation (converted from CHM)

Get DimXpert Tolerance5 Example (VBA)

This example shows how to build a part and get attributes for the DimXpert Concentricity geometric tolerance annotation.

```
' -----  
' Preconditions:  
' 1. Open public_documents\samples\tutorial\api\cover_with_dimensions.sldprt.  
' 2. Open the DimXpert toolbar from View > Toolbars.  
'  
' Create concentricity geometric tolerance:  
' 1. Click Datum of the DimXpert tool bar.  
' 2. Click Boss1 (front extrusion).  
' 3. Click to place the annotation.  
' 4. Click the green check mark to accept Datum A.  
' 5. Click Geometric Tolerance of the DimXpert toolbar.  
' 6. In the Geometric Tolerance Properties dialog:  
' a. Select Concentricity in the Symbol dropdown.  
' b. Click Tolerance 1.  
' c. Click Diameter on the toolbar at the top of the dialog.  
' d. Type A in Primary.  
' 7. Click the inside face of Simple Hole2.  
' 8. Click to place the annotation.  
' 9. Click OK to close the Geometric Tolerance Properties dialog.  
' 10. In the DimXpertManager tab of the Management Panel, expand Simple Hole2.  
' 11. Observe the following Dimxpert annotation: Concentricity1  
' 12. Ensure that the SOLIDWORKS DimXpert type library is loaded  
' in Tools > References.  
' 13. Ensure that the Microsoft Scripting Runtime library is loaded  
' in Tools > References.  
'  
' Postconditions:  
' 1. Writes the output ton c:\temp\dimXpertInfo.txt.  
' 2. Inspect the Immediate window.  
'  
' NOTE: Because the part is used elsewhere, do not save changes.  
' -----
```

Option Explicit

Dim strs As New Collection

Dim dimXpertPart As SwDimXpert.dimXpertPart

Sub Main()

Dim swapp As SldWorks.SldWorks

```

    Set swapp = Application.SldWorks
Dim swModelDoc As SldWorks.ModelDoc2
Set swModelDoc = swapp.ActiveDoc
If swModelDoc Is Nothing Then
    Exit Sub
End If
Dim f As New FileSystemObject
Dim textStr As TextStream
Set textStr = f.CreateTextFile("C:\temp\dimXpertInfo.txt", True)
If textStr Is Nothing Then
    Debug.Print "Error creating temp file."
    Exit Sub
End If

Call log("Starting DimXpert log...", textStr)
Call retrieve_info_text(swapp, textStr)
textStr.Close
End Sub

Private Sub log(text As String, textStr As TextStream)
    Debug.Print text
    textStr.WriteLine (text)
End Sub

Private Sub retrieve_info_text(swapp As SldWorks.SldWorks, textStr As TextStream)
    Dim dimXpertMgr As SldWorks.DimXpertManager

    Set dimXpertMgr =
swapp.IActiveDoc2.Extension.DimXpertManager(swapp.IActiveDoc2.IGetActiveConfiguration().Name,
True)
    Call log("Model: " & swapp.IActiveDoc2.GetPathName, textStr)
    Dim dimXpertPartObj As dimXpertPart
    Set dimXpertPartObj = dimXpertMgr.dimXpertPart

    Set dimXpertPart = dimXpertPartObj

    Dim vAnnotations As Variant

    vAnnotations = dimXpertPart.GetAnnotations()

    Call log("-----", textStr)
    Call log("Annotations...", textStr)
    Call log("-----", textStr)

    Dim annotationTemp As DimXpertAnnotation

```

```

Dim annotationIndex As Long
For annotationIndex = 0 To UBound(vAnnotations)
    Set annotationTemp = vAnnotations(annotationIndex)

    Dim AnnotationDataText As Collection

    Set AnnotationDataText = AnnotationData(annotationTemp)
    Dim annotationTextIndex As Long
    For annotationTextIndex = 1 To AnnotationDataText.Count
        Call log(AnnotationDataText(annotationTextIndex), textStr)
    Next
Next

```

End Sub

```

Public Function AnnotationData(annotation As DimXpertAnnotation) As Collection
    Dim annoType As Long

    'general info
    Call GeneralInfo(annotation)
    annoType = annotation.Type
    If annoType = swDimXpertDatum Then
        Call DatumData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Position Then
        Call PositionData(annotation)

    ElseIf annoType = swDimXpertGeoTol_CompositePosition Then
        Call CompositePositionData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Symmetry Then
        Call SymmetryData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Concentricity Then
        Call ConcentricityData(annotation)

    ElseIf annoType = swDimXpertGeoTol_LineProfile Then
        Call LineProfileData(annotation)

    ElseIf annoType = swDimXpertGeoTol_CompositeLineProfile Then
        Call CompositeLineProfileData(annotation)

    ElseIf annoType = swDimXpertGeoTol_SurfaceProfile Then
        Call SurfaceProfileData(annotation)

```

```

ElseIf annoType = swDimXpertGeoTol_CompositeSurfaceProfile Then
    Call CompositeSurfaceProfileData(annotation)

ElseIf annoType = swDimXpertGeoTol_Angularity Or annoType = swDimXpertGeoTol_Parallelism
Or annoType = swDimXpertGeoTol_Perpendicularity Then
    Call OrientationData(annotation)

ElseIf annoType = swDimXpertGeoTol_TotalRunout Then
    Call TotalRunoutData(annotation)

ElseIf annoType = swDimXpertGeoTol_CircularRunout Then
    Call CircularRunoutData(annotation)

ElseIf annoType = swDimXpertGeoTol_Flatness Then
    Call FlatnessData(annotation)

ElseIf annoType = swDimXpertGeoTol_Circularity Then
    Call CircularityData(annotation)

ElseIf annoType = swDimXpertGeoTol_Cylindricity Then
    Call CylindricityData(annotation)

ElseIf annoType = swDimXpertGeoTol_Straightness Then
    Call StraightnessData(annotation)
ElseIf annoType = swDimXpertGeoTol_Tangency Then
    Call TangencyData(annotation)
Else ' any of the dimension tolerance types
    Call DimensionToleranceData(annotation)

End If

Set AnnotationData = strs
End Function
Private Sub Clear(strs As Collection)
    Dim n As Long
    strs.Remove (strs.Count)
    If Not strs.Count = 0 Then
        Call Clear(strs)
    End If
End Sub
Private Sub GeneralInfo(annotation As DimXpertAnnotation)
    Dim annoType As String
    Dim modelObj As Object
    Dim modelFeature As SldWorks.feature

```

```

If Not strs.Count = 0 Then
    Call Clear(strs)
End If

strs.Add ("")
strs.Add ("Name: " + annotation.Name)

annoType = annotationTypeNameFromObject(annotation)
strs.Add ("Type: " + annoType)
strs.Add ("Display Entity: " + DisplayEntity(annotation))

Set modelObj = annotation.GetModelFeature
Set modelFeature = modelObj
If Not (modelFeature Is Nothing) Then
    strs.Add ("ModelFeature: " + modelFeature.Name + " (" + modelFeature.GetTypeName2() +
    ")")
End If
End Sub

Private Sub DatumData(annotation As DimXpertDatum)
    ' the datum letter
    strs.Add ("")
    strs.Add ("Datum Letter: " + annotation.Identifier)

End Sub

Private Sub PositionData(annotation As DimXpertPositionTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim boolstatus As Boolean

    strs.Add ("")
    strs.Add ("Position Tolerance Compartment:")

    ' the shape of the tolerance zone
    strs.Add (" Zone Type: " + PositionZoneType(annotation.zoneType))

    ' the zone vector if the tolerance zone is planar
    If annotation.zoneType = swDimXpertPositionZoneType_PlanarPosition Then
        boolstatus = annotation.GetPlanarZoneVector(I, J, K)
        strs.Add (" Direction: " + FormatVector(I, J, K))
    End If

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

    ' the material condition modifier applied to feature

```

```
strs.Add (" Modifier: " + mcmStr(annotation.modifier))
```

```
' the projected tolerance zone when specified
```

```
boolstatus = annotation.GetProjectedZone(enabled, value)
```

```
Call FormatProjectedZone(enabled, value)
```

```
' the datum reference frame
```

```
Call DatumsStr(annotation)
```

```
End Sub
```

```
Private Sub CompositePositionData(annotation As DimXpertCompositePositionTolerance)
```

```
Dim I As Double, J As Double, K As Double
```

```
Dim enabled As Boolean, value As Double
```

```
Dim boolstatus As Boolean
```

```
strs.Add ("")
```

```
strs.Add ("Composite Position Tolerance Compartment")
```

```
' the shape of the tolerance zone
```

```
strs.Add (" Zone Type: " + PositionZoneType(annotation.zoneType))
```

```
' the zone vector when the zone is planar
```

```
If annotation.zoneType = swDimXpertPositionZoneType_PlanarPosition Then
```

```
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)
```

```
    strs.Add (" Direction: " + FormatVector(I, J, K))
```

```
End If
```

```
' the tolerance value
```

```
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
' the material condition modifier
```

```
strs.Add (" Modifier: " + mcmStr(annotation.modifier))
```

```
' the projected tolerance zone when specified
```

```
boolstatus = annotation.GetProjectedZone(enabled, value)
```

```
Call FormatProjectedZone(enabled, value)
```

```
' the datum reference frame for the pattern location
```

```
Call DatumsStr(annotation)
```

```
' the datum reference frame for the feature to feature location
```

```
strs.Add ("Composite datums:")
```

```
strs.Add (" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
```

```
strs.Add (" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True", "False"))
```

```
    strs.Add (" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True", "False"))
```

```
End Sub
```

```
Private Sub SymmetryData(annotation As DimXpertSymmetryTolerance)
```

```
    Dim I As Double, J As Double, K As Double
```

```
    Dim boolstatus As Boolean
```

```
    strs.Add ("")
```

```
    strs.Add ("Symmetry Tolerance Compartment")
```

```
    ' the tolerance value
```

```
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
    ' the material condition modifier applied to feature
```

```
    strs.Add (" Modifier: " + mcmStr(annotation.modifier))
```

```
    ' the datum reference frame
```

```
    strs.Add ("")
```

```
    Call DatumsStr(annotation)
```

```
    ' the direction of the planar zone
```

```
    strs.Add ("")
```

```
    boolstatus = annotation.GetZoneDirection(I, J, K)
```

```
    strs.Add ("Planar Zone Direction: " + FormatVector(I, J, K))
```

```
End Sub
```

```
Private Sub ConcentricityData(annotation As DimXpertConcentricityTolerance)
```

```
    strs.Add ("")
```

```
    strs.Add ("Concentricity Tolerance Compartment")
```

```
    ' the tolerance value
```

```
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
    ' the material condition modifier applied to feature
```

```
    strs.Add (" Modifier: " + mcmStr(annotation.modifier))
```

```
    ' the datum reference frame
```

```
    Call DatumsStr(annotation)
```

```
End Sub
```

```
Private Sub TotalRunoutData(annotation As DimXpertTolerance)
```

```
    strs.Add ("")
```

```
    strs.Add ("Total Runout Tolerance Compartment")
```

```
    ' the tolerance value
```

```
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
' the datum reference frame  
Call DatumsStr(annotation)
```

End Sub

```
Private Sub CircularRunoutData(annotation As DimXpertTolerance)  
    strs.Add ("")  
    strs.Add ("Circular Runout Tolerance Compartment")  
  
    ' the tolerance value  
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
' the datum reference frame  
Call DatumsStr(annotation)
```

End Sub

```
Private Sub LineProfileData(annotation As DimXpertLineProfileTolerance)  
    Dim I As Double, J As Double, K As Double  
    Dim boolstatus As Boolean  
  
    strs.Add ("")  
    strs.Add ("Line Profile Tolerance Compartment")  
  
    ' the tolerance value  
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))  
  
    ' the outer (outside material) tolerance value  
    strs.Add (" Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))  
  
    ' the vector normal to the profile zones  
    strs.Add ("")  
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)  
    strs.Add ("Planar Zone Vector: " + FormatVector(I, J, K))  
  
    ' the datum reference frame  
    Call DatumsStr(annotation)
```

End Sub

```
Private Sub CompositeLineProfileData(annotation As DimXpertCompositeLineProfileTolerance)  
  
    strs.Add ("")  
    strs.Add ("Composite Line Profile Tolerance Compartment")  
  
    ' the tolerance value  
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```

' the outer (outside material) tolerance value
strs.Add (" Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))

' the vector normal to the profile zones
strs.Add ("")
boolstatus = annotation.GetPlanarZoneVector(I, J, K)
strs.Add ("Planar Zone Vector: " + FormatVector(I, J, K))

' the datum reference frame
Call DatumsStr(annotation)

' the datum reference frame for the orientation and form
strs.Add ("Composite Datums:")
strs.Add (" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
strs.Add (" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True", "False"))
strs.Add (" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True", "False"))

```

End Sub

```
Private Sub SurfaceProfileData(annotation As DimXpertSurfaceProfileTolerance)
```

```

strs.Add ("")
strs.Add ("Surface Profile Tolerance Compartment")

' the tolerance value
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

' the outer (outside material) tolerance value
strs.Add (" Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))

' the datum reference frame
Call DatumsStr(annotation)

```

End Sub

```
Private Sub CompositeSurfaceProfileData(annotation As
DimXpertCompositeSurfaceProfileTolerance)
```

```

strs.Add ("")
strs.Add ("Composite Surface Profile Tolerance Compartment")

' the tolerance value
strs.Add (" Tolerance Upper Tier: " + FormatDouble(annotation.Tolerance))

' the outer tolerance value

```

```

    strs.Add (" Outer Tolerance Upper Tier: " +
FormatDouble(annotation.OuterToleranceValue))

' the datum reference frame for the location
Call DatumsStr(annotation)

' the datum reference frame for the orientation and form
strs.Add ("Composite Datums:")
strs.Add (" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
strs.Add (" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True", "False"))
strs.Add (" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True", "False"))
End Sub
Private Sub OrientationData(annotation As DimXpertOrientationTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim annoType As Long
    Dim boolstatus As Boolean
    annoType = annotation.Type
    ' the type or orientation tolerance
    If annoType = swDimXpertGeoTol_Perpendicularity Then
        strs.Add ("Orientation Type: Perpendicularity")
    ElseIf annoType = swDimXpertGeoTol_Parallelism Then
        strs.Add ("Orientation Type: Parallelism")
    ElseIf annoType = swDimXpertGeoTol_Angularity Then
        strs.Add ("Orientation Type: Angularity")
    End If

    strs.Add ("")
    strs.Add ("Orientation Tolerance Compartment:")

    ' the shape of the tolerance zone
    Select Case annotation.zoneType
    Case swDimXpertOrientationZoneType_Cylindrical
        strs.Add (" Zone Type: Cylindrical")
    Case swDimXpertOrientationZoneType_Planar
        strs.Add (" Zone Type: Planar")
        boolstatus = annotation.GetPlanarZoneVector(I, J, K)
        strs.Add ("Planar Zone Vector: " + FormatVector(I, J, K))
    End Select

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

    'material condition modifier applied to feature
    strs.Add (" Modifier: " + mcmStr(annotation.modifier))

```

```

' the projected tolerance zone when specified
boolstatus = annotation.GetProjectedZone(enabled, value)
Call FormatProjectedZone(enabled, value)

' is tangent plane
strs.Add (" IsTangentPlane: " + IIf(annotation.IsTangentPlane, "True", "False"))

' the datum reference frame
Call DatumsStr(annotation)

```

End Sub

```

Private Sub FlatnessData(annotation As DimXpertFlatnessTolerance)
    Dim enabled As Boolean
    Dim length As Double, width As Double
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean

    strs.Add ("")
    strs.Add ("Flatness Tolerance Compartment:")

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

    ' the per unit area data
    boolstatus = annotation.GetPerUnitArea(enabled, length, width, I, J, K)
    strs.Add (" Per Unit Area: " + IIf(enabled, "True", "False"))
    If enabled Then
        strs.Add (" Per Unit Length: " + FormatDouble(length))
        strs.Add (" Per Unit Width: " + FormatDouble(width))
        strs.Add (" Per Unit Direction: " + FormatVector(I, J, K))
    End If

```

End Sub

```

Private Sub CircularityData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Circularity Tolerance Compartment")

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

```

End Sub

```

Private Sub CylindricityData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Cylindricity Tolerance Compartment")

```

```

' the tolerance value
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

End Sub

Private Sub StraightnessData(annotation As DimXpertStraightnessTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean
    Dim dist As Double
    Dim boolstatus As Boolean
    'tolerance compartment info
    strs.Add ("")
    strs.Add ("Straightness Tolerance Compartment")

    'type or shape of the tolerance zone
    Select Case annotation.zoneType
    Case swDimXpertStraightnessZoneType_Cylindrical
        strs.Add (" Zone Type: Cylindrical")
    Case swDimXpertStraightnessZoneType_PlanarMedian
        strs.Add (" Zone Type: Planar Median")
    Case swDimXpertStraightnessZoneType_Surface
        strs.Add (" Zone Type: Surface Straightness")
        boolstatus = annotation.GetPlanarZoneVector(I, J, K)
        strs.Add (" Zone Vector: " + FormatVector(I, J, K))
    End Select

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

    'per unit length
    boolstatus = annotation.GetPerUnitLength(enabled, dist)
    strs.Add (" Per Unit Length: " + IIf(enabled, "True", "False"))
    If enabled Then
        strs.Add (" Per Unit Length Distance: " + FormatDouble(dist))
    End If

    ' the material condition modifier
    strs.Add (" Modifier: " + mcmStr(annotation.modifier))
End Sub

Private Sub ProfileData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the datum reference frame

```

```

    Call DatumsStr(annotation)
End Sub
Private Sub SurfaceFinishData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Surface Finish Tolerance Compartment")
    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub
Private Sub TangencyData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Tangency Tolerance Compartment")
    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub
Private Sub DimensionToleranceData(annotation As DimXpertDimensionTolerance)
    Dim isAngleType As Boolean
    Dim annoType As Long
    Dim upper As Double, lower As Double
    Dim plus As Double, minus As Double
    Dim boolstatus As Boolean
    annoType = annotation.Type

    isAngleType = False

    strs.Add ("")
    strs.Add ("Dimension Tolerance Compartment")
    If annoType = swDimXpertDimTol_DistanceBetween Then
        Dim distancebetween As DimXpertDistanceBetweenDimTol
        Set distancebetween = annotation
        Call DistanceBetweenData(distancebetween)
    ElseIf annoType = swDimXpertDimTol_CompositeDistanceBetween Then
        Dim compdistancebetween As DimXpertCompositeDistanceBetweenDimTol
        Set compdistancebetween = annotation
        Call CompositeDistanceBetweenData(compdistancebetween)

    ElseIf annoType = swDimXpertDimTol_CounterBore Then
        Dim counterBore As IDimXpertCounterBoreDimTol
        Set counterBore = annotation
        If counterBore.ReferenceFeature Is Nothing Then
            strs.Add ("Reference Feature: NULL")
        Else
            strs.Add ("Reference Feature: " + counterBore.ReferenceFeature.Name)
        End If

    ElseIf annoType = swDimXpertDimTol_Depth Then

```

```

Dim depth As IDimXpertDepthDimTol
Set depth = annotation
If depth.ReferenceFeature Is Nothing Then
    str.Add ("Reference Feature: NULL")
Else
    str.Add ("Reference Feature: " + depth.ReferenceFeature.Name)
End If

ElseIf annoType = swDimXpertDimTol_CounterSinkDiameter Then
    Dim countersink As IDimXpertCounterSinkDiameterDimTol
    Set countersink = annotation
    If countersink.ReferenceFeature Is Nothing Then
        str.Add ("Reference Feature: NULL")
    Else
        str.Add ("Reference Feature: " + countersink.ReferenceFeature.Name)
    End If

ElseIf annoType = swDimXpertDimTol_ChamferDimension Then

    Select Case annotation.ChamferType
    Case swDimXpertChamferDimensionType_Angle
        str.Add ("Chamfer Dimension Type: Angle")
        isAngleType = True
    Case swDimXpertChamferDimensionType_LinearDistance1
        str.Add ("Chamfer Dimension Type: Distance 1")
    Case swDimXpertChamferDimensionType_LinearDistance2
        str.Add ("Chamfer Dimension Type: Distance 2")
    End Select

ElseIf annoType = swDimXpertDimTol_AngleBetween Then
    isAngleType = True
    Dim angleBetween As IDimXpertAngleBetweenDimTol
    Set angleBetween = annotation
    ' the origin and tolerance feature
    str.Add ("Origin Feature: " + angleBetween.OriginFeature.Name)

    ' is supplement angle
    str.Add ("Supplement Angle: " + IIf(angleBetween.Supplement, "True", "False"))

ElseIf annoType = swDimXpertDimTol_CounterSinkAngle Then
    isAngleType = True
    Dim countersinkAngle As IDimXpertCounterSinkAngleDimTol
    Set countersinkAngle = annotation

```

```

    If countersinkAngle.ReferenceFeature Is Nothing Then
        strsr.Add ("Reference Feature: NULL")
    Else
        strsr.Add ("Reference Feature: " + countersinkAngle.ReferenceFeature.Name)
    End If

ElseIf annoType = swDimXpertDimTol_ConeAngle Then
    isAngleType = True
End If

' conversion for radians to degrees when dimension type is angle
Dim dbl As Double
If isAngleType Then
    dbl = 57.2957795130823
Else
    dbl = 1#
End If

' the nominal, and upper and lower limits of size of the dimension
strsr.Add ("")
strsr.Add ("Compute Nominal Dimension: " + FormatDouble(annotation.GetNominalValue * dbl))
boolstatus = annotation.GetUpperAndLowerLimit(upper, lower)
strsr.Add ("Get Upper Limit: " + FormatDouble(upper * dbl))
strsr.Add ("Get Lower Limit: " + FormatDouble(lower * dbl))

' the upper and lower tolerance value by type
Select Case annotation.DimensionType

Case swDimXpertDimTolType_BlockTolerance
    strsr.Add ("Dimension Type: Block Tolerance")

' block tolerance
Case swDimXpertDimTolType_BlockToleranceNoNominal
    Dim blockTols As DimXpertBlockTolerances
    Set blockTols = dimXpertPart.GetBlockTolerances

    Select Case blockTols.Type
        Case swDimXpertBlockToleranceType_ASMEInch
            strsr.Add ("Dimension Type: Block Tolerance No Nominal")
            If isAngleType Then
                strsr.Add ("Angular Block Tolerance")
            Else
                strsr.Add ("Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlaces, "##,##0"))
            End If
        End Select
    End Select

```

```

        End If
        Case swDimXpertBlockToleranceType_ISO2768
            strsr.Add ("Dimension Type: General Tolerance")
        End Select

Case swDimXpertDimTolType_ISOLimitsAndFits
    strsr.Add ("Dimension Type: Limits and Fits")
    ' limits and fits tolerance
Case swDimXpertDimTolType_ISOLimitsAndFitsNoNominal
    strsr.Add ("Dimension Type: Limits and Fits No Nominal")
    strsr.Add ("Limits and Fits: " + annotation.LimitsAndFitsCode)
    ' limit dimension
Case swDimXpertDimTolType_LimitDimension
    strsr.Add ("Dimension Type: Limit Dimension")
    boolstatus = annotation.GetUpperAndLowerLimit(upper, lower)
    strsr.Add ("Get Upper Limit: " + FormatDouble(upper * dbl))
    strsr.Add ("Get Lower Limit: " + FormatDouble(lower * dbl))
Case swDimXpertDimTolType_MAXTolerance
    strsr.Add ("Dimension Type: MAXTolerance")
Case swDimXpertDimTolType_MINTolerance
    strsr.Add ("Dimension Type: MINTolerance")
Case swDimXpertDimTolType_NoTolerance
    strsr.Add ("Dimension Type: NoTolerance")
Case swDimXpertDimTolType_PlusMinusDimension
    strsr.Add ("Dimension Type: Plus Minus Dimension")

    ' plus and minus dimension
Case swDimXpertDimTolType_PlusMinusNoNominal
    strsr.Add ("Dimension Type: Plus Minus No Nominal")
    boolstatus = annotation.GetPlusAndMinusTolerance(plus, minus)
    strsr.Add ("Plus Tolerance: " + FormatDouble(plus * dbl))
    strsr.Add ("Minus Tolerance: " + FormatDouble(minus * dbl))

End Select

End Sub

Private Sub DistanceBetweenData(annotation As DimXpertDistanceBetweenDimTol)
    Dim feature As DimXpertFeature
    Dim featureFosUsage As Long
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    ' the origin and tolerance feature along with their feature of size usage (min, max, center)
    boolstatus = annotation.GetOriginFeature(feature, featureFosUsage)
    strsr.Add ("")

```

```

    strs.Add ("Origin Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    boolstatus = annotation.GetFeature(feature, featureFosUsage)
    strs.Add ("Tolerance Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))

    ' The direction vector
    boolstatus = annotation.GetDirectionVector(I, J, K)
    strs.Add ("")
    strs.Add ("Direction Vector: " + FormatVector(I, J, K))

```

End Sub

```

Private Sub CompositeDistanceBetweenData(annotation As
DimXpertCompositeDistanceBetweenDimTol)

```

```

    Dim feature As DimXpertFeature
    Dim featureFosUsage As Long
    Dim plus As Double, minus As Double
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    Dim blockTols As DimXpertBlockTolerances

```

```

    ' the origin and tolerance feature along with their feature of size usage (min, max,
center)

```

```

    boolstatus = annotation.GetOriginFeature(feature, featureFosUsage)
    strs.Add ("")
    strs.Add ("Origin Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    boolstatus = annotation.GetFeature(feature, featureFosUsage)
    strs.Add ("Tolerance Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))

```

```

    ' the pattern locating feature

```

```

    boolstatus = annotation.GetIntraFeature(feature, featureFosUsage)

```

```

    strs.Add ("Pattern Locating Feature: " + feature.Name + " @ " +
FosUsage(featureFosUsage))

```

```

    ' The direction vector

```

```

    boolstatus = annotation.GetDirectionVector(I, J, K)
    strs.Add ("")
    strs.Add ("Direction Vector: " + FormatVector(I, J, K))

```

```

    ' the upper and lower tolerance value for the pattern location by type

```

```

Select Case annotation.DimensionType

```

```

    ' plus and minus dimension

```

```

Case swDimXpertDimTolType_PlusMinusNoNominal

```

```

    strs.Add ("Pattern Locating Dimension Type: Plus Minus No Nominal")
    boolstatus = annotation.GetPlusAndMinusToleranceIntraFeature(plus, minus)
    strs.Add (" Plus Tolerance: " + FormatDouble(plus))

```

```

        strs.Add (" Minus Tolerance: " + FormatDouble(minus))
' block tolerance
Case swDimXpertDimTolType_BlockToleranceNoNominal

    Set blockTols = dimXpertPart.GetBlockTolerances

    Select Case blockTols.Type
    Case swDimXpertBlockToleranceType_ASMEInch
        strs.Add ("Pattern Locating Dimension Type: Block Tolerance No Nominal")
        strs.Add (" Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlaces, "##,##0"))
    Case swDimXpertBlockToleranceType_IS02768
        strs.Add ("Pattern Locating Dimension Type: General Tolerance")
    End Select

End Select

' the upper and lower tolerance value for the feature to feature location by type
Select Case annotation.DimensionTypeIntraFeature
' plus and minus dimension
Case swDimXpertDimTolType_PlusMinusNoNominal
    strs.Add ("Feature Locating Dimension Type: Plus Minus No Nominal")
    boolstatus = annotation.GetPlusAndMinusToleranceIntraFeature(plus, minus)
    strs.Add (" Plus Tolerance: " + FormatDouble(plus))
    strs.Add (" Minus Tolerance: " + FormatDouble(minus))
' block tolerance
Case swDimXpertDimTolType_BlockToleranceNoNominal

    Set blockTols = dimXpertPart.GetBlockTolerances
    Select Case blockTols.Type
    Case swDimXpertBlockToleranceType_ASMEInch
        strs.Add ("Feature locating Dimension Type: Block Tolerance No Nominal")
        strs.Add (" Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlacesIntraFeature, "##,##0"))
    Case swDimXpertBlockToleranceType_IS02768
        strs.Add ("Feature locating Dimension Type: General Tolerance")
    End Select
End Select

End Sub

Private Sub DatumsStr(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Datums:")
    Call datumStr(annotation.GetPrimaryDatums(), annotation.GetPrimaryDatumModifiers(), "
Primary:")

```

```
    Call datumStr(annotation.GetSecondaryDatums(), annotation.GetSecondaryDatumModifiers(), "Secondary:")
```

```
    Call datumStr(annotation.GetTertiaryDatums(), annotation.GetTertiaryDatumModifiers(), "Tertiary:")
```

```
End Sub
```

```
Private Sub datumStr(dats As Variant, mods As Variant, datumOrder As String)
```

```
    Dim I As Long
```

```
    Dim str As String
```

```
    Dim mcm As Long
```

```
    If IsEmpty(dats) Then
```

```
        str.Add (datumOrder + ": none")
```

```
        Exit Sub
```

```
    End If
```

```
    For I = LBound(dats) To UBound(dats)
```

```
        mcm = mods(I)
```

```
        str = str + " " + dats(I).Identifier + " @ " + mcmStr(mcm)
```

```
    Next I
```

```
    If StrComp(str, "") > 0 Then
```

```
        str.Add (datumOrder + str)
```

```
    Else
```

```
        str.Add (datumOrder + " <none>")
```

```
    End If
```

```
End Sub
```

```
' returns a string containing the height of the projected tolerance zone
```

```
Private Sub FormatProjectedZone(enabled As Boolean, height As Double)
```

```
    If enabled = True Then
```

```
        str.Add (" Projected Zone: True")
```

```
        str.Add (" Zone Height: " + FormatDouble(height))
```

```
    Else
```

```
        str.Add (" Projected Zone: False")
```

```
    End If
```

```
End Sub
```

```
Private Function mcmStr(mcm As Long) As String
```

```
    Dim str
```

```
    Select Case mcm
```

```
    Case swDimXpertMCM_LMC
```

```
        str = "LMC"
```

```
    Case swDimXpertMCM_MMC
```

```
        str = "MMC"
```

```
Case swDimXpertMCM_NoMCM
```

```
    str = "NoMCM"
```

```
Case swDimXpertMCM_RFS
```

```
    str = "RFS"
```

```
End Select
```

```
mcmStr = str
```

```
End Function
```

```
' returns a string containing the type of position tolerance zone used
```

```
Private Function PositionZoneType(typ As Long) As String
```

```
    Dim str As String
```

```
    Select Case typ
```

```
    Case swDimXpertPositionZoneType_CylindricalPosition
```

```
        str = "Cylindrical"
```

```
    Case swDimXpertPositionZoneType_PlanarPosition
```

```
        str = "Planar"
```

```
    Case swDimXpertPositionZoneType_SphericalPosition
```

```
        str = "Spherical"
```

```
    Case swDimXpertPositionZoneType_Boundary
```

```
        str = "Boundary"
```

```
    Case swDimXpertPositionZoneType_RadialPositionArc
```

```
        str = "RadialPositionArc"
```

```
    Case swDimXpertPositionZoneType_RadialPositionPlanar
```

```
        str = "RadialPositionPlanar"
```

```
    Case Else
```

```
        str = "N/A"
```

```
    End Select
```

```
    PositionZoneType = str
```

```
End Function
```

```
' returns a string containing the names of the SW display entities
```

```
Private Function DisplayEntity(annotation As DimXpertAnnotation) As String
```

```
    Dim str As String
```

```
    Dim dispEnt As Object
```

```
    Dim swAnnot As SldWorks.annotation
```

```
'Set dispEnt = swDimXpert.GetDisplayEntity(annot)
```

```
Set dispEnt = annotation.GetDisplayEntity
```

```
If Not dispEnt Is Nothing Then
```

```
    If TypeOf dispEnt Is SldWorks.annotation Then
```

```
        Set swAnnot = dispEnt
```

```
        str = swAnnot.GetName
```

```

        End If
    End If

    DisplayEntity = str
End Function
' returns a string containing the feature of size usage (min, max, center)
Private Function FosUsage(value As Long) As String
    Dim str
    Select Case value
    Case swDimXpertDistanceFosUsage_Center
        str = "Center"
    Case swDimXpertDistanceFosUsage_MaximumSide
        str = "Max"
    Case swDimXpertDistanceFosUsage_MinimumSide
        str = "Min"
    Case Else
        str = "N/A"
    End Select
    FosUsage = str
End Function
Private Function FormatVector(I As Double, J As Double, K As Double) As String
    Dim str
    str = FormatDouble(I) + ", " + FormatDouble(J) + ", " + FormatDouble(K)

    FormatVector = str
End Function
Private Function FormatDouble(value As Double) As String
    Dim str

    str = Format(value, "##,##0.0000")

    FormatDouble = str
End Function
Private Function RadiansToDegrees(value As Double) As String
    Dim str

    str = Format((value * 57.2957795130823), "##,##0.00")

    RadiansToDegrees = str
End Function
Private Function annotationTypeNameFromObject(anno As DimXpertAnnotation) As String
    annotationTypeNameFromObject = annotationTypeNameFromTypeNumber(anno.Type)
End Function
Private Function annotationTypeNameFromTypeNumber(annoTypeIndex As Long) As String
    Select Case annoTypeIndex

```

```
Case swDimXpertDimTol_DistanceBetween
    annotationTypeNameFromTypeNumber = "DistanceBetween Dim"
Case swDimXpertDimTol_CounterBore
    annotationTypeNameFromTypeNumber = "CounterBore Dim"
Case swDimXpertDimTol_Depth
    annotationTypeNameFromTypeNumber = "Depth Dim"
Case swDimXpertDimTol_CounterSinkDiameter
    annotationTypeNameFromTypeNumber = "CounterSinkDiameter Dim"
Case swDimXpertDimTol_ChamferDimension
    annotationTypeNameFromTypeNumber = "ChamferDimension Dim"
Case swDimXpertDimTol_AngleBetween
    annotationTypeNameFromTypeNumber = "AngleBetween Dim"
Case swDimXpertDimTol_CounterSinkAngle
    annotationTypeNameFromTypeNumber = "CounterSinkAngle Dim"
Case swDimXpertDimTol_ConeAngle
    annotationTypeNameFromTypeNumber = "ConeAngle Dim"
Case swDimXpertDimTol_Diameter
    annotationTypeNameFromTypeNumber = "Diameter Dim"
Case swDimXpertDimTol_Length
    annotationTypeNameFromTypeNumber = "Length Dim"
Case swDimXpertDimTol_Radius
    annotationTypeNameFromTypeNumber = "Radius Dim"
Case swDimXpertDimTol_Width
    annotationTypeNameFromTypeNumber = "Width Dim"
Case swDimXpertDimTol_CompositeDistanceBetween
    annotationTypeNameFromTypeNumber = "CompositeDistanceBetween Dim"
Case swDimXpertDatum
    annotationTypeNameFromTypeNumber = "Datum"
Case swDimXpertGeoTol_Position
    annotationTypeNameFromTypeNumber = "Position Tol"
Case swDimXpertGeoTol_CompositePosition
    annotationTypeNameFromTypeNumber = "CompositePosition Tol"
Case swDimXpertGeoTol_Symmetry
    annotationTypeNameFromTypeNumber = "Symmetry Tol"
Case swDimXpertGeoTol_Concentricity
    annotationTypeNameFromTypeNumber = "Concentricity Tol"
Case swDimXpertGeoTol_LineProfile
    annotationTypeNameFromTypeNumber = "LineProfile Tol"
Case swDimXpertGeoTol_CompositeLineProfile
    annotationTypeNameFromTypeNumber = "CompositeLineProfile Tol"
Case swDimXpertGeoTol_SurfaceProfile
    annotationTypeNameFromTypeNumber = "SurfaceProfile Tol"
Case swDimXpertGeoTol_CompositeSurfaceProfile
    annotationTypeNameFromTypeNumber = "CompositeSurfaceProfile Tol"
```

```

Case swDimXpertGeoTol_Angularity
    annotationTypeNameFromTypeNumber = "Angularity Tol"
Case swDimXpertGeoTol_Parallelism
    annotationTypeNameFromTypeNumber = "Parallelism Tol"
Case swDimXpertGeoTol_Perpendicularity
    annotationTypeNameFromTypeNumber = "Perpendicularity Tol"
Case swDimXpertGeoTol_TotalRunout
    annotationTypeNameFromTypeNumber = "TotalRunout Tol"
Case swDimXpertGeoTol_CircularRunout
    annotationTypeNameFromTypeNumber = "CircularRunout Tol"
Case swDimXpertGeoTol_Flatness
    annotationTypeNameFromTypeNumber = "Flatness Tol"
Case swDimXpertGeoTol_Circularity
    annotationTypeNameFromTypeNumber = "Circularity Tol"
Case swDimXpertGeoTol_Cylindricity
    annotationTypeNameFromTypeNumber = "Cylindricity Tol"
Case swDimXpertGeoTol_Straightness
    annotationTypeNameFromTypeNumber = "Straightness Tol"
Case swDimXpertGeoTol_Tangency
    annotationTypeNameFromTypeNumber = "Tangency Tol"
Case Else
    annotationTypeNameFromTypeNumber = "<unknown> " & CStr(annoTypeIndex)

End Select
End Function

```

Get DimXpert Tolerance5 Example (VB.NET)

This example shows how to build a part and get attributes for the following DimXpert annotation:

* Concentricity geometric tolerance

```
' -----  
' Preconditions:  
' 1. Open public_documents\samples\tutorial\api\cover_with_dimensions.sldprt  
' 2. Open the DimXpert toolbar on View > Toolbars.  
'  
' Create concentricity geometric tolerance:  
' 1. Click Datum on the DimXpert tool bar.  
' 2. Click on Boss1 (front extrusion).  
' 3. Click to place the annotation.  
' 4. Click the green check mark to accept Datum A.  
' 5. Click Geometric Tolerance of the DimXpert tool bar.  
' 6. In the Geometric Tolerance Properties dialog:  
' a. Select Concentricity in the Symbol dropdown.  
' b. Click Tolerance 1.  
' c. Click Diameter on the toolbar at the top of the dialog.  
' d. Type A in Primary.  
' 7. Click the inside face of Simple Hole2.  
' 8. Click to place the annotation.  
' 9. Click OK to close the Geometric Tolerance Properties dialog.  
' 10. In the DimXpertManager tab of the Management Panel, expand Simple Hole2.  
' 11. Observe the following Dimxpert annotation: Concentricity1  
' 12. Ensure that the SolidWorks.Interop.swdimxpert.dll interop  
' assembly is loaded (right-click the project in Project Explorer, and  
' click Add Reference > .NET tab).  
' 13. Ensure that the Microsoft Scripting Runtime library is loaded  
' (right-click the project in Project Explorer and click Add Reference >  
' COM tab).  
'  
' Postconditions:  
' 1. Writes the output to c:\temp\dimXpertInfo.txt.  
' 2. Inspect the Immediate window.  
'  
' NOTE: Because the part is used elsewhere, do not save changes.  
' -----
```

```
Imports SolidWorks.Interop.sldworks
```

```
Imports SolidWorks.Interop.swdimxpert
```

```

Imports SolidWorks.Interop.swconst
Imports System
Imports System.Diagnostics
Imports Scripting
Partial Class SolidWorksMacro
    Dim strs As New Collection
    Dim boolstatus As Boolean
    Dim dimXpertPart As DimXpertPart
    Dim i As Double
    Dim j As Double
    Dim k As Double
    Sub Main()
        Dim swModelDoc As IModelDoc2
        swModelDoc = swApp.ActiveDoc
        If swModelDoc Is Nothing Then
            Exit Sub
        End If
        Dim fso As New Scripting.FileSystemObject()
        Dim f As Scripting.File
        Dim textStr As Scripting.TextStream
        textStr = fso.CreateTextFile("c:\temp\dimXpertInfo.txt")
        f = fso.GetFile("c:\temp\dimXpertInfo.txt")
        'textStr = f.OpenAsTextStream(2, -2)
        If textStr Is Nothing Then
            Debug.Print("Error creating temp file.")
            Exit Sub
        End If
        Call log("Starting DimXpert log...", textStr)
        Call retrieve_info_text(swApp, textStr)
        textStr.Close()
    End Sub
    Private Sub log(ByVal text As String, ByVal textStr As Scripting.TextStream)
        Debug.Print(text)
        textStr.WriteLine(text)
    End Sub
    Private Sub retrieve_info_text(ByVal swapp As SldWorks, ByVal textStr As TextStream)
        Dim dimXpertMgr As SolidWorks.Interop.sldworks.DimXpertManager
        dimXpertMgr =
swapp.IActiveDoc2.Extension.DimXpertManager(swapp.IActiveDoc2.IGetActiveConfiguration().Name,
True)
        Call log("Model: " & swapp.IActiveDoc2.GetPathName, textStr)
        Dim dimXpertPartObj As DimXpertPart
        dimXpertPartObj = dimXpertMgr.DimXpertPart
        dimXpertPart = dimXpertPartObj
        Dim vAnnotations As Object

```

```

vAnnotations = dimXpertPart.GetAnnotations()
Call log("-----", textStr)
Call log("Annotations...", textStr)
Call log("-----", textStr)
Dim annotationTemp As DimXpertAnnotation
Dim annotationIndex As Long
For annotationIndex = 0 To UBound(vAnnotations)
    annotationTemp = vAnnotations(annotationIndex)
    Dim AnnotationDataText As Collection
    AnnotationDataText = AnnotationData(annotationTemp)
    Dim annotationTextIndex As Long
    For annotationTextIndex = 1 To AnnotationDataText.Count
        Call log(AnnotationDataText(annotationTextIndex), textStr)
    Next
Next
End Sub

Public Function AnnotationData(ByVal annotation As DimXpertAnnotation) As Collection
    Dim annoType As Long
    'general info
    Call GeneralInfo(annotation)
    annoType = annotation.Type
    If annoType = swDimXpertAnnotationType_e.swDimXpertDatum Then
        Call DatumData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Position Then
        Call PositionData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositePosition Then
        Call CompositePositionData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Symmetry Then
        Call SymmetryData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Concentricity Then
        Call ConcentricityData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_LineProfile Then
        Call LineProfileData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositeLineProfile
Then
        Call CompositeLineProfileData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_SurfaceProfile Then
        Call SurfaceProfileData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositeSurfaceProfile
Then
        Call CompositeSurfaceProfileData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Angularity Or annoType =
swDimXpertAnnotationType_e.swDimXpertGeoTol_Parallelism Or annoType =
swDimXpertAnnotationType_e.swDimXpertGeoTol_Perpendicularity Then
        Call OrientationData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_TotalRunout Then

```

```

        Call TotalRunoutData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_CircularRunout Then
        Call CircularRunoutData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Flatness Then
        Call FlatnessData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Circularity Then
        Call CircularityData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Cylindricity Then
        Call CylindricityData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Straightness Then
        Call StraightnessData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Tangency Then
        Call TangencyData(annotation)
    Else ' any of the dimension tolerance types
        Call DimensionToleranceData(annotation)
    End If
    AnnotationData = strs
End Function
Private Sub Clear(ByVal strs As Collection)
    strs.Remove(strs.Count)
    If Not strs.Count = 0 Then
        Call Clear(strs)
    End If
End Sub
Private Sub GeneralInfo(ByVal annotation As DimXpertAnnotation)
    Dim annoType As String
    Dim modelObj As Feature
    If Not strs.Count = 0 Then
        Call Clear(strs)
    End If
    strs.Add("")
    strs.Add("Name: " + annotation.Name)
    annoType = annotationTypeNameFromObject(annotation)
    strs.Add("Type: " + annoType)
    strs.Add("Display Entity: " + DisplayEntity(annotation))
    modelObj = annotation.GetModelFeature()
    If Not (modelObj Is Nothing) Then
        strs.Add("ModelFeature: " + modelObj.Name + " (" + modelObj.GetTypeName2() + ")")
    End If
End Sub
Private Sub DatumData(ByVal annotation As DimXpertDatum)
    ' the datum letter
    strs.Add("")
    strs.Add("Datum Letter: " + annotation.Identifier)
End Sub

```

```

Private Sub PositionData(ByVal annotation As DimXpertPositionTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim boolstatus As Boolean
    strs.Add("")
    strs.Add("Position Tolerance Compartment:")
    ' the shape of the tolerance zone
    strs.Add(" Zone Type: " + PositionZoneType(annotation.ZoneType))
    ' the zone vector if the tolerance zone is planar
    If annotation.ZoneType =
swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_PlanarPosition Then
        boolstatus = annotation.GetPlanarZoneVector(I, J, K)
        strs.Add(" Direction: " + FormatVector(I, J, K))
    End If
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the material condition modifier applied to feature
    strs.Add(" Modifier: " + mcmStr(annotation.Modifier))
    ' the projected tolerance zone when specified
    boolstatus = annotation.GetProjectedZone(enabled, value)
    Call FormatProjectedZone(enabled, value)
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub CompositePositionData(ByVal annotation As DimXpertCompositePositionTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim boolstatus As Boolean
    strs.Add("")
    strs.Add("Composite Position Tolerance Compartment")
    ' the shape of the tolerance zone
    strs.Add(" Zone Type: " + PositionZoneType(annotation.ZoneType))
    ' the zone vector when the zone is planar
    If annotation.ZoneType =
swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_PlanarPosition Then
        boolstatus = annotation.GetPlanarZoneVector(I, J, K)
        strs.Add(" Direction: " + FormatVector(I, J, K))
    End If
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the material condition modifier
    strs.Add(" Modifier: " + mcmStr(annotation.Modifier))
    ' the projected tolerance zone when specified
    boolstatus = annotation.GetProjectedZone(enabled, value)
    Call FormatProjectedZone(enabled, value)

```

```

' the datum reference frame for the pattern location
Call DatumsStr(annotation)
' the datum reference frame for the feature to feature location
strs.Add("Composite datums:")
strs.Add(" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
strs.Add(" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True",
"False"))
strs.Add(" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True",
"False"))
End Sub

Private Sub SymmetryData(ByVal annotation As DimXpertSymmetryTolerance)
Dim I As Double, J As Double, K As Double
Dim boolstatus As Boolean
strs.Add("")
strs.Add("Symmetry Tolerance Compartment")
' the tolerance value
strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
' the material condition modifier applied to feature
strs.Add(" Modifier: " + mcmStr(annotation.Modifier))
' the datum reference frame
strs.Add("")
Call DatumsStr(annotation)
' the direction of the planar zone
strs.Add("")
boolstatus = annotation.GetZoneDirection(I, J, K)
strs.Add("Planar Zone Direction: " + FormatVector(I, J, K))
End Sub

Private Sub ConcentricityData(ByVal annotation As DimXpertConcentricityTolerance)
strs.Add("")
strs.Add("Concentricity Tolerance Compartment")
' the tolerance value
strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
' the material condition modifier applied to feature
strs.Add(" Modifier: " + mcmStr(annotation.Modifier))
' the datum reference frame
Call DatumsStr(annotation)
End Sub

Private Sub TotalRunoutData(ByVal annotation As DimXpertTolerance)
strs.Add("")
strs.Add("Total Runout Tolerance Compartment")
' the tolerance value
strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
' the datum reference frame
Call DatumsStr(annotation)
End Sub

```

```

Private Sub CircularRunoutData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Circular Runout Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub LineProfileData(ByVal annotation As DimXpertLineProfileTolerance)
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    strs.Add("")
    strs.Add("Line Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the outer (outside material) tolerance value
    strs.Add(" Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))
    ' the vector normal to the profile zones
    strs.Add("")
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)
    strs.Add("Planar Zone Vector: " + FormatVector(I, J, K))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub CompositeLineProfileData(ByVal annotation As
DimXpertCompositeLineProfileTolerance)
    strs.Add("")
    strs.Add("Composite Line Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the outer (outside material) tolerance value
    strs.Add(" Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))
    ' the vector normal to the profile zones
    strs.Add("")
    boolstatus = annotation.GetPlanarZoneVector(i, j, k)
    strs.Add("Planar Zone Vector: " + FormatVector(i, j, k))
    ' the datum reference frame
    Call DatumsStr(annotation)
    ' the datum reference frame for the orientation and form
    strs.Add("Composite Datums:")
    strs.Add(" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
    strs.Add(" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True",
"False"))
    strs.Add(" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True",
"False"))
End Sub

```

```

Private Sub SurfaceProfileData(ByVal annotation As DimXpertSurfaceProfileTolerance)
    strs.Add("")
    strs.Add("Surface Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the outer (outside material) tolerance value
    strs.Add(" Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub CompositeSurfaceProfileData(ByVal annotation As
DimXpertCompositeSurfaceProfileTolerance)
    strs.Add("")
    strs.Add("Composite Surface Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance Upper Tier: " + FormatDouble(annotation.Tolerance))
    ' the outer tolerance value
    strs.Add(" Outer Tolerance Upper Tier: " +
FormatDouble(annotation.OuterToleranceValue))
    ' the datum reference frame for the location
    Call DatumsStr(annotation)
    ' the datum reference frame for the orientation and form
    strs.Add("Composite Datums:")
    strs.Add(" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
    strs.Add(" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True",
"False"))
    strs.Add(" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True",
"False"))
End Sub

Private Sub OrientationData(ByVal annotation As DimXpertOrientationTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim annoType As Long
    annoType = annotation.Type
    ' the type or orientation tolerance
    If annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Perpendicularity Then
        strs.Add("Orientation Type: Perpendicularity")
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Parallelism Then
        strs.Add("Orientation Type: Parallelism")
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Angularity Then
        strs.Add("Orientation Type: Angularity")
    End If
    strs.Add("")
    strs.Add("Orientation Tolerance Compartment:")
    ' the shape of the tolerance zone
    Select Case annotation.ZoneType

```

```

        Case swDimXpertOrientationZoneType_e.swDimXpertOrientationZoneType_Cylindrical
            strsr.Add(" Zone Type: Cylindrical")
        Case swDimXpertOrientationZoneType_e.swDimXpertOrientationZoneType_Planar
            strsr.Add(" Zone Type: Planar")
            boolstatus = annotation.GetPlanarZoneVector(I, J, K)
            strsr.Add("Planar Zone Vector: " + FormatVector(I, J, K))
    End Select
    ' the tolerance value
    strsr.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    'material condition modifier applied to feature
    strsr.Add(" Modifier: " + mcmStr(annotation.Modifier))
    ' the projected tolerance zone when specified
    boolstatus = annotation.GetProjectedZone(enabled, value)
    Call FormatProjectedZone(enabled, value)
    ' is tangent plane
    strsr.Add(" IsTangentPlane: " + IIf(annotation.IsTangentPlane, "True", "False"))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub FlatnessData(ByVal annotation As DimXpertFlatnessTolerance)
    Dim enabled As Boolean
    Dim length As Double, width As Double
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    strsr.Add("")
    strsr.Add("Flatness Tolerance Compartment:")
    ' the tolerance value
    strsr.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the per unit area data
    boolstatus = annotation.GetPerUnitArea(enabled, length, width, I, J, K)
    strsr.Add(" Per Unit Area: " + IIf(enabled, "True", "False"))
    If enabled Then
        strsr.Add(" Per Unit Length: " + FormatDouble(length))
        strsr.Add(" Per Unit Width: " + FormatDouble(width))
        strsr.Add(" Per Unit Direction: " + FormatVector(I, J, K))
    End If
End Sub

Private Sub CircularityData(ByVal annotation As DimXpertTolerance)
    strsr.Add("")
    strsr.Add("Circularity Tolerance Compartment")
    ' the tolerance value
    strsr.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub

Private Sub CylindricityData(ByVal annotation As DimXpertTolerance)
    strsr.Add("")

```

```

        strs.Add("Cylindricity Tolerance Compartment")
        ' the tolerance value
        strs.Add("  Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub

Private Sub StraightnessData(ByVal annotation As DimXpertStraightnessTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean
    Dim dist As Double
    Dim boolstatus As Boolean
    'tolerance compartment info
    strs.Add("")
    strs.Add("Straightness Tolerance Compartment")
    'type or shape of the tolerance zone
    Select Case annotation.ZoneType
        Case swDimXpertStraightnessZoneType_e.swDimXpertStraightnessZoneType_Cylindrical
            strs.Add("  Zone Type: Cylindrical")
        Case swDimXpertStraightnessZoneType_e.swDimXpertStraightnessZoneType_PlanarMedian
            strs.Add("  Zone Type: Planar Median")
        Case swDimXpertStraightnessZoneType_e.swDimXpertStraightnessZoneType_Surface
            strs.Add("  Zone Type: Surface Straightness")
            boolstatus = annotation.GetPlanarZoneVector(I, J, K)
            strs.Add("  Zone Vector: " + FormatVector(I, J, K))
    End Select
    ' the tolerance value
    strs.Add("  Tolerance: " + FormatDouble(annotation.Tolerance))
    'per unit length
    boolstatus = annotation.GetPerUnitLength(enabled, dist)
    strs.Add("  Per Unit Length: " + IIf(enabled, "True", "False"))
    If enabled Then
        strs.Add("  Per Unit Length Distance: " + FormatDouble(dist))
    End If
    ' the material condition modifier
    strs.Add("  Modifier: " + mcmStr(annotation.Modifier))
End Sub

Private Sub ProfileData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add("  Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub SurfaceFinishData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Surface Finish Tolerance Compartment")

```

```

        ' the tolerance value
        strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub
Private Sub TangencyData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Tangency Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub
Private Sub DimensionToleranceData(ByVal annotation As DimXpertDimensionTolerance)
    Dim isAngleType As Boolean
    Dim annoType As Long
    Dim upper As Double, lower As Double
    Dim plus As Double, minus As Double
    Dim boolstatus As Boolean
    annoType = annotation.Type
    isAngleType = False
    strs.Add("")
    strs.Add("Dimension Tolerance Compartment")
    If annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_DistanceBetween Then
        Call DistanceBetweenData(annotation)
    ElseIf annoType =
swDimXpertAnnotationType_e.swDimXpertDimTol_CompositeDistanceBetween Then
        Call CompositeDistanceBetweenData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_CounterBore Then
        If annotation.ReferenceFeature Is Nothing Then
            strs.Add("Reference Feature: NULL")
        Else
            strs.Add("Reference Feature: " + annotation.ReferenceFeature.Name)
        End If
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_Depth Then
        If annotation.ReferenceFeature Is Nothing Then
            strs.Add("Reference Feature: NULL")
        Else
            strs.Add("Reference Feature: " + annotation.ReferenceFeature.Name)
        End If
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_CounterSinkDiameter
Then
        If annotation.ReferenceFeature Is Nothing Then
            strs.Add("Reference Feature: NULL")
        Else
            strs.Add("Reference Feature: " + annotation.ReferenceFeature.Name)
        End If
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_ChamferDimension Then
        Dim chamferAnno As IDimXpertChamferDimTol

```

```

    chamferAnno = annotation
    Select Case chamferAnno.ChamferType
        Case swDimXpertChamferDimensionType_e.swDimXpertChamferDimensionType_Angle
            strs.Add("Chamfer Dimension Type: Angle")
            isAngleType = True
        Case
            swDimXpertChamferDimensionType_e.swDimXpertChamferDimensionType_LinearDistance1
                strs.Add("Chamfer Dimension Type: Distance 1")
            Case
                swDimXpertChamferDimensionType_e.swDimXpertChamferDimensionType_LinearDistance2
                    strs.Add("Chamfer Dimension Type: Distance 2")
    End Select
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_AngleBetween Then
        isAngleType = True
        ' the origin and tolerance feature
        strs.Add("Origin Feature: " + annotation.OriginFeature.Name)
        ' is supplement angle
        strs.Add("Supplement Angle: " + IIf(annotation.Supplement, "True", "False"))
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_CounterSinkAngle Then
        isAngleType = True
        If annotation.ReferenceFeature Is Nothing Then
            strs.Add("Reference Feature: NULL")
        Else
            strs.Add("Reference Feature: " + annotation.ReferenceFeature.Name)
        End If
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_ConeAngle Then
        isAngleType = True
    End If
    ' conversion for radians to degrees when dimension type is angle
    Dim dbl As Double
    If isAngleType Then
        dbl = 57.2957795130823
    Else
        dbl = 1.0#
    End If
    ' the nominal, and upper and lower limits of size of the dimension
    strs.Add("")
    strs.Add("Compute Nominal Dimension: " + FormatDouble(annotation.GetNominalValue *
dbl))
    boolstatus = annotation.GetUpperAndLowerLimit(upper, lower)
    strs.Add("Get Upper Limit: " + FormatDouble(upper * dbl))
    strs.Add("Get Lower Limit: " + FormatDouble(lower * dbl))
    ' the upper and lower tolerance value by type
    Select Case annotation.DimensionType
        Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_BlockTolerance
            strs.Add("Dimension Type: Block Tolerance")

```

```

        ' block tolerance
    Case
swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_BlockToleranceNoNominal
        Dim blockTols As DimXpertBlockTolerances
        blockTols = dimXpertPart.GetBlockTolerances
        Select Case blockTols.Type
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ASMEInch
                strs.Add("Dimension Type: Block Tolerance No Nominal")
                If isAngleType Then
                    strs.Add("Angular Block Tolerance")
                Else
                    strs.Add("Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlaces, "##,##0"))
                End If
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ISO2768
                strs.Add("Dimension Type: General Tolerance")
        End Select
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_ISOLimitsAndFits
        strs.Add("Dimension Type: Limits and Fits")
        ' limits and fits tolerance
    Case
swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_ISOLimitsAndFitsNoNominal
        strs.Add("Dimension Type: Limits and Fits No Nominal")
        strs.Add("Limits and Fits: " + annotation.LimitsAndFitsCode)
        ' limit dimension
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_LimitDimension
        strs.Add("Dimension Type: Limit Dimension")
        boolstatus = annotation.GetUpperAndLowerLimit(upper, lower)
        strs.Add("Get Upper Limit: " + FormatDouble(upper * dbl))
        strs.Add("Get Lower Limit: " + FormatDouble(lower * dbl))
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_MAXTolerance
        strs.Add("Dimension Type: MAXTolerance")
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_MINTolerance
        strs.Add("Dimension Type: MINTolerance")
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_NoTolerance
        strs.Add("Dimension Type: NoTolerance")
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_PlusMinusDimension
        strs.Add("Dimension Type: Plus Minus Dimension")
        ' plus and minus dimension
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_PlusMinusNoNominal
        strs.Add("Dimension Type: Plus Minus No Nominal")
        boolstatus = annotation.GetPlusAndMinusTolerance(plus, minus)
        strs.Add("Plus Tolerance: " + FormatDouble(plus * dbl))
        strs.Add("Minus Tolerance: " + FormatDouble(minus * dbl))
End Select
End Sub

```

```

Private Sub DistanceBetweenData(ByVal annotation As DimXpertDistanceBetweenDimTol)
    Dim feature As DimXpertFeature
    Dim featureFosUsage As Long
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    feature = Nothing
    ' the origin and tolerance feature along with their feature of size usage (min, max,
center)
    boolstatus = annotation.GetOriginFeature(feature, featureFosUsage)
    strs.Add("")
    strs.Add("Origin Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    boolstatus = annotation.GetFeature(feature, featureFosUsage)
    strs.Add("Tolerance Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    ' The direction vector
    boolstatus = annotation.GetDirectionVector(I, J, K)
    strs.Add("")
    strs.Add("Direction Vector: " + FormatVector(I, J, K))
End Sub

Private Sub CompositeDistanceBetweenData(ByVal annotation As
DimXpertCompositeDistanceBetweenDimTol)
    Dim feature As DimXpertFeature
    Dim featureFosUsage As Long
    Dim plus As Double, minus As Double
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    feature = Nothing
    ' the origin and tolerance feature along with their feature of size usage (min, max,
center)
    boolstatus = annotation.GetOriginFeature(feature, featureFosUsage)
    strs.Add("")
    strs.Add("Origin Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    boolstatus = annotation.GetFeature(feature, featureFosUsage)
    strs.Add("Tolerance Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    ' the pattern locating feature
    boolstatus = annotation.GetIntraFeature(feature, featureFosUsage)
    strs.Add("Pattern Locating Feature: " + feature.Name + " @ " +
FosUsage(featureFosUsage))
    ' The direction vector
    boolstatus = annotation.GetDirectionVector(I, J, K)
    strs.Add("")
    strs.Add("Direction Vector: " + FormatVector(I, J, K))
    ' the upper and lower tolerance value for the pattern location by type
    Dim dimTol As IDimXpertDimensionTolerance
    dimTol = annotation
    Select Case dimTol.DimensionType
        ' plus and minus dimension

```

```

        Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_PlusMinusNoNominal
            dimTol.GetPlusAndMinusTolerance(plus, minus)
            strs.Add("Pattern Locating Dimension Type: Plus Minus No Nominal")
            strs.Add(" Plus Tolerance: " + FormatDouble(plus))
            strs.Add(" Minus Tolerance: " + FormatDouble(minus))
            ' block tolerance
    Case
swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_BlockToleranceNoNominal
        Dim blockTols As DimXpertBlockTolerances
        blockTols = dimXpertPart.GetBlockTolerances
        Select Case blockTols.Type
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ASMEInch
                strs.Add("Pattern Locating Dimension Type: Block Tolerance No
Nominal")
                strs.Add(" Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlaces, "##,##0"))
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ISO2768
                strs.Add("Pattern Locating Dimension Type: General Tolerance")
        End Select
    End Select
' the upper and lower tolerance value for the feature to feature location by type
Select Case annotation.DimensionTypeIntraFeature
    ' plus and minus dimension
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_PlusMinusNoNominal
        strs.Add("Feature Locating Dimension Type: Plus Minus No Nominal")
        boolstatus = annotation.GetPlusAndMinusToleranceIntraFeature(plus, minus)
        strs.Add(" Plus Tolerance: " + FormatDouble(plus))
        strs.Add(" Minus Tolerance: " + FormatDouble(minus))
        ' block tolerance
    Case
swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_BlockToleranceNoNominal
        Dim blockTols As DimXpertBlockTolerances
        blockTols = dimXpertPart.GetBlockTolerances
        Select Case blockTols.Type
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ASMEInch
                strs.Add("Feature locating Dimension Type: Block Tolerance No
Nominal")
                strs.Add(" Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlacesIntraFeature, "##,##0"))
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ISO2768
                strs.Add("Feature locating Dimension Type: General Tolerance")
        End Select
    End Select
End Sub
Private Sub DatumsStr(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Datums:")

```

```

        Call datumStr(annotation.GetPrimaryDatums(), annotation.GetPrimaryDatumModifiers(), "
Primary:")
        Call datumStr(annotation.GetSecondaryDatums(),
annotation.GetSecondaryDatumModifiers(), "  Secondary:")
        Call datumStr(annotation.GetTertiaryDatums(), annotation.GetTertiaryDatumModifiers(),
"    Tertiary:")
    End Sub

    Private Sub datumStr(ByVal dats As Object, ByVal mods As Object, ByVal datumOrder As
String)
        Dim I As Long
        Dim str As String
        Dim mcm As Long
        If IsNothing(dats) Then
            Exit Sub
        End If
        str = ""
        For I = LBound(dats) To UBound(dats)
            mcm = mods(I)
            str = str + "  " + dats(I).Identifier + " @ " + mcmStr(mcm)
        Next I
        If StrComp(str, "") > 0 Then
            strs.Add(datumOrder + str)
        Else
            strs.Add(datumOrder + " <none>")
        End If
    End Sub

    ' returns a string containing the height of the projected tolerance zone
    Private Sub FormatProjectedZone(ByVal enabled As Boolean, ByVal height As Double)
        If enabled = True Then
            strs.Add("  Projected Zone:  True")
            strs.Add("  Zone Height: " + FormatDouble(height))
        Else
            strs.Add("  Projected Zone:  False")
        End If
    End Sub

    Private Function mcmStr(ByVal mcm As Long) As String
        Dim str As String
        str = ""
        Select Case mcm
            Case swDimXpertMaterialConditionModifier_e.swDimXpertMCM_LMC
                str = "LMC"
            Case swDimXpertMaterialConditionModifier_e.swDimXpertMCM_MMC
                str = "MMC"
            Case swDimXpertMaterialConditionModifier_e.swDimXpertMCM_NoMCM
                str = "NoMCM"
            Case swDimXpertMaterialConditionModifier_e.swDimXpertMCM_RFS

```

```

        str = "RFS"
    End Select
    mcmStr = str
End Function
' returns a string containing the type of position tolerance zone used
Private Function PositionZoneType(ByVal typ As Long) As String
    Dim str As String
    Select Case typ
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_CylindricalPosition
            str = "Cylindrical"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_PlanarPosition
            str = "Planar"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_SphericalPosition
            str = "Spherical"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_Boundary
            str = "Boundary"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_RadialPositionArc
            str = "RadialPositionArc"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_RadialPositionPlanar
            str = "RadialPositionPlanar"
        Case Else
            str = "N/A"
    End Select
    PositionZoneType = str
End Function
' returns a string containing the names of the SW display entities
Private Function DisplayEntity(ByVal annotation As DimXpertAnnotation) As String
    Dim str As String
    Dim dispEnt As Object
    Dim swAnnot As SolidWorks.Interop.sldworks.Annotation
    str = ""
    'Set dispEnt = swDimXpert.GetDisplayEntity(annotation)
    dispEnt = annotation.GetDisplayEntity()
    If Not dispEnt Is Nothing Then
        If TypeOf dispEnt Is SolidWorks.Interop.sldworks.Annotation Then
            swAnnot = dispEnt
            str = swAnnot.GetName
        End If
    End If
    DisplayEntity = str
End Function
' returns a string containing the feature of size usage (min, max, center)
Private Function FosUsage(ByVal value As Long) As String
    Dim str As String
    Select Case value

```

```

        Case swDimXpertDistanceFosUsage_e.swDimXpertDistanceFosUsage_Center
            str = "Center"
        Case swDimXpertDistanceFosUsage_e.swDimXpertDistanceFosUsage_MaximumSide
            str = "Max"
        Case swDimXpertDistanceFosUsage_e.swDimXpertDistanceFosUsage_MinimumSide
            str = "Min"
        Case Else
            str = "N/A"
    End Select
    FosUsage = str
End Function

Private Function FormatVector(ByVal I As Double, ByVal J As Double, ByVal K As Double) As String
    Dim str As String
    str = FormatDouble(I) + ", " + FormatDouble(J) + ", " + FormatDouble(K)
    FormatVector = str
End Function

Private Function FormatDouble(ByVal value As Double) As String
    Dim str As String
    str = Format(value, "##,##0.0000")
    FormatDouble = str
End Function

Private Function RadiansToDegrees(ByVal value As Double) As String
    Dim str As String
    str = Format((value * 57.2957795130823), "##,##0.00")
    RadiansToDegrees = str
End Function

Private Function annotationTypeNameFromObject(ByVal anno As DimXpertAnnotation) As String
    annotationTypeNameFromObject = annotationTypeNameFromTypeNumber(anno.Type)
End Function

Private Function annotationTypeNameFromTypeNumber(ByVal annoTypeIndex As Long) As String
    Select Case annoTypeIndex
        Case swDimXpertAnnotationType_e.swDimXpertDimTol_DistanceBetween
            annotationTypeNameFromTypeNumber = "DistanceBetween Dim"
        Case swDimXpertAnnotationType_e.swDimXpertDimTol_CounterBore
            annotationTypeNameFromTypeNumber = "CounterBore Dim"
        Case swDimXpertAnnotationType_e.swDimXpertDimTol_Depth
            annotationTypeNameFromTypeNumber = "Depth Dim"
        Case swDimXpertAnnotationType_e.swDimXpertDimTol_CounterSinkDiameter
            annotationTypeNameFromTypeNumber = "CounterSinkDiameter Dim"
        Case swDimXpertAnnotationType_e.swDimXpertDimTol_ChamferDimension
            annotationTypeNameFromTypeNumber = "ChamferDimension Dim"
        Case swDimXpertAnnotationType_e.swDimXpertDimTol_AngleBetween
            annotationTypeNameFromTypeNumber = "AngleBetween Dim"
        Case swDimXpertAnnotationType_e.swDimXpertDimTol_CounterSinkAngle

```

```
        annotationTypeNameFromTypeNumber = "CounterSinkAngle Dim"
Case swDimXpertAnnotationType_e.swDimXpertDimTol_ConeAngle
        annotationTypeNameFromTypeNumber = "ConeAngle Dim"
Case swDimXpertAnnotationType_e.swDimXpertDimTol_Diameter
        annotationTypeNameFromTypeNumber = "Diameter Dim"
Case swDimXpertAnnotationType_e.swDimXpertDimTol_Length
        annotationTypeNameFromTypeNumber = "Length Dim"
Case swDimXpertAnnotationType_e.swDimXpertDimTol_Radius
        annotationTypeNameFromTypeNumber = "Radius Dim"
Case swDimXpertAnnotationType_e.swDimXpertDimTol_Width
        annotationTypeNameFromTypeNumber = "Width Dim"
Case swDimXpertAnnotationType_e.swDimXpertDimTol_CompositeDistanceBetween
        annotationTypeNameFromTypeNumber = "CompositeDistanceBetween Dim"
Case swDimXpertAnnotationType_e.swDimXpertDatum
        annotationTypeNameFromTypeNumber = "Datum"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Position
        annotationTypeNameFromTypeNumber = "Position Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositePosition
        annotationTypeNameFromTypeNumber = "CompositePosition Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Symmetry
        annotationTypeNameFromTypeNumber = "Symmetry Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Concentricity
        annotationTypeNameFromTypeNumber = "Concentricity Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_LineProfile
        annotationTypeNameFromTypeNumber = "LineProfile Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositeLineProfile
        annotationTypeNameFromTypeNumber = "CompositeLineProfile Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_SurfaceProfile
        annotationTypeNameFromTypeNumber = "SurfaceProfile Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositeSurfaceProfile
        annotationTypeNameFromTypeNumber = "CompositeSurfaceProfile Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Angularity
        annotationTypeNameFromTypeNumber = "Angularity Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Parallelism
        annotationTypeNameFromTypeNumber = "Parallelism Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Perpendicularity
        annotationTypeNameFromTypeNumber = "Perpendicularity Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_TotalRunout
        annotationTypeNameFromTypeNumber = "TotalRunout Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_CircularRunout
        annotationTypeNameFromTypeNumber = "CircularRunout Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Flatness
        annotationTypeNameFromTypeNumber = "Flatness Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Circularity
        annotationTypeNameFromTypeNumber = "Circularity Tol"
```

```
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Cylindricity
    annotationTypeNameFromTypeNumber = "Cylindricity Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Straightness
    annotationTypeNameFromTypeNumber = "Straightness Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Tangency
    annotationTypeNameFromTypeNumber = "Tangency Tol"
Case Else
    annotationTypeNameFromTypeNumber = "<unknown> " & CStr(annoTypeIndex)
End Select
End Function
Public swApp As SldWorks
End Class
```

Get DimXpert Tolerance6 Example (VBA)

This example shows how to build a part and get attributes for the following DimXpert annotations:

- * Composite surface profile geometric tolerance
- * Tangency geometric tolerance

```
' -----  
' Preconditions:  
' 1. Open public_documents\samples\tutorial\cosmosxpress\aw_anchor_plate.sldprt.  
' 2. Open the DimXpert toolbar from View > Toolbars.  
'  
' Create a composite surface profile geometric tolerance:  
' 1. Click Datum on the DimXpert tool bar.  
' 2. Click a top face of the part.  
' 3. Click to place Datum A.  
' 4. Click a back face of the part.  
' 5. Click to place Datum B.  
' 6. Click a side face of the part.  
' 7. Click to place Datum C.  
' 8. Click Geometric Tolerance of the DimXpert tool bar.  
' 9. In the Geometric Tolerance Properties dialog:  
' a. Select Profile of Surface from the Symbol dropdown.  
' b. Type A in Primary, B in Secondary, and C  
'    in Tertiary.  
' c. In the second row, select Profile of Surface in the Symbol dropdown.  
' d. In the second row, type A in Primary .  
' e. Select the Composite frame check box.  
' f. Click the front curve of the hook.  
' g. Click to place the annotation.  
' h. Click OK to close the Geometric Tolerance Properties dialog.  
' 10. In the DimXpertManager tab of the Management Panel, expand Cylinder1.  
' 11. Observe the following DimXpert annotation: Composite Surface Profile1  
'  
' Create tangency geometric tolerances:  
' 1. Click Auto Dimension Scheme.  
' 2. Select all feature filters.  
' 3. Click the green check mark to accept the settings.  
' 4. Observe several tangency tolerance annotations.  
'  
' Before running this macro:  
' 1. Ensure that the SOLIDWORKS DimXpert type library is loaded  
'    in Tools > References.
```

```

' 2. Ensure that the Microsoft Scripting Runtime library is loaded
'    in Tools > References.
'
' Postconditions:
' 1. Writes the output to c:\temp\dimXpertInfo.txt.
' 2. Inspect the Immediate window.
'
' NOTE: Because the part is used elsewhere, do not save changes.
' -----
Option Explicit
Dim str As New Collection
Dim dimXpertPart As SwDimXpert.dimXpertPart
Sub Main()
    Dim swapp As SldWorks.SldWorks
    Set swapp = Application.SldWorks
    Dim swModelDoc As SldWorks.ModelDoc2
    Set swModelDoc = swapp.ActiveDoc
    If swModelDoc Is Nothing Then
        Exit Sub
    End If
    Dim f As New FileSystemObject
    Dim textStr As TextStream
    Set textStr = f.CreateTextFile("C:\temp\dimXpertInfo.txt", True)
    If textStr Is Nothing Then
        Debug.Print "Error creating temp file."
        Exit Sub
    End If

    Call log("Starting DimXpert log...", textStr)
    Call retrieve_info_text(swapp, textStr)
    textStr.Close
End Sub
Private Sub log(text As String, textStr As TextStream)
    Debug.Print text
    textStr.WriteLine (text)
End Sub
Private Sub retrieve_info_text(swapp As SldWorks.SldWorks, textStr As TextStream)
    Dim dimXpertMgr As SldWorks.DimXpertManager

    Set dimXpertMgr =
swapp.IActiveDoc2.Extension.DimXpertManager(swapp.IActiveDoc2.IGetActiveConfiguration().Name,
True)

    Call log("Model: " & swapp.IActiveDoc2.GetPathName, textStr)
    Dim dimXpertPartObj As dimXpertPart
    Set dimXpertPartObj = dimXpertMgr.dimXpertPart

```

```
Set dimXpertPart = dimXpertPartObj
```

```
Dim vAnnotations As Variant
```

```
vAnnotations = dimXpertPart.GetAnnotations()
```

```
Call log("-----", textStr)
```

```
Call log("Annotations...", textStr)
```

```
Call log("-----", textStr)
```

```
Dim annotationTemp As DimXpertAnnotation
```

```
Dim annotationIndex As Long
```

```
For annotationIndex = 0 To UBound(vAnnotations)
```

```
    Set annotationTemp = vAnnotations(annotationIndex)
```

```
    Dim AnnotationDataText As Collection
```

```
    Set AnnotationDataText = AnnotationData(annotationTemp)
```

```
    Dim annotationTextIndex As Long
```

```
    For annotationTextIndex = 1 To AnnotationDataText.Count
```

```
        Call log(AnnotationDataText(annotationTextIndex), textStr)
```

```
    Next
```

```
Next
```

```
End Sub
```

```
Public Function AnnotationData(annotation As DimXpertAnnotation) As Collection
```

```
    Dim annoType As Long
```

```
    'general info
```

```
    Call GeneralInfo(annotation)
```

```
    annoType = annotation.Type
```

```
    If annoType = swDimXpertDatum Then
```

```
        Call DatumData(annotation)
```

```
    ElseIf annoType = swDimXpertGeoTol_Position Then
```

```
        Call PositionData(annotation)
```

```
    ElseIf annoType = swDimXpertGeoTol_CompositePosition Then
```

```
        Call CompositePositionData(annotation)
```

```
    ElseIf annoType = swDimXpertGeoTol_Symmetry Then
```

```

        Call SymmetryData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Concentricity Then
        Call ConcentricityData(annotation)

    ElseIf annoType = swDimXpertGeoTol_LineProfile Then
        Call LineProfileData(annotation)

    ElseIf annoType = swDimXpertGeoTol_CompositeLineProfile Then
        Call CompositeLineProfileData(annotation)

    ElseIf annoType = swDimXpertGeoTol_SurfaceProfile Then
        Call SurfaceProfileData(annotation)

    ElseIf annoType = swDimXpertGeoTol_CompositeSurfaceProfile Then
        Call CompositeSurfaceProfileData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Angularity Or annoType = swDimXpertGeoTol_Parallelism
Or annoType = swDimXpertGeoTol_Perpendicularity Then
        Call OrientationData(annotation)

    ElseIf annoType = swDimXpertGeoTol_TotalRunout Then
        Call TotalRunoutData(annotation)

    ElseIf annoType = swDimXpertGeoTol_CircularRunout Then
        Call CircularRunoutData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Flatness Then
        Call FlatnessData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Circularity Then
        Call CircularityData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Cylindricity Then
        Call CylindricityData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Straightness Then
        Call StraightnessData(annotation)

    ElseIf annoType = swDimXpertGeoTol_Tangency Then
        Call TangencyData(annotation)
    Else ' any of the dimension tolerance types
        Call DimensionToleranceData(annotation)

End If

```

```

        Set AnnotationData = strs
End Function
Private Sub Clear(strs As Collection)
    Dim n As Long
    strs.Remove (strs.Count)
    If Not strs.Count = 0 Then
        Call Clear(strs)
    End If
End Sub
Private Sub GeneralInfo(annotation As DimXpertAnnotation)
    Dim annoType As String
    Dim modelObj As Object
    Dim modelFeature As SldWorks.feature
    If Not strs.Count = 0 Then
        Call Clear(strs)
    End If

    strs.Add ("")
    strs.Add ("Name: " + annotation.Name)

    annoType = annotationTypeNameFromObject(annotation)
    strs.Add ("Type: " + annoType)
    strs.Add ("Display Entity: " + DisplayEntity(annotation))

    Set modelObj = annotation.GetModelFeature
    Set modelFeature = modelObj
    If Not (modelFeature Is Nothing) Then
        strs.Add ("ModelFeature: " + modelFeature.Name + " (" + modelFeature.GetTypeName2() +
        ")")
    End If
End Sub
Private Sub DatumData(annotation As DimXpertDatum)
    ' the datum letter
    strs.Add ("")
    strs.Add ("Datum Letter: " + annotation.Identifier)

End Sub
Private Sub PositionData(annotation As DimXpertPositionTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim boolstatus As Boolean

    strs.Add ("")

```

```

strs.Add ("Position Tolerance Compartment:")

' the shape of the tolerance zone
strs.Add (" Zone Type: " + PositionZoneType(annotation.zoneType))

' the zone vector if the tolerance zone is planar
If annotation.zoneType = swDimXpertPositionZoneType_PlanarPosition Then
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)
    strs.Add (" Direction: " + FormatVector(I, J, K))
End If

' the tolerance value
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

' the material condition modifier applied to feature
strs.Add (" Modifier: " + mcmStr(annotation.modifier))

' the projected tolerance zone when specified
boolstatus = annotation.GetProjectedZone(enabled, value)
Call FormatProjectedZone(enabled, value)

' the datum reference frame
Call DatumsStr(annotation)

```

End Sub

```
Private Sub CompositePositionData(annotation As DimXpertCompositePositionTolerance)
```

```

Dim I As Double, J As Double, K As Double
Dim enabled As Boolean, value As Double
Dim boolstatus As Boolean

```

```

strs.Add ("")
strs.Add ("Composite Position Tolerance Compartment")

```

```

' the shape of the tolerance zone
strs.Add (" Zone Type: " + PositionZoneType(annotation.zoneType))

```

```

' the zone vector when the zone is planar
If annotation.zoneType = swDimXpertPositionZoneType_PlanarPosition Then
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)
    strs.Add (" Direction: " + FormatVector(I, J, K))
End If

```

```

' the tolerance value
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

```

```

' the material condition modifier
strs.Add (" Modifier: " + mcmStr(annotation.modifier))

' the projected tolerance zone when specified
boolstatus = annotation.GetProjectedZone(enabled, value)
Call FormatProjectedZone(enabled, value)

' the datum reference frame for the pattern location
Call DatumsStr(annotation)

' the datum reference frame for the feature to feature location
strs.Add ("Composite datums:")
strs.Add (" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
strs.Add (" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True", "False"))
strs.Add (" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True", "False"))

```

End Sub

```

Private Sub SymmetryData(annotation As DimXpertSymmetryTolerance)
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    strs.Add ("")
    strs.Add ("Symmetry Tolerance Compartment")

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

    ' the material condition modifier applied to feature
    strs.Add (" Modifier: " + mcmStr(annotation.modifier))

    ' the datum reference frame
    strs.Add ("")
    Call DatumsStr(annotation)
    ' the direction of the planar zone
    strs.Add ("")
    boolstatus = annotation.GetZoneDirection(I, J, K)
    strs.Add ("Planar Zone Direction: " + FormatVector(I, J, K))

```

End Sub

```

Private Sub ConcentricityData(annotation As DimXpertConcentricityTolerance)

    strs.Add ("")
    strs.Add ("Concentricity Tolerance Compartment")

    ' the tolerance value

```

```
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
' the material condition modifier applied to feature
```

```
strs.Add (" Modifier: " + mcmStr(annotation.modifier))
```

```
' the datum reference frame
```

```
Call DatumsStr(annotation)
```

```
End Sub
```

```
Private Sub TotalRunoutData(annotation As DimXpertTolerance)
```

```
strs.Add ("")
```

```
strs.Add ("Total Runout Tolerance Compartment")
```

```
' the tolerance value
```

```
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
' the datum reference frame
```

```
Call DatumsStr(annotation)
```

```
End Sub
```

```
Private Sub CircularRunoutData(annotation As DimXpertTolerance)
```

```
strs.Add ("")
```

```
strs.Add ("Circular Runout Tolerance Compartment")
```

```
' the tolerance value
```

```
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
' the datum reference frame
```

```
Call DatumsStr(annotation)
```

```
End Sub
```

```
Private Sub LineProfileData(annotation As DimXpertLineProfileTolerance)
```

```
Dim I As Double, J As Double, K As Double
```

```
Dim boolstatus As Boolean
```

```
strs.Add ("")
```

```
strs.Add ("Line Profile Tolerance Compartment")
```

```
' the tolerance value
```

```
strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

```
' the outer (outside material) tolerance value
```

```
strs.Add (" Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))
```

```
' the vector normal to the profile zones
```

```

    strs.Add ("")
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)
    strs.Add ("Planar Zone Vector: " + FormatVector(I, J, K))

' the datum reference frame
    Call DatumsStr(annotation)

```

End Sub

```
Private Sub CompositeLineProfileData(annotation As DimXpertCompositeLineProfileTolerance)
```

```

    strs.Add ("")
    strs.Add ("Composite Line Profile Tolerance Compartment")

' the tolerance value
    strs.Add ("  Tolerance: " + FormatDouble(annotation.Tolerance))

' the outer (outside material) tolerance value
    strs.Add ("  Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))

' the vector normal to the profile zones
    strs.Add ("")
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)
    strs.Add ("Planar Zone Vector: " + FormatVector(I, J, K))

' the datum reference frame
    Call DatumsStr(annotation)

' the datum reference frame for the orientation and form
    strs.Add ("Composite Datums:")
    strs.Add ("  Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
    strs.Add ("  Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True", "False"))
    strs.Add ("  Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True", "False"))

```

End Sub

```
Private Sub SurfaceProfileData(annotation As DimXpertSurfaceProfileTolerance)
```

```

    strs.Add ("")
    strs.Add ("Surface Profile Tolerance Compartment")

' the tolerance value
    strs.Add ("  Tolerance: " + FormatDouble(annotation.Tolerance))

' the outer (outside material) tolerance value
    strs.Add ("  Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))

```

```

' the datum reference frame
Call DatumsStr(annotation)

End Sub

Private Sub CompositeSurfaceProfileData(annotation As
DimXpertCompositeSurfaceProfileTolerance)

    strs.Add ("")
    strs.Add ("Composite Surface Profile Tolerance Compartment")

    ' the tolerance value
    strs.Add (" Tolerance Upper Tier: " + FormatDouble(annotation.Tolerance))

    ' the outer tolerance value
    strs.Add (" Outer Tolerance Upper Tier: " +
FormatDouble(annotation.OuterToleranceValue))

    ' the datum reference frame for the location
    Call DatumsStr(annotation)

    ' the datum reference frame for the orientation and form
    strs.Add ("Composite Datums:")
    strs.Add (" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
    strs.Add (" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True", "False"))
    strs.Add (" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True", "False"))
End Sub

Private Sub OrientationData(annotation As DimXpertOrientationTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim annoType As Long
    Dim boolstatus As Boolean
    annoType = annotation.Type
    ' the type or orientation tolerance
    If annoType = swDimXpertGeoTol_Perpendicularity Then
        strs.Add ("Orientation Type: Perpendicularity")
    ElseIf annoType = swDimXpertGeoTol_Parallelism Then
        strs.Add ("Orientation Type: Parallelism")
    ElseIf annoType = swDimXpertGeoTol_Angularity Then
        strs.Add ("Orientation Type: Angularity")
    End If

    strs.Add ("")
    strs.Add ("Orientation Tolerance Compartment:")

    ' the shape of the tolerance zone

```

```

Select Case annotation.zoneType
Case swDimXpertOrientationZoneType_Cylindrical
    strs.Add (" Zone Type: Cylindrical")
Case swDimXpertOrientationZoneType_Planar
    strs.Add (" Zone Type: Planar")
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)
    strs.Add ("Planar Zone Vector: " + FormatVector(I, J, K))
End Select

```

```

' the tolerance value

```

```

strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

```

```

'material condition modifier applied to feature

```

```

strs.Add (" Modifier: " + mcmStr(annotation.modifier))

```

```

' the projected tolerance zone when specified

```

```

boolstatus = annotation.GetProjectedZone(enabled, value)

```

```

Call FormatProjectedZone(enabled, value)

```

```

' is tangent plane

```

```

strs.Add (" IsTangentPlane: " + IIf(annotation.IsTangentPlane, "True", "False"))

```

```

' the datum reference frame

```

```

Call DatumsStr(annotation)

```

```

End Sub

```

```

Private Sub FlatnessData(annotation As DimXpertFlatnessTolerance)

```

```

    Dim enabled As Boolean

```

```

    Dim length As Double, width As Double

```

```

    Dim I As Double, J As Double, K As Double

```

```

    Dim boolstatus As Boolean

```

```

    strs.Add ("")

```

```

    strs.Add ("Flatness Tolerance Compartment:")

```

```

' the tolerance value

```

```

strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

```

```

' the per unit area data

```

```

boolstatus = annotation.GetPerUnitArea(enabled, length, width, I, J, K)

```

```

strs.Add (" Per Unit Area: " + IIf(enabled, "True", "False"))

```

```

If enabled Then

```

```

    strs.Add (" Per Unit Length: " + FormatDouble(length))

```

```

    strs.Add (" Per Unit Width: " + FormatDouble(width))

```

```

    strs.Add (" Per Unit Direction: " + FormatVector(I, J, K))

```

End If

End Sub

```
Private Sub CircularityData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Circularity Tolerance Compartment")

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

End Sub

```
Private Sub CylindricityData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Cylindricity Tolerance Compartment")

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
```

End Sub

```
Private Sub StraightnessData(annotation As DimXpertStraightnessTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean
    Dim dist As Double
    Dim boolstatus As Boolean
    'tolerance compartment info
    strs.Add ("")
    strs.Add ("Straightness Tolerance Compartment")

    'type or shape of the tolerance zone
    Select Case annotation.zoneType
    Case swDimXpertStraightnessZoneType_Cylindrical
        strs.Add (" Zone Type: Cylindrical")
    Case swDimXpertStraightnessZoneType_PlanarMedian
        strs.Add (" Zone Type: Planar Median")
    Case swDimXpertStraightnessZoneType_Surface
        strs.Add (" Zone Type: Surface Straightness")
        boolstatus = annotation.GetPlanarZoneVector(I, J, K)
        strs.Add (" Zone Vector: " + FormatVector(I, J, K))
    End Select

    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))

    'per unit length
    boolstatus = annotation.GetPerUnitLength(enabled, dist)
```

```

    strs.Add (" Per Unit Length: " + IIf(enabled, "True", "False"))
    If enabled Then
        strs.Add (" Per Unit Length Distance: " + FormatDouble(dist))
    End If

    ' the material condition modifier
    strs.Add (" Modifier: " + mcmStr(annotation.modifier))
End Sub

Private Sub ProfileData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub SurfaceFinishData(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Surface Finish Tolerance Compartment")
    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub

Private Sub TangencyData(annotation As DimXpertTangencyTolerance)
    strs.Add ("")
    strs.Add ("Tangency Tolerance Compartment")
    strs.Add ("Origin feature: " + annotation.originFeature.Name)
    ' the tolerance value
    strs.Add (" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub

Private Sub DimensionToleranceData(annotation As DimXpertDimensionTolerance)
    Dim isAngleType As Boolean
    Dim annoType As Long
    Dim upper As Double, lower As Double
    Dim plus As Double, minus As Double
    Dim boolstatus As Boolean
    annoType = annotation.Type

    isAngleType = False

    strs.Add ("")
    strs.Add ("Dimension Tolerance Compartment")
    If annoType = swDimXpertDimTol_DistanceBetween Then
        Dim distancebetween As DimXpertDistanceBetweenDimTol
        Set distancebetween = annotation
        Call DistanceBetweenData(distancebetween)
    End If

```

```

ElseIf annoType = swDimXpertDimTol_CompositeDistanceBetween Then
    Dim compdistancebetween As DimXpertCompositeDistanceBetweenDimTol
    Set compdistancebetween = annotation
    Call CompositeDistanceBetweenData(compdistancebetween)

ElseIf annoType = swDimXpertDimTol_CounterBore Then
    Dim counterBore As IDimXpertCounterBoreDimTol
    Set counterBore = annotation
    If counterBore.ReferenceFeature Is Nothing Then
        str$.Add ("Reference Feature: NULL")
    Else
        str$.Add ("Reference Feature: " + counterBore.ReferenceFeature.Name)
    End If

ElseIf annoType = swDimXpertDimTol_Depth Then
    Dim depth As IDimXpertDepthDimTol
    Set depth = annotation
    If depth.ReferenceFeature Is Nothing Then
        str$.Add ("Reference Feature: NULL")
    Else
        str$.Add ("Reference Feature: " + depth.ReferenceFeature.Name)
    End If

ElseIf annoType = swDimXpertDimTol_CounterSinkDiameter Then
    Dim countersink As IDimXpertCounterSinkDiameterDimTol
    Set countersink = annotation
    If countersink.ReferenceFeature Is Nothing Then
        str$.Add ("Reference Feature: NULL")
    Else
        str$.Add ("Reference Feature: " + countersink.ReferenceFeature.Name)
    End If

ElseIf annoType = swDimXpertDimTol_ChamferDimension Then

    Select Case annotation.ChamferType
    Case swDimXpertChamferDimensionType_Angle
        str$.Add ("Chamfer Dimension Type: Angle")
        isAngleType = True
    Case swDimXpertChamferDimensionType_LinearDistance1
        str$.Add ("Chamfer Dimension Type: Distance 1")
    Case swDimXpertChamferDimensionType_LinearDistance2
        str$.Add ("Chamfer Dimension Type: Distance 2")
    End Select

```

```

ElseIf annoType = swDimXpertDimTol_AngleBetween Then
    isAngleType = True
    Dim angleBetween As IDimXpertAngleBetweenDimTol
    Set angleBetween = annotation
    ' the origin and tolerance feature
    str$.Add ("Origin Feature: " + angleBetween.OriginFeature.Name)

    ' is supplement angle
    str$.Add ("Supplement Angle: " + IIf(angleBetween.Supplement, "True", "False"))

ElseIf annoType = swDimXpertDimTol_CounterSinkAngle Then
    isAngleType = True
    Dim countersinkAngle As IDimXpertCounterSinkAngleDimTol
    Set countersinkAngle = annotation

    If countersinkAngle.ReferenceFeature Is Nothing Then
        str$.Add ("Reference Feature: NULL")
    Else
        str$.Add ("Reference Feature: " + countersinkAngle.ReferenceFeature.Name)
    End If

ElseIf annoType = swDimXpertDimTol_ConeAngle Then
    isAngleType = True
End If

' conversion for radians to degrees when dimension type is angle
Dim dbl As Double
If isAngleType Then
    dbl = 57.2957795130823
Else
    dbl = 1#
End If

' the nominal, and upper and lower limits of size of the dimension
str$.Add ("")
str$.Add ("Compute Nominal Dimension: " + FormatDouble(annotation.GetNominalValue * dbl))
boolstatus = annotation.GetUpperAndLowerLimit(upper, lower)
str$.Add ("Get Upper Limit: " + FormatDouble(upper * dbl))
str$.Add ("Get Lower Limit: " + FormatDouble(lower * dbl))

' the upper and lower tolerance value by type
Select Case annotation.DimensionType

Case swDimXpertDimTolType_BlockTolerance

```

```

        str.Add ("Dimension Type: Block Tolerance")

' block tolerance
Case swDimXpertDimTolType_BlockToleranceNoNominal
    Dim blockTols As DimXpertBlockTolerances
    Set blockTols = dimXpertPart.GetBlockTolerances

    Select Case blockTols.Type
        Case swDimXpertBlockToleranceType_ASMEInch
            str.Add ("Dimension Type: Block Tolerance No Nominal")
            If isAngleType Then
                str.Add ("Angular Block Tolerance")
            Else
                str.Add ("Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlaces, "##,##0"))
            End If
        Case swDimXpertBlockToleranceType_ISO2768
            str.Add ("Dimension Type: General Tolerance")
    End Select

Case swDimXpertDimTolType_ISOLimitsAndFits
    str.Add ("Dimension Type: Limits and Fits")
' limits and fits tolerance
Case swDimXpertDimTolType_ISOLimitsAndFitsNoNominal
    str.Add ("Dimension Type: Limits and Fits No Nominal")
    str.Add ("Limits and Fits: " + annotation.LimitsAndFitsCode)
' limit dimension
Case swDimXpertDimTolType_LimitDimension
    str.Add ("Dimension Type: Limit Dimension")
    boolstatus = annotation.GetUpperAndLowerLimit(upper, lower)
    str.Add ("Get Upper Limit: " + FormatDouble(upper * dbl))
    str.Add ("Get Lower Limit: " + FormatDouble(lower * dbl))
Case swDimXpertDimTolType_MAXTolerance
    str.Add ("Dimension Type: MAXTolerance")
Case swDimXpertDimTolType_MINTolerance
    str.Add ("Dimension Type: MINTolerance")
Case swDimXpertDimTolType_NoTolerance
    str.Add ("Dimension Type: NoTolerance")
Case swDimXpertDimTolType_PlusMinusDimension
    str.Add ("Dimension Type: Plus Minus Dimension")

' plus and minus dimension
Case swDimXpertDimTolType_PlusMinusNoNominal
    str.Add ("Dimension Type: Plus Minus No Nominal")
    boolstatus = annotation.GetPlusAndMinusTolerance(plus, minus)

```

```
    strs.Add ("Plus Tolerance: " + FormatDouble(plus * dbl))
    strs.Add ("Minus Tolerance: " + FormatDouble(minus * dbl))
```

```
End Select
```

```
End Sub
```

```
Private Sub DistanceBetweenData(annotation As DimXpertDistanceBetweenDimTol)
    Dim feature As DimXpertFeature
    Dim featureFosUsage As Long
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    ' the origin and tolerance feature along with their feature of size usage (min, max,
    center)
    boolstatus = annotation.GetOriginFeature(feature, featureFosUsage)
    strs.Add ("")
    strs.Add ("Origin Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    boolstatus = annotation.GetFeature(feature, featureFosUsage)
    strs.Add ("Tolerance Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))

    ' The direction vector
    boolstatus = annotation.GetDirectionVector(I, J, K)
    strs.Add ("")
    strs.Add ("Direction Vector: " + FormatVector(I, J, K))

```

```
End Sub
```

```
Private Sub CompositeDistanceBetweenData(annotation As
DimXpertCompositeDistanceBetweenDimTol)
    Dim feature As DimXpertFeature
    Dim featureFosUsage As Long
    Dim plus As Double, minus As Double
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    Dim blockTols As DimXpertBlockTolerances

    ' the origin and tolerance feature along with their feature of size usage (min, max,
    center)
    boolstatus = annotation.GetOriginFeature(feature, featureFosUsage)
    strs.Add ("")
    strs.Add ("Origin Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    boolstatus = annotation.GetFeature(feature, featureFosUsage)
    strs.Add ("Tolerance Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))

    ' the pattern locating feature
    boolstatus = annotation.GetIntraFeature(feature, featureFosUsage)
    strs.Add ("Pattern Locating Feature: " + feature.Name + " @ " +
FosUsage(featureFosUsage))

```

```

' The direction vector
boolstatus = annotation.GetDirectionVector(I, J, K)
strs.Add ("")
strs.Add ("Direction Vector: " + FormatVector(I, J, K))

' the upper and lower tolerance value for the pattern location by type

Select Case annotation.DimensionType
' plus and minus dimension
Case swDimXpertDimTolType_PlusMinusNoNominal
    strs.Add ("Pattern Locating Dimension Type: Plus Minus No Nominal")
    boolstatus = annotation.GetPlusAndMinusToleranceIntraFeature(plus, minus)
    strs.Add (" Plus Tolerance: " + FormatDouble(plus))
    strs.Add (" Minus Tolerance: " + FormatDouble(minus))
' block tolerance
Case swDimXpertDimTolType_BlockToleranceNoNominal

    Set blockTols = dimXpertPart.GetBlockTolerances

    Select Case blockTols.Type
    Case swDimXpertBlockToleranceType_ASMEInch
        strs.Add ("Pattern Locating Dimension Type: Block Tolerance No Nominal")
        strs.Add (" Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlaces, "##,##0"))
    Case swDimXpertBlockToleranceType_ISO2768
        strs.Add ("Pattern Locating Dimension Type: General Tolerance")
    End Select

End Select

' the upper and lower tolerance value for the feature to feature location by type
Select Case annotation.DimensionTypeIntraFeature
' plus and minus dimension
Case swDimXpertDimTolType_PlusMinusNoNominal
    strs.Add ("Feature Locating Dimension Type: Plus Minus No Nominal")
    boolstatus = annotation.GetPlusAndMinusToleranceIntraFeature(plus, minus)
    strs.Add (" Plus Tolerance: " + FormatDouble(plus))
    strs.Add (" Minus Tolerance: " + FormatDouble(minus))
' block tolerance
Case swDimXpertDimTolType_BlockToleranceNoNominal

    Set blockTols = dimXpertPart.GetBlockTolerances
    Select Case blockTols.Type

```

```

        Case swDimXpertBlockToleranceType_ASMEInch
            strs.Add ("Feature locating Dimension Type: Block Tolerance No Nominal")
            strs.Add (" Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlacesIntraFeature, "##,##0"))
        Case swDimXpertBlockToleranceType_ISO2768
            strs.Add ("Feature locating Dimension Type: General Tolerance")
        End Select
    End Select

End Sub

Private Sub DatumsStr(annotation As DimXpertTolerance)
    strs.Add ("")
    strs.Add ("Datums:")
    Call datumStr(annotation.GetPrimaryDatums(), annotation.GetPrimaryDatumModifiers(), "
Primary:")
    Call datumStr(annotation.GetSecondaryDatums(), annotation.GetSecondaryDatumModifiers(), "
Secondary:")
    Call datumStr(annotation.GetTertiaryDatums(), annotation.GetTertiaryDatumModifiers(), "
Tertiary:")

End Sub

Private Sub datumStr(dats As Variant, mods As Variant, datumOrder As String)
    Dim I As Long
    Dim str As String
    Dim mcm As Long
    If IsEmpty(dats) Then
        strs.Add (datumOrder + ": none")
        Exit Sub
    End If

    For I = LBound(dats) To UBound(dats)
        mcm = mods(I)
        str = str + " " + dats(I).Identifier + " @ " + mcmStr(mcm)
    Next I

    If StrComp(str, "") > 0 Then
        strs.Add (datumOrder + str)
    Else
        strs.Add (datumOrder + " <none>")
    End If

End Sub

' returns a string containing the height of the projected tolerance zone
Private Sub FormatProjectedZone(enabled As Boolean, height As Double)

    If enabled = True Then
        strs.Add (" Projected Zone: True")
    End If
End Sub

```

```

        str.Add (" Zone Height: " + FormatDouble(height))
Else
    str.Add (" Projected Zone: False")
End If

End Sub

Private Function mcmStr(mcm As Long) As String
    Dim str

    Select Case mcm
    Case swDimXpertMCM_LMC
        str = "LMC"
    Case swDimXpertMCM_MMC
        str = "MMC"
    Case swDimXpertMCM_NoMCM
        str = "NoMCM"
    Case swDimXpertMCM_RFS
        str = "RFS"
    End Select

    mcmStr = str
End Function

' returns a string containing the type of position tolerance zone used
Private Function PositionZoneType(typ As Long) As String
    Dim str As String

    Select Case typ
    Case swDimXpertPositionZoneType_CylindricalPosition
        str = "Cylindrical"
    Case swDimXpertPositionZoneType_PlanarPosition
        str = "Planar"
    Case swDimXpertPositionZoneType_SphericalPosition
        str = "Spherical"
    Case swDimXpertPositionZoneType_Boundary
        str = "Boundary"
    Case swDimXpertPositionZoneType_RadialPositionArc
        str = "RadialPositionArc"
    Case swDimXpertPositionZoneType_RadialPositionPlanar
        str = "RadialPositionPlanar"
    Case Else
        str = "N/A"
    End Select

    PositionZoneType = str
End Function

```

```

' returns a string containing the names of the SW display entities
Private Function DisplayEntity(annotation As DimXpertAnnotation) As String
    Dim str As String
    Dim dispEnt As Object
    Dim swAnnot As SldWorks.annotation

    'Set dispEnt = swDimXpert.GetDisplayEntity(annot)
    Set dispEnt = annotation.GetDisplayEntity

    If Not dispEnt Is Nothing Then
        If TypeOf dispEnt Is SldWorks.annotation Then
            Set swAnnot = dispEnt
            str = swAnnot.GetName
        End If
    End If

    DisplayEntity = str
End Function

' returns a string containing the feature of size usage (min, max, center)
Private Function FosUsage(value As Long) As String
    Dim str
    Select Case value
        Case swDimXpertDistanceFosUsage_Center
            str = "Center"
        Case swDimXpertDistanceFosUsage_MaximumSide
            str = "Max"
        Case swDimXpertDistanceFosUsage_MinimumSide
            str = "Min"
        Case Else
            str = "N/A"
        End Select
    FosUsage = str
End Function

Private Function FormatVector(I As Double, J As Double, K As Double) As String
    Dim str
    str = FormatDouble(I) + ", " + FormatDouble(J) + ", " + FormatDouble(K)

    FormatVector = str
End Function

Private Function FormatDouble(value As Double) As String
    Dim str

    str = Format(value, "##,##0.0000")

```

```

    FormatDouble = str
End Function
Private Function RadiansToDegrees(value As Double) As String
    Dim str

    str = Format((value * 57.2957795130823), "##,##0.00")

    RadiansToDegrees = str
End Function
Private Function annotationTypeNameFromObject(anno As DimXpertAnnotation) As String
    annotationTypeNameFromObject = annotationTypeNameFromTypeNumber(anno.Type)
End Function
Private Function annotationTypeNameFromTypeNumber(annoTypeIndex As Long) As String
    Select Case annoTypeIndex

    Case swDimXpertDimTol_DistanceBetween
        annotationTypeNameFromTypeNumber = "DistanceBetween Dim"
    Case swDimXpertDimTol_CounterBore
        annotationTypeNameFromTypeNumber = "CounterBore Dim"
    Case swDimXpertDimTol_Depth
        annotationTypeNameFromTypeNumber = "Depth Dim"
    Case swDimXpertDimTol_CounterSinkDiameter
        annotationTypeNameFromTypeNumber = "CounterSinkDiameter Dim"
    Case swDimXpertDimTol_ChamferDimension
        annotationTypeNameFromTypeNumber = "ChamferDimension Dim"
    Case swDimXpertDimTol_AngleBetween
        annotationTypeNameFromTypeNumber = "AngleBetween Dim"
    Case swDimXpertDimTol_CounterSinkAngle
        annotationTypeNameFromTypeNumber = "CounterSinkAngle Dim"
    Case swDimXpertDimTol_ConeAngle
        annotationTypeNameFromTypeNumber = "ConeAngle Dim"
    Case swDimXpertDimTol_Diameter
        annotationTypeNameFromTypeNumber = "Diameter Dim"
    Case swDimXpertDimTol_Length
        annotationTypeNameFromTypeNumber = "Length Dim"
    Case swDimXpertDimTol_Radius
        annotationTypeNameFromTypeNumber = "Radius Dim"
    Case swDimXpertDimTol_Width
        annotationTypeNameFromTypeNumber = "Width Dim"
    Case swDimXpertDimTol_CompositeDistanceBetween
        annotationTypeNameFromTypeNumber = "CompositeDistanceBetween Dim"
    Case swDimXpertDatum
        annotationTypeNameFromTypeNumber = "Datum"
    Case swDimXpertGeoTol_Position
        annotationTypeNameFromTypeNumber = "Position Tol"
    
```

```

Case swDimXpertGeoTol_CompositePosition
    annotationTypeNameFromTypeNumber = "CompositePosition Tol"
Case swDimXpertGeoTol_Symmetry
    annotationTypeNameFromTypeNumber = "Symmetry Tol"
Case swDimXpertGeoTol_Concentricity
    annotationTypeNameFromTypeNumber = "Concentricity Tol"
Case swDimXpertGeoTol_LineProfile
    annotationTypeNameFromTypeNumber = "LineProfile Tol"
Case swDimXpertGeoTol_CompositeLineProfile
    annotationTypeNameFromTypeNumber = "CompositeLineProfile Tol"
Case swDimXpertGeoTol_SurfaceProfile
    annotationTypeNameFromTypeNumber = "SurfaceProfile Tol"
Case swDimXpertGeoTol_CompositeSurfaceProfile
    annotationTypeNameFromTypeNumber = "CompositeSurfaceProfile Tol"
Case swDimXpertGeoTol_Angularity
    annotationTypeNameFromTypeNumber = "Angularity Tol"
Case swDimXpertGeoTol_Parallelism
    annotationTypeNameFromTypeNumber = "Parallelism Tol"
Case swDimXpertGeoTol_Perpendicularity
    annotationTypeNameFromTypeNumber = "Perpendicularity Tol"
Case swDimXpertGeoTol_TotalRunout
    annotationTypeNameFromTypeNumber = "TotalRunout Tol"
Case swDimXpertGeoTol_CircularRunout
    annotationTypeNameFromTypeNumber = "CircularRunout Tol"
Case swDimXpertGeoTol_Flatness
    annotationTypeNameFromTypeNumber = "Flatness Tol"
Case swDimXpertGeoTol_Circularity
    annotationTypeNameFromTypeNumber = "Circularity Tol"
Case swDimXpertGeoTol_Cylindricity
    annotationTypeNameFromTypeNumber = "Cylindricity Tol"
Case swDimXpertGeoTol_Straightness
    annotationTypeNameFromTypeNumber = "Straightness Tol"
Case swDimXpertGeoTol_Tangency
    annotationTypeNameFromTypeNumber = "Tangency Tol"
Case Else
    annotationTypeNameFromTypeNumber = "<unknown> " & CStr(annoTypeIndex)

```

```

End Select

```

```

End Function

```

Get DimXpert Tolerance6 Example (VB.NET)

This example shows how to build a part and get attributes for the following DimXpert annotations:

- * Composite surface profile geometric tolerance
- * Tangency geometric tolerance

```
' -----  
' Preconditions:  
' 1. Open public_documents\samples\tutorial\cosmosxpress\aw_anchor_plate.sldprt.  
' 2. Open the DimXpert toolbar from View > Toolbars.  
'  
' Create a composite surface profile geometric tolerance:  
' 1. Click Datum on the DimXpert tool bar.  
' 2. Click a top face of the part.  
' 3. Click to place Datum A.  
' 4. Click a back face of the part.  
' 5. Click to place Datum B.  
' 6. Click a side face of the part.  
' 7. Click to place Datum C.  
' 8. Click Geometric Tolerance of the DimXpert tool bar.  
' 9. In the Geometric Tolerance Properties dialog:  
' a. Select Surface Profile from the Symbol dropdown.  
' b. Enter A in Primary, B in Secondary, and  
'    in Tertiary.  
' c. In the second row, select Profile of Surface from the Symbol dropdown.  
' d. In the second row, type A in Primary.  
' e. Select the Composite frame check box.  
' f. Click the front curve of the hook.  
' g. Click to place the annotation.  
' h. Click OK to close the Geometric Tolerance Properties dialog.  
' 10. In the DimXpertManager tab of the Management Panel, expand Cylinder1.  
' 11. Observe the following Dimxpert annotation: Composite Surface Profile1  
'  
' Create tangency geometric tolerances:  
' 1. Click Auto Dimension Scheme.  
' 2. Select all feature filters.  
' 3. Click on the green check mark to accept the settings.  
' 4. Observe several tangency tolerance annotations.  
'  
' Before running this macro:  
' 1. Ensure that the SolidWorks.Interop.swdimxpert.dll interop assembly  
'    is loaded (right-click on the project name in the Project Explorer,
```

```
' click Add Reference > .NET tab).  
' 2. Ensure that the Microsoft Scripting Runtime library is loaded  
' (right-click on the project name in the Project Explorer, click  
' Add Reference > COM tab).  
,
```

```
' Postconditions:
```

```
' 1. Writes the output to c:\temp\dimXpertInfo.txt.  
' 2. Inspect the Immediate Window.  
,
```

```
' NOTE: Because the part is used elsewhere, do not save changes.  
' -----
```

```
Imports SolidWorks.Interop.sldworks  
Imports SolidWorks.Interop.swdimxpert  
Imports SolidWorks.Interop.swconst  
Imports System  
Imports System.Diagnostics  
Imports Scripting  
Partial Class SolidWorksMacro  
    Dim strs As New Collection  
    Dim boolstatus As Boolean  
    Dim dimXpertPart As DimXpertPart  
    Dim i As Double  
    Dim j As Double  
    Dim k As Double  
    Sub Main()  
        Dim swModelDoc As IModelDoc2  
        swModelDoc = swApp.ActiveDoc  
        If swModelDoc Is Nothing Then  
            Exit Sub  
        End If  
        Dim fso As New Scripting.FileSystemObject()  
        Dim f As Scripting.File  
        Dim textStr As Scripting.TextStream  
        textStr = fso.CreateTextFile("c:\temp\dimXpertInfo.txt")  
        f = fso.GetFile("c:\temp\dimXpertInfo.txt")  
        'textStr = f.OpenAsTextStream(2, -2)  
        If textStr Is Nothing Then  
            Debug.Print("Error creating temp file.")  
            Exit Sub  
        End If  
        Call log("Starting DimXpert log...", textStr)  
        Call retrieve_info_text(swApp, textStr)  
        textStr.Close()  
    End Sub  
    Private Sub log(ByVal text As String, ByVal textStr As Scripting.TextStream)
```

```

        Debug.Print(text)
        textStr.WriteLine(text)
    End Sub

    Private Sub retrieve_info_text(ByVal swapp As SldWorks, ByVal textStr As TextStream)
        Dim dimXpertMgr As SolidWorks.Interop.sldworks.DimXpertManager
        dimXpertMgr =
swapp.IActiveDoc2.Extension.DimXpertManager(swapp.IActiveDoc2.IGetActiveConfiguration().Name,
True)

        Call log("Model: " & swapp.IActiveDoc2.GetPathName, textStr)
        Dim dimXpertPartObj As DimXpertPart
        dimXpertPartObj = dimXpertMgr.DimXpertPart
        dimXpertPart = dimXpertPartObj
        Dim vAnnotations As Object
        vAnnotations = dimXpertPart.GetAnnotations()
        Call log("-----", textStr)
        Call log("Annotations...", textStr)
        Call log("-----", textStr)
        Dim annotationTemp As DimXpertAnnotation
        Dim annotationIndex As Long
        For annotationIndex = 0 To UBound(vAnnotations)
            annotationTemp = vAnnotations(annotationIndex)
            Dim AnnotationDataText As Collection
            AnnotationDataText = AnnotationData(annotationTemp)
            Dim annotationTextIndex As Long
            For annotationTextIndex = 1 To AnnotationDataText.Count
                Call log(AnnotationDataText(annotationTextIndex), textStr)
            Next
        Next
    End Sub

    Public Function AnnotationData(ByVal annotation As DimXpertAnnotation) As Collection
        Dim annoType As Long
        'general info
        Call GeneralInfo(annotation)
        annoType = annotation.Type
        If annoType = swDimXpertAnnotationType_e.swDimXpertDatum Then
            Call DatumData(annotation)
        ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Position Then
            Call PositionData(annotation)
        ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositePosition Then
            Call CompositePositionData(annotation)
        ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Symmetry Then
            Call SymmetryData(annotation)
        ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Concentricity Then
            Call ConcentricityData(annotation)
        ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_LineProfile Then

```

```

        Call LineProfileData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositeLineProfile
Then
        Call CompositeLineProfileData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_SurfaceProfile Then
        Call SurfaceProfileData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositeSurfaceProfile
Then
        Call CompositeSurfaceProfileData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Angularity Or annoType
= swDimXpertAnnotationType_e.swDimXpertGeoTol_Parallelism Or annoType =
swDimXpertAnnotationType_e.swDimXpertGeoTol_Perpendicularity Then
        Call OrientationData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_TotalRunout Then
        Call TotalRunoutData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_CircularRunout Then
        Call CircularRunoutData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Flatness Then
        Call FlatnessData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Circularity Then
        Call CircularityData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Cylindricity Then
        Call CylindricityData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Straightness Then
        Call StraightnessData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Tangency Then
        Call TangencyData(annotation)
    Else ' any of the dimension tolerance types
        Call DimensionToleranceData(annotation)
    End If
    AnnotationData = strs
End Function
Private Sub Clear(ByVal strs As Collection)
    strs.Remove(strs.Count)
    If Not strs.Count = 0 Then
        Call Clear(strs)
    End If
End Sub
Private Sub GeneralInfo(ByVal annotation As DimXpertAnnotation)
    Dim annoType As String
    Dim modelObj As Feature
    If Not strs.Count = 0 Then
        Call Clear(strs)
    End If
    strs.Add("")
    strs.Add("Name: " + annotation.Name)

```

```

annoType = annotationTypeNameFromObject(annotation)
strs.Add("Type: " + annoType)
strs.Add("Display Entity: " + DisplayEntity(annotation))
modelObj = annotation.GetModelFeature()
If Not (modelObj Is Nothing) Then
    strs.Add("ModelFeature: " + modelObj.Name + " (" + modelObj.GetTypeName2() + ")")
End If
End Sub

Private Sub DatumData(ByVal annotation As DimXpertDatum)
    ' the datum letter
    strs.Add("")
    strs.Add("Datum Letter: " + annotation.Identifier)
End Sub

Private Sub PositionData(ByVal annotation As DimXpertPositionTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim boolstatus As Boolean
    strs.Add("")
    strs.Add("Position Tolerance Compartment:")
    ' the shape of the tolerance zone
    strs.Add(" Zone Type: " + PositionZoneType(annotation.ZoneType))
    ' the zone vector if the tolerance zone is planar
    If annotation.ZoneType =
swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_PlanarPosition Then
        boolstatus = annotation.GetPlanarZoneVector(I, J, K)
        strs.Add(" Direction: " + FormatVector(I, J, K))
    End If
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the material condition modifier applied to feature
    strs.Add(" Modifier: " + mcmStr(annotation.Modifier))
    ' the projected tolerance zone when specified
    boolstatus = annotation.GetProjectedZone(enabled, value)
    Call FormatProjectedZone(enabled, value)
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub CompositePositionData(ByVal annotation As DimXpertCompositePositionTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim boolstatus As Boolean
    strs.Add("")
    strs.Add("Composite Position Tolerance Compartment")
    ' the shape of the tolerance zone
    strs.Add(" Zone Type: " + PositionZoneType(annotation.ZoneType))

```

```

        ' the zone vector when the zone is planar
        If annotation.ZoneType =
swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_PlanarPosition Then
            boolstatus = annotation.GetPlanarZoneVector(I, J, K)
            strs.Add(" Direction: " + FormatVector(I, J, K))
        End If
        ' the tolerance value
        strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
        ' the material condition modifier
        strs.Add(" Modifier: " + mcmStr(annotation.Modifier))
        ' the projected tolerance zone when specified
        boolstatus = annotation.GetProjectedZone(enabled, value)
        Call FormatProjectedZone(enabled, value)
        ' the datum reference frame for the pattern location
        Call DatumsStr(annotation)
        ' the datum reference frame for the feature to feature location
        strs.Add("Composite datums:")
        strs.Add(" Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
        strs.Add(" Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True",
"False"))
        strs.Add(" Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True",
"False"))
    End Sub
    Private Sub SymmetryData(ByVal annotation As DimXpertSymmetryTolerance)
        Dim I As Double, J As Double, K As Double
        Dim boolstatus As Boolean
        strs.Add("")
        strs.Add("Symmetry Tolerance Compartment")
        ' the tolerance value
        strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
        ' the material condition modifier applied to feature
        strs.Add(" Modifier: " + mcmStr(annotation.Modifier))
        ' the datum reference frame
        strs.Add("")
        Call DatumsStr(annotation)
        ' the direction of the planar zone
        strs.Add("")
        boolstatus = annotation.GetZoneDirection(I, J, K)
        strs.Add("Planar Zone Direction: " + FormatVector(I, J, K))
    End Sub
    Private Sub ConcentricityData(ByVal annotation As DimXpertConcentricityTolerance)
        strs.Add("")
        strs.Add("Concentricity Tolerance Compartment")
        ' the tolerance value
        strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
        ' the material condition modifier applied to feature

```

```

        strs.Add("  Modifier: " + mcmStr(annotation.Modifier))
        ' the datum reference frame
        Call DatumsStr(annotation)
End Sub

Private Sub TotalRunoutData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Total Runout Tolerance Compartment")
    ' the tolerance value
    strs.Add("  Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub CircularRunoutData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Circular Runout Tolerance Compartment")
    ' the tolerance value
    strs.Add("  Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub LineProfileData(ByVal annotation As DimXpertLineProfileTolerance)
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    strs.Add("")
    strs.Add("Line Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add("  Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the outer (outside material) tolerance value
    strs.Add("  Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))
    ' the vector normal to the profile zones
    strs.Add("")
    boolstatus = annotation.GetPlanarZoneVector(I, J, K)
    strs.Add("Planar Zone Vector: " + FormatVector(I, J, K))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub CompositeLineProfileData(ByVal annotation As
DimXpertCompositeLineProfileTolerance)
    strs.Add("")
    strs.Add("Composite Line Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add("  Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the outer (outside material) tolerance value
    strs.Add("  Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))
    ' the vector normal to the profile zones

```

```

    strs.Add("")
    boolstatus = annotation.GetPlanarZoneVector(i, j, k)
    strs.Add("Planar Zone Vector: " + FormatVector(i, j, k))
    ' the datum reference frame
    Call DatumsStr(annotation)
    ' the datum reference frame for the orientation and form
    strs.Add("Composite Datums:")
    strs.Add("  Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
    strs.Add("  Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True",
"False"))
    strs.Add("  Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True",
"False"))
End Sub

Private Sub SurfaceProfileData(ByVal annotation As DimXpertSurfaceProfileTolerance)
    strs.Add("")
    strs.Add("Surface Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add("  Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the outer (outside material) tolerance value
    strs.Add("  Outer Tolerance: " + FormatDouble(annotation.OuterToleranceValue))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub

Private Sub CompositeSurfaceProfileData(ByVal annotation As
DimXpertCompositeSurfaceProfileTolerance)
    strs.Add("")
    strs.Add("Composite Surface Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add("  Tolerance Upper Tier: " + FormatDouble(annotation.Tolerance))
    ' the outer tolerance value
    strs.Add("  Outer Tolerance Upper Tier: " +
FormatDouble(annotation.OuterToleranceValue))
    ' the datum reference frame for the location
    Call DatumsStr(annotation)
    ' the datum reference frame for the orientation and form
    strs.Add("Composite Datums:")
    strs.Add("  Repeat Primary: " + IIf(annotation.PrimaryInLowerTier, "True", "False"))
    strs.Add("  Repeat Secondary: " + IIf(annotation.SecondaryInLowerTier, "True",
"False"))
    strs.Add("  Repeat Tertiary: " + IIf(annotation.TertiaryInLowerTier, "True",
"False"))
End Sub

Private Sub OrientationData(ByVal annotation As DimXpertOrientationTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean, value As Double
    Dim annoType As Long
    annoType = annotation.Type

```

```

' the type or orientation tolerance
If annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Perpendicularity Then
    strs.Add("Orientation Type: Perpendicularity")
ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Parallelism Then
    strs.Add("Orientation Type: Parallelism")
ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertGeoTol_Angularity Then
    strs.Add("Orientation Type: Angularity")
End If
strs.Add("")
strs.Add("Orientation Tolerance Compartment:")
' the shape of the tolerance zone
Select Case annotation.ZoneType
    Case swDimXpertOrientationZoneType_e.swDimXpertOrientationZoneType_Cylindrical
        strs.Add(" Zone Type: Cylindrical")
    Case swDimXpertOrientationZoneType_e.swDimXpertOrientationZoneType_Planar
        strs.Add(" Zone Type: Planar")
        boolstatus = annotation.GetPlanarZoneVector(I, J, K)
        strs.Add("Planar Zone Vector: " + FormatVector(I, J, K))
End Select
' the tolerance value
strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
'material condition modifier applied to feature
strs.Add(" Modifier: " + mcmStr(annotation.Modifier))
' the projected tolerance zone when specified
boolstatus = annotation.GetProjectedZone(enabled, value)
Call FormatProjectedZone(enabled, value)
' is tangent plane
strs.Add(" IsTangentPlane: " + IIf(annotation.IsTangentPlane, "True", "False"))
' the datum reference frame
Call DatumsStr(annotation)
End Sub

Private Sub FlatnessData(ByVal annotation As DimXpertFlatnessTolerance)
    Dim enabled As Boolean
    Dim length As Double, width As Double
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    strs.Add("")
    strs.Add("Flatness Tolerance Compartment:")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the per unit area data
    boolstatus = annotation.GetPerUnitArea(enabled, length, width, I, J, K)
    strs.Add(" Per Unit Area: " + IIf(enabled, "True", "False"))
    If enabled Then
        strs.Add(" Per Unit Length: " + FormatDouble(length))
    End If
End Sub

```

```

        strs.Add(" Per Unit Width: " + FormatDouble(width))
        strs.Add(" Per Unit Direction: " + FormatVector(I, J, K))
    End If
End Sub

Private Sub CircularityData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Circularity Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub

Private Sub CylindricityData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Cylindricity Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub

Private Sub StraightnessData(ByVal annotation As DimXpertStraightnessTolerance)
    Dim I As Double, J As Double, K As Double
    Dim enabled As Boolean
    Dim dist As Double
    Dim boolstatus As Boolean
    'tolerance compartment info
    strs.Add("")
    strs.Add("Straightness Tolerance Compartment")
    'type or shape of the tolerance zone
    Select Case annotation.ZoneType
        Case swDimXpertStraightnessZoneType_e.swDimXpertStraightnessZoneType_Cylindrical
            strs.Add(" Zone Type: Cylindrical")
        Case swDimXpertStraightnessZoneType_e.swDimXpertStraightnessZoneType_PlanarMedian
            strs.Add(" Zone Type: Planar Median")
        Case swDimXpertStraightnessZoneType_e.swDimXpertStraightnessZoneType_Surface
            strs.Add(" Zone Type: Surface Straightness")
            boolstatus = annotation.GetPlanarZoneVector(I, J, K)
            strs.Add(" Zone Vector: " + FormatVector(I, J, K))
    End Select
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    'per unit length
    boolstatus = annotation.GetPerUnitLength(enabled, dist)
    strs.Add(" Per Unit Length: " + IIf(enabled, "True", "False"))
    If enabled Then
        strs.Add(" Per Unit Length Distance: " + FormatDouble(dist))
    End If
    ' the material condition modifier
    strs.Add(" Modifier: " + mcmStr(annotation.Modifier))

```

```

End Sub
Private Sub ProfileData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Profile Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
    ' the datum reference frame
    Call DatumsStr(annotation)
End Sub
Private Sub SurfaceFinishData(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Surface Finish Tolerance Compartment")
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub
Private Sub TangencyData(ByVal annotation As DimXpertTangencyTolerance)
    strs.Add("")
    strs.Add("Tangency Tolerance Compartment")
    strs.Add("Origin feature: " + annotation.OriginFeature.Name)
    ' the tolerance value
    strs.Add(" Tolerance: " + FormatDouble(annotation.Tolerance))
End Sub
Private Sub DimensionToleranceData(ByVal annotation As DimXpertDimensionTolerance)
    Dim isAngleType As Boolean
    Dim annoType As Long
    Dim upper As Double, lower As Double
    Dim plus As Double, minus As Double
    Dim boolstatus As Boolean
    annoType = annotation.Type
    isAngleType = False
    strs.Add("")
    strs.Add("Dimension Tolerance Compartment")
    If annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_DistanceBetween Then
        Call DistanceBetweenData(annotation)
    ElseIf annoType =
swDimXpertAnnotationType_e.swDimXpertDimTol_CompositeDistanceBetween Then
        Call CompositeDistanceBetweenData(annotation)
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_CounterBore Then
        If annotation.ReferenceFeature Is Nothing Then
            strs.Add("Reference Feature: NULL")
        Else
            strs.Add("Reference Feature: " + annotation.ReferenceFeature.Name)
        End If
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_Depth Then
        If annotation.ReferenceFeature Is Nothing Then

```

```

        strs.Add("Reference Feature: NULL")
    Else
        strs.Add("Reference Feature: " + annotation.ReferenceFeature.Name)
    End If
Then
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_CounterSinkDiameter
        If annotation.ReferenceFeature Is Nothing Then
            strs.Add("Reference Feature: NULL")
        Else
            strs.Add("Reference Feature: " + annotation.ReferenceFeature.Name)
        End If
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_ChamferDimension Then
        Dim chamferAnno As IDimXpertChamferDimTol
        chamferAnno = annotation
        Select Case chamferAnno.ChamferType
            Case swDimXpertChamferDimensionType_e.swDimXpertChamferDimensionType_Angle
                strs.Add("Chamfer Dimension Type: Angle")
                isAngleType = True
            Case
                swDimXpertChamferDimensionType_e.swDimXpertChamferDimensionType_LinearDistance1
                strs.Add("Chamfer Dimension Type: Distance 1")
            Case
                swDimXpertChamferDimensionType_e.swDimXpertChamferDimensionType_LinearDistance2
                strs.Add("Chamfer Dimension Type: Distance 2")
        End Select
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_AngleBetween Then
        isAngleType = True
        ' the origin and tolerance feature
        strs.Add("Origin Feature: " + annotation.OriginFeature.Name)
        ' is supplement angle
        strs.Add("Supplement Angle: " + IIf(annotation.Supplement, "True", "False"))
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_CounterSinkAngle Then
        isAngleType = True
        If annotation.ReferenceFeature Is Nothing Then
            strs.Add("Reference Feature: NULL")
        Else
            strs.Add("Reference Feature: " + annotation.ReferenceFeature.Name)
        End If
    ElseIf annoType = swDimXpertAnnotationType_e.swDimXpertDimTol_ConeAngle Then
        isAngleType = True
    End If
    ' conversion for radians to degrees when dimension type is angle
    Dim dbl As Double
    If isAngleType Then
        dbl = 57.2957795130823
    Else

```

```

        dbl = 1.0#
End If
' the nominal, and upper and lower limits of size of the dimension
strs.Add("")
strs.Add("Compute Nominal Dimension: " + FormatDouble(annotation.GetNominalValue *
dbl))
boolstatus = annotation.GetUpperAndLowerLimit(upper, lower)
strs.Add("Get Upper Limit: " + FormatDouble(upper * dbl))
strs.Add("Get Lower Limit: " + FormatDouble(lower * dbl))
' the upper and lower tolerance value by type
Select Case annotation.DimensionType
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_BlockTolerance
        strs.Add("Dimension Type: Block Tolerance")
        ' block tolerance
    Case
swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_BlockToleranceNoNominal
        Dim blockTols As DimXpertBlockTolerances
        blockTols = dimXpertPart.GetBlockTolerances
        Select Case blockTols.Type
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ASMEInch
                strs.Add("Dimension Type: Block Tolerance No Nominal")
                If isAngleType Then
                    strs.Add("Angular Block Tolerance")
                Else
                    strs.Add("Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlaces, "##,##0"))
                End If
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ISO2768
                strs.Add("Dimension Type: General Tolerance")
        End Select
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_ISOLimitsAndFits
        strs.Add("Dimension Type: Limits and Fits")
        ' limits and fits tolerance
    Case
swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_ISOLimitsAndFitsNoNominal
        strs.Add("Dimension Type: Limits and Fits No Nominal")
        strs.Add("Limits and Fits: " + annotation.LimitsAndFitsCode)
        ' limit dimension
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_LimitDimension
        strs.Add("Dimension Type: Limit Dimension")
        boolstatus = annotation.GetUpperAndLowerLimit(upper, lower)
        strs.Add("Get Upper Limit: " + FormatDouble(upper * dbl))
        strs.Add("Get Lower Limit: " + FormatDouble(lower * dbl))
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_MAXTolerance
        strs.Add("Dimension Type: MAXTolerance")
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_MINTolerance

```

```

        strs.Add("Dimension Type: MINTolerance")
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_NoTolerance
        strs.Add("Dimension Type: NoTolerance")
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_PlusMinusDimension
        strs.Add("Dimension Type: Plus Minus Dimension")
        ' plus and minus dimension
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_PlusMinusNoNominal
        strs.Add("Dimension Type: Plus Minus No Nominal")
        boolstatus = annotation.GetPlusAndMinusTolerance(plus, minus)
        strs.Add("Plus Tolerance: " + FormatDouble(plus * dbl))
        strs.Add("Minus Tolerance: " + FormatDouble(minus * dbl))
    End Select
End Sub

Private Sub DistanceBetweenData(ByVal annotation As DimXpertDistanceBetweenDimTol)
    Dim feature As DimXpertFeature
    Dim featureFosUsage As Long
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    feature = Nothing
    ' the origin and tolerance feature along with their feature of size usage (min, max,
center)
    boolstatus = annotation.GetOriginFeature(feature, featureFosUsage)
    strs.Add("")
    strs.Add("Origin Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    boolstatus = annotation.GetFeature(feature, featureFosUsage)
    strs.Add("Tolerance Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    ' The direction vector
    boolstatus = annotation.GetDirectionVector(I, J, K)
    strs.Add("")
    strs.Add("Direction Vector: " + FormatVector(I, J, K))
End Sub

Private Sub CompositeDistanceBetweenData(ByVal annotation As
DimXpertCompositeDistanceBetweenDimTol)
    Dim feature As DimXpertFeature
    Dim featureFosUsage As Long
    Dim plus As Double, minus As Double
    Dim I As Double, J As Double, K As Double
    Dim boolstatus As Boolean
    feature = Nothing
    ' the origin and tolerance feature along with their feature of size usage (min, max,
center)
    boolstatus = annotation.GetOriginFeature(feature, featureFosUsage)
    strs.Add("")
    strs.Add("Origin Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))
    boolstatus = annotation.GetFeature(feature, featureFosUsage)
    strs.Add("Tolerance Feature: " + feature.Name + " @ " + FosUsage(featureFosUsage))

```

```

' the pattern locating feature
boolstatus = annotation.GetIntraFeature(feature, featureFosUsage)
strs.Add("Pattern Locating Feature: " + feature.Name + " @ " +
FosUsage(featureFosUsage))
' The direction vector
boolstatus = annotation.GetDirectionVector(I, J, K)
strs.Add("")
strs.Add("Direction Vector: " + FormatVector(I, J, K))
' the upper and lower tolerance value for the pattern location by type
Dim dimTol As IDimXpertDimensionTolerance
dimTol = annotation
Select Case dimTol.DimensionType
    ' plus and minus dimension
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_PlusMinusNoNominal
        dimTol.GetPlusAndMinusTolerance(plus, minus)
        strs.Add("Pattern Locating Dimension Type: Plus Minus No Nominal")
        strs.Add(" Plus Tolerance: " + FormatDouble(plus))
        strs.Add(" Minus Tolerance: " + FormatDouble(minus))
    ' block tolerance
    Case
swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_BlockToleranceNoNominal
        Dim blockTols As DimXpertBlockTolerances
        blockTols = dimXpertPart.GetBlockTolerances
        Select Case blockTols.Type
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ASMEInch
                strs.Add("Pattern Locating Dimension Type: Block Tolerance No
Nominal")
                strs.Add(" Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlaces, "##,##0"))
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ISO2768
                strs.Add("Pattern Locating Dimension Type: General Tolerance")
        End Select
    End Select
End Select
' the upper and lower tolerance value for the feature to feature location by type
Select Case annotation.DimensionTypeIntraFeature
    ' plus and minus dimension
    Case swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_PlusMinusNoNominal
        strs.Add("Feature Locating Dimension Type: Plus Minus No Nominal")
        boolstatus = annotation.GetPlusAndMinusToleranceIntraFeature(plus, minus)
        strs.Add(" Plus Tolerance: " + FormatDouble(plus))
        strs.Add(" Minus Tolerance: " + FormatDouble(minus))
    ' block tolerance
    Case
swDimXpertDimensionToleranceType_e.swDimXpertDimTolType_BlockToleranceNoNominal
        Dim blockTols As DimXpertBlockTolerances
        blockTols = dimXpertPart.GetBlockTolerances

```

```

        Select Case blockTols.Type
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ASMEInch
                strs.Add("Feature locating Dimension Type: Block Tolerance No
Nominal")
                strs.Add("  Block Tolerance Decimal Places: " +
Format(annotation.BlockToleranceDecimalPlacesIntraFeature, "##,##0"))
            Case swDimXpertBlockToleranceType_e.swDimXpertBlockToleranceType_ISO2768
                strs.Add("Feature locating Dimension Type: General Tolerance")
        End Select
    End Select
End Sub

Private Sub DatumsStr(ByVal annotation As DimXpertTolerance)
    strs.Add("")
    strs.Add("Datums:")
    Call datumStr(annotation.GetPrimaryDatums(), annotation.GetPrimaryDatumModifiers(), "
Primary:")
    Call datumStr(annotation.GetSecondaryDatums(),
annotation.GetSecondaryDatumModifiers(), "  Secondary:")
    Call datumStr(annotation.GetTertiaryDatums(), annotation.GetTertiaryDatumModifiers(),
"    Tertiary:")
End Sub

Private Sub datumStr(ByVal dats As Object, ByVal mods As Object, ByVal datumOrder As
String)
    Dim I As Long
    Dim str As String
    Dim mcm As Long
    If IsNothing(dats) Then
        Exit Sub
    End If
    str = ""
    For I = LBound(dats) To UBound(dats)
        mcm = mods(I)
        str = str + "  " + dats(I).Identifier + " @ " + mcmStr(mcm)
    Next I
    If StrComp(str, "") > 0 Then
        strs.Add(datumOrder + str)
    Else
        strs.Add(datumOrder + " <none>")
    End If
End Sub

' returns a string containing the heith of the projected tolerance zone
Private Sub FormatProjectedZone(ByVal enabled As Boolean, ByVal height As Double)
    If enabled = True Then
        strs.Add("  Projected Zone:  True")
        strs.Add("  Zone Height: " + FormatDouble(height))
    Else
        strs.Add("  Projected Zone:  False")
    End If
End Sub

```

```

    End If
End Sub
Private Function mcmStr(ByVal mcm As Long) As String
    Dim str As String
    str = ""
    Select Case mcm
        Case swDimXpertMaterialConditionModifier_e.swDimXpertMCM_LMC
            str = "LMC"
        Case swDimXpertMaterialConditionModifier_e.swDimXpertMCM_MMC
            str = "MMC"
        Case swDimXpertMaterialConditionModifier_e.swDimXpertMCM_NoMCM
            str = "NoMCM"
        Case swDimXpertMaterialConditionModifier_e.swDimXpertMCM_RFS
            str = "RFS"
    End Select
    mcmStr = str
End Function
' returns a string containing the type of position tolerance zone used
Private Function PositionZoneType(ByVal typ As Long) As String
    Dim str As String
    Select Case typ
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_CylindricalPosition
            str = "Cylindrical"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_PlanarPosition
            str = "Planar"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_SphericalPosition
            str = "Spherical"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_Boundary
            str = "Boundary"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_RadialPositionArc
            str = "RadialPositionArc"
        Case swDimXpertPositionZoneType_e.swDimXpertPositionZoneType_RadialPositionPlanar
            str = "RadialPositionPlanar"
        Case Else
            str = "N/A"
    End Select
    PositionZoneType = str
End Function
' returns a string containing the names of the SW display entities
Private Function DisplayEntity(ByVal annotation As DimXpertAnnotation) As String
    Dim str As String
    Dim dispEnt As Object
    Dim swAnnot As SolidWorks.Interop.sldworks.Annotation
    str = ""
    'Set dispEnt = swDimXpert.GetDisplayEntity(annot)

```

```

    dispEnt = annotation.GetDisplayEntity()
    If Not dispEnt Is Nothing Then
        If TypeOf dispEnt Is SolidWorks.Interop.sldworks.Annotation Then
            swAnnot = dispEnt
            str = swAnnot.GetName
        End If
    End If
    DisplayEntity = str
End Function
' returns a string containing the feature of size usage (min, max, center)
Private Function FosUsage(ByVal value As Long) As String
    Dim str As String
    Select Case value
        Case swDimXpertDistanceFosUsage_e.swDimXpertDistanceFosUsage_Center
            str = "Center"
        Case swDimXpertDistanceFosUsage_e.swDimXpertDistanceFosUsage_MaximumSide
            str = "Max"
        Case swDimXpertDistanceFosUsage_e.swDimXpertDistanceFosUsage_MinimumSide
            str = "Min"
        Case Else
            str = "N/A"
    End Select
    FosUsage = str
End Function
Private Function FormatVector(ByVal I As Double, ByVal J As Double, ByVal K As Double) As String
    Dim str As String
    str = FormatDouble(I) + ", " + FormatDouble(J) + ", " + FormatDouble(K)
    FormatVector = str
End Function
Private Function FormatDouble(ByVal value As Double) As String
    Dim str As String
    str = Format(value, "##,##0.0000")
    FormatDouble = str
End Function
Private Function RadiansToDegrees(ByVal value As Double) As String
    Dim str As String
    str = Format((value * 57.2957795130823), "##,##0.00")
    RadiansToDegrees = str
End Function
Private Function annotationTypeNameFromObject(ByVal anno As DimXpertAnnotation) As String
    annotationTypeNameFromObject = annotationTypeNameFromTypeNumber(anno.Type)
End Function
Private Function annotationTypeNameFromTypeNumber(ByVal annoTypeIndex As Long) As String
    Select Case annoTypeIndex

```

Case swDimXpertAnnotationType_e.swDimXpertDimTol_DistanceBetween
annotationTypeNameFromTypeNumber = "DistanceBetween Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_CounterBore
annotationTypeNameFromTypeNumber = "CounterBore Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_Depth
annotationTypeNameFromTypeNumber = "Depth Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_CounterSinkDiameter
annotationTypeNameFromTypeNumber = "CounterSinkDiameter Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_ChamferDimension
annotationTypeNameFromTypeNumber = "ChamferDimension Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_AngleBetween
annotationTypeNameFromTypeNumber = "AngleBetween Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_CounterSinkAngle
annotationTypeNameFromTypeNumber = "CounterSinkAngle Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_ConeAngle
annotationTypeNameFromTypeNumber = "ConeAngle Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_Diameter
annotationTypeNameFromTypeNumber = "Diameter Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_Length
annotationTypeNameFromTypeNumber = "Length Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_Radius
annotationTypeNameFromTypeNumber = "Radius Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_Width
annotationTypeNameFromTypeNumber = "Width Dim"

Case swDimXpertAnnotationType_e.swDimXpertDimTol_CompositeDistanceBetween
annotationTypeNameFromTypeNumber = "CompositeDistanceBetween Dim"

Case swDimXpertAnnotationType_e.swDimXpertDatum
annotationTypeNameFromTypeNumber = "Datum"

Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Position
annotationTypeNameFromTypeNumber = "Position Tol"

Case swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositePosition
annotationTypeNameFromTypeNumber = "CompositePosition Tol"

Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Symmetry
annotationTypeNameFromTypeNumber = "Symmetry Tol"

Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Concentricity
annotationTypeNameFromTypeNumber = "Concentricity Tol"

Case swDimXpertAnnotationType_e.swDimXpertGeoTol_LineProfile
annotationTypeNameFromTypeNumber = "LineProfile Tol"

Case swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositeLineProfile
annotationTypeNameFromTypeNumber = "CompositeLineProfile Tol"

Case swDimXpertAnnotationType_e.swDimXpertGeoTol_SurfaceProfile
annotationTypeNameFromTypeNumber = "SurfaceProfile Tol"

Case **swDimXpertAnnotationType_e.swDimXpertGeoTol_CompositeSurfaceProfile**
annotationTypeNameFromTypeNumber = "CompositeSurfaceProfile Tol"

Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Angularity

```

        annotationTypeNameFromTypeNumber = "Angularity Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Parallelism
    annotationTypeNameFromTypeNumber = "Parallelism Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Perpendicularity
    annotationTypeNameFromTypeNumber = "Perpendicularity Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_TotalRunout
    annotationTypeNameFromTypeNumber = "TotalRunout Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_CircularRunout
    annotationTypeNameFromTypeNumber = "CircularRunout Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Flatness
    annotationTypeNameFromTypeNumber = "Flatness Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Circularity
    annotationTypeNameFromTypeNumber = "Circularity Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Cylindricity
    annotationTypeNameFromTypeNumber = "Cylindricity Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Straightness
    annotationTypeNameFromTypeNumber = "Straightness Tol"
Case swDimXpertAnnotationType_e.swDimXpertGeoTol_Tangency
    annotationTypeNameFromTypeNumber = "Tangency Tol"
Case Else
    annotationTypeNameFromTypeNumber = "<unknown> " & CStr(annoTypeIndex)
End Select
End Function
Public swApp As SldWorks
End Class

```