

SOLIDWORKS DimXpert API (.NET) — Reference

(1/8): namespace hierarchy

IDimXpertChamferDimTol

SOLIDWORKS API Documentation (converted from CHM)

namespace_hierarchy (Type)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

SolidWorks.Interop.swdimxpert Namespace Inheritance Hierarchy

[See Also](#)



Inheritance Hierarchy

System.Object



See Also

[SolidWorks.Interop.swdimxpert Assembly.](#)

IDimXpertAngleBetweenCircularDimTol (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertAngleBetweenCircularDimTol Interface

Allows you to access DimXpert angle-between circular dimension tolerances.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertAngleBetweenCircularDimTol

Visual Basic (Usage)  Copy Code

Dim instance As [IDimXpertAngleBetweenCircularDimTol](#)

C#

public interface IDimXpertAngleBetweenCircularDimTol

C++/CLI

public interface class IDimXpertAngleBetweenCircularDimTol

 Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenCircularDimTol](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)

[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)

[IDimXpertPart::GetAnnotation](#)

[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)

[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertAngleBetweenCircularDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)



SolidWorks.Interop.swdimxpert Namespace : IDimXpertAngleBetweenCircularDimTol Interface

The following tables list the members exposed by [IDimXpertAngleBetweenCircularDimTol](#).

 Public Properties

Name	Description
 CenterFeature	Gets the DimXpert center feature for this DimXpert angle-between circular dimension tolerance.
 OriginFeature	Gets the DimXpert origin feature for this DimXpert angle-between circular dimension tolerance.
 Supplement	Gets whether to evaluate the supplement angle for this DimXpert angle-between circular dimension tolerance.

[Top](#)

 Public Methods

Name	Description
 GetActPlaneVector	Gets the actual plane vector for computing the angle of this DimXpert angle-between circular dimension tolerance.
 GetNomPlaneVector	Gets the nominal plane vector for computing the angle of this DimXpert angle-between circular dimension tolerance.



[Top](#)

See Also

[IDimXpertAngleBetweenCircularDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertAngleBetweenCircularDimTol Interface Methods

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertAngleBetweenCircularDimTol Interface

For a list of all members of this type, see [IDimXpertAngleBetweenCircularDimTol members](#).

Public Methods

Name	Description
GetActPlaneVector	Gets the actual plane vector for computing the angle of this DimXpert angle-between circular dimension tolerance.
GetNomPlaneVector	Gets the nominal plane vector for computing the angle of this DimXpert angle-between circular dimension tolerance.

[Top](#)

See Also

[IDimXpertAngleBetweenCircularDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertAngleBetweenCircularDimTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertAngleBetweenCircularDimTol Interface

For a list of all members of this type, see [IDimXpertAngleBetweenCircularDimTol members](#).

Public Properties

Name	Description
CenterFeature	Gets the DimXpert center feature for this DimXpert angle-between circular dimension tolerance.
OriginFeature	Gets the DimXpert origin feature for this DimXpert angle-between circular dimension tolerance.
Supplement	Gets whether to evaluate the supplement angle for this DimXpert angle-between circular dimension tolerance.

[Top](#)

See Also

[IDimXpertAngleBetweenCircularDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

CenterFeature Property (IDimXpertAngleBetweenCircularDimTol)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAngleBetweenCircularDimTol Interface](#) : CenterFeature Property (IDimXpertAngleBetweenCircularDimTol)

Gets the DimXpert center feature for this DimXpert angle-between circular dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property CenterFeature As DimXpertFeature

Visual Basic (Usage)



```
Dim instance As IDimXpertAngleBetweenCircularDimTol  
Dim value As DimXpertFeature
```

```
value = instance.CenterFeature
```

C#

```
DimXpertFeature CenterFeature {get;}
```

C++/CLI

```
property DimXpertFeature^ CenterFeature {  
    DimXpertFeature^ get();  
}
```

Property Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenCircularDimTol::CenterFeature](#).

See Also

[IDimXpertAngleBetweenCircularDimTol Interface](#)

[IDimXpertAngleBetweenCircularDimTol Members](#)

Availability

SOLIDWORKS 2026 SP02, Revision Number 34.2

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetActPlaneVector Method (IDimXpertAngleBetweenCircularDimTol)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAngleBetweenCircularDimTol Interface](#) : GetActPlaneVector Method (IDimXpertAngleBetweenCircularDimTol)

Gets the actual plane vector for computing the angle of this DimXpert angle-between circular dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetActPlaneVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAngleBetweenCircularDimTol  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetActPlaneVector(I, J, K)
```

C#

```
System.bool GetActPlaneVector(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetActPlaneVector(  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

I
I component of the direction vector
J
J component of the direction vector
K
K component of the direction vector

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenCircularDimTol::GetActPlaneVector](#).

See Also

[IDimXpertAngleBetweenCircularDimTol Interface](#)
[IDimXpertAngleBetweenCircularDimTol Members](#)

Availability

SOLIDWORKS 2026 SP02, Revision Number 34.2

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNomPlaneVector Method (IDimXpertAngleBetweenCircularDimTol)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAngleBetweenCircularDimTol Interface](#) : GetNomPlaneVector Method (IDimXpertAngleBetweenCircularDimTol)

Gets the nominal plane vector for computing the angle of this DimXpert angle-between circular dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNomPlaneVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAngleBetweenCircularDimTol  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNomPlaneVector(I, J, K)
```

C#

```
System.bool GetNomPlaneVector(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNomPlaneVector(  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

I
I component of the direction vector
J
J component of the direction vector
K

K component of the direction vector

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenCircularDimTol::GetNomPlaneVector](#).

See Also

[IDimXpertAngleBetweenCircularDimTol Interface](#)
[IDimXpertAngleBetweenCircularDimTol Members](#)

Availability

SOLIDWORKS 2026 SP02, Revision Number 34.2

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

OriginFeature Property (IDimXpertAngleBetweenCircularDimTol)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAngleBetweenCircularDimTol Interface](#) : OriginFeature Property (IDimXpertAngleBetweenCircularDimTol)

Gets the DimXpert origin feature for this DimXpert angle-between circular dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OriginFeature As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAngleBetweenCircularDimTol  
Dim value As DimXpertFeature  
  
value = instance.OriginFeature
```

C#

```
DimXpertFeature OriginFeature {get;}
```

C++/CLI

```
property DimXpertFeature^ OriginFeature {  
    DimXpertFeature^ get();  
}
```

Property Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenCircularDimTol::OriginFeature](#).

See Also

[IDimXpertAngleBetweenCircularDimTol Interface](#)
[IDimXpertAngleBetweenCircularDimTol Members](#)

Availability

SOLIDWORKS 2026 SP02, Revision Number 34.2

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Supplement Property (IDimXpertAngleBetweenCircularDimTol)

[See Also](#)



.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Supplement As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertAngleBetweenCircularDimTol  
Dim value As System.Boolean  
  
value = instance.Supplement
```

C#

```
System.bool Supplement {get;}
```

C++/CLI

```
property System.bool Supplement {  
    System.bool get();  
}
```

Property Value

True to evaluate the supplement angle (default); false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenCircularDimTol::Supplement](#).

See Also

[IDimXpertAngleBetweenCircularDimTol Interface](#)
[IDimXpertAngleBetweenCircularDimTol Members](#)

Availability

SOLIDWORKS 2026 SP02, Revision Number 34.2

IDimXpertAngleBetweenDimTol (Type)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertAngleBetweenDimTol Interface

[See Also](#) [Members](#) [Example](#)

SolidWorks.Interop.swdimxpert Namespace : IDimXpertAngleBetweenDimTol Interface

Allows you to access DimXpert angle-between dimension tolerances.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

[-] .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertAngleBetweenDimTol

Visual Basic (Usage)

Dim instance As [IDimXpertAngleBetweenDimTol](#)

C#

public interface IDimXpertAngleBetweenDimTol

C++/CLI

public interface class IDimXpertAngleBetweenDimTol

[-] Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenDimTol](#).

[-] Example

[Get and Set Location Dimension Example \(C#\)](#)
[Get and Set Location Dimension Example \(VB.NET\)](#)
[Get and Set Location Dimension Example \(VBA\)](#)
[Get DimXpert Tolerance4 Example \(VBA\)](#)
[Get DimXpert Tolerance4 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

[-] Remarks

You can access more general dimension tolerance information using [IDimXpertDimensionTolerance](#).

[-] Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::IGetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::IGetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::IGetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

[-] See Also

[IDimXpertAngleBetweenDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertAngleBetweenDimTol Interface Members

[See Also](#) [Properties](#) [Methods](#)

SolidWorks.Interop.swdimxpert Namespace : IDimXpertAngleBetweenDimTol Interface

The following tables list the members exposed by [IDimXpertAngleBetweenDimTol](#).

[-] Public Properties

Name	Description
 OriginFeature	Gets the DimXpert origin feature for this DimXpert angle-between dimension tolerance.
 Supplement	Gets whether to evaluate the supplement angle for this DimXpert angle-between dimension tolerance.

[Top](#)

 Public Methods

Name	Description
 GetDirectionVector	Gets the direction vector for computing the angle of this DimXpert angle-between dimension tolerance.

[Top](#)

 See Also

[IDimXpertAngleBetweenDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertAngleBetweenDimTol Interface Methods
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : [IDimXpertAngleBetweenDimTol Interface](#)

For a list of all members of this type, see [IDimXpertAngleBetweenDimTol members](#).

 Public Methods

Name	Description
 GetDirectionVector	Gets the direction vector for computing the angle of this DimXpert angle-between dimension tolerance.

[Top](#)

 See Also

[IDimXpertAngleBetweenDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertAngleBetweenDimTol Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : [IDimXpertAngleBetweenDimTol Interface](#)

For a list of all members of this type, see [IDimXpertAngleBetweenDimTol members](#).

 Public Properties

Name	Description
 OriginFeature	Gets the DimXpert origin feature for this DimXpert angle-between dimension tolerance.
 Supplement	Gets whether to evaluate the supplement angle for this DimXpert angle-between dimension tolerance.

[Top](#)

 See Also

[IDimXpertAngleBetweenDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetDirectionVector Method (IDimXpertAngleBetweenDimTol)
[See Also](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAngleBetweenDimTol Interface](#) : [GetDirectionVector Method \(IDimXpertAngleBetweenDimTol\)](#)
Gets the direction vector for computing the angle of this DimXpert angle-between dimension tolerance.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionVector( _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAngleBetweenDimTol
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetDirectionVector(I, J, K)
```

C#

```
System.bool GetDirectionVector(
    out System.double I,
    out System.double J,
    out System.double K
)
```

C++/CLI

```
System.bool GetDirectionVector(
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)
```

Parameters

I
I component of the direction vector
J
J component of the direction vector
K
K component of the direction vector

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenDimTol::GetDirectionVector](#).

See Also

[IDimXpertAngleBetweenDimTol Interface](#)
[IDimXpertAngleBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

OriginFeature Property (IDimXpertAngleBetweenDimTol)
[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAngleBetweenDimTol Interface](#) : OriginFeature Property (IDimXpertAngleBetweenDimTol)

Gets the DimXpert origin feature for this DimXpert angle-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OriginFeature As DimXpertFeature
```

```
Dim instance As IDimXpertAngleBetweenDimTol
Dim value As DimXpertFeature

value = instance.OriginFeature
```

C#

```
DimXpertFeature OriginFeature {get;}
```

C++/CLI

```
property DimXpertFeature^ OriginFeature {
    DimXpertFeature^ get();
}
```

Property Value

[IDimXpertFeature](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenDimTol::OriginFeature](#).

 Example

[Get and Set Location Dimension Example \(C#\)](#)
[Get and Set Location Dimension Example \(VB.NET\)](#)
[Get and Set Location Dimension Example \(VBA\)](#)
[Get DimXpert Tolerance4 Example \(VBA\)](#)
[Get DimXpert Tolerance4 Example \(VB.NET\)](#)

 See Also

[IDimXpertAngleBetweenDimTol Interface](#)
[IDimXpertAngleBetweenDimTol Members](#)

 Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Supplement Property (IDimXpertAngleBetweenDimTol)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAngleBetweenDimTol Interface](#) : Supplement Property (IDimXpertAngleBetweenDimTol)
 Gets whether to evaluate the supplement angle for this DimXpert angle-between dimension tolerance.

 .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Supplement As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDimXpertAngleBetweenDimTol
Dim value As System.Boolean

value = instance.Supplement
```

C#

```
System.bool Supplement {get;}
```

C++/CLI

```
property System.bool Supplement {
    System.bool get();
}
```

}

Property Value

True to evaluate the supplement angle (default); false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertAngleBetweenDimTol::Supplement](#).

Example

[Get and Set Location Dimension Example \(C#\)](#)
[Get and Set Location Dimension Example \(VB.NET\)](#)
[Get and Set Location Dimension Example \(VBA\)](#)
[Get DimXpert Tolerance4 Example \(VBA\)](#)
[Get DimXpert Tolerance4 Example \(VB.NET\)](#)

See Also

[IDimXpertAngleBetweenDimTol Interface](#)
[IDimXpertAngleBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertAnnotation (Type)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertAnnotation Interface

[See Also](#) [Members](#) [Example](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertAnnotation Interface

Allows you to access DimXpert annotations on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertAnnotation

Visual Basic (Usage)

Dim instance As [IDimXpertAnnotation](#)

C#

public interface IDimXpertAnnotation

C++/CLI

public interface class IDimXpertAnnotation

 Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation](#).

 Example

[Get DimXpert Tolerance Example \(VBA\)](#)

[Get DimXpert Tolerance Example \(VB.NET\)](#)

[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

This interface is the base class for three types of annotation interface: [IDimXpertTolerance](#), [IDimXpertDimensionTolerance](#), and [IDimXpertDatum](#). Use the [IDimXpertAnnotation::Type](#) property to find out which specific interface is needed to acquire more information for a given DimXpert annotation type.

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)

[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)

[IDimXpertGtol::Annotation](#)

[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)

[IDimXpertPart::GetAnnotation](#)

[IDimXpertPart::InsertGtol](#)

[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertAnnotation Members](#)

[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertAnnotation Interface

The following tables list the members exposed by [IDimXpertAnnotation](#).

Public Properties

Name	Description
 Feature	Gets the DimXpert feature to which this DimXpert annotation is applied.
 Name	Gets the name of this DimXpert annotation.
 Type	Gets the type of this DimXpert annotation.

[Top](#)

Public Methods

Name	Description
 GetAppliedAnnotationCount	Gets the number of annotations applied to this DimXpert annotation.
 GetAppliedAnnotations	Gets all of the annotations that reference this DimXpert annotation (datum).
 GetDisplayEntity	Gets the SOLIDWORKS annotation representing this DimXpert annotation.
 GetModelFeature	Gets the underlying DimXpert model feature that corresponds to this geometric, dimensioning, and tolerancing annotation.
 IGetAppliedAnnotations	Gets all of the annotations applied to this DimXpert annotation.
 IsFreeState	Gets whether this annotation is in a free state.
 IsStatistical	Gets whether this annotation is statistical.
 IsSuppressed	Gets whether the annotation is suppressed from view on the DimXpertManager tab of the Management Panel.
 IsToBeInspected	Gets whether this annotation is to be inspected.

[Top](#)

See Also

[IDimXpertAnnotation Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertAnnotation Interface Methods

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertAnnotation Interface

For a list of all members of this type, see [IDimXpertAnnotation members](#).

Public Methods

Name	Description
 GetAppliedAnnotationCount	Gets the number of annotations applied to this DimXpert annotation.
 GetAppliedAnnotations	Gets all of the annotations that reference this DimXpert annotation (datum).
 GetDisplayEntity	Gets the SOLIDWORKS annotation representing this DimXpert annotation.
 GetModelFeature	Gets the underlying DimXpert model feature that corresponds to this geometric, dimensioning, and tolerancing annotation.
 IGetAppliedAnnotations	Gets all of the annotations applied to this DimXpert annotation.
 IsFreeState	Gets whether this annotation is in a free state.
 IsStatistical	Gets whether this annotation is statistical.
 IsSuppressed	Gets whether the annotation is suppressed from view on the DimXpertManager tab of the Management Panel.
 IsToBeInspected	Gets whether this annotation is to be inspected.

[Top](#)

See Also

[IDimXpertAnnotation Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertAnnotation Interface

For a list of all members of this type, see [IDimXpertAnnotation members](#).

Public Properties

Name	Description
 Feature	Gets the DimXpert feature to which this DimXpert annotation is applied.
 Name	Gets the name of this DimXpert annotation.
 Type	Gets the type of this DimXpert annotation.

[Top](#)

 See Also

[IDimXpertAnnotation Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

Feature Property (IDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : Feature Property (IDimXpertAnnotation)

Gets the DimXpert feature to which this DimXpert annotation is applied.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property Feature As DimXpertFeature

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation
Dim value As DimXpertFeature

value = instance.Feature
```

C#

```
DimXpertFeature Feature {get;}
```

C++/CLI

```
property DimXpertFeature^ Feature {
    DimXpertFeature^ get();
}
```

Property Value

[IDimXpertFeature](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::Feature](#).

 See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

 Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetAppliedAnnotationCount Method (IDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : GetAppliedAnnotationCount Method (IDimXpertAnnotation)

Gets the number of annotations applied to this DimXpert annotation.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetAppliedAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.Integer  
  
value = instance.GetAppliedAnnotationCount()
```

C#

```
System.int GetAppliedAnnotationCount()
```

C++/CLI

```
System.int GetAppliedAnnotationCount();
```

Return Value

Number of annotations applied to this DimXpert feature

Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::GetAppliedAnnotationCount](#).

See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetAppliedAnnotations Method (IDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : GetAppliedAnnotations Method (IDimXpertAnnotation)

Gets all of the annotations that reference this DimXpert annotation (datum).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAppliedAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.Object  
  
value = instance.GetAppliedAnnotations()
```

C#

```
System.object GetAppliedAnnotations()
```

C++/CLI

```
System.Object^ GetAppliedAnnotations();
```

Return Value

Array of [IDimXpertAnnotations](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::GetAppliedAnnotations](#).

Remarks

Currently, this method works only for annotations of type [IDimXpertDatum](#).

See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetDisplayEntity Method (IDimXpertAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : GetDisplayEntity Method (IDimXpertAnnotation)

Gets the SOLIDWORKS annotation representing this DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayEntity() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.Object  
  
value = instance.GetDisplayEntity()
```

C#

```
System.Object GetDisplayEntity()
```

C++/CLI

```
System.Object^ GetDisplayEntity();
```

Return Value

[IAnnotation](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::GetDisplayEntity](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetModelFeature Method (IDimXpertAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : GetModelFeature Method (IDimXpertAnnotation)

Gets the underlying DimXpert model feature that corresponds to this geometric, dimensioning, and tolerancing annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModelFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.Object  
  
value = instance.GetModelFeature()
```

C#

```
System.Object GetModelFeature()
```

C++/CLI

```
System.Object^ GetModelFeature();
```

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::GetModelFeature](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)

[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertAnnotation Interface](#)

[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

[IGetAppliedAnnotations Method \(IDimXpertAnnotation\)](#)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : IGetAppliedAnnotations Method (IDimXpertAnnotation)

Gets all of the annotations applied to this DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAppliedAnnotations( _  
    ByVal Count As System.Integer _  
) As DimXpertAnnotation
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim Count As System.Integer  
Dim value As DimXpertAnnotation
```

```
value = instance.IGetAppliedAnnotations(Count)
```

C#

```
DimXpertAnnotation IGetAppliedAnnotations(  
    System.int Count  
)
```

C++/CLI

```
DimXpertAnnotation^ IGetAppliedAnnotations(  
& System.int Count  
)
```

Parameters

Count
Number of applied annotations

Return Value

- in-process, unmanaged C++: Pointer to an array of [IDimXpertAnnotation](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

See [In-process Methods](#) for details about this type of method.

Before calling this method, call [IDimXpertAnnotation::GetAppliedAnnotationCount](#) to get the value for the Count parameter.

See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IsFreeState Method (IDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : IsFreeState Method (IDimXpertAnnotation)

Gets whether this annotation is in a free state.

.NET Syntax

Visual Basic (Declaration)

```
Function IsFreeState() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.Boolean
```

```
value = instance.IsFreeState()
```

C#

```
System.bool IsFreeState()
```

C++/CLI

```
System.bool IsFreeState();
```

Return Value

True if the tolerance is in a free state; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::IsFreeState](#).

Remarks

This tolerance modifier is set by clicking the F option at the top of the Geometric Tolerance Properties dialog (invoked from the Geometric Tolerance icon on the DimXpert tool bar).

See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

IsStatistical Method (IDimXpertAnnotation)

[See Also](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertAnnotation Interface](#) : IsStatistical Method (IDimXpertAnnotation)

Gets whether this annotation is statistical.

.NET Syntax

Visual Basic (Declaration)

```
Function IsStatistical() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.Boolean  
  
value = instance.IsStatistical()
```

C#

```
System.bool IsStatistical()
```

C++/CLI

```
System.bool IsStatistical();
```

Return Value

True if the tolerance is statistical; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::IsStatistical](#).

Remarks

This tolerance modifier is set by clicking the ST option at the top of the Geometric Tolerance Properties dialog (invoked from the Geometric Tolerance icon on the DimXpert tool bar).

See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IsSuppressed Method (IDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : IsSuppressed Method (IDimXpertAnnotation)

Gets whether the annotation is suppressed from view on the DimXpertManager tab of the Management Panel.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSuppressed() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.Boolean  
  
value = instance.IsSuppressed()
```

C#

```
System.bool IsSuppressed()
```

C++/CLI

```
System.bool IsSuppressed();
```

Return Value

True if the annotation is suppressed; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::IsSuppressed](#).

See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IsToBeInspected Method (IDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : IsToBeInspected Method (IDimXpertAnnotation)

Gets whether this annotation is to be inspected.

.NET Syntax

Visual Basic (Declaration)

```
Function IsToBeInspected() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.Boolean  
  
value = instance.IsToBeInspected()
```

C#

```
System.bool IsToBeInspected()
```

C++/CLI

```
System.bool IsToBeInspected();
```

Return Value

True if to be inspected; false otherwise



Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::IsToBeInspected](#).



Remarks

This tolerance modifier is set by clicking the second option from the right on the Dimension Text section of the DimXpert Properties manager.



See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)



Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Name Property (IDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : Name Property (IDimXpertAnnotation)

Gets the name of this DimXpert annotation.



.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

Property Value

Name of this annotation



Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::Name](#).



See Also

[IDimXpertAnnotation Interface](#)
[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Type Property (IDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAnnotation Interface](#) : Type Property (IDimXpertAnnotation)

Gets the type of this DimXpert annotation.

Visual Basic Syntax

Visual Basic (Declaration)

ReadOnly Property Type As [swDimXpertAnnotationType_e](#)

Visual Basic (Usage)



```
Dim instance As IDimXpertAnnotation
Dim value As swDimXpertAnnotationType\_e

value = instance.Type
```

C#

```
swDimXpertAnnotationType\_e Type {get;}
```

C++/CLI

```
property swDimXpertAnnotationType\_e Type {
    swDimXpertAnnotationType\_e get();
}
```

Property Value

Type of this DimXpert annotation as defined in [swDimXpertAnnotationType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertAnnotation::Type](#).

See Also

[IDimXpertAnnotation Interface](#)

[IDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertAutoDimSchemeOption (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertAutoDimSchemeOption Interface

Allows you to get and set Auto Dimension Scheme options.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertAutoDimSchemeOption

Visual Basic (Usage) 

Dim instance As [IDimXpertAutoDimSchemeOption](#)

C#

public interface IDimXpertAutoDimSchemeOption

C++/CLI

public interface class IDimXpertAutoDimSchemeOption

 Visual Basic for Applications (VBA) Syntax

See [DimXpertAutoDimSchemeOption](#).

 Example

[Auto Dimension Scheme Example \(C#\)](#)
[Auto Dimension Scheme Example \(VB.NET\)](#)
[Auto Dimension Scheme Example \(VBA\)](#)

 Remarks

When implemented as-is, this interface sets properties to default values.

 Accessors

[IDimXpertPart::GetAutoDimSchemeOption](#)

 See Also

[IDimXpertAutoDimSchemeOption Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertAutoDimSchemeOption Interface

The following tables list the members exposed by [IDimXpertAutoDimSchemeOption](#).

 Public Properties

Name	Description
 FeatureFilters	Gets and sets a feature filter bitmask for the Auto Dimension Scheme.
 PartType	Gets and sets the type of part to dimension.
 PatternType	Gets and sets the type of pattern to dimension.
 PolarPatternHoleCount	Gets and sets the number of holes to dimension in the polar pattern.
 ScopeAllFeature	Gets and sets whether to dimension all features.

 ToleranceType	Gets and sets the type of tolerance to dimension.
--	---

[Top](#)

 See Also

[IDimXpertAutoDimSchemeOption Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertAutoDimSchemeOption Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertAutoDimSchemeOption Interface

For a list of all members of this type, see [IDimXpertAutoDimSchemeOption members](#).

 Public Properties

Name	Description
 FeatureFilters	Gets and sets a feature filter bitmask for the Auto Dimension Scheme.
 PartType	Gets and sets the type of part to dimension.
 PatternType	Gets and sets the type of pattern to dimension.
 PolarPatternHoleCount	Gets and sets the number of holes to dimension in the polar pattern.
 ScopeAllFeature	Gets and sets whether to dimension all features.
 ToleranceType	Gets and sets the type of tolerance to dimension.

[Top](#)

 See Also

[IDimXpertAutoDimSchemeOption Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

FeatureFilters Property (IDimXpertAutoDimSchemeOption)
[See Also](#) [Example](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAutoDimSchemeOption Interface](#) : FeatureFilters Property (IDimXpertAutoDimSchemeOption)

Gets and sets a feature filter [bitmask](#) for the Auto Dimension Scheme.

 .NET Syntax

Visual Basic (Declaration)	
Property FeatureFilters As System.Integer	
Visual Basic (Usage)	 Copy Code
<pre>Dim instance As IDimXpertAutoDimSchemeOption Dim value As System.Integer instance.FeatureFilters = value value = instance.FeatureFilters</pre>	
C#	
<pre>System.int FeatureFilters {get; set;}</pre>	
C++/CLI	
<pre>property System.int FeatureFilters { System.int get(); void set (& System.int value); }</pre>	

Property Value

[Bitmask](#) of values as defined in [swDimXpertFeatureFilters e](#); default is all features or 8191.

Visual Basic for Applications (VBA) Syntax

See [DimXpertAutoDimSchemeOption::FeatureFilters](#).

Example

[Auto Dimension Scheme Example \(C#\)](#)
[Auto Dimension Scheme Example \(VB.NET\)](#)
[Auto Dimension Scheme Example \(VBA\)](#)

Remarks

This API is in force only when [IDimXpertAutoDimSchemeOption::ScopeAllFeature](#) is set to true.

See Also

[IDimXpertAutoDimSchemeOption Interface](#)
[IDimXpertAutoDimSchemeOption Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

PartType Property (IDimXpertAutoDimSchemeOption)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAutoDimSchemeOption Interface](#) : PartType Property (IDimXpertAutoDimSchemeOption)

Gets and sets the type of part to dimension.

.NET Syntax

Visual Basic (Declaration)

Property PartType As System.Integer

Visual Basic (Usage)



```
Dim instance As IDimXpertAutoDimSchemeOption  
Dim value As System.Integer  
  
instance.PartType = value  
value = instance.PartType
```

C#

```
System.int PartType {get; set;}
```

C++/CLI

```
property System.int PartType {  
    System.int get();  
    void set ( & System.int value);  
}
```

Property Value

Part type as defined in [swDimXpertAutoDimSchemePartType_e](#); default is swDimXpertAutoDimSchemePartType_Prismatic

Visual Basic for Applications (VBA) Syntax

See [DimXpertAutoDimSchemeOption::PartType](#).

Example

[Auto Dimension Scheme Example \(C#\)](#)
[Auto Dimension Scheme Example \(VB.NET\)](#)
[Auto Dimension Scheme Example \(VBA\)](#)

See Also

[IDimXpertAutoDimSchemeOption Interface](#)
[IDimXpertAutoDimSchemeOption Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

PatternType Property (IDimXpertAutoDimSchemeOption)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAutoDimSchemeOption Interface](#) : PatternType Property (IDimXpertAutoDimSchemeOption)

Gets and sets the type of pattern to dimension.

.NET Syntax

Visual Basic (Declaration)

Property PatternType As System.Integer

Visual Basic (Usage)



```
Dim instance As IDimXpertAutoDimSchemeOption
Dim value As System.Integer

instance.PatternType = value
value = instance.PatternType
```

C#

```
System.int PatternType {get; set;}
```

C++/CLI

```
property System.int PatternType {
    System.int get();
    void set ( & System.int value);
}
```

Property Value

Pattern type as defined in [swDimXpertAutoDimSchemePatternType_e](#); default is swDimXpertAutoDimSchemePatternType_Linear

Visual Basic for Applications (VBA) Syntax

See [DimXpertAutoDimSchemeOption::PatternType](#).

Example

[Auto Dimension Scheme Example \(C#\)](#)
[Auto Dimension Scheme Example \(VB.NET\)](#)
[Auto Dimension Scheme Example \(VBA\)](#)

See Also

[IDimXpertAutoDimSchemeOption Interface](#)
[IDimXpertAutoDimSchemeOption Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

PolarPatternHoleCount Property (IDimXpertAutoDimSchemeOption)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAutoDimSchemeOption Interface](#) : PolarPatternHoleCount Property (IDimXpertAutoDimSchemeOption)

Gets and sets the number of holes to dimension in the polar pattern.

.NET Syntax

Visual Basic (Declaration)

Property PolarPatternHoleCount As System.Integer

Visual Basic (Usage)



```
Dim instance As IDimXpertAutoDimSchemeOption  
Dim value As System.Integer  
  
instance.PolarPatternHoleCount = value  
value = instance.PolarPatternHoleCount
```

C#

```
System.int PolarPatternHoleCount {get; set;}
```

C++/CLI

```
property System.int PolarPatternHoleCount {  
    System.int get();  
    void set ( & System.int value);  
}
```

Property Value

Number of holes to dimension in the polar pattern; default is 5

Visual Basic for Applications (VBA) Syntax

See [DimXpertAutoDimSchemeOption::PolarPatternHoleCount](#).

Example

[Auto Dimension Scheme Example \(C#\)](#)
[Auto Dimension Scheme Example \(VB.NET\)](#)
[Auto Dimension Scheme Example \(VBA\)](#)

See Also

[IDimXpertAutoDimSchemeOption Interface](#)
[IDimXpertAutoDimSchemeOption Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

ScopeAllFeature Property (IDimXpertAutoDimSchemeOption)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAutoDimSchemeOption Interface](#) : ScopeAllFeature Property (IDimXpertAutoDimSchemeOption)

Gets and sets whether to dimension all features.

.NET Syntax

Visual Basic (Declaration)

Property ScopeAllFeature As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertAutoDimSchemeOption  
Dim value As System.Boolean
```

```
instance.ScopeAllFeature = value  
value = instance.ScopeAllFeature
```

C#

```
System.bool ScopeAllFeature {get; set;}
```

C++/CLI

```
property System.bool ScopeAllFeature {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

Property Value

True to dimension all features (default), false to dimension only selected features

Visual Basic for Applications (VBA) Syntax

See [DimXpertAutoDimSchemeOption::ScopeAllFeature](#).

Example

[Auto Dimension Scheme Example \(C#\)](#)
[Auto Dimension Scheme Example \(VB.NET\)](#)
[Auto Dimension Scheme Example \(VBA\)](#)

Remarks

If this API is set to false, then you can only dimension manually selected features whose selection marks are greater than 50.

If this API is set to true, then [IDimXpertAutoDimSchemeOption::FeatureFilters](#) is in force.

See Also

[IDimXpertAutoDimSchemeOption Interface](#)
[IDimXpertAutoDimSchemeOption Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

ToleranceType Property (IDimXpertAutoDimSchemeOption)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertAutoDimSchemeOption Interface](#) : ToleranceType Property (IDimXpertAutoDimSchemeOption)

Gets and sets the type of tolerance to dimension.

.NET Syntax

Visual Basic (Declaration)

```
Property ToleranceType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimXpertAutoDimSchemeOption  
Dim value As System.Integer
```

```
instance.ToleranceType = value
```

```
value = instance.ToleranceType
```

C#

```
System.int ToleranceType {get; set;}
```

```
property System.int ToleranceType {  
    System.int get();  
    void set ( & System.int value);  
}
```

Property Value

Type of tolerance as defined in [swDimXpertAutoDimSchemeToleranceType_e](#); default is swDimXpertAutoDimSchemeToleranceType_PlusMinus

Visual Basic for Applications (VBA) Syntax

See [DimXpertAutoDimSchemeOption::ToleranceType](#).

Example

[Auto Dimension Scheme Example \(C#\)](#)
[Auto Dimension Scheme Example \(VB.NET\)](#)
[Auto Dimension Scheme Example \(VBA\)](#)

See Also

[IDimXpertAutoDimSchemeOption Interface](#)
[IDimXpertAutoDimSchemeOption Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

IDimXpertBestfitPlaneFeature (Type)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertBestfitPlaneFeature Interface

See Also [Members](#) [Example](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertBestfitPlaneFeature Interface

Allows you to access specific information about DimXpert best fit planes on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertBestfitPlaneFeature

Visual Basic (Usage)



Dim instance As [IDimXpertBestfitPlaneFeature](#)

C#

public interface IDimXpertBestfitPlaneFeature

C++/CLI

public interface class IDimXpertBestfitPlaneFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertBestfitPlaneFeature](#).

Example

[Get DimXpert Width And Best Fit Plane Features Example \(VBA\)](#)
[Get DimXpert Width And Best Fit Plane Features Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)
[IDimXpertPart::GetFeature](#)
[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertBestfitPlaneFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertBestfitPlaneFeature Interface Members

See Also [Methods](#)



SolidWorks.Interop.swdimxpert Namespace : IDimXpertBestfitPlaneFeature Interface

The following tables list the members exposed by [IDimXpertBestfitPlaneFeature](#).

Public Methods

Name	Description
 GetNominalPlane	Gets the coordinates and vector for this DimXpert best fit plane.
 GetSubFeatureCount	Gets the number of sub-features in this DimXpert best fit plane.
 GetSubFeatures	Gets all of the sub-features of this DimXpert best fit plane.

 IGetSubFeatures	Gets all of the sub-features of this DimXpert best fit plane.
--	---

[Top](#)

 See Also

[IDimXpertBestfitPlaneFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertBestfitPlaneFeature Interface Methods
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertBestfitPlaneFeature Interface

For a list of all members of this type, see [IDimXpertBestfitPlaneFeature members](#).

 Public Methods

Name	Description
 GetNominalPlane	Gets the coordinates and vector for this DimXpert best fit plane.
 GetSubFeatureCount	Gets the number of sub-features in this DimXpert best fit plane.
 GetSubFeatures	Gets all of the sub-features of this DimXpert best fit plane.
 IGetSubFeatures	Gets all of the sub-features of this DimXpert best fit plane.

[Top](#)

 See Also

[IDimXpertBestfitPlaneFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetNominalPlane Method (IDimXpertBestfitPlaneFeature)
[See Also](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertBestfitPlaneFeature Interface](#) : GetNominalPlane Method (IDimXpertBestfitPlaneFeature)
Gets the coordinates and vector for this DimXpert best fit plane.

 .NET Syntax

Visual Basic (Declaration)	
<pre>Function GetNominalPlane(_ ByRef X As System.Double, _ ByRef Y As System.Double, _ ByRef Z As System.Double, _ ByRef I As System.Double, _ ByRef J As System.Double, _ ByRef K As System.Double _) As System.Boolean</pre>	
Visual Basic (Usage)	
<pre>Dim instance As IDimXpertBestfitPlaneFeature Dim X As System.Double Dim Y As System.Double Dim Z As System.Double Dim I As System.Double Dim J As System.Double Dim K As System.Double Dim value As System.Boolean value = instance.GetNominalPlane(X, Y, Z, I, J, K)</pre>	
C#	
<pre>System.bool GetNominalPlane(out System.double X, out System.double Y, out System.double Z, out System.double I,</pre>	

```

        out System.double J,
        out System.double K
    )

```

C++/CLI

```

System.bool GetNominalPlane(
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)

```

Parameters

X
 x coordinate of the plane
Y
 y coordinate of the plane
Z
 z coordinate of the plane
I
 i component of the direction vector of the plane
J
 j component of the direction vector of the plane
K
 k component of the direction vector of the plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertBestfitPlaneFeature::GetNominalPlane](#).

See Also

[IDimXpertBestfitPlaneFeature Interface](#)
[IDimXpertBestfitPlaneFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetSubFeatureCount Method (IDimXpertBestfitPlaneFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertBestfitPlaneFeature Interface](#) : GetSubFeatureCount Method (IDimXpertBestfitPlaneFeature)

Gets the number of sub-features in this DimXpert best fit plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSubFeatureCount() As System.Integer
```

Visual Basic (Usage)



```

Dim instance As IDimXpertBestfitPlaneFeature
Dim value As System.Integer

value = instance.GetSubFeatureCount()

```

C#

```
System.int GetSubFeatureCount()
```

C++/CLI

```
System.int GetSubFeatureCount();
```

Return Value

Number of sub-features in this DimXpert best fit plane

 Visual Basic for Applications (VBA) Syntax

See [DimXpertBestfitPlaneFeature::GetSubFeatureCount](#).

 Example

[Get DimXpert Width And Best Fit Plane Features Example \(VBA\)](#)
[Get DimXpert Width And Best Fit Plane Features Example \(VB.NET\)](#)

 See Also

[IDimXpertBestfitPlaneFeature Interface](#)
[IDimXpertBestfitPlaneFeature Members](#)

 Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

 

SolidWorks.Interop.swdimxpert Namespace > [IDimXpertBestfitPlaneFeature Interface](#) : GetSubFeatures Method (IDimXpertBestfitPlaneFeature)

Gets all of the sub-features of this DimXpert best fit plane.

 .NET Syntax

Visual Basic (Declaration)

Function GetSubFeatures() As System.Object

Visual Basic (Usage) Copy Code

```
Dim instance As IDimXpertBestfitPlaneFeature  
Dim value As System.Object  
  
value = instance.GetSubFeatures()
```

C#

```
System.object GetSubFeatures()
```

C++/CLI

```
System.Object^ GetSubFeatures();
```

Return Value

Array of [IDimXpertFeatures](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertBestfitPlaneFeature::GetSubFeatures](#).

 Example

[Get DimXpert Width And Best Fit Plane Features Example \(VBA\)](#)
[Get DimXpert Width And Best Fit Plane Features Example \(VB.NET\)](#)

 Remarks

This method returns all sub-features of this best fit plane feature. All of the sub-features returned by this method do not appear on the DimXpertManager tab of the Management Panel. Functional geometry sub-features such as planes and cylinders that represent each individual face of a part are for internal use only. These sub-features do not appear in the DimXpertManager tree. However, manufacturing sub-features that are significant for downstream machining and inspection do appear in the DimXpertManager tree.

See Also

[IDimXpertBestfitPlaneFeature Interface](#)
[IDimXpertBestfitPlaneFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

IGetSubFeatures Method (IDimXpertBestfitPlaneFeature)

[See Also](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertBestfitPlaneFeature Interface](#) : IGetSubFeatures Method (IDimXpertBestfitPlaneFeature)

Gets all of the sub-features of this DimXpert best fit plane.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSubFeatures(  
    ByVal Count As System.Integer _  
) As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertBestfitPlaneFeature  
Dim Count As System.Integer  
Dim value As DimXpertFeature  
  
value = instance.IGetSubFeatures(Count)
```

C#

```
DimXpertFeature IGetSubFeatures(  
    System.int Count  
)
```

C++/CLI

```
DimXpertFeature^ IGetSubFeatures(  
& System.int Count  
)
```

Parameters

Count

Number of sub-features of this DimXpert best fit plane feature

Return Value

- in-process, unmanaged C++; Pointer to an array of [IDimXpertFeatures](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

This method returns all sub-features of this best fit plane feature. All of the sub-features returned by this method do not appear on the DimXpertManager tab of the Management Panel. Functional geometry sub-features such as planes and cylinders that represent each individual face of a part are for internal use only. These sub-features do not appear in the DimXpertManager tree. However, manufacturing sub-features that are significant for downstream machining and inspection do appear in the DimXpertManager tree. See [In-process Methods](#) for details about this type of method.

Before calling this method, call [IDimXpertBestfitPlaneFeature::GetSubFeatureCount](#) to get the value for the Count parameter.

See Also

[IDimXpertBestfitPlaneFeature Interface](#)
[IDimXpertBestfitPlaneFeature Members](#)

IDimXpertBlockTolerances (Type)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertBlockTolerances Interface

See Also [Members](#) [Example](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertBlockTolerances Interface

Allows you to access DimXpert block tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertBlockTolerances

Visual Basic (Usage)



Dim instance As [IDimXpertBlockTolerances](#)

C#

public interface IDimXpertBlockTolerances

C++/CLI

public interface class IDimXpertBlockTolerances

Visual Basic for Applications (VBA) Syntax

See [DimXpertBlockTolerances](#).

Example

[Get DimXpert Block Tolerance Example \(VBA\)](#)
[Get DimXpert Block Tolerance Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

This interface accesses the DimXpert block tolerances that are specified in the [SOLIDWORKS System Options and Document Properties dialog \(Tools > Options > Document Properties > DimXpert\)](#).

Accessors

[IDimXpertPart::GetBlockTolerances method](#)

See Also

[IDimXpertBlockTolerances Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertBlockTolerances Interface Members

See Also [Properties](#) [Methods](#)



SolidWorks.Interop.swdimxpert Namespace : IDimXpertBlockTolerances Interface

The following tables list the members exposed by [IDimXpertBlockTolerances](#).

Public Properties

Name	Description
 Type	Gets the type of this DimXpert block tolerance.

[Top](#)

Public Methods

Name	Description
 GetISO2768PartType	Gets the ISO 2768 part type of this DimXpert block tolerance.
 GetToleranceValues	Gets block tolerance settings for a given document.

[Top](#)

 See Also

[IDimXpertBlockTolerances Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertBlockTolerances Interface Methods
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertBlockTolerances Interface

For a list of all members of this type, see [IDimXpertBlockTolerances members](#).

 Public Methods

Name	Description
 GetISO2768PartType	Gets the ISO 2768 part type of this DimXpert block tolerance.
 GetToleranceValues	Gets block tolerance settings for a given document.

[Top](#)

 See Also

[IDimXpertBlockTolerances Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertBlockTolerances Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertBlockTolerances Interface

For a list of all members of this type, see [IDimXpertBlockTolerances members](#).

 Public Properties

Name	Description
 Type	Gets the type of this DimXpert block tolerance.

[Top](#)

 See Also

[IDimXpertBlockTolerances Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetISO2768PartType Method (IDimXpertBlockTolerances)
[See Also](#) [Example](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertBlockTolerances Interface](#) : GetISO2768PartType Method (IDimXpertBlockTolerances)
Gets the ISO 2768 part type of this DimXpert block tolerance.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetISO2768PartType(  
    ByRef Type As swDimXpertISO2768PartType\_e _  
) As System.Boolean
```

Visual Basic (Usage) 

```
Dim instance As IDimXpertBlockTolerances  
Dim Type As swDimXpertISO2768PartType\_e  
Dim value As System.Boolean  
  
value = instance.GetISO2768PartType(Type)
```

C#

```
System.bool GetISO2768PartType(  
    out swDimXpertISO2768PartType\_e Type  
)
```

C++/CLI

```
System.bool GetISO2768PartType(  
& [Out] swDimXpertISO2768PartType\_e Type  
)
```

Parameters

Type

ISO 2768 part type of this DimXpert block tolerance as defined in [swDimXpertISO2768PartType_e](#)

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertBlockTolerances::GetISO2768PartType](#).

Example

[Get DimXpert Block Tolerance Example \(VBA\)](#)

[Get DimXpert Block Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertBlockTolerances Interface](#)

[IDimXpertBlockTolerances Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetToleranceValues Method (IDimXpertBlockTolerances)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertBlockTolerances Interface](#) : GetToleranceValues Method (IDimXpertBlockTolerances)

Gets block tolerance settings for a given document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetToleranceValues( _  
    ByRef Linear1 As System.Double, _  
    ByRef Linear1Prec As System.Integer, _  
    ByRef Linear2 As System.Double, _  
    ByRef Linear2Prec As System.Integer, _  
    ByRef Linear3 As System.Double, _  
    ByRef Linear3Prec As System.Integer, _  
    ByRef Angular As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertBlockTolerances  
Dim Linear1 As System.Double  
Dim Linear1Prec As System.Integer  
Dim Linear2 As System.Double  
Dim Linear2Prec As System.Integer  
Dim Linear3 As System.Double  
Dim Linear3Prec As System.Integer  
Dim Angular As System.Double
```

```
Dim value As System.Boolean
```

```
value = instance.GetToleranceValues(Linear1, Linear1Prec, Linear2, Linear2Prec, Linear3,  
Linear3Prec, Angular)
```

C#

```
System.bool GetToleranceValues(  
    out System.double Linear1,  
    out System.int Linear1Prec,  
    out System.double Linear2,  
    out System.int Linear2Prec,  
    out System.double Linear3,  
    out System.int Linear3Prec,  
    out System.double Angular  
)
```

C++/CLI

```
System.bool GetToleranceValues(  
& [Out] System.double Linear1,  
& [Out] System.int Linear1Prec,  
& [Out] System.double Linear2,  
& [Out] System.int Linear2Prec,  
& [Out] System.double Linear3,  
& [Out] System.int Linear3Prec,  
& [Out] System.double Angular  
)
```

Parameters

Linear1

Length unit dimension for Tolerance 1

Linear1Prec

Number of decimal places for Tolerance 1

Linear2

Length unit dimension for Tolerance 2

Linear2Prec

Number of decimal places for Tolerance 2

Linear3

Length unit dimension for Tolerance 3

Linear3Prec

Number of decimal places for Tolerance 3

Angular

Angular unit dimensions

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertBlockTolerances::GetToleranceValues](#).

Example

[Get DimXpert Block Tolerance Example \(VBA\)](#)

[Get DimXpert Block Tolerance Example \(VB.NET\)](#)

Remarks

This method gets the DimXpert block tolerance values that are set in the [SOLIDWORKS System Options and Document Properties dialog \(Tools > Options > Document Properties > DimXpert\)](#).

See Also

[IDimXpertBlockTolerances Interface](#)

[IDimXpertBlockTolerances Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertBlockTolerances Interface](#) : Type Property (IDimXpertBlockTolerances)

Gets the type of this DimXpert block tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Type As [swDimXpertBlockToleranceType_e](#)

Visual Basic (Usage)



```
Dim instance As IDimXpertBlockTolerances  
Dim value As swDimXpertBlockToleranceType\_e  
  
value = instance.Type
```

C#

```
swDimXpertBlockToleranceType\_e Type {get;}
```

C++/CLI

```
property swDimXpertBlockToleranceType\_e Type {  
    swDimXpertBlockToleranceType\_e get();  
}
```

Property Value

Type of this DimXpert block tolerance as defined in [swDimXpertBlockToleranceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertBlockTolerances::Type](#).

See Also

[IDimXpertBlockTolerances Interface](#)
[IDimXpertBlockTolerances Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertChamferDimTol (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertChamferDimTol Interface

Allows you to access DimXpert chamfer dimension tolerances.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertChamferDimTol

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [IDimXpertChamferDimTol](#)

C#

public interface IDimXpertChamferDimTol

C++/CLI

public interface class IDimXpertChamferDimTol

 Visual Basic for Applications (VBA) Syntax

See [DimXpertChamferDimTol](#).

 Example

[Get DimXpert Tolerance4 Example \(VBA\)](#)
[Get DimXpert Tolerance4 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general dimension tolerance information using [IDimXpertDimensionTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertChamferDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertChamferDimTol Interface

The following tables list the members exposed by [IDimXpertChamferDimTol](#).

 Public Properties

Name	Description
------	-------------



[ChamferType](#)

Gets the type of this DimXpert chamfer dimension tolerance.

[Top](#)

 [See Also](#)

[IDimXpertChamferDimTol Interface](#)

[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertChamferDimTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertChamferDimTol Interface

For a list of all members of this type, see [IDimXpertChamferDimTol members](#).

 **Public Properties**



[ChamferType](#)

Gets the type of this DimXpert chamfer dimension tolerance.

[Top](#)

 [See Also](#)

[IDimXpertChamferDimTol Interface](#)

[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

ChamferType Property (IDimXpertChamferDimTol)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertChamferDimTol Interface](#) : ChamferType Property (IDimXpertChamferDimTol)

Gets the type of this DimXpert chamfer dimension tolerance.

 **.NET Syntax**

Visual Basic (Declaration)

ReadOnly Property ChamferType As [swDimXpertChamferDimensionType_e](#)

Visual Basic (Usage)



Copy Code

```
Dim instance As IDimXpertChamferDimTol
Dim value As swDimXpertChamferDimensionType\_e
```

```
value = instance.ChamferType
```

C#

```
swDimXpertChamferDimensionType\_e ChamferType {get;}
```

C++/CLI

```
property swDimXpertChamferDimensionType\_e ChamferType {
    swDimXpertChamferDimensionType\_e get();
}
```

Property Value

Type of chamfer as defined in [swDimXpertChamferDimensionType_e](#)

 **Visual Basic for Applications (VBA) Syntax**

See [DimXpertChamferDimTol::ChamferType](#).

 **Example**

[Get DimXpert Tolerance4 Example \(VBA\)](#)

[Get DimXpert Tolerance4 Example \(VB.NET\)](#)

See Also

[IDimXpertChamferDimTol Interface](#)
[IDimXpertChamferDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0