

# SOLIDWORKS DimXpert API (.NET) — Reference

## (2/8): IDimXpertChamferFeature

### IDimXpertCompositeSurfaceProfileToleranc

SOLIDWORKS API Documentation (converted from CHM)

# IDimXpertChamferFeature (Type)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertChamferFeature Interface

See Also [Members](#) [Example](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertChamferFeature Interface

Allows you to access specific information about DimXpert chamfers on the DimXpertManager tab of the Management Panel.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

## .NET Syntax

### Visual Basic (Declaration)

Public Interface IDimXpertChamferFeature

### Visual Basic (Usage)



Dim instance As [IDimXpertChamferFeature](#)

### C#

public interface IDimXpertChamferFeature

### C++/CLI

public interface class IDimXpertChamferFeature

## Visual Basic for Applications (VBA) Syntax

See [DimXpertChamferFeature](#).

## Example

[Get DimXpert Chamfer Feature Example \(VBA\)](#)  
[Get DimXpert Chamfer Feature Example \(VB.NET\)](#)  
[Get DimXpert Features and Annotations Example \(C#\)](#)

## Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

## Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IFeature::GetSpecificFeature2](#)

## See Also

[IDimXpertChamferFeature Members](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertChamferFeature Interface Members

See Also [Properties](#)



SolidWorks.Interop.swdimxpert Namespace : IDimXpertChamferFeature Interface

The following tables list the members exposed by [IDimXpertChamferFeature](#).

## Public Properties

| Name                                                                                                            | Description                                   |
|-----------------------------------------------------------------------------------------------------------------|-----------------------------------------------|
|  <a href="#">Angle</a>       | Gets the angle of this DimXpert chamfer.      |
|  <a href="#">AngleType</a>   | Gets the angle type of this DimXpert chamfer. |
|  <a href="#">ChamferType</a> | Gets the type of this DimXpert chamfer.       |

|                                                                                                             |                                                                        |
|-------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|
|  <a href="#">Distance1</a>  | Gets the length on bevel side 1 of the selected edge, face, or vertex. |
|  <a href="#">Distance2</a> | Gets the length on bevel side 2 of the selected edge, face, or vertex. |

[Top](#)

 **See Also**

[IDimXpertChamferFeature Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

**IDimXpertChamferFeature Interface Properties**

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : [IDimXpertChamferFeature Interface](#)

For a list of all members of this type, see [IDimXpertChamferFeature members](#).

 **Public Properties**

| Name                                                                                                          | Description                                                            |
|---------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|
|  <a href="#">Angle</a>       | Gets the angle of this DimXpert chamfer.                               |
|  <a href="#">AngleType</a>   | Gets the angle type of this DimXpert chamfer.                          |
|  <a href="#">ChamferType</a> | Gets the type of this DimXpert chamfer.                                |
|  <a href="#">Distance1</a>   | Gets the length on bevel side 1 of the selected edge, face, or vertex. |
|  <a href="#">Distance2</a>   | Gets the length on bevel side 2 of the selected edge, face, or vertex. |

[Top](#)

 **See Also**

[IDimXpertChamferFeature Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

**Angle Property (IDimXpertChamferFeature)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertChamferFeature Interface](#) : Angle Property (IDimXpertChamferFeature)

Gets the angle of this DimXpert chamfer.

 **.NET Syntax**

|                                                                                                                       |                                                                                                 |
|-----------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| Visual Basic (Declaration)                                                                                            |                                                                                                 |
| ReadOnly Property Angle As System.Double                                                                              |                                                                                                 |
| Visual Basic (Usage)                                                                                                  |  Copy Code |
| <pre>Dim instance As <a href="#">IDimXpertChamferFeature</a> Dim value As System.Double  value = instance.Angle</pre> |                                                                                                 |
| C#                                                                                                                    |                                                                                                 |
| <pre>System.double Angle {get;}</pre>                                                                                 |                                                                                                 |
| C++/CLI                                                                                                               |                                                                                                 |
| <pre>property System.double Angle {     System.double get(); }</pre>                                                  |                                                                                                 |

**Property Value**

Angle in radians of this chamfer

 **Visual Basic for Applications (VBA) Syntax**

See [DimXpertChamferFeature::Angle](#).

## Example

[Get DimXpert Chamfer Feature Example \(VBA\)](#)  
[Get DimXpert Chamfer Feature Example \(VB.NET\)](#)

## See Also

[IDimXpertChamferFeature Interface](#)  
[IDimXpertChamferFeature Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

**AngleType Property (IDimXpertChamferFeature)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertChamferFeature Interface](#) : AngleType Property (IDimXpertChamferFeature)

Gets the angle type of this DimXpert chamfer.

## .NET Syntax

### Visual Basic (Declaration)

ReadOnly Property AngleType As [swDimXpertChamferAngleType\\_e](#)

### Visual Basic (Usage)



```
Dim instance As IDimXpertChamferFeature  
Dim value As swDimXpertChamferAngleType\_e  
  
value = instance.AngleType
```

### C#

```
swDimXpertChamferAngleType\_e AngleType {get;}
```

### C++/CLI

```
property swDimXpertChamferAngleType\_e AngleType {  
    swDimXpertChamferAngleType\_e get();  
}
```

### Property Value

Type of angle as defined in [swDimXpertChamferAngleType\\_e](#)

## Visual Basic for Applications (VBA) Syntax

See [DimXpertChamferFeature::AngleType](#).

## Example

[Get DimXpert Chamfer Feature Example \(VBA\)](#)  
[Get DimXpert Chamfer Feature Example \(VB.NET\)](#)

## See Also

[IDimXpertChamferFeature Interface](#)  
[IDimXpertChamferFeature Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

**ChamferType Property (IDimXpertChamferFeature)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertChamferFeature Interface](#) : ChamferType Property (IDimXpertChamferFeature)

Gets the type of this DimXpert chamfer.

#### .NET Syntax

##### Visual Basic (Declaration)

ReadOnly Property ChamferType As [swDimXpertChamferType\\_e](#)

##### Visual Basic (Usage)



```
Dim instance As IDimXpertChamferFeature  
Dim value As swDimXpertChamferType\_e  
  
value = instance.ChamferType
```

##### C#

```
swDimXpertChamferType\_e ChamferType {get;}
```

##### C++/CLI

```
property swDimXpertChamferType\_e ChamferType {  
    swDimXpertChamferType\_e get();  
}
```

#### Property Value

Type of chamfer as defined in [swDimXpertChamferType\\_e](#)

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertChamferFeature::ChamferType](#).

#### Example

[Get DimXpert Chamfer Feature Example \(VBA\)](#)  
[Get DimXpert Chamfer Feature Example \(VB.NET\)](#)

#### See Also

[IDimXpertChamferFeature Interface](#)  
[IDimXpertChamferFeature Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

**Distance1 Property (IDimXpertChamferFeature)**

See Also [Example](#)

[Send comments on this topic.](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertChamferFeature Interface](#) : Distance1 Property (IDimXpertChamferFeature)

Gets the length on bevel side 1 of the selected edge, face, or vertex.

#### .NET Syntax

##### Visual Basic (Declaration)

ReadOnly Property Distance1 As System.Double

##### Visual Basic (Usage)



```
Dim instance As IDimXpertChamferFeature  
Dim value As System.Double  
  
value = instance.Distance1
```

```
C#

System.double Distance1 {get;}
```

```
C++/CLI

property System.double Distance1 {
    System.double get();
}
```

**Property Value**  
Length of bevel on one side of the selected entity

 **Visual Basic for Applications (VBA) Syntax**

See [DimXpertChamferFeature::Distance1](#).

 **Example**

[Get DimXpert Chamfer Feature Example \(VBA\)](#)  
[Get DimXpert Chamfer Feature Example \(VB.NET\)](#)

 **See Also**

[IDimXpertChamferFeature Interface](#)  
[IDimXpertChamferFeature Members](#)

 **Availability**

SOLIDWORKS 2010 FCS, Revision Number 18.0

**Distance2 Property (IDimXpertChamferFeature)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertChamferFeature Interface](#) : Distance2 Property (IDimXpertChamferFeature)  
Gets the length on bevel side 2 of the selected edge, face, or vertex.

 **.NET Syntax**

**Visual Basic (Declaration)**

ReadOnly Property Distance2 As System.Double

**Visual Basic (Usage)**  [Copy Code](#)

```
Dim instance As IDimXpertChamferFeature
Dim value As System.Double

value = instance.Distance2
```

```
C#

System.double Distance2 {get;}
```

```
C++/CLI

property System.double Distance2 {
    System.double get();
}
```

**Property Value**  
Length of bevel on one side of the selected entity

 **Visual Basic for Applications (VBA) Syntax**

See [DimXpertChamferFeature::Distance2](#).

### Example

[Get DimXpert Chamfer Feature Example \(VBA\)](#)  
[Get DimXpert Chamfer Feature Example \(VB.NET\)](#)

### See Also

[IDimXpertChamferFeature Interface](#)  
[IDimXpertChamferFeature Members](#)

### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

# IDimXpertCompositeDistanceBetweenDimTol (Type)

SOLIDWORKS DimXpert API Help

IDimXpertCompositeDistanceBetweenDimTol Interface

See Also   [Members](#)   [Example](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompositeDistanceBetweenDimTol Interface

Allows you to access DimXpert composite distance-between dimension tolerances.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### Visual Basic Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCompositeDistanceBetweenDimTol

Visual Basic (Usage)



Dim instance As [IDimXpertCompositeDistanceBetweenDimTol](#)

C#

public interface IDimXpertCompositeDistanceBetweenDimTol

C++/CLI

public interface class IDimXpertCompositeDistanceBetweenDimTol

### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol](#).

### Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)  
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)  
[Get DimXpert Features and Annotations Example \(C#\)](#)

### Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#), [IDimXpertDimensionTolerance](#).

### Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)  
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)  
[IDimXpertPart::GetAnnotation](#)  
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)  
[IFeature::GetSpecificFeature2](#)

### See Also

[IDimXpertCompositeDistanceBetweenDimTol Members](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

IDimXpertCompositeDistanceBetweenDimTol Interface Methods

See Also

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompositeDistanceBetweenDimTol Interface

For a list of all members of this type, see [IDimXpertCompositeDistanceBetweenDimTol members](#).

### Public Methods

| Name                                                                                                                   | Description                                                                                                 |
|------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
|  <a href="#">GetDirectionVector</a> | Gets the direction vector for computing the distance of this DimXpert distance-between dimension tolerance. |

|                                                                                   |                                                      |                                                                                                                                             |
|-----------------------------------------------------------------------------------|------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|   | <a href="#">GetFeature</a>                           | Gets the feature to which this DimXpert composite distance-between dimension tolerance is applied.                                          |
|  | <a href="#">GetIntraFeature</a>                      | Gets the feature located by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.                   |
|  | <a href="#">GetNominalValueIntraFeature</a>          | Gets the tolerance value for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.                  |
|  | <a href="#">GetOriginFeature</a>                     | Gets the origin feature for this DimXpert composite distance-between dimension tolerance.                                                   |
|  | <a href="#">GetPlusAndMinusToleranceIntraFeature</a> | Gets the plus and minus tolerance values for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.  |
|  | <a href="#">GetUpperAndLowerLimitIntraFeature</a>    | Gets the upper and lower tolerance limits for the feature-locating portion of this DimXpert composite distance-between dimension tolerance. |

[Top](#)

## See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

### IDimXpertCompositeDistanceBetweenDimTol Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompositeDistanceBetweenDimTol Interface

The following tables list the members exposed by [IDimXpertCompositeDistanceBetweenDimTol](#).

## Public Properties

| Name                                                                                                                                      | Description                                                                                                                              |
|-------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">BlockToleranceDecimalPlacesIntraFeature</a> | Gets the precision of block tolerances for the feature-locating portion of this DimXpert composite distance-between dimension tolerance. |
|  <a href="#">DimensionTypeIntraFeature</a>               | Gets the dimension type of the feature-locating portion of this DimXpert composite distance-between dimension tolerance.                 |
|  <a href="#">LimitsAndFitsCodeIntraFeature</a>           | Gets the limits and fits code for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.          |

[Top](#)

## Public Methods

| Name                                                                                                                                     | Description                                                                                                                                 |
|------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">GetDirectionVector</a>                   | Gets the direction vector for computing the distance of this DimXpert distance-between dimension tolerance.                                 |
|  <a href="#">GetFeature</a>                           | Gets the feature to which this DimXpert composite distance-between dimension tolerance is applied.                                          |
|  <a href="#">GetIntraFeature</a>                      | Gets the feature located by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.                   |
|  <a href="#">GetNominalValueIntraFeature</a>          | Gets the tolerance value for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.                  |
|  <a href="#">GetOriginFeature</a>                     | Gets the origin feature for this DimXpert composite distance-between dimension tolerance.                                                   |
|  <a href="#">GetPlusAndMinusToleranceIntraFeature</a> | Gets the plus and minus tolerance values for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.  |
|  <a href="#">GetUpperAndLowerLimitIntraFeature</a>    | Gets the upper and lower tolerance limits for the feature-locating portion of this DimXpert composite distance-between dimension tolerance. |

[Top](#)

## See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

### IDimXpertCompositeDistanceBetweenDimTol Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompositeDistanceBetweenDimTol Interface

For a list of all members of this type, see [IDimXpertCompositeDistanceBetweenDimTol members](#).

## Public Properties

| Name                                                                                                                                        | Description                                                                                                                              |
|---------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">BlockToleranceDecimalPlacesIntraFeature</a> | Gets the precision of block tolerances for the feature-locating portion of this DimXpert composite distance-between dimension tolerance. |
|  <a href="#">DimensionTypeIntraFeature</a>               | Gets the dimension type of the feature-locating portion of this DimXpert composite distance-between dimension tolerance.                 |
|  <a href="#">LimitsAndFitsCodeIntraFeature</a>           | Gets the limits and fits code for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.          |

[Top](#)

## See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

**BlockToleranceDecimalPlacesIntraFeature Property (IDimXpertCompositeDistanceBetweenDimTol)**[See Also](#) [Example](#)

[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : BlockToleranceDecimalPlacesIntraFeature Property (IDimXpertCompositeDistanceBetweenDimTol)

Gets the precision of block tolerances for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

**.NET Syntax****Visual Basic (Declaration)**

```
ReadOnly Property BlockToleranceDecimalPlacesIntraFeature As System.Integer
```

**Visual Basic (Usage)**

```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol  
Dim value As System.Integer  
  
value = instance.BlockToleranceDecimalPlacesIntraFeature
```

**C#**

```
System.int BlockToleranceDecimalPlacesIntraFeature {get;}
```

**C++/CLI**

```
property System.int BlockToleranceDecimalPlacesIntraFeature {  
    System.int get();  
}
```

**Property Value**

Number of decimal places

**Visual Basic for Applications (VBA) Syntax**

See [DimXpertCompositeDistanceBetweenDimTol::BlockToleranceDecimalPlacesIntraFeature](#).

**Example**

[Get DimXpert Tolerance2 Example \(VBA\)](#)

[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

**See Also**

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)

[IDimXpertCompositeDistanceBetweenDimTol Members](#)

**Availability**

SOLIDWORKS 2010 FCS, Revision Number 18.0

**DimensionTypeIntraFeature Property (IDimXpertCompositeDistanceBetweenDimTol)**[See Also](#) [Example](#)

[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : DimensionTypeIntraFeature Property (IDimXpertCompositeDistanceBetweenDimTol)

Gets the dimension type of the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

**.NET Syntax****Visual Basic (Declaration)**

```
ReadOnly Property DimensionTypeIntraFeature As swDimXpertDimensionToleranceType\_e
```

**Visual Basic (Usage)**

```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol  
Dim value As swDimXpertDimensionToleranceType\_e
```

```
value = instance.DimensionTypeIntraFeature
```

C#

```
swDimXpertDimensionToleranceType_e DimensionTypeIntraFeature {get;}
```

C++/CLI

```
property swDimXpertDimensionToleranceType_e DimensionTypeIntraFeature {  
    swDimXpertDimensionToleranceType_e get();  
}
```

#### Property Value

Dimension type as defined in [swDimXpertDimensionToleranceType\\_e](#)

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol::DimensionTypeIntraFeature](#).

#### Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)  
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

#### See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)  
[IDimXpertCompositeDistanceBetweenDimTol Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**GetDirectionVector Method (IDimXpertCompositeDistanceBetweenDimTol)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetDirectionVector Method (IDimXpertCompositeDistanceBetweenDimTol)

Gets the direction vector for computing the distance of this DimXpert distance-between dimension tolerance.

#### .NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetDirectionVector(I, J, K)
```

C#

```
System.bool GetDirectionVector(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetDirectionVector(  
    & [Out] System.double I,  
    & [Out] System.double J,  
    & [Out] System.double K  
)
```

#### Parameters

I  
I component of the direction vector  
J  
J component of the direction vector  
K  
K component of the direction vector

#### Return Value

True if the method call is successful; false otherwise

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol::GetDirectionVector](#).

#### Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)  
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

#### See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)  
[IDimXpertCompositeDistanceBetweenDimTol Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**GetFeature Method (IDimXpertCompositeDistanceBetweenDimTol)**

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetFeature Method (IDimXpertCompositeDistanceBetweenDimTol)

Gets the feature to which this DimXpert composite distance-between dimension tolerance is applied.

#### .NET Syntax

Visual Basic (Declaration)

```
Function GetFeature( _  
    ByRef Feature As DimXpertFeature, _  
    ByRef FosUsage As swDimXpertDistanceFosUsage_e _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol  
Dim Feature As DimXpertFeature  
Dim FosUsage As swDimXpertDistanceFosUsage\_e  
Dim value As System.Boolean
```

```
value = instance.GetFeature(Feature, FosUsage)
```

C#

```
System.bool GetFeature(  
    out DimXpertFeature Feature,  
    out swDimXpertDistanceFosUsage\_e FosUsage  
)
```

C++/CLI

```
System.bool GetFeature(
& [Out] DimXpertFeature^ Feature,
& [Out] swDimXpertDistanceFosUsage\_e FosUsage
)
```

#### Parameters

*Feature*  
[IDimXpertFeature](#)  
*FosUsage*  
Feature of size usage as defined in [swDimXpertDistanceFosUsage\\_e](#)

#### Return Value

True if the method call is successful; false otherwise

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol::GetFeature](#).

#### Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)  
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

#### See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)  
[IDimXpertCompositeDistanceBetweenDimTol Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**GetIntraFeature Method (IDimXpertCompositeDistanceBetweenDimTol)**

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetIntraFeature Method (IDimXpertCompositeDistanceBetweenDimTol)

Gets the feature located by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

#### .NET Syntax

##### Visual Basic (Declaration)

```
Function GetIntraFeature( _
    ByRef Feature As DimXpertFeature, _
    ByRef FosUsage As swDimXpertDistanceFosUsage\_e _
) As System.Boolean
```

##### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol
Dim Feature As DimXpertFeature
Dim FosUsage As swDimXpertDistanceFosUsage\_e
Dim value As System.Boolean
```

```
value = instance.GetIntraFeature(Feature, FosUsage)
```

##### C#

```
System.bool GetIntraFeature(
    out DimXpertFeature Feature,
    out swDimXpertDistanceFosUsage\_e FosUsage
)
```

##### C++/CLI

```
System.bool GetIntraFeature(
& [Out] DimXpertFeature^ Feature,
```

& [Out] [swDimXpertDistanceFosUsage\\_e](#) *FosUsage*  
)

#### Parameters

Feature

[IDimXpertFeature](#)

FosUsage

Feature of size usage as defined in [swDimXpertDistanceFosUsage\\_e](#)

#### Return Value

True if the method call is successful; false otherwise

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol::GetIntraFeature](#).

#### Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)

[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

#### See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)

[IDimXpertCompositeDistanceBetweenDimTol Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**GetNominalValueIntraFeature Method (IDimXpertCompositeDistanceBetweenDimTol)**

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetNominalValueIntraFeature Method (IDimXpertCompositeDistanceBetweenDimTol)

Gets the tolerance value for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

#### .NET Syntax

##### Visual Basic (Declaration)

```
Function GetNominalValueIntraFeature() As System.Double
```

##### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol  
Dim value As System.Double
```

```
value = instance.GetNominalValueIntraFeature()
```

##### C#

```
System.double GetNominalValueIntraFeature()
```

##### C++/CLI

```
System.double GetNominalValueIntraFeature();
```

#### Return Value

Nominal composite distance-between dimension tolerance

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol::GetNominalValueIntraFeature](#).

#### See Also

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

**GetOriginFeature Method (IDimXpertCompositeDistanceBetweenDimTol)**

[See Also](#) [Example](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetOriginFeature Method (IDimXpertCompositeDistanceBetweenDimTol)  
Gets the origin feature for this DimXpert composite distance-between dimension tolerance.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetOriginFeature( _  
    ByRef Feature As DimXpertFeature, _  
    ByRef FosUsage As swDimXpertDistanceFosUsage\_e _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol  
Dim Feature As DimXpertFeature  
Dim FosUsage As swDimXpertDistanceFosUsage\_e  
Dim value As System.Boolean  
  
value = instance.GetOriginFeature(Feature, FosUsage)
```

### C#

```
System.bool GetOriginFeature(  
    out DimXpertFeature Feature,  
    out swDimXpertDistanceFosUsage\_e FosUsage  
)
```

### C++/CLI

```
System.bool GetOriginFeature(  
& [Out] DimXpertFeature^ Feature,  
& [Out] swDimXpertDistanceFosUsage\_e FosUsage  
)
```

## Parameters

*Feature*

[IDimXpertFeature](#)

*FosUsage*

Feature of size usage as defined in [swDimXpertDistanceFosUsage\\_e](#)

## Return Value

True if the method call is successful; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol::GetOriginFeature](#).

## Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)

[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

## See Also

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**GetPlusAndMinusToleranceIntraFeature Method (IDimXpertCompositeDistanceBetweenDimTol)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetPlusAndMinusToleranceIntraFeature Method (IDimXpertCompositeDistanceBetweenDimTol)  
Gets the plus and minus tolerance values for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetPlusAndMinusToleranceIntraFeature( _  
    ByRef Plus As System.Double, _  
    ByRef Minus As System.Double _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol  
Dim Plus As System.Double  
Dim Minus As System.Double  
Dim value As System.Boolean  
  
value = instance.GetPlusAndMinusToleranceIntraFeature(Plus, Minus)
```

### C#

```
System.bool GetPlusAndMinusToleranceIntraFeature(  
    out System.double Plus,  
    out System.double Minus  
)
```

### C++/CLI

```
System.bool GetPlusAndMinusToleranceIntraFeature(  
& [Out] System.double Plus,  
& [Out] System.double Minus  
)
```

### Parameters

*Plus*  
Plus tolerance value  
*Minus*  
Minus tolerance value

### Return Value

True if the method call is successful; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol::GetPlusAndMinusToleranceIntraFeature](#).

## Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)  
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

## See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)  
[IDimXpertCompositeDistanceBetweenDimTol Members](#)

## Availability

**GetUpperAndLowerLimitIntraFeature Method (IDimXpertCompositeDistanceBetweenDimTol)**[See Also](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetUpperAndLowerLimitIntraFeature Method (IDimXpertCompositeDistanceBetweenDimTol)

Gets the upper and lower tolerance limits for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

**.NET Syntax****Visual Basic (Declaration)**

```
Function GetUpperAndLowerLimitIntraFeature( _
    ByRef Upper As System.Double, _
    ByRef Lower As System.Double _
) As System.Boolean
```

**Visual Basic (Usage)**

```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol
Dim Upper As System.Double
Dim Lower As System.Double
Dim value As System.Boolean

value = instance.GetUpperAndLowerLimitIntraFeature(Upper, Lower)
```

**C#**

```
System.bool GetUpperAndLowerLimitIntraFeature(
    out System.double Upper,
    out System.double Lower
)
```

**C++/CLI**

```
System.bool GetUpperAndLowerLimitIntraFeature(
    & [Out] System.double Upper,
    & [Out] System.double Lower
)
```

**Parameters**

*Upper*  
Upper limit

*Lower*  
Lower limit

**Return Value**

True if the method call is successful; false otherwise

**Visual Basic for Applications (VBA) Syntax**See [DimXpertCompositeDistanceBetweenDimTol::GetUpperAndLowerLimitIntraFeature](#). **See Also**

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)

[IDimXpertCompositeDistanceBetweenDimTol Members](#)

**Availability****LimitsAndFitsCodeIntraFeature Property (IDimXpertCompositeDistanceBetweenDimTol)**[See Also](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeDistanceBetweenDimTol Interface](#) : LimitsAndFitsCodeIntraFeature Property (IDimXpertCompositeDistanceBetweenDimTol)

Gets the limits and fits code for the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

## .NET Syntax

### Visual Basic (Declaration)

```
ReadOnly Property LimitsAndFitsCodeIntraFeature As System.String
```

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeDistanceBetweenDimTol  
Dim value As System.String  
  
value = instance.LimitsAndFitsCodeIntraFeature
```

### C#

```
System.string LimitsAndFitsCodeIntraFeature {get;}
```

### C++/CLI

```
property System.String^ LimitsAndFitsCodeIntraFeature {  
    System.String^ get();  
}
```

### Property Value

Limits and fits code

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeDistanceBetweenDimTol::LimitsAndFitsCodeIntraFeature](#).

## See Also

[IDimXpertCompositeDistanceBetweenDimTol Interface](#)  
[IDimXpertCompositeDistanceBetweenDimTol Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

# IDimXpertCompositeLineProfileTolerance (Type)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompositeLineProfileTolerance Interface

Allows you to access DimXpert composite line profile tolerances.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 **Visual Basic (Declaration)**

Public Interface IDimXpertCompositeLineProfileTolerance

 **Visual Basic (Usage)**  [Copy Code](#)

Dim instance As [IDimXpertCompositeLineProfileTolerance](#)

**C#**

public interface IDimXpertCompositeLineProfileTolerance

**C++/CLI**

public interface class IDimXpertCompositeLineProfileTolerance

 **Visual Basic for Applications (VBA) Syntax**

See [DimXpertCompositeLineProfileTolerance](#).

 **Example**

[Get DimXpert Features and Annotations Example \(C#\)](#)

 **Remarks**

You can access more general geometric tolerance information using [IDimXpertTolerance](#).

 **Accessors**

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)  
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)  
[IDimXpertPart::GetAnnotation](#)  
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)  
[IFeature::GetSpecificFeature2](#)

 **See Also**

[IDimXpertCompositeLineProfileTolerance Members](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompositeLineProfileTolerance Interface

The following tables list the members exposed by [IDimXpertCompositeLineProfileTolerance](#).

 **Public Properties**

| Name                                                                                                                    | Description                                                                        |
|-------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
|  <a href="#">OuterToleranceValue</a> | Gets the outer tolerance value for this DimXpert composite line profile tolerance. |

|                                                                                   |                                              |                                                                                                                   |
|-----------------------------------------------------------------------------------|----------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
|   | <a href="#">OuterToleranceValueLowerTier</a> | Gets the outer tolerance value in the lower tier for this DimXpert composite line profile tolerance.              |
|  | <a href="#">PrimaryInLowerTier</a>           | Gets whether the primary datum is repeated in the lower tier of this DimXpert composite line profile tolerance.   |
|  | <a href="#">SecondaryInLowerTier</a>         | Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite line profile tolerance. |
|  | <a href="#">TertiaryInLowerTier</a>          | Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite line profile tolerance.  |
|  | <a href="#">ToleranceLowerTier</a>           | Gets the tolerance value in the lower tier for this DimXpert composite line profile tolerance.                    |

[Top](#)

 **Public Methods**

| Name                                                                                                                  | Description                                                                                            |
|-----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
|  <a href="#">GetPlanarZoneVector</a> | Gets the planar zone vector that is used for computing this DimXpert composite line profile tolerance. |

[Top](#)

 **See Also**

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

**IDimXpertCompositeLineProfileTolerance Interface Methods**

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : [IDimXpertCompositeLineProfileTolerance Interface](#)

For a list of all members of this type, see [IDimXpertCompositeLineProfileTolerance members](#).

 **Public Methods**

| Name                                                                                                                  | Description                                                                                            |
|-----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
|  <a href="#">GetPlanarZoneVector</a> | Gets the planar zone vector that is used for computing this DimXpert composite line profile tolerance. |

[Top](#)

 **See Also**

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

**IDimXpertCompositeLineProfileTolerance Interface Properties**

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : [IDimXpertCompositeLineProfileTolerance Interface](#)

For a list of all members of this type, see [IDimXpertCompositeLineProfileTolerance members](#).

 **Public Properties**

| Name                                                                                                                             | Description                                                                                                       |
|----------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
|  <a href="#">OuterToleranceValue</a>          | Gets the outer tolerance value for this DimXpert composite line profile tolerance.                                |
|  <a href="#">OuterToleranceValueLowerTier</a> | Gets the outer tolerance value in the lower tier for this DimXpert composite line profile tolerance.              |
|  <a href="#">PrimaryInLowerTier</a>           | Gets whether the primary datum is repeated in the lower tier of this DimXpert composite line profile tolerance.   |
|  <a href="#">SecondaryInLowerTier</a>         | Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite line profile tolerance. |
|  <a href="#">TertiaryInLowerTier</a>          | Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite line profile tolerance.  |
|  <a href="#">ToleranceLowerTier</a>           | Gets the tolerance value in the lower tier for this DimXpert composite line profile tolerance.                    |

[Top](#)

 **See Also**

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

**GetPlanarZoneVector Method (IDimXpertCompositeLineProfileTolerance)**

[See Also](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeLineProfileTolerance Interface](#) : [GetPlanarZoneVector Method \(IDimXpertCompositeLineProfileTolerance\)](#)  
Gets the planar zone vector that is used for computing this DimXpert composite line profile tolerance.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetPlanarZoneVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeLineProfileTolerance  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetPlanarZoneVector(I, J, K)
```

### C#

```
System.bool GetPlanarZoneVector(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

### C++/CLI

```
System.bool GetPlanarZoneVector(  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

### Parameters

*I*  
I component of the planar zone vector  
*J*  
J component of the planar zone vector  
*K*  
K component of the planar zone vector

### Return Value

True if the method call is successful; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeLineProfileTolerance::GetPlanarZoneVector](#).

## See Also

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[IDimXpertCompositeLineProfileTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**OuterToleranceValue Property (IDimXpertCompositeLineProfileTolerance)**

[See Also](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertCompositeLineProfileTolerance Interface](#) : OuterToleranceValue Property (IDimXpertCompositeLineProfileTolerance)

Gets the outer tolerance value for this DimXpert composite line profile tolerance.

## .NET Syntax

Visual Basic (Declaration)

ReadOnly Property OuterToleranceValue As System.Double

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeLineProfileTolerance  
Dim value As System.Double  
  
value = instance.OuterToleranceValue
```

C#

```
System.double OuterToleranceValue {get;}
```

C++/CLI

```
property System.double OuterToleranceValue {  
    System.double get();  
}
```

Property Value

Outer tolerance value

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeLineProfileTolerance::OuterToleranceValue](#).

See Also

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[IDimXpertCompositeLineProfileTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**OuterToleranceValueLowerTier Property (IDimXpertCompositeLineProfileTolerance)**

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeLineProfileTolerance Interface](#) : OuterToleranceValueLowerTier Property (IDimXpertCompositeLineProfileTolerance)

Gets the outer tolerance value in the lower tier for this DimXpert composite line profile tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property OuterToleranceValueLowerTier As System.Double

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeLineProfileTolerance  
Dim value As System.Double  
  
value = instance.OuterToleranceValueLowerTier
```

C#

```
System.double OuterToleranceValueLowerTier {get;}
```

C++/CLI

```
property System.double OuterToleranceValueLowerTier {  
    System.double get();  
}
```

Property Value

Outer tolerance value in the lower tier

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeLineProfileTolerance::OuterToleranceValueLowerTier](#).

#### Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

#### See Also

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[IDimXpertCompositeLineProfileTolerance Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

#### PrimaryInLowerTier Property (IDimXpertCompositeLineProfileTolerance)

[See Also](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertCompositeLineProfileTolerance Interface](#) : PrimaryInLowerTier Property (IDimXpertCompositeLineProfileTolerance)

Gets whether the primary datum is repeated in the lower tier of this DimXpert composite line profile tolerance.

#### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PrimaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeLineProfileTolerance  
Dim value As System.Boolean  
  
value = instance.PrimaryInLowerTier
```

C#

```
System.bool PrimaryInLowerTier {get;}
```

C++/CLI

```
property System.bool PrimaryInLowerTier {  
    System.bool get();  
}
```

#### Property Value

True if the primary datum is repeated in the lower tier; false otherwise

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeLineProfileTolerance::PrimaryInLowerTier](#).

#### Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

#### See Also

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[IDimXpertCompositeLineProfileTolerance Members](#)

#### Availability

**SecondaryInLowerTier Property (IDimXpertCompositeLineProfileTolerance)**[See Also](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeLineProfileTolerance Interface](#) : SecondaryInLowerTier Property (IDimXpertCompositeLineProfileTolerance)

Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite line profile tolerance.

## .NET Syntax

## Visual Basic (Declaration)

ReadOnly Property SecondaryInLowerTier As System.Boolean

## Visual Basic (Usage)

Dim instance As [IDimXpertCompositeLineProfileTolerance](#)

Dim value As System.Boolean

value = instance.SecondaryInLowerTier

## C#

System.bool SecondaryInLowerTier {get;}

## C++/CLI

```
property System.bool SecondaryInLowerTier {
    System.bool get();
}
```

**Property Value**

True if the secondary datum is repeated in the lower tier; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeLineProfileTolerance::SecondaryInLowerTier](#).

## Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

## See Also

[IDimXpertCompositeLineProfileTolerance Interface](#)[IDimXpertCompositeLineProfileTolerance Members](#)

## Availability

**TertiaryInLowerTier Property (IDimXpertCompositeLineProfileTolerance)**[See Also](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeLineProfileTolerance Interface](#) : TertiaryInLowerTier Property (IDimXpertCompositeLineProfileTolerance)

Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite line profile tolerance.

## .NET Syntax

## Visual Basic (Declaration)

ReadOnly Property TertiaryInLowerTier As System.Boolean

## Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeLineProfileTolerance
Dim value As System.Boolean

value = instance.TertiaryInLowerTier
```

C#

```
System.bool TertiaryInLowerTier {get;}
```

C++/CLI

```
property System.bool TertiaryInLowerTier {
    System.bool get();
}
```

#### Property Value

True if the tertiary datum is repeated in the lower tier; false otherwise

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeLineProfileTolerance::TertiaryInLowerTier](#).

#### Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

#### See Also

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[IDimXpertCompositeLineProfileTolerance Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**ToleranceLowerTier Property (IDimXpertCompositeLineProfileTolerance)**

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeLineProfileTolerance Interface](#) : ToleranceLowerTier Property (IDimXpertCompositeLineProfileTolerance)

Gets the tolerance value in the lower tier for this DimXpert composite line profile tolerance.

#### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ToleranceLowerTier As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeLineProfileTolerance
Dim value As System.Double

value = instance.ToleranceLowerTier
```

C#

```
System.double ToleranceLowerTier {get;}
```

C++/CLI

```
property System.double ToleranceLowerTier {
    System.double get();
}
```

#### Property Value

Tolerance value in the lower tier

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeLineProfileTolerance::ToleranceLowerTier](#).

## Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

## See Also

[IDimXpertCompositeLineProfileTolerance Interface](#)  
[IDimXpertCompositeLineProfileTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

# IDimXpertCompositePositionTolerance (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCompositePositionTolerance Interface

Allows you to access DimXpert composite position tolerances.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCompositePositionTolerance

Visual Basic (Usage)  Copy Code

Dim instance As [IDimXpertCompositePositionTolerance](#)

C#

public interface IDimXpertCompositePositionTolerance

C++/CLI

public interface class IDimXpertCompositePositionTolerance

 Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance](#).

 Example

[Get DimXpert Tolerance3 Example \(VBA\)](#)  
[Get DimXpert Tolerance3 Example \(VB.NET\)](#)  
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general geometric tolerance information using [IDimXpertTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)  
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)  
[IDimXpertPart::GetAnnotation](#)  
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)  
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertCompositePositionTolerance Members](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCompositePositionTolerance Interface

For a list of all members of this type, see [IDimXpertCompositePositionTolerance members](#).

 Public Methods

| Name                                                                                                                | Description                                                                |
|---------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
|  <a href="#">GetMaxTolerance</a> | Gets the maximum tolerance for this DimXpert composite position tolerance. |

|                                                                                                                            |                                                                                                             |
|----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
|  <a href="#">GetMaxToleranceLowerTier</a> | Gets whether the maximum tolerance is set in the lower tier for this DimXpert composite position tolerance. |
|  <a href="#">GetPlanarZoneVector</a>      | Gets the planar zone vector that is used for computing this DimXpert composite position tolerance.          |
|  <a href="#">GetProjectedZone</a>         | Gets the projected zone value of this DimXpert composite position tolerance.                                |

[Top](#)

## See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

## IDimXpertCompositePositionTolerance Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompositePositionTolerance Interface

The following tables list the members exposed by [IDimXpertCompositePositionTolerance](#).

## Public Properties

| Name                                                                                                                   | Description                                                                                                              |
|------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">Modifier</a>             | Gets the material condition modifier for this DimXpert composite position tolerance.                                     |
|  <a href="#">ModifierLowerTier</a>    | Gets the material condition modifier for the tolerance in the lower tier for this DimXpert composite position tolerance. |
|  <a href="#">PrimaryInLowerTier</a>   | Gets whether the primary datum is repeated in the lower tier of this DimXpert composite position tolerance.              |
|  <a href="#">SecondaryInLowerTier</a> | Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite position tolerance.            |
|  <a href="#">TertiaryInLowerTier</a>  | Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite position tolerance.             |
|  <a href="#">ToleranceLowerTier</a>   | Gets the tolerance value in the lower tier for this DimXpert composite position tolerance.                               |
|  <a href="#">ZoneType</a>             | Gets the zone type of this DimXpert composite position tolerance.                                                        |

[Top](#)

## Public Methods

| Name                                                                                                                         | Description                                                                                                 |
|------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
|  <a href="#">GetMaxTolerance</a>          | Gets the maximum tolerance for this DimXpert composite position tolerance.                                  |
|  <a href="#">GetMaxToleranceLowerTier</a> | Gets whether the maximum tolerance is set in the lower tier for this DimXpert composite position tolerance. |
|  <a href="#">GetPlanarZoneVector</a>      | Gets the planar zone vector that is used for computing this DimXpert composite position tolerance.          |
|  <a href="#">GetProjectedZone</a>         | Gets the projected zone value of this DimXpert composite position tolerance.                                |

[Top](#)

## See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

## IDimXpertCompositePositionTolerance Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompositePositionTolerance Interface

For a list of all members of this type, see [IDimXpertCompositePositionTolerance members](#).

## Public Properties

| Name                                                                                                                     | Description                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">Modifier</a>             | Gets the material condition modifier for this DimXpert composite position tolerance.                                     |
|  <a href="#">ModifierLowerTier</a>    | Gets the material condition modifier for the tolerance in the lower tier for this DimXpert composite position tolerance. |
|  <a href="#">PrimaryInLowerTier</a>   | Gets whether the primary datum is repeated in the lower tier of this DimXpert composite position tolerance.              |
|  <a href="#">SecondaryInLowerTier</a> | Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite position tolerance.            |
|  <a href="#">TertiaryInLowerTier</a>  | Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite position tolerance.             |
|  <a href="#">ToleranceLowerTier</a>   | Gets the tolerance value in the lower tier for this DimXpert composite position tolerance.                               |
|  <a href="#">ZoneType</a>             | Gets the zone type of this DimXpert composite position tolerance.                                                        |

[Top](#)

## See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

### GetMaxTolerance Method (IDimXpertCompositePositionTolerance)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositePositionTolerance Interface](#) : GetMaxTolerance Method (IDimXpertCompositePositionTolerance)

Gets the maximum tolerance for this DimXpert composite position tolerance.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetMaxTolerance( _  
    ByRef IsMax As System.Boolean, _  
    ByRef Tolerance As System.Double _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance  
Dim IsMax As System.Boolean  
Dim Tolerance As System.Double  
Dim value As System.Boolean  
  
value = instance.GetMaxTolerance(IsMax, Tolerance)
```

### C#

```
System.bool GetMaxTolerance(  
    out System.bool IsMax,  
    out System.double Tolerance  
)
```

### C++/CLI

```
System.bool GetMaxTolerance(  
& [Out] System.bool IsMax,  
& [Out] System.double Tolerance  
)
```

### Parameters

*IsMax*  
True if maximum tolerance is set; false otherwise  
*Tolerance*  
Maximum tolerance value

### Return Value

True if the method call is successful; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::GetMaxTolerance](#).

## See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

### GetMaxToleranceLowerTier Method (IDimXpertCompositePositionTolerance)

[See Also](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertCompositePositionTolerance Interface](#) : GetMaxToleranceLowerTier Method (IDimXpertCompositePositionTolerance)

Gets whether the maximum tolerance is set in the lower tier for this DimXpert composite position tolerance.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetMaxToleranceLowerTier( _  
    ByRef IsMax As System.Boolean, _  
    ByRef Tolerance As System.Double _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance  
Dim IsMax As System.Boolean  
Dim Tolerance As System.Double  
Dim value As System.Boolean  
  
value = instance.GetMaxToleranceLowerTier(IsMax, Tolerance)
```

### C#

```
System.bool GetMaxToleranceLowerTier(  
    out System.bool IsMax,  
    out System.double Tolerance  
)
```

### C++/CLI

```
System.bool GetMaxToleranceLowerTier(  
& [Out] System.bool IsMax,  
& [Out] System.double Tolerance  
)
```

## Parameters

### *IsMax*

True if the maximum tolerance is set in the lower tier; false otherwise

### *Tolerance*

Maximum tolerance in lower tier

## Return Value

True if the method call is successful; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::GetMaxToleranceLowerTier](#).

## Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

## See Also

[IDimXpertCompositePositionTolerance Interface](#)

[IDimXpertCompositePositionTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**GetPlanarZoneVector Method (IDimXpertCompositePositionTolerance)**

[See Also](#) [Example](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertCompositePositionTolerance Interface](#) : GetPlanarZoneVector Method (IDimXpertCompositePositionTolerance)

Gets the planar zone vector that is used for computing this DimXpert composite position tolerance.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetPlanarZoneVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetPlanarZoneVector(I, J, K)
```

### C#

```
System.bool GetPlanarZoneVector(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

### C++/CLI

```
System.bool GetPlanarZoneVector(  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

### Parameters

*I*  
I component of the planar zone vector  
*J*  
J component of the planar zone vector  
*K*  
K component of the planar zone vector

### Return Value

True if the method call is successful; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::GetPlanarZoneVector](#).

## Example

[Get DimXpert Tolerance3 Example \(VBA\)](#)  
[Get DimXpert Tolerance3 Example \(VB.NET\)](#)

## See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

#### .NET Syntax

##### Visual Basic (Declaration)

```
Function GetProjectedZone( _  
    ByRef Enabled As System.Boolean, _  
    ByRef Value As System.Double _  
) As System.Boolean
```

##### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance  
Dim Enabled As System.Boolean  
Dim Value As System.Double  
Dim value As System.Boolean  
  
value = instance.GetProjectedZone(Enabled, Value)
```

##### C#

```
System.bool GetProjectedZone(  
    out System.bool Enabled,  
    out System.double Value  
)
```

##### C++/CLI

```
System.bool GetProjectedZone(  
& [Out] System.bool Enabled,  
& [Out] System.double Value  
)
```

#### Parameters

##### *Enabled*

True if projected zone is in effect; false otherwise

##### *Value*

Projected zone value

#### Return Value

True if the method call is successful; false otherwise

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::GetProjectedZone](#).

#### Example

[Get DimXpert Tolerance3 Example \(VBA\)](#)  
[Get DimXpert Tolerance3 Example \(VB.NET\)](#)

#### See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0



## .NET Syntax

### Visual Basic (Declaration)

ReadOnly Property Modifier As [swDimXpertMaterialConditionModifier\\_e](#)

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance  
Dim value As swDimXpertMaterialConditionModifier\_e  
  
value = instance.Modifier
```

### C#

```
swDimXpertMaterialConditionModifier\_e Modifier {get;}
```

### C++/CLI

```
property swDimXpertMaterialConditionModifier\_e Modifier {  
    swDimXpertMaterialConditionModifier\_e get();  
}
```

### Property Value

Material condition modifier as defined in [swDimXpertMaterialConditionModifier\\_e](#)

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::Modifier](#).

## Example

[Get DimXpert Tolerance3 Example \(VBA\)](#)  
[Get DimXpert Tolerance3 Example \(VB.NET\)](#)

## See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

### ModifierLowerTier Property (IDimXpertCompositePositionTolerance)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositePositionTolerance Interface](#) : ModifierLowerTier Property (IDimXpertCompositePositionTolerance)

Gets the material condition modifier for the tolerance in the lower tier for this DimXpert composite position tolerance.

## .NET Syntax

### Visual Basic (Declaration)

ReadOnly Property ModifierLowerTier As [swDimXpertMaterialConditionModifier\\_e](#)

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance  
Dim value As swDimXpertMaterialConditionModifier\_e  
  
value = instance.ModifierLowerTier
```

### C#

```
swDimXpertMaterialConditionModifier\_e ModifierLowerTier {get;}
```

C++/CLI

```
property swDimXpertMaterialConditionModifier\_e ModifierLowerTier {  
    swDimXpertMaterialConditionModifier\_e get();  
}
```

#### Property Value

Material condition modifier as defined in [swDimXpertMaterialConditionModifier\\_e](#)

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::ModifierLowerTier](#).

#### Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

#### See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**PrimaryInLowerTier Property (IDimXpertCompositePositionTolerance)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositePositionTolerance Interface](#) : PrimaryInLowerTier Property (IDimXpertCompositePositionTolerance)

Gets whether the primary datum is repeated in the lower tier of this DimXpert composite position tolerance.

#### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PrimaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance  
Dim value As System.Boolean  
  
value = instance.PrimaryInLowerTier
```

C#

```
System.bool PrimaryInLowerTier {get;}
```

C++/CLI

```
property System.bool PrimaryInLowerTier {  
    System.bool get();  
}
```

#### Property Value

True if the primary datum is repeated in the lower tier; false otherwise

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::PrimaryInLowerTier](#).

#### Example

[Get DimXpert Tolerance3 Example \(VBA\)](#)  
[Get DimXpert Tolerance3 Example \(VB.NET\)](#)

## Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

## See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**SecondaryInLowerTier Property (IDimXpertCompositePositionTolerance)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositePositionTolerance Interface](#) : SecondaryInLowerTier Property (IDimXpertCompositePositionTolerance)

Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite position tolerance.

## .NET Syntax

### Visual Basic (Declaration)

ReadOnly Property SecondaryInLowerTier As System.Boolean

### Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance  
Dim value As System.Boolean  
  
value = instance.SecondaryInLowerTier
```

### C#

```
System.bool SecondaryInLowerTier {get;}
```

### C++/CLI

```
property System.bool SecondaryInLowerTier {  
    System.bool get();  
}
```

### Property Value

True if the secondary datum is repeated in the lower tier; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::SecondaryInLowerTier](#).

## Example

[Get DimXpert Tolerance3 Example \(VBA\)](#)  
[Get DimXpert Tolerance3 Example \(VB.NET\)](#)

## Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

## See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

**TertiaryInLowerTier Property (IDimXpertCompositePositionTolerance)**[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositePositionTolerance Interface](#) : TertiaryInLowerTier Property (IDimXpertCompositePositionTolerance)

Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite position tolerance.

## .NET Syntax

## Visual Basic (Declaration)

ReadOnly Property TertiaryInLowerTier As System.Boolean

## Visual Basic (Usage)



```
Dim instance As IDimXpertCompositePositionTolerance
Dim value As System.Boolean

value = instance.TertiaryInLowerTier
```

## C#

```
System.bool TertiaryInLowerTier {get;}
```

## C++/CLI

```
property System.bool TertiaryInLowerTier {
    System.bool get();
}
```

**Property Value**

True if the tertiary datum is repeated in the lower tier; false otherwise

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::TertiaryInLowerTier](#).

## Example

[Get DimXpert Tolerance3 Example \(VBA\)](#)[Get DimXpert Tolerance3 Example \(VB.NET\)](#)

## Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

## See Also

[IDimXpertCompositePositionTolerance Interface](#)[IDimXpertCompositePositionTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

**ToleranceLowerTier Property (IDimXpertCompositePositionTolerance)**[See Also](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositePositionTolerance Interface](#) : ToleranceLowerTier Property (IDimXpertCompositePositionTolerance)

Gets the tolerance value in the lower tier for this DimXpert composite position tolerance.

## .NET Syntax

## Visual Basic (Declaration)

ReadOnly Property ToleranceLowerTier As System.Double

```
Dim instance As IDimXpertCompositePositionTolerance
Dim value As System.Double

value = instance.ToleranceLowerTier
```

C#

```
System.double ToleranceLowerTier {get;}
```

C++/CLI

```
property System.double ToleranceLowerTier {
    System.double get();
}
```

**Property Value**

Tolerance value in the lower tier

 **Visual Basic for Applications (VBA) Syntax**

See [DimXpertCompositePositionTolerance::ToleranceLowerTier](#).

 **Remarks**

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

 **See Also**

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

 **Availability**

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)**ZoneType Property (IDimXpertCompositePositionTolerance)**[See Also](#) [Example](#)

[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositePositionTolerance Interface](#) : ZoneType Property (IDimXpertCompositePositionTolerance)

Gets the zone type of this DimXpert composite position tolerance.

 **.NET Syntax**

Visual Basic (Declaration)

```
ReadOnly Property ZoneType As swDimXpertPositionZoneType\_e
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IDimXpertCompositePositionTolerance
Dim value As swDimXpertPositionZoneType\_e

value = instance.ZoneType
```

C#

```
swDimXpertPositionZoneType\_e ZoneType {get;}
```

C++/CLI

```
property swDimXpertPositionZoneType\_e ZoneType {
    swDimXpertPositionZoneType\_e get();
}
```

**Property Value**

Position zone type as defined in [swDimXpertPositionZoneType\\_e](#)

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositePositionTolerance::ZoneType](#).

#### Example

[Get DimXpert Tolerance3 Example \(VBA\)](#)  
[Get DimXpert Tolerance3 Example \(VB.NET\)](#)

#### See Also

[IDimXpertCompositePositionTolerance Interface](#)  
[IDimXpertCompositePositionTolerance Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

# IDimXpertCompositeSurfaceProfileTolerance (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCompositeSurfaceProfileTolerance Interface

Allows you to access DimXpert composite surface profile tolerances.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCompositeSurfaceProfileTolerance

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [IDimXpertCompositeSurfaceProfileTolerance](#)

C#

public interface IDimXpertCompositeSurfaceProfileTolerance

C++/CLI

public interface class IDimXpertCompositeSurfaceProfileTolerance

 Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeSurfaceProfileTolerance](#).

 Example

[Get DimXpert Tolerance6 Example \(VBA\)](#)  
[Get DimXpert Tolerance6 Example \(VB.NET\)](#)  
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general geometric tolerance information using [IDimXpertTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)  
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)  
[IDimXpertPart::GetAnnotation](#)  
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)  
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertCompositeSurfaceProfileTolerance Members](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCompositeSurfaceProfileTolerance Interface

The following tables list the members exposed by [IDimXpertCompositeSurfaceProfileTolerance](#).

 Public Properties

| Name                                                                                                                    | Description                                                                           |
|-------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|  <a href="#">OuterToleranceValue</a> | Gets the outer tolerance value for this DimXpert composite surface profile tolerance. |

|                                                                                                                               |                                                                                                                       |
|-------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|
|  <a href="#">OuterToleranceValueLowerTier</a> | Gets the outer tolerance value in the lower tier for this DimXpert composite surface profile tolerance.               |
|  <a href="#">PrimaryInLowerTier</a>          | Gets whether the primary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance.   |
|  <a href="#">SecondaryInLowerTier</a>        | Gets whether the secondary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance. |
|  <a href="#">TertiaryInLowerTier</a>         | Gets whether the tertiary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance.  |
|  <a href="#">ToleranceLowerTier</a>          | Gets the tolerance value in the lower tier for this DimXpert composite surface profile tolerance.                     |

[Top](#)

 See Also

[IDimXpertCompositeSurfaceProfileTolerance Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**IDimXpertCompositeSurfaceProfileTolerance Interface Properties**  
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : [IDimXpertCompositeSurfaceProfileTolerance Interface](#)

For a list of all members of this type, see [IDimXpertCompositeSurfaceProfileTolerance members](#).

 Public Properties

| Name                                                                                                                           | Description                                                                                                           |
|--------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|
|  <a href="#">OuterToleranceValue</a>          | Gets the outer tolerance value for this DimXpert composite surface profile tolerance.                                 |
|  <a href="#">OuterToleranceValueLowerTier</a> | Gets the outer tolerance value in the lower tier for this DimXpert composite surface profile tolerance.               |
|  <a href="#">PrimaryInLowerTier</a>           | Gets whether the primary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance.   |
|  <a href="#">SecondaryInLowerTier</a>         | Gets whether the secondary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance. |
|  <a href="#">TertiaryInLowerTier</a>          | Gets whether the tertiary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance.  |
|  <a href="#">ToleranceLowerTier</a>           | Gets the tolerance value in the lower tier for this DimXpert composite surface profile tolerance.                     |

[Top](#)

 See Also

[IDimXpertCompositeSurfaceProfileTolerance Interface](#)  
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**OuterToleranceValue Property (IDimXpertCompositeSurfaceProfileTolerance)**  
[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeSurfaceProfileTolerance Interface](#) : OuterToleranceValue Property (IDimXpertCompositeSurfaceProfileTolerance)  
Gets the outer tolerance value for this DimXpert composite surface profile tolerance.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property OuterToleranceValue As System.Double

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeSurfaceProfileTolerance
Dim value As System.Double

value = instance.OuterToleranceValue
```

C#

```
System.double OuterToleranceValue {get;}
```

C++/CLI

```
property System.double OuterToleranceValue {
    System.double get();
}
```

Property Value

Outer tolerance value

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeSurfaceProfileTolerance::OuterToleranceValue](#).

#### Example

[Get DimXpert Tolerance6 Example \(VBA\)](#)  
[Get DimXpert Tolerance6 Example \(VB.NET\)](#)

#### See Also

[IDimXpertCompositeSurfaceProfileTolerance Interface](#)  
[IDimXpertCompositeSurfaceProfileTolerance Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**OuterToleranceValueLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)**

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeSurfaceProfileTolerance Interface](#) : OuterToleranceValueLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)

Gets the outer tolerance value in the lower tier for this DimXpert composite surface profile tolerance.

#### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OuterToleranceValueLowerTier As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeSurfaceProfileTolerance  
Dim value As System.Double  
  
value = instance.OuterToleranceValueLowerTier
```

C#

```
System.double OuterToleranceValueLowerTier {get;}
```

C++/CLI

```
property System.double OuterToleranceValueLowerTier {  
    System.double get();  
}
```

#### Property Value

Outer tolerance value in the lower tier

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeSurfaceProfileTolerance::OuterToleranceValueLowerTier](#).

#### Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

#### See Also

[IDimXpertCompositeSurfaceProfileTolerance Interface](#)  
[IDimXpertCompositeSurfaceProfileTolerance Members](#)

#### Availability

**PrimaryInLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)**[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeSurfaceProfileTolerance Interface](#) : PrimaryInLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)

Gets whether the primary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance.

**.NET Syntax****Visual Basic (Declaration)****ReadOnly Property PrimaryInLowerTier As System.Boolean****Visual Basic (Usage)**

```
Dim instance As IDimXpertCompositeSurfaceProfileTolerance
Dim value As System.Boolean
```

```
value = instance.PrimaryInLowerTier
```

**C#**

```
System.bool PrimaryInLowerTier {get;}
```

**C++/CLI**

```
property System.bool PrimaryInLowerTier {
    System.bool get();
}
```

**Property Value**

True if the primary datum is repeated in the lower tier; false otherwise

**Visual Basic for Applications (VBA) Syntax**See [DimXpertCompositeSurfaceProfileTolerance::PrimaryInLowerTier](#). **Example**[Get DimXpert Tolerance6 Example \(VBA\)](#)[Get DimXpert Tolerance6 Example \(VB.NET\)](#) **Remarks**

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

**See Also**[IDimXpertCompositeSurfaceProfileTolerance Interface](#)[IDimXpertCompositeSurfaceProfileTolerance Members](#) **Availability**

SOLIDWORKS 2010 FCS, Revision Number 18.0

**SecondaryInLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)**[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeSurfaceProfileTolerance Interface](#) : SecondaryInLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)

Gets whether the secondary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance.

**.NET Syntax****Visual Basic (Declaration)**

## ReadOnly Property SecondaryInLowerTier As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeSurfaceProfileTolerance  
Dim value As System.Boolean
```

```
value = instance.SecondaryInLowerTier
```

C#

```
System.bool SecondaryInLowerTier {get;}
```

C++/CLI

```
property System.bool SecondaryInLowerTier {  
    System.bool get();  
}
```

### Property Value

True if the secondary datum is repeated in the lower tier; false otherwise

### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeSurfaceProfileTolerance::SecondaryInLowerTier](#).

### Example

[Get DimXpert Tolerance6 Example \(VBA\)](#)  
[Get DimXpert Tolerance6 Example \(VB.NET\)](#)

### Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

### See Also

[IDimXpertCompositeSurfaceProfileTolerance Interface](#)  
[IDimXpertCompositeSurfaceProfileTolerance Members](#)

### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**TertiaryInLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)**

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeSurfaceProfileTolerance Interface](#) : TertiaryInLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)

Gets whether the tertiary datum is repeated in the lower tier for this DimXpert composite surface profile tolerance.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TertiaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeSurfaceProfileTolerance  
Dim value As System.Boolean
```

```
value = instance.TertiaryInLowerTier
```

C#

```
System.bool TertiaryInLowerTier {get;}
```

C++/CLI

```
property System.bool TertiaryInLowerTier {  
    System.bool get();  
}
```

#### Property Value

True if the tertiary datum is repeated in the lower tier; false otherwise

#### Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeSurfaceProfileTolerance::TertiaryInLowerTier](#).

#### Example

[Get DimXpert Tolerance6 Example \(VBA\)](#)  
[Get DimXpert Tolerance6 Example \(VB.NET\)](#)

#### Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

#### See Also

[IDimXpertCompositeSurfaceProfileTolerance Interface](#)  
[IDimXpertCompositeSurfaceProfileTolerance Members](#)

#### Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

**ToleranceLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)**

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompositeSurfaceProfileTolerance Interface](#) : ToleranceLowerTier Property (IDimXpertCompositeSurfaceProfileTolerance)

Gets the tolerance value in the lower tier for this DimXpert composite surface profile tolerance.

#### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ToleranceLowerTier As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompositeSurfaceProfileTolerance  
Dim value As System.Double
```

```
value = instance.ToleranceLowerTier
```

C#

```
System.double ToleranceLowerTier {get;}
```

C++/CLI

```
property System.double ToleranceLowerTier {  
    System.double get();  
}
```

#### Property Value

Tolerance value in the lower tier

## Visual Basic for Applications (VBA) Syntax

See [DimXpertCompositeSurfaceProfileTolerance::ToleranceLowerTier](#).

## Remarks

The second row of the Geometric Tolerance Properties dialog comes into play for composite tolerances. This lower tier property is set in the second row of the dialog.

## See Also

[IDimXpertCompositeSurfaceProfileTolerance Interface](#)  
[IDimXpertCompositeSurfaceProfileTolerance Members](#)

## Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0