

SOLIDWORKS DimXpert API (.NET) — Reference

(3/8): IDimXpertCompoundClosedSlot3DFeature- IDimXpertCounterBoreDimIol

SOLIDWORKS API Documentation (converted from CHM)

IDimXpertCompoundClosedSlot3DFeature (Type)

IDimXpertCompoundClosedSlot3DFeature Interface
[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundClosedSlot3DFeature Interface

Allows you to access specific information about DimXpert 3D closed slots on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCompoundClosedSlot3DFeature

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [IDimXpertCompoundClosedSlot3DFeature](#)

C#

public interface IDimXpertCompoundClosedSlot3DFeature

C++/CLI

public interface class IDimXpertCompoundClosedSlot3DFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundClosedSlot3DFeature](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertCompoundClosedSlot3DFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertCompoundClosedSlot3DFeature Interface Members
[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundClosedSlot3DFeature Interface

The following tables list the members exposed by [IDimXpertCompoundClosedSlot3DFeature](#).

Public Properties

Name	Description
 Blind	Gets whether the DimXpert compound closed slot is blind or through all.

[Top](#)

Public Methods

Name	Description
 GetBottomFeature	Gets the bottom DimXpert feature for this DimXpert compound closed slot.
 GetEndFeatures	Gets the closed end features of this DimXpert compound closed slot.
 GetNominalBottomPlane	Gets the coordinates and vector for the bottom reference plane of this DimXpert compound closed slot.
 GetNominalClosedSlot	Gets various attributes for this DimXpert compound closed slot.
 GetNominalTopPlane	Gets the coordinates and vector for the top reference plane of this DimXpert compound closed slot.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound closed slot.

[Top](#)

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

IDimXpertCompoundClosedSlot3DFeature Interface Methods

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundClosedSlot3DFeature Interface

For a list of all members of this type, see [IDimXpertCompoundClosedSlot3DFeature members](#).

Public Methods

Name	Description
 GetBottomFeature	Gets the bottom DimXpert feature for this DimXpert compound closed slot.
 GetEndFeatures	Gets the closed end features of this DimXpert compound closed slot.
 GetNominalBottomPlane	Gets the coordinates and vector for the bottom reference plane of this DimXpert compound closed slot.
 GetNominalClosedSlot	Gets various attributes for this DimXpert compound closed slot.
 GetNominalTopPlane	Gets the coordinates and vector for the top reference plane of this DimXpert compound closed slot.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound closed slot.

[Top](#)

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

IDimXpertCompoundClosedSlot3DFeature Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundClosedSlot3DFeature Interface

For a list of all members of this type, see [IDimXpertCompoundClosedSlot3DFeature members](#).

Public Properties

Name	Description
 Blind	Gets whether the DimXpert compound closed slot is blind or through all.

[Top](#)

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

Blind Property (IDimXpertCompoundClosedSlot3DFeature)

[See Also](#)

 

[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundClosedSlot3DFeature Interface](#) : Blind Property (IDimXpertCompoundClosedSlot3DFeature)

Gets whether the DimXpert compound closed slot is blind or through all.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Blind As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundClosedSlot3DFeature  
Dim value As System.Boolean  
  
value = instance.Blind
```

C#

```
System.bool Blind {get;}
```

C++/CLI

```
property System.bool Blind {  
    System.bool get();  
}
```

Property Value

True if blind; false if through all

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundClosedSlot3DFeature::Blind](#).

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetBottomFeature Method (IDimXpertCompoundClosedSlot3DFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundClosedSlot3DFeature Interface](#) : GetBottomFeature Method (IDimXpertCompoundClosedSlot3DFeature)

Gets the bottom DimXpert feature for this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

Function GetBottomFeature() As DimXpertFeature

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundClosedSlot3DFeature  
Dim value As DimXpertFeature  
  
value = instance.GetBottomFeature()
```

C#

```
DimXpertFeature GetBottomFeature()
```

C++/CLI

```
DimXpertFeature^ GetBottomFeature();
```

Return Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundClosedSlot3DFeature::GetBottomFeature](#).

Remarks

Only blind slots have bottom features. The bottom feature of a blind slot is a DimXpert plane feature in which the plane is perpendicular to the slot axis.

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetEndFeatures Method (IDimXpertCompoundClosedSlot3DFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundClosedSlot3DFeature Interface](#) : GetEndFeatures Method (IDimXpertCompoundClosedSlot3DFeature)

Gets the closed end features of this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndFeatures( _  
    ByRef End1 As DimXpertFeature, _  
    ByRef End2 As DimXpertFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundClosedSlot3DFeature  
Dim End1 As DimXpertFeature  
Dim End2 As DimXpertFeature  
Dim value As System.Boolean  
  
value = instance.GetEndFeatures(End1, End2)
```

C#

```
System.bool GetEndFeatures(  
    out DimXpertFeature End1,  
    out DimXpertFeature End2  
)
```

C++/CLI

```
System.bool GetEndFeatures(  
& [Out] DimXpertFeature^ End1,  
& [Out] DimXpertFeature^ End2  
)
```

Parameters

End1
[IDimXpertFeature](#)
End2
[IDimXpertFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundClosedSlot3DFeature::GetEndFeatures](#).

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

GetNominalBottomPlane Method (IDimXpertCompoundClosedSlot3DFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundClosedSlot3DFeature Interface](#) : GetNominalBottomPlane Method (IDimXpertCompoundClosedSlot3DFeature)

Gets the coordinates and vector for the bottom reference plane of this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalBottomPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundClosedSlot3DFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalBottomPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalBottomPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalBottomPlane(  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

X
X-coordinate of the bottom plane

Y
Y-coordinate of the bottom plane

Z
Z-coordinate of the bottom plane

I
I component of the direction vector of the bottom plane

J
J component of the direction vector of the bottom plane

K
K component of the direction vector of the bottom plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundClosedSlot3DFeature::GetNominalBottomPlane](#).

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalClosedSlot Method (IDimXpertCompoundClosedSlot3DFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundClosedSlot3DFeature Interface](#) : GetNominalClosedSlot Method (IDimXpertCompoundClosedSlot3DFeature)

Gets various attributes for this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalClosedSlot( _  
    ByRef Width As System.Double, _  
    ByRef Length As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double, _  
    ByRef LongitudeI As System.Double, _  
    ByRef LongitudeJ As System.Double, _  
    ByRef LongitudeK As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IDimXpertCompoundClosedSlot3DFeature
Dim Width As System.Double
Dim Length As System.Double
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim LongitudeI As System.Double
Dim LongitudeJ As System.Double
Dim LongitudeK As System.Double
Dim value As System.Boolean

```

```

value = instance.GetNominalClosedSlot(Width, Length, X, Y, Z, I, J, K, LongitudeI, LongitudeJ, LongitudeK)

```

C#

```

System.bool GetNominalClosedSlot(
    out System.double Width,
    out System.double Length,
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K,
    out System.double LongitudeI,
    out System.double LongitudeJ,
    out System.double LongitudeK
)

```

C++/CLI

```

System.bool GetNominalClosedSlot(
    & [Out] System.double Width,
    & [Out] System.double Length,
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K,
    & [Out] System.double LongitudeI,
    & [Out] System.double LongitudeJ,
    & [Out] System.double LongitudeK
)

```

Parameters

Width

Width of the closed slot

Length

Length of the closed slot

X

X-coordinate of the closed slot origin

Y

Y-coordinate of the closed slot origin

Z

Z-coordinate of the closed slot origin

I

I component of the direction vector of the closed slot

J

J component of the direction vector of the closed slot

K

K component of the direction vector of the closed slot

LongitudeI

I component of the longitudinal unit vector of the closed slot

LongitudeJ

J component of the longitudinal unit vector of the closed slot

LongitudeK

K component of the longitudinal unit vector of the closed slot

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundClosedSlot3DFeature::GetNominalClosedSlot](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)

Remarks

The i, j, and k components of the longitudinal vector indicate the direction of a feature's length with respect to its part axes. For example, if the length of a feature goes along the y-axis of the part, its longitudinal vector is (0, 1, 0).

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalTopPlane Method (IDimXpertCompoundClosedSlot3DFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundClosedSlot3DFeature Interface](#) : GetNominalTopPlane Method (IDimXpertCompoundClosedSlot3DFeature)

Gets the coordinates and vector for the top reference plane of this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalTopPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundClosedSlot3DFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalTopPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalTopPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,
```

```
    out System.double K
)
```

C++/CLI

```
System.bool GetNominalTopPlane(
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)
```

Parameters

X
X-coordinate of the top reference plane

Y
Y-coordinate of the top reference plane

Z
Z-coordinate of the top reference plane

I
I component of the direction vector of the top reference plane

J
J component of the direction vector of the top reference plane

K
K component of the direction vector of the top reference plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundClosedSlot3DFeature::GetNominalTopPlane](#).

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetPlaneFeatures Method (IDimXpertCompoundClosedSlot3DFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundClosedSlot3DFeature Interface](#) : GetPlaneFeatures Method (IDimXpertCompoundClosedSlot3DFeature)

Gets the DimXpert plane features for both sides of this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeatures( _
    ByRef Plane1 As DimXpertPlaneFeature, _
    ByRef Plane2 As DimXpertPlaneFeature _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundClosedSlot3DFeature
Dim Plane1 As DimXpertPlaneFeature
Dim Plane2 As DimXpertPlaneFeature
Dim value As System.Boolean
```

```
value = instance.GetPlaneFeatures(Plane1, Plane2)
```

C#

```
System.bool GetPlaneFeatures(  
    out DimXpertPlaneFeature Plane1,  
    out DimXpertPlaneFeature Plane2  
)
```

C++/CLI

```
System.bool GetPlaneFeatures(  
& [Out] DimXpertPlaneFeature^ Plane1,  
& [Out] DimXpertPlaneFeature^ Plane2  
)
```

Parameters

Plane1
[IDimXpertPlaneFeature](#)
Plane2
[IDimXpertPlaneFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundClosedSlot3DFeature::GetPlaneFeatures](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)

See Also

[IDimXpertCompoundClosedSlot3DFeature Interface](#)
[IDimXpertCompoundClosedSlot3DFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertCompoundHoleFeature (Type)

IDimXpertCompoundHoleFeature Interface
[See Also](#) [Members](#) [Example](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCompoundHoleFeature Interface

Allows you to access specific information about compound DimXpert holes on the DimXpertManager tab of the Management Panel.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 **Visual Basic (.NET) Syntax**

Visual Basic (Declaration)

Public Interface IDimXpertCompoundHoleFeature

Visual Basic (Usage)

Dim instance As [IDimXpertCompoundHoleFeature](#)

C#

public interface IDimXpertCompoundHoleFeature

C++/CLI

public interface class IDimXpertCompoundHoleFeature

 **Visual Basic for Applications (VBA) Syntax**

See [DimXpertCompoundHoleFeature](#).

 **Example**

[Get More DimXpert Feature Examples \(VBA\)](#)
[Get More DimXpert Feature Examples \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 **Remarks**

You can access more general DimXpert feature information using [IDimXpertFeature](#).

 **Accessors**

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)
[IDimXpertPart::GetFeature](#)
[IFeature::GetSpecificFeature2](#)

 **See Also**

[IDimXpertCompoundHoleFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertCompoundHoleFeature Interface Methods
[See Also](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCompoundHoleFeature Interface

For a list of all members of this type, see [IDimXpertCompoundHoleFeature members](#).

 **Public Methods**

Name	Description
 GetBottomFeature	Gets the bottom DimXpert feature for this DimXpert compound hole.
 GetReferenceFeature	Gets the reference DimXpert feature for this DimXpert compound hole.
 GetSubFeatureCount	Gets the number of sub-features in this DimXpert compound hole.

 GetSubFeatures	Gets all of the sub-features of this DimXpert compound hole.
 IGetSubFeatures	Gets all of the sub-features of this DimXpert compound hole.

[Top](#)

 See Also

[IDimXpertCompoundHoleFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertCompoundHoleFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundHoleFeature Interface

The following tables list the members exposed by [IDimXpertCompoundHoleFeature](#).

 Public Properties

Name	Description
 Blind	Gets whether the DimXpert compound hole is blind or through all.
 CompoundHoleType	Gets the type of this DimXpert compound hole.

[Top](#)

 Public Methods

Name	Description
 GetBottomFeature	Gets the bottom DimXpert feature for this DimXpert compound hole.
 GetReferenceFeature	Gets the reference DimXpert feature for this DimXpert compound hole.
 GetSubFeatureCount	Gets the number of sub-features in this DimXpert compound hole.
 GetSubFeatures	Gets all of the sub-features of this DimXpert compound hole.
 IGetSubFeatures	Gets all of the sub-features of this DimXpert compound hole.

[Top](#)

 See Also

[IDimXpertCompoundHoleFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertCompoundHoleFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundHoleFeature Interface

For a list of all members of this type, see [IDimXpertCompoundHoleFeature members](#).

 Public Properties

Name	Description
 Blind	Gets whether the DimXpert compound hole is blind or through all.
 CompoundHoleType	Gets the type of this DimXpert compound hole.

[Top](#)

 See Also

[IDimXpertCompoundHoleFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

Blind Property (IDimXpertCompoundHoleFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundHoleFeature Interface](#) : Blind Property (IDimXpertCompoundHoleFeature)

Gets whether the DimXpert compound hole is blind or through all.

 NET Syntax

Visual Basic (Declaration)

ReadOnly Property Blind As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundHoleFeature  
Dim value As System.Boolean
```

```
value = instance.Blind
```

C#

```
System.bool Blind {get;}
```

C++/CLI

```
property System.bool Blind {  
    System.bool get();  
}
```

Property Value

True if blind; false if through all

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundHoleFeature::Blind](#).

Example

[Get More DimXpert Feature Examples \(VBA\)](#)
[Get More DimXpert Feature Examples \(VB.NET\)](#)

See Also

[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

CompoundHoleType Property (IDimXpertCompoundHoleFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundHoleFeature Interface](#) : CompoundHoleType Property (IDimXpertCompoundHoleFeature)

Gets the type of this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CompoundHoleType As swDimXpertCompoundHoleType\_e
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundHoleFeature  
Dim value As swDimXpertCompoundHoleType\_e
```

```
value = instance.CompoundHoleType
```

C#

```
swDimXpertCompoundHoleType\_e CompoundHoleType {get;}
```

C++/CLI

```
property swDimXpertCompoundHoleType\_e CompoundHoleType {  
    swDimXpertCompoundHoleType\_e get();  
}
```

Property Value

Type of this DimXpert compound hole as defined in [swDimXpertCompoundHoleType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundHoleFeature::CompoundHoleType](#).

Example

[Get More DimXpert Feature Examples \(VBA\)](#)
[Get More DimXpert Feature Examples \(VB.NET\)](#)

See Also

[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetBottomFeature Method (IDimXpertCompoundHoleFeature)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundHoleFeature Interface](#) : GetBottomFeature Method (IDimXpertCompoundHoleFeature)

Gets the bottom DimXpert feature for this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBottomFeature() As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundHoleFeature  
Dim value As DimXpertFeature  
  
value = instance.GetBottomFeature()
```

C#

```
DimXpertFeature GetBottomFeature()
```

C++/CLI

```
DimXpertFeature^ GetBottomFeature();
```

Return Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundHoleFeature::GetBottomFeature](#).

Example

[Get More DimXpert Feature Examples \(VBA\)](#)
[Get More DimXpert Feature Examples \(VB.NET\)](#)

Remarks

Only blind holes have bottom features. The bottom feature of a blind hole is a [DimXpert plane feature](#) in which the plane is perpendicular to the hole axis.

See Also

[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

[Send comments on this topic.](#)

SOLIDWORKS DimXpert API Help

GetReferenceFeature Method (IDimXpertCompoundHoleFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundHoleFeature Interface](#) : GetReferenceFeature Method (IDimXpertCompoundHoleFeature)

Gets the reference DimXpert feature for this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferenceFeature() As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundHoleFeature  
Dim value As DimXpertFeature  
  
value = instance.GetReferenceFeature()
```

C#

```
DimXpertFeature GetReferenceFeature()
```

C++/CLI

```
DimXpertFeature^ GetReferenceFeature();
```

Return Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundHoleFeature::GetReferenceFeature](#).

Example

[Get More DimXpert Feature Examples \(VBA\)](#)
[Get More DimXpert Feature Examples \(VB.NET\)](#)

Remarks

The reference feature is used to dimension the depth of a blind hole. This method currently returns a plane feature but could return another feature type. Cast the object returned by this method to [IDimXpertPlaneFeature](#).

See Also

[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetSubFeatureCount Method (IDimXpertCompoundHoleFeature)[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundHoleFeature Interface](#) : GetSubFeatureCount Method (IDimXpertCompoundHoleFeature)

Gets the number of sub-features in this DimXpert compound hole.

 .NET Syntax**Visual Basic (Declaration)**

```
Function GetSubFeatureCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IDimXpertCompoundHoleFeature  
Dim value As System.Integer  
  
value = instance.GetSubFeatureCount()
```

C#

```
System.int GetSubFeatureCount()
```

C++/CLI

```
System.int GetSubFeatureCount();
```

Return Value

Number of sub-features in this DimXpert compound hole

 Visual Basic for Applications (VBA) SyntaxSee [DimXpertCompoundHoleFeature::GetSubFeatureCount](#). **Example**[Get More DimXpert Feature Examples \(VBA\)](#)[Get More DimXpert Feature Examples \(VB.NET\)](#) **See Also**[IDimXpertCompoundHoleFeature Interface](#)[IDimXpertCompoundHoleFeature Members](#) **Availability**

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetSubFeatures Method (IDimXpertCompoundHoleFeature)[See Also](#) [Example](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundHoleFeature Interface](#) : GetSubFeatures Method (IDimXpertCompoundHoleFeature)

Gets all of the sub-features of this DimXpert compound hole.

 .NET Syntax**Visual Basic (Declaration)**

```
Function GetSubFeatures() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IDimXpertCompoundHoleFeature  
Dim value As System.Object  
  
value = instance.GetSubFeatures()
```

C#

```
System.Object GetSubFeatures()
```

C++/CLI

```
System.Object^ GetSubFeatures();
```

Return Value

Array of [IDimXpertFeatures](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundHoleFeature::GetSubFeatures](#).

Example

[Get More DimXpert Feature Examples \(VBA\)](#)
[Get More DimXpert Feature Examples \(VB.NET\)](#)

Remarks

This method returns all sub-features of the hole feature. All of the sub-features returned by this method do not appear on the DimXpertManager tab of the Management Panel. Functional geometry sub-features such as planes and cylinders that represent each individual face of a part are for internal use only. These sub-features do not appear in the DimXpertManager tree. However, manufacturing sub-features that are significant for downstream machining and inspection do appear in the DimXpertManager tree.

For example, the sub-features of a simple hole are related to functional geometry and are not listed in the DimXpertManager tree. However, the sub-features of a hole pattern are manufacturing features (e.g., simple holes) that are significant for downstream processes. These manufacturing features are listed in the DimXpertManager tree.

See Also

[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IGetSubFeatures Method (IDimXpertCompoundHoleFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundHoleFeature Interface](#) : IGetSubFeatures Method (IDimXpertCompoundHoleFeature)

Gets all of the sub-features of this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSubFeatures( _  
    ByVal Count As System.Integer _  
) As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundHoleFeature  
Dim Count As System.Integer  
Dim value As DimXpertFeature
```

```
value = instance.IGetSubFeatures(Count)
```

C#

```
DimXpertFeature IGetSubFeatures(  
    System.int Count  
)
```

C++/CLI

```
DimXpertFeature^ IGetSubFeatures(  
& System.int Count  
)
```

Parameters

Count

Number of sub-features of this DimXpert hole feature

Return Value

- in-process, unmanaged C++: Pointer to an array of [IDimXpertFeatures](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

This method returns all sub-features of the hole feature. All of the sub-features returned by this method do not appear on the DimXpertManager tab of the Management Panel. Functional geometry sub-features such as planes and cylinders that represent each individual face of a part are for internal use only. These sub-features do not appear in the DimXpertManager tree. However, manufacturing sub-features that are significant for downstream machining and inspection do appear in the DimXpertManager tree.

For example, the sub-features of a simple hole are related to functional geometry and are not listed in the DimXpertManager tree. However, the sub-features of a hole pattern are manufacturing features (e.g., simple holes) that are significant for downstream processes. These manufacturing features are listed in the DimXpertManager tree.

See [In-process Methods](#) for details about this type of method.

Before calling this method, call [IDimXpertCompoundHoleFeature::GetSubFeatureCount](#) to get the value for the Count parameter.

See Also

[IDimXpertCompoundHoleFeature Interface](#)
[IDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertCompoundNotchFeature (Type)

IDimXpertCompoundNotchFeature Interface
[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundNotchFeature Interface

Allows you to access specific information about compound DimXpert notches on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCompoundNotchFeature

Visual Basic (Usage)



Dim instance As [IDimXpertCompoundNotchFeature](#)

C#

public interface IDimXpertCompoundNotchFeature

C++/CLI

public interface class IDimXpertCompoundNotchFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature](#).

Example

[Get More DimXpert Feature Examples \(VB.NET\)](#)
[Get More DimXpert Feature Examples \(VBA\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertCompoundNotchFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertCompoundNotchFeature Interface Members
[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundNotchFeature Interface

The following tables list the members exposed by [IDimXpertCompoundNotchFeature](#).

Public Properties

Name	Description
 Blind	Gets whether the DimXpert compound notch is blind or through all.

[Top](#)

Public Methods

Name	Description
 GetBottomFeature	Gets the bottom DimXpert feature for this DimXpert compound notch.
 GetEndFeature	Gets the closed end feature of this DimXpert compound notch.
 GetNominalBottomPlane	Gets the coordinates and vector for the bottom plane of this DimXpert compound notch.
 GetNominalNotch	Gets various attributes for this DimXpert compound notch.
 GetOpenSideReferenceFeature	Gets the open side reference feature of this DimXpert compound notch.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound notch.
 GetTopReferenceFeature	Gets the top reference feature of this DimXpert compound notch.

[Top](#)

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertCompoundNotchFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundNotchFeature Interface

For a list of all members of this type, see [IDimXpertCompoundNotchFeature members](#).

Public Methods

Name	Description
 GetBottomFeature	Gets the bottom DimXpert feature for this DimXpert compound notch.
 GetEndFeature	Gets the closed end feature of this DimXpert compound notch.
 GetNominalBottomPlane	Gets the coordinates and vector for the bottom plane of this DimXpert compound notch.
 GetNominalNotch	Gets various attributes for this DimXpert compound notch.
 GetOpenSideReferenceFeature	Gets the open side reference feature of this DimXpert compound notch.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound notch.
 GetTopReferenceFeature	Gets the top reference feature of this DimXpert compound notch.

[Top](#)

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertCompoundNotchFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundNotchFeature Interface

For a list of all members of this type, see [IDimXpertCompoundNotchFeature members](#).

Public Properties

Name	Description
 Blind	Gets whether the DimXpert compound notch is blind or through all.

[Top](#)

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Blind Property (IDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundNotchFeature Interface](#) : Blind Property (IDimXpertCompoundNotchFeature)

Gets whether the DimXpert compound notch is blind or through all.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Blind As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundNotchFeature  
Dim value As System.Boolean  
  
value = instance.Blind
```

C#

```
System.bool Blind {get;}
```

C++/CLI

```
property System.bool Blind {  
    System.bool get();  
}
```

Property Value

True if blind; false if through all

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature::Blind](#).

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetBottomFeature Method (IDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundNotchFeature Interface](#) : GetBottomFeature Method (IDimXpertCompoundNotchFeature)

Gets the bottom DimXpert feature for this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

Function GetBottomFeature() As DimXpertFeature

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundNotchFeature  
Dim value As DimXpertFeature  
  
value = instance.GetBottomFeature()
```

C#

```
DimXpertFeature GetBottomFeature()
```

C++/CLI

```
DimXpertFeature^ GetBottomFeature();
```

Return Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature::GetBottomFeature](#).

Remarks

Only blind notches have bottom features. The bottom feature of a blind notch is a [DimXpert plane feature](#) in which the plane is perpendicular to the notch axis.

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetEndFeature Method (IDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundNotchFeature Interface](#) : GetEndFeature Method (IDimXpertCompoundNotchFeature)

Gets the closed end feature of this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndFeature() As DimXpertFeature
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IDimXpertCompoundNotchFeature  
Dim value As DimXpertFeature  
  
value = instance.GetEndFeature()
```

C#

```
DimXpertFeature GetEndFeature()
```

C++/CLI

```
DimXpertFeature^ GetEndFeature();
```

Return Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature::GetEndFeature](#).

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalBottomPlane Method (IDimXpertCompoundNotchFeature)

[See Also](#)



Gets the coordinates and vector for the bottom plane of this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalBottomPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundNotchFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalBottomPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalBottomPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalBottomPlane(  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

X
X-coordinate of the bottom plane

Y
Y-coordinate of the bottom plane

Z
Z-coordinate of the bottom plane

I
I component of the direction vector of the bottom plane

J
J component of the direction vector of the bottom plane

K
K component of the direction vector of the bottom plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature::GetNominalBottomPlane](#).

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalNotch Method (IDimXpertCompoundNotchFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundNotchFeature Interface](#) : GetNominalNotch Method (IDimXpertCompoundNotchFeature)

Gets various attributes for this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalNotch( _  
    ByRef Width As System.Double, _  
    ByRef Length As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double, _  
    ByRef LongitudeI As System.Double, _  
    ByRef LongitudeJ As System.Double, _  
    ByRef LongitudeK As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundNotchFeature  
Dim Width As System.Double  
Dim Length As System.Double  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim LongitudeI As System.Double  
Dim LongitudeJ As System.Double  
Dim LongitudeK As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalNotch(Width, Length, X, Y, Z, I, J, K, LongitudeI, LongitudeJ,  
LongitudeK)
```

C#

```
System.bool GetNominalNotch(  
    out System.double Width,  
    out System.double Length,  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K,  
    out System.double LongitudeI,  
    out System.double LongitudeJ,
```

```
    out System.double LongitudeK
)
```

C++/CLI

```
System.bool GetNominalNotch(
& [Out] System.double Width,
& [Out] System.double Length,
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K,
& [Out] System.double LongitudeI,
& [Out] System.double LongitudeJ,
& [Out] System.double LongitudeK
)
```

Parameters

Width

Width of the notch

Length

Length of the notch

X

X-coordinate of the notch

Y

Y-coordinate of the notch

Z

Z-coordinate of the notch

I

I component of the direction vector of the notch

J

J component of the direction vector of the notch

K

K component of the direction vector of the notch

LongitudeI

I component of the longitudinal unit vector of the notch

LongitudeJ

J component of the longitudinal unit vector of the notch

LongitudeK

K component of the longitudinal unit vector of the notch

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature::GetNominalNotch](#).

Example

[Get More DimXpert Feature Examples \(VBA\)](#)

[Get More DimXpert Feature Examples \(VB.NET\)](#)

Remarks

The longitudinal i, j, and k component vectors indicate the direction of a notch's length with respect to its part axes. For example, if the length of a notch goes along the y-axis of the part, its longitudinal vector is (0, 1, 0).

See Also

[IDimXpertCompoundNotchFeature Interface](#)

[IDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

.NET Syntax

Visual Basic (Declaration)

```
Function GetOpenSideReferenceFeature() As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundNotchFeature  
Dim value As DimXpertFeature  
  
value = instance.GetOpenSideReferenceFeature()
```

C#

```
DimXpertFeature GetOpenSideReferenceFeature()
```

C++/CLI

```
DimXpertFeature^ GetOpenSideReferenceFeature();
```

Return Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature::GetOpenSideReferenceFeature](#).

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

[GetPlaneFeatures Method \(IDimXpertCompoundNotchFeature\)](#)

[See Also](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertCompoundNotchFeature Interface](#) : GetPlaneFeatures Method (IDimXpertCompoundNotchFeature)

Gets the DimXpert plane features for both sides of this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeatures( _  
    ByRef Plane1 As DimXpertPlaneFeature, _  
    ByRef Plane2 As DimXpertPlaneFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundNotchFeature  
Dim Plane1 As DimXpertPlaneFeature  
Dim Plane2 As DimXpertPlaneFeature  
Dim value As System.Boolean  
  
value = instance.GetPlaneFeatures(Plane1, Plane2)
```

C#

```
System.bool GetPlaneFeatures(
    out DimXpertPlaneFeature Plane1,
    out DimXpertPlaneFeature Plane2
)
```

C++/CLI

```
System.bool GetPlaneFeatures(
    & [Out] DimXpertPlaneFeature^ Plane1,
    & [Out] DimXpertPlaneFeature^ Plane2
)
```

Parameters

Plane1
[IDimXpertPlaneFeature](#)
Plane2
[IDimXpertPlaneFeature](#)

Return Value

True if method call is successful; false otherwise

 Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature::GetPlaneFeatures](#).

 See Also

[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundNotchFeature Members](#)

 Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetTopReferenceFeature Method (IDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundNotchFeature Interface](#) : GetTopReferenceFeature Method (IDimXpertCompoundNotchFeature)

Gets the top reference feature of this DimXpert compound notch.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetTopReferenceFeature() As DimXpertFeature
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IDimXpertCompoundNotchFeature
Dim value As DimXpertFeature

value = instance.GetTopReferenceFeature()
```

C#

```
DimXpertFeature GetTopReferenceFeature()
```

C++/CLI

```
DimXpertFeature^ GetTopReferenceFeature();
```

Return Value

[IDimXpertFeature](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundNotchFeature::GetTopReferenceFeature](#).

See Also

[IDimXpertCompoundNotchFeature Interface](#)
[IDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertCompoundWidthFeature (Type)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundWidthFeature Interface

Allows you to access specific information about compound DimXpert widths on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCompoundWidthFeature

Visual Basic (Usage)



Dim instance As [IDimXpertCompoundWidthFeature](#)

C#

public interface IDimXpertCompoundWidthFeature

C++/CLI

public interface class IDimXpertCompoundWidthFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundWidthFeature](#).

Example

[Get and Set Size Dimension Example \(C#\)](#)
[Get and Set Size Dimension Example \(VB.NET\)](#)
[Get and Set Size Dimension Example \(VBA\)](#)
[Get DimXpert Width And Best Fit Plane Features Example \(VBA\)](#)
[Get DimXpert Width And Best Fit Plane Features Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::IGetFeatures](#)
[IDimXpertPart::GetFeature](#)
[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertCompoundWidthFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundWidthFeature Interface

The following tables list the members exposed by [IDimXpertCompoundWidthFeature](#).

Public Properties

Name	Description
Inner	Gets whether the width is for a hole or a pin.

[Top](#)

 Public Methods

Name	Description
 GetNominalCompoundWidth	Gets various attributes for this DimXpert compound width.
 GetNominalLongitude	Gets components of the longitudinal vector for this width.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound width.

[Top](#)

 See Also

[IDimXpertCompoundWidthFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertCompoundWidthFeature Interface Methods
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundWidthFeature Interface

For a list of all members of this type, see [IDimXpertCompoundWidthFeature members](#).

 Public Methods

Name	Description
 GetNominalCompoundWidth	Gets various attributes for this DimXpert compound width.
 GetNominalLongitude	Gets components of the longitudinal vector for this width.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound width.

[Top](#)

 See Also

[IDimXpertCompoundWidthFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertCompoundWidthFeature Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCompoundWidthFeature Interface

For a list of all members of this type, see [IDimXpertCompoundWidthFeature members](#).

 Public Properties

Name	Description
 Inner	Gets whether the width is for a hole or a pin.

[Top](#)

 See Also

[IDimXpertCompoundWidthFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetNominalCompoundWidth Method (IDimXpertCompoundWidthFeature)
[See Also](#) [Example](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundWidthFeature Interface](#) : GetNominalCompoundWidth Method (IDimXpertCompoundWidthFeature)
Gets various attributes for this DimXpert compound width.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetNominalCompoundWidth( _  
    ByRef Width As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _
```

```

    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDimXpertCompoundWidthFeature
Dim Width As System.Double
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetNominalCompoundWidth(Width, X, Y, Z, I, J, K)

```

C#

```

System.bool GetNominalCompoundWidth(
    out System.double Width,
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetNominalCompoundWidth(
& [Out] System.double Width,
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)

```

Parameters

Width

Width of the feature

X

X-coordinate of the width

Y

Y-coordinate of the width

Z

Z-coordinate of the width

I

I component of the direction vector of the width

J

J component of the direction vector of the width

K

K component of the direction vector of the width

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundWidthFeature::GetNominalCompoundWidth](#).

Example

[Get and Set Size Dimension Example \(C#\)](#)
[Get and Set Size Dimension Example \(VB.NET\)](#)
[Get and Set Size Dimension Example \(VBA\)](#)

[Get DimXpert Width And Best Fit Plane Features Example \(VBA\)](#)
[Get DimXpert Width And Best Fit Plane Features Example \(VB.NET\)](#)

See Also

[IDimXpertCompoundWidthFeature Interface](#)
[IDimXpertCompoundWidthFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalLongitude Method (IDimXpertCompoundWidthFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundWidthFeature Interface](#) : GetNominalLongitude Method (IDimXpertCompoundWidthFeature)

Gets components of the longitudinal vector for this width.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalLongitude( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundWidthFeature  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalLongitude(I, J, K)
```

C#

```
System.bool GetNominalLongitude(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalLongitude(  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

I
I component of the longitudinal unit vector of the width
J
J component of the longitudinal unit vector of the width
K
K component of the longitudinal unit vector of the width

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundWidthFeature::GetNominalLongitude](#).

Remarks

The i, j, and k components of the longitudinal vector indicate the direction of a feature's length with respect to its part axes. For example, if the length of a feature goes along the y-axis of the part, its longitudinal vector is (0, 1, 0).

See Also

[IDimXpertCompoundWidthFeature Interface](#)
[IDimXpertCompoundWidthFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetPlaneFeatures Method (IDimXpertCompoundWidthFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundWidthFeature Interface](#) : GetPlaneFeatures Method (IDimXpertCompoundWidthFeature)

Gets the DimXpert plane features for both sides of this DimXpert compound width.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeatures( _  
    ByRef Plane1 As DimXpertPlaneFeature, _  
    ByRef Plane2 As DimXpertPlaneFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundWidthFeature  
Dim Plane1 As DimXpertPlaneFeature  
Dim Plane2 As DimXpertPlaneFeature  
Dim value As System.Boolean  
  
value = instance.GetPlaneFeatures(Plane1, Plane2)
```

C#

```
System.bool GetPlaneFeatures(  
    out DimXpertPlaneFeature Plane1,  
    out DimXpertPlaneFeature Plane2  
)
```

C++/CLI

```
System.bool GetPlaneFeatures(  
& [Out] DimXpertPlaneFeature^ Plane1,  
& [Out] DimXpertPlaneFeature^ Plane2  
)
```

Parameters

Plane1
[IDimXpertPlaneFeature](#)
Plane2
[IDimXpertPlaneFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundWidthFeature::GetPlaneFeatures](#).

See Also

[IDimXpertCompoundWidthFeature Interface](#)
[IDimXpertCompoundWidthFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Inner Property (IDimXpertCompoundWidthFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCompoundWidthFeature Interface](#) : Inner Property (IDimXpertCompoundWidthFeature)

Gets whether the width is for a hole or a pin.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Inner As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertCompoundWidthFeature  
Dim value As System.Boolean
```

```
value = instance.Inner
```

C#

```
System.bool Inner {get;}
```

C++/CLI

```
property System.bool Inner {  
    System.bool get();  
}
```

Property Value

True if width is for a hole; false if for a pin

Visual Basic for Applications (VBA) Syntax

See [DimXpertCompoundWidthFeature::Inner](#).

Example

[Get and Set Size Dimension Example \(C#\)](#)
[Get and Set Size Dimension Example \(VB.NET\)](#)
[Get and Set Size Dimension Example \(VBA\)](#)
[Get DimXpert Width And Best Fit Plane Features Example \(VBA\)](#)
[Get DimXpert Width And Best Fit Plane Features Example \(VB.NET\)](#)

See Also

[IDimXpertCompoundWidthFeature Interface](#)
[IDimXpertCompoundWidthFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertConcentricityTolerance (Type)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertConcentricityTolerance Interface

Allows you to access DimXpert concentricity tolerances.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

[-] .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertConcentricityTolerance

Visual Basic (Usage)  Copy Code

Dim instance As [IDimXpertConcentricityTolerance](#)

C#

public interface IDimXpertConcentricityTolerance

C++/CLI

public interface class IDimXpertConcentricityTolerance

[-] Visual Basic for Applications (VBA) Syntax

See [DimXpertConcentricityTolerance](#).

[-] Example

[Get DimXpert Tolerance5 Example \(VBA\)](#)
[Get DimXpert Tolerance5 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

[-] Remarks

You can access more general geometric tolerance information using [IDimXpertTolerance](#).

[-] Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

[-] See Also

[IDimXpertConcentricityTolerance Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertConcentricityTolerance Interface

For a list of all members of this type, see [IDimXpertConcentricityTolerance members](#).

[-] Public Methods

Name	Description
------	-------------

	GetMaxTolerance	Gets the maximum tolerance for this DimXpert concentricity tolerance.
--	---------------------------------	---

[Top](#)

 See Also

[IDimXpertConcentricityTolerance Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertConcentricityTolerance Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertConcentricityTolerance Interface

The following tables list the members exposed by [IDimXpertConcentricityTolerance](#).

 Public Properties

Name	Description
 Modifier	Gets the material condition modifier for this DimXpert concentricity tolerance.

[Top](#)

 Public Methods

Name	Description
 GetMaxTolerance	Gets the maximum tolerance for this DimXpert concentricity tolerance.

[Top](#)

 See Also

[IDimXpertConcentricityTolerance Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertConcentricityTolerance Interface Properties

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertConcentricityTolerance Interface

For a list of all members of this type, see [IDimXpertConcentricityTolerance members](#).

 Public Properties

Name	Description
 Modifier	Gets the material condition modifier for this DimXpert concentricity tolerance.

[Top](#)

 See Also

[IDimXpertConcentricityTolerance Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetMaxTolerance Method (IDimXpertConcentricityTolerance)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertConcentricityTolerance Interface](#) : GetMaxTolerance Method (IDimXpertConcentricityTolerance)

Gets the maximum tolerance for this DimXpert concentricity tolerance.

 .NET Syntax

Visual Basic (Declaration)

Function GetMaxTolerance(_
 ByRef [IsMax](#) As System.Boolean, _
 ByRef [Tolerance](#) As System.Double _
) As System.Boolean

Visual Basic (Usage) 

```
Dim instance As IDimXpertConcentricityTolerance
Dim IsMax As System.Boolean
Dim Tolerance As System.Double
Dim value As System.Boolean

value = instance.GetMaxTolerance(IsMax, Tolerance)
```

C#

```
System.bool GetMaxTolerance(
    out System.bool IsMax,
    out System.double Tolerance
)
```

C++/CLI

```
System.bool GetMaxTolerance(
& [Out] System.bool IsMax,
& [Out] System.double Tolerance
)
```

Parameters

IsMax

True if maximum tolerance is set; false otherwise

Tolerance

Maximum tolerance value

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertConcentricityTolerance::GetMaxTolerance](#).

See Also

[IDimXpertConcentricityTolerance Interface](#)
[IDimXpertConcentricityTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Modifier Property (IDimXpertConcentricityTolerance)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertConcentricityTolerance Interface](#) : Modifier Property (IDimXpertConcentricityTolerance)

Gets the material condition modifier for this DimXpert concentricity tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Modifier As swDimXpertMaterialConditionModifier\_e
```

Visual Basic (Usage)



```
Dim instance As IDimXpertConcentricityTolerance
Dim value As swDimXpertMaterialConditionModifier\_e

value = instance.Modifier
```

C#

```
swDimXpertMaterialConditionModifier\_e Modifier {get;}
```

C++/CLI

```
property swDimXpertMaterialConditionModifier\_e Modifier {  
    swDimXpertMaterialConditionModifier\_e get();  
}
```

Property Value

Material condition modifier as defined in [swDimXpertMaterialConditionModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertConcentricityTolerance::Modifier](#).

Example

[Get DimXpert Tolerance5 Example \(VBA\)](#)
[Get DimXpert Tolerance5 Example \(VB.NET\)](#)

See Also

[IDimXpertConcentricityTolerance Interface](#)
[IDimXpertConcentricityTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertConeFeature (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertConeFeature Interface

Allows you to access specific information about DimXpert cones on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 **Visual Basic (Declaration)**

Public Interface IDimXpertConeFeature

 **Visual Basic (Usage)**  [Copy Code](#)

Dim instance As [IDimXpertConeFeature](#)

 **C#**

public interface IDimXpertConeFeature

 **C++/CLI**

public interface class IDimXpertConeFeature

 Visual Basic for Applications (VBA) Syntax

See [DimXpertConeFeature](#).

 **Example**

[Get DimXpert Cone Feature Example \(VBA\)](#)
[Get DimXpert Cone Feature Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 **Remarks**

You can access more general DimXpert feature information using [IDimXpertFeature](#).

 **Accessors**

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)
[IDimXpertPart::GetFeature](#)
[IFeature::GetSpecificFeature2](#)

 **See Also**

[IDimXpertConeFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertConeFeature Interface

The following tables list the members exposed by [IDimXpertConeFeature](#).

 **Public Properties**

Name	Description
 Inner	Gets whether the DimXpert cone is a hole or a pin.

 Public Methods

Name	Description
 GetNominalBottomPlane	Gets the coordinates and vector for the bottom plane of this DimXpert cone.
 GetNominalCone	Gets various attributes for this DimXpert cone.
 GetNominalTopPlane	Gets the coordinates and vector for the top plane of this DimXpert cone.

[Top](#)

 See Also

[IDimXpertConeFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertConeFeature Interface Methods
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertConeFeature Interface

For a list of all members of this type, see [IDimXpertConeFeature members](#).

 Public Methods

Name	Description
 GetNominalBottomPlane	Gets the coordinates and vector for the bottom plane of this DimXpert cone.
 GetNominalCone	Gets various attributes for this DimXpert cone.
 GetNominalTopPlane	Gets the coordinates and vector for the top plane of this DimXpert cone.

[Top](#)

 See Also

[IDimXpertConeFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertConeFeature Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertConeFeature Interface

For a list of all members of this type, see [IDimXpertConeFeature members](#).

 Public Properties

Name	Description
 Inner	Gets whether the DimXpert cone is a hole or a pin.

[Top](#)

 See Also

[IDimXpertConeFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetNominalBottomPlane Method (IDimXpertConeFeature)
[See Also](#) [Example](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertConeFeature Interface](#) : GetNominalBottomPlane Method (IDimXpertConeFeature)

Gets the coordinates and vector for the bottom plane of this DimXpert cone.

 .NET Syntax

```
Visual Basic (Declaration)

Function GetNominalBottomPlane( _
    ByRef X As System.Double, _
    ByRef Y As System.Double, _
    ByRef Z As System.Double, _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
```

```
ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertConeFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalBottomPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalBottomPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalBottomPlane(  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

[X](#)
X-coordinate of the bottom plane

[Y](#)
Y-coordinate of the bottom plane

[Z](#)
Z-coordinate of the bottom plane

[I](#)
I component of the direction vector of the bottom plane

[J](#)
J component of the direction vector of the bottom plane

[K](#)
K component of the direction vector of the bottom plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertConeFeature::GetNominalBottomPlane](#).

Example

[Get DimXpert Cone Feature Example \(VBA\)](#)
[Get DimXpert Cone Feature Example \(VB.NET\)](#)

See Also

[IDimXpertConeFeature Interface](#)
[IDimXpertConeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalCone Method (IDimXpertConeFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertConeFeature Interface](#) : GetNominalCone Method (IDimXpertConeFeature)

Gets various attributes for this DimXpert cone.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalCone( _  
    ByRef Angle As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertConeFeature  
Dim Angle As System.Double  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalCone(Angle, X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalCone(  
    out System.double Angle,  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalCone(  
& [Out] System.double Angle,  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

Angle

Angle in radians of the cone

X

X-coordinate of the cone

Y

Y-coordinate of the cone

Z

Z-coordinate of the cone

I

I component of the direction vector of the cone

J

J component of the direction vector of the cone

K

K component of the direction vector of the cone

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertConeFeature::GetNominalCone](#).

Example

[Get DimXpert Cone Feature Example \(VBA\)](#)

[Get DimXpert Cone Feature Example \(VB.NET\)](#)

See Also

[IDimXpertConeFeature Interface](#)

[IDimXpertConeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalTopPlane Method (IDimXpertConeFeature)

See Also [Example](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertConeFeature Interface](#) : GetNominalTopPlane Method (IDimXpertConeFeature)

Gets the coordinates and vector for the top plane of this DimXpert cone.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalTopPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertConeFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalTopPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalTopPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,
```

```
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalTopPlane(  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

X

X-coordinate of the top plane

Y

Y-coordinate of the top plane

Z

Z-coordinate of the top plane

I

I component of the direction vector of the top plane

J

J component of the direction vector of the top plane

K

K component of the direction vector of the top plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertConeFeature::GetNominalTopPlane](#).

Example

[Get DimXpert Cone Feature Example \(VBA\)](#)

[Get DimXpert Cone Feature Example \(VB.NET\)](#)

See Also

[IDimXpertConeFeature Interface](#)

[IDimXpertConeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Inner Property (IDimXpertConeFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertConeFeature Interface](#) : Inner Property (IDimXpertConeFeature)

Gets whether the DimXpert cone is a hole or a pin.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Inner As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertConeFeature
```

```
Dim value As System.Boolean
```

```
value = instance.Inner
```

C#

```
System.bool Inner {get;}
```

C++/CLI

```
property System.bool Inner {  
    System.bool get();  
}
```

Property Value

True if cone is a hole; false if a pin

Visual Basic for Applications (VBA) Syntax

See [DimXpertConeFeature::Inner](#).

Example

[Get DimXpert Cone Feature Example \(VBA\)](#)
[Get DimXpert Cone Feature Example \(VB.NET\)](#)

See Also

[IDimXpertConeFeature Interface](#)
[IDimXpertConeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertCounterBoreDimTol (Type)

IDimXpertCounterBoreDimTol Interface
[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCounterBoreDimTol Interface

Allows you to access specific dimension tolerancing information about DimXpert counterbore annotations on the DimXpertManager tab of the Management Panel.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCounterBoreDimTol

Visual Basic (Usage)



Dim instance As [IDimXpertCounterBoreDimTol](#)

C#

public interface IDimXpertCounterBoreDimTol

C++/CLI

public interface class IDimXpertCounterBoreDimTol

Visual Basic for Applications (VBA) Syntax

See [DimXpertCounterBoreDimTol](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general dimension tolerance information using [IDimXpertDimensionTolerance](#).

Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertCounterBoreDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertCounterBoreDimTol Interface Members
[See Also](#) [Properties](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCounterBoreDimTol Interface

The following tables list the members exposed by [IDimXpertCounterBoreDimTol](#).

Public Properties

Name	Description
------	-------------

	ReferenceFeature	Gets the reference feature for this DimXpert counterbore dimension tolerance.
--	----------------------------------	---

[Top](#)

 See Also

[IDimXpertCounterBoreDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertCounterBoreDimTol Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCounterBoreDimTol Interface

For a list of all members of this type, see [IDimXpertCounterBoreDimTol members](#).

 Public Properties

Name	Description
	ReferenceFeature
	Gets the reference feature for this DimXpert counterbore dimension tolerance.

[Top](#)

 See Also

[IDimXpertCounterBoreDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

ReferenceFeature Property (IDimXpertCounterBoreDimTol)

[See Also](#) [Example](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCounterBoreDimTol Interface](#) : ReferenceFeature Property (IDimXpertCounterBoreDimTol)

Gets the reference feature for this DimXpert counterbore dimension tolerance.

 .NET Syntax

Visual Basic (Declaration)
ReadOnly Property ReferenceFeature As DimXpertFeature
Visual Basic (Usage)  Copy Code
<pre>Dim instance As IDimXpertCounterBoreDimTol Dim value As DimXpertFeature value = instance.ReferenceFeature</pre>
C#
<pre>DimXpertFeature ReferenceFeature {get;}</pre>
C++/CLI
<pre>property DimXpertFeature^ ReferenceFeature { DimXpertFeature^ get(); }</pre>

Property Value

[IDimXpertFeature](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertCounterBoreDimTol::ReferenceFeature](#).

 Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertCounterBoreDimTol Interface](#)
[IDimXpertCounterBoreDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0