

SOLIDWORKS DimXpert API (.NET) — Reference

(4/8): IDimXpertCounterSinkAngleDim Tol- IDimXpertDistanceBetweenDim Tol

SOLIDWORKS API Documentation (converted from CHM)

IDimXpertCounterSinkAngleDimTol (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCounterSinkAngleDimTol Interface

Allows you to access angle dimension tolerances for DimXpert countersink annotations on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCounterSinkAngleDimTol

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [IDimXpertCounterSinkAngleDimTol](#)

C#

public interface IDimXpertCounterSinkAngleDimTol

C++/CLI

public interface class IDimXpertCounterSinkAngleDimTol

 Visual Basic for Applications (VBA) Syntax

See [DimXpertCounterSinkAngleDimTol](#).

 Example

[Get DimXpert Tolerance1 Example \(VBA\)](#)
[Get DimXpert Tolerance1 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general dimension tolerance information using [IDimXpertDimensionTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertCounterSinkAngleDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCounterSinkAngleDimTol Interface

The following tables list the members exposed by [IDimXpertCounterSinkAngleDimTol](#).

 Public Properties

Name	Description
------	-------------



[ReferenceFeature](#)

Gets the reference feature for this DimXpert countersink angle dimension tolerance.

[Top](#)

See Also

[IDimXpertCounterSinkAngleDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertCounterSinkAngleDimTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCounterSinkAngleDimTol Interface

For a list of all members of this type, see [IDimXpertCounterSinkAngleDimTol members](#).

Public Properties



Name
[ReferenceFeature](#)

Description
Gets the reference feature for this DimXpert countersink angle dimension tolerance.

[Top](#)

See Also

[IDimXpertCounterSinkAngleDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

ReferenceFeature Property (IDimXpertCounterSinkAngleDimTol)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCounterSinkAngleDimTol Interface](#) : ReferenceFeature Property (IDimXpertCounterSinkAngleDimTol)

Gets the reference feature for this DimXpert countersink angle dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ReferenceFeature As DimXpertFeature

Visual Basic (Usage)



```
Dim instance As IDimXpertCounterSinkAngleDimTol  
Dim value As DimXpertFeature  
  
value = instance.ReferenceFeature
```

C#

```
DimXpertFeature ReferenceFeature {get;}
```

C++/CLI

```
property DimXpertFeature^ ReferenceFeature {  
    DimXpertFeature^ get();  
}
```

Property Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertCounterSinkAngleDimTol::ReferenceFeature](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertCounterSinkAngleDimTol Interface](#)
[IDimXpertCounterSinkAngleDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertCounterSinkDiameterDimTol (Type)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCounterSinkDiameterDimTol Interface

Allows you to access diameter dimension tolerances for DimXpert countersink annotations on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCounterSinkDiameterDimTol

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [IDimXpertCounterSinkDiameterDimTol](#)

C#

public interface IDimXpertCounterSinkDiameterDimTol

C++/CLI

public interface class IDimXpertCounterSinkDiameterDimTol

 Visual Basic for Applications (VBA) Syntax

See [DimXpertCounterSinkDiameterDimTol](#).

 Example

[Get DimXpert Tolerance1 Example \(VBA\)](#)
[Get DimXpert Tolerance1 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general dimension tolerance information using [IDimXpertDimensionTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertCounterSinkDiameterDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertCounterSinkDiameterDimTol Interface

The following tables list the members exposed by [IDimXpertCounterSinkDiameterDimTol](#).

 Public Properties

Name	Description
------	-------------

	ReferenceFeature	Gets the reference feature for this DimXpert countersink diameter dimension tolerance.
--	----------------------------------	--

[Top](#)

 See Also

[IDimXpertCounterSinkDiameterDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertCounterSinkDiameterDimTol Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCounterSinkDiameterDimTol Interface

For a list of all members of this type, see [IDimXpertCounterSinkDiameterDimTol members](#).

 Public Properties

Name	Description
	ReferenceFeature
	Gets the reference feature for this DimXpert countersink diameter dimension tolerance.

[Top](#)

 See Also

[IDimXpertCounterSinkDiameterDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

ReferenceFeature Property (IDimXpertCounterSinkDiameterDimTol)
[See Also](#) [Example](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCounterSinkDiameterDimTol Interface](#) : ReferenceFeature Property (IDimXpertCounterSinkDiameterDimTol)

Gets the reference feature for this DimXpert countersink diameter dimension tolerance.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property ReferenceFeature As DimXpertFeature

Visual Basic (Usage)  Copy Code

```
Dim instance As IDimXpertCounterSinkDiameterDimTol
Dim value As DimXpertFeature

value = instance.ReferenceFeature
```

C#

```
DimXpertFeature ReferenceFeature {get;}
```

C++/CLI

```
property DimXpertFeature^ ReferenceFeature {
    DimXpertFeature^ get();
}
```

Property Value

[IDimXpertFeature](#)

 Visual Basic for Applications (VBA) Syntax

See [DimXpertCounterSinkDiameterDimTol::ReferenceFeature](#).

 Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertCounterSinkDiameterDimTol Interface](#)
[IDimXpertCounterSinkDiameterDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertCylinderFeature (Type)

IDimXpertCylinderFeature Interface
[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCylinderFeature Interface

Allows you to access specific information about DimXpert cylinders on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertCylinderFeature

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [IDimXpertCylinderFeature](#)

C#

public interface IDimXpertCylinderFeature

C++/CLI

public interface class IDimXpertCylinderFeature

Visual Basic for Applications (VBA) Syntax

See [DimXpertCylinderFeature](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)
[Get DimXpert Feature Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general DimXpert feature information using [IDimXpertFeature](#).

Accessors

[IDimXpertPart::GetFeatures](#) and [IDimXpertPart::!GetFeatures](#)

[IDimXpertPart::GetFeature](#)

[IFeature::GetSpecificFeature2](#)

See Also

[IDimXpertCylinderFeature Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

IDimXpertCylinderFeature Interface Members
[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCylinderFeature Interface

The following tables list the members exposed by [IDimXpertCylinderFeature](#).

Public Properties

Name	Description
Inner	Gets whether this DimXpert cylinder is a hole or a pin.

[Top](#)

 Public Methods

Name	Description
 GetNominalBottomPlane	Gets the coordinates and vector for the bottom plane of this DimXpert cylinder.
 GetNominalCylinder	Gets various attributes for this DimXpert cylinder.
 GetNominalTopPlane	Gets the coordinates and vector for the top plane of this DimXpert cylinder.
 GetThread	Gets thread information for this DimXpert cylinder.

[Top](#)

 See Also

[IDimXpertCylinderFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)
IDimXpertCylinderFeature Interface Methods
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCylinderFeature Interface
For a list of all members of this type, see [IDimXpertCylinderFeature members](#).

 Public Methods

Name	Description
 GetNominalBottomPlane	Gets the coordinates and vector for the bottom plane of this DimXpert cylinder.
 GetNominalCylinder	Gets various attributes for this DimXpert cylinder.
 GetNominalTopPlane	Gets the coordinates and vector for the top plane of this DimXpert cylinder.
 GetThread	Gets thread information for this DimXpert cylinder.

[Top](#)

 See Also

[IDimXpertCylinderFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)
IDimXpertCylinderFeature Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertCylinderFeature Interface
For a list of all members of this type, see [IDimXpertCylinderFeature members](#).

 Public Properties

Name	Description
 Inner	Gets whether this DimXpert cylinder is a hole or a pin.

[Top](#)

 See Also

[IDimXpertCylinderFeature Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)
GetNominalBottomPlane Method (IDimXpertCylinderFeature)
[See Also](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCylinderFeature Interface](#) : GetNominalBottomPlane Method (IDimXpertCylinderFeature)
Gets the coordinates and vector for the bottom plane of this DimXpert cylinder.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetNominalBottomPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _
```

```

    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDimXpertCylinderFeature
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetNominalBottomPlane(X, Y, Z, I, J, K)

```

C#

```

System.bool GetNominalBottomPlane(
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetNominalBottomPlane(
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)

```

Parameters

X
X-coordinate of the bottom plane

Y
Y-coordinate of the bottom plane

Z
Z-coordinate of the bottom plane

I
I component of the direction vector of the bottom plane

J
J component of the direction vector of the bottom plane

K
K component of the direction vector of the bottom plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCylinderFeature::GetNominalBottomPlane](#).

See Also

[IDimXpertCylinderFeature Interface](#)
[IDimXpertCylinderFeature Members](#)

Availability

GetNominalCylinder Method (IDimXpertCylinderFeature)[See Also](#)[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCylinderFeature Interface](#) : GetNominalCylinder Method (IDimXpertCylinderFeature)

Gets various attributes for this DimXpert cylinder.

 .NET Syntax

Visual Basic (Declaration)

```

Function GetNominalCylinder( _
    ByRef R As System.Double, _
    ByRef X As System.Double, _
    ByRef Y As System.Double, _
    ByRef Z As System.Double, _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



Copy Code

```

Dim instance As IDimXpertCylinderFeature
Dim R As System.Double
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

```

```
value = instance.GetNominalCylinder(R, X, Y, Z, I, J, K)
```

C#

```

System.bool GetNominalCylinder(
    out System.double R,
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetNominalCylinder(
    & [Out] System.double R,
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)

```

Parameters

R
Radius of the cylinder

X
X-coordinate of the cylinder

Y
Y-coordinate of the cylinder

Z
Z-coordinate of the cylinder

I
I component of the direction vector of the cylinder

J

J component of the direction vector of the cylinder
K
K component of the direction vector of the cylinder

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCylinderFeature::GetNominalCylinder](#).

See Also

[IDimXpertCylinderFeature Interface](#)
[IDimXpertCylinderFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetNominalTopPlane Method (IDimXpertCylinderFeature)

See Also [Example](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertCylinderFeature Interface](#) : GetNominalTopPlane Method (IDimXpertCylinderFeature)

Gets the coordinates and vector for the top plane of this DimXpert cylinder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalTopPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCylinderFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalTopPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalTopPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalTopPlane(  
& [Out] System.double X,  
& [Out] System.double Y,
```

```

& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)

```

Parameters

X

X-coordinate of the top plane

Y

Y-coordinate of the top plane

Z

Z-coordinate of the top plane

I

I component of the direction vector of the top plane

J

J component of the direction vector of the top plane

K

K component of the direction vector of the top plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCylinderFeature::GetNominalTopPlane](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)

[Get DimXpert Feature Example \(VB.NET\)](#)

See Also

[IDimXpertCylinderFeature Interface](#)

[IDimXpertCylinderFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetThread Method (IDimXpertCylinderFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCylinderFeature Interface](#) : GetThread Method (IDimXpertCylinderFeature)

Gets thread information for this DimXpert cylinder.

.NET Syntax

Visual Basic (Declaration)

```

Function GetThread( _
    ByRef IsThreaded As System.Boolean, _
    ByRef ThreadDesignation As System.String, _
    ByRef ThreadDepth As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDimXpertCylinderFeature
Dim IsThreaded As System.Boolean
Dim ThreadDesignation As System.String
Dim ThreadDepth As System.Double
Dim value As System.Boolean

```

```
value = instance.GetThread(IsThreaded, ThreadDesignation, ThreadDepth)
```

C#

```
System.bool GetThread(
    out System.bool IsThreaded,
    out System.string ThreadDesignation,
    out System.double ThreadDepth
)
```

C++/CLI

```
System.bool GetThread(
    & [Out] System.bool IsThreaded,
    & [Out] System.String^ ThreadDesignation,
    & [Out] System.double ThreadDepth
)
```

Parameters

IsThreaded

True if the cylinder is threaded; false otherwise

ThreadDesignation

Description of the thread

ThreadDepth

Depth of the thread for a threaded hole

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertCylinderFeature::GetThread](#).

Example

[Get DimXpert Feature Example \(VBA\)](#)

[Get DimXpert Feature Example \(VB.NET\)](#)

See Also

[IDimXpertCylinderFeature Interface](#)

[IDimXpertCylinderFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Inner Property (IDimXpertCylinderFeature)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertCylinderFeature Interface](#) : Inner Property (IDimXpertCylinderFeature)

Gets whether this DimXpert cylinder is a hole or a pin.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Inner As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertCylinderFeature
```

```
Dim value As System.Boolean
```

```
value = instance.Inner
```

C#

```
System.bool Inner {get;}
```

C++/CLI

```
property System.bool Inner {  
    System.bool get();  
}
```

Property Value

True if cylinder is a hole; false if a pin

Visual Basic for Applications (VBA) Syntax

See [DimXpertCylinderFeature.Inner](#).

See Also

[IDimXpertCylinderFeature Interface](#)
[IDimXpertCylinderFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertDatum (Type)

SOLIDWORKS DimXpert API Help

IDimXpertDatum Interface

See AlsoMembersExample

Send comments on this topic.

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDatum Interface

Allows you to access specific information about DimXpert datums on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertDatum

Visual Basic (Usage)

Dim instance As [IDimXpertDatum](#)

C#

public interface IDimXpertDatum

C++/CLI

public interface class IDimXpertDatum

Visual Basic for Applications (VBA) Syntax

See [DimXpertDatum](#).

Example

[Get and Set Datum Example \(C#\)](#)
[Get and Set Datum Example \(VB.NET\)](#)
[Get and Set Datum Example \(VBA\)](#)
[Get DimXpert Datum Example \(VBA\)](#)
[Get DimXpert Datum Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

Remarks

You can access more general annotation information using [IDimXpertAnnotation](#).

Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::IGetAppliedAnnotations](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::IGetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::IGetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertTolerance::GetPrimaryDatums](#), [IDimXpertTolerance::IGetPrimaryDatums](#), [IDimXpertTolerance::GetSecondaryDatums](#),
[IDimXpertTolerance::IGetSecondaryDatums](#), [IDimXpertTolerance::GetTertiaryDatums](#), [IDimXpertTolerance::IGetTertiaryDatums](#)

See Also

[IDimXpertDatum Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

IDimXpertDatum Interface Members

See AlsoProperties

Send comments on this topic.

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDatum Interface

The following tables list the members exposed by [IDimXpertDatum](#).

Public Properties

Name	Description
 Identifier	Gets the label for this DimXpert datum.

[Top](#)

See Also

[IDimXpertDatum Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertDatum Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDatum Interface

For a list of all members of this type, see [IDimXpertDatum members](#).

Public Properties

Name	Description
 Identifier	Gets the label for this DimXpert datum.

[Top](#)

See Also

[IDimXpertDatum Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

Identifier Property (IDimXpertDatum)

[See Also](#) [Example](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDatum Interface](#) : Identifier Property (IDimXpertDatum)

Gets the label for this DimXpert datum.

NET Syntax

Visual Basic (Declaration)

ReadOnly Property Identifier As System.String

Visual Basic (Usage)



```
Dim instance As IDimXpertDatum
Dim value As System.String

value = instance.Identifier
```

C#

```
System.string Identifier {get;}
```

C++/CLI

```
property System.String^ Identifier {
    System.String^ get();
}
```

Property Value

A label for the datum

Visual Basic for Applications (VBA) Syntax

See [DimXpertDatum::Identifier](#).

Example

[Get and Set Datum Example \(C#\)](#)
[Get and Set Datum Example \(VB.NET\)](#)
[Get and Set Datum Example \(VBA\)](#)
[Get DimXpert Datum Example \(VBA\)](#)
[Get DimXpert Datum Example \(VB.NET\)](#)

See Also

[IDimXpertDatum Interface](#)
[IDimXpertDatum Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertDepthDimTol (Type)

 ▾

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDepthDimTol Interface

Allows you to access specific information about DimXpert depth dimension tolerances for annotations on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertDepthDimTol

Visual Basic (Usage)  Copy Code

Dim instance As [IDimXpertDepthDimTol](#)

C#

public interface IDimXpertDepthDimTol

C++/CLI

public interface class IDimXpertDepthDimTol

 Visual Basic for Applications (VBA) Syntax

See [DimXpertDepthDimTol](#).

 Example

[Get DimXpert Datum Example \(VBA\)](#)
[Get DimXpert Datum Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general dimension tolerance information using [IDimXpertDimensionTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertDepthDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

 ▾

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDepthDimTol Interface

The following tables list the members exposed by [IDimXpertDepthDimTol](#).

 Public Properties

Name	Description
------	-------------

Name	Description
 ReferenceFeature	Gets the reference feature for this DimXpert depth dimension tolerance.

[Top](#)

Public Methods

Name	Description
 IsThreadDepth	Gets whether this dimension tolerance is for thread depth.

[Top](#)

See Also

[IDimXpertDepthDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertDepthDimTol Interface Methods
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDepthDimTol Interface

For a list of all members of this type, see [IDimXpertDepthDimTol members](#).

Public Methods

Name	Description
 IsThreadDepth	Gets whether this dimension tolerance is for thread depth.

[Top](#)

See Also

[IDimXpertDepthDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertDepthDimTol Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDepthDimTol Interface

For a list of all members of this type, see [IDimXpertDepthDimTol members](#).

Public Properties

Name	Description
 ReferenceFeature	Gets the reference feature for this DimXpert depth dimension tolerance.

[Top](#)

See Also

[IDimXpertDepthDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IsThreadDepth Method (IDimXpertDepthDimTol)
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDepthDimTol Interface](#) : IsThreadDepth Method (IDimXpertDepthDimTol)

Gets whether this dimension tolerance is for thread depth.

NET Syntax

Visual Basic (Declaration)

Function IsThreadDepth() As System.Boolean

Visual Basic (Usage) 

```
Dim instance As IDimXpertDepthDimTol  
Dim value As System.Boolean
```

```
value = instance.IsThreadDepth()
```

C#

```
System.bool IsThreadDepth()
```

C++/CLI

```
System.bool IsThreadDepth();
```

Return Value

True if the tolerance is for thread depth; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertDepthDimTol::IsThreadDepth](#).

See Also

[IDimXpertDepthDimTol Interface](#)
[IDimXpertDepthDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

ReferenceFeature Property (IDimXpertDepthDimTol)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDepthDimTol Interface](#) : ReferenceFeature Property (IDimXpertDepthDimTol)

Gets the reference feature for this DimXpert depth dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceFeature As DimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDepthDimTol  
Dim value As DimXpertFeature
```

```
value = instance.ReferenceFeature
```

C#

```
DimXpertFeature ReferenceFeature {get;}
```

C++/CLI

```
property DimXpertFeature^ ReferenceFeature {  
    DimXpertFeature^ get();  
}
```

Property Value

[IDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertDepthDimTol::ReferenceFeature](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertDepthDimTol Interface](#)
[IDimXpertDepthDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertDiameterDimTol (Type)

 ▾

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDiameterDimTol Interface

Allows you to access DimXpert diameter dimension tolerances.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertDiameterDimTol

Visual Basic (Usage)  Copy Code

Dim instance As [IDimXpertDiameterDimTol](#)

C#

public interface IDimXpertDiameterDimTol

C++/CLI

public interface class IDimXpertDiameterDimTol

 Visual Basic for Applications (VBA) Syntax

See [DimXpertDiameterDimTol](#).

 Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations in a Model Example \(C#\)](#)

 Remarks

Use the Dimension Size icon on the DimXpert toolbar to create diameter dimensions on closed curved faces.
You can access more general dimension tolerance information using [IDimXpertDimensionTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::!GetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::!GetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::!GetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertDiameterDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertRadiusDimTol Interface](#)

 ▾

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDiameterDimTol Interface

The following tables list the members exposed by [IDimXpertDiameterDimTol](#).

 Public Properties

Name	Description
 EnvelopeRequirement	Gets whether this diameter dimension tolerance has an envelope requirement.
 IndependencyRequirement	Gets whether this diameter dimension tolerance has an independency requirement.
 PatternTreatment	Gets the pattern treatment for this DimXpert diameter dimension tolerance.

[Top](#)

 See Also

[IDimXpertDiameterDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertRadiusDimTol Interface](#)

IDimXpertDiameterDimTol Interface Properties
[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDiameterDimTol Interface

For a list of all members of this type, see [IDimXpertDiameterDimTol members](#).

 Public Properties

Name	Description
 EnvelopeRequirement	Gets whether this diameter dimension tolerance has an envelope requirement.
 IndependencyRequirement	Gets whether this diameter dimension tolerance has an independency requirement.
 PatternTreatment	Gets the pattern treatment for this DimXpert diameter dimension tolerance.

[Top](#)

 See Also

[IDimXpertDiameterDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertRadiusDimTol Interface](#)

EnvelopeRequirement Property (IDimXpertDiameterDimTol)
[See Also](#) [Example](#)

  [SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDiameterDimTol Interface](#) : EnvelopeRequirement Property (IDimXpertDiameterDimTol)
Gets whether this diameter dimension tolerance has an envelope requirement.

 .NET Syntax

Visual Basic (Declaration)
<code>ReadOnly Property EnvelopeRequirement As System.Boolean</code>
Visual Basic (Usage)
 Copy Code <code>Dim instance As IDimXpertDiameterDimTol Dim value As System.Boolean value = instance.EnvelopeRequirement</code>
C#
<code>System.bool EnvelopeRequirement {get;}</code>
C++/CLI
<code>property System.bool EnvelopeRequirement { System.bool get(); }</code>

Property Value
True if envelope requirement, false if not

 Visual Basic for Applications (VBA) Syntax

See [DimXpertDiameterDimTol::EnvelopeRequirement](#).

Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations in a Model Example \(C#\)](#)

See Also

[IDimXpertDiameterDimTol Interface](#)
[IDimXpertDiameterDimTol Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IndependencyRequirement Property (IDimXpertDiameterDimTol)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDiameterDimTol Interface](#) : IndependencyRequirement Property (IDimXpertDiameterDimTol)

Gets whether this diameter dimension tolerance has an independency requirement.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property IndependencyRequirement As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimXpertDiameterDimTol  
Dim value As System.Boolean
```

```
value = instance.IndependencyRequirement
```

C#

```
System.bool IndependencyRequirement {get;}
```

C++/CLI

```
property System.bool IndependencyRequirement {  
    System.bool get();  
}
```

Property Value

True if independency requirement, false if not

Visual Basic for Applications (VBA) Syntax

See [DimXpertDiameterDimTol.IndependencyRequirement](#).

Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations in a Model Example \(C#\)](#)

See Also

[IDimXpertDiameterDimTol Interface](#)
[IDimXpertDiameterDimTol Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

PatternTreatment Property (IDimXpertDiameterDimTol)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDiameterDimTol Interface](#) : PatternTreatment Property (IDimXpertDiameterDimTol)

Gets the pattern treatment for this DimXpert diameter dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property PatternTreatment As [swDimXpertPatternTreatmentType_e](#)

Visual Basic (Usage)



```
Dim instance As IDimXpertDiameterDimTol  
Dim value As swDimXpertPatternTreatmentType\_e  
  
value = instance.PatternTreatment
```

C#

```
swDimXpertPatternTreatmentType\_e PatternTreatment {get;}
```

C++/CLI

```
property swDimXpertPatternTreatmentType\_e PatternTreatment {  
    swDimXpertPatternTreatmentType\_e get();  
}
```

Property Value

Pattern treatment type as defined in [swDimXpertPatternTreatmentType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertDiameterDimTol::PatternTreatment](#).

Example

[Get DimXpert Tolerance2 Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations in a Model Example \(C#\)](#)

See Also

[IDimXpertDiameterDimTol Interface](#)
[IDimXpertDiameterDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertDimensionOption (Type)

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDimensionOption Interface

Allows you to get and set options on datums, patterns, and dimensions.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic (.NET Syntax)

Visual Basic (Declaration)

Public Interface IDimXpertDimensionOption

Visual Basic (Usage)  Copy Code

Dim instance As [IDimXpertDimensionOption](#)

C#

public interface IDimXpertDimensionOption

C++/CLI

public interface class IDimXpertDimensionOption

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionOption](#).

Example

[Get and Set Size Dimension Example \(C#\)](#)
[Get and Set Size Dimension Example \(VB.NET\)](#)
[Get and Set Size Dimension Example \(VBA\)](#)

Accessors

[IDimXpertPart::GetDimOption](#)

See Also

[IDimXpertDimensionOption Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertPart::InsertDatum Method](#)
[IDimXpertPart::InsertLocationDimension Method](#)
[IDimXpertPart::InsertPattern Method](#)
[IDimXpertPart::InsertSizeDimension Method](#)
[IDimXpertPart::InsertBasicDimension Method](#)

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDimensionOption Interface

The following tables list the members exposed by [IDimXpertDimensionOption](#).

Public Properties

Name	Description
 DatumLength	Gets and sets the leader length of the datum.
 DimensionPositionOption	Obsolete. Superseded by IDimXpertDimensionOption::DimensionPositionOption2 .
 DimensionPositionOption2	Gets and sets the reference axis with which to dimension the location of a face with respect to another locating feature.
 FeatureSelectorOptions	Gets and sets the type of feature to dimension.
 TextPosition	Gets and sets coordinates of the dimension text.

See Also

[IDimXpertDimensionOption Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertPart::InsertDatum Method](#)
[IDimXpertPart::InsertLocationDimension Method](#)
[IDimXpertPart::InsertPattern Method](#)
[IDimXpertPart::InsertSizeDimension Method](#)
[IDimXpertPart::InsertBasicDimension Method](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertDimensionOption Interface Properties

[See Also](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDimensionOption Interface

For a list of all members of this type, see [IDimXpertDimensionOption members](#).

Public Properties

Name	Description
 DatumLength	Gets and sets the leader length of the datum.
 DimensionPositionOption	Obsolete. Superseded by IDimXpertDimensionOption::DimensionPositionOption2 .
 DimensionPositionOption2	Gets and sets the reference axis with which to dimension the location of a face with respect to another locating feature.
 FeatureSelectorOptions	Gets and sets the type of feature to dimension.
 TextPosition	Gets and sets coordinates of the dimension text.

[Top](#)

See Also

[IDimXpertDimensionOption Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertPart::InsertDatum Method](#)
[IDimXpertPart::InsertLocationDimension Method](#)
[IDimXpertPart::InsertPattern Method](#)
[IDimXpertPart::InsertSizeDimension Method](#)
[IDimXpertPart::InsertBasicDimension Method](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

DatumLength Property (IDimXpertDimensionOption)

[See Also](#) [Example](#)

[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDimensionOption Interface](#) : DatumLength Property (IDimXpertDimensionOption)

Gets and sets the leader length of the datum.

.NET Syntax

Visual Basic (Declaration)

```
Property DatumLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionOption  
Dim value As System.Double  
  
instance.DatumLength = value  
  
value = instance.DatumLength
```

C#

```
System.double DatumLength {get; set;}
```

C++/CLI

```
property System.double DatumLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

Property Value

Length of datum leader in meters.

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionOption::DatumLength](#).

Example

[Get and Set Datum Example \(C#\)](#)
[Get and Set Datum Example \(VB.NET\)](#)
[Get and Set Datum Example \(VBA\)](#)

See Also

[IDimXpertDimensionOption Interface](#)
[IDimXpertDimensionOption Members](#)
[IDimXpertPart::InsertDatum Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

DimensionPositionOption Property (IDimXpertDimensionOption)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDimensionOption Interface](#) : DimensionPositionOption Property (IDimXpertDimensionOption)
Obsolete. Superseded by [IDimXpertDimensionOption::DimensionPositionOption2](#).

.NET Syntax

Visual Basic (Declaration)

Property DimensionPositionOption As System.Integer

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionOption
Dim value As System.Integer

instance.DimensionPositionOption = value

value = instance.DimensionPositionOption
```

C#

```
System.int DimensionPositionOption {get; set;}
```

C++/CLI

```
property System.int DimensionPositionOption {
    System.int get();
    void set ( & System.int value);
}
```

Property Value

0, 1, or 2 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionOption::DimensionPositionOption](#).

Remarks

This property sets or returns:

- 0 to use a normal axis to dimension the location of a face with respect to its locating feature.
- 1 to use the horizontal axis to dimension the location of a face with respect to its locating feature.
- 2 to use the vertical axis to dimension the location of a face with respect to its locating feature.

See Also

[IDimXpertDimensionOption Interface](#)
[IDimXpertDimensionOption Members](#)
[IDimXpertPart.InsertLocationDimension Method](#)
[IDimXpertPart.InsertBasicDimension Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

DimensionPositionOption2 Property (IDimXpertDimensionOption)

[See Also](#) [Example](#)



SolidWorks.Interop.swdimxpert Namespace > [IDimXpertDimensionOption Interface](#) : DimensionPositionOption2 Property (IDimXpertDimensionOption)

Gets and sets the reference axis with which to dimension the location of a face with respect to another locating feature.

NET Syntax

Visual Basic (Declaration)

Property DimensionPositionOption2 As System.Integer

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionOption  
Dim value As System.Integer  
  
instance.DimensionPositionOption2 = value  
value = instance.DimensionPositionOption2
```

C#

```
System.int DimensionPositionOption2 {get; set;}
```

C++/CLI

```
property System.int DimensionPositionOption2 {  
    System.int get();  
    void set ( & System.int value);  
}
```

Property Value

Reference axis as defined in [swDimXpertDimensionPositionOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionOption::DimensionPositionOption2](#).

Example

[Get and Set Location Dimension \(VBA\)](#)
[Get and Set Location Dimension \(VB.NET\)](#)
[Get and Set Location Dimension \(C#\)](#)

See Also

[IDimXpertDimensionOption Interface](#)
[IDimXpertDimensionOption Members](#)
[IDimXpertPart.InsertLocationDimension Method \(\)](#)
[IDimXpertPart.InsertBasicDimension Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

FeatureSelectorOptions Property (IDimXpertDimensionOption)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDimensionOption Interface](#) : FeatureSelectorOptions Property (IDimXpertDimensionOption)

Gets and sets the type of feature to dimension.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureSelectorOptions As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionOption  
Dim value As System.Object  
  
instance.FeatureSelectorOptions = value  
  
value = instance.FeatureSelectorOptions
```

C#

```
System.object FeatureSelectorOptions {get; set;}
```

C++/CLI

```
property System.Object^ FeatureSelectorOptions {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

Property Value

Array of long values as defined in [swDimXpertFeatureSelectorOption e](#); however, only the first element in the array is used; all of the other elements, if any, in the array are ignored

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionOption::FeatureSelectorOptions](#).

Example

[Get and Set Pattern Example \(C#\)](#)
[Get and Set Pattern Example \(VB.NET\)](#)
[Get and Set Pattern Example \(VBA\)](#)

Remarks

Use this property to set the type of feature to dimension. For example, if you select a hole face and you want that face to be dimensioned as a cylinder, then make [swDimXpertFeatureSelectorOption e.swDimXpertFeatureSelectorOption_Cylinder](#) the first element in the FeatureSelectorOptions array.

See Also

[IDimXpertDimensionOption Interface](#)
[IDimXpertDimensionOption Members](#)
[IDimXpertPart::InsertDatum Method](#)
[IDimXpertPart::InsertSizeDimension Method](#)
[IDimXpertPart::InsertPattern Method](#)
[IDimXpertPart::InsertBasicDimension Method \(\)](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

TextPosition Property (IDimXpertDimensionOption)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDimensionOption Interface](#) : TextPosition Property (IDimXpertDimensionOption)

Gets and sets coordinates of the dimension text.

.NET Syntax

Property TextPosition As System.Object

```
Dim instance As IDimXpertDimensionOption  
Dim value As System.Object  
  
instance.TextPosition = value  
value = instance.TextPosition
```

```
System.Object TextPosition {get; set;}
```

```
property System.Object^ TextPosition {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

Property Value

Array of double values corresponding to x, y, and z coordinates of the dimension text

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionOption::TextPosition](#).

Example

[Get and Set Size Dimension Example \(C#\)](#)
[Get and Set Size Dimension Example \(VB.NET\)](#)
[Get and Set Size Dimension Example \(VBA\)](#)

See Also

[IDimXpertDimensionOption Interface](#)
[IDimXpertDimensionOption Members](#)
[IDimXpertPart::InsertSizeDimension Method](#)
[IDimXpertPart::InsertLocationDimension Method](#)
[IDimXpertPart::InsertBasicDimension Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

IDimXpertDimensionTolerance (Type)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertDimensionTolerance Interface

[See Also](#) [Members](#) [Example](#)

 

SolidWorks.Interop.swdimxpert Namespace : IDimXpertDimensionTolerance Interface

Allows you to access DimXpert dimension tolerance information for annotations on the DimXpertManager tab of the Management Panel.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertDimensionTolerance

Visual Basic (Usage)

Dim instance As [IDimXpertDimensionTolerance](#)

C#

public interface IDimXpertDimensionTolerance

C++/CLI

public interface class IDimXpertDimensionTolerance

 Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionTolerance](#).

 Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

This interface is the base class for several more specific interfaces (see the **See Also** section below). You can access more general annotation information using [IDimXpertAnnotation](#). Use the [IDimXpertAnnotation::Type](#) property to find out which specific interface is needed to acquire more information for a given DimXpert tolerance type.

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::IGetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::IGetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::IGetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertDimensionTolerance Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertAngleBetweenDimTol Interface](#)
[IDimXpertChamferDimTol Interface](#)
[IDimXpertCompositeDistanceBetweenDimTol Interface](#)
[IDimXpertCounterBoreDimTol Interface](#)
[IDimXpertCounterSinkAngleDimTol Interface](#)
[IDimXpertCounterSinkDiameterDimTol Interface](#)
[IDimXpertDepthDimTol Interface](#)
[IDimXpertDistanceBetweenDimTol Interface](#)
[IDimXpertDiameterDimTol Interface](#)
[IDimXpertRadiusDimTol Interface](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertDimensionTolerance Interface Methods

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDimensionTolerance Interface

For a list of all members of this type, see [IDimXpertDimensionTolerance members](#).

 Public Methods

Name	Description
 GetNominalValue	Gets the value of this DimXpert dimension tolerance.
 GetPlusAndMinusTolerance	Gets the plus and minus tolerance values for this DimXpert dimension tolerance.
 GetUpperAndLowerLimit	Gets the upper and lower tolerance limits for this DimXpert dimension tolerance.

[Top](#)

 See Also

[IDimXpertDimensionTolerance Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertAngleBetweenDimTol Interface](#)
[IDimXpertChamferDimTol Interface](#)
[IDimXpertCompositeDistanceBetweenDimTol Interface](#)
[IDimXpertCounterBoreDimTol Interface](#)
[IDimXpertCounterSinkAngleDimTol Interface](#)
[IDimXpertCounterSinkDiameterDimTol Interface](#)
[IDimXpertDepthDimTol Interface](#)
[IDimXpertDistanceBetweenDimTol Interface](#)
[IDimXpertDiameterDimTol Interface](#)
[IDimXpertRadiusDimTol Interface](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertDimensionTolerance Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDimensionTolerance Interface

The following tables list the members exposed by [IDimXpertDimensionTolerance](#).

 Public Properties

Name	Description
 BlockToleranceDecimalPlaces	Gets the precision of the block tolerance of this DimXpert dimension tolerance.
 DimensionType	Gets the type of this DimXpert dimension tolerance.
 LimitsAndFitsCode	Gets the limits and fits code for this DimXpert dimension tolerance.

[Top](#)

 Public Methods

Name	Description
 GetNominalValue	Gets the value of this DimXpert dimension tolerance.
 GetPlusAndMinusTolerance	Gets the plus and minus tolerance values for this DimXpert dimension tolerance.
 GetUpperAndLowerLimit	Gets the upper and lower tolerance limits for this DimXpert dimension tolerance.

[Top](#)

 See Also

[IDimXpertDimensionTolerance Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertAngleBetweenDimTol Interface](#)
[IDimXpertChamferDimTol Interface](#)
[IDimXpertCompositeDistanceBetweenDimTol Interface](#)
[IDimXpertCounterBoreDimTol Interface](#)
[IDimXpertCounterSinkAngleDimTol Interface](#)
[IDimXpertCounterSinkDiameterDimTol Interface](#)
[IDimXpertDepthDimTol Interface](#)
[IDimXpertDistanceBetweenDimTol Interface](#)
[IDimXpertDiameterDimTol Interface](#)
[IDimXpertRadiusDimTol Interface](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

IDimXpertDimensionTolerance Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDimensionTolerance Interface

For a list of all members of this type, see [IDimXpertDimensionTolerance members](#).

 Public Properties

Name	Description
 BlockToleranceDecimalPlaces	Gets the precision of the block tolerance of this DimXpert dimension tolerance.
 DimensionType	Gets the type of this DimXpert dimension tolerance.
 LimitsAndFitsCode	Gets the limits and fits code for this DimXpert dimension tolerance.

[Top](#)

See Also

[IDimXpertDimensionTolerance Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)
[IDimXpertAngleBetweenDimTol Interface](#)
[IDimXpertChamferDimTol Interface](#)
[IDimXpertCompositeDistanceBetweenDimTol Interface](#)
[IDimXpertCounterBoreDimTol Interface](#)
[IDimXpertCounterSinkAngleDimTol Interface](#)
[IDimXpertCounterSinkDiameterDimTol Interface](#)
[IDimXpertDepthDimTol Interface](#)
[IDimXpertDistanceBetweenDimTol Interface](#)
[IDimXpertDiameterDimTol Interface](#)
[IDimXpertRadiusDimTol Interface](#)

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

BlockToleranceDecimalPlaces Property (IDimXpertDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDimensionTolerance Interface](#) : BlockToleranceDecimalPlaces Property (IDimXpertDimensionTolerance)

Gets the precision of the block tolerance of this DimXpert dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property BlockToleranceDecimalPlaces As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionTolerance
Dim value As System.Integer

value = instance.BlockToleranceDecimalPlaces
```

C#

```
System.int BlockToleranceDecimalPlaces {get;}
```

C++/CLI

```
property System.int BlockToleranceDecimalPlaces {
    System.int get();
}
```

Property Value

Number of decimal places.

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionTolerance::BlockToleranceDecimalPlaces](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertDimensionTolerance Interface](#)
[IDimXpertDimensionTolerance Members](#)

Availability

DimensionType Property (IDimXpertDimensionTolerance)[See Also](#) [Example](#)SolidWorks.Interop.swdimxpert Namespace > [IDimXpertDimensionTolerance Interface](#) : DimensionType Property (IDimXpertDimensionTolerance)

Gets the type of this DimXpert dimension tolerance.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property DimensionType As [swDimXpertDimensionToleranceType_e](#)

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionTolerance
Dim value As swDimXpertDimensionToleranceType\_e

value = instance.DimensionType
```

C#

```
swDimXpertDimensionToleranceType\_e DimensionType {get;}
```

C++/CLI

```
property swDimXpertDimensionToleranceType\_e DimensionType {
    swDimXpertDimensionToleranceType\_e get();
}
```

Property ValueType of this DimXpert dimension tolerance as defined in [swDimXpertDimensionToleranceType_e](#) Visual Basic for Applications (VBA) SyntaxSee [DimXpertDimensionTolerance::DimensionType](#). Example[Get DimXpert Tolerance Example \(VBA\)](#)[Get DimXpert Tolerance Example \(VB.NET\)](#) See Also[IDimXpertDimensionTolerance Interface](#)[IDimXpertDimensionTolerance Members](#) Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetNominalValue Method (IDimXpertDimensionTolerance)[See Also](#) [Example](#)SolidWorks.Interop.swdimxpert Namespace > [IDimXpertDimensionTolerance Interface](#) : GetNominalValue Method (IDimXpertDimensionTolerance)

Gets the value of this DimXpert dimension tolerance.

 .NET Syntax

Visual Basic (Declaration)

Function GetNominalValue() As System.Double

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionTolerance
Dim value As System.Double
```

```
value = instance.GetNominalValue()
```

C#

```
System.double GetNominalValue()
```

C++/CLI

```
System.double GetNominalValue();
```

Return Value

Value of the dimension tolerance.

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionTolerance::GetNominalValue](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)

[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertDimensionTolerance Interface](#)

[IDimXpertDimensionTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetPlusAndMinusTolerance Method (IDimXpertDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDimensionTolerance Interface](#) : GetPlusAndMinusTolerance Method (IDimXpertDimensionTolerance)

Gets the plus and minus tolerance values for this DimXpert dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlusAndMinusTolerance( _  
    ByRef Plus As System.Double, _  
    ByRef Minus As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionTolerance  
Dim Plus As System.Double  
Dim Minus As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetPlusAndMinusTolerance(Plus, Minus)
```

C#

```
System.bool GetPlusAndMinusTolerance(  
    out System.double Plus,  
    out System.double Minus  
)
```

C++/CLI

```
System.bool GetPlusAndMinusTolerance(  
& [Out] System.double Plus,
```

```
& [Out] System.double Minus
)
```

Parameters

Plus
The plus value
Minus
The minus value

Return Value

True if the method call was successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionTolerance::GetPlusAndMinusTolerance](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertDimensionTolerance Interface](#)
[IDimXpertDimensionTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetUpperAndLowerLimit Method (IDimXpertDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDimensionTolerance Interface](#) : GetUpperAndLowerLimit Method (IDimXpertDimensionTolerance)

Gets the upper and lower tolerance limits for this DimXpert dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUpperAndLowerLimit( _  
    ByRef Upper As System.Double, _  
    ByRef Lower As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionTolerance  
Dim Upper As System.Double  
Dim Lower As System.Double  
Dim value As System.Boolean  
  
value = instance.GetUpperAndLowerLimit(Upper, Lower)
```

C#

```
System.bool GetUpperAndLowerLimit(  
    out System.double Upper,  
    out System.double Lower  
)
```

C++/CLI

```
System.bool GetUpperAndLowerLimit(  
& [Out] System.double Upper,  
& [Out] System.double Lower  
)
```

Parameters

Upper
Upper limit
Lower
Lower limit

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionTolerance::GetUpperAndLowerLimit](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertDimensionTolerance Interface](#)
[IDimXpertDimensionTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

LimitsAndFitsCode Property (IDimXpertDimensionTolerance)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDimensionTolerance Interface](#) : LimitsAndFitsCode Property (IDimXpertDimensionTolerance)

Gets the limits and fits code for this DimXpert dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LimitsAndFitsCode As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDimensionTolerance  
Dim value As System.String  
  
value = instance.LimitsAndFitsCode
```

C#

```
System.string LimitsAndFitsCode {get;}
```

C++/CLI

```
property System.String^ LimitsAndFitsCode {  
    System.String^ get();  
}
```

Property Value

Limits and fits code

Visual Basic for Applications (VBA) Syntax

See [DimXpertDimensionTolerance::LimitsAndFitsCode](#).

Example

[Get DimXpert Tolerance Example \(VBA\)](#)
[Get DimXpert Tolerance Example \(VB.NET\)](#)

See Also

[IDimXpertDimensionTolerance Interface](#)
[IDimXpertDimensionTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IDimXpertDistanceBetweenDimTol (Type)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDistanceBetweenDimTol Interface

Allows you to access DimXpert distance-between dimension tolerances.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface IDimXpertDistanceBetweenDimTol

Visual Basic (Usage) 

Dim instance As [IDimXpertDistanceBetweenDimTol](#)

C#

public interface IDimXpertDistanceBetweenDimTol

C++/CLI

public interface class IDimXpertDistanceBetweenDimTol

 Visual Basic for Applications (VBA) Syntax

See [DimXpertDistanceBetweenDimTol](#).

 Example

[Get and Set Location Dimension Example \(C#\)](#)
[Get and Set Location Dimension Example \(VB.NET\)](#)
[Get and Set Location Dimension Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)
[Get DimXpert Features and Annotations Example \(C#\)](#)

 Remarks

You can access more general dimension tolerance information using [IDimXpertDimensionTolerance](#).

 Accessors

[IDimXpertAnnotation::GetAppliedAnnotations](#) and [IDimXpertAnnotation::IGetAppliedAnnotations](#)
[IDimXpertPart::GetAnnotations](#) and [IDimXpertPart::IGetAnnotations](#)
[IDimXpertPart::GetAnnotation](#)
[IDimXpertFeature::GetAppliedAnnotations](#) and [IDimXpertFeature::IGetAppliedAnnotations](#)
[IFeature::GetSpecificFeature2](#)

 See Also

[IDimXpertDistanceBetweenDimTol Members](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

[SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDistanceBetweenDimTol Interface

The following tables list the members exposed by [IDimXpertDistanceBetweenDimTol](#).

 Public Properties

Name	Description
 PatternTreatment	Gets the pattern treatment for this DimXpert distance-between dimension tolerance.

[Top](#)

 Public Methods

Name	Description
 GetDirectionVector	Gets the direction vector for this DimXpert distance-between dimension tolerance.
 GetFeature	Gets the feature to which this DimXpert distance-between dimension tolerance is applied.
 GetOriginFeature	Gets the origin feature for this DimXpert distance-between dimension tolerance.

[Top](#)

 See Also

[IDimXpertDistanceBetweenDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertDistanceBetweenDimTol Interface Methods

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDistanceBetweenDimTol Interface

For a list of all members of this type, see [IDimXpertDistanceBetweenDimTol members](#).

 Public Methods

Name	Description
 GetDirectionVector	Gets the direction vector for this DimXpert distance-between dimension tolerance.
 GetFeature	Gets the feature to which this DimXpert distance-between dimension tolerance is applied.
 GetOriginFeature	Gets the origin feature for this DimXpert distance-between dimension tolerance.

[Top](#)

 See Also

[IDimXpertDistanceBetweenDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

IDimXpertDistanceBetweenDimTol Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdimxpert Namespace](#) : IDimXpertDistanceBetweenDimTol Interface

For a list of all members of this type, see [IDimXpertDistanceBetweenDimTol members](#).

 Public Properties

Name	Description
 PatternTreatment	Gets the pattern treatment for this DimXpert distance-between dimension tolerance.

[Top](#)

 See Also

[IDimXpertDistanceBetweenDimTol Interface](#)
[SolidWorks.Interop.swdimxpert Namespace](#)

SOLIDWORKS DimXpert API Help [Send comments on this topic.](#)

GetDirectionVector Method (IDimXpertDistanceBetweenDimTol)

[See Also](#) [Example](#)

 

[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDistanceBetweenDimTol Interface](#) : GetDirectionVector Method (IDimXpertDistanceBetweenDimTol)
Gets the direction vector for this DimXpert distance-between dimension tolerance.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionVector( _  
    ByRef I As System.Double, _
```

```

    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDimXpertDistanceBetweenDimTol
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetDirectionVector(I, J, K)

```

C#

```

System.bool GetDirectionVector(
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetDirectionVector(
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)

```

Parameters

[I](#)
I component of the direction vector
[J](#)
J component of the direction vector
[K](#)
K component of the direction vector

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertDistanceBetweenDimTol::GetDirectionVector](#).

Example

[Get and Set Location Dimension Example \(C#\)](#)
[Get and Set Location Dimension Example \(VB.NET\)](#)
[Get and Set Location Dimension Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

See Also

[IDimXpertDistanceBetweenDimTol Interface](#)
[IDimXpertDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetFeature Method (IDimXpertDistanceBetweenDimTol)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDistanceBetweenDimTol Interface](#) : GetFeature Method (IDimXpertDistanceBetweenDimTol)

Gets the feature to which this DimXpert distance-between dimension tolerance is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature( _
    ByRef Feature As DimXpertFeature, _
    ByRef FosUsage As swDimXpertDistanceFosUsage\_e _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDistanceBetweenDimTol
Dim Feature As DimXpertFeature
Dim FosUsage As swDimXpertDistanceFosUsage\_e
Dim value As System.Boolean

value = instance.GetFeature(Feature, FosUsage)
```

C#

```
System.bool GetFeature(
    out DimXpertFeature Feature,
    out swDimXpertDistanceFosUsage\_e FosUsage
)
```

C++/CLI

```
System.bool GetFeature(
    & [Out] DimXpertFeature^ Feature,
    & [Out] swDimXpertDistanceFosUsage\_e FosUsage
)
```

Parameters

Feature

[IDimXpertFeature](#)

FosUsage

Feature of size usage as defined in [swDimXpertDistanceFosUsage_e](#)

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertDistanceBetweenDimTol::GetFeature](#).

Example

[Get and Set Location Dimension Example \(C#\)](#)
[Get and Set Location Dimension Example \(VB.NET\)](#)
[Get and Set Location Dimension Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

See Also

[IDimXpertDistanceBetweenDimTol Interface](#)
[IDimXpertDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

GetOriginFeature Method (IDimXpertDistanceBetweenDimTol)

See Also [Example](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDistanceBetweenDimTol Interface](#) : GetOriginFeature Method (IDimXpertDistanceBetweenDimTol)

Gets the origin feature for this DimXpert distance-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOriginFeature( _
    ByRef Feature As DimXpertFeature, _
    ByRef FosUsage As swDimXpertDistanceFosUsage\_e _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimXpertDistanceBetweenDimTol
Dim Feature As DimXpertFeature
Dim FosUsage As swDimXpertDistanceFosUsage\_e
Dim value As System.Boolean

value = instance.GetOriginFeature(Feature, FosUsage)
```

C#

```
System.bool GetOriginFeature(
    out DimXpertFeature Feature,
    out swDimXpertDistanceFosUsage\_e FosUsage
)
```

C++/CLI

```
System.bool GetOriginFeature(
    & [Out] DimXpertFeature^ Feature,
    & [Out] swDimXpertDistanceFosUsage\_e FosUsage
)
```

Parameters

Feature

[IDimXpertFeature](#)

FosUsage

Feature of size usage as defined in [swDimXpertDistanceFosUsage_e](#)

Return Value

True if the method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [DimXpertDistanceBetweenDimTol::GetOriginFeature](#).

Example

[Get and Set Location Dimension Example \(C#\)](#)
[Get and Set Location Dimension Example \(VB.NET\)](#)
[Get and Set Location Dimension Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VBA\)](#)
[Get DimXpert Tolerance2 Example \(VB.NET\)](#)

See Also

[IDimXpertDistanceBetweenDimTol Interface](#)
[IDimXpertDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS DimXpert API Help

[Send comments on this topic.](#)

PatternTreatment Property (IDimXpertDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdimxpert Namespace](#) > [IDimXpertDistanceBetweenDimTol Interface](#) : PatternTreatment Property (IDimXpertDistanceBetweenDimTol)

Gets the pattern treatment for this DimXpert distance-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property PatternTreatment As [swDimXpertPatternTreatmentType_e](#)

Visual Basic (Usage)



```
Dim instance As IDimXpertDistanceBetweenDimTol  
Dim value As swDimXpertPatternTreatmentType\_e
```

```
value = instance.PatternTreatment
```

C#

```
swDimXpertPatternTreatmentType\_e PatternTreatment {get;}
```

C++/CLI

```
property swDimXpertPatternTreatmentType\_e PatternTreatment {  
    swDimXpertPatternTreatmentType\_e get();  
}
```

Property Value

Pattern treatment type as defined in [swDimXpertPatternTreatmentType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertDistanceBetweenDimTol::PatternTreatment](#).

See Also

[IDimXpertDistanceBetweenDimTol Interface](#)
[IDimXpertDistanceBetweenDimTol Members](#)

Availability