

SOLIDWORKS Document Manager API (.NET) — Reference (2/19): ISwDMComponent3- ISwDMConfiguration

SOLIDWORKS API Documentation (converted from CHM)

ISwDMComponent3 (Type)

ISwDMComponent3 Interface

[See Also](#) [Members](#) [Example](#)



SolidWorks.Interop.swdocumentmgr.Namespace : ISwDMComponent3 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent3
    Inherits ISwDMComponent, ISwDMComponent2
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent3
```

C#

```
public interface ISwDMComponent3 : ISwDMComponent, ISwDMComponent2
```

C++/CLI

```
public interface class ISwDMComponent3 : public ISwDMComponent, ISwDMComponent2
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent3](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

Remarks

- You can access an ISwDMComponent3 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be assigned to an ISwDMComponent3 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent3 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent3 Interface Members

[See Also](#) [Properties](#) [Methods](#)



SolidWorks.Interop.swdocumentmgr.Namespace : ISwDMComponent3 Interface

The following tables list the members exposed by [ISwDMComponent3](#).

Public Properties

Name	Description
 IsVirtual	Gets whether this component is a virtual component. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 Public Methods

Name	Description
 GetDocument	Obsolete. Superseded by ISwDMComponent4 - GetDocument2

[Top](#)

 See Also

[ISwDMComponent3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent3 Interface Methods

[See Also](#)

 SolidWorks.Interop.swdocumentmgr Namespace : ISwDMComponent3 Interface
--

For a list of all members of this type, see [ISwDMComponent3 members](#).

 Public Methods

Name	Description
 GetDocument	Obsolete. Superseded by ISwDMComponent4 - GetDocument2

[Top](#)

 See Also

[ISwDMComponent3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent3 Interface Properties

[See Also](#)

 SolidWorks.Interop.swdocumentmgr Namespace : ISwDMComponent3 Interface
--

For a list of all members of this type, see [ISwDMComponent3 members](#).

 Public Properties

Name	Description
 IsVirtual	Gets whether this component is a virtual component. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 See Also

[ISwDMComponent3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetDocument Method (ISwDMComponent3)

[See Also](#)

SolidWorks.Interop.swdocumentmgr Namespace > [ISwDMComponent3 Interface](#) : GetDocument Method (ISwDMComponent3)

Obsolete. Superseded by [ISwDMComponent4::GetDocument2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function GetDocument(  
    ByVal allowReadOnly As System.Boolean, _  
    ByRef result As SwDmDocumentOpenError _  
) As SwDMDocument
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent3  
Dim allowReadOnly As System.Boolean  
Dim result As SwDmDocumentOpenError  
Dim value As SwDMDocument  
  
value = instance.GetDocument(allowReadOnly, result)
```

C#

```
SwDMDocument GetDocument(  
    System.bool allowReadOnly,  
    out SwDmDocumentOpenError result  
)
```

C++/CLI

```
SwDMDocument^ GetDocument(  
& System.bool allowReadOnly,  
& [Out] SwDmDocumentOpenError result  
)
```

Parameters

allowReadOnly
True to open the document as read-only, false as read-write
result
Error as defined by [SwDmDocumentOpenError](#)

Return Value

Pointer to the [ISwDMDocument](#) object

 Visual Basic for Applications (VBA) Syntax

See [SwDMComponent3::GetDocument](#).

 See Also

[ISwDMComponent3 Interface](#)
[ISwDMComponent3 Members](#)

 Availability

SOLIDWORKS Document Manager API 2008 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsVirtual Property (ISwDMComponent3)

[See Also](#)

SolidWorks.Interop.swdocumentmgr Namespace > [ISwDMComponent3 Interface](#) : IsVirtual Property (ISwDMComponent3)

Gets whether this component is a virtual component.

NOTE: This property is a get-only property. Set is not implemented.

 .NET Syntax

Visual Basic (Declaration)

```
Property IsVirtual As System.Boolean
```

```
Dim instance As ISwDMComponent3
Dim value As System.Boolean

instance.IsVirtual = value

value = instance.IsVirtual
```

C#

```
System.bool IsVirtual {get; set;}
```

C++/CLI

```
property System.bool IsVirtual {
    System.bool get();
    void set ( & System.bool value);
}
```

Property Value

True if this component is virtual, false if not

 Visual Basic for Applications (VBA) Syntax

See [SwDMComponent3::IsVirtual](#).

 Remarks

This property is only valid for assemblies saved in SOLIDWORKS 2008 and later. See the SOLIDWORKS Help for information about virtual components.

 See Also

[ISwDMComponent3 Interface](#)
[ISwDMComponent3 Members](#)

 Availability

SOLIDWORKS Document Manager API 2008 FCS

ISwDMComponent4 (Type)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent4 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent4 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent4
    Inherits ISwDMComponent, ISwDMComponent2, ISwDMComponent3
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent4
```

C#

```
public interface ISwDMComponent4 : ISwDMComponent, ISwDMComponent2, ISwDMComponent3
```

C++/CLI

```
public interface class ISwDMComponent4 : public ISwDMComponent, ISwDMComponent2, ISwDMComponent3
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent4](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

Remarks

- You can access an ISwDMComponent4 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be assigned to an ISwDMComponent4 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent4 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent4 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent4 Interface

The following tables list the members exposed by [ISwDMComponent4](#).

Public Methods

Name	Description
 GetDocument2	Gets this component's document using the specified search options.

[Top](#)

See Also

[ISwDMComponent4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent4 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : [ISwDMComponent4 Interface](#)

For a list of all members of this type, see [ISwDMComponent4 members](#).

Public Methods

Name	Description
 GetDocument2	Gets this component's document using the specified search options.

[Top](#)

See Also

[ISwDMComponent4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetDocument2 Method (ISwDMComponent4)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent4 Interface](#) : [GetDocument2 Method \(ISwDMComponent4\)](#)

Gets this component's document using the specified search options.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocument2( _  
    ByVal allowReadOnly As System.Boolean, _  
    ByVal pSrcOption As SwDMSearchOption, _  
    ByRef result As SwDmDocumentOpenError _  
) As SwDMDocument
```

Visual Basic (Usage)

```
Dim instance As ISwDMComponent4  
Dim allowReadOnly As System.Boolean  
Dim pSrcOption As SwDMSearchOption  
Dim result As SwDmDocumentOpenError  
Dim value As SwDMDocument
```

```
value = instance.GetDocument2(allowReadOnly, pSrcOption, result)
```

C#

```
SwDMDocument GetDocument2(  
    System.bool allowReadOnly,  
    SwDMSearchOption pSrcOption,  
    out SwDmDocumentOpenError result  
)
```

C++/CLI

```
SwDMDocument^ GetDocument2(  
&    System.bool allowReadOnly,
```



```
& SwDMSearchOption^ pSrcOption,  
& [Out] SwDmDocumentOpenError result  
)
```

Parameters

allowReadOnly

True to open the document as read-only, false as read-write

pSrcOption

[Search options](#)

result

Error as defined by [ISwDMDocumentOpenError](#)

Return Value

[ISwDMDocument](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent4::GetDocument2](#).

See Also

[ISwDMComponent4 Interface](#)

[ISwDMComponent4 Members](#)

Availability

SOLIDWORKS Document Manager API 2008 SP1

ISwDMComponent5 (Type)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent5 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent5 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent5
    Inherits ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4
```

Visual Basic (Usage)

```
Dim instance As ISwDMComponent5
```

C#

```
public interface ISwDMComponent5 : ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4
```

C++/CLI

```
public interface class ISwDMComponent5 : public
ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent5](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

Remarks

- You can access an ISwDMComponent5 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be assigned to an ISwDMComponent5 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent5 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent5 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent5 Interface

The following tables list the members exposed by [ISwDMComponent5](#).

Public Properties

Name	Description
ExcludeFromBOM	Gets whether this component is excluded from the bill of materials (BOM).

[Top](#)

Public Methods

Name	Description
 IsEnvelope	Gets whether this component is an envelope.

[Top](#)

See Also

[ISwDMComponent5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent5 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : [ISwDMComponent5 Interface](#)

For a list of all members of this type, see [ISwDMComponent5 members](#).

Public Methods

Name	Description
 IsEnvelope	Gets whether this component is an envelope.

[Top](#)

See Also

[ISwDMComponent5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent5 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : [ISwDMComponent5 Interface](#)

For a list of all members of this type, see [ISwDMComponent5 members](#).

Public Properties

Name	Description
 ExcludeFromBOM	Gets whether this component is excluded from the bill of materials (BOM).

[Top](#)

See Also

[ISwDMComponent5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ExcludeFromBOM Property (ISwDMComponent5)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent5 Interface](#) : [ExcludeFromBOM Property \(ISwDMComponent5\)](#)

Gets whether this component is excluded from the bill of materials (BOM).

 **.NET Syntax**

Visual Basic (Declaration)

Property ExcludeFromBOM As System.Integer

Visual Basic (Usage)

Copy Code

```
Dim instance As ISwDMComponent5
Dim value As System.Integer

instance.ExcludeFromBOM = value

value = instance.ExcludeFromBOM
```

C#

System.int ExcludeFromBOM {get; set;}

C++/CLI

property System.int ExcludeFromBOM {
 System.int get();
 void set (& System.int value);
}

Property Value

Exclude or include this component from the BOM as defined in [swDmExcludeFromBOMResults](#)

 **Visual Basic for Applications (VBA) Syntax**

See [SwDMComponent5::ExcludeFromBOM](#).

 **Example**

[Get Whether Component Is Envelope And Excluded From BOM \(VB.NET\)](#)
[Get Whether Component Is Envelope And Excluded From BOM \(C#\)](#)

 **Remarks**

This method only supports documents saved in SOLIDWORKS 2009 SP0 and later.

 **See Also**

[ISwDMComponent5 Interface](#)
[ISwDMComponent5 Members](#)
[ISwDMConfiguration11::ShowChildComponentsInBOM Property](#)
[ISwDMConfiguration11::BOMPartNoSource Property](#)
[ISwDMTable2::GetBOMNumberIncrement Method](#)
[ISwDMTable2::GetBOMStartNumber Method](#)
[ISwDMTable2::GetBOMTableType Method](#)
[ISwDMTable2::GetFeatureName Method](#)
[ISwDMTable2::ReferencedConfigurationNames Method](#)
[ISwDMTable2::ReferencedDocumentName Method](#)

 **Availability**

SOLIDWORKS Document Manager API 2008 SP2

SOLIDWORKS Document Manager API Help

IsEnvelope Method (ISwDMComponent5)

[See Also](#) [Example](#)

 

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent5 Interface](#) : IsEnvelope Method (ISwDMComponent5)

Gets whether this component is an envelope.

 **.NET Syntax**

Visual Basic (Declaration)

Function IsEnvelope() As System.Boolean

Visual Basic (Usage)

Copy Code

```
Dim instance As ISwDMComponent5  
Dim value As System.Boolean  
  
value = instance.IsEnvelope()
```

C#

```
System.bool IsEnvelope()
```

C++/CLI

```
System.bool IsEnvelope();
```

Return Value

True if this component is an envelope, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent5.IsEnvelope](#).

Example

[Get Whether Component Is Envelope And Excluded From BOM \(VB.NET\)](#)
[Get Whether Component Is Envelope And Excluded From BOM \(C#\)](#)

See Also

[ISwDMComponent5 Interface](#)
[ISwDMComponent5 Members](#)

Availability

SOLIDWORKS Document Manager API 2008 SP2

ISwDMComponent6 (Type)

ISwDMComponent6 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent6 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent6
    Inherits ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent6
```

C#

```
public interface ISwDMComponent6 :
ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5
```

C++/CLI

```
public interface class ISwDMComponent6 : public
ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent6](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

Remarks

- You can access an ISwDMComponent6 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be assigned to an ISwDMComponent6 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent6 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent6 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent6 Interface

For a list of all members of this type, see [ISwDMComponent6 members](#).

Public Methods

Name	Description
Replace	Replace this component with the specified component.



[Top](#)

See Also

[ISwDMComponent6 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent6 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent6 Interface

The following tables list the members exposed by [ISwDMComponent6](#).

Public Properties

Name	Description
 PathName	Gets the path for this component.

[Top](#)

Public Methods

Name	Description
 Replace	Replace this component with the specified component.

[Top](#)

See Also

[ISwDMComponent6 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent6 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent6 Interface

For a list of all members of this type, see [ISwDMComponent6 members](#).

Public Properties

Name	Description
 PathName	Gets the path for this component.

[Top](#)

See Also

[ISwDMComponent6 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

PathName Property (ISwDMComponent6)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent6 Interface](#) : PathName Property (ISwDMComponent6)

Gets the path for this component.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PathName As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent6  
Dim value As System.String  
  
value = instance.PathName
```

C#

```
System.string PathName {get;}
```

C++/CLI

```
property System.String^ PathName {  
    System.String^ get();  
}
```

Property Value

Path

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent6::PathName](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

See Also

[ISwDMComponent6 Interface](#)
[ISwDMComponent6 Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Replace Method (ISwDMComponent6)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent6 Interface](#) : Replace Method (ISwDMComponent6)

Replace this component with the specified component.

.NET Syntax

Visual Basic (Declaration)

```
Function Replace(  
    ByVal fileName As System.String, _  
    ByVal configurationName As System.String, _  
    ByVal ReattachMates As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As ISwDMComponent6
Dim fileName As System.String
Dim ConfigurationName As System.String
Dim ReattachMates As System.Boolean
Dim value As System.Boolean

value = instance.Replace(fileName, ConfigurationName, ReattachMates)

```

C#

```

System.bool Replace(
    System.string fileName,
    System.string ConfigurationName,
    System.bool ReattachMates
)

```

C++/CLI

```

System.bool Replace(
    & System.String^ fileName,
    & System.String^ ConfigurationName,
    & System.bool ReattachMates
)

```

Parameters

fileName
Path and file name of the component to replace this component

ConfigurationName
Configuration of the component to replace this component

ReattachMates
True to reattach mates to the component that replaced this component, false to not

Return Value

True if the operation succeeds, false if it fails

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent6::Replace](#).

Example

[Replace Component \(C#\)](#)
[Replace Component \(VB.NET\)](#)

Remarks

Call [ISwDMConfiguration11::GetReplacedComponents](#) to get information about replaced components in an assembly.

NOTE: If you call [ISwComponent6::PathName](#) after calling [ISwDMComponent6::Replace](#) and before opening and saving an assembly, then the path to the original component is returned, not the path to the replaced component. References to replaced components are not updated until the assembly is opened and saved in SOLIDWORKS.

See Also

[ISwDMComponent6 Interface](#)
[ISwDMComponent6 Members](#)
[ISwDMDocument8::GetChangedReferences Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

ISwDMComponent7 (Type)

ISwDMComponent7 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent7 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent7
    Inherits
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent7
```

C#

```
public interface ISwDMComponent7 :
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6
```

C++/CLI

```
public interface class ISwDMComponent7 : public
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent7](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)

Remarks

- You can access an ISwDMComponent7 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be assigned to an ISwDMComponent7 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent7 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent7 Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent7 Interface

The following tables list the members exposed by [ISwDMComponent7](#).

Public Properties

Name	Description
------	-------------

 Name2	Obsolete. Superseded by ISwDMComponent11-Name3
 SelectName	Obsolete. Superseded by ISwDMComponent11-SelectName2

[Top](#)

See Also

- [ISwDMComponent7 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMComponent2 Interface](#)
- [ISwDMComponent3 Interface](#)
- [ISwDMComponent4 Interface](#)
- [ISwDMComponent5 Interface](#)
- [ISwDMComponent6 Interface](#)
- [ISwDMComponent8 Interface](#)
- [ISwDMComponent9 Interface](#)
- [ISwDMComponent10 Interface](#)
- [ISwDMComponent11 Interface](#)
- [ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent7 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent7 Interface

For a list of all members of this type, see [ISwDMComponent7 members](#).

Public Properties

Name	Description
 Name2	Obsolete. Superseded by ISwDMComponent11-Name3
 SelectName	Obsolete. Superseded by ISwDMComponent11-SelectName2

[Top](#)

See Also

- [ISwDMComponent7 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMComponent2 Interface](#)
- [ISwDMComponent3 Interface](#)
- [ISwDMComponent4 Interface](#)
- [ISwDMComponent5 Interface](#)
- [ISwDMComponent6 Interface](#)
- [ISwDMComponent8 Interface](#)
- [ISwDMComponent9 Interface](#)
- [ISwDMComponent10 Interface](#)
- [ISwDMComponent11 Interface](#)
- [ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Name2 Property (ISwDMComponent7)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent7 Interface](#) : Name2 Property (ISwDMComponent7)

Obsolete. Superseded by [ISwDMComponent11-Name3](#).

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Name2 As System.String

Visual Basic (Usage)



```
Dim instance As ISwDMComponent7
Dim value As System.String

value = instance.Name2
```

C#

```
System.string Name2 {get;}
```

C++/CLI

```
property System.String^ Name2 {
    System.String^ get();
}
```

Property Value

Name of the component appended with an index value

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent7::Name2](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)

Remarks

This property returns the component name appended with an index in the format, "component-1".

See Also

[ISwDMComponent7 Interface](#)
[ISwDMComponent7 Members](#)
[ISwDMComponent7::SelectName Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SelectName Property (ISwDMComponent7)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent7 Interface](#) : SelectName Property (ISwDMComponent7)

Obsolete. Superseded by [ISwDMComponent11::SelectName2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SelectName As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent7  
Dim value As System.String  
  
value = instance.SelectName
```

C#

```
System.string SelectName {get;}
```

C++/CLI

```
property System.String^ SelectName {  
    System.String^ get();  
}
```

Property Value

Name to use during a selective open

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent7::SelectName](#).

See Also

[ISwDMComponent7 Interface](#)
[ISwDMComponent7 Members](#)
[ISwDMComponent7::Name2 Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMComponent8 (Type)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent8 Interface

[See Also](#) [Members](#) [Example](#)



SolidWorks.Interop.swdocumentmgr Namespace : ISwDMComponent8 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent8
    Inherits
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent8
```

C#

```
public interface ISwDMComponent8 :
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7
```

C++/CLI

```
public interface class ISwDMComponent8 : public
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent8](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)

Remarks

- You can access an ISwDMComponent8 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be assigned to an ISwDMComponent8 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent8 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent8 Interface Members

[See Also](#) [Properties](#)



SolidWorks.Interop.swdocumentmgr Namespace : ISwDMComponent8 Interface

The following tables list the members exposed by [ISwDMComponent8](#).

Public Properties

Name	Description
 ConfigurationID	Gets the ID of the configuration of this component.

[Top](#)

See Also

[ISwDMComponent8 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent8 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : [ISwDMComponent8 Interface](#)

For a list of all members of this type, see [ISwDMComponent8 members](#).

Public Properties

Name	Description
 ConfigurationID	Gets the ID of the configuration of this component.

[Top](#)

See Also

[ISwDMComponent8 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent9 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ConfigurationID Property (ISwDMComponent8)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent8 Interface](#) : [ConfigurationID Property \(ISwDMComponent8\)](#)

Gets the ID of the configuration of this component.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ConfigurationID As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent8  
Dim value As System.Integer  
  
value = instance.ConfigurationID
```

C#

```
System.int ConfigurationID {get;}
```

C++/CLI

```
property System.int ConfigurationID {  
    System.int get();  
}
```

Property Value

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent8::ConfigurationID](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)

Remarks

SOLIDWORKS does not update suppressed assembly components with changes that occur in referenced documents. For instance, if a component's configuration is renamed, the suppressed component in the assembly is not updated with the new configuration name.

To find the current configuration name of a suppressed component in an assembly, query the referenced component document for the name of the configuration whose ID matches ISwDMComponent8::ConfigurationID.

See Also

[ISwDMComponent8 Interface](#)
[ISwDMComponent8 Members](#)

Availability

SOLIDWORKS 2010 SP05, Revision Number 18.5 and SOLIDWORKS 2011 SP01, Revision Number 19.1

ISwDMComponent9 (Type)

ISwDMComponent9 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent9 Interface

Accesses a component's data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMComponent9
    Inherits
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent9
```

C#

```
public interface ISwDMComponent9 :
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8
```

C++/CLI

```
public interface class ISwDMComponent9 : public
    ISwDMComponent, ISwDMComponent2, ISwDMComponent3, ISwDMComponent4, ISwDMComponent5, ISwDMComponent6, ISwDMComponent7, ISwDMComponent8
```

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent9](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

Remarks

- You can access an ISwDMComponent9 object by calling QueryInterface on an [ISwDMComponent](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMComponent object can be assigned to an ISwDMComponent9 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration2::GetComponents](#)

See Also

[ISwDMComponent9 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

ISwDMComponent9 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent9 Interface

For a list of all members of this type, see [ISwDMComponent9 members](#).

 Public Methods

Name	Description
 GetID	Gets the ID of the component.

[Top](#)

 See Also

[ISwDMComponent9 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMComponent9 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMComponent9 Interface

The following tables list the members exposed by [ISwDMComponent9](#).

 Public Methods

Name	Description
 GetID	Gets the ID of the component.

[Top](#)

 See Also

[ISwDMComponent9 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMComponent2 Interface](#)
[ISwDMComponent3 Interface](#)
[ISwDMComponent4 Interface](#)
[ISwDMComponent5 Interface](#)
[ISwDMComponent6 Interface](#)
[ISwDMComponent7 Interface](#)
[ISwDMComponent8 Interface](#)
[ISwDMComponent10 Interface](#)
[ISwDMComponent11 Interface](#)
[ISwDMComponent12 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetID Method (ISwDMComponent9)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMComponent9 Interface](#) : GetID Method (ISwDMComponent9)

Gets the ID of the component.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetID() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMComponent9  
Dim value As System.Integer  
  
value = instance.GetID()
```

C#

```
System.int GetID()
```

C++/CLI

```
System.int GetID();
```

Return Value

ID of the component

Visual Basic for Applications (VBA) Syntax

See [SwDMComponent9::GetID](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

See Also

[ISwDMComponent9 Interface](#)
[ISwDMComponent9 Members](#)

Availability

SOLIDWORKS Document Manager API 2014 SP0

ISwDMConfiguration (Type)

ISwDMConfiguration Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMConfiguration
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration
```

C#

```
public interface ISwDMConfiguration
```

C++/CLI

```
public interface class ISwDMConfiguration
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration](#).

Example

[Write Parasolid Partition Stream to File \(C#\)](#)
[Write Parasolid Partition Stream to File \(VB.NET\)](#)

Accessors

[ISwDMConfigurationMgr.GetConfigurationByName](#)

See Also

[ISwDMConfiguration Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration Interface

The following tables list the members exposed by [ISwDMConfiguration](#).

Public Properties

Name	Description
 Application	Gets the application for this configuration.
 Description	Gets or sets the description for this configuration.
 Document	Gets the document for this configuration.

 Name	Obsolete. Superseded by ISwDMConfiguration7-Name2
 PreviewStreamName	Gets the name of the stream for the preview bitmap of this configuration.
 StreamName	Gets the name of the stream for the configuration.

[Top](#)

Public Methods

Name	Description
 AddCustomProperty	Adds a custom property to this configuration.
 DeleteCustomProperty	Deletes the specified custom property from this configuration.
 GetBodiesCount	Gets the number of solid bodies for this configuration.
 GetBody	Gets the body at the specified index in the specified Parasolid binary file (filename extension .x_b).
 GetCustomProperty	Gets the specified custom property for this configuration.
 GetCustomPropertyCount	Gets the number of custom properties for this configuration.
 GetCustomPropertyNames	Gets the names of the custom properties for this configuration.
 GetLastUpdateStamp	Gets the date that this configuration was last updated.
 GetMassProperties	Gets the mass properties, if valid, for this configuration.
 GetParentConfigurationName	Gets the name of the parent configuration for this configuration.
 GetPreviewBitmap	Gets the preview bitmap for this configuration.
 SetCustomProperty	Obsolete. Superseded by ISwDMConfiguration18-SetCustomProperty2

[Top](#)

See Also

[ISwDMConfiguration Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMConfiguration Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : [ISwDMConfiguration Interface](#)

For a list of all members of this type, see [ISwDMConfiguration members](#).

Public Methods

Name	Description
 AddCustomProperty	Adds a custom property to this configuration.
 DeleteCustomProperty	Deletes the specified custom property from this configuration.
 GetBodiesCount	Gets the number of solid bodies for this configuration.
 GetBody	Gets the body at the specified index in the specified Parasolid binary file (filename extension .x_b).
 GetCustomProperty	Gets the specified custom property for this configuration.
 GetCustomPropertyCount	Gets the number of custom properties for this configuration.
 GetCustomPropertyNames	Gets the names of the custom properties for this configuration.
 GetLastUpdateStamp	Gets the date that this configuration was last updated.
 GetMassProperties	Gets the mass properties, if valid, for this configuration.
 GetParentConfigurationName	Gets the name of the parent configuration for this configuration.
 GetPreviewBitmap	Gets the preview bitmap for this configuration.

[Top](#)

 See Also

- [ISwDMConfiguration Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMConfiguration2 Interface](#)
- [ISwDMConfiguration3 Interface](#)
- [ISwDMConfiguration4 Interface](#)
- [ISwDMConfiguration5 Interface](#)
- [ISwDMConfiguration6 Interface](#)
- [ISwDMConfiguration7 Interface](#)
- [ISwDMConfiguration8 Interface](#)
- [ISwDMConfiguration9 Interface](#)
- [ISwDMConfiguration10 Interface](#)
- [ISwDMConfiguration11 Interface](#)
- [ISwDMConfiguration12 Interface](#)
- [ISwDMConfiguration13 Interface](#)
- [ISwDMConfiguration14 Interface](#)
- [ISwDMConfiguration15 Interface](#)
- [ISwDMConfiguration16 Interface](#)
- [ISwDMConfigurationMgr2 Interface](#)
- [ISwDMConfiguration17 Interface](#)
- [ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMConfiguration Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration Interface

For a list of all members of this type, see [ISwDMConfiguration members](#).

 Public Properties

Name	Description
 Application	Gets the application for this configuration.
 Description	Gets or sets the description for this configuration.
 Document	Gets the document for this configuration.
 Name	Obsolete. Superseded by ISwDMConfiguration7-Name2 .
 PreviewStreamName	Gets the name of the stream for the preview bitmap of this configuration.
 StreamName	Gets the name of the stream for the configuration.

[Top](#)

 See Also

- [ISwDMConfiguration Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMConfiguration2 Interface](#)
- [ISwDMConfiguration3 Interface](#)
- [ISwDMConfiguration4 Interface](#)
- [ISwDMConfiguration5 Interface](#)
- [ISwDMConfiguration6 Interface](#)
- [ISwDMConfiguration7 Interface](#)
- [ISwDMConfiguration8 Interface](#)
- [ISwDMConfiguration9 Interface](#)
- [ISwDMConfiguration10 Interface](#)
- [ISwDMConfiguration11 Interface](#)
- [ISwDMConfiguration12 Interface](#)
- [ISwDMConfiguration13 Interface](#)
- [ISwDMConfiguration14 Interface](#)
- [ISwDMConfiguration15 Interface](#)
- [ISwDMConfiguration16 Interface](#)
- [ISwDMConfigurationMgr2 Interface](#)
- [ISwDMConfiguration17 Interface](#)
- [ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

AddCustomProperty Method (ISwDMConfiguration)

[See Also](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : AddCustomProperty Method (ISwDMConfiguration)

Adds a custom property to this configuration.

 .NET Syntax

```
Visual Basic (Declaration)

Function AddCustomProperty( _
    ByVal FieldName As System.String, _
    ByVal SwDmCustomInfoType As SwDmCustomInfoType, _
    ByVal FieldValue As System.String _
) As System.Boolean
```

```
Dim instance As ISwDMConfiguration
Dim FieldName As System.String
Dim SwDmCustomInfoType As SwDmCustomInfoType
Dim FieldValue As System.String
Dim value As System.Boolean

value = instance.AddCustomProperty(FieldName, SwDmCustomInfoType, FieldValue)
```

C#

```
System.bool AddCustomProperty(
    System.string FieldName,
    SwDmCustomInfoType SwDmCustomInfoType,
    System.string FieldValue
)
```

C++/CLI

```
System.bool AddCustomProperty(
    & System.String^ FieldName,
    & SwDmCustomInfoType SwDmCustomInfoType,
    & System.String^ FieldValue
)
```

Parameters*FieldName*

Name of the custom property to add

*SwDmCustomInfoType*Type of custom property as defined by [SwDmCustomInfoType](#)*FieldValue*

Value for custom property to add

Return Value

True if custom property is added, false if not

Visual Basic for Applications (VBA) SyntaxSee [SwDMConfiguration::AddCustomProperty](#).**Remarks**

If you call this method to add a linked custom property with an expression value, then you need to open and save the file in SOLIDWORKS before calling [ISwDMConfiguration::GetCustomProperty](#), [ISwDMConfiguration14::GetCustomProperty2](#), [ISwDMConfiguration4::GetAllCustomPropertyNamesAndValues](#), or [ISwDMConfiguration5::GetCustomPropertyValues](#). SOLIDWORKS needs to process the linked custom property before your DocumentMgr application attempts to get its evaluated value.

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMConfiguration::DeleteCustomProperty Method](#)
[ISwDMConfiguration::GetCustomPropertyCount Method](#)
[ISwDMConfiguration::GetCustomPropertyNames Method](#)
[ISwDMConfiguration::SetCustomProperty Method](#)
[ISwDMDocument::AddCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)**Application Property (ISwDMConfiguration)**[See Also](#)[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : Application Property (ISwDMConfiguration)

Gets the application for this configuration.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Application As SwDMAApplication

Visual Basic (Usage)

```
Dim instance As ISwDMConfiguration
Dim value As SwDMAApplication

value = instance.Application
```

C#

```
SwDMAApplication Application {get;}
```

C++/CLI

```
property SwDMAApplication^ Application {
    SwDMAApplication^ get();
}
```

Property Value

Pointer to the [ISwDMAApplication](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::Application](#).

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

DeleteCustomProperty Method (ISwDMConfiguration)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : DeleteCustomProperty Method (ISwDMConfiguration)

Deletes the specified custom property from this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteCustomProperty( _
    ByVal FieldName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration
Dim FieldName As System.String
Dim value As System.Boolean

value = instance.DeleteCustomProperty(FieldName)
```

C#

```
System.bool DeleteCustomProperty(
    System.string FieldName
)
```

C++/CLI

```
System.bool DeleteCustomProperty(
    & System.String^ FieldName
)
```

Parameters

FieldName
Name of custom property to delete

Return Value

True if custom property is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::DeleteCustomProperty](#).

Remarks

To get the names of the custom properties for this configuration, call [ISwDMConfiguration::GetCustomPropertyNames](#).

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMConfiguration::AddCustomProperty Method](#)
[ISwDMConfiguration::GetCustomProperty Method](#)
[ISwDMConfiguration::GetCustomPropertyCount Method](#)
[ISwDMConfiguration::SetCustomProperty Method](#)
[ISwDMConfiguration4::GetAllCustomPropertyNamesAndValues Method](#)
[ISwDMConfiguration5::GetCustomPropertyValues Method](#)
[ISwDMDocument::DeleteCustomProperty Method](#)
[ISwDMConfiguration14::GetCustomProperty2 Method \(\)](#)
[ISwDMConfiguration::GetCustomPropertyNames Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Description Property (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : Description Property (ISwDMConfiguration)

Gets or sets the description for this configuration.

.NET Syntax

Visual Basic (Declaration)

Property Description As System.String

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration  
Dim value As System.String
```

```
instance.Description = value
```

```
value = instance.Description
```

C#

```
System.string Description {get; set;}
```

C++/CLI

```
property System.String^ Description {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

Property Value

Description

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::Description](#).

Example

[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)

Availability

SOLIDWORKS Document Manager API 2007 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Document Property (ISwDMConfiguration)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : Document Property (ISwDMConfiguration)

Gets the document for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Document As SwDMDocument
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration  
Dim value As SwDMDocument  
  
value = instance.Document
```

C#

```
SwDMDocument Document {get;}
```

C++/CLI

```
property SwDMDocument^ Document {  
    SwDMDocument^ get();  
}
```

Property Value

Pointer to the [ISwDMDocument](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::Document](#).

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetBodiesCount Method (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetBodiesCount Method (ISwDMConfiguration)

Gets the number of solid bodies for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration  
Dim value As System.Integer  
  
value = instance.GetBodiesCount()
```

C#

```
System.int GetBodiesCount()
```

C++/CLI

```
System.int GetBodiesCount();
```

Return Value

Number of solid bodies

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetBodiesCount](#).

Example

[Write Parasolid Partition Stream to File \(C#\)](#)
[Write Parasolid Partition Stream to File \(VB.NET\)](#)

Remarks

This method only returns the number of solid bodies for documents saved in SOLIDWORKS 2003 and lower. To get the version of a document, use [ISwDMDocument::GetVersion](#).

Call this method before calling [ISwDMConfiguration::GetBody](#) to find out the number of solid bodies for this configuration.

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMConfiguration3::GetImportedBodiesCount Method](#)
[ISwDMConfiguration3::GetImportedBody Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetBody Method (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetBody Method (ISwDMConfiguration)

Gets the body at the specified index in the specified Parasolid binary file (filename extension .x_b).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBody( _  
    ByVal index As System.Integer, _  
    ByVal fileName As System.String _  
) As SwDmBodyError
```

Visual Basic (Usage)

```
Dim instance As ISwDMConfiguration  
Dim index As System.Integer  
Dim fileName As System.String  
Dim value As SwDmBodyError  
  
value = instance.GetBody(index, fileName)
```

C#

```
SwDmBodyError GetBody(  
    System.int index,  
    System.string fileName  
)
```

C++/CLI

```
SwDmBodyError GetBody(  
& System.int index,  
& System.String^ fileName  
)
```

Parameters

index

Index number indicating the body to get

fileName

Full path and filename in which to get the body

Return Value

Success or error code as defined by [SwDmBodyError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetBody](#).

Example

[Write Parasolid Partition Stream to File \(C#\)](#)

[Write Parasolid Partition Stream to File \(VB.NET\)](#)

Remarks

This method supports:

- part and assembly documents saved in SOLIDWORKS 2003 and earlier.
- only assembly documents saved in SOLIDWORKS 2004 and later. Use [ISwDMConfiguration2::GetPartitionStream](#) for part documents saved in SOLIDWORKS 2004 and later.

To get the version of a document, use [ISwDMDocument::GetVersion](#).

To find out the number of solid bodies in this Parasolid binary file, call [ISwDMConfiguration::GetBodiesCount](#) before calling this method.

See Also

[ISwDMConfiguration Interface](#)

[ISwDMConfiguration Members](#)

[ISwDMConfiguration3::GetImportedBodiesCount Method](#)

[ISwDMConfiguration3::GetImportedBody Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetCustomProperty Method (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetCustomProperty Method (ISwDMConfiguration)

Gets the specified custom property for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomProperty( _  
    ByVal FieldName As System.String, _  
    ByRef type As SwDmCustomInfoType _  
) As System.String
```

Visual Basic (Usage)

```
Dim instance As ISwDMConfiguration  
Dim FieldName As System.String  
Dim type As SwDmCustomInfoType  
Dim value As System.String  
  
value = instance.GetCustomProperty(FieldName, type)
```

C#

```
System.string GetCustomProperty(  
    System.string FieldName,  
    out SwDmCustomInfoType type  
)
```

C++/CLI

```
System.String^ GetCustomProperty(  
    & System.String^ FieldName,  
    & [Out] SwDmCustomInfoType type  
)
```

Parameters

FieldName

Name of the custom property

type

Type of custom property as defined by [SwDmCustomInfoType](#)

Return Value

Value of the custom property

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetCustomProperty](#).

Example

[Get Configuration Information \(C#\)](#)

[Get Configuration Information \(VB.NET\)](#)

Remarks

To get the names of all the custom properties for this configuration, call [ISwDMConfiguration::GetCustomPropertyNames](#).

This method returns an evaluated value:

- from when the file was last saved in SOLIDWORKS. If you used [ISwDMConfiguration::SetCustomProperty](#) to set a linked custom property, then you need to open and save the file in SOLIDWORKS before your DocumentMgr application calls this method to retrieve the evaluated value of the linked custom property.
- prefaced with **fromparent+** for external referenced documents. Use [ISwConfiguration14::GetCustomProperty2](#) to return resolved evaluated values without the **fromparent+** preface.

See Also

[ISwDMConfiguration Interface](#)

[ISwDMConfiguration Members](#)

[ISwDMConfiguration::AddCustomProperty Method](#)

[ISwDMConfiguration::DeleteCustomProperty Method](#)

[ISwDMConfiguration::GetCustomPropertyCount Method](#)

[ISwDMConfiguration4::GetAllCustomPropertyNamesAndValues Method](#)

[ISwDMConfiguration5::GetCustomPropertyValues Method](#)

[ISwDMDocument::GetCustomProperty Method](#)

[ISwDMDocument17::GetCustomProperty2 Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetCustomPropertyCount Method (ISwDMConfiguration)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetCustomPropertyCount Method (ISwDMConfiguration)

Gets the number of custom properties for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomPropertyCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISwDMConfiguration
```

```
Dim value As System.Integer
```

```
value = instance.GetCustomPropertyCount()
```

C#

```
System.int GetCustomPropertyCount()
```

C++/CLI

```
System.int GetCustomPropertyCount();
```

Return Value

Number of custom properties

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetCustomPropertyCount](#).

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMConfiguration::AddCustomProperty Method](#)
[ISwDMConfiguration::DeleteCustomProperty Method](#)
[ISwDMConfiguration::GetCustomProperty Method](#)
[ISwDMConfiguration::GetCustomPropertyNames Method](#)
[ISwDMConfiguration::SetCustomProperty Method](#)
[ISwDMConfiguration4::GetAllCustomPropertyNamesAndValues Method](#)
[ISwDMConfiguration5::GetCustomPropertyValues Method](#)
[ISwDMDocument::GetCustomPropertyCount Method](#)
[ISwDMConfiguration14::GetCustomProperty2](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetCustomPropertyNames Method (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetCustomPropertyNames Method (ISwDMConfiguration)

Gets the names of the custom properties for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomPropertyNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration
Dim value As System.Object

value = instance.GetCustomPropertyNames()
```

C#

```
System.object GetCustomPropertyNames()
```

C++/CLI

```
System.Object^ GetCustomPropertyNames();
```

Return Value

Names of the custom properties

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetCustomPropertyNames](#).

Example

[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

Remarks

Call this method before calling [ISwDMConfiguration::DeleteCustomProperty](#), [ISwDMConfiguration::GetCustomProperty](#), or [ISwDMConfiguration::SetCustomProperty](#).

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMConfiguration::AddCustomProperty](#)
[ISwDMConfiguration::DeleteCustomProperty](#)
[ISwDMConfiguration::GetCustomProperty](#)
[ISwDMConfiguration::GetCustomPropertyCount](#)
[ISwDMConfiguration::SetCustomProperty](#)
[ISwDMConfiguration14::GetCustomProperty2](#)
[ISwDMDocument::GetCustomPropertyNames Method \(\)](#)
[ISwDMConfiguration4::GetAllCustomPropertyNamesAndValues Method](#)
[ISwDMConfiguration5::GetCustomPropertyValues Method \(\)](#)
[ISwDMConfiguration15::IsCustomPropertyEditable Method \(\)](#)

Availability

GetLastUpdateStamp Method (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetLastUpdateStamp Method (ISwDMConfiguration)

Gets the date that this configuration was last updated.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLastUpdateStamp() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISwDMConfiguration  
Dim value As System.Integer  
  
value = instance.GetLastUpdateStamp()
```

C#

```
System.int GetLastUpdateStamp()
```

C++/CLI

```
System.int GetLastUpdateStamp();
```

Return Value

Date last updated

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetLastUpdateStamp](#).

Example

[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

Remarks

The update stamp is essentially an integer form of a time stamp. The update stamp in a SOLIDWORKS document is incremented when:

- the state of the model changes (for example, you suppress or unsuppress a feature in a part or an assembly)
- the geometry changes (for example, any action that requires a rebuild)

This time stamp is not incremented for such operations as color changes, feature or configuration name changes, and so on.

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

GetMassProperties Method (ISwDMConfiguration)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetMassProperties Method (ISwDMConfiguration)

Gets the mass properties, if valid, for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMassProperties( _  
    ByRef bRet As SwDmMassPropError _
```

) As System.Object

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration
Dim bRet As SwDmMassPropError
Dim value As System.Object

value = instance.GetMassProperties(bRet)
```

C#

```
System.object GetMassProperties(
    out SwDmMassPropError bRet
)
```

C++/CLI

```
System.Object^ GetMassProperties(
    & [Out] SwDmMassPropError bRet
)
```

Parameters

bRet

Success or error code as defined by [SwDmMassPropError](#)

Return Value

Array of mass properties (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetMassProperties](#).

Remarks

This method only returns data for documents created using SOLIDWORKS 2004 (Version 2500) and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

The 13 elements in the array are:

Element	Description
[0 2]:	(x, y, z) Center of mass (m)
[3]:	Volume (m^3)
[4]:	Surface area (m^2)
[5] :	Mass (kg)
[6]:	momXX (kg*m^2)
[7] :	momYY (kg*m^2)
[8] :	momZZ (kg*m^2)
[9] :	momXY (kg*m^2)
[10]:	momZX (kg*m^2)
[11]:	momYZ (kg*m^2)
[12]:	Include hidden

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetParentConfigurationName Method (ISwDMConfiguration)

Gets the name of the parent configuration for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParentConfigurationName() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration  
Dim value As System.String  
  
value = instance.GetParentConfigurationName()
```

C#

```
System.string GetParentConfigurationName()
```

C++/CLI

```
System.String^ GetParentConfigurationName();
```

Return Value

Name of the parent configuration or NULL if no parent configuration exists

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetParentConfigurationName](#).

Example

[Write Parasolid Partition Stream to File \(C#\)](#)
[Write Parasolid Partition Stream to File \(VB.NET\)](#)
[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMComponent::ConfigurationName Property](#)
[ISwDMConfiguration7::Name2 Property](#)
[ISwDMConfigurationMgr::GetActiveConfigurationName Method](#)
[ISwDMConfigurationMgr::GetConfigurationByName Method](#)
[ISwDMConfigurationMgr::GetConfigurationNames Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPreviewBitmap Method (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : GetPreviewBitmap Method (ISwDMConfiguration)

Gets the preview bitmap for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPreviewBitmap( _  
    ByRef result As SwDmPreviewError _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration  
Dim result As SwDmPreviewError  
Dim value As System.Object  
  
value = instance.GetPreviewBitmap(result)
```

C#

```
System.Object GetPreviewBitmap(  
    out SwDmPreviewError result  
)
```

C++/CLI

```
System.Object^ GetPreviewBitmap(  
    & [Out] SwDmPreviewError result  
)
```

Parameters

result

Success or error code as defined by [SwDmPreviewError](#)

Return Value

Pointer to the preview bitmap (an IPictureDisp*)

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::GetPreviewBitmap](#).

Example

[Write Parasolid Partition Stream to File \(C#\)](#)
[Write Parasolid Partition Stream to File \(VB.NET\)](#)

Remarks

This method does not work in out-of-process and some ASP.NET/IIS web applications.

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMConfiguration::PreviewStreamName Property](#)
[ISwDMConfiguration7::GetPreviewPNGBitmap Method](#)
[ISwDMConfiguration7::PreviewPNGStreamName Property](#)
[ISwDMConfiguration10::GetPreviewBitmap Method](#)
[ISwDMConfiguration10::GetPreviewPNGBitmap Method](#)
[ISwDMConfiguration10::PreviewPNGStreamName Property](#)
[ISwDMConfiguration10::PreviewStreamName Property](#)
[ISwDMConfiguration9::GetPreviewBitmapBytes Method](#)
[ISwDMConfiguration9::GetPreviewPNGBitmapBytes Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Name Property (ISwDMConfiguration)

[See Also](#)



SolidWorks.Interop.swdocumentmgr Namespace > [ISwDMConfiguration Interface](#) : Name Property (ISwDMConfiguration)

Obsolete. Superseded by [ISwDMConfiguration7::Name2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)

```
Dim instance As ISwDMConfiguration  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI



```
property System.String^ Name {
    System.String^ get();
}
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::Name](#).

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

PreviewStreamName Property (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : PreviewStreamName Property (ISwDMConfiguration)

Gets the name of the stream for the preview bitmap of this configuration.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PreviewStreamName As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration
Dim value As System.String

value = instance.PreviewStreamName
```

C#

```
System.string PreviewStreamName {get;}
```

C++/CLI

```
property System.String^ PreviewStreamName {
    System.String^ get();
}
```

Property Value

Name of the stream for the preview bitmap or an empty string if preview bitmap does not exist

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::PreviewStreamName](#).

Example

[Write Parasolid Partition Stream to File \(C#\)](#)
[Write Parasolid Partition Stream to File \(VB.NET\)](#)

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMConfiguration::GetPreviewBitmap Method](#)
[ISwDMConfiguration7::GetPreviewPNGBitmap Method](#)
[ISwDMConfiguration7::PreviewPNGStreamName Property](#)
[ISwDMDocument10::GetPreviewBitmap Method](#)
[ISwDMDocument10::GetPreviewPNGBitmap Method](#)
[ISwDMDocument10::PreviewPNGStreamName Property](#)
[ISwDMDocument10::PreviewStreamName Property](#)
[ISwDMConfiguration9::GetPreviewBitmapBytes Method](#)
[ISwDMConfiguration9::GetPreviewPNGBitmapBytes Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SetCustomProperty Method (ISwDMConfiguration)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : SetCustomProperty Method (ISwDMConfiguration)

Obsolete. Superseded by [ISwDMConfiguration18::SetCustomProperty2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomProperty( _  
    ByVal FieldName As System.String, _  
    ByVal newValue As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration  
Dim FieldName As System.String  
Dim newValue As System.String  
  
instance.SetCustomProperty(FieldName, newValue)
```

C#

```
void SetCustomProperty(  
    System.string FieldName,  
    System.string newValue  
)
```

C++/CLI

```
void SetCustomProperty(  
& System.String^ FieldName,  
& System.String^ newValue  
)
```

Parameters

FieldName
Custom property to set
newValue
Value for custom property

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::SetCustomProperty](#).

Remarks

Before calling this method, call [ISwDMConfiguration::GetCustomPropertyNames](#) to populate FieldName.

If you call this method to set a linked custom property with an expression value, then you need to open and save the file in SOLIDWORKS before calling [ISwDMConfiguration::GetCustomProperty](#), [ISwDMConfiguration14::GetCustomProperty2](#), [ISwDMConfiguration4::GetAllCustomPropertyNamesAndValues](#), or [ISwDMConfiguration5::GetCustomPropertyValues](#). SOLIDWORKS needs to process the linked custom property before your DocumentMgr application attempts to get its evaluated value.

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)
[ISwDMConfiguration::AddCustomProperty Method](#)
[ISwDMConfiguration::DeleteCustomProperty Method](#)
[ISwDMConfiguration::GetCustomPropertyCount Method](#)
[ISwDMConfiguration::GetCustomPropertyNames Method](#)
[ISwDMDocument::SetCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

StreamName Property (ISwDMConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration Interface](#) : StreamName Property (ISwDMConfiguration)

Gets the name of the stream for the configuration.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property StreamName As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration  
Dim value As System.String  
  
value = instance.StreamName
```

C#

```
System.string StreamName {get;}
```

C++/CLI

```
property System.String^ StreamName {  
    System.String^ get();  
}
```

Property Value

Name of the stream for the configuration

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration::StreamName](#).

Example

[Write Parasolid Partition Stream to File \(C#\)](#)
[Write Parasolid Partition Stream to File \(VB.NET\)](#)

See Also

[ISwDMConfiguration Interface](#)
[ISwDMConfiguration Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS