

SOLIDWORKS Document Manager API (.NET) — Reference (4/19): ISwDMConfiguration2- ISwDMConfiguration9

SOLIDWORKS API Documentation (converted from CHM)

ISwDMConfiguration2 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMConfiguration2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfiguration2 Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMConfiguration2
    Inherits ISwDMConfiguration
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration2
```

C#

```
public interface ISwDMConfiguration2 : ISwDMConfiguration
```

C++/CLI

```
public interface class ISwDMConfiguration2 : public ISwDMConfiguration
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration2](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Write Parasolid Partition Stream to File \(C#\)](#)
[Write Parasolid Partition Stream to File \(VB.NET\)](#)

Remarks

- You can access an ISwDMConfiguration2 object by calling QueryInterface on an [ISwDMConfiguration](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMConfiguration object can be assigned to an ISwDMConfiguration2 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfigurationMgr::GetConfigurationByName](#)

See Also

[ISwDMConfiguration2 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)

ISwDMConfiguration2 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration2 Interface

For a list of all members of this type, see [ISwDMConfiguration2 members](#).

Public Methods

Name	Description
 GetComponents	Gets the components referenced by the configuration.
 GetPartitionStream	Gets the Parasolid partition stream that has the body partition information and writes it the specified file. Supports part documents only.

[Top](#)

See Also

[ISwDMConfiguration2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration2 Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration2 Interface

The following tables list the members exposed by [ISwDMConfiguration2](#).

Public Properties

Name	Description
 PartitionStreamName	Gets the name of the Parasolid body partition stream.

[Top](#)

Public Methods

Name	Description
 GetComponents	Gets the components referenced by the configuration.
 GetPartitionStream	Gets the Parasolid partition stream that has the body partition information and writes it the specified file. Supports part documents only.

[Top](#)

See Also

[ISwDMConfiguration2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)

[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMConfiguration2 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration2 Interface

For a list of all members of this type, see [ISwDMConfiguration2 members](#).

Public Properties

Name	Description
PartitionStreamName	Gets the name of the Parasolid body partition stream.

[Top](#)

See Also

[ISwDMConfiguration2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetComponents Method (ISwDMConfiguration2)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration2 Interface](#) : GetComponents Method (ISwDMConfiguration2)

Gets the components referenced by the configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration2  
Dim value As System.Object  
  
value = instance.GetComponents()
```

C#

```
System.object GetComponents()
```

C++/CLI

```
System.Object^ GetComponents();
```

Return Value

Array of [ISwDMComponent](#) objects

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration2::GetComponents](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(C#\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(VB.NET\)](#)
[Replace Component \(C#\)](#)
[Replace Component \(VB.NET\)](#)

Remarks

Do not use this method if a document component or reference is changed by [ISwDMDocument::ReplaceReference](#) and the document is not subsequently opened and saved in SOLIDWORKS, because this method could return old and now nonexistent references. Instead, use [ISwDMDocument8::GetChangedReferences](#) or [ISwDMConfiguration11::GetReplacedComponents](#) until opening and saving the document in SOLIDWORKS.

This method only returns data for documents created using SOLIDWORKS 2003 (Version 2200) and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

See Also

[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration2 Members](#)

Availability

SOLIDWORKS Document Manager API 2004 SP1

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPartitionStream Method (ISwDMConfiguration2)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration2 Interface](#) : GetPartitionStream Method (ISwDMConfiguration2)

Gets the Parasolid partition stream that has the body partition information and writes it to the specified file. Supports part documents only.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPartitionStream( _  
    ByVal fileName As System.String _  
) As SwDmBodyError
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration2  
Dim fileName As System.String  
Dim value As SwDmBodyError  
  
value = instance.GetPartitionStream(fileName)
```

C#

```
SwDmBodyError GetPartitionStream(  
    System.string fileName  
)
```

C++/CLI

```
SwDmBodyError GetPartitionStream(  
& System.String^ fileName  
)
```

Parameters

fileName

Filename to which to write the Parasolid partition and body information (see **Remarks**)

Return Value

Success or error code as defined by [SwDmBodyError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration2::GetPartitionStream](#).

Example

[Write Parasolid Partition Stream to File \(C#\)](#)
[Write Parasolid Partition Stream to File \(VB.NET\)](#)
[Write Parasolid Partition Stream to File \(C++\)](#)

Remarks

This method only supports part documents saved in SOLIDWORKS 2004 and later. Use [ISwDMConfiguration::GetBody](#) for part documents saved in SOLIDWORKS 2003 and earlier and assembly documents saved in any version of SOLIDWORKS.

To get the version of a part document, use [ISwDMDocument::GetVersion](#).

Before using this method, call [ISwDMConfiguration2::PartitionStreamName](#) to get fileName. Valid filename extensions are *.xmp_bin for NTFS and *.p_b for FAT.

If fileName...

Then...

Does not exist

This method creates the file and writes the Parasolid partition and body information to that file

Exists

Writes the Parasolid partition and body information to that file, overwriting any data in that file

See Also

[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration2 Members](#)

Availability

SOLIDWORKS Document Manager API 2004 SP1

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

PartitionStreamName Property (ISwDMConfiguration2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration2 Interface](#) : PartitionStreamName Property (ISwDMConfiguration2)

Gets the name of the Parasolid body partition stream.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property PartitionStreamName As System.String

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration2  
Dim value As System.String
```

```
value = instance.PartitionStreamName
```

C#

```
System.string PartitionStreamName {get;}
```

C++/CLI

```
property System.String^ PartitionStreamName {  
    System.String^ get();  
}
```

Property Value

Name of the stream; valid filename extensions are *.xmp_bin for NTFS and *.p_b for FAT

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration2::PartitionStreamName](#).

Remarks

Call this method before calling [ISwDMConfiguration2::GetPartitionStream](#).

See Also

[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration2 Members](#)

Availability

SOLIDWORKS Document Manager API 2004 SP1

ISwDMConfiguration3 (Type)

ISwDMConfiguration3 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfiguration3 Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMConfiguration3
    Inherits ISwDMConfiguration, ISwDMConfiguration2
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration3
```

C#

```
public interface ISwDMConfiguration3 : ISwDMConfiguration, ISwDMConfiguration2
```

C++/CLI

```
public interface class ISwDMConfiguration3 : public ISwDMConfiguration, ISwDMConfiguration2
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration3](#).

Remarks

- You can access an ISwDMConfiguration3 object by calling QueryInterface on an [ISwDMConfiguration](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMConfiguration object can be assigned to an ISwDMConfiguration3 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfigurationMgr::GetConfigurationByName](#)

See Also

[ISwDMConfiguration3 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration3 Interface Members

[See Also](#) [Methods](#)



The following tables list the members exposed by [ISwDMConfiguration3](#).

 Public Methods

Name	Description
 GetImportedBodiesCount	Gets the number of imported solid bodies in this configuration.
 GetImportedBody	Gets the imported solid body in this configuration and writes the body to the specified file in Parasolid .x_b format.

[Top](#)

 See Also

- [ISwDMConfiguration3 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMConfiguration Interface](#)
- [ISwDMConfiguration2 Interface](#)
- [ISwDMConfiguration4 Interface](#)
- [ISwDMConfiguration5 Interface](#)
- [ISwDMConfiguration6 Interface](#)
- [ISwDMConfiguration7 Interface](#)
- [ISwDMConfiguration8 Interface](#)
- [ISwDMConfiguration9 Interface](#)
- [ISwDMConfiguration10 Interface](#)
- [ISwDMConfiguration11 Interface](#)
- [ISwDMConfiguration12 Interface](#)
- [ISwDMConfiguration13 Interface](#)
- [ISwDMConfiguration14 Interface](#)
- [ISwDMConfiguration15 Interface](#)
- [ISwDMConfiguration16 Interface](#)
- [ISwDMConfigurationMgr2 Interface](#)
- [ISwDMConfiguration17 Interface](#)
- [ISwDMConfiguration18 Interface](#)

ISwDMConfiguration3 Interface Methods

[See Also](#)



For a list of all members of this type, see [ISwDMConfiguration3 members](#).

 Public Methods

Name	Description
 GetImportedBodiesCount	Gets the number of imported solid bodies in this configuration.
 GetImportedBody	Gets the imported solid body in this configuration and writes the body to the specified file in Parasolid .x_b format.

[Top](#)

 See Also

- [ISwDMConfiguration3 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMConfiguration Interface](#)
- [ISwDMConfiguration2 Interface](#)
- [ISwDMConfiguration4 Interface](#)
- [ISwDMConfiguration5 Interface](#)
- [ISwDMConfiguration6 Interface](#)
- [ISwDMConfiguration7 Interface](#)
- [ISwDMConfiguration8 Interface](#)
- [ISwDMConfiguration9 Interface](#)
- [ISwDMConfiguration10 Interface](#)
- [ISwDMConfiguration11 Interface](#)
- [ISwDMConfiguration12 Interface](#)
- [ISwDMConfiguration13 Interface](#)
- [ISwDMConfiguration14 Interface](#)
- [ISwDMConfiguration15 Interface](#)
- [ISwDMConfiguration16 Interface](#)
- [ISwDMConfigurationMgr2 Interface](#)
- [ISwDMConfiguration17 Interface](#)
- [ISwDMConfiguration18 Interface](#)

GetImportedBodiesCount Method (ISwDMConfiguration3)

[See Also](#)



Gets the number of imported solid bodies in this configuration.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetImportedBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration3  
Dim value As System.Integer  
  
value = instance.GetImportedBodiesCount()
```

C#

```
System.int GetImportedBodiesCount()
```

C++/CLI

```
System.int GetImportedBodiesCount();
```

Return Value

Number of imported solid bodies; this is a 0-based index

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration3::GetImportedBodiesCount](#).

Remarks

This method does not include the number of imported surface bodies, if any.

Call this method before [ISwDMConfiguration3::GetImportedBody](#).

See Also

[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration3 Members](#)
[ISwDMConfiguration::GetBodiesCount Method](#)
[ISwDMConfiguration::GetBody Method](#)

Availability

SOLIDWORKS Document Manager API 2004 SP2

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetImportedBody Method (ISwDMConfiguration3)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration3 Interface](#) : GetImportedBody Method (ISwDMConfiguration3)

Gets the imported solid body in this configuration and writes the body to the specified file in Parasolid .x_b format.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetImportedBody(  
    ByVal index As System.Integer, _  
    ByVal fileName As System.String _  
) As SwDmBodyError
```

Visual Basic (Usage)



```

Dim instance As ISwDMConfiguration3
Dim index As System.Integer
Dim fileName As System.String
Dim value As SwDmBodyError

value = instance.GetImportedBody(index, fileName)

```

C#

```

SwDmBodyError GetImportedBody(
    System.int index,
    System.string fileName
)

```

C++/CLI

```

SwDmBodyError GetImportedBody(
    & System.int index,
    & System.String^ fileName
)

```

Parameters

index
Number indicating which imported solid body in this configuration to get
fileName
File to which to write the body in Parasolid **.x_b** format (see **Remarks**)

Return Value

Success or error code as defined by [SwDmBodyError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration3::GetImportedBody](#).

Remarks

This method gets imported solid bodies only; it does not get imported surface bodies.

Before calling this method, call [ISwConfiguration3::GetImportedBodiesCount](#) to get the number of imported solid bodies in the configuration.

If fileName...	Then this method...
Exists	Writes the imported solid body to fileName in Parasolid .x_b format, overwriting any data in that file
Does not exist	Creates fileName and writes the imported solid body to that file in Parasolid .x_b format

See Also

[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration3 Members](#)

Availability

SOLIDWORKS Document Manager API 2004 SP2

ISwDMConfiguration4 (Type)

ISwDMConfiguration4 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfiguration4 Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMConfiguration4
    Inherits ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration4
```

C#

```
public interface ISwDMConfiguration4 :
    ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3
```

C++/CLI

```
public interface class ISwDMConfiguration4 : public
    ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration4](#).

Remarks

- You can access an ISwDMConfiguration4 object by calling QueryInterface on an [ISwDMConfiguration](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMConfiguration object can be assigned to an ISwDMConfiguration4 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfigurationMgr::GetConfigurationByName](#)

See Also

[ISwDMConfiguration4 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration4 Interface

For a list of all members of this type, see [ISwDMConfiguration4 members](#).

 Public Methods

Name	Description
 GetAllCustomPropertyNamesAndValues	Gets all of the custom properties for this configuration.

[Top](#)

 See Also

[ISwDMConfiguration4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMConfiguration4 Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration4 Interface

The following tables list the members exposed by [ISwDMConfiguration4](#).

 Public Methods

Name	Description
 GetAllCustomPropertyNamesAndValues	Gets all of the custom properties for this configuration.

[Top](#)

 See Also

[ISwDMConfiguration4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetAllCustomPropertyNamesAndValues Method (ISwDMConfiguration4)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration4 Interface](#) : GetAllCustomPropertyNamesAndValues Method (ISwDMConfiguration4)

Gets all of the custom properties for this configuration.

 .NET Syntax

```

Sub GetAllCustomPropertyNamesAndValues( _
    ByRef names As System.Object, _
    ByRef types As System.Object, _
    ByRef linkedTo As System.Object, _
    ByRef values As System.Object _
)

```



```

Dim instance As ISwDMConfiguration4
Dim names As System.Object
Dim types As System.Object
Dim linkedTo As System.Object
Dim values As System.Object

instance.GetAllCustomPropertyNamesAndValues(names, types, linkedTo, values)

```

```

void GetAllCustomPropertyNamesAndValues(
    out System.object names,
    out System.object types,
    out System.object linkedTo,
    out System.object values
)

```

```

void GetAllCustomPropertyNamesAndValues(
& [Out] System.Object^ names,
& [Out] System.Object^ types,
& [Out] System.Object^ linkedTo,
& [Out] System.Object^ values
)

```

Parameters

[names](#)
 Array of Property Names
[types](#)
 Array of Types as defined in [SwDmCustomInfoType](#)
[linkedTo](#)
 Array of Estimated Values
[values](#)
 Array of linked to Values/Text Expressions (see **Remarks**)

Return Value

If the properties are...	Then this method returns...
Linked	The evaluated results of values
Not linked	Empty strings. This method returns the same values as returned by ISwDMConfiguration::GetCustomProperty

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration4::GetAllCustomPropertyNamesAndValues](#).

Remarks

If you called [ISwDMConfiguration::SetCustomProperty](#) to set a linked custom property, then you must open and save the file in SOLIDWORKS before calling this method. SOLIDWORKS must process the linked custom property before your DocumentMgr application can retrieve its evaluated value.

See Also

[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration4 Members](#)
[ISwDMConfiguration::AddCustomProperty Method](#)
[ISwDMConfiguration::DeleteCustomProperty Method](#)
[ISwDMConfiguration::GetCustomPropertyCount Method](#)
[ISwDMConfiguration::GetCustomPropertyNames Method](#)
[ISwDMConfiguration5::GetCustomPropertyValues Method](#)
[ISwDMDocument3::GetAllCustomPropertyNamesAndValues Method](#)
[ISwDMConfiguration14::GetCustomProperty2 Method \(\)](#)
[ISwDMConfiguration15::IsCustomPropertyEditable Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2004 SP4

ISwDMConfiguration5 (Type)

ISwDMConfiguration5 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfiguration5 Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMConfiguration5
    Inherits ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration5
```

C#

```
public interface ISwDMConfiguration5 :
    ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4
```

C++/CLI

```
public interface class ISwDMConfiguration5 : public
    ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration5](#).

Remarks

- You can access an ISwDMConfiguration5 object by calling QueryInterface on an [ISwDMConfiguration](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMConfiguration object can be assigned to an ISwDMConfiguration5 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfigurationMgr::GetConfigurationByName](#)

See Also

[ISwDMConfiguration5 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

The following tables list the members exposed by [ISwDMConfiguration5](#).

 Public Properties

Name	Description
 AlternateName	Obsolete. Superseded by ISwDMConfiguration7::AlternateName2 .
 Comment	Obsolete. Superseded by ISwDMConfiguration7::Comment2 .

[Top](#)

 Public Methods

Name	Description
 GetCustomPropertyValues	Gets the specified custom property value for this configuration.

[Top](#)

 See Also

[ISwDMConfiguration5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration5 Interface Methods

[See Also](#)

For a list of all members of this type, see [ISwDMConfiguration5 members](#).

 Public Methods

Name	Description
 GetCustomPropertyValues	Gets the specified custom property value for this configuration.

[Top](#)

 See Also

[ISwDMConfiguration5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration5 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration5 Interface

For a list of all members of this type, see [ISwDMConfiguration5 members](#).

Public Properties

Name	Description
 AlternateName	Obsolete. Superseded by ISwDMConfiguration7::AlternateName2 .
 Comment	Obsolete. Superseded by ISwDMConfiguration7::Comment2 .

[Top](#)

See Also

- [ISwDMConfiguration5 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMConfiguration Interface](#)
- [ISwDMConfiguration2 Interface](#)
- [ISwDMConfiguration3 Interface](#)
- [ISwDMConfiguration4 Interface](#)
- [ISwDMConfiguration6 Interface](#)
- [ISwDMConfiguration7 Interface](#)
- [ISwDMConfiguration8 Interface](#)
- [ISwDMConfiguration9 Interface](#)
- [ISwDMConfiguration10 Interface](#)
- [ISwDMConfiguration11 Interface](#)
- [ISwDMConfiguration12 Interface](#)
- [ISwDMConfiguration13 Interface](#)
- [ISwDMConfiguration14 Interface](#)
- [ISwDMConfiguration15 Interface](#)
- [ISwDMConfiguration16 Interface](#)
- [ISwDMConfigurationMgr2 Interface](#)
- [ISwDMConfiguration17 Interface](#)
- [ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

AlternateName Property (ISwDMConfiguration5)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration5 Interface](#) : AlternateName Property (ISwDMConfiguration5)

Obsolete. Superseded by [ISwDMConfiguration7::AlternateName2](#).

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property AlternateName As System.String

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration5  
Dim value As System.String
```

```
value = instance.AlternateName
```

C#

```
System.string AlternateName {get;}
```

C++/CLI

```
property System.String^ AlternateName {  
    System.String^ get();  
}
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration5::AlternateName](#).

See Also

Comment Property (ISwDMConfiguration5)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration5 Interface](#) : Comment Property (ISwDMConfiguration5)

Obsolete. Superseded by [ISwDMConfiguration7::Comment2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Comment As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration5  
Dim value As System.String  
  
value = instance.Comment
```

C#

```
System.string Comment {get;}
```

C++/CLI

```
property System.String^ Comment {  
    System.String^ get();  
}
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration5::Comment](#).

See Also

[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration5 Members](#)

GetCustomPropertyValues Method (ISwDMConfiguration5)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration5 Interface](#) : GetCustomPropertyValues Method (ISwDMConfiguration5)

Gets the specified custom property value for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomPropertyValues( _  
    ByVal FieldName As System.String, _  
    ByRef type As SwDmCustomInfoType, _  
    ByRef LinkedTo As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration5  
Dim FieldName As System.String  
Dim type As SwDmCustomInfoType  
Dim linkedTo As System.String  
Dim value As System.String
```

```
value = instance.GetCustomPropertyValues(FieldName, type, linkedTo)
```

C#

```
System.string GetCustomPropertyValues(  
    System.string FieldName,  
    out SwDmCustomInfoType type,  
    out System.string linkedTo  
)
```

C++/CLI

```
System.String^ GetCustomPropertyValues(  
& System.String^ FieldName,  
& [Out] SwDmCustomInfoType type,  
& [Out] System.String^ linkedTo  
)
```

Parameters

FieldName

Property Name

type

Type of custom property as defined in [SwDmCustomInfoType](#)

linkedTo

Linked to Value/Text Expression (see **Remarks**)

Return Value

See **Remarks**

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration5::GetCustomPropertyValues](#).

Remarks

If the property is...	Then this method returns...
Linked	The evaluated result of linkedTo
Not linked	An empty string. This method returns the same value as returned by ISwDMConfiguration::GetCustomProperty

This property only supports documents saved in SOLIDWORKS 2005 and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

If you called [ISwDMConfiguration::SetCustomProperty](#) to set a linked custom property, then you must open and save the file in SOLIDWORKS before calling this method. SOLIDWORKS must process the linked custom property before your DocumentMgr application can retrieve its evaluated value.

See Also

[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration5 Members](#)

Availability

SOLIDWORKS Document Manager API 2005 FCS

ISwDMConfiguration6 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMConfiguration6 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfiguration6 Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMConfiguration6
```

```
    Inherits
```

```
    ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4, ISwDMConfiguration5
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration6
```

C#

```
public interface ISwDMConfiguration6 :
```

```
    ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4, ISwDMConfiguration5
```

C++/CLI

```
public interface class ISwDMConfiguration6 : public
```

```
    ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4, ISwDMConfiguration5
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration6](#).

Remarks

- You can access an ISwDMConfiguration6 object by calling QueryInterface on an [ISwDMConfiguration](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMConfiguration object can be assigned to an ISwDMConfiguration6 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfigurationMgr::GetConfigurationByName](#)

See Also

[ISwDMConfiguration6 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)

ISwDMConfiguration6 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration6 Interface

The following tables list the members exposed by [ISwDMConfiguration6](#).

Public Methods

Name	Description
 GetReferencesInformation	Obsolete. Superseded by ISwDMConfiguration8::GetReferencesInformation2

[Top](#)

See Also

[ISwDMConfiguration6 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration6 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration6 Interface

For a list of all members of this type, see [ISwDMConfiguration6 members](#).

Public Methods

Name	Description
 GetReferencesInformation	Obsolete. Superseded by ISwDMConfiguration8::GetReferencesInformation2

[Top](#)

See Also

[ISwDMConfiguration6 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

GetReferencesInformation Method (ISwDMConfiguration6)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration6 Interface](#) : GetReferencesInformation Method (ISwDMConfiguration6)

Obsolete. Superseded by [ISwDMConfiguration8::GetReferencesInformation2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub GetReferencesInformation( _  
    ByRef references As System.Object, _  
    ByRef configurations As System.Object, _  
    ByRef sstates As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration6  
Dim references As System.Object  
Dim configurations As System.Object  
Dim sstates As System.Object  
  
instance.GetReferencesInformation(references, configurations, sstates)
```

C#

```
void GetReferencesInformation(  
    out System.object references,  
    out System.object configurations,  
    out System.object sstates  
)
```

C++/CLI

```
void GetReferencesInformation(  
& [Out] System.Object^ references,  
& [Out] System.Object^ configurations,  
& [Out] System.Object^ sstates  
)
```

Parameters

references

Array of paths and names of the reference documents

configurations

Array of configuration names of the reference documents

sstates

Array of Booleans indicating if the reference document is suppressed (true) or not (false)

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration6::GetReferencesInformation](#).

Remarks

This method only works with references modified using SOLIDWORKS Document Manager API 2007 and later and SOLIDWORKS Explorer.

See Also

[ISwDMConfiguration6 Interface](#)

[ISwDMConfiguration6 Members](#)

Availability

SOLIDWORKS Document Manager API 2007 FCS

ISwDMConfiguration7 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMConfiguration7 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfiguration7 Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMConfiguration7

Inherits

[ISwDMConfiguration](#), [ISwDMConfiguration2](#), [ISwDMConfiguration3](#), [ISwDMConfiguration4](#), [ISwDMConfiguration5](#), [ISwDMConfiguration6](#)

Visual Basic (Usage)



Dim instance As [ISwDMConfiguration7](#)

C#

```
public interface ISwDMConfiguration7 :  
ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4, ISwDMConfiguration5, ISwDMConfiguration6
```

C++/CLI

```
public interface class ISwDMConfiguration7 : public  
ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4, ISwDMConfiguration5, ISwDMConfiguration6
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration7](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get PNG Preview Bitmap and Stream for Configuration \(C#\)](#)
[Get PNG Preview Bitmap and Stream for Configuration \(VB.NET\)](#)

Remarks

- You can access an ISwDMConfiguration7 object by calling QueryInterface on an [ISwDMConfiguration](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMConfiguration object can be assigned to an ISwDMConfiguration7 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfigurationMgr::GetConfigurationByName](#)

See Also

[ISwDMConfiguration7 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)

[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMConfiguration7 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration7 Interface

For a list of all members of this type, see [ISwDMConfiguration7 members](#).

Public Methods

Name	Description
GetPreviewPNGBitmap	Gets the PNG preview bitmap for this configuration.

[Top](#)

See Also

[ISwDMConfiguration7 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMConfiguration7 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration7 Interface

The following tables list the members exposed by [ISwDMConfiguration7](#).

Public Properties

Name	Description
AlternateName2	Gets or sets the user-specified name of the configuration.
Comment2	Gets or sets the comment for the configuration.
Delete	Gets or sets whether to mark this configuration as deleted.
Name2	Gets or sets the name of the configuration.
PreviewPNGStreamName	Gets the name of the stream for the PNG preview bitmap of this configuration.

[Top](#)

Public Methods

Name	Description
GetPreviewPNGBitmap	Gets the PNG preview bitmap for this configuration.

[Top](#)

See Also

[ISwDMConfiguration7 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration7 Interface Properties

[See Also](#)

SolidWorks.Interop.swdocumentmgr Namespace : ISwDMConfiguration7 Interface

For a list of all members of this type, see [ISwDMConfiguration7 members](#).

Public Properties

Name	Description
AlternateName2	Gets or sets the user-specified name of the configuration.
Comment2	Gets or sets the comment for the configuration.
Delete	Gets or sets whether to mark this configuration as deleted.
Name2	Gets or sets the name of the configuration.
PreviewPNGStreamName	Gets the name of the stream for the PNG preview bitmap of this configuration.

[Top](#)

See Also

[ISwDMConfiguration7 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

AlternateName2 Property (ISwDMConfiguration7)

[See Also](#)

SolidWorks.Interop.swdocumentmgr Namespace > [ISwDMConfiguration7 Interface](#) : AlternateName2 Property (ISwDMConfiguration7)

Gets or sets the user-specified name of the configuration.

.NET Syntax

Visual Basic (Declaration)

Property AlternateName2 As System.String

Visual Basic (Usage)

```
Dim instance As ISwDMConfiguration7  
Dim value As System.String
```



```
instance.AlternateName2 = value  
value = instance.AlternateName2
```

C#

```
System.string AlternateName2 {get; set;}
```

C++/CLI

```
property System.String^ AlternateName2 {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

Property Value

Alternate or user-specified name of the configuration

Visual Basic for Applications (VBA) Syntax

See [ISwDMConfiguration7::AlternateName2](#).

Remarks

This property only supports documents saved in SOLIDWORKS 2005 and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

If you set [ISwDMConfiguration11::BOMPartNoSource](#) to anything other than [swDmBOMPartNumberSource.swDmBOMPartNumber_UserSpecified](#), then this property is set to an empty string.

See Also

[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration7 Members](#)

Availability

SOLIDWORKS Document Manager API 2007 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Comment2 Property (ISwDMConfiguration7)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration7 Interface](#) : Comment2 Property (ISwDMConfiguration7)

Gets or sets the comment for the configuration.

.NET Syntax

Visual Basic (Declaration)

```
Property Comment2 As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration7  
Dim value As System.String
```

```
instance.Comment2 = value
```

```
value = instance.Comment2
```

C#

```
System.string Comment2 {get; set;}
```

C++/CLI

```
property System.String^ Comment2 {
    System.String^ get();
    void set ( & System.String^ value);
}
```

Property Value

Comment for the configuration

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration7::Comment2](#).

Remarks

This property only supports documents saved in SOLIDWORKS 2005 and later. To get the version of a document, use [ISwDMDocument::GetVersion](#).

See Also

[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration7 Members](#)

Availability

SOLIDWORKS Document Manager API 2007 FCS

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

Delete Property (ISwDMConfiguration7)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration7 Interface](#) : Delete Property (ISwDMConfiguration7)

Gets or sets whether to mark this configuration as deleted.

.NET Syntax

Visual Basic (Declaration)

Property Delete As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration7
Dim value As System.Boolean
```

```
instance.Delete = value
```

```
value = instance.Delete
```

C#

```
System.bool Delete {get; set;}
```

C++/CLI

```
property System.bool Delete {
    System.bool get();
    void set ( & System.bool value);
}
```

Property Value

True marks this configuration as deleted, false does not

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration7::Delete](#).

See Also

[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration7 Members](#)

Availability

SOLIDWORKS Document Manager API 2007 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPreviewPNGBitmap Method (ISwDMConfiguration7)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration7 Interface](#) : GetPreviewPNGBitmap Method (ISwDMConfiguration7)

Gets the PNG preview bitmap for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPreviewPNGBitmap( _  
    ByRef result As SwDmPreviewError _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration7  
Dim result As SwDmPreviewError  
Dim value As System.Object  
  
value = instance.GetPreviewPNGBitmap(result)
```

C#

```
System.object GetPreviewPNGBitmap(  
    out SwDmPreviewError result  
)
```

C++/CLI

```
System.Object^ GetPreviewPNGBitmap(  
& [Out] SwDmPreviewError result  
)
```

Parameters

result

Success or error code as defined by [swDmPreviewError](#)

Return Value

Pointer to the PNG preview bitmap (an IPictureDisp*)

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration7::GetPreviewPNGBitmap](#).

Example

[Get PNG Preview Bitmap and Stream for Configuration \(C#\)](#)
[Get PNG Preview Bitmap and Stream for Configuration \(VB.NET\)](#)

Remarks

This method does not work in out-of-process and some ASP.NET/IIS web applications.

See Also

[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration7 Members](#)
[ISwDMConfiguration::GetPreviewBitmap Method](#)
[ISwDMConfiguration::PreviewStreamName Property](#)
[ISwDMConfiguration7::PreviewPNGStreamName Property](#)
[ISwDocument10::GetPreviewBitmap Method](#)
[ISwDocument10::GetPreviewPNGBitmap Method](#)
[ISwDocument10::PreviewPNGStreamName Property](#)
[ISwDocument10::PreviewStreamName Property](#)
[ISwDocument11::GetPreviewBitmapBytes Method](#)
[ISwDocument11::GetPreviewPNGBitmapBytes Method](#)
[ISwSheet2::GetPreviewPNGBitmap Method](#)
[ISwSheet2::GetPreviewPNGBitmapBytes Method](#)
[ISwSheet2::PreviewPNGStreamName Property](#)

Availability

SOLIDWORKS Document Manager API 2007 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Name2 Property (ISwDMConfiguration7)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration7 Interface](#) : Name2 Property (ISwDMConfiguration7)

Gets or sets the name of the configuration.

.NET Syntax

Visual Basic (Declaration)

```
Property Name2 As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration7  
Dim value As System.String
```

```
instance.Name2 = value
```

```
value = instance.Name2
```

C#

```
System.string Name2 {get; set;}
```

C++/CLI

```
property System.String^ Name2 {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

Property Value

Name of the configuration

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration7::Name2](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

See Also

[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration7 Members](#)

Availability

PreviewPNGStreamName Property (ISwDMConfiguration7)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration7 Interface](#) : PreviewPNGStreamName Property (ISwDMConfiguration7)

Gets the name of the stream for the PNG preview bitmap of this configuration.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PreviewPNGStreamName As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration7
Dim value As System.String

value = instance.PreviewPNGStreamName
```

C#

```
System.string PreviewPNGStreamName {get;}
```

C++/CLI

```
property System.String^ PreviewPNGStreamName {
    System.String^ get();
}
```

Property Value

Name of the stream for the PNG preview bitmap or an empty string if preview bitmap does not exist

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration7::PreviewPNGStreamName](#).

Example

[Get PNG Preview Bitmap and Stream for Configuration \(C#\)](#)
[Get PNG Preview Bitmap and Stream for Configuration \(VB.NET\)](#)

See Also

[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration7 Members](#)
[ISwDMConfiguration7::GetPreviewPNGBitmap Method](#)
[ISwDMConfiguration::GetPreviewBitmap Method](#)
[ISwDMConfiguration::PreviewStreamName Property](#)
[ISwDMDocument10::GetPreviewBitmap Method](#)
[ISwDMDocument10::GetPreviewPNGBitmap Method](#)
[ISwDMDocument10::PreviewPNGStreamName Property](#)
[ISwDMDocument10::PreviewStreamName Property](#)
[ISwDMConfiguration9::GetPreviewBitmapBytes Method](#)
[ISwDMConfiguration9::GetPreviewPNGBitmapBytes Method](#)

Availability

SOLIDWORKS Document Manager API 2007 FCS

ISwDMConfiguration8 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMConfiguration8 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfiguration8 Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMConfiguration8

Inherits

[ISwDMConfiguration](#), [ISwDMConfiguration2](#), [ISwDMConfiguration3](#), [ISwDMConfiguration4](#), [ISwDMConfiguration5](#), [ISwDMConfiguration6](#), [ISwDMConfiguration7](#)

Visual Basic (Usage)



Dim instance As [ISwDMConfiguration8](#)

C#

```
public interface ISwDMConfiguration8 :  
ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4, ISwDMConfiguration5, ISwDMConfiguration6, ISwDMConfiguration7
```

C++/CLI

```
public interface class ISwDMConfiguration8 : public  
ISwDMConfiguration, ISwDMConfiguration2, ISwDMConfiguration3, ISwDMConfiguration4, ISwDMConfiguration5, ISwDMConfiguration6, ISwDMConfiguration7
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration8](#).

Remarks

- You can access an ISwDMConfiguration8 object by calling QueryInterface on an [ISwDMConfiguration](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMConfiguration object can be assigned to an ISwDMConfiguration8 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfigurationMgr::GetConfigurationByName](#)

See Also

[ISwDMConfiguration8 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)

ISwDMConfiguration8 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration8 Interface

For a list of all members of this type, see [ISwDMConfiguration8 members](#).

Public Methods

Name	Description
 GetReferencesInformation2	Gets the names of any reference documents, the configuration names of the references, and their suppression states.

[Top](#)

See Also

[ISwDMConfiguration8 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration8 Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration8 Interface

The following tables list the members exposed by [ISwDMConfiguration8](#).

Public Methods

Name	Description
 GetReferencesInformation2	Gets the names of any reference documents, the configuration names of the references, and their suppression states.

[Top](#)

See Also

[ISwDMConfiguration8 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

GetReferencesInformation2 Method (ISwDMConfiguration8)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration8 Interface](#) : GetReferencesInformation2 Method (ISwDMConfiguration8)

Gets the names of any reference documents, the configuration names of the references, and their suppression states.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetReferencesInformation2( _  
    ByRef references As System.Object, _  
    ByRef configurations As System.Object, _  
    ByRef sstates As System.Object, _  
    ByRef IsVirtual As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration8  
Dim references As System.Object  
Dim configurations As System.Object  
Dim sstates As System.Object  
Dim IsVirtual As System.Object  
  
instance.GetReferencesInformation2(references, configurations, sstates, IsVirtual)
```

C#

```
void GetReferencesInformation2(  
    out System.object references,  
    out System.object configurations,  
    out System.object sstates,  
    out System.object IsVirtual  
)
```

C++/CLI

```
void GetReferencesInformation2(  
& [Out] System.Object^ references,  
& [Out] System.Object^ configurations,  
& [Out] System.Object^ sstates,  
& [Out] System.Object^ IsVirtual  
)
```

Parameters

references

Array of paths and names of the reference documents

configurations

Array of configuration names of the reference documents

sstates

Array of Booleans indicating if the reference document is suppressed (true) or not (false)

IsVirtual

Array of Booleans indicating whether each configuration reference is a virtual component

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration8::GetReferencesInformation2](#).

Remarks

This method only works with references modified using SOLIDWORKS Document Manager API 2007 and later and SOLIDWORKS Explorer.

See Also

[ISwDMConfiguration8 Interface](#)

[ISwDMConfiguration8 Members](#)

Availability

SOLIDWORKS Document Manager API 2008 SP1

ISwDMConfiguration9 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMConfiguration9 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfiguration9 Interface

Accesses configuration-specific information for the part, assembly, or drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMConfiguration9

Inherits

[ISwDMConfiguration](#), [ISwDMConfiguration2](#), [ISwDMConfiguration3](#), [ISwDMConfiguration4](#), [ISwDMConfiguration5](#), [ISwDMConfiguration6](#), [ISwDMConfiguration7](#), [ISwDMConfiguration8](#)

Visual Basic (Usage)



Dim instance As [ISwDMConfiguration9](#)

C#

public interface ISwDMConfiguration9 :

[ISwDMConfiguration](#), [ISwDMConfiguration2](#), [ISwDMConfiguration3](#), [ISwDMConfiguration4](#), [ISwDMConfiguration5](#), [ISwDMConfiguration6](#), [ISwDMConfiguration7](#), [ISwDMConfiguration8](#)

C++/CLI

public interface class ISwDMConfiguration9 : public

[ISwDMConfiguration](#), [ISwDMConfiguration2](#), [ISwDMConfiguration3](#), [ISwDMConfiguration4](#), [ISwDMConfiguration5](#), [ISwDMConfiguration6](#), [ISwDMConfiguration7](#), [ISwDMConfiguration8](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration9](#).

Remarks

- You can access an ISwDMConfiguration9 object by calling QueryInterface on an [ISwDMConfiguration](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMConfiguration object can be assigned to an ISwDMConfiguration9 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfigurationMgr::GetConfigurationByName](#)

See Also

[ISwDMConfiguration9 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)

ISwDMConfiguration9 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration9 Interface

For a list of all members of this type, see [ISwDMConfiguration9 members](#).

Public Methods

Name	Description
 GetPreviewBitmapBytes	Gets the preview byte array for this document.
 GetPreviewPNGBitmapBytes	Gets the preview PNG byte array for this document.

[Top](#)

See Also

[ISwDMConfiguration9 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfiguration9 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfiguration9 Interface

The following tables list the members exposed by [ISwDMConfiguration9](#).

Public Methods

Name	Description
 GetPreviewBitmapBytes	Gets the preview byte array for this document.
 GetPreviewPNGBitmapBytes	Gets the preview PNG byte array for this document.

[Top](#)

See Also

[ISwDMConfiguration9 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

GetPreviewBitmapBytes Method (ISwDMConfiguration9)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration9 Interface](#) : GetPreviewBitmapBytes Method (ISwDMConfiguration9)

Gets the preview byte array for this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPreviewBitmapBytes( _  
    ByRef result As SwDmPreviewError _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration9  
Dim result As SwDmPreviewError  
Dim value As System.Object  
  
value = instance.GetPreviewBitmapBytes(result)
```

C#

```
System.object GetPreviewBitmapBytes(  
    out SwDmPreviewError result  
)
```

C++/CLI

```
System.Object^ GetPreviewBitmapBytes(  
& [Out] SwDmPreviewError result  
)
```

Parameters

result

Success or error code as defined by [swDmPreviewError](#)

Return Value

Preview byte array

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration9::GetPreviewBitmapBytes](#).

See Also

[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration9 Members](#)
[ISwDMConfiguration::GetPreviewBitmap Method](#)
[ISwDMConfiguration::PreviewStreamName Property](#)
[ISwDMConfiguration7::GetPreviewPNGBitmap Method](#)
[ISwDMConfiguration7::PreviewPNGStreamName Property](#)
[ISwDMDocument10::GetPreviewBitmap Method](#)
[ISwDMDocument10::GetPreviewPNGBitmap Method](#)
[ISwDMDocument10::PreviewPNGStreamName Property](#)
[ISwDMDocument10::PreviewStreamName Property](#)
[ISwDMConfiguration9::GetPreviewPNGBitmapBytes Method](#)
[ISwDSheet2::GetPreviewPNGBitmapBytes Method](#)
[ISwDSheet2::GetPreviewPNGBitmap Method](#)
[ISwDSheet2::PreviewPNGStreamName Property](#)

Availability

SOLIDWORKS Document Manager API 2008 SP4

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPreviewPNGBitmapBytes Method (ISwDMConfiguration9)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfiguration9 Interface](#) : GetPreviewPNGBitmapBytes Method (ISwDMConfiguration9)

Gets the preview PNG byte array for this document.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetPreviewPNGBitmapBytes( _  
    ByRef result As SwDmPreviewError _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfiguration9  
Dim result As SwDmPreviewError  
Dim value As System.Object  
  
value = instance.GetPreviewPNGBitmapBytes(result)
```

C#

```
System.Object GetPreviewPNGBitmapBytes(  
    out SwDmPreviewError result  
)
```

C++/CLI

```
System.Object^ GetPreviewPNGBitmapBytes(  
& [Out] SwDmPreviewError result  
)
```

Parameters

result

Success or error code as defined by [swDmPreviewError](#)

Return Value

Preview PNG byte array

Visual Basic for Applications (VBA) Syntax

See [SwDMConfiguration9::GetPreviewPNGBitmapBytes](#).

See Also

[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration9 Members](#)
[ISwDMConfiguration9::GetPreviewBitmapBytes Method](#)
[ISwDMConfiguration::GetPreviewBitmap Method](#)
[ISwDMConfiguration::PreviewStreamName Property](#)
[ISwDMConfiguration7::GetPreviewPNGBitmap Method](#)
[ISwDMConfiguration7::PreviewPNGStreamName Property](#)
[ISwDMDocument10::GetPreviewBitmap Method](#)
[ISwDMDocument10::GetPreviewPNGBitmap Method](#)
[ISwDMDocument10::PreviewPNGStreamName Property](#)
[ISwDMDocument10::PreviewStreamName Property](#)
[ISwDMSheet2::GetPreviewPNGBitmap Method](#)
[ISwDMSheet2::GetPreviewPNGBitmapBytes Method](#)
[ISwDMSheet2::PreviewPNGStreamName Property](#)

Availability

SOLIDWORKS Document Manager API 2008 SP4