

SOLIDWORKS Document Manager API (.NET) — Reference (5/19): ISwDMConfigurationMgr- ISwDMDimXpertAngularityGeo Tol

SOLIDWORKS API Documentation (converted from CHM)

ISwDMConfigurationMgr (Type)

ISwDMConfigurationMgr Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfigurationMgr Interface

Accesses the ConfigurationMgr for the document, which lets you get different configurations in the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMConfigurationMgr

Visual Basic (Usage)



Dim instance As [ISwDMConfigurationMgr](#)

C#

public interface ISwDMConfigurationMgr

C++/CLI

public interface class ISwDMConfigurationMgr

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

Accessors

[ISwDMDocument::ConfigurationManager](#)

See Also

[ISwDMConfigurationMgr Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfigurationMgr Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfigurationMgr Interface

The following tables list the members exposed by [ISwDMConfigurationMgr](#).

Public Properties

Name	Description
 Application	Gets the ISwDMSApplication object.
 Document	Gets the ISwDMDocument object for this document.

[Top](#)

Public Methods

Name	Description
 GetActiveConfigurationName	Gets the name of the active configuration in the document.
 GetConfigurationByName	Obsolete. Superseded by ISwDMConfigurationMgr2::GetConfigurationByName2 .
 GetConfigurationCount	Obsolete. Superseded by ISwDMConfigurationMgr2::GetConfigurationCount2 .
 GetConfigurationNames	Obsolete. Superseded by ISwDMConfigurationMgr2::GetConfigurationNames2 .

[Top](#)

See Also

[ISwDMConfigurationMgr Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMConfigurationMgr Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfigurationMgr Interface

For a list of all members of this type, see [ISwDMConfigurationMgr members](#).

Public Methods

Name	Description
 GetActiveConfigurationName	Gets the name of the active configuration in the document.
 GetConfigurationByName	Obsolete. Superseded by ISwDMConfigurationMgr2::GetConfigurationByName2 .
 GetConfigurationCount	Obsolete. Superseded by ISwDMConfigurationMgr2::GetConfigurationCount2 .
 GetConfigurationNames	Obsolete. Superseded by ISwDMConfigurationMgr2::GetConfigurationNames2 .

[Top](#)

See Also

[ISwDMConfigurationMgr Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)

[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMConfigurationMgr Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfigurationMgr Interface

For a list of all members of this type, see [ISwDMConfigurationMgr members](#).

Public Properties

Name	Description
Application	Gets the ISwDMAApplication object.
Document	Gets the ISwDMDocument object for this document.

[Top](#)

See Also

[ISwDMConfigurationMgr Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Application Property (ISwDMConfigurationMgr)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfigurationMgr Interface](#) : Application Property (ISwDMConfigurationMgr)

Gets the [ISwDMAApplication](#) object.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Application As SwDMAApplication
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr  
Dim value As SwDMAApplication  
  
value = instance.Application
```

C#

```
SwDMAApplication Application {get;}
```

C++/CLI

```
property SwDMAApplication^ Application {  
    SwDMAApplication^ get();  
}
```

Property Value

Pointer to the [ISwDMApplication](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr::Application](#).

See Also

[ISwDMConfigurationMgr Interface](#)
[ISwDMConfigurationMgr Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Document Property (ISwDMConfigurationMgr)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfigurationMgr Interface](#) : Document Property (ISwDMConfigurationMgr)

Gets the [ISwDMDocument](#) object for this document.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Document As SwDMDocument
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr  
Dim value As SwDMDocument  
  
value = instance.Document
```

C#

```
SwDMDocument Document {get;}
```

C++/CLI

```
property SwDMDocument^ Document {  
    SwDMDocument^ get();  
}
```

Property Value

Pointer to [ISwDMDocument](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr::Document](#).

See Also

[ISwDMConfigurationMgr Interface](#)
[ISwDMConfigurationMgr Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetActiveConfigurationName Method (ISwDMConfigurationMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfigurationMgr Interface](#) : GetActiveConfigurationName Method (ISwDMConfigurationMgr)

Gets the name of the active configuration in the document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetActiveConfigurationName() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr
Dim value As System.String

value = instance.GetActiveConfigurationName()
```

C#

```
System.string GetActiveConfigurationName()
```

C++/CLI

```
System.String^ GetActiveConfigurationName();
```

Return Value

Name of the active configuration

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr::GetActiveConfigurationName](#).

Example

[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

See Also

[ISwDMConfigurationMgr Interface](#)
[ISwDMConfigurationMgr Members](#)
[ISwDMComponent::ConfigurationName Property](#)
[ISwDMConfiguration::GetParentConfigurationName Method](#)
[ISwDMConfiguration7::Name2 Property](#)
[ISwDMConfigurationMgr::GetConfigurationByName Method](#)
[ISwDMConfigurationMgr::GetConfigurationCount Method](#)
[ISwDMConfigurationMgr::GetConfigurationNames Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetConfigurationByName Method (ISwDMConfigurationMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfigurationMgr Interface](#) : GetConfigurationByName Method (ISwDMConfigurationMgr)

Obsolete. Superseded by [ISwDMConfigurationMgr2::GetConfigurationByName2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationByName( _
    ByVal ConfigurationName As System.String _
) As SwDMConfiguration
```

```
Dim instance As ISwDMConfigurationMgr
Dim ConfigurationName As System.String
Dim value As SwDMConfiguration

value = instance.GetConfigurationByName(ConfigurationName)
```

C#

```
SwDMConfiguration GetConfigurationByName(
    System.string ConfigurationName
)
```

C++/CLI

```
SwDMConfiguration^ GetConfigurationByName(
    & System.String^ ConfigurationName
)
```

Parameters*ConfigurationName*Name of configuration to get (see **Remarks**)**Return Value**Pointer to an [ISwDMConfiguration](#) object **Visual Basic for Applications (VBA) Syntax**See [SwDMConfigurationMgr::GetConfigurationByName](#). **Example**

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Write Parasolid Partition Stream to File \(C++\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(C#\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(VB.NET\)](#)
[Replace Component \(C#\)](#)
[Replace Component \(VB.NET\)](#)

 RemarksCall [ISwDMConfigurationMgr::GetConfigurationNames](#) before calling this method. **See Also**

[ISwDMConfigurationMgr Interface](#)
[ISwDMConfigurationMgr Members](#)
[ISwDMComponent::ConfigurationName Property](#)
[ISwDMConfiguration::GetParentConfigurationName Method](#)
[ISwDMConfiguration7::Name2 Property](#)
[ISwDMConfigurationMgr::GetActiveConfigurationName Method](#)
[ISwDMConfigurationMgr::GetConfigurationCount Method](#)

 Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)**GetConfigurationCount Method (ISwDMConfigurationMgr)**[See Also](#)[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfigurationMgr Interface](#) : GetConfigurationCount Method (ISwDMConfigurationMgr)**Obsolete.** Superseded by [ISwDMConfigurationMgr2::GetConfigurationCount2](#). **.NET Syntax**

Visual Basic (Declaration)

```
Function GetConfigurationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr  
Dim value As System.Integer  
  
value = instance.GetConfigurationCount()
```

C#

```
System.int GetConfigurationCount()
```

C++/CLI

```
System.int GetConfigurationCount();
```

Return Value

Number of configurations

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr::GetConfigurationCount](#).

See Also

[ISwDMConfigurationMgr Interface](#)
[ISwDMConfigurationMgr Members](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetConfigurationNames Method (ISwDMConfigurationMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfigurationMgr Interface](#) : GetConfigurationNames Method (ISwDMConfigurationMgr)

Obsolete. Superseded by [ISwDMConfigurationMgr2::GetConfigurationNames2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr  
Dim value As System.Object  
  
value = instance.GetConfigurationNames()
```

C#

```
System.object GetConfigurationNames()
```

C++/CLI

```
System.Object^ GetConfigurationNames();
```

Return Value

Names of the configurations

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr::GetConfigurationNames](#).

Example

[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Write Parasolid Partition Stream to File \(C++\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(C#\)](#)
[Get Whether Component Is Envelope and Excluded from BOM \(VB.NET\)](#)
[Replace Component \(C#\)](#)
[Replace Component \(VB.NET\)](#)

Remarks

Call this method before calling [ISwDMConfigurationMgr::GetConfigurationByName](#).

See Also

[ISwDMConfigurationMgr Interface](#)
[ISwDMConfigurationMgr Members](#)
[ISwDMComponent::ConfigurationName Property](#)
[ISwDMConfiguration::GetParentConfigurationName Method](#)
[ISwDMConfiguration7::Name2 Property](#)
[ISwDMConfigurationMgr::GetActiveConfigurationName Method](#)
[ISwDMConfigurationMgr::GetConfigurationCount Method](#)

Availability

SOLIDWORKS Document Manager API 2004 FCS

ISwDMConfigurationMgr2 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMConfigurationMgr2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMConfigurationMgr2 Interface

Accesses the ConfigurationMgr for the document, which lets you get different configurations of the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMConfigurationMgr2
    Inherits ISwDMConfigurationMgr
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr2
```

C#

```
public interface ISwDMConfigurationMgr2 : ISwDMConfigurationMgr
```

C++/CLI

```
public interface class ISwDMConfigurationMgr2 : public ISwDMConfigurationMgr
```

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr2](#).

Example

[Get Configuration Information \(VB.NET\)](#)
[Get Configuration Information \(C#\)](#)

Remarks

- In C++ you can access an ISwDMConfigurationMgr2 object by calling QueryInterface on an [ISwDMConfigurationMgr](#) object.
- In other languages, the ISwDMConfigurationMgr object can be cast to ISwDMConfigurationMgr2 by assignment.

Accessors

[ISwDMDocument::ConfigurationManager](#)

See Also

[ISwDMConfigurationMgr2 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMConfigurationMgr Interface](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfigurationMgr2 Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfigurationMgr2 Interface

The following tables list the members exposed by [ISwDMConfigurationMgr2](#).

Public Methods

Name	Description
 GetConfigurationByName2	Gets the specified configuration in the document.
 GetConfigurationCount2	Gets the number of configurations in this document.
 GetConfigurationNames2	Gets the names of the configurations in this document.

[Top](#)

See Also

[ISwDMConfigurationMgr2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfigurationMgr Interface](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

ISwDMConfigurationMgr2 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMConfigurationMgr2 Interface

For a list of all members of this type, see [ISwDMConfigurationMgr2 members](#).

Public Methods

Name	Description
 GetConfigurationByName2	Gets the specified configuration in the document.
 GetConfigurationCount2	Gets the number of configurations in this document.
 GetConfigurationNames2	Gets the names of the configurations in this document.

[Top](#)

See Also

[ISwDMConfigurationMgr2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMConfigurationMgr Interface](#)
[ISwDMConfiguration Interface](#)
[ISwDMConfiguration2 Interface](#)
[ISwDMConfiguration3 Interface](#)
[ISwDMConfiguration4 Interface](#)
[ISwDMConfiguration5 Interface](#)
[ISwDMConfiguration6 Interface](#)
[ISwDMConfiguration7 Interface](#)
[ISwDMConfiguration8 Interface](#)
[ISwDMConfiguration9 Interface](#)
[ISwDMConfiguration10 Interface](#)
[ISwDMConfiguration11 Interface](#)
[ISwDMConfiguration12 Interface](#)
[ISwDMConfiguration13 Interface](#)
[ISwDMConfiguration14 Interface](#)
[ISwDMConfiguration15 Interface](#)
[ISwDMConfiguration16 Interface](#)
[ISwDMConfiguration17 Interface](#)
[ISwDMConfiguration18 Interface](#)

GetConfigurationByName2 Method (ISwDMConfigurationMgr2)

[See Also](#)[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfigurationMgr2 Interface](#) : GetConfigurationByName2 Method (ISwDMConfigurationMgr2)

Gets the specified configuration in the document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationByName2( _
    ByVal ConfigurationName As System.String, _
    ByRef result As SwDMConfigurationError _
) As SwDMConfiguration
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr2
Dim ConfigurationName As System.String
Dim result As SwDMConfigurationError
Dim value As SwDMConfiguration

value = instance.GetConfigurationByName2(ConfigurationName, result)
```

C#

```
SwDMConfiguration GetConfigurationByName2(
    System.string ConfigurationName,
    out SwDMConfigurationError result
)
```

C++/CLI

```
SwDMConfiguration^ GetConfigurationByName2(
    & System.String^ ConfigurationName,
    & [Out] SwDMConfigurationError result
)
```

Parameters

*ConfigurationName*Name of configuration to get (see **Remarks**)*result*Return code as defined in [swDMConfigurationError](#)

Return Value

Pointer to an [ISwDMConfiguration](#) object

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr2::GetConfigurationByName2](#).

Example

See the [ISwDMConfigurationMgr2](#) examples.

Remarks

Call [ISwDMConfigurationMgr2::GetConfigurationNames2](#) before calling this method.

See Also

[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfigurationMgr2 Members](#)
[ISwDMComponent::ConfigurationName Property\(\)](#)
[ISwDMConfiguration::GetParentConfigurationName Method\(\)](#)
[ISwDMConfiguration7::Name2 Property\(\)](#)

Availability

SOLIDWORKS Document Manager API 2019 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetConfigurationCount2 Method (ISwDMConfigurationMgr2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMConfigurationMgr2 Interface](#) : GetConfigurationCount2 Method (ISwDMConfigurationMgr2)

Gets the number of configurations in this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationCount2( _  
    ByRef result As SwDMConfigurationError _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr2  
Dim result As SwDMConfigurationError  
Dim value As System.Integer  
  
value = instance.GetConfigurationCount2(result)
```

C#

```
System.int GetConfigurationCount2(  
    out SwDMConfigurationError result  
)
```

C++/CLI

```
System.int GetConfigurationCount2(  
& [Out] SwDMConfigurationError result  
)
```

Parameters

result

Return code as defined in [swDMConfigurationError](#)

Return Value

Number of configurations

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr2::GetConfigurationCount2](#).

Example

See the [ISwDMConfigurationMgr2](#) examples.

See Also

[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfigurationMgr2 Members](#)

Availability

SOLIDWORKS Document Manager API 2019 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetConfigurationNames2 Method (ISwDMConfigurationMgr2)

[See Also](#)



Gets the names of the configurations in this document.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetConfigurationNames2( _  
    ByRef result As SwDMConfigurationError _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMConfigurationMgr2  
Dim result As SwDMConfigurationError  
Dim value As System.Object  
  
value = instance.GetConfigurationNames2(result)
```

C#

```
System.object GetConfigurationNames2(  
    out SwDMConfigurationError result  
)
```

C++/CLI

```
System.Object^ GetConfigurationNames2(  
& [Out] SwDMConfigurationError result  
)
```

Parameters

result

Return code as defined in [swDMConfigurationError](#)

Return Value

Array of configuration names

Visual Basic for Applications (VBA) Syntax

See [SwDMConfigurationMgr2::GetConfigurationNames2](#).

Example

See the [ISwDMConfigurationMgr2](#) examples.

Remarks

Call this method before calling [ISwDMConfigurationMgr2::GetConfigurationByName2](#).

See Also

[ISwDMConfigurationMgr2 Interface](#)
[ISwDMConfigurationMgr2 Members](#)
[ISwDMComponent::ConfigurationName Property\(\)](#)
[ISwDMConfiguration::GetParentConfigurationName Method\(\)](#)
[ISwDMConfiguration7::Name2 Property\(\)](#)

Availability

SOLIDWORKS Document Manager API 2019 SP0

ISwDMCutListItem (Type)

ISwDMCutListItem Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem Interface

Accesses cut-list items.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMCutListItem
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem
```

C#

```
public interface ISwDMCutListItem
```

C++/CLI

```
public interface class ISwDMCutListItem
```

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

Accessors

[ISwDMDocument10.GetCutListItems2](#)

See Also

[ISwDMCutListItem Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem4 Interface](#)

ISwDMCutListItem Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem Interface

The following tables list the members exposed by [ISwDMCutListItem](#).

Public Properties

Name	Description
 Name	Gets the name of this cut-list item.
 Quantity	Gets the number of this cut-list item.

[Top](#)

Public Methods

Name	Description
 GetCustomPropertyNames	Gets the names of custom property names for this cut-list item.
 GetCustomPropertyValue	Obsolete. Superseded by ISwDMCutListItem2.GetCustomPropertyValue2 .

[Top](#)

See Also

[ISwDMCutListItem Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem4 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMCutListItem Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem Interface

For a list of all members of this type, see [ISwDMCutListItem members](#).

Public Methods

Name	Description
 GetCustomPropertyNames	Gets the names of custom property names for this cut-list item.
 GetCustomPropertyValue	Obsolete. Superseded by ISwDMCutListItem2.GetCustomPropertyValue2 .

[Top](#)

See Also

[ISwDMCutListItem Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem4 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMCutListItem Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem Interface

For a list of all members of this type, see [ISwDMCutListItem members](#).

Public Properties

Name	Description
 Name	Gets the name of this cut-list item.
 Quantity	Gets the number of this cut-list item.

[Top](#)

See Also

[ISwDMCutListItem Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem4 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetCustomPropertyNames Method (ISwDMCutListItem)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem Interface](#) : GetCustomPropertyNames Method (ISwDMCutListItem)

Gets the names of custom property names for this cut-list item.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetCustomPropertyNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem  
Dim value As System.Object  
  
value = instance.GetCustomPropertyNames()
```

C#

```
System.Object GetCustomPropertyNames()
```

C++/CLI

```
System.Object^ GetCustomPropertyNames();
```

Return Value

Array of custom property names

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem::GetCustomPropertyNames](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

See Also

[ISwDMCutListItem Interface](#)
[ISwDMCutListItem Members](#)
[ISwDMCutListItem2::DeleteCustomProperty Method](#)
[ISwDMCutListItem2::SetCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetCustomPropertyValue Method (ISwDMCutListItem)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem Interface](#) : GetCustomPropertyValue Method (ISwDMCutListItem)

Obsolete. Superseded by [ISwDMCutListItem2::GetCustomPropertyValue2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetCustomPropertyValue( _  
    ByVal FieldName As System.String, _  
    ByRef type As SwDmCustomInfoType, _  
    ByRef linkedTo As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem  
Dim fieldName As System.String  
Dim type As SwDmCustomInfoType
```

```
Dim linkedTo As System.String
Dim value As System.String

value = instance.GetCustomPropertyValue(FieldName, type, linkedTo)
```

C#

```
System.string GetCustomPropertyValue(
    System.string FieldName,
    out SwDmCustomInfoType type,
    out System.string linkedTo
)
```

C++/CLI

```
System.String^ GetCustomPropertyValue(
    & System.String^ FieldName,
    & [Out] SwDmCustomInfoType type,
    & [Out] System.String^ linkedTo
)
```

Parameters

FieldName

type

linkedTo

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem::GetCustomPropertyValue](#).

See Also

[ISwDMCutListItem Interface](#)
[ISwDMCutListItem Members](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

Name Property (ISwDMCutListItem)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem Interface](#) : Name Property (ISwDMCutListItem)

Gets the name of this cut-list item.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem
Dim value As System.String

instance.Name = value

value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

Property Value

Name of cut-list item

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem::Name](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

See Also

[ISwDMCutListItem Interface](#)
[ISwDMCutListItem Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

Quantity Property (ISwDMCutListItem)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem Interface](#) : Quantity Property (ISwDMCutListItem)

Gets the number of this cut-list item.

.NET Syntax

Visual Basic (Declaration)

```
Property Quantity As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem  
Dim value As System.Integer  
  
instance.Quantity = value  
  
value = instance.Quantity
```

C#

```
System.int Quantity {get; set;}
```

C++/CLI

```
property System.int Quantity {  
    System.int get();  
    void set ( & System.int value);  
}
```

Property Value

Number of this cut-list item

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem::Quantity](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

See Also

[ISwDMCutListItem Interface](#)
[ISwDMCutListItem Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

ISwDMCutListItem2 (Type)

ISwDMCutListItem2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem2 Interface

Accesses cut-list items.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMCutListItem2
    Inherits ISwDMCutListItem
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem2
```

C#

```
public interface ISwDMCutListItem2 : ISwDMCutListItem
```

C++/CLI

```
public interface class ISwDMCutListItem2 : public ISwDMCutListItem
```

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem2](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

Remarks

- You can access an ISwCutListItem2 object by calling QueryInterface on an [ISwDMCutListItem](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMCutListItem object can be assigned to an ISwDMCutListItem variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMDocument10::GetCutListItems2](#)

See Also

[ISwDMCutListItem2 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem4 Interface](#)

ISwDMCutListItem2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem2 Interface

The following tables list the members exposed by [ISwDMCutListItem2](#).

Public Properties

Name	Description
 ChildFolderName	Gets the name of the cut list's child folder, if it exists.
 IsSubFolder	Gets whether a cut-list item is a sub-folder. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 AddCustomProperty	Adds a custom property to this cut-list item.
 DeleteCustomProperty	Deletes the specified custom property from this cut-list item.
 GetCustomPropertyValue2	Gets the evaluated value of this custom property for this cut-list item.
 SetCustomProperty	Sets a custom property for this cut-list item.

[Top](#)

See Also

[ISwDMCutListItem2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem4 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMCutListItem2 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem2 Interface

For a list of all members of this type, see [ISwDMCutListItem2 members](#).

Public Methods

Name	Description
 AddCustomProperty	Adds a custom property to this cut-list item.
 DeleteCustomProperty	Deletes the specified custom property from this cut-list item.
 GetCustomPropertyValue2	Gets the evaluated value of this custom property for this cut-list item.
 SetCustomProperty	Sets a custom property for this cut-list item.

[Top](#)

See Also

[ISwDMCutListItem2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem4 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMCutListItem2 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem2 Interface

For a list of all members of this type, see [ISwDMCutListItem2 members](#).

Public Properties

Name	Description
 ChildFolderName	Gets the name of the cut list's child folder, if it exists.



[IsSubFolder](#)

Gets whether a cut-list item is a sub-folder.

NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[ISwDMCutListItem2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem4 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

AddCustomProperty Method (ISwDMCutListItem2)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem2 Interface](#) : AddCustomProperty Method (ISwDMCutListItem2)

Adds a custom property to this cut-list item.

.NET Syntax

Visual Basic (Declaration)

```
Function AddCustomProperty( _  
    ByVal FieldName As System.String, _  
    ByVal FieldType As SwDmCustomInfoType, _  
    ByVal FieldValue As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem2  
Dim FieldName As System.String  
Dim FieldType As SwDmCustomInfoType  
Dim FieldValue As System.String  
Dim value As System.Boolean  
  
value = instance.AddCustomProperty(FieldName, FieldType, FieldValue)
```

C#

```
System.bool AddCustomProperty(  
    System.string FieldName,  
    SwDmCustomInfoType FieldType,  
    System.string FieldValue  
)
```

C++/CLI

```
System.bool AddCustomProperty(  
& System.String^ FieldName,  
& SwDmCustomInfoType FieldType,  
& System.String^ FieldValue  
)
```

Parameters

FieldName
Property name
FieldType
Property type as defined by [swDMCustomInfoType](#)
FieldValue
Property link-to value or text expression

Return Value

True if the custom property is added to the cut-list item, false if not and false if the specified custom property name already exists

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem2::AddCustomProperty](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

Remarks

This method only supports model documents saved in SOLIDWORKS 2009 or later.

If you call this method to add a linked custom property with an expression value, then you need to open and save the file in SOLIDWORKS before calling [ISwDMCutListItem2::GetCustomPropertyValue2](#). SOLIDWORKS needs to process the linked custom property before your DocumentMgr application attempts to get its evaluated value.

See Also

[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem2 Members](#)
[ISwDMCutListItem2::DeleteCustomProperty Method](#)
[ISwDMCutListItem2::SetCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ChildFolderName Property (ISwDMCutListItem2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem2 Interface](#) : ChildFolderName Property (ISwDMCutListItem2)

Gets the name of the cut list's child folder, if it exists.

.NET Syntax

Visual Basic (Declaration)

```
Property ChildFolderName As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem2
Dim value As System.String

instance.ChildFolderName = value
value = instance.ChildFolderName
```

C#

```
System.string ChildFolderName {get; set;}
```

C++/CLI

```
property System.String^ ChildFolderName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

Property Value

Name of cut list's child folder, if it exists

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem2::ChildFolderName](#).

Remarks

This property only supports documents saved in SOLIDWORKS 2009 or later.

See Also

[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem2 Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

[SOLIDWORKS Document Manager API Help](#)

[Send comments on this topic.](#)

DeleteCustomProperty Method (ISwDMCutListItem2)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem2 Interface](#) : DeleteCustomProperty Method (ISwDMCutListItem2)

Deletes the specified custom property from this cut-list item.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteCustomProperty( _  
    ByVal FieldName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem2  
Dim fieldName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteCustomProperty(fieldName)
```

C#

```
System.bool DeleteCustomProperty(  
    System.string FieldName  
)
```

C++/CLI

```
System.bool DeleteCustomProperty(  
& System.String^ FieldName  
)
```

Parameters

FieldName
Custom property to delete from the cut-list item

Return Value

True if the custom property is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem2.DeleteCustomProperty](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

Remarks

This method only supports model documents saved in SOLIDWORKS 2009 or later.

Before calling this method, call [ISwDMCutListItem::GetCustomPropertyNames](#).

See Also

[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem2 Members](#)
[ISwDMCutListItem2::AddCustomProperty Method](#)
[ISwDMCutListItem2::GetCustomPropertyValue2 Method](#)
[ISwDMCutListItem2::SetCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetCustomPropertyValue2 Method (ISwDMCutListItem2)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem2 Interface](#) : GetCustomPropertyValue2 Method (ISwDMCutListItem2)

Gets the evaluated value of this custom property for this cut-list item.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomPropertyValue2( _  
    ByVal FieldName As System.String, _  
    ByRef type As SwDmCustomInfoType, _  
    ByRef linkedTo As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem2  
Dim FieldName As System.String  
Dim type As SwDmCustomInfoType  
Dim linkedTo As System.String  
Dim value As System.String  
  
value = instance.GetCustomPropertyValue2(FieldName, type, linkedTo)
```

C#

```
System.string GetCustomPropertyValue2(  
    System.string FieldName,  
    out SwDmCustomInfoType type,  
    out System.string linkedTo  
)
```

C++/CLI

```
System.String^ GetCustomPropertyValue2(  
& System.String^ FieldName,  
& [Out] SwDmCustomInfoType type,  
& [Out] System.String^ linkedTo  
)
```

Parameters

FieldName

Custom property name (see **Remarks**)

type

Property type as defined by [swDmCustomInfoType](#)

linkedTo

Link-to value or text expression

Return Value

Evaluated value

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem2::GetCustomPropertyValue2](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

Remarks

This method only supports model documents saved in SOLIDWORKS 2009 or later.

To populate FieldName, use [ISwDMCutListItem::GetCustomPropertyNames](#) to get the names of all of the custom properties.

If you called [ISwDMCutListItem2::SetCustomProperty](#) to set a linked custom property, then you must open and save the file in SOLIDWORKS before calling this method. SOLIDWORKS must process the linked custom property before your DocumentMgr application can retrieve its evaluated value.

See Also

[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem2 Members](#)
[ISwDMCutListItem2::AddCustomProperty Method](#)
[ISwDMCutListItem2::DeleteCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsSubFolder Property (ISwDMCutListItem2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem2 Interface](#) : IsSubFolder Property (ISwDMCutListItem2)

Gets whether a cut-list item is a sub-folder.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property IsSubFolder As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem2  
Dim value As System.Boolean
```

```
instance.IsSubFolder = value
```

```
value = instance.IsSubFolder
```

C#

```
System.bool IsSubFolder {get; set;}
```

C++/CLI

```
property System.bool IsSubFolder {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

Property Value

True if the cut-list item is a sub-folder, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem2::IsSubFolder](#).

Remarks

A cut-list folder has either one or no child folder.

This property only supports documents saved in SOLIDWORKS 2009 or later.

See Also

[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem2 Members](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

SetCustomProperty Method (ISwDMCutListItem2)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem2 Interface](#) : SetCustomProperty Method (ISwDMCutListItem2)

Sets a custom property for this cut-list item.

.NET Syntax

Visual Basic (Declaration)

```
Function SetCustomProperty( _  
    ByVal FieldName As System.String, _  
    ByVal newValue As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem2  
Dim fieldName As System.String  
Dim newValue As System.String  
Dim value As System.Boolean  
  
value = instance.SetCustomProperty(fieldName, newValue)
```

C#

```
System.bool SetCustomProperty(  
    System.string FieldName,  
    System.string newValue  
)
```

C++/CLI

```
System.bool SetCustomProperty(  
& System.String^ FieldName,  
& System.String^ newValue  
)
```

Parameters

FieldName
Property name
newValue
Property link-to value or text expression

Return Value

True if the custom property is updated, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem2::SetCustomProperty](#).

Example

[Get, Add, Change, and Delete Cut-List Custom Properties \(C#\)](#)
[Get, Add, Change, and Delete Cut-List Custom Properties \(VB.NET\)](#)

Remarks

This method only supports model documents saved in SOLIDWORKS 2009 and later.

Before calling this method, call [ISwDMCutListItem::GetCustomPropertyNames](#) to get all of the custom properties for this cut-list item.

If you call this method to set a linked custom property with an expression value, then you need to open and save the file in SOLIDWORKS before calling [ISwDMCutListItem2::GetCustomPropertyValue2](#). SOLIDWORKS needs to process the linked custom property before your DocumentMgr application attempts to get its evaluated value.

See Also

[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem2 Members](#)
[ISwDMCutListItem2::AddCustomProperty Method](#)
[ISwDMCutListItem2::DeleteCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

ISwDMCutListItem3 (Type)

ISwDMCutListItem3 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem3 Interface

Accesses cut-list items.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMCutListItem3
    Inherits ISwDMCutListItem, ISwDMCutListItem2
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem3
```

C#

```
public interface ISwDMCutListItem3 : ISwDMCutListItem, ISwDMCutListItem2
```

C++/CLI

```
public interface class ISwDMCutListItem3 : public ISwDMCutListItem, ISwDMCutListItem2
```

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem3](#).

Remarks

- You can access an ISwCutListItem3 object by calling QueryInterface on an [ISwDMCutListItem](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMCutListItem object can be assigned to an ISwDMCutListItem3 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration16::GetCutListItems](#)

[ISwDMDocument10::GetCutListItems2](#)

See Also

[ISwDMCutListItem3 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem4 Interface](#)

ISwDMCutListItem3 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem3 Interface

The following tables list the members exposed by [ISwDMCutListItem3](#).

Public Methods

Name	Description
 IsCustomPropertyEditable	Gets whether the specified custom property is editable.

[Top](#)

See Also

[ISwDMCutListItem3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem4 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMCutListItem3 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem3 Interface

For a list of all members of this type, see [ISwDMCutListItem3 members](#).

Public Methods

Name	Description
 IsCustomPropertyEditable	Gets whether the specified custom property is editable.

[Top](#)

See Also

[ISwDMCutListItem3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem4 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

IsCustomPropertyEditable Method (ISwDMCutListItem3)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem3 Interface](#) : IsCustomPropertyEditable Method (ISwDMCutListItem3)

Gets whether the specified custom property is editable.

.NET Syntax

Visual Basic (Declaration)

```
Sub IsCustomPropertyEditable( _  
    ByVal FieldName As System.String, _  
    ByRef IsEditable As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem3  
Dim FieldName As System.String  
Dim IsEditable As System.Boolean  
  
instance.IsCustomPropertyEditable(FieldName, IsEditable)
```

C#

```
void IsCustomPropertyEditable(  
    System.string FieldName,  
    out System.bool IsEditable  
)
```

C++/CLI

```
void IsCustomPropertyEditable(  
& System.String^ FieldName,  
& [Out] System.bool IsEditable  
)
```

Parameters

FieldName
Name of the custom property
IsEditable
True if editable, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem3::IsCustomPropertyEditable](#).

Remarks

To populate *FieldName*, use [ISwDMCutListItem::GetCustomPropertyNames](#) to get the names of all of the custom properties.

See Also

[ISwDMCutListItem3 Interface](#)
[ISwDMCutListItem3 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

ISwDMCutListItem4 (Type)

ISwDMCutListItem4 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem4 Interface

Accesses cut-list items.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMCutListItem4
    Inherits ISwDMCutListItem, ISwDMCutListItem2, ISwDMCutListItem3
```

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem4
```

C#

```
public interface ISwDMCutListItem4 : ISwDMCutListItem, ISwDMCutListItem2, ISwDMCutListItem3
```

C++/CLI

```
public interface class ISwDMCutListItem4 : public
ISwDMCutListItem, ISwDMCutListItem2, ISwDMCutListItem3
```

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem4](#).

Remarks

- You can access an ISwCutListItem4 object by calling QueryInterface on an [ISwDMCutListItem](#) object in C++ or by direct assignment in Visual Basic.
- The ISwDMCutListItem object can be assigned to an ISwDMCutListItem4 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMConfiguration16::GetCutListItems](#)

[ISwDMDocument10::GetCutListItems2](#)

See Also

[ISwDMCutListItem4 Members](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#)

[ISwDMCutListItem Interface](#)

[ISwDMCutListItem2 Interface](#)

[ISwDMCutListItem3 Interface](#)

ISwDMCutListItem4 Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem4 Interface

The following tables list the members exposed by [ISwDMCutListItem4](#).

Public Properties

Name	Description
------	-------------

 CutlistType	Gets the type of this item's cut list.
 ExcludeFromCutlist	Gets whether this item is excluded from the cut list. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 See Also

[ISwDMCutListItem4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem3 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMCutListItem4 Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMCutListItem4 Interface

For a list of all members of this type, see [ISwDMCutListItem4 members](#).

 Public Properties

Name	Description
 CutlistType	Gets the type of this item's cut list.
 ExcludeFromCutlist	Gets whether this item is excluded from the cut list. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 See Also

[ISwDMCutListItem4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMCutListItem Interface](#)
[ISwDMCutListItem2 Interface](#)
[ISwDMCutListItem3 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

CutlistType Property (ISwDMCutListItem4)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem4 Interface](#) : CutlistType Property (ISwDMCutListItem4)

Gets the type of this item's cut list.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property CutlistType As [swDMCutListType_e](#)

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem4
Dim value As swDMCutListType\_e

value = instance.CutlistType
```

C#

```
swDMCutListType\_e CutlistType {get;}
```

C++/CLI

```
property swDMCutListType\_e CutlistType {
    swDMCutListType\_e get();
}
```

Property Value

Cut list type as defined by [swDMCutListType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem4::CutListType](#).

See Also

[ISwDMCutListItem4 Interface](#)
[ISwDMCutListItem4 Members](#)

Availability

SOLIDWORKS Document Manager API 2021 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ExcludeFromCutlist Property (ISwDMCutListItem4)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMCutListItem4 Interface](#) : ExcludeFromCutlist Property (ISwDMCutListItem4)

Gets whether this item is excluded from the cut list.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property ExcludeFromCutlist As [swDMCutListExclusionStatus_e](#)

Visual Basic (Usage)



```
Dim instance As ISwDMCutListItem4
Dim value As swDMCutListExclusionStatus\_e

instance.ExcludeFromCutlist = value

value = instance.ExcludeFromCutlist
```

C#

```
swDMCutListExclusionStatus\_e ExcludeFromCutlist {get; set;}
```

C++/CLI

```
property swDMCutListExclusionStatus\_e ExcludeFromCutlist {
    swDMCutListExclusionStatus\_e get();
    void set ( & swDMCutListExclusionStatus\_e value);
}
```

Property Value

As defined by [swDMCutListExclusionStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMCutListItem4::ExcludeFromCutlist](#).

Remarks

This property is only valid for documents saved in SOLIDWORKS 2021 or later.

See Also

[ISwDMCutListItem4 Interface](#)
[ISwDMCutListItem4 Members](#)

ISwDMDimXpertAngleBetweenDimTol (Type)

ISwDMDimXpertAngleBetweenDimTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertAngleBetweenDimTol Interface

Allows you to access tolerance information for DimXpert angle-between dimensions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertAngleBetweenDimTol
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAngleBetweenDimTol
```

C#

```
public interface ISwDMDimXpertAngleBetweenDimTol
```

C++/CLI

```
public interface class ISwDMDimXpertAngleBetweenDimTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAngleBetweenDimTol](#).

Example

[Get DimXpert Tolerance4 \(VB.NET\)](#)
[Get DimXpert Tolerance4 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertDimensionTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertAngleBetweenDimTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertAngleBetweenDimTol Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertAngleBetweenDimTol Interface

For a list of all members of this type, see [ISwDMDimXpertAngleBetweenDimTol members](#).

Public Methods

Name	Description
 GetDirectionVector	Gets the direction vector for computing the angle of this DimXpert angle-between dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertAngleBetweenDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertAngleBetweenDimTol Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertAngleBetweenDimTol Interface

The following tables list the members exposed by [ISwDMDimXpertAngleBetweenDimTol](#).

Public Properties

Name	Description
 OriginFeature	Gets the DimXpert feature of origin for this DimXpert angle-between dimension tolerance.
 Supplement	Gets whether to evaluate the supplement angle for this DimXpert angle-between dimension tolerance.

[Top](#)

Public Methods

Name	Description
 GetDirectionVector	Gets the direction vector for computing the angle of this DimXpert angle-between dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertAngleBetweenDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertAngleBetweenDimTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertAngleBetweenDimTol Interface

For a list of all members of this type, see [ISwDMDimXpertAngleBetweenDimTol members](#).

Public Properties

Name	Description
 OriginFeature	Gets the DimXpert feature of origin for this DimXpert angle-between dimension tolerance.
 Supplement	Gets whether to evaluate the supplement angle for this DimXpert angle-between dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertAngleBetweenDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetDirectionVector Method (ISwDMDimXpertAngleBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAngleBetweenDimTol Interface](#) : GetDirectionVector Method (ISwDMDimXpertAngleBetweenDimTol)

Gets the direction vector for computing the angle of this DimXpert angle-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _
```

```
ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAngleBetweenDimTol  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetDirectionVector(I, J, K)
```

C#

```
System.bool GetDirectionVector(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetDirectionVector(  
    & [Out] System.double I,  
    & [Out] System.double J,  
    & [Out] System.double K  
)
```

Parameters

I
i component of direction vector
J
j component of direction vector
K
k component of direction vector

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAngleBetweenDimTol::GetDirectionVector](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAngleBetweenDimTol Interface](#)
[ISwDMDimXpertAngleBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

OriginFeature Property (ISwDMDimXpertAngleBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAngleBetweenDimTol Interface](#) : OriginFeature Property (ISwDMDimXpertAngleBetweenDimTol)

Gets the DimXpert feature of origin for this DimXpert angle-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property OriginFeature As SwDMDimXpertFeature

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAngleBetweenDimTol  
Dim value As SwDMDimXpertFeature
```

```
value = instance.OriginFeature
```

C#

```
SwDMDimXpertFeature OriginFeature {get;}
```

C++/CLI

```
property SwDMDimXpertFeature^ OriginFeature {  
    SwDMDimXpertFeature^ get();  
}
```

Property Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAngleBetweenDimTol::OriginFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAngleBetweenDimTol Interface](#)
[ISwDMDimXpertAngleBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Supplement Property (ISwDMDimXpertAngleBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAngleBetweenDimTol Interface](#) : Supplement Property (ISwDMDimXpertAngleBetweenDimTol)

Gets whether to evaluate the supplement angle for this DimXpert angle-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Supplement As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAngleBetweenDimTol  
Dim value As System.Boolean
```

```
value = instance.Supplement
```

C#

```
System.bool Supplement {get;}
```

C++/CLI

```
property System.bool Supplement {  
    System.bool get();  
}
```

Property Value

True to evaluate the supplement angle; false to not

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAngleBetweenDimTol::Supplement](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAngleBetweenDimTol Interface](#)
[ISwDMDimXpertAngleBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertAngularityGeoTol (Type)

ISwDMDimXpertAngularityGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertAngularityGeoTol Interface

Allows you to access DimXpert angularity geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertAngularityGeoTol

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [ISwDMDimXpertAngularityGeoTol](#)

C#

public interface ISwDMDimXpertAngularityGeoTol

C++/CLI

public interface class ISwDMDimXpertAngularityGeoTol

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAngularityGeoTol](#).

Example

[Get DimXpert Tolerance8 \(VB.NET\)](#)
[Get DimXpert Tolerance8 \(C#\)](#)

Remarks

This interface is one of three orientation interfaces described by [ISwDMDimXpertOrientationGeoTol](#).
You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertAngularityGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertAngularityGeoTol Interface Members

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertAngularityGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertAngularityGeoTol](#).

See Also

[ISwDMDimXpertAngularityGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)