

SOLIDWORKS Document Manager API (.NET) — Reference (6/19): ISwDMDimXpertAnnotation- ISwDMDimXpertCompositeDistanceBetweenDim

SOLIDWORKS API Documentation (converted from CHM)

ISwDMDimXpertAnnotation (Type)

ISwDMDimXpertAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertAnnotation Interface

Allows you to access general information about DimXpert geometric tolerance, dimension tolerance, and datum annotations.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertAnnotation

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertAnnotation](#)

C#

public interface ISwDMDimXpertAnnotation

C++/CLI

public interface class ISwDMDimXpertAnnotation

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation](#).

Example

[Get DimXpert Sphere and Datum \(VB.NET\)](#)
[Get DimXpert Sphere and Datum \(C#\)](#)

Remarks

This interface is the base class for three types of annotation interface: [ISwDMDimXpertGeometricTolerance](#), [ISwDMDimXpertDimensionTolerance](#), and [ISwDMDimXpertDatum](#). Use the [ISwDMDimXpertAnnotation::type](#) property to find out which specific interface is needed to acquire more information for a given DimXpert annotation type.

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertAnnotation Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertAnnotation Interface

The following tables list the members exposed by [ISwDMDimXpertAnnotation](#).

Public Properties

Name	Description
 Feature	Gets the DimXpert feature to which this DimXpert annotation is applied.
 Name	Gets the name of this DimXpert annotation.



[type](#)

Gets the type of this DimXpert annotation.

[Top](#)

Public Methods

Name	Description
 GetCadIdentifierCount	Gets the number of CAD identifiers in this DimXpert annotation.
 GetCadIdentifiers	Gets all of the CAD identifiers of this DimXpert annotation.
 IGetCadIdentifiers	Gets all of the CAD identifiers of this DimXpert annotation.
 IsFreeState	Gets whether this DimXpert annotation is in a free state.
 IsStatistical	Gets whether this DimXpert annotation is statistical.
 IsSuppressed	Gets whether this DimXpert annotation is suppressed from view in the model.
 IsToBeInspected	Gets whether this DimXpert annotation is to be inspected.

[Top](#)

See Also

[ISwMDDimXpertAnnotation Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDDimXpertAnnotation Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDDimXpertAnnotation Interface

For a list of all members of this type, see [ISwMDDimXpertAnnotation members](#).

Public Methods

Name	Description
 GetCadIdentifierCount	Gets the number of CAD identifiers in this DimXpert annotation.
 GetCadIdentifiers	Gets all of the CAD identifiers of this DimXpert annotation.
 IGetCadIdentifiers	Gets all of the CAD identifiers of this DimXpert annotation.
 IsFreeState	Gets whether this DimXpert annotation is in a free state.
 IsStatistical	Gets whether this DimXpert annotation is statistical.
 IsSuppressed	Gets whether this DimXpert annotation is suppressed from view in the model.
 IsToBeInspected	Gets whether this DimXpert annotation is to be inspected.

[Top](#)

See Also

[ISwMDDimXpertAnnotation Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDDimXpertAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDDimXpertAnnotation Interface

For a list of all members of this type, see [ISwMDDimXpertAnnotation members](#).

Public Properties

Name	Description
 Feature	Gets the DimXpert feature to which this DimXpert annotation is applied.
 Name	Gets the name of this DimXpert annotation.



[type](#)

Gets the type of this DimXpert annotation.

[Top](#)

See Also

[ISwMDimXpertAnnotation Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Feature Property (ISwMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertAnnotation Interface](#) : Feature Property (ISwMDimXpertAnnotation)

Gets the DimXpert feature to which this DimXpert annotation is applied.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Feature As SwMDimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertAnnotation  
Dim value As SwMDimXpertFeature  
  
value = instance.Feature
```

C#

```
SwMDimXpertFeature Feature {get;}
```

C++/CLI

```
property SwMDimXpertFeature^ Feature {  
    SwMDimXpertFeature^ get();  
}
```

Property Value

[ISwMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertAnnotation::Feature](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertAnnotation Interface](#)
[ISwMDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetCadIdentifierCount Method (ISwMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertAnnotation Interface](#) : GetCadIdentifierCount Method (ISwMDimXpertAnnotation)

Gets the number of CAD identifiers in this DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCadIdentifierCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation  
Dim value As System.Integer  
  
value = instance.GetCadIdentifierCount()
```

C#

```
System.int GetCadIdentifierCount()
```

C++/CLI

```
System.int GetCadIdentifierCount();
```

Return Value

Number of CAD identifiers

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation::GetCadIdentifierCount](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetCadIdentifiers Method (ISwDMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAnnotation Interface](#) : GetCadIdentifiers Method (ISwDMDimXpertAnnotation)

Gets all of the CAD identifiers of this DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCadIdentifiers() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation  
Dim value As System.Object  
  
value = instance.GetCadIdentifiers()
```

C#

```
System.object GetCadIdentifiers()
```

C++/CLI

```
System.Object^ GetCadIdentifiers();
```

Return Value

Array of strings; the format of each string is bodyid:faceid

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation::GetCadIdentifiers](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)
[ISwDMDimXpertAnnotation::IGetCadIdentifiers Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IGetCadIdentifiers Method (ISwDMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAnnotation Interface](#) : IGetCadIdentifiers Method (ISwDMDimXpertAnnotation)

Gets all of the CAD identifiers of this DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCadIdentifiers( _  
    ByVal Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation  
Dim Count As System.Integer  
Dim value As System.String  
  
value = instance.IGetCadIdentifiers(Count)
```

C#

```
System.string IGetCadIdentifiers(  
    System.int Count  
)
```

C++/CLI

```
System.String^ IGetCadIdentifiers(  
& System.int Count  
)
```

Parameters

Count
Number of CAD identifiers

Return Value

- in-process, unmanaged C++: Pointer to an array of strings; the format of each string is bodyid:faceid

- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwDMDimXpertAnnotation::GetCadIdentifierCount](#) to populate the Count argument.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)
[ISwDMDimXpertAnnotation::GetCadIdentifiers Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsFreeState Method (ISwDMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAnnotation Interface](#) : IsFreeState Method (ISwDMDimXpertAnnotation)

Gets whether this DimXpert annotation is in a free state.

.NET Syntax

Visual Basic (Declaration)

```
Function IsFreeState() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation
Dim value As System.Boolean

value = instance.IsFreeState()
```

C#

```
System.bool IsFreeState()
```

C++/CLI

```
System.bool IsFreeState();
```

Return Value

True if in a free state; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation::IsFreeState](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsStatistical Method (ISwDMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAnnotation Interface](#) : IsStatistical Method (ISwDMDimXpertAnnotation)

Gets whether this DimXpert annotation is statistical.

.NET Syntax

Visual Basic (Declaration)

```
Function IsStatistical() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation  
Dim value As System.Boolean  
  
value = instance.IsStatistical()
```

C#

```
System.bool IsStatistical()
```

C++/CLI

```
System.bool IsStatistical();
```

Return Value

True if statistical; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation::IsStatistical](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

IsSuppressed Method (ISwDMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAnnotation Interface](#) : IsSuppressed Method (ISwDMDimXpertAnnotation)

Gets whether this DimXpert annotation is suppressed from view in the model.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSuppressed() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation  
Dim value As System.Boolean
```

```
value = instance.IsSuppressed()
```

C#

```
System.bool IsSuppressed()
```

C++/CLI

```
System.bool IsSuppressed();
```

Return Value

True if suppressed from view; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation::IsSuppressed](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsToBeInspected Method (ISwDMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAnnotation Interface](#) : IsToBeInspected Method (ISwDMDimXpertAnnotation)

Gets whether this DimXpert annotation is to be inspected.

.NET Syntax

Visual Basic (Declaration)

```
Function IsToBeInspected() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation  
Dim value As System.Boolean  
  
value = instance.IsToBeInspected()
```

C#

```
System.bool IsToBeInspected()
```

C++/CLI

```
System.bool IsToBeInspected();
```

Return Value

True if is to be inspected; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation::IsToBeInspected](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Name Property (ISwDMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAnnotation Interface](#) : Name Property (ISwDMDimXpertAnnotation)

Gets the name of this DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Name As System.String

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

Property Value

Name of the annotation

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation::Name](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

type Property (ISwDMDimXpertAnnotation)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertAnnotation Interface](#) : type Property (ISwDMDimXpertAnnotation)

Gets the type of this DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property type As swDmDimXpertAnnotationType\_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertAnnotation  
Dim value As swDmDimXpertAnnotationType\_e
```

```
value = instance.type
```

C#

```
swDmDimXpertAnnotationType\_e type {get;}
```

C++/CLI

```
property swDmDimXpertAnnotationType\_e type {  
    swDmDimXpertAnnotationType\_e get();  
}
```

Property Value

Type of annotation as defined in [swDmDimXpertAnnotationType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertAnnotation::type](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertAnnotation Interface](#)
[ISwDMDimXpertAnnotation Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertBestFitPlaneFeature (Type)

ISwDMDimXpertBestFitPlaneFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertBestFitPlaneFeature Interface

Allows you to access specific information about DimXpert best fit planes.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertBestFitPlaneFeature

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertBestFitPlaneFeature](#)

C#

public interface ISwDMDimXpertBestFitPlaneFeature

C++/CLI

public interface class ISwDMDimXpertBestFitPlaneFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertBestFitPlaneFeature](#).

Example

[Get DimXpert Compound Width and Best Fit Plane Features \(VB.NET\)](#)
[Get DimXpert Compound Width and Best Fit Plane Features \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertBestFitPlaneFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertBestFitPlaneFeature Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertBestFitPlaneFeature Interface

The following tables list the members exposed by [ISwDMDimXpertBestFitPlaneFeature](#).

Public Methods

Name	Description
 GetNominalPlane	Gets the coordinates and direction vector for this DimXpert best fit plane.
 GetSubFeatureCount	Gets the number of sub-features of this DimXpert best fit plane.
GetSubFeatures	Gets all of the sub-features of this DimXpert best fit plane.



[IGetSubFeatures](#)

Gets all of the sub-features of this DimXpert best fit plane.

[Top](#)

See Also

[ISwDMDimXpertBestFitPlaneFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertBestFitPlaneFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : [ISwDMDimXpertBestFitPlaneFeature Interface](#)

For a list of all members of this type, see [ISwDMDimXpertBestFitPlaneFeature members](#).

Public Methods

Name	Description
GetNominalPlane	Gets the coordinates and direction vector for this DimXpert best fit plane.
GetSubFeatureCount	Gets the number of sub-features of this DimXpert best fit plane.
GetSubFeatures	Gets all of the sub-features of this DimXpert best fit plane.
IGetSubFeatures	Gets all of the sub-features of this DimXpert best fit plane.

[Top](#)

See Also

[ISwDMDimXpertBestFitPlaneFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalPlane Method (ISwDMDimXpertBestFitPlaneFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertBestFitPlaneFeature Interface](#) : [GetNominalPlane Method \(ISwDMDimXpertBestFitPlaneFeature\)](#)

Gets the coordinates and direction vector for this DimXpert best fit plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertBestFitPlaneFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalPlane(X, Y, Z, I, J, K)
```

C#

```

System.bool GetNominalPlane(
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetNominalPlane(
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)

```

Parameters

X
x coordinate of the best fit plane

Y
y coordinate of the best fit plane

Z
z coordinate of the best fit plane

I
i component of direction vector of the best fit plane

J
j component of direction vector of the best fit plane

K
k component of direction vector of the best fit plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [ISwDMDimXpertBestFitPlaneFeature::GetNominalPlane](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertBestFitPlaneFeature Interface](#)
[ISwDMDimXpertBestFitPlaneFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetSubFeatureCount Method (ISwDMDimXpertBestFitPlaneFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertBestFitPlaneFeature Interface](#) : GetSubFeatureCount Method (ISwDMDimXpertBestFitPlaneFeature)

Gets the number of sub-features of this DimXpert best fit plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSubFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertBestFitPlaneFeature  
Dim value As System.Integer  
  
value = instance.GetSubFeatureCount()
```

C#

```
System.int GetSubFeatureCount()
```

C++/CLI

```
System.int GetSubFeatureCount();
```

Return Value

Number of sub-features of the best fit plane

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertBestFitPlaneFeature::GetSubFeatureCount](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertBestFitPlaneFeature Interface](#)
[ISwDMDimXpertBestFitPlaneFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetSubFeatures Method (ISwDMDimXpertBestFitPlaneFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertBestFitPlaneFeature Interface](#) : GetSubFeatures Method (ISwDMDimXpertBestFitPlaneFeature)

Gets all of the sub-features of this DimXpert best fit plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSubFeatures() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertBestFitPlaneFeature  
Dim value As System.Object  
  
value = instance.GetSubFeatures()
```

C#

```
System.object GetSubFeatures()
```

C++/CLI

```
System.Object^ GetSubFeatures();
```

Return Value

Array of [ISwDMDimXpertFeatures](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertBestFitPlaneFeature::GetSubFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertBestFitPlaneFeature Interface](#)
[ISwDMDimXpertBestFitPlaneFeature Members](#)
[ISwDMDimXpertBestFitPlaneFeature::IGetSubFeatures Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IGetSubFeatures Method (ISwDMDimXpertBestFitPlaneFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertBestFitPlaneFeature Interface](#) : IGetSubFeatures Method (ISwDMDimXpertBestFitPlaneFeature)

Gets all of the sub-features of this DimXpert best fit plane.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSubFeatures(  
    ByVal Count As System.Integer _  
) As SwDMDimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertBestFitPlaneFeature  
Dim Count As System.Integer  
Dim value As SwDMDimXpertFeature  
  
value = instance.IGetSubFeatures(Count)
```

C#

```
SwDMDimXpertFeature IGetSubFeatures(  
    System.int Count  
)
```

C++/CLI

```
SwDMDimXpertFeature^ IGetSubFeatures(  
&    System.int Count  
)
```

Parameters

Count
Number of sub-features of the best fit plane

Return Value

- in-process, unmanaged C++: Pointer to an array of [SwDMDimXpertFeatures](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwDMDimXpertBestFitPlaneFeature::GetSubFeatureCount](#) to populate the Count argument.

See Also

[ISwDMDimXpertBestFitPlaneFeature Interface](#)
[ISwDMDimXpertBestFitPlaneFeature Members](#)
[ISwDMDimXpertBestFitPlaneFeature::GetSubFeatures Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertBlockTolerances (Type)

ISwDMDimXpertBlockTolerances Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertBlockTolerances Interface

Allows you to access DimXpert block tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertBlockTolerances

Visual Basic (Usage)

Dim instance As [ISwDMDimXpertBlockTolerances](#)

C#

public interface ISwDMDimXpertBlockTolerances

C++/CLI

public interface class ISwDMDimXpertBlockTolerances

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertBlockTolerances](#).

Example

[Get DimXpert Block Tolerance \(VB.NET\)](#)
[Get DimXpert Block Tolerance \(C#\)](#)

Accessors

[ISwDMDimXpertPart::GetBlockTolerances method](#)

See Also

[ISwDMDimXpertBlockTolerances Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertBlockTolerances Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertBlockTolerances Interface

For a list of all members of this type, see [ISwDMDimXpertBlockTolerances members](#).

Public Methods

Name	Description
GetISO2768PartType	Gets the ISO 2768 part type of this DimXpert block tolerance.
GetToleranceValues	Gets block tolerance settings for a given document.

[Top](#)

See Also

ISwDMDimXpertBlockTolerances Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertBlockTolerances Interface

The following tables list the members exposed by [ISwDMDimXpertBlockTolerances](#).

Public Properties

Name	Description
 type	Gets the type of this DimXpert block tolerance.

[Top](#)

Public Methods

Name	Description
 GetISO2768PartType	Gets the ISO 2768 part type of this DimXpert block tolerance.
 GetToleranceValues	Gets block tolerance settings for a given document.

[Top](#)

See Also

[ISwDMDimXpertBlockTolerances Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertBlockTolerances Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertBlockTolerances Interface

For a list of all members of this type, see [ISwDMDimXpertBlockTolerances members](#).

Public Properties

Name	Description
 type	Gets the type of this DimXpert block tolerance.

[Top](#)

See Also

[ISwDMDimXpertBlockTolerances Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

GetISO2768PartType Method (ISwDMDimXpertBlockTolerances)

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertBlockTolerances Interface](#) : GetISO2768PartType Method (ISwDMDimXpertBlockTolerances)

Gets the ISO 2768 part type of this DimXpert block tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetISO2768PartType( _  
    ByRef type As swDmDimXpertISO2768PartType\_e _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertBlockTolerances
Dim type As swDmDimXpertISO2768PartType_e
Dim value As System.Boolean

value = instance.GetISO2768PartType(type)
```

C#

```
System.bool GetISO2768PartType(
    out swDmDimXpertISO2768PartType_e type
)
```

C++/CLI

```
System.bool GetISO2768PartType(
    & [Out] swDmDimXpertISO2768PartType_e type
)
```

Parameters

type
Type of ISO 2768 block tolerance as defined in [swDmDimXpertISO2768PartType_e](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertBlockTolerances::GetISO2768PartType](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertBlockTolerances Interface](#)
[ISwMDimXpertBlockTolerances Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetToleranceValues Method (ISwMDimXpertBlockTolerances)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertBlockTolerances Interface](#) : GetToleranceValues Method (ISwMDimXpertBlockTolerances)

Gets block tolerance settings for a given document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetToleranceValues( _
    ByRef Linear1 As System.Double, _
    ByRef Linear1Prec As System.Integer, _
    ByRef Linear2 As System.Double, _
    ByRef Linear2Prec As System.Integer, _
    ByRef Linear3 As System.Double, _
    ByRef Linear3Prec As System.Integer, _
    ByRef Angular As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As ISwDMDimXpertBlockTolerances
Dim Linear1 As System.Double
Dim Linear1Prec As System.Integer
Dim Linear2 As System.Double
Dim Linear2Prec As System.Integer
Dim Linear3 As System.Double
Dim Linear3Prec As System.Integer
Dim Angular As System.Double
Dim value As System.Boolean

value = instance.GetToleranceValues(Linear1, Linear1Prec, Linear2, Linear2Prec, Linear3,
Linear3Prec, Angular)

```

C#

```

System.bool GetToleranceValues(
    out System.double Linear1,
    out System.int Linear1Prec,
    out System.double Linear2,
    out System.int Linear2Prec,
    out System.double Linear3,
    out System.int Linear3Prec,
    out System.double Angular
)

```

C++/CLI

```

System.bool GetToleranceValues(
    & [Out] System.double Linear1,
    & [Out] System.int Linear1Prec,
    & [Out] System.double Linear2,
    & [Out] System.int Linear2Prec,
    & [Out] System.double Linear3,
    & [Out] System.int Linear3Prec,
    & [Out] System.double Angular
)

```

Parameters

Linear1
Tolerance for x dimension
Linear1Prec
Number of decimal places for Linear1 tolerance
Linear2
Tolerance for y dimension
Linear2Prec
Number of decimal places for Linear2 tolerance
Linear3
Tolerance for z dimension
Linear3Prec
Number of decimal places for Linear3 tolerance
Angular
Tolerance for angular dimension

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertBlockTolerances::GetToleranceValues](#).

Example

See the examples on the interface page.

Remarks

This interface accesses the DimXpert block tolerance settings that are specified in the SOLIDWORKS System Options and Document Properties dialog (Tools > Options > Document Properties DimXpert).

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

type Property (ISwDMDimXpertBlockTolerances)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertBlockTolerances Interface](#) : type Property (ISwDMDimXpertBlockTolerances)

Gets the type of this DimXpert block tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property type As [swDmDimXpertBlockToleranceType_e](#)

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertBlockTolerances  
Dim value As swDmDimXpertBlockToleranceType\_e
```

```
value = instance.type
```

C#

```
swDmDimXpertBlockToleranceType\_e type {get;}
```

C++/CLI

```
property swDmDimXpertBlockToleranceType\_e type {  
    swDmDimXpertBlockToleranceType\_e get();  
}
```

Property Value

Type of block tolerance as defined in [swDmDimXpertBlockToleranceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertBlockTolerances::type](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertBlockTolerances Interface](#)
[ISwDMDimXpertBlockTolerances Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertChamferDimTol (Type)

ISwDMDimXpertChamferDimTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertChamferDimTol Interface

Allows you to access tolerance information for DimXpert chamfer dimensions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertChamferDimTol
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertChamferDimTol
```

C#

```
public interface ISwDMDimXpertChamferDimTol
```

C++/CLI

```
public interface class ISwDMDimXpertChamferDimTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertChamferDimTol](#).

Example

[Get DimXpert Tolerance4 \(VB.NET\)](#)
[Get DimXpert Tolerance4 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertDimensionTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertChamferDimTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertChamferDimTol Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertChamferDimTol Interface

The following tables list the members exposed by [ISwDMDimXpertChamferDimTol](#).

Public Properties

Name	Description
 ChamferType	Gets the type of chamfer dimension for this DimXpert chamfer dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertChamferDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertChamferDimTol Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertChamferDimTol Interface

For a list of all members of this type, see [ISwDMDimXpertChamferDimTol members](#).

Public Properties

Name	Description
 ChamferType	Gets the type of chamfer dimension for this DimXpert chamfer dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertChamferDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ChamferType Property (ISwDMDimXpertChamferDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertChamferDimTol Interface](#) : ChamferType Property (ISwDMDimXpertChamferDimTol)

Gets the type of chamfer dimension for this DimXpert chamfer dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ChamferType As [swDmDimXpertChamferDimensionType_e](#)

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertChamferDimTol  
Dim value As swDmDimXpertChamferDimensionType\_e  
  
value = instance.ChamferType
```

C#

```
swDmDimXpertChamferDimensionType\_e ChamferType {get;}
```

C++/CLI

```
property swDmDimXpertChamferDimensionType\_e ChamferType {  
    swDmDimXpertChamferDimensionType\_e get();  
}
```

Property Value

Type of chamfer dimension as defined in [swDmDimXpertChamferDimensionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertChamferDimTol::ChamferType](#).

Example

See the examples on the interface page.

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertChamferFeature (Type)

ISwDMDimXpertChamferFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertChamferFeature Interface

Allows you to access specific information about DimXpert chamfers.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertChamferFeature

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertChamferFeature](#)

C#

public interface ISwDMDimXpertChamferFeature

C++/CLI

public interface class ISwDMDimXpertChamferFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertChamferFeature](#).

Example

[Get DimXpert Chamfer Feature \(VB.NET\)](#)
[Get DimXpert Chamfer Feature \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertChamferFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertChamferFeature Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertChamferFeature Interface

The following tables list the members exposed by [ISwDMDimXpertChamferFeature](#).

Public Properties

Name	Description
 Angle	Gets the angle of this DimXpert chamfer.
 AngleType	Gets the type of chamfer angle for this DimXpert chamfer.
ChamferType	Gets the type of this DimXpert chamfer.

[Distance1](#)

Gets the length on bevel side 1 of the selected edge, face, or vertex of this DimXpert chamfer.

[Distance2](#)

Gets the length on bevel side 2 of the selected edge, face, or vertex of this DimXpert chamfer.

[Top](#)

See Also

[ISwDMDimXpertChamferFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertChamferFeature Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertChamferFeature Interface

For a list of all members of this type, see [ISwDMDimXpertChamferFeature members](#).

Public Properties

Name	Description
 Angle	Gets the angle of this DimXpert chamfer.
 AngleType	Gets the type of chamfer angle for this DimXpert chamfer.
 ChamferType	Gets the type of this DimXpert chamfer.
 Distance1	Gets the length on bevel side 1 of the selected edge, face, or vertex of this DimXpert chamfer.
 Distance2	Gets the length on bevel side 2 of the selected edge, face, or vertex of this DimXpert chamfer.

[Top](#)

See Also

[ISwDMDimXpertChamferFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Angle Property (ISwDMDimXpertChamferFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertChamferFeature Interface](#) : Angle Property (ISwDMDimXpertChamferFeature)

Gets the angle of this DimXpert chamfer.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Angle As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertChamferFeature  
Dim value As System.Double
```

```
value = instance.Angle
```

C#

```
System.double Angle {get;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
}
```

Property Value

Angle of the chamfer in radians

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertChamferFeature::Angle](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertChamferFeature Interface](#)
[ISwDMDimXpertChamferFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

AngleType Property (ISwDMDimXpertChamferFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertChamferFeature Interface](#) : AngleType Property (ISwDMDimXpertChamferFeature)

Gets the type of chamfer angle for this DimXpert chamfer.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property AngleType As swDmDimXpertChamferAngleType\_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertChamferFeature  
Dim value As swDmDimXpertChamferAngleType\_e  
  
value = instance.AngleType
```

C#

```
swDmDimXpertChamferAngleType\_e AngleType {get;}
```

C++/CLI

```
property swDmDimXpertChamferAngleType\_e AngleType {  
    swDmDimXpertChamferAngleType\_e get();  
}
```

Property Value

Type of chamfer angle as defined in [swDmDimXpertChamferAngleType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertChamferFeature::AngleType](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertChamferFeature Interface](#)
[ISwDMDimXpertChamferFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ChamferType Property (ISwMDimXpertChamferFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertChamferFeature Interface](#) : ChamferType Property (ISwMDimXpertChamferFeature)

Gets the type of this DimXpert chamfer.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ChamferType As swDmDimXpertChamferType\_e
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertChamferFeature  
Dim value As swDmDimXpertChamferType\_e  
  
value = instance.ChamferType
```

C#

```
swDmDimXpertChamferType\_e ChamferType {get;}
```

C++/CLI

```
property swDmDimXpertChamferType\_e ChamferType {  
    swDmDimXpertChamferType\_e get();  
}
```

Property Value

Type of chamfer as defined in [swDmDimXpertChamferType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertChamferFeature::ChamferType](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertChamferFeature Interface](#)
[ISwMDimXpertChamferFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Distance1 Property (ISwMDimXpertChamferFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertChamferFeature Interface](#) : Distance1 Property (ISwMDimXpertChamferFeature)

Gets the length on bevel side 1 of the selected edge, face, or vertex of this DimXpert chamfer.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Distance1 As System.Double

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertChamferFeature  
Dim value As System.Double
```

```
value = instance.Distance1
```

C#

```
System.double Distance1 {get;}
```

C++/CLI

```
property System.double Distance1 {  
    System.double get();  
}
```

Property Value

Length on bevel side 1 of the chamfer

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertChamferFeature::Distance1](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertChamferFeature Interface](#)
[ISwDMDimXpertChamferFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

Distance2 Property (ISwDMDimXpertChamferFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertChamferFeature Interface](#) : Distance2 Property (ISwDMDimXpertChamferFeature)

Gets the length on bevel side 2 of the selected edge, face, or vertex of this DimXpert chamfer.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Distance2 As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertChamferFeature  
Dim value As System.Double
```

```
value = instance.Distance2
```

C#

```
System.double Distance2 {get;}
```

C++/CLI

```
property System.double Distance2 {  
    System.double get();  
}
```

Property Value

Length on bevel side 2 of the chamfer

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertChamferFeature::Distance2](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertChamferFeature Interface](#)
[ISwDMDimXpertChamferFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCircularityGeoTol (Type)

ISwDMDimXpertCircularityGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCircularityGeoTol Interface

Allows you to access DimXpert circularity geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertCircularityGeoTol

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertCircularityGeoTol](#)

C#

public interface ISwDMDimXpertCircularityGeoTol

C++/CLI

public interface class ISwDMDimXpertCircularityGeoTol

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCircularityGeoTol](#).

Example

[Get DimXpert Tolerance1 \(VB.NET\)](#)
[Get DimXpert Tolerance1 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertCircularityGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCircularityGeoTol Interface Members

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCircularityGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertCircularityGeoTol](#).

See Also

[ISwDMDimXpertCircularityGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCircularRunoutGeoTol (Type)

ISwDMDimXpertCircularRunoutGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCircularRunoutGeoTol Interface

Allows you to access DimXpert circular runout geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertCircularRunoutGeoTol

Visual Basic (Usage)

Dim instance As [ISwDMDimXpertCircularRunoutGeoTol](#)

C#

public interface ISwDMDimXpertCircularRunoutGeoTol

C++/CLI

public interface class ISwDMDimXpertCircularRunoutGeoTol

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCircularRunoutGeoTol](#).

Example

[Get DimXpert Tolerance8 \(VB.NET\)](#)
[Get DimXpert Tolerance8 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertCircularRunoutGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCircularRunoutGeoTol Interface Members

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCircularRunoutGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertCircularRunoutGeoTol](#).

See Also

[ISwDMDimXpertCircularRunoutGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCompositeDistanceBetweenDimTol (Type)

ISwDMDimXpertCompositeDistanceBetweenDimTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeDistanceBetweenDimTol Interface

Allows you to access tolerance information for DimXpert composite distance-between dimensions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCompositeDistanceBetweenDimTol
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeDistanceBetweenDimTol
```

C#

```
public interface ISwDMDimXpertCompositeDistanceBetweenDimTol
```

C++/CLI

```
public interface class ISwDMDimXpertCompositeDistanceBetweenDimTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeDistanceBetweenDimTol](#).

Example

[Get DimXpert Tolerance2 \(VB.NET\)](#)
[Get DimXpert Tolerance2 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertDimensionTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertCompositeDistanceBetweenDimTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCompositeDistanceBetweenDimTol Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeDistanceBetweenDimTol Interface

For a list of all members of this type, see [ISwDMDimXpertCompositeDistanceBetweenDimTol members](#).

Public Methods

Name	Description
 GetDirectionVector	Gets the direction vector used to compute the distance-between of this DimXpert distance-between dimension tolerance.
 GetFeature	Gets the DimXpert feature to which this DimXpert composite distance-between dimension tolerance is applied.
GetIntraFeature	Gets the DimXpert feature located by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

		
	GetNominalValueIntraFeature	Gets the tolerance used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.
	GetOriginFeature	Gets the DimXpert feature of origin to which this DimXpert composite distance-between dimension tolerance is applied.
	GetPlusAndMinusToleranceIntraFeature	Gets the plus and minus tolerance values used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.
	GetUpperAndLowerLimitIntraFeature	Gets the upper and lower tolerance limits used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

[Top](#)

See Also

[ISwMDDimXpertCompositeDistanceBetweenDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwMDDimXpertCompositeDistanceBetweenDimTol Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDDimXpertCompositeDistanceBetweenDimTol Interface

The following tables list the members exposed by [ISwMDDimXpertCompositeDistanceBetweenDimTol](#).

Public Properties

Name	Description
 BlockToleranceDecimalPlacesIntraFeature	Gets the precision of the block tolerances used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.
 DimensionTypeIntraFeature	Gets the type of dimension tolerance used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.
 LimitsAndFitsCodeIntraFeature	Gets the limits and fits code used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

[Top](#)

Public Methods

Name	Description
 GetDirectionVector	Gets the direction vector used to compute the distance-between of this DimXpert distance-between dimension tolerance.
 GetFeature	Gets the DimXpert feature to which this DimXpert composite distance-between dimension tolerance is applied.
 GetIntraFeature	Gets the DimXpert feature located by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.
 GetNominalValueIntraFeature	Gets the tolerance used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.
 GetOriginFeature	Gets the DimXpert feature of origin to which this DimXpert composite distance-between dimension tolerance is applied.
 GetPlusAndMinusToleranceIntraFeature	Gets the plus and minus tolerance values used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.
 GetUpperAndLowerLimitIntraFeature	Gets the upper and lower tolerance limits used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

[Top](#)

See Also

[ISwMDDimXpertCompositeDistanceBetweenDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwMDDimXpertCompositeDistanceBetweenDimTol Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDDimXpertCompositeDistanceBetweenDimTol Interface

For a list of all members of this type, see [ISwMDDimXpertCompositeDistanceBetweenDimTol members](#).

Public Properties

Name	Description
 BlockToleranceDecimalPlacesIntraFeature	Gets the precision of the block tolerances used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.
 DimensionTypeIntraFeature	Gets the type of dimension tolerance used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.



[LimitsAndFitsCodeIntraFeature](#)

Gets the limits and fits code used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

[Top](#)

See Also

[ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

BlockToleranceDecimalPlacesIntraFeature Property (ISwMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#) : BlockToleranceDecimalPlacesIntraFeature Property (ISwMDimXpertCompositeDistanceBetweenDimTol)

Gets the precision of the block tolerances used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property BlockToleranceDecimalPlacesIntraFeature As System.Integer

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompositeDistanceBetweenDimTol  
Dim value As System.Integer
```

```
value = instance.BlockToleranceDecimalPlacesIntraFeature
```

C#

```
System.int BlockToleranceDecimalPlacesIntraFeature {get;}
```

C++/CLI

```
property System.int BlockToleranceDecimalPlacesIntraFeature {  
    System.int get();  
}
```

Property Value

Number of decimal places for block tolerances

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompositeDistanceBetweenDimTol::BlockToleranceDecimalPlacesIntraFeature](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[ISwMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

DimensionTypeIntraFeature Property (ISwMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#) : DimensionTypeIntraFeature Property (ISwMDimXpertCompositeDistanceBetweenDimTol)

Gets the type of dimension tolerance used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property DimensionTypeIntraFeature As swDmDimXpertDimensionToleranceType\_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeDistanceBetweenDimTol  
Dim value As swDmDimXpertDimensionToleranceType\_e  
  
value = instance.DimensionTypeIntraFeature
```

C#

```
swDmDimXpertDimensionToleranceType\_e DimensionTypeIntraFeature {get;}
```

C++/CLI

```
property swDmDimXpertDimensionToleranceType\_e DimensionTypeIntraFeature {  
    swDmDimXpertDimensionToleranceType\_e get();  
}
```

Property Value

Type of dimension tolerance as defined in [swDmDimXpertDimensionToleranceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeDistanceBetweenDimTol::DimensionTypeIntraFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[ISwDMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetDirectionVector Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetDirectionVector Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Gets the direction vector used to compute the distance-between of this DimXpert distance-between dimension tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetDirectionVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeDistanceBetweenDimTol  
Dim I As System.Double  
Dim J As System.Double
```

```
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetDirectionVector(I, J, K)
```

C#

```
System.bool GetDirectionVector(
    out System.double I,
    out System.double J,
    out System.double K
)
```

C++/CLI

```
System.bool GetDirectionVector(
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)
```

Parameters

I
i component of the direction vector
J
j component of the direction vector
K
k component of the direction vector

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeDistanceBetweenDimTol::GetDirectionVector](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[ISwDMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Gets the DimXpert feature to which this DimXpert composite distance-between dimension tolerance is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature( _
    ByRef Feature As SwDMDimXpertFeature, _
    ByRef FosUsage As swDmDimXpertDistanceFosUsage_e _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompositeDistanceBetweenDimTol
Dim Feature As SwMDimXpertFeature
Dim FosUsage As swDmDimXpertDistanceFosUsage_e
Dim value As System.Boolean
```

```
value = instance.GetFeature(Feature, FosUsage)
```

C#

```
System.bool GetFeature(
    out SwMDimXpertFeature Feature,
    out swDmDimXpertDistanceFosUsage_e FosUsage
)
```

C++/CLI

```
System.bool GetFeature(
    & [Out] SwMDimXpertFeature^ Feature,
    & [Out] swDmDimXpertDistanceFosUsage_e FosUsage
)
```

Parameters

Feature

[ISwMDimXpertFeature](#)

FosUsage

How to treat the feature of size when applying this tolerance as defined in [swDmDimXpertDistanceFosUsage_e](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompositeDistanceBetweenDimTol::GetFeature](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[ISwMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetIntraFeature Method (ISwMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetIntraFeature Method (ISwMDimXpertCompositeDistanceBetweenDimTol)

Gets the DimXpert feature located by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIntraFeature( _
    ByRef Feature As SwMDimXpertFeature, _
    ByRef FosUsage As swDmDimXpertDistanceFosUsage_e _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompositeDistanceBetweenDimTol
Dim Feature As SwMDimXpertFeature
Dim FosUsage As swDmDimXpertDistanceFosUsage_e
Dim value As System.Boolean
```

```
value = instance.GetIntraFeature(Feature, FosUsage)
```

C#

```
System.bool GetIntraFeature(
    out SwMDimXpertFeature Feature,
    out swDmDimXpertDistanceFosUsage_e FosUsage
)
```

C++/CLI

```
System.bool GetIntraFeature(
    & [Out] SwMDimXpertFeature^ Feature,
    & [Out] swDmDimXpertDistanceFosUsage_e FosUsage
)
```

Parameters

Feature

[ISwMDimXpertFeature](#)

FosUsage

How to treat the feature of size when applying this tolerance as defined in [swDmDimXpertDistanceFosUsage_e](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompositeDistanceBetweenDimTol::GetIntraFeature](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#)

[ISwMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalValueIntraFeature Method (ISwMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetNominalValueIntraFeature Method (ISwMDimXpertCompositeDistanceBetweenDimTol)

Gets the tolerance used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalValueIntraFeature() As System.Double
```

Visual Basic (Usage)

```
Dim instance As ISwMDimXpertCompositeDistanceBetweenDimTol
Dim value As System.Double
```



```
value = instance.GetNominalValueIntraFeature()
```

C#

```
System.double GetNominalValueIntraFeature()
```

C++/CLI

```
System.double GetNominalValueIntraFeature();
```

Return Value

Tolerance used for feature-locating

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeDistanceBetweenDimTol::GetNominalValueIntraFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[ISwDMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetOriginFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetOriginFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Gets the DimXpert feature of origin to which this DimXpert composite distance-between dimension tolerance is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOriginFeature( _  
    ByRef Feature As SwDMDimXpertFeature, _  
    ByRef FosUsage As swDmDimXpertDistanceFosUsage\_e _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeDistanceBetweenDimTol  
Dim Feature As SwDMDimXpertFeature  
Dim FosUsage As swDmDimXpertDistanceFosUsage\_e  
Dim value As System.Boolean
```

```
value = instance.GetOriginFeature(Feature, FosUsage)
```

C#

```
System.bool GetOriginFeature(  
    out SwDMDimXpertFeature Feature,  
    out swDmDimXpertDistanceFosUsage\_e FosUsage  
)
```

C++/CLI

```
System.bool GetOriginFeature(
& [Out] SwMDimXpertFeature^ Feature,
& [Out] swDmDimXpertDistanceFosUsage\_e FosUsage
)
```

Parameters

Feature

[ISwMDimXpertFeature](#)

FosUsage

How to treat the feature of size when applying this tolerance as defined in [swDmDimXpertDistanceFosUsage_e](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompositeDistanceBetweenDimTol::GetOriginFeature](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#)

[ISwMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPlusAndMinusToleranceIntraFeature Method (ISwMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetPlusAndMinusToleranceIntraFeature Method (ISwMDimXpertCompositeDistanceBetweenDimTol)

Gets the plus and minus tolerance values used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlusAndMinusToleranceIntraFeature( _
    ByRef Plus As System.Double, _
    ByRef Minus As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompositeDistanceBetweenDimTol
Dim Plus As System.Double
Dim Minus As System.Double
Dim value As System.Boolean
```

```
value = instance.GetPlusAndMinusToleranceIntraFeature(Plus, Minus)
```

C#

```
System.bool GetPlusAndMinusToleranceIntraFeature(
    out System.double Plus,
    out System.double Minus
)
```

C++/CLI

```
System.bool GetPlusAndMinusToleranceIntraFeature(
& [Out] System.double Plus,
& [Out] System.double Minus
)
```

Parameters

Plus

Plus tolerance value for feature-locating

Minus

Minus tolerance value for feature-locating

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeDistanceBetweenDimTol::GetPlusAndMinusToleranceIntraFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[ISwDMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetUpperAndLowerLimitIntraFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#) : GetUpperAndLowerLimitIntraFeature Method (ISwDMDimXpertCompositeDistanceBetweenDimTol)

Gets the upper and lower tolerance limits used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUpperAndLowerLimitIntraFeature( _
    ByRef Upper As System.Double, _
    ByRef Lower As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeDistanceBetweenDimTol
Dim Upper As System.Double
Dim Lower As System.Double
Dim value As System.Boolean
```

```
value = instance.GetUpperAndLowerLimitIntraFeature(Upper, Lower)
```

C#

```
System.bool GetUpperAndLowerLimitIntraFeature(
    out System.double Upper,
    out System.double Lower
)
```

C++/CLI

```
System.bool GetUpperAndLowerLimitIntraFeature(
& [Out] System.double Upper,
& [Out] System.double Lower
)
```

Parameters

Upper
Upper tolerance limit for feature-locating
Lower
Lower tolerance limit for feature-locating

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeDistanceBetweenDimTol::GetUpperAndLowerLimitIntraFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[ISwDMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

LimitsAndFitsCodeIntraFeature Property (ISwDMDimXpertCompositeDistanceBetweenDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#) : LimitsAndFitsCodeIntraFeature Property
(ISwDMDimXpertCompositeDistanceBetweenDimTol)

Gets the limits and fits code used by the feature-locating portion of this DimXpert composite distance-between dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LimitsAndFitsCodeIntraFeature As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeDistanceBetweenDimTol
Dim value As System.String

value = instance.LimitsAndFitsCodeIntraFeature
```

C#

```
System.string LimitsAndFitsCodeIntraFeature {get;}
```

C++/CLI

```
property System.String^ LimitsAndFitsCodeIntraFeature {
    System.String^ get();
}
```

Property Value

Limits and fits code for feature-locating

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeDistanceBetweenDimTol::LimitsAndFitsCodeIntraFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeDistanceBetweenDimTol Interface](#)
[ISwDMDimXpertCompositeDistanceBetweenDimTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0