

SOLIDWORKS Document Manager API (.NET) — Reference (7/19) ISwDMDimXpertCompositeLineProfileGeoTol- ISwDMDimXpertCompoundHoleFeature

SOLIDWORKS API Documentation (converted from CHM)

ISwDMDimXpertCompositeLineProfileGeoTol (Type)

ISwDMDimXpertCompositeLineProfileGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeLineProfileGeoTol Interface

Allows you to access DimXpert composite line profile geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCompositeLineProfileGeoTol
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeLineProfileGeoTol
```

C#

```
public interface ISwDMDimXpertCompositeLineProfileGeoTol
```

C++/CLI

```
public interface class ISwDMDimXpertCompositeLineProfileGeoTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeLineProfileGeoTol](#).

Example

[Get DimXpert Tolerance7 \(VB.NET\)](#)
[Get DimXpert Tolerance7 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCompositeLineProfileGeoTol Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeLineProfileGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertCompositeLineProfileGeoTol members](#).

Public Methods

Name	Description
 GetPlanarZoneVector	Gets the planar zone vector that is used to compute this DimXpert composite line profile geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompositeLineProfileGeoTol Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeLineProfileGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertCompositeLineProfileGeoTol](#).

Public Properties

Name	Description
 OuterToleranceValue	Gets the outer profile tolerance value for this DimXpert composite line profile geometric tolerance.
 OuterToleranceValueLowerTier	Gets the outer profile tolerance value in the lower tier for this DimXpert composite line profile geometric tolerance.
 PrimaryInLowerTier	Gets whether the primary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.
 SecondaryInLowerTier	Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.
 TertiaryInLowerTier	Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.
 ToleranceLowerTier	Gets the tolerance value in the lower tier for this DimXpert composite line profile geometric tolerance.

[Top](#)

Public Methods

Name	Description
 GetPlanarZoneVector	Gets the planar zone vector that is used to compute this DimXpert composite line profile geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompositeLineProfileGeoTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeLineProfileGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertCompositeLineProfileGeoTol members](#).

Public Properties

Name	Description
 OuterToleranceValue	Gets the outer profile tolerance value for this DimXpert composite line profile geometric tolerance.
 OuterToleranceValueLowerTier	Gets the outer profile tolerance value in the lower tier for this DimXpert composite line profile geometric tolerance.
 PrimaryInLowerTier	Gets whether the primary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.
 SecondaryInLowerTier	Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.
 TertiaryInLowerTier	Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.
 ToleranceLowerTier	Gets the tolerance value in the lower tier for this DimXpert composite line profile geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPlanarZoneVector Method (ISwDMDimXpertCompositeLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeLineProfileGeoTol Interface](#) : GetPlanarZoneVector Method (ISwDMDimXpertCompositeLineProfileGeoTol)

Gets the planar zone vector that is used to compute this DimXpert composite line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlanarZoneVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeLineProfileGeoTol  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetPlanarZoneVector(I, J, K)
```

C#

```
System.bool GetPlanarZoneVector(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetPlanarZoneVector(  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

I
i component of planar zone vector
J
j component of planar zone vector
K
k component of planar zone vector

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeLineProfileGeoTol::GetPlanarZoneVector](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Members](#)

Availability

OuterToleranceValue Property (ISwDMDimXpertCompositeLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeLineProfileGeoTol Interface](#) : OuterToleranceValue Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Gets the outer profile tolerance value for this DimXpert composite line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OuterToleranceValue As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeLineProfileGeoTol  
Dim value As System.Double  
  
value = instance.OuterToleranceValue
```

C#

```
System.double OuterToleranceValue {get;}
```

C++/CLI

```
property System.double OuterToleranceValue {  
    System.double get();  
}
```

Property Value

Outer profile tolerance value

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeLineProfileGeoTol.OuterToleranceValue](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

OuterToleranceValueLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeLineProfileGeoTol Interface](#) : OuterToleranceValueLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Gets the outer profile tolerance value in the lower tier for this DimXpert composite line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OuterToleranceValueLowerTier As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeLineProfileGeoTol
Dim value As System.Double

value = instance.OuterToleranceValueLowerTier
```

C#

```
System.double OuterToleranceValueLowerTier {get;}
```

C++/CLI

```
property System.double OuterToleranceValueLowerTier {
    System.double get();
}
```

Property Value

Outer profile tolerance value in the lower tier

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeLineProfileGeoTol::OuterToleranceValueLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

PrimaryInLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeLineProfileGeoTol Interface](#) : PrimaryInLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Gets whether the primary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PrimaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeLineProfileGeoTol
Dim value As System.Boolean

value = instance.PrimaryInLowerTier
```

C#

```
System.bool PrimaryInLowerTier {get;}
```

C++/CLI

```
property System.bool PrimaryInLowerTier {
    System.bool get();
}
```

Property Value

True, if the primary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeLineProfileGeoTol::PrimaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SecondaryInLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeLineProfileGeoTol Interface](#) : SecondaryInLowerTier Property (ISwDMDimXpertCompositeLineProfileGeoTol)

Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SecondaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeLineProfileGeoTol  
Dim value As System.Boolean
```

```
value = instance.SecondaryInLowerTier
```

C#

```
System.bool SecondaryInLowerTier {get;}
```

C++/CLI

```
property System.bool SecondaryInLowerTier {  
    System.bool get();  
}
```

Property Value

True, if the secondary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeLineProfileGeoTol::SecondaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

TertiaryInLowerTier Property (ISwMDimXpertCompositeLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompositeLineProfileGeoTol Interface](#) : TertiaryInLowerTier Property (ISwMDimXpertCompositeLineProfileGeoTol)

Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TertiaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompositeLineProfileGeoTol  
Dim value As System.Boolean
```

```
value = instance.TertiaryInLowerTier
```

C#

```
System.bool TertiaryInLowerTier {get;}
```

C++/CLI

```
property System.bool TertiaryInLowerTier {  
    System.bool get();  
}
```

Property Value

True, if the tertiary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompositeLineProfileGeoTol::TertiaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwMDimXpertCompositeLineProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ToleranceLowerTier Property (ISwMDimXpertCompositeLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompositeLineProfileGeoTol Interface](#) : ToleranceLowerTier Property (ISwMDimXpertCompositeLineProfileGeoTol)

Gets the tolerance value in the lower tier for this DimXpert composite line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ToleranceLowerTier As System.Double

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeLineProfileGeoTol  
Dim value As System.Double
```

```
value = instance.ToleranceLowerTier
```

C#

```
System.double ToleranceLowerTier {get;}
```

C++/CLI

```
property System.double ToleranceLowerTier {  
    System.double get();  
}
```

Property Value

Tolerance value in the lower tier

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeLineProfileGeoTol.ToleranceLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCompositePositionGeoTol (Type)

ISwDMDimXpertCompositePositionGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositePositionGeoTol Interface

Allows you to access DimXpert composite position geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCompositePositionGeoTol
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol
```

C#

```
public interface ISwDMDimXpertCompositePositionGeoTol
```

C++/CLI

```
public interface class ISwDMDimXpertCompositePositionGeoTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol](#).

Example

[Get DimXpert Tolerance3 \(VB.NET\)](#)
[Get DimXpert Tolerance3 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertCompositePositionGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCompositePositionGeoTol Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositePositionGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertCompositePositionGeoTol members](#).

Public Methods

Name	Description
 GetMaxTolerance	Gets the maximum tolerance for this DimXpert composite position geometric tolerance.
 GetMaxToleranceLowerTier	Gets whether the maximum tolerance is set in the lower tier for this DimXpert composite position geometric tolerance.
GetPlanarZoneVector	Gets the planar zone vector that is used for computing this DimXpert composite position geometric tolerance.



[GetProjectedZone](#)

Gets the projected zone value of this DimXpert composite position geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompositePositionGeoTol Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositePositionGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertCompositePositionGeoTol](#).

Public Properties

Name	Description
 Modifier	Gets the material condition modifier for this DimXpert composite position geometric tolerance.
 ModifierLowerTier	Gets the material condition modifier for the tolerance in the lower tier for this DimXpert composite position geometric tolerance.
 PrimaryInLowerTier	Gets whether the primary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.
 SecondaryInLowerTier	Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.
 TertiaryInLowerTier	Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.
 ToleranceLowerTier	Gets the tolerance value in the lower tier for this DimXpert composite position geometric tolerance.
 ZoneType	Gets the zone type of this DimXpert composite position geometric tolerance.

[Top](#)

Public Methods

Name	Description
 GetMaxTolerance	Gets the maximum tolerance for this DimXpert composite position geometric tolerance.
 GetMaxToleranceLowerTier	Gets whether the maximum tolerance is set in the lower tier for this DimXpert composite position geometric tolerance.
 GetPlanarZoneVector	Gets the planar zone vector that is used for computing this DimXpert composite position geometric tolerance.
 GetProjectedZone	Gets the projected zone value of this DimXpert composite position geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompositePositionGeoTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositePositionGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertCompositePositionGeoTol members](#).

Public Properties

Name	Description
 Modifier	Gets the material condition modifier for this DimXpert composite position geometric tolerance.
 ModifierLowerTier	Gets the material condition modifier for the tolerance in the lower tier for this DimXpert composite position geometric tolerance.
 PrimaryInLowerTier	Gets whether the primary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.
 SecondaryInLowerTier	Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.

 TertiaryInLowerTier	Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.
 ToleranceLowerTier	Gets the tolerance value in the lower tier for this DimXpert composite position geometric tolerance.
 ZoneType	Gets the zone type of this DimXpert composite position geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetMaxTolerance Method (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : GetMaxTolerance Method (ISwDMDimXpertCompositePositionGeoTol)

Gets the maximum tolerance for this DimXpert composite position geometric tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetMaxTolerance( _
    ByRef IsMax As System.Boolean, _
    ByRef Tolerance As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol
Dim IsMax As System.Boolean
Dim Tolerance As System.Double
Dim value As System.Boolean

value = instance.GetMaxTolerance(IsMax, Tolerance)
```

C#

```
System.bool GetMaxTolerance(
    out System.bool IsMax,
    out System.double Tolerance
)
```

C++/CLI

```
System.bool GetMaxTolerance(
    & [Out] System.bool IsMax,
    & [Out] System.double Tolerance
)
```

Parameters

IsMax
True, if maximum tolerance is set; false, otherwise
Tolerance
Maximum tolerance

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::GetMaxTolerance](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetMaxToleranceLowerTier Method (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : GetMaxToleranceLowerTier Method (ISwDMDimXpertCompositePositionGeoTol)

Gets whether the maximum tolerance is set in the lower tier for this DimXpert composite position geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMaxToleranceLowerTier( _  
    ByRef IsMax As System.Boolean, _  
    ByRef Tolerance As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol  
Dim IsMax As System.Boolean  
Dim Tolerance As System.Double  
Dim value As System.Boolean  
  
value = instance.GetMaxToleranceLowerTier(IsMax, Tolerance)
```

C#

```
System.bool GetMaxToleranceLowerTier(  
    out System.bool IsMax,  
    out System.double Tolerance  
)
```

C++/CLI

```
System.bool GetMaxToleranceLowerTier(  
& [Out] System.bool IsMax,  
& [Out] System.double Tolerance  
)
```

Parameters

IsMax

True, if maximum tolerance is set in the lower tier; false, otherwise

Tolerance

Maximum tolerance in the lower tier

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::GetMaxToleranceLowerTier](#).

Example

See the examples on the interface page.

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPlanarZoneVector Method (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : GetPlanarZoneVector Method (ISwDMDimXpertCompositePositionGeoTol)

Gets the planar zone vector that is used for computing this DimXpert composite position geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlanarZoneVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetPlanarZoneVector(I, J, K)
```

C#

```
System.bool GetPlanarZoneVector(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetPlanarZoneVector(  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

I
i component of the planar zone vector
J
j component of the planar zone vector
K
k component of the planar zone vector

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::GetPlanarZoneVector](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetProjectedZone Method (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : GetProjectedZone Method (ISwDMDimXpertCompositePositionGeoTol)

Gets the projected zone value of this DimXpert composite position geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProjectedZone( _  
    ByRef Enabled As System.Boolean, _  
    ByRef Value As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol  
Dim Enabled As System.Boolean  
Dim Value As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetProjectedZone(Enabled, Value)
```

C#

```
System.bool GetProjectedZone(  
    out System.bool Enabled,  
    out System.double Value  
)
```

C++/CLI

```
System.bool GetProjectedZone(  
& [Out] System.bool Enabled,  
& [Out] System.double Value  
)
```

Parameters

Enabled

True, if the projected zone is in effect; false, otherwise

Value

Composite position projected zone value

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::GetProjectedZone](#).

Example

See the examples on the interface page.

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Modifier Property (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : Modifier Property (ISwDMDimXpertCompositePositionGeoTol)

Gets the material condition modifier for this DimXpert composite position geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Modifier As [swDmDimXpertMaterialConditionModifier_e](#)

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol  
Dim value As swDmDimXpertMaterialConditionModifier\_e
```

```
value = instance.Modifier
```

C#

```
swDmDimXpertMaterialConditionModifier\_e Modifier {get;}
```

C++/CLI

```
property swDmDimXpertMaterialConditionModifier\_e Modifier {  
    swDmDimXpertMaterialConditionModifier\_e get();  
}
```

Property Value

Material condition modifier for the composite position tolerance as defined in [swDmDimXpertMaterialConditionModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::Modifier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ModifierLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : ModifierLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Gets the material condition modifier for the tolerance in the lower tier for this DimXpert composite position geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ModifierLowerTier As swDmDimXpertMaterialConditionModifier\_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol  
Dim value As swDmDimXpertMaterialConditionModifier\_e  
  
value = instance.ModifierLowerTier
```

C#

```
swDmDimXpertMaterialConditionModifier\_e ModifierLowerTier {get;}
```

C++/CLI

```
property swDmDimXpertMaterialConditionModifier\_e ModifierLowerTier {  
    swDmDimXpertMaterialConditionModifier\_e get();  
}
```

Property Value

Material condition modifier in the lower tier as defined in [swDmDimXpertMaterialConditionModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::ModifierLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

PrimaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : PrimaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Gets whether the primary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PrimaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol  
Dim value As System.Boolean  
  
value = instance.PrimaryInLowerTier
```

C#

```
System.bool PrimaryInLowerTier {get;}
```

C++/CLI

```
property System.bool PrimaryInLowerTier {
    System.bool get();
}
```

Property Value

True, if the primary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::PrimaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SecondaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : SecondaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Gets whether the secondary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SecondaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol
Dim value As System.Boolean

value = instance.SecondaryInLowerTier
```

C#

```
System.bool SecondaryInLowerTier {get;}
```

C++/CLI

```
property System.bool SecondaryInLowerTier {
    System.bool get();
}
```

Property Value

True, if the secondary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::SecondaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

TertiaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : TertiaryInLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Gets whether the tertiary datum is repeated in the lower tier of this DimXpert composite position geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TertiaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol  
Dim value As System.Boolean
```

```
value = instance.TertiaryInLowerTier
```

C#

```
System.bool TertiaryInLowerTier {get;}
```

C++/CLI

```
property System.bool TertiaryInLowerTier {  
    System.bool get();  
}
```

Property Value

True, if the tertiary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::TertiaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ToleranceLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : ToleranceLowerTier Property (ISwDMDimXpertCompositePositionGeoTol)

Gets the tolerance value in the lower tier for this DimXpert composite position geometric tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property ToleranceLowerTier As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol
Dim value As System.Double

value = instance.ToleranceLowerTier
```

C#

```
System.double ToleranceLowerTier {get;}
```

C++/CLI

```
property System.double ToleranceLowerTier {
    System.double get();
}
```

Property Value

Tolerance in the lower tier

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::ToleranceLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ZoneType Property (ISwDMDimXpertCompositePositionGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositePositionGeoTol Interface](#) : ZoneType Property (ISwDMDimXpertCompositePositionGeoTol)

Gets the zone type of this DimXpert composite position geometric tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property ZoneType As swDmDimXpertPositionZoneType_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositePositionGeoTol
Dim value As swDmDimXpertPositionZoneType_e

value = instance.ZoneType
```

C#

```
swDmDimXpertPositionZoneType\_e ZoneType {get;}
```

C++/CLI

```
property swDmDimXpertPositionZoneType\_e ZoneType {  
    swDmDimXpertPositionZoneType\_e get();  
}
```

Property Value

Type of zone for the position as defined in [swDmDimXpertPositionZoneType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositePositionGeoTol::ZoneType](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCompositeSurfaceProfileGeoTol (Type)

ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface

Allows you to access DimXpert composite surface profile geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCompositeSurfaceProfileGeoTol
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeSurfaceProfileGeoTol
```

C#

```
public interface ISwDMDimXpertCompositeSurfaceProfileGeoTol
```

C++/CLI

```
public interface class ISwDMDimXpertCompositeSurfaceProfileGeoTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeSurfaceProfileGeoTol](#).

Example

[Get DimXpert Tolerance6 \(VB.NET\)](#)
[Get DimXpert Tolerance6 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertCompositeSurfaceProfileGeoTol](#).

Public Properties

Name	Description
OuterToleranceValue	Gets the outer tolerance value for this DimXpert composite surface profile geometric tolerance.
OuterToleranceValueLowerTier	Gets the outer tolerance value in the lower tier for this DimXpert composite surface profile geometric tolerance.
PrimaryInLowerTier	Gets whether the primary datum is repeated in the lower tier of this DimXpert composite surface profile geometric tolerance.

[SecondaryInLowerTier](#)

Gets whether the secondary datum is repeated in the lower tier for this DimXpert composite surface profile geometric tolerance.

[TertiaryInLowerTier](#)

Gets whether the tertiary datum is repeated in the lower tier for this DimXpert composite surface profile geometric tolerance.

[ToleranceLowerTier](#)

Gets the tolerance value in the lower tier for this DimXpert composite surface profile geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface Properties

[See Also](#)[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompositeSurfaceProfileGeoTol InterfaceFor a list of all members of this type, see [ISwDMDimXpertCompositeSurfaceProfileGeoTol members](#).

Public Properties

Name	Description
 OuterToleranceValue	Gets the outer tolerance value for this DimXpert composite surface profile geometric tolerance.
 OuterToleranceValueLowerTier	Gets the outer tolerance value in the lower tier for this DimXpert composite surface profile geometric tolerance.
 PrimaryInLowerTier	Gets whether the primary datum is repeated in the lower tier of this DimXpert composite surface profile geometric tolerance.
 SecondaryInLowerTier	Gets whether the secondary datum is repeated in the lower tier for this DimXpert composite surface profile geometric tolerance.
 TertiaryInLowerTier	Gets whether the tertiary datum is repeated in the lower tier for this DimXpert composite surface profile geometric tolerance.
 ToleranceLowerTier	Gets the tolerance value in the lower tier for this DimXpert composite surface profile geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

OuterToleranceValue Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

[See Also](#)[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#) : OuterToleranceValue Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Gets the outer tolerance value for this DimXpert composite surface profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property OuterToleranceValue As System.Double

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeSurfaceProfileGeoTol
Dim value As System.Double
```

```
value = instance.OuterToleranceValue
```

C#

```
System.double OuterToleranceValue {get;}
```

C++/CLI

```
property System.double OuterToleranceValue {
    System.double get();
```

}

Property Value

Outer profile tolerance value

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeSurfaceProfileGeoTol.OuterToleranceValue](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

OuterToleranceValueLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#) : OuterToleranceValueLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Gets the outer tolerance value in the lower tier for this DimXpert composite surface profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OuterToleranceValueLowerTier As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeSurfaceProfileGeoTol  
Dim value As System.Double  
  
value = instance.OuterToleranceValueLowerTier
```

C#

```
System.double OuterToleranceValueLowerTier {get;}
```

C++/CLI

```
property System.double OuterToleranceValueLowerTier {  
    System.double get();  
}
```

Property Value

Outer profile tolerance value in the lower tier

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeSurfaceProfileGeoTol.OuterToleranceValueLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

PrimaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#) : PrimaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Gets whether the primary datum is repeated in the lower tier of this DimXpert composite surface profile geometric tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property PrimaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeSurfaceProfileGeoTol  
Dim value As System.Boolean
```

```
value = instance.PrimaryInLowerTier
```

C#

```
System.bool PrimaryInLowerTier {get;}
```

C++/CLI

```
property System.bool PrimaryInLowerTier {  
    System.bool get();  
}
```

Property Value

True, if the primary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeSurfaceProfileGeoTol::PrimaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SecondaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#) : SecondaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Gets whether the secondary datum is repeated in the lower tier for this DimXpert composite surface profile geometric tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property SecondaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeSurfaceProfileGeoTol
Dim value As System.Boolean

value = instance.SecondaryInLowerTier
```

C#

```
System.bool SecondaryInLowerTier {get;}
```

C++/CLI

```
property System.bool SecondaryInLowerTier {
    System.bool get();
}
```

Property Value

True, if the secondary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeSurfaceProfileGeoTol::SecondaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

TertiaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#) : TertiaryInLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Gets whether the tertiary datum is repeated in the lower tier for this DimXpert composite surface profile geometric tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property TertiaryInLowerTier As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeSurfaceProfileGeoTol
Dim value As System.Boolean

value = instance.TertiaryInLowerTier
```

C#

```
System.bool TertiaryInLowerTier {get;}
```

C++/CLI

```
property System.bool TertiaryInLowerTier {  
    System.bool get();  
}
```

Property Value

True, if the tertiary datum is repeated in the lower tier; false, otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeSurfaceProfileGeoTol::TertiaryInLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ToleranceLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#) : ToleranceLowerTier Property (ISwDMDimXpertCompositeSurfaceProfileGeoTol)

Gets the tolerance value in the lower tier for this DimXpert composite surface profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ToleranceLowerTier As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompositeSurfaceProfileGeoTol  
Dim value As System.Double  
  
value = instance.ToleranceLowerTier
```

C#

```
System.double ToleranceLowerTier {get;}
```

C++/CLI

```
property System.double ToleranceLowerTier {  
    System.double get();  
}
```

Property Value

Tolerance in the lower tier

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompositeSurfaceProfileGeoTol::ToleranceLowerTier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCompoundClosedSlot3dFeature (Type)

ISwDMDimXpertCompoundClosedSlot3dFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundClosedSlot3dFeature Interface

Allows you to access specific information about DimXpert 3D compound closed slots.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCompoundClosedSlot3dFeature
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundClosedSlot3dFeature
```

C#

```
public interface ISwDMDimXpertCompoundClosedSlot3dFeature
```

C++/CLI

```
public interface class ISwDMDimXpertCompoundClosedSlot3dFeature
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundClosedSlot3dFeature](#).

Example

[Get DimXpert Feature \(VB.NET\)](#)
[Get DimXpert Feature \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertCompoundClosedSlot3dFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCompoundClosedSlot3dFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundClosedSlot3dFeature Interface

The following tables list the members exposed by [ISwDMDimXpertCompoundClosedSlot3dFeature](#).

Public Properties

Name	Description
Blind	Gets whether this DimXpert compound closed slot is blind or through all.

[Top](#)

Public Methods

Name	Description
 GetBottomFeature	Gets DimXpert feature at the bottom of this DimXpert compound closed slot.
 GetEndFeatures	Gets the DimXpert features at both closed ends of this DimXpert compound closed slot.
 GetNominalBottomPlane	Gets the coordinates and vector for the reference plane at the bottom of this DimXpert compound closed slot.
 GetNominalClosedSlot	Gets various attributes for this DimXpert compound closed slot.
 GetNominalTopPlane	Gets the coordinates and vector for the reference plane at the top of this DimXpert compound closed slot.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound closed slot.

[Top](#)

See Also

[ISwMDimXpertCompoundClosedSlot3dFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwMDimXpertCompoundClosedSlot3dFeature Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDimXpertCompoundClosedSlot3dFeature Interface

For a list of all members of this type, see [ISwMDimXpertCompoundClosedSlot3dFeature members](#).

Public Methods

Name	Description
 GetBottomFeature	Gets DimXpert feature at the bottom of this DimXpert compound closed slot.
 GetEndFeatures	Gets the DimXpert features at both closed ends of this DimXpert compound closed slot.
 GetNominalBottomPlane	Gets the coordinates and vector for the reference plane at the bottom of this DimXpert compound closed slot.
 GetNominalClosedSlot	Gets various attributes for this DimXpert compound closed slot.
 GetNominalTopPlane	Gets the coordinates and vector for the reference plane at the top of this DimXpert compound closed slot.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound closed slot.

[Top](#)

See Also

[ISwMDimXpertCompoundClosedSlot3dFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwMDimXpertCompoundClosedSlot3dFeature Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDimXpertCompoundClosedSlot3dFeature Interface

For a list of all members of this type, see [ISwMDimXpertCompoundClosedSlot3dFeature members](#).

Public Properties

Name	Description
 Blind	Gets whether this DimXpert compound closed slot is blind or through all.

[Top](#)

See Also

[ISwMDimXpertCompoundClosedSlot3dFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Blind Property (ISwMDimXpertCompoundClosedSlot3dFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompoundClosedSlot3dFeature Interface](#) : Blind Property (ISwMDimXpertCompoundClosedSlot3dFeature)

Gets whether this DimXpert compound closed slot is blind or through all.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Blind As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompoundClosedSlot3dFeature  
Dim value As System.Boolean
```

```
value = instance.Blind
```

C#

```
System.bool Blind {get;}
```

C++/CLI

```
property System.bool Blind {  
    System.bool get();  
}
```

Property Value

True if the closed slot is blind; false if through all

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompoundClosedSlot3dFeature::Blind](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompoundClosedSlot3dFeature Interface](#)
[ISwMDimXpertCompoundClosedSlot3dFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetBottomFeature Method (ISwMDimXpertCompoundClosedSlot3dFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompoundClosedSlot3dFeature Interface](#) : GetBottomFeature Method (ISwMDimXpertCompoundClosedSlot3dFeature)

Gets DimXpert feature at the bottom of this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

Function GetBottomFeature() As SwMDimXpertFeature

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundClosedSlot3dFeature  
Dim value As SwDMDimXpertFeature  
  
value = instance.GetBottomFeature()
```

C#

```
SwDMDimXpertFeature GetBottomFeature()
```

C++/CLI

```
SwDMDimXpertFeature^ GetBottomFeature();
```

Return Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundClosedSlot3dFeature::GetBottomFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundClosedSlot3dFeature Interface](#)
[ISwDMDimXpertCompoundClosedSlot3dFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetEndFeatures Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundClosedSlot3dFeature Interface](#) : GetEndFeatures Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

Gets the DimXpert features at both closed ends of this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndFeatures( _  
    ByRef End1 As SwDMDimXpertFeature, _  
    ByRef End2 As SwDMDimXpertFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundClosedSlot3dFeature  
Dim End1 As SwDMDimXpertFeature  
Dim End2 As SwDMDimXpertFeature  
Dim value As System.Boolean  
  
value = instance.GetEndFeatures(End1, End2)
```

C#

```
System.bool GetEndFeatures(  
    out SwDMDimXpertFeature End1,  
    out SwDMDimXpertFeature End2  
)
```

```
System.bool GetEndFeatures(
& [Out] SwMDimXpertFeature^ End1,
& [Out] SwMDimXpertFeature^ End2
)
```

Parameters

End1

[ISwMDimXpertFeature](#)

End2

[ISwMDimXpertFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompoundClosedSlot3dFeature::GetEndFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompoundClosedSlot3dFeature Interface](#)
[ISwMDimXpertCompoundClosedSlot3dFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalBottomPlane Method (ISwMDimXpertCompoundClosedSlot3dFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompoundClosedSlot3dFeature Interface](#) : GetNominalBottomPlane Method (ISwMDimXpertCompoundClosedSlot3dFeature)

Gets the coordinates and vector for the reference plane at the bottom of this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalBottomPlane( _
    ByRef X As System.Double, _
    ByRef Y As System.Double, _
    ByRef Z As System.Double, _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompoundClosedSlot3dFeature
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean
```

```
value = instance.GetNominalBottomPlane(X, Y, Z, I, J, K)
```

C#

```

System.bool GetNominalBottomPlane(
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetNominalBottomPlane(
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)

```

Parameters

X
x coordinate of the bottom plane

Y
y coordinate of the bottom plane

Z
z coordinate of the bottom plane

I
i component of the direction vector of the bottom plane

J
j component of the direction vector of the bottom plane

K
k component of the direction vector of the bottom plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [ISwMDimXpertCompoundClosedSlot3dFeature::GetNominalBottomPlane](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompoundClosedSlot3dFeature Interface](#)
[ISwMDimXpertCompoundClosedSlot3dFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalClosedSlot Method (ISwMDimXpertCompoundClosedSlot3dFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompoundClosedSlot3dFeature Interface](#) : GetNominalClosedSlot Method (ISwMDimXpertCompoundClosedSlot3dFeature)

Gets various attributes for this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```

Function GetNominalClosedSlot( _
    ByRef width As System.Double, _
    ByRef Length As System.Double, _
    ByRef X As System.Double, _

```

```

ByRef Y As System.Double, _
ByRef Z As System.Double, _
ByRef I As System.Double, _
ByRef J As System.Double, _
ByRef K As System.Double, _
ByRef LongitudeI As System.Double, _
ByRef LongitudeJ As System.Double, _
ByRef LongitudeK As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As ISwDMDimXpertCompoundClosedSlot3dFeature
Dim width As System.Double
Dim Length As System.Double
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim LongitudeI As System.Double
Dim LongitudeJ As System.Double
Dim LongitudeK As System.Double
Dim value As System.Boolean

```

```

value = instance.GetNominalClosedSlot(width, Length, X, Y, Z, I, J, K, LongitudeI, LongitudeJ, LongitudeK)

```

C#

```

System.bool GetNominalClosedSlot(
    out System.double width,
    out System.double Length,
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K,
    out System.double LongitudeI,
    out System.double LongitudeJ,
    out System.double LongitudeK
)

```

C++/CLI

```

System.bool GetNominalClosedSlot(
    & [Out] System.double width,
    & [Out] System.double Length,
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K,
    & [Out] System.double LongitudeI,
    & [Out] System.double LongitudeJ,
    & [Out] System.double LongitudeK
)

```

Parameters

width

Width of the compound closed slot

Length

Length of the compound closed slot

X

x coordinate of the compound closed slot

Y

y coordinate of the compound closed slot

Z

z coordinate of the compound closed slot

I

i component of the direction vector of the compound closed slot
j component of the direction vector of the compound closed slot
K component of the direction vector of the compound closed slot
k component of the direction vector of the compound closed slot
LongitudeI
i component of the longitudinal unit vector of the closed slot
LongitudeJ
j component of the longitudinal unit vector of the closed slot
LongitudeK
k component of the longitudinal unit vector of the closed slot

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundClosedSlot3dFeature::GetNominalClosedSlot](#).

Example

See the examples on the interface page.

Remarks

The i, j, and k components of the longitudinal vector indicate the direction of a feature's length with respect to its part axes. For example, if the length of a feature goes along the y-axis of the part, its longitudinal vector is (0, 1, 0).

See Also

[ISwDMDimXpertCompoundClosedSlot3dFeature Interface](#)
[ISwDMDimXpertCompoundClosedSlot3dFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetNominalTopPlane Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundClosedSlot3dFeature Interface](#) : GetNominalTopPlane Method (ISwDMDimXpertCompoundClosedSlot3dFeature)

Gets the coordinates and vector for the reference plane at the top of this DimXpert compound closed slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalTopPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As ISwDMDimXpertCompoundClosedSlot3dFeature
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

```

```

value = instance.GetNominalTopPlane(X, Y, Z, I, J, K)

```

C#

```

System.bool GetNominalTopPlane(
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetNominalTopPlane(
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)

```

Parameters

X
x component of the top reference plane
Y
y component of the top reference plane
Z
z component of the top reference plane
I
i component of the direction vector of the top reference plane
J
j component of the direction vector of the top reference plane
K
k component of the direction vector of the top reference plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundClosedSlot3dFeature::GetNominalTopPlane](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundClosedSlot3dFeature Interface](#)
[ISwDMDimXpertCompoundClosedSlot3dFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompoundClosedSlot3dFeature Interface](#) : GetPlaneFeatures Method (ISwMDimXpertCompoundClosedSlot3dFeature)

Gets the DimXpert plane features for both sides of this DimXpert compound closed slot.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeatures( _  
    ByRef Plane1 As SwMDimXpertPlaneFeature, _  
    ByRef Plane2 As SwMDimXpertPlaneFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompoundClosedSlot3dFeature  
Dim Plane1 As SwMDimXpertPlaneFeature  
Dim Plane2 As SwMDimXpertPlaneFeature  
Dim value As System.Boolean  
  
value = instance.GetPlaneFeatures(Plane1, Plane2)
```

C#

```
System.bool GetPlaneFeatures(  
    out SwMDimXpertPlaneFeature Plane1,  
    out SwMDimXpertPlaneFeature Plane2  
)
```

C++/CLI

```
System.bool GetPlaneFeatures(  
& [Out] SwMDimXpertPlaneFeature^ Plane1,  
& [Out] SwMDimXpertPlaneFeature^ Plane2  
)
```

Parameters

Plane1
[ISwMDimXpertPlaneFeature](#)
Plane2
[ISwMDimXpertPlaneFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompoundClosedSlot3dFeature::GetPlaneFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompoundClosedSlot3dFeature Interface](#)
[ISwMDimXpertCompoundClosedSlot3dFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCompoundHoleFeature (Type)

ISwDMDimXpertCompoundHoleFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertCompoundHoleFeature Interface

Allows you to access specific information about DimXpert compound holes.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertCompoundHoleFeature

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertCompoundHoleFeature](#)

C#

public interface ISwDMDimXpertCompoundHoleFeature

C++/CLI

public interface class ISwDMDimXpertCompoundHoleFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundHoleFeature](#).

Example

[Get More DimXpert Feature Examples \(VB.NET\)](#)
[Get More DimXpert Feature Examples \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertCompoundHoleFeature Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)

ISwDMDimXpertCompoundHoleFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertCompoundHoleFeature Interface

For a list of all members of this type, see [ISwDMDimXpertCompoundHoleFeature members](#).

Public Methods

Name	Description
 GetBottomFeature	Gets the DimXpert feature at the bottom of this DimXpert compound hole.
 GetReferenceFeature	Gets the reference DimXpert feature for this DimXpert compound hole.
GetSubFeatureCount	Gets the number of sub-features in this DimXpert compound hole.

		
	GetSubFeatures	Gets all of the sub-features of this DimXpert compound hole.
	IGetSubFeatures	Gets all of the sub-features of this DimXpert compound hole.

[Top](#)

See Also

[ISwDMDimXpertCompoundHoleFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompoundHoleFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundHoleFeature Interface

The following tables list the members exposed by [ISwDMDimXpertCompoundHoleFeature](#).

Public Properties

Name	Description
 Blind	Gets whether this DimXpert compound hole is blind or through all.

[Top](#)

Public Methods

Name	Description
 GetBottomFeature	Gets the DimXpert feature at the bottom of this DimXpert compound hole.
 GetReferenceFeature	Gets the reference DimXpert feature for this DimXpert compound hole.
 GetSubFeatureCount	Gets the number of sub-features in this DimXpert compound hole.
 GetSubFeatures	Gets all of the sub-features of this DimXpert compound hole.
 IGetSubFeatures	Gets all of the sub-features of this DimXpert compound hole.

[Top](#)

See Also

[ISwDMDimXpertCompoundHoleFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompoundHoleFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundHoleFeature Interface

For a list of all members of this type, see [ISwDMDimXpertCompoundHoleFeature members](#).

Public Properties

Name	Description
 Blind	Gets whether this DimXpert compound hole is blind or through all.

[Top](#)

See Also

[ISwDMDimXpertCompoundHoleFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Blind Property (ISwDMDimXpertCompoundHoleFeature)

[See Also](#)



Gets whether this DimXpert compound hole is blind or through all.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Blind As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompoundHoleFeature  
Dim value As System.Boolean  
  
value = instance.Blind
```

C#

```
System.bool Blind {get;}
```

C++/CLI

```
property System.bool Blind {  
    System.bool get();  
}
```

Property Value

True if the compound hole is blind; false if through all

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompoundHoleFeature::Blind](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompoundHoleFeature Interface](#)
[ISwMDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetBottomFeature Method (ISwMDimXpertCompoundHoleFeature)

[See Also](#)



SolidWorks.Interop.swdocumentmgr Namespace > [ISwMDimXpertCompoundHoleFeature Interface](#) : GetBottomFeature Method (ISwMDimXpertCompoundHoleFeature)

Gets the DimXpert feature at the bottom of this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

Function GetBottomFeature() As SwMDimXpertFeature

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompoundHoleFeature  
Dim value As SwMDimXpertFeature  
  
value = instance.GetBottomFeature()
```

C#

```
SwDMDimXpertFeature GetBottomFeature()
```

C++/CLI

```
SwDMDimXpertFeature^ GetBottomFeature();
```

Return Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundHoleFeature::GetBottomFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundHoleFeature Interface](#)
[ISwDMDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetReferenceFeature Method (ISwDMDimXpertCompoundHoleFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundHoleFeature Interface](#) : GetReferenceFeature Method (ISwDMDimXpertCompoundHoleFeature)

Gets the reference DimXpert feature for this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferenceFeature() As SwDMDimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundHoleFeature  
Dim value As SwDMDimXpertFeature  
  
value = instance.GetReferenceFeature()
```

C#

```
SwDMDimXpertFeature GetReferenceFeature()
```

C++/CLI

```
SwDMDimXpertFeature^ GetReferenceFeature();
```

Return Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundHoleFeature::GetReferenceFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundHoleFeature Interface](#)
[ISwDMDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetSubFeatureCount Method (ISwDMDimXpertCompoundHoleFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundHoleFeature Interface](#) : GetSubFeatureCount Method (ISwDMDimXpertCompoundHoleFeature)

Gets the number of sub-features in this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSubFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundHoleFeature  
Dim value As System.Integer
```

```
value = instance.GetSubFeatureCount()
```

C#

```
System.int GetSubFeatureCount()
```

C++/CLI

```
System.int GetSubFeatureCount();
```

Return Value

Number of sub-features in the compound hole

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundHoleFeature::GetSubFeatureCount](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundHoleFeature Interface](#)
[ISwDMDimXpertCompoundHoleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetSubFeatures Method (ISwDMDimXpertCompoundHoleFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundHoleFeature Interface](#) : GetSubFeatures Method (ISwDMDimXpertCompoundHoleFeature)

Gets all of the sub-features of this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSubFeatures() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundHoleFeature  
Dim value As System.Object  
  
value = instance.GetSubFeatures()
```

C#

```
System.object GetSubFeatures()
```

C++/CLI

```
System.Object^ GetSubFeatures();
```

Return Value

Array of [ISwDMDimXpertFeatures](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundHoleFeature::GetSubFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundHoleFeature Interface](#)
[ISwDMDimXpertCompoundHoleFeature Members](#)
[ISwDMDimXpertCompoundHoleFeature::IGetSubFeatures Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

IGetSubFeatures Method (ISwDMDimXpertCompoundHoleFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundHoleFeature Interface](#) : IGetSubFeatures Method (ISwDMDimXpertCompoundHoleFeature)

Gets all of the sub-features of this DimXpert compound hole.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSubFeatures(  
    ByVal Count As System.Integer  
) As SwDMDimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundHoleFeature  
Dim Count As System.Integer  
Dim value As SwDMDimXpertFeature  
  
value = instance.IGetSubFeatures(Count)
```

C#

```
SwDMDimXpertFeature IGetSubFeatures(  
    System.int Count  
)
```

C++/CLI

```
SwDMDimXpertFeature^ IGetSubFeatures(  
& System.int Count  
)
```

Parameters

Count

Number of sub-features in this compound hole

Return Value

- in-process, unmanaged C++: Pointer to an array of [SwDMDimXpertFeatures](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwDMDimXpertCompoundHoleFeature::GetSubFeatureCount](#) to populate the Count argument.

See Also

[ISwDMDimXpertCompoundHoleFeature Interface](#)

[ISwDMDimXpertCompoundHoleFeature Members](#)

[ISwDMDimXpertCompoundHoleFeature::GetSubFeatures Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0