

SOLIDWORKS Document Manager API (.NET) — Reference (8/19)

ISwDMDimXpertCompoundNotchFeature- ISwDMDimXpertDatum

SOLIDWORKS API Documentation (converted from CHM)

ISwDMDimXpertCompoundNotchFeature (Type)

ISwDMDimXpertCompoundNotchFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundNotchFeature Interface

Allows you to access specific information about DimXpert compound notches.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertCompoundNotchFeature

Visual Basic (Usage)

Dim instance As [ISwDMDimXpertCompoundNotchFeature](#)

C#

public interface ISwDMDimXpertCompoundNotchFeature

C++/CLI

public interface class ISwDMDimXpertCompoundNotchFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundNotchFeature](#).

Example

[Get More DimXpert Feature Examples \(VB.NET\)](#)
[Get More DimXpert Feature Examples \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertCompoundNotchFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCompoundNotchFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundNotchFeature Interface

The following tables list the members exposed by [ISwDMDimXpertCompoundNotchFeature](#).

Public Properties

Name	Description
 Blind	Gets whether this DimXpert compound notch is blind or through all.

[Top](#)

Public Methods

Name	Description
 GetBottomFeature	Gets the DimXpert feature at the bottom of this DimXpert compound notch.
 GetEndFeature	Gets the DimXpert feature at the closed end of this DimXpert compound notch.
 GetNominalBottomPlane	Gets the coordinates and vector for the plane at the bottom of this DimXpert compound notch.
 GetNominalNotch	Gets various attributes for this DimXpert compound notch.
 GetOpenSideReferenceFeature	Gets the DimXpert reference feature on the open side of this DimXpert compound notch.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound notch.
 GetTopReferenceFeature	Gets the DimXpert reference feature at the top of this DimXpert compound notch.

[Top](#)

See Also

[ISwDMDimXpertCompoundNotchFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompoundNotchFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundNotchFeature Interface

For a list of all members of this type, see [ISwDMDimXpertCompoundNotchFeature members](#).

Public Methods

Name	Description
 GetBottomFeature	Gets the DimXpert feature at the bottom of this DimXpert compound notch.
 GetEndFeature	Gets the DimXpert feature at the closed end of this DimXpert compound notch.
 GetNominalBottomPlane	Gets the coordinates and vector for the plane at the bottom of this DimXpert compound notch.
 GetNominalNotch	Gets various attributes for this DimXpert compound notch.
 GetOpenSideReferenceFeature	Gets the DimXpert reference feature on the open side of this DimXpert compound notch.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound notch.
 GetTopReferenceFeature	Gets the DimXpert reference feature at the top of this DimXpert compound notch.

[Top](#)

See Also

[ISwDMDimXpertCompoundNotchFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCompoundNotchFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundNotchFeature Interface

For a list of all members of this type, see [ISwDMDimXpertCompoundNotchFeature members](#).

Public Properties

Name	Description
 Blind	Gets whether this DimXpert compound notch is blind or through all.

[Top](#)

See Also

Blind Property (ISwMDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompoundNotchFeature Interface](#) : Blind Property (ISwMDimXpertCompoundNotchFeature)

Gets whether this DimXpert compound notch is blind or through all.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Blind As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompoundNotchFeature  
Dim value As System.Boolean  
  
value = instance.Blind
```

C#

```
System.bool Blind {get;}
```

C++/CLI

```
property System.bool Blind {  
    System.bool get();  
}
```

Property Value

True if the compound notch is blind; false if through all

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompoundNotchFeature::Blind](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompoundNotchFeature Interface](#)
[ISwMDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetBottomFeature Method (ISwMDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompoundNotchFeature Interface](#) : GetBottomFeature Method (ISwMDimXpertCompoundNotchFeature)

Gets the DimXpert feature at the bottom of this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBottomFeature() As SwMDimXpertFeature
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertCompoundNotchFeature  
Dim value As SwDMDimXpertFeature  
  
value = instance.GetBottomFeature()
```

C#

```
SwDMDimXpertFeature GetBottomFeature()
```

C++/CLI

```
SwDMDimXpertFeature^ GetBottomFeature();
```

Return Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundNotchFeature::GetBottomFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundNotchFeature Interface](#)
[ISwDMDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetEndFeature Method (ISwDMDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundNotchFeature Interface](#) : GetEndFeature Method (ISwDMDimXpertCompoundNotchFeature)

Gets the DimXpert feature at the closed end of this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndFeature() As SwDMDimXpertFeature
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertCompoundNotchFeature  
Dim value As SwDMDimXpertFeature  
  
value = instance.GetEndFeature()
```

C#

```
SwDMDimXpertFeature GetEndFeature()
```

C++/CLI

```
SwDMDimXpertFeature^ GetEndFeature();
```

Return Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundNotchFeature::GetEndFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundNotchFeature Interface](#)
[ISwDMDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalBottomPlane Method (ISwDMDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundNotchFeature Interface](#) : GetNominalBottomPlane Method (ISwDMDimXpertCompoundNotchFeature)

Gets the coordinates and vector for the plane at the bottom of this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalBottomPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundNotchFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalBottomPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalBottomPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalBottomPlane(  
& [Out] System.double X,  
& [Out] System.double Y,
```

```
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

[X](#)
x coordinate of the bottom plane
[Y](#)
y coordinate of the bottom plane
[Z](#)
z coordinate of the bottom plane
[I](#)
i component of the direction vector of the bottom plane
[J](#)
j component of the direction vector of the bottom plane
[K](#)
k component of the direction vector of the bottom plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundNotchFeature::GetNominalBottomPlane](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundNotchFeature Interface](#)
[ISwDMDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalNotch Method (ISwDMDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundNotchFeature Interface](#) : GetNominalNotch Method (ISwDMDimXpertCompoundNotchFeature)

Gets various attributes for this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalNotch( _  
    ByRef width As System.Double, _  
    ByRef Length As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double, _  
    ByRef LongitudeI As System.Double, _  
    ByRef LongitudeJ As System.Double, _  
    ByRef LongitudeK As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundNotchFeature  
Dim width As System.Double
```

```

Dim Length As System.Double
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim LongitudeI As System.Double
Dim LongitudeJ As System.Double
Dim LongitudeK As System.Double
Dim value As System.Boolean

```

```

value = instance.GetNominalNotch(width, Length, X, Y, Z, I, J, K, LongitudeI, LongitudeJ, LongitudeK)

```

C#

```

System.bool GetNominalNotch(
    out System.double width,
    out System.double Length,
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K,
    out System.double LongitudeI,
    out System.double LongitudeJ,
    out System.double LongitudeK
)

```

C++/CLI

```

System.bool GetNominalNotch(
& [Out] System.double width,
& [Out] System.double Length,
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K,
& [Out] System.double LongitudeI,
& [Out] System.double LongitudeJ,
& [Out] System.double LongitudeK
)

```

Parameters

width
Width of the compound notch

Length
Length of the compound notch

X
x coordinate of the compound notch

Y
y coordinate of the compound notch

Z
z coordinate of the compound notch

I
i component of the direction vector of the compound notch

J
j component of the direction vector of the compound notch

K
k component of the direction vector of the compound notch

LongitudeI
i component of the longitudinal unit vector of the closed slot

LongitudeJ
j component of the longitudinal unit vector of the closed slot

LongitudeK
k component of the longitudinal unit vector of the closed slot

Return Value

True if method call is successful; false otherwise

See [ISwDMDimXpertCompoundNotchFeature::GetNominalNotch](#).

Example

See the examples on the interface page.

Remarks

The i, j, and k components of the longitudinal vector indicate the direction of a feature's length with respect to its part axes. For example, if the length of a feature goes along the y-axis of the part, its longitudinal vector is (0, 1, 0).

See Also

[ISwDMDimXpertCompoundNotchFeature Interface](#)
[ISwDMDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetOpenSideReferenceFeature Method (ISwDMDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundNotchFeature Interface](#) : GetOpenSideReferenceFeature Method (ISwDMDimXpertCompoundNotchFeature)

Gets the DimXpert reference feature on the open side of this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOpenSideReferenceFeature() As SwDMDimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundNotchFeature  
Dim value As SwDMDimXpertFeature
```

```
value = instance.GetOpenSideReferenceFeature()
```

C#

```
SwDMDimXpertFeature GetOpenSideReferenceFeature()
```

C++/CLI

```
SwDMDimXpertFeature^ GetOpenSideReferenceFeature();
```

Return Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundNotchFeature::GetOpenSideReferenceFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundNotchFeature Interface](#)
[ISwDMDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPlaneFeatures Method (ISwDMDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundNotchFeature Interface](#) : GetPlaneFeatures Method (ISwDMDimXpertCompoundNotchFeature)

Gets the DimXpert plane features for both sides of this DimXpert compound notch.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeatures( _  
    ByRef Plane1 As SwDMDimXpertPlaneFeature, _  
    ByRef Plane2 As SwDMDimXpertPlaneFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundNotchFeature  
Dim Plane1 As SwDMDimXpertPlaneFeature  
Dim Plane2 As SwDMDimXpertPlaneFeature  
Dim value As System.Boolean  
  
value = instance.GetPlaneFeatures(Plane1, Plane2)
```

C#

```
System.bool GetPlaneFeatures(  
    out SwDMDimXpertPlaneFeature Plane1,  
    out SwDMDimXpertPlaneFeature Plane2  
)
```

C++/CLI

```
System.bool GetPlaneFeatures(  
& [Out] SwDMDimXpertPlaneFeature^ Plane1,  
& [Out] SwDMDimXpertPlaneFeature^ Plane2  
)
```

Parameters

Plane1
[ISwDMDimXpertPlaneFeature](#)
Plane2
[ISwDMDimXpertPlaneFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundNotchFeature::GetPlaneFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundNotchFeature Interface](#)
[ISwDMDimXpertCompoundNotchFeature Members](#)

Availability

GetTopReferenceFeature Method (ISwMDimXpertCompoundNotchFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertCompoundNotchFeature Interface](#) : GetTopReferenceFeature Method (ISwMDimXpertCompoundNotchFeature)

Gets the DimXpert reference feature at the top of this DimXpert compound notch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTopReferenceFeature() As SwMDimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCompoundNotchFeature  
Dim value As SwMDimXpertFeature  
  
value = instance.GetTopReferenceFeature()
```

C#

```
SwMDimXpertFeature GetTopReferenceFeature()
```

C++/CLI

```
SwMDimXpertFeature^ GetTopReferenceFeature();
```

Return Value

[ISwMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCompoundNotchFeature::GetTopReferenceFeature](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCompoundNotchFeature Interface](#)
[ISwMDimXpertCompoundNotchFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCompoundWidthFeature (Type)

ISwDMDimXpertCompoundWidthFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundWidthFeature Interface

Allows you to access specific information about DimXpert compound widths.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertCompoundWidthFeature

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertCompoundWidthFeature](#)

C#

public interface ISwDMDimXpertCompoundWidthFeature

C++/CLI

public interface class ISwDMDimXpertCompoundWidthFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundWidthFeature](#).

Example

[Get DimXpert Compound Width and Best Fit Plane Features \(VB.NET\)](#)
[Get DimXpert Compound Width and Best Fit Plane Features \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertCompoundWidthFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCompoundWidthFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundWidthFeature Interface

For a list of all members of this type, see [ISwDMDimXpertCompoundWidthFeature members](#).

Public Methods

Name	Description
 GetNominalCompoundWidth	Gets the coordinates and vector for this DimXpert compound width.
 GetNominalLongitude	Gets the longitudinal vector for this DimXpert compound width.
GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound width.



[Top](#)

See Also

[ISwDMDimXpertCompoundWidthFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertCompoundWidthFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundWidthFeature Interface

The following tables list the members exposed by [ISwDMDimXpertCompoundWidthFeature](#).

Public Properties

Name	Description
 Inner	Gets whether this compound width is for a hole or a pin.

[Top](#)

Public Methods

Name	Description
 GetNominalCompoundWidth	Gets the coordinates and vector for this DimXpert compound width.
 GetNominalLongitude	Gets the longitudinal vector for this DimXpert compound width.
 GetPlaneFeatures	Gets the DimXpert plane features for both sides of this DimXpert compound width.

[Top](#)

See Also

[ISwDMDimXpertCompoundWidthFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertCompoundWidthFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCompoundWidthFeature Interface

For a list of all members of this type, see [ISwDMDimXpertCompoundWidthFeature members](#).

Public Properties

Name	Description
 Inner	Gets whether this compound width is for a hole or a pin.

[Top](#)

See Also

[ISwDMDimXpertCompoundWidthFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetNominalCompoundWidth Method (ISwDMDimXpertCompoundWidthFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundWidthFeature Interface](#) : GetNominalCompoundWidth Method (ISwDMDimXpertCompoundWidthFeature)

Gets the coordinates and vector for this DimXpert compound width.

.NET Syntax

Visual Basic (Declaration)

```

Function GetNominalCompoundWidth( _
    ByRef width As System.Double, _
    ByRef X As System.Double, _
    ByRef Y As System.Double, _
    ByRef Z As System.Double, _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As ISwDMDimXpertCompoundWidthFeature
Dim width As System.Double
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetNominalCompoundWidth(width, X, Y, Z, I, J, K)

```

C#

```

System.bool GetNominalCompoundWidth(
    out System.double width,
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetNominalCompoundWidth(
    & [Out] System.double width,
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)

```

Parameters

width
Width of compound width

X
x coordinate of compound width

Y
y coordinate of compound width

Z
z coordinate of compound width

I
i component of the direction vector of compound width

J
j component of the direction vector of compound width

K
k component of the direction vector of compound width

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundWidthFeature::GetNominalCompoundWidth](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundWidthFeature Interface](#)
[ISwDMDimXpertCompoundWidthFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalLongitude Method (ISwDMDimXpertCompoundWidthFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundWidthFeature Interface](#) : GetNominalLongitude Method (ISwDMDimXpertCompoundWidthFeature)

Gets the longitudinal vector for this DimXpert compound width.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalLongitude( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundWidthFeature  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalLongitude(I, J, K)
```

C#

```
System.bool GetNominalLongitude(  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalLongitude(  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

I
i component of longitudinal unit vector of compound width
J
j component of longitudinal unit vector of compound width
K
k component of longitudinal unit vector of compound width

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundWidthFeature::GetNominalLongitude](#).

Example

See the examples on the interface page.

Remarks

The i, j, and k components of the longitudinal vector indicate the direction of a feature's length with respect to its part axes. For example, if the length of a feature goes along the y-axis of the part, its longitudinal vector is (0, 1, 0).

See Also

[ISwDMDimXpertCompoundWidthFeature Interface](#)
[ISwDMDimXpertCompoundWidthFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPlaneFeatures Method (ISwDMDimXpertCompoundWidthFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundWidthFeature Interface](#) : GetPlaneFeatures Method (ISwDMDimXpertCompoundWidthFeature)

Gets the DimXpert plane features for both sides of this DimXpert compound width.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeatures( _  
    ByRef Plane1 As SwDMDimXpertPlaneFeature, _  
    ByRef Plane2 As SwDMDimXpertPlaneFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundWidthFeature  
Dim Plane1 As SwDMDimXpertPlaneFeature  
Dim Plane2 As SwDMDimXpertPlaneFeature  
Dim value As System.Boolean  
  
value = instance.GetPlaneFeatures(Plane1, Plane2)
```

C#

```
System.bool GetPlaneFeatures(  
    out SwDMDimXpertPlaneFeature Plane1,  
    out SwDMDimXpertPlaneFeature Plane2  
)
```

C++/CLI

```
System.bool GetPlaneFeatures(  
& [Out] SwDMDimXpertPlaneFeature^ Plane1,  
& [Out] SwDMDimXpertPlaneFeature^ Plane2  
)
```

Parameters

Plane1
[ISwDMDimXpertPlaneFeature](#)
Plane2
[ISwDMDimXpertPlaneFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundWidthFeature::GetPlaneFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCompoundWidthFeature Interface](#)
[ISwDMDimXpertCompoundWidthFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Inner Property (ISwDMDimXpertCompoundWidthFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCompoundWidthFeature Interface](#) : Inner Property (ISwDMDimXpertCompoundWidthFeature)

Gets whether this compound width is for a hole or a pin.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Inner As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCompoundWidthFeature  
Dim value As System.Boolean
```

```
value = instance.Inner
```

C#

```
System.bool Inner {get;}
```

C++/CLI

```
property System.bool Inner {  
    System.bool get();  
}
```

Property Value

True if width is for a hole; false if for a pin

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCompoundWidthFeature::Inner](#).

Example

See the examples on the interface page.

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertConcentricityGeoTol (Type)

ISwDMDimXpertConcentricityGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConcentricityGeoTol Interface

Allows you to access DimXpert concentricity geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertConcentricityGeoTol

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertConcentricityGeoTol](#)

C#

public interface ISwDMDimXpertConcentricityGeoTol

C++/CLI

public interface class ISwDMDimXpertConcentricityGeoTol

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConcentricityGeoTol](#).

Example

[Get DimXpert Tolerance5 \(VB.NET\)](#)
[Get DimXpert Tolerance5 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertConcentricityGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertConcentricityGeoTol Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConcentricityGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertConcentricityGeoTol members](#).

Public Methods

Name	Description
 GetMaxTolerance	Gets the maximum tolerance for this DimXpert concentricity geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertConcentricityGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertConcentricityGeoTol Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConcentricityGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertConcentricityGeoTol](#).

Public Properties

Name	Description
 Modifier	Gets the material condition modifier for this DimXpert concentricity geometric tolerance.

[Top](#)

Public Methods

Name	Description
 GetMaxTolerance	Gets the maximum tolerance for this DimXpert concentricity geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertConcentricityGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertConcentricityGeoTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConcentricityGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertConcentricityGeoTol members](#).

Public Properties

Name	Description
 Modifier	Gets the material condition modifier for this DimXpert concentricity geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertConcentricityGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetMaxTolerance Method (ISwDMDimXpertConcentricityGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertConcentricityGeoTol Interface](#) : GetMaxTolerance Method (ISwDMDimXpertConcentricityGeoTol)

Gets the maximum tolerance for this DimXpert concentricity geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMaxTolerance( _  
    ByRef IsMax As System.Boolean, _  
    ByRef Tolerance As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertConcentricityGeoTol
Dim IsMax As System.Boolean
Dim Tolerance As System.Double
Dim value As System.Boolean
```

```
value = instance.GetMaxTolerance(IsMax, Tolerance)
```

C#

```
System.bool GetMaxTolerance(
    out System.bool IsMax,
    out System.double Tolerance
)
```

C++/CLI

```
System.bool GetMaxTolerance(
    & [Out] System.bool IsMax,
    & [Out] System.double Tolerance
)
```

Parameters

IsMax
True, if maximum tolerance is set; false, otherwise
Tolerance
Maximum tolerance

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConcentricityGeoTol::GetMaxTolerance](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertConcentricityGeoTol Interface](#)
[ISwDMDimXpertConcentricityGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Modifier Property (ISwDMDimXpertConcentricityGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertConcentricityGeoTol Interface](#) : Modifier Property (ISwDMDimXpertConcentricityGeoTol)

Gets the material condition modifier for this DimXpert concentricity geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Modifier As swDmDimXpertMaterialConditionModifier\_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertConcentricityGeoTol  
Dim value As swDmDimXpertMaterialConditionModifier\_e  
  
value = instance.Modifier
```

C#

```
swDmDimXpertMaterialConditionModifier\_e Modifier {get;}
```

C++/CLI

```
property swDmDimXpertMaterialConditionModifier\_e Modifier {  
    swDmDimXpertMaterialConditionModifier\_e get();  
}
```

Property Value

Material condition modifier for the concentricity tolerance as defined in [swDmDimXpertMaterialConditionModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConcentricityGeoTol::Modifier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertConcentricityGeoTol Interface](#)
[ISwDMDimXpertConcentricityGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertConeAngleDimTol (Type)

ISwDMDimXpertConeAngleDimTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConeAngleDimTol Interface

Allows you to access tolerance information for DimXpert cone angle dimensions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertConeAngleDimTol
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertConeAngleDimTol
```

C#

```
public interface ISwDMDimXpertConeAngleDimTol
```

C++/CLI

```
public interface class ISwDMDimXpertConeAngleDimTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConeAngleDimTol](#).

Example

[Get DimXpert Cone Feature \(VB.NET\)](#)
[Get DimXpert Cone Feature \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertDimensionTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertConeAngleDimTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertConeAngleDimTol Interface Members

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConeAngleDimTol Interface

The following tables list the members exposed by [ISwDMDimXpertConeAngleDimTol](#).

See Also

[ISwDMDimXpertConeAngleDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertConeFeature (Type)

ISwDMDimXpertConeFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConeFeature Interface

Allows you to access specific information about DimXpert cones.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertConeFeature

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertConeFeature](#)

C#

public interface ISwDMDimXpertConeFeature

C++/CLI

public interface class ISwDMDimXpertConeFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConeFeature](#).

Example

[Get DimXpert Cone Feature \(VB.NET\)](#)
[Get DimXpert Cone Feature \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertConeFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertConeFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConeFeature Interface

For a list of all members of this type, see [ISwDMDimXpertConeFeature members](#).

Public Methods

Name	Description
 GetNominalBottomPlane	Gets the coordinates and vector for the plane at the bottom of this DimXpert cone.
 GetNominalCone	Gets various attributes for this DimXpert cone.
 GetNominalTopPlane	Gets the coordinates and vector for the plane at the top of this DimXpert cone.



[Top](#)

See Also

[ISwDMDimXpertConeFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertConeFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConeFeature Interface

The following tables list the members exposed by [ISwDMDimXpertConeFeature](#).

Public Properties

Name	Description
 Inner	Gets whether this DimXpert cone is a hole or a pin.

[Top](#)

Public Methods

Name	Description
 GetNominalBottomPlane	Gets the coordinates and vector for the plane at the bottom of this DimXpert cone.
 GetNominalCone	Gets various attributes for this DimXpert cone.
 GetNominalTopPlane	Gets the coordinates and vector for the plane at the top of this DimXpert cone.

[Top](#)

See Also

[ISwDMDimXpertConeFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertConeFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertConeFeature Interface

For a list of all members of this type, see [ISwDMDimXpertConeFeature members](#).

Public Properties

Name	Description
 Inner	Gets whether this DimXpert cone is a hole or a pin.

[Top](#)

See Also

[ISwDMDimXpertConeFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetNominalBottomPlane Method (ISwDMDimXpertConeFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertConeFeature Interface](#) : GetNominalBottomPlane Method (ISwDMDimXpertConeFeature)

Gets the coordinates and vector for the plane at the bottom of this DimXpert cone.

.NET Syntax

Visual Basic (Declaration)

```

Function GetNominalBottomPlane( _
    ByRef X As System.Double, _
    ByRef Y As System.Double, _
    ByRef Z As System.Double, _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As ISwDMDimXpertConeFeature
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

```

```
value = instance.GetNominalBottomPlane(X, Y, Z, I, J, K)
```

C#

```

System.bool GetNominalBottomPlane(
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)

```

C++/CLI

```

System.bool GetNominalBottomPlane(
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)

```

Parameters

X
x coordinate of the bottom plane

Y
y coordinate of the bottom plane

Z
z coordinate of the bottom plane

I
i component of the direction vector of the bottom plane

J
j component of the direction vector of the bottom plane

K
k component of the direction vector of the bottom plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConeFeature::GetNominalBottomPlane](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertConeFeature Interface](#)
[ISwDMDimXpertConeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalCone Method (ISwDMDimXpertConeFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertConeFeature Interface](#) : GetNominalCone Method (ISwDMDimXpertConeFeature)

Gets various attributes for this DimXpert cone.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalCone( _  
    ByRef Angle As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertConeFeature  
Dim Angle As System.Double  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalCone(Angle, X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalCone(  
    out System.double Angle,  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalCone(  
& [Out] System.double Angle,  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

Angle

Angle in radians of the cone

X

x coordinate of the cone

Y

y coordinate of the cone

Z

z coordinate of the cone

I

i component of the direction vector of the cone

J

j component of the direction vector of the cone

K

k component of the direction vector of the cone

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConeFeature::GetNominalCone](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertConeFeature Interface](#)

[ISwDMDimXpertConeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalTopPlane Method (ISwDMDimXpertConeFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertConeFeature Interface](#) : GetNominalTopPlane Method (ISwDMDimXpertConeFeature)

Gets the coordinates and vector for the plane at the top of this DimXpert cone.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalTopPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertConeFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalTopPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalTopPlane(
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)
```

C++/CLI

```
System.bool GetNominalTopPlane(
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)
```

Parameters

X
x coordinate of the top plane
Y
y coordinate of the top plane
Z
z coordinate of the top plane
I
i component of the direction vector of the top plane
J
j component of the direction vector of the top plane
K
k component of the direction vector of the top plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConeFeature::GetNominalTopPlane](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertConeFeature Interface](#)
[ISwDMDimXpertConeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Inner Property (ISwDMDimXpertConeFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertConeFeature Interface](#) : Inner Property (ISwDMDimXpertConeFeature)

Gets whether this DimXpert cone is a hole or a pin.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Inner As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertConeFeature  
Dim value As System.Boolean  
  
value = instance.Inner
```

C#

```
System.bool Inner {get;}
```

C++/CLI

```
property System.bool Inner {  
    System.bool get();  
}
```

Property Value

True if the cone is a hole; false if it's a pin

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertConeFeature::Inner](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertConeFeature Interface](#)
[ISwDMDimXpertConeFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCounterBoreDimTol (Type)

ISwDMDimXpertCounterBoreDimTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCounterBoreDimTol Interface

Allows you to access tolerance information for DimXpert counterbore dimensions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCounterBoreDimTol
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCounterBoreDimTol
```

C#

```
public interface ISwDMDimXpertCounterBoreDimTol
```

C++/CLI

```
public interface class ISwDMDimXpertCounterBoreDimTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCounterBoreDimTol](#).

Example

[Get DimXpert Tolerance \(VB.NET\)](#)
[Get DimXpert Tolerance \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertDimensionTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertCounterBoreDimTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCounterBoreDimTol Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCounterBoreDimTol Interface

The following tables list the members exposed by [ISwDMDimXpertCounterBoreDimTol](#).

Public Properties

Name	Description
ReferenceFeature	Gets the DimXpert reference feature for this DimXpert counterbore dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertCounterBoreDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertCounterBoreDimTol Interface Properties

[See Also](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCounterBoreDimTol Interface

For a list of all members of this type, see [ISwDMDimXpertCounterBoreDimTol members](#).

Public Properties

Name	Description
 ReferenceFeature	Gets the DimXpert reference feature for this DimXpert counterbore dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertCounterBoreDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ReferenceFeature Property (ISwDMDimXpertCounterBoreDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCounterBoreDimTol Interface](#) : ReferenceFeature Property (ISwDMDimXpertCounterBoreDimTol)

Gets the DimXpert reference feature for this DimXpert counterbore dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ReferenceFeature As SwDMDimXpertFeature

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCounterBoreDimTol  
Dim value As SwDMDimXpertFeature  
  
value = instance.ReferenceFeature
```

C#

```
SwDMDimXpertFeature ReferenceFeature {get;}
```

C++/CLI

```
property SwDMDimXpertFeature^ ReferenceFeature {  
    SwDMDimXpertFeature^ get();  
}
```

Property Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCounterBoreDimTol::ReferenceFeature](#).

Example

See the examples on the interface page.

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCounterSinkAngleDimTol (Type)

ISwDMDimXpertCounterSinkAngleDimTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCounterSinkAngleDimTol Interface

Allows you to access tolerance information for DimXpert countersink angle dimensions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCounterSinkAngleDimTol
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertCounterSinkAngleDimTol
```

C#

```
public interface ISwDMDimXpertCounterSinkAngleDimTol
```

C++/CLI

```
public interface class ISwDMDimXpertCounterSinkAngleDimTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCounterSinkAngleDimTol](#).

Example

[Get DimXpert Tolerance1 \(VB.NET\)](#)
[Get DimXpert Tolerance1 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertDimensionTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertCounterSinkAngleDimTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCounterSinkAngleDimTol Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCounterSinkAngleDimTol Interface

The following tables list the members exposed by [ISwDMDimXpertCounterSinkAngleDimTol](#).

Public Properties

Name	Description
ReferenceFeature	Gets the DimXpert reference feature for this DimXpert countersink angle dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertCounterSinkAngleDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertCounterSinkAngleDimTol Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCounterSinkAngleDimTol Interface

For a list of all members of this type, see [ISwDMDimXpertCounterSinkAngleDimTol members](#).

Public Properties

Name	Description
 ReferenceFeature	Gets the DimXpert reference feature for this DimXpert countersink angle dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertCounterSinkAngleDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ReferenceFeature Property (ISwDMDimXpertCounterSinkAngleDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCounterSinkAngleDimTol Interface](#) : ReferenceFeature Property (ISwDMDimXpertCounterSinkAngleDimTol)

Gets the DimXpert reference feature for this DimXpert countersink angle dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ReferenceFeature As SwDMDimXpertFeature

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCounterSinkAngleDimTol  
Dim value As SwDMDimXpertFeature  
  
value = instance.ReferenceFeature
```

C#

```
SwDMDimXpertFeature ReferenceFeature {get;}
```

C++/CLI

```
property SwDMDimXpertFeature^ ReferenceFeature {  
    SwDMDimXpertFeature^ get();  
}
```

Property Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCounterSinkAngleDimTol::ReferenceFeature](#).

Example

See the examples on the interface page.

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCounterSinkDiameterDimTol (Type)

ISwDMDimXpertCounterSinkDiameterDimTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertCounterSinkDiameterDimTol Interface

Allows you to access tolerance information for DimXpert countersink diameter dimensions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCounterSinkDiameterDimTol
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertCounterSinkDiameterDimTol
```

C#

```
public interface ISwDMDimXpertCounterSinkDiameterDimTol
```

C++/CLI

```
public interface class ISwDMDimXpertCounterSinkDiameterDimTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCounterSinkDiameterDimTol](#).

Example

[Get DimXpert Tolerance1 \(VB.NET\)](#)
[Get DimXpert Tolerance1 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertDimensionTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertCounterSinkDiameterDimTol Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)

ISwDMDimXpertCounterSinkDiameterDimTol Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertCounterSinkDiameterDimTol Interface

The following tables list the members exposed by [ISwDMDimXpertCounterSinkDiameterDimTol](#).

Public Properties

Name	Description
 ReferenceFeature	Gets the DimXpert reference feature for this DimXpert countersink diameter dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertCounterSinkDiameterDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertCounterSinkDiameterDimTol Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCounterSinkDiameterDimTol Interface

For a list of all members of this type, see [ISwDMDimXpertCounterSinkDiameterDimTol members](#).

Public Properties

Name	Description
 ReferenceFeature	Gets the DimXpert reference feature for this DimXpert countersink diameter dimension tolerance.

[Top](#)

See Also

[ISwDMDimXpertCounterSinkDiameterDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ReferenceFeature Property (ISwDMDimXpertCounterSinkDiameterDimTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCounterSinkDiameterDimTol Interface](#) : ReferenceFeature Property (ISwDMDimXpertCounterSinkDiameterDimTol)

Gets the DimXpert reference feature for this DimXpert countersink diameter dimension tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceFeature As SwDMDimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCounterSinkDiameterDimTol  
Dim value As SwDMDimXpertFeature  
  
value = instance.ReferenceFeature
```

C#

```
SwDMDimXpertFeature ReferenceFeature {get;}
```

C++/CLI

```
property SwDMDimXpertFeature^ ReferenceFeature {  
    SwDMDimXpertFeature^ get();  
}
```

Property Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCounterSinkDiameterDimTol::ReferenceFeature](#).

Example

See the examples on the interface page.

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCylinderFeature (Type)

ISwDMDimXpertCylinderFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCylinderFeature Interface

Allows you to access specific information about DimXpert cylinders.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertCylinderFeature
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertCylinderFeature
```

C#

```
public interface ISwDMDimXpertCylinderFeature
```

C++/CLI

```
public interface class ISwDMDimXpertCylinderFeature
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCylinderFeature](#).

Example

[Get DimXpert Feature \(VB.NET\)](#)
[Get DimXpert Feature \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertCylinderFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCylinderFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCylinderFeature Interface

The following tables list the members exposed by [ISwDMDimXpertCylinderFeature](#).

Public Properties

Name	Description
 Inner	Gets whether this DimXpert cylinder is a hole or a pin.

[Top](#)

Public Methods

Name	Description
 GetNominalBottomPlane	Gets the coordinates and vector for the plane at the bottom of this DimXpert cylinder.
 GetNominalCylinder	Gets various attributes for this DimXpert cylinder.
 GetNominalTopPlane	Gets the coordinates and vector for the plane at the top of this DimXpert cylinder.
 GetThread	Gets thread information for this DimXpert cylinder.

[Top](#)

See Also

[ISwDMDimXpertCylinderFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCylinderFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCylinderFeature Interface

For a list of all members of this type, see [ISwDMDimXpertCylinderFeature members](#).

Public Methods

Name	Description
 GetNominalBottomPlane	Gets the coordinates and vector for the plane at the bottom of this DimXpert cylinder.
 GetNominalCylinder	Gets various attributes for this DimXpert cylinder.
 GetNominalTopPlane	Gets the coordinates and vector for the plane at the top of this DimXpert cylinder.
 GetThread	Gets thread information for this DimXpert cylinder.

[Top](#)

See Also

[ISwDMDimXpertCylinderFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertCylinderFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCylinderFeature Interface

For a list of all members of this type, see [ISwDMDimXpertCylinderFeature members](#).

Public Properties

Name	Description
 Inner	Gets whether this DimXpert cylinder is a hole or a pin.

[Top](#)

See Also

[ISwDMDimXpertCylinderFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalBottomPlane Method (ISwDMDimXpertCylinderFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCylinderFeature Interface](#) : GetNominalBottomPlane Method (ISwDMDimXpertCylinderFeature)

Gets the coordinates and vector for the plane at the bottom of this DimXpert cylinder.

Visual Basic (Declaration)

```
Function GetNominalBottomPlane( _
    ByRef X As System.Double, _
    ByRef Y As System.Double, _
    ByRef Z As System.Double, _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCylinderFeature
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetNominalBottomPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalBottomPlane(
    out System.double X,
    out System.double Y,
    out System.double Z,
    out System.double I,
    out System.double J,
    out System.double K
)
```

C++/CLI

```
System.bool GetNominalBottomPlane(
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z,
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)
```

Parameters

X
x coordinate of the bottom plane

Y
y coordinate of the bottom plane

Z
z coordinate of the bottom plane

I
i component of the direction vector of the bottom plane

J
j component of the direction vector of the bottom plane

K
k component of the direction vector of the bottom plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCylinderFeature::GetNominalBottomPlane](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCylinderFeature Interface](#)
[ISwDMDimXpertCylinderFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalCylinder Method (ISwDMDimXpertCylinderFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCylinderFeature Interface](#) : GetNominalCylinder Method (ISwDMDimXpertCylinderFeature)

Gets various attributes for this DimXpert cylinder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalCylinder( _  
    ByRef R As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCylinderFeature  
Dim R As System.Double  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalCylinder(R, X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalCylinder(  
    out System.double R,  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalCylinder(  
& [Out] System.double R,  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,
```

```
& [Out] System.Double K  
)
```

Parameters

R
Radius of cylinder
X
x coordinate of the cylinder
Y
y coordinate of the cylinder
Z
z coordinate of the cylinder
I
i component of the direction vector of the cylinder
J
j component of the direction vector of the cylinder
K
k component of the direction vector of the cylinder

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCylinderFeature::GetNominalCylinder](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCylinderFeature Interface](#)
[ISwDMDimXpertCylinderFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalTopPlane Method (ISwDMDimXpertCylinderFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCylinderFeature Interface](#) : GetNominalTopPlane Method (ISwDMDimXpertCylinderFeature)

Gets the coordinates and vector for the plane at the top of this DimXpert cylinder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalTopPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCylinderFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalTopPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalTopPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalTopPlane(  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

X
x coordinate of the top plane
Y
y coordinate of the top plane
Z
z coordinate of the top plane
I
i component of the direction vector of the top plane
J
j component of the direction vector of the top plane
K
k component of the direction vector of the top plane

Return Value

True if method call is successful; false otherwise

 Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCylinderFeature::GetNominalTopPlane](#).

 Example

See the examples on the interface page.

 See Also

[ISwDMDimXpertCylinderFeature Interface](#)
[ISwDMDimXpertCylinderFeature Members](#)

 Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetThread Method (ISwDMDimXpertCylinderFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCylinderFeature Interface](#) : GetThread Method (ISwDMDimXpertCylinderFeature)

Gets thread information for this DimXpert cylinder.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetThread( _
    ByRef IsThreaded As System.Boolean, _
    ByRef ThreadDesignation As System.String, _
    ByRef ThreadDepth As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertCylinderFeature
Dim IsThreaded As System.Boolean
Dim ThreadDesignation As System.String
Dim ThreadDepth As System.Double
Dim value As System.Boolean

value = instance.GetThread(IsThreaded, ThreadDesignation, ThreadDepth)
```

C#

```
System.bool GetThread(
    out System.bool IsThreaded,
    out System.string ThreadDesignation,
    out System.double ThreadDepth
)
```

C++/CLI

```
System.bool GetThread(
    & [Out] System.bool IsThreaded,
    & [Out] System.String^ ThreadDesignation,
    & [Out] System.double ThreadDepth
)
```

Parameters

IsThreaded

True if the cylinder is threaded; false otherwise

ThreadDesignation

Description of the thread

ThreadDepth

Depth of the thread for a threaded cylindrical hole

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCylinderFeature::GetThread](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertCylinderFeature Interface](#)

[ISwDMDimXpertCylinderFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Inner Property (ISwDMDimXpertCylinderFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertCylinderFeature Interface](#) : Inner Property (ISwDMDimXpertCylinderFeature)

Gets whether this DimXpert cylinder is a hole or a pin.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Inner As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertCylinderFeature  
Dim value As System.Boolean  
  
value = instance.Inner
```

C#

```
System.bool Inner {get;}
```

C++/CLI

```
property System.bool Inner {  
    System.bool get();  
}
```

Property Value

True if the cylinder is a hole; false if it's a pin

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertCylinderFeature::Inner](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertCylinderFeature Interface](#)
[ISwMDimXpertCylinderFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertCylindricityGeoTol (Type)

ISwDMDimXpertCylindricityGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCylindricityGeoTol Interface

Allows you to access DimXpert cylindricity geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertCylindricityGeoTol

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertCylindricityGeoTol](#)

C#

public interface ISwDMDimXpertCylindricityGeoTol

C++/CLI

public interface class ISwDMDimXpertCylindricityGeoTol

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertCylindricityGeoTol](#).

Example

[Get DimXpert Tolerance1 \(VB.NET\)](#)
[Get DimXpert Tolerance1 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertCylindricityGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertCylindricityGeoTol Interface Members

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertCylindricityGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertCylindricityGeoTol](#).

See Also

[ISwDMDimXpertCylindricityGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertDatum (Type)

ISwDMDimXpertDatum Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertDatum Interface

Allows you to access information about DimXpert datums.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertDatum

Visual Basic (Usage)

Dim instance As [ISwDMDimXpertDatum](#)

C#

public interface ISwDMDimXpertDatum

C++/CLI

public interface class ISwDMDimXpertDatum

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertDatum](#).

Example

[Get DimXpert Sphere and Datum \(VB.NET\)](#)
[Get DimXpert Sphere and Datum \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertAnnotation](#).

Accessors

[ISwDMDimXpertGeometricTolerance::GetPrimaryDatums](#), [ISwDMDimXpertGeometricTolerance::!GetPrimaryDatums](#),
[ISwDMDimXpertGeometricTolerance::GetSecondaryDatums](#), [ISwDMDimXpertGeometricTolerance::!GetSecondaryDatums](#),
[ISwDMDimXpertGeometricTolerance::GetTertiaryDatums](#), [ISwDMDimXpertGeometricTolerance::!GetTertiaryDatums](#)
[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

[ISwDMDimXpertDatum Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)

ISwDMDimXpertDatum Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertDatum Interface

The following tables list the members exposed by [ISwDMDimXpertDatum](#).

Public Properties

Name	Description
Identifier	Gets the label for this DimXpert datum.



[Top](#)

See Also

[ISwMDimXpertDatum Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwMDimXpertDatum Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDimXpertDatum Interface

For a list of all members of this type, see [ISwMDimXpertDatum members](#).

Public Properties

Name	Description
 Identifier	Gets the label for this DimXpert datum.

[Top](#)

See Also

[ISwMDimXpertDatum Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Identifier Property (ISwMDimXpertDatum)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertDatum Interface](#) : Identifier Property (ISwMDimXpertDatum)

Gets the label for this DimXpert datum.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Identifier As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertDatum  
Dim value As System.String
```

```
value = instance.Identifier
```

C#

```
System.string Identifier {get;}
```

C++/CLI

```
property System.String^ Identifier {  
    System.String^ get();  
}
```

Property Value

Label for the datum

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertDatum.Identifier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertDatum Interface](#)
[ISwDMDimXpertDatum Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0